CHILTONLIBRARY



Front Carpet

FRONT CARPET

REMOVAL

- 1. Remove the load floor frame (Refer to Body/Interior/LOAD FLOOR, Frame/Removal and Installation).
- 2. Remove the front seats (Refer to Body/Seats/SEAT/Removal and Installation)(Refer To List 1).
- 3. Remove the floor console (Refer to Body/Interior/CONSOLE, Floor/Removal and Installation).
- 4. Remove the cowl side trim panel (Refer to 23 Body/Interior/PANEL, Cowl Trim, Side/Removal and Installation).
- 5. Remove the lower B-pillar trim panel (Refer to 23 Body/Interior/PANEL, B-Pillar Trim/Removal and Installation)(Refer To List 2).
- 6. Remove the floor console bracket.
- 7. Remove the module located under the driver side front seat, if equipped.
- 8. Remove the module located under the passenger side front seat, if equipped.
- 9. Remove the push fasteners at the front of the front floor carpet.
- 10. Remove the plastic nuts at the rear, then the front floor carpet.

INSTALLATION

- 1. Position the front floor carpet in the vehicle and install the push fasteners and plastic nuts.
- 2. Install the floor console bracket.
- 3. Install the module located under the driver side front seat, if equipped.
- 4. Install the module located under the passenger side front seat, if equipped.

- 5. Install the lower B-pillar trim panels (Refer to 23 Body/Interior/PANEL, B-Pillar Trim/Removal and Installation)(Refer To List 2).
- 6. Install the cowl side trim panels (Refer to 23 Body/Interior/PANEL, Cowl Trim, Side/Removal and Installation).
- 7. Install the floor console (Refer to Body/Interior/CONSOLE, Floor/Removal and Installation).
- 8. Install the front seats (Refer to Body/Seats/SEAT/Removal and Installation)(Refer To List 1).
- 9. Install the load floor frame (Refer to Body/Interior/LOAD FLOOR, Frame/Removal and Installation).

Refer To List:

List 1

- 23 Body / Seats, First Row / SEAT, Front / Removal and Installation
- 23 Body / Seats, Second Row, Stow-n-Go / SEAT, Stow-n-Go / Removal and Installation
- 23 Body / Seats, Third Row, Stow-n-Go / SEAT / Removal and Installation
- 23 Body / Seats, Third Row, Power Folding / SEAT / Removal and Installation

List 2

- 23 Body / Interior / PANEL, B-Pillar Trim, Lower / Removal and Installation
- 23 Body / Interior / PANEL, B-Pillar Trim, Upper / Removal and Installation