CHILTONLIBRARY



Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL

WARNING


Do not attempt to move or reposition the sunroof glass panel, the sunshade or the drive cables with the sunroof or sunshade motor and module unit removed. Damage to the vehicle, to the sunroof or personal injuries may result.

WARNING

The Sunroof Initialization and Obstacle Detection Calibration procedure must be completed any time a sunroof or sunshade motor and module unit is replaced with a new component or existing motor is removed and re-installed onto sunroof module. Failure to perform these procedures may result in damage to the vehicle, to the sunroof, to the sunshade or in serious or fatal injuries.

SUNROOF GLASS MOTOR


- 1. Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable.
- 2. Lower the headliner from the inner roof panel. (Refer to 23 Body/Interior/HEADLINER/Removal and Installation).



- 3. Disconnect the sunroof wire harness connector (1) from the sunroof glass motor (2).
- 4. Remove the three screws (3) that secure the sunroof glass motor to the sunroof frame.
- 5. Remove the sunroof glass motor (2) from the vehicle.

SUNSHADE MOTOR

- 1. Disconnect and isolate the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), disconnect the IBS connector first before disconnecting the negative battery cable.
- 2. Lower the headliner from the inner roof panel. (Refer to 23 Body/Interior/HEADLINER/Removal and Installation).



3. Disconnect the sunroof wire harness connector (1) from the sunshade motor (2).

- 4. Remove the three screws (3) that secure the sunshade motor to the sunroof frame.
- 5. Remove the sunshade motor (2) from the vehicle.


INSTALLATION

WARNING

Do not attempt to move or reposition the sunroof glass panel, the sunshade or the drive cables with the sunroof or sunshade motor and module unit removed. Damage to the vehicle, to the sunroof or personal injuries may result.

WARNING

The Sunroof Initialization and Obstacle Detection Calibration procedure must be completed any time a sunroof or sunshade motor and module unit is replaced with a new component or existing motor is removed and re-installed onto sunroof module. Failure to perform these procedures may result in damage to the vehicle, to the sunroof, to the sunshade or in serious or fatal injuries.




SUNROOF GLASS MOTOR

- 1. Position the sunroof glass motor (2) to the sunroof frame.
- 2. Install and tighten the three screws (3) that secure the motor to the sunroof frame. Tighten the screws to 3.8 N·m.
- 3. Connect the sunroof wire harness connector (1) to the sunroof glass motor (2).

- 4. Reinstall the headliner to the inner roof panel (Refer to 23 Body/Interior/HEADLINER/Removal and Installation).
- 5. Connect the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), connect the IBS connector to the negative battery cable.
- 6. Perform the Sunroof Initialization and Obstacle Detection Calibration. (Refer to Electrical/8N Power Systems/Power Top/MOTOR, Sunroof Standard Procedure).

SUNSHADE MOTOR



- 1. Position the sunshade motor (2) to the sunroof frame.
- 2. Install and tighten the three screws (3) that secure the motor to the sunroof frame. Tighten the screws to 3.8 N·m.
- 3. Connect the sunroof wire harness connector (1) to the sunshade motor (2).
- 4. Install the headliner to the inner roof panel (Refer to Body/Interior/HEADLINER/Removal and Installation).
- 5. Connect the negative battery cable. If equipped with an Intelligent Battery Sensor (IBS), connect the IBS connector to the negative battery cable.
- 6. Perform the Sunroof Initialization and Obstacle Detection Calibration. (Refer to Electrical/8N Power Systems/Power Top/MOTOR, Sunroof Standard Procedure).