CHILTONLIBRARY




Removal And Installation

REMOVAL AND INSTALLATION


REMOVAL

- 1. Disconnect and isolate the battery negative cable.
- 2. Remove the left D-pillar. (Refer to Body/Interior/PANEL, D-Pillar Trim/Removal and Installation).



- 3. Disconnect the electrical connector (2) from the switch (1).
- 4. Using a trim stick


Trim Stick



or equivalent, carefully depress the switch retaining tabs to separate the power liftgate switch from the D-Pillar.

INSTALLATION

1. Seat the liftgate switch into the D-pillar until all of the switch retaining clips are engaged.



- 2. Connect the wiring harness connector (2) to the liftgate switch (1).
- 3. Install the left D-pillar. (Refer to 23 Body/Interior/PANEL, D-Pillar Trim/Removal and Installation).
- 4. Connect the negative battery cable.