CHILTONLIBRARY



Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL



2319098220

- 1. Remove the second row, center seat from the vehicle.
- 2. By hand, pull to remove the front cover (1).



- 3. By hand, pull the cover (1) forward and outward to remove. Remove the screw behind this cover.
- 4. Remove the screws (3) and then the side cover (2). Do this on both sides of the seat.



- 5. Remove the headrest (1).
- 6. Using a trim stick, remove the cupholder and bin (2) as one unit.



- 7. Release the J-hooks (2).
- 8. Using a flat bladed tool, push the tab (1) and pull out the headrest guides.
- 9. Open the zipper (3) at the bottom of the cover.



- 10. Remove the seatback cover (1) from the seatback cushion as shown.
- 11. Remove the seatback cushion from the frame if necessary.

INSTALLATION



1. Install the cover (1) onto the seatback cushion (2).



- 2. Close the zipper (3) at the bottom of the cover.
- 3. Fasten the J-hooks (2).
- 4. Install the headrest guides (1).



5. Install the headrest (1) and cupholder (2).



- 6. Install the side covers (2) and the screws (3).
- 7. Install the screw behind the cover (1).
- 8. Position the cover (1) and push rearward to install.



2319098220

9. Install the front cover (1).