
CHILTONLIBRARY



Removal & Installation

REMOVAL AND INSTALLATION


REMOVAL






1304098884

- 1. Remove the engine belly pan (Refer to Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation).(Refer To List 1)
- 2. Twist and release the decking aid (4).
- 3. Remove the nuts (1)
- 4. Remove the belly pan closeout panel (2) and release the tab from the side belly pan (3).




- 5. Twist and release the three decking aids (1).
- 6. Remove the screw (3).
- 7. Remove the 11 nuts (2) on the left side.
- 8. Remove the 10 nuts (2) on the right side.
- 9. Remove the side belly pan.

INSTALLATION



- 1. Install the side belly pan and seat the three decking aids (1) fully.
- 2. Install the 10 nuts (2) on the right side belly pan.

- 3. Install the 11 nuts (2) on the left side belly pan.
- 4. Install the screw (3) and tighten all fasteners to the proper (Torque Specifications).



- 5. Position the tab into the slot (3) of the side belly pan and install the belly pan closeout panels.
- 6. Seat the decking aid (4) fully.
- 7. Install the two nuts and to the proper (Torque Specifications).
- 8. Install the engine belly pan (Refer to 13 Frame and Bumpers/Under Body Protection/BELLY PAN/Removal and Installation).(Refer To List 1)

Refer To List:

List 1

- 13 Frame and Bumpers / Under Body Protection / BELLY PAN, Engine / Removal and Installation
- 13 Frame and Bumpers / Under Body Protection / BELLY PAN, Front / Removal and Installation
- 13 Frame and Bumpers / Under Body Protection / BELLY PAN, Rear / Removal and Installation
- 13 Frame and Bumpers / Under Body Protection / BELLY PAN, Rear Suspension / Removal and Installation
- 13 Frame and Bumpers / Under Body Protection / BELLY PAN, Side / Removal and Installation