
CHILTONLIBRARY



Description & Operation

DESCRIPTION AND OPERATION


DESCRIPTION



0811098568

There is one dedicated Hands Free Entry (HFE) liftgate module (if equipped) (1) located mounted to the vehicle behind the rear fascia.

The HFE hardware and circuitry is contained and protected within a molded plastic housing that has two mounts and three wiring harness connection receptacles. There are two available designs. With trailer tow and without trailer tow. With trailer tow, the sensors and bracket are split to both sides of the trailer hitch



0811098570

The HFE module (1) cannot be adjusted or repaired and, if damaged or ineffective, the HFE module must be replaced.

OPERATION

(Refer to Electrical/Power Locks/Description and Operation) for operating characteristics of the Hands Free Entry (HFE) system.