CHILTONLIBRARY



Removal & Installation

REMOVAL AND INSTALLATION

REMOVAL



- 1. Using a small flat bladed tool, remove the cap (2) from the side of the armrest (1).
- 2. Remove the bolt and the armrest

INSTALLATION



- 1. Position the armrest (1) onto the seat.
- 2. Install the front seat armrest bolt and tighten to the proper (Torque Specifications).
- 3. Install the cap (2).