CHILTONLIBRARY



Without Trailer Tow

WITHOUT TRAILER TOW

REMOVAL

- 1. Disconnect and isolate the battery negative cable.
- 2. Remove the rear fascia. (Refer to Frame and Bumpers/Bumpers/FASCIA, Rear/Removal and Installation).
- 3. Disconnect the body wiring harness connector from the Hands Free Entry Power Liftgate (HFEPLG) module
- 4. Remove the fasteners securing the HFEPLG module with sensor assembly to the vehicle.
- 5. Remove the HFEPLG module with sensor from the vehicle.

INSTALLATION

- 1. Position the Hands Free Entry Power Liftgate (HFEPLG) module to the vehicle for installation.
- 2. Install the fasteners to secure the HFEPLG module with sensor to the vehicle.
- 3. Connect the wiring harness to the HFEPLG module.
- 4. Install the rear fascia. (Refer to Frame and Bumpers/Bumpers/FASCIA, Rear/Removal and Installation).
- 5. Connect the negative battery cable.