CHILTONLIBRARY



Front

FRONT

REMOVAL

- 1. Remove the instrument panel (Refer to Body/Instrument Panel/PANEL, Instrument Panel/Removal and Installation).
- 2. Lower the front of the headliner (Refer to Body/Interior/HEADLINER/Removal and Installation).
- 3. Disconnect the front drain tube from the sunroof.
- 4. Remove the front drain tube from the retaining clips.
- 5. Remove the drain tube grommet out of the cowl panel.

INSTALLATION

- 1. Route the front drain tube and install the grommet into the body. Make sure the grommet is fully seated.
- 2. Install the front drain tube into the retaining clips.
- 3. Connect the front drain tube to the sunroof.
- 4. Install the headliner (Refer to Body/Interior/HEADLINER/Removal and Installation).
- 5. Install the instrument panel (Refer to 23 Body/Instrument Panel/PANEL, Instrument Panel/Removal and Installation).