
CHILTONLIBRARY



Removal & Installation


REMOVAL AND INSTALLATION

REMOVAL




2310060938

- 1. Remove the front door trim panel (Refer to 23 Body/Door Front/PANEL, Door Trim/Removal and Installation).
- 2. Disconnect the wire harness connectors (1) as necessary.




2310100009

3. Remove the four bezel screws (1).




2310100012

4. Using trim stick C-4755 or equivalent, remove the interior handle bezel (1).




2310100010

- 5. Separate the wire harness (1) from the handle.
- 6. Remove the seven screws (2).




7. Remove the interior handle (1) from the door trim panel.

INSTALLATION



1. Install the interior handle (1) onto the door trim panel.



- 2. Install the six screws (2) and tighten to the proper (Torque Specifications).
- 3. Install the front door trim panel (Refer to 23 Body/Door Front/PANEL, Door Trim/Removal and Installation).