# **Sweeper Lesson Plan**

Vehicle Management Codes: D594



QUALIFICATION TRAINING PACKAGE

# **CONTENTS**

SEC	CTION 1—OVERVIEW	3
1.1.	Overview	3
SEC 2.1.	CTION 2—RESPONSIBILITIES	
	CTION 3—INTRODUCTION	4
3.1.	Objectives	
3.2.	Desired Learning Outcomes.	
3.3.	Lesson Duration.	
3.4.	Instructional References.	
3.5.	Instructional Training Aids and Equipment	5
SEC 4.1.	CTION 4—TRAINEE PREPARATIONLicensing Requirements	
4.2.	Required Reading.	6
<b>SEC</b> 5.1.	CTION 5—KNOWLEDGE LECTURE AND EVALUATION  Overview of Training and Requirements	
5.2.	Vehicle Inspection	7
5.3.	Vehicle Safety and Equipment.	14
5.4.	Driving Safety and Precautions	15
5.5.	Vehicle Operation	18
SEC 6.1.	CTION 6—EXPLANATION AND DEMONSTRATIONInstructor's Preparation.	
6.2.	Safety Procedures and Equipment	19
6.3.	Operator Maintenance Demonstration	20
6.4.	Operation Demonstration.	20
SEC 7.1.	TTION 7—TRAINEE PERFORMANCE AND EVALUATION	
7.2.	Performance Evaluation.	24
Atta	chment 1—GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION	28
Atta	chment 2—VEHICLE INSPECTION GUIDE	29
Atta	chment 3—PERFORMANCE TEST	33
Atta	chment 4—SEVEN-STEP INSPECTION PROCESS	37

#### Section 1—OVERVIEW

#### 1.1. Overview.

- 1.1.1. Send comments and suggested improvements on Air Force (AF) Form 847, *Recommendation for Change of Publication* through Air Force Installation and Mission Support Center (AFIMSC) functional managers via e-mail at AFIMSC.IZSL.VehicleOps@us.af.mil.
- 1.1.2. How to use this plan:
  - 1.1.2.1. Instructor:
    - 1.1.2.1.1. Provide overview of training, Section 2 and Section 3.
    - 1.1.2.1.2. Instructor's lesson plan for trainee preparation, give classroom lecture, **Section 4**.
    - 1.1.2.1.3. Instructor's lesson plan for knowledge overview, **Section 5**.
    - 1.1.2.1.4. Instructor's lesson plan for demonstration, **Section 6**.
    - 1.1.2.1.5. Instructor's lesson plan for performance test evaluation, **Section 7**.
  - 1.1.2.2. Trainee:
    - 1.1.2.2.1. Reads this entire lesson plan prior to starting lecture.
    - 1.1.2.2.2. Follows along with lecture using this lesson plan and its attachments.
    - 1.1.2.2.3. Uses **Attachment 2** and **Attachment 4** as guides for vehicle inspection.
    - 1.1.2.2.4. Takes performance test.

## **Section 2—RESPONSIBILITIES**

## 2.1. Responsibilities.

- 2.1.1. The trainee shall:
  - 2.1.1.1. Ensure the trainer explains the Air Force Qualification Training Plan (AFQTP) process and the trainee's responsibilities.
  - 2.1.1.2. Review the AFQTP/Module/Unit with the trainer.

2.1.1.3. The trainee should ask questions if he or she does not understand the objectives for each unit.

#### 2.1.2. Instructor shall:

- 2.1.2.1. Review the AFQTP with the trainee.
- 2.1.2.2. Conduct knowledge training with the trainee using the AFQTP.
- 2.1.2.3. Sign-off the task(s).

## Section 3—INTRODUCTION

## 3.1. Objectives.

- 3.1.1. Given lectures, demonstrations, and a hands-on driving session, trainees will be able to perform operator's inspection and complete the performance test with zero instructor assists.
  - 3.1.1.1. Train and qualify each trainee in safe operation and preventive maintenance of the sweeper.
  - 3.1.1.2. This training will ensure the trainee becomes a qualified sweeper operator; an operator who has the knowledge and skills to operate a sweeper in a safe, proficient and professional manner.

## 3.2. Desired Learning Outcomes.

- 3.2.1. Understand the purpose of the sweeper and its role in the mission.
- 3.2.2. Understand the safety precautions to be followed for pre-, during- and post-operation inspections of the sweeper.
- 3.2.3. Know and perform proper operator maintenance procedures of the sweeper IAW applicable technical manuals and use of AF Form 1800, *Operator's Inspection Guide and Trouble Report*.
- 3.2.4. Be completely familiar with the safety features of the sweeper.
- 3.2.5. Safely and proficiently operate the sweeper.

#### 3.3. Lesson Duration.

3.3.1. Recommended instructional and hands on training time is 14 hours:

**Table 3.1. Recommended Training Time for Training Activities.** 

Training Activity	Training Time
Trainee's Preparation	2 Hours
Instructor's Lecture	3 Hours
Instructor's Demonstration	2 Hours
Trainee's Personal Experience (to build	
confidence and proficiency)	6 Hours
<ul> <li>Perform Operator Maintenance</li> </ul>	o nouis
<ul> <li>Operate the Vehicle</li> </ul>	
Trainee's Performance Evaluation	1 Hour

**Note:** This is a recommended time; training time may be more or less depending how quickly a trainee learns new tasks.

## 3.4. Instructional References.

- 3.4.1. Risk Management (RM) and Safety Principles IAW Air Force Pamphlet (AFPAM) 90-803, *Risk Management (RM) Guidelines and Tools*.
- 3.4.2. Applicable technical manual(s) or Manufacturer's Operator's Manual (see Vehicle Management for technical manuals for vehicle being used in training).
- 3.4.3. Air Force Manual (AFMAN) 24-306, Operation of Air Force Government Motor Vehicles.
- 3.4.4. AF Form 1800.
- 3.4.5. Air Force Instruction (AFI) 91-203, Air Force Consolidated Occupational Safety Instruction.
- 3.4.6. AFI 24-302, Vehicle Management.
- 3.4.7. AFI 91-207, The U.S. Air Force Traffic Safety Program, Chapter 3.

# 3.5. Instructional Training Aids and Equipment.

- 3.5.1. Sweeper Lesson Plan.
- 3.5.2. Sweeper.
- 3.5.3. Applicable technical manuals or manufacturer's operator's manual.
- 3.5.4. AF Form 1800.
- 3.5.5. Videos (if locally produced).

- 3.5.6. Suitable training area.
- 3.5.7. Traffic cones.
- 3.5.8. Applicable hand tools.

## **Section 4—TRAINEE PREPARATION**

## 4.1. Licensing Requirements.

- 4.1.1. Trainee must have in his/her possession a valid state driver's license.
- 4.1.2. AF Form 171, Request for Driver's Training and Addition to U.S. Government Drivers in accordance with (IAW) AFI 24-301, Ground Transportation.
- 4.1.3. Applicable local licensing jurisdiction requirements.

# 4.2. Required Reading.

- 4.2.1. Read this entire lesson plan.
- 4.2.2. Read AFMAN 24-306.
- 4.2.3. Read manufacturer's operator's manual for the vehicle being trained on.

#### Section 5—KNOWLEDGE LECTURE AND EVALUATION

# 5.1. Overview of Training and Requirements.

- 5.1.1. Training objectives:
  - 5.1.1.1. Given lectures, demonstrations, and a hands-on driving session, trainees will be able to perform operator's inspection and complete the performance test with zero instructor assists.
  - 5.1.1.2. Train and qualify each trainee in safe operation and preventive maintenance of the sweeper.
  - 5.1.1.3. This training will ensure the trainee becomes a qualified sweeper operator—an operator who has the knowledge and skills to perform operator maintenance and operate the sweeper in a safe and professional manner.

# 5.1.2. Desired learning outcomes:

5.1.2.1. Understand the purpose of the sweeper and its role in the mission.

- 5.1.2.1.1. The purpose of the sweeper is to remove foreign object damage (FOD) and debris from paved surfaces.
- 5.1.2.1.2. Role in the mission (Unit/Base/Community (during natural disasters)/Air Force).
- 5.1.2.2. Be completely familiar with the safety features of the sweeper.
- 5.1.2.3. Safely and proficiently operate the sweeper.
- 5.1.3. Sweeper design. The design of a sweeper consists of a regenerative air system that enables the sweeper to clean pavement surfaces. The air system is a closed loop system in which the only air used is the air confined within the sweeper. Refer to the manufacturer's operator's manual for additional information on the specific sweeper being operated.
- 5.1.4. The trainee should be able to identify the following components of the sweeper:
  - 5.1.4.1. Prime mover components.
  - 5.1.4.2. Auxiliary engine.
  - 5.1.4.3. Hopper and hand suction hose.
  - 5.1.4.4. Pick-up head assembly.
  - 5.1.4.5. Gutter broom assemblies.
  - 5.1.4.6. Water system.
  - 5.1.4.7. Front bumper magnet.

## **5.2.** Vehicle Inspection.

- 5.2.1. Pre-operation vehicle inspection test. Use **Attachment 2** as a 360 walk-around guide along with AF Form 1800.
- 5.2.2. A Seven-Step Inspection Method will help ensure the inspection is the same each time it is conducted, and that nothing is left out. See **Attachment 4** for the Seven-Step Inspection Method.
- 5.2.3. Types of Vehicle Inspection. If discrepancies are found the operator must report them to Vehicle Control Officer/Vehicle Control Non-Commissioned Officer (VCO/VCNCO), the supervisor, and/or vehicle maintenance:

- 5.2.3.1. Pre-operation inspection identify items/problems that could cause accidents or breakdowns.
  - 5.2.3.1.1. Vehicle Maintenance may authorize continued use for all other maintenance discrepancies.
  - 5.2.3.1.2. Cleanliness/damaged/missing items.
  - 5.2.3.1.3. Leaks (fuel/oil/coolant/air).
  - 5.2.3.1.4. Fluid levels; ensure levels are within limits:
    - 5.2.3.1.4.1. Engine oil.
    - 5.2.3.1.4.2. Coolant.
    - 5.2.3.1.4.3. Power steering fluid.
    - 5.2.3.1.4.4. Transmission fluid.
    - 5.2.3.1.4.5. Hydraulic fluid, if applicable.
  - 5.2.3.1.5. Drive belts; tension and fraying.
  - 5.2.3.1.6. Air filter(s).
  - 5.2.3.1.7. All hoses and wiring.
  - 5.2.3.1.8. Battery; security, fluid, damage and corrosion.
  - 5.2.3.1.9. All wheel rims (cracks, splits, etc.); check for loose or missing lug nuts.
  - 5.2.3.1.10. All tires.
    - 5.2.3.1.10.1. Proper inflation.
    - 5.2.3.1.10.2. Sidewalls, tread/retreads, to include depth, bulges.
    - 5.2.3.1.10.3. Cuts and abrasions.
    - 5.2.3.1.10.4. Lug nuts.
    - 5.2.3.1.10.5. Mud flaps.
  - 5.2.3.1.11. Transmission.

- 5.2.3.1.11.1. Differential. Damage, wear and leaks.
- 5.2.3.1.11.2. Drive train. Damage, wear and leaks.
- 5.2.3.1.12. Suspension.
  - 5.2.3.1.12.1. Shocks and springs, damage.
- 5.2.3.1.13. Frame bolts and other fasteners, visual inspection for damage.
- 5.2.3.1.14. Welds visual inspection for cracks.
- 5.2.3.1.15. Visual and auditory warning devices.
- 5.2.3.1.16. Storage bin doors properly latched, if applicable.
- 5.2.3.1.17. Auxiliary engine.
  - 5.2.3.1.17.1. Fluid levels; ensure levels are is within limits:
    - 5.2.3.1.17.1.1. Engine oil.
    - 5.2.3.1.17.1.2. Coolant.
    - 5.2.3.1.17.1.3. Hydraulic fluid.
  - 5.2.3.1.17.2. Drive belts; tension and fraying.
  - 5.2.3.1.17.3. Air filter(s).
  - 5.2.3.1.17.4. All hoses and wiring.
- 5.2.3.1.18. Hopper and hand suction hose.
  - 5.2.3.1.18.1. Damage and cleaniness.
  - 5.2.3.1.18.2. Injection door and hopper door seals for damage. **Note:** Dump assembly.
  - 5.2.3.1.18.3. Dust separator assembly (interior).
  - 5.2.3.1.18.4. Screens/mud flaps.
  - 5.2.3.1.18.5. Scraper Rake bar, if applicable.
  - 5.2.3.1.18.6. Hydraulic cylinders.

- 5.2.3.1.18.7. Hand suction hose assembly.
- 5.2.3.1.18.8. Shutter plate. **Note:** Configure for application.
- 5.2.3.1.19. Pick-up head assembly.
  - 5.2.3.1.19.1. Pick-up head deck.
  - 5.2.3.1.19.2. Skid plates.
  - 5.2.3.1.19.3. Curtains.
  - 5.2.3.1.19.4. Springs, chains, and shackles/pins.
  - 5.2.3.1.19.5. Hydraulic lift cylinders.
  - 5.2.3.1.19.6. Drag bars.
  - 5.2.3.1.19.7. Inlet hose.
  - 5.2.3.1.19.8. Outlet hose.
  - 5.2.3.1.19.9. Pressure bleeder door and cable.
  - 5.2.3.1.19.10. Agitator broom, if applicable.
- 5.2.3.1.20. Gutter broom assemblies.
  - 5.2.3.1.20.1. Gutter broom mounting plates.
  - 5.2.3.1.20.2. Control arms.
  - 5.2.3.1.20.3. Bristles.
  - 5.2.3.1.20.4. Springs.
  - 5.2.3.1.20.5. Hydraulic motors.
  - 5.2.3.1.20.6. Hydraulic lines.
- 5.2.3.1.21. Water system.
  - 5.2.3.1.21.1. Tank and fill hose.
  - 5.2.3.1.21.2. Pump(s).

- 5.2.3.1.21.3. Water filter(s). **Note:** Filter(s) must be primed before starting pump.
- 5.2.3.1.21.4. Water lines.
- 5.2.3.1.21.5. Nozzels (front bumper, gutter brooms, pick-up head, and hopper).
- 5.2.3.1.22. Front bumper magnet.
  - 5.2.3.1.22.1. Properly secured and clean.
  - 5.2.3.1.22.2. Chains and shackles/pins.
  - 5.2.3.1.22.3. Hydraulic lift cylinders.
  - 5.2.3.1.22.4. Support arms.
- 5.2.3.1.23. Fuel tank(s) assembly for damage.
- 5.2.3.1.24. Wiring/reflectors.
- 5.2.3.1.25. Lights (interior/exterior).
- 5.2.3.1.26. Mirrors.
- 5.2.3.1.27. Windshield and windshield wipers/washers.
- 5.2.3.1.28. Doors.
- 5.2.3.1.29. Windows.
- 5.2.3.1.30. Seatbelts.
- 5.2.3.2. During-operation inspection.
  - 5.2.3.2.1. Ignition to accessory position.
  - 5.2.3.2.2. Check all gauges and warning lights/indicators for proper operations.
  - 5.2.3.2.3. Ignition to start.
  - 5.2.3.2.4. Check for unusal conditions (interior).
    - 5.2.3.2.4.1. Sounds.
    - 5.2.3.2.4.2. Odors.

- 5.2.3.2.4.3. Vibrations.
- 5.2.3.2.5. Conduct 360 walk-around (exterior).
  - 5.2.3.2.5.1. Sounds.
  - 5.2.3.2.5.2. Odors.
  - 5.2.3.2.5.3. Vibrations.
  - 5.2.3.2.5.4. Leaks.
  - 5.2.3.2.5.5. Light function.
- 5.2.3.2.6. Conduct function check of all controls.
  - 5.2.3.2.6.1. Steering wheel.
  - 5.2.3.2.6.2. Shift selector.
  - 5.2.3.2.6.3. Parking brake.
  - 5.2.3.2.6.4. Hydraulic control levers (power take-off (PTO)), if equipped.
  - 5.2.3.2.6.5. Windshield wipers.
  - 5.2.3.2.6.6. Climate control.
- 5.2.3.2.7. Air brake check. The trainee must accomplish all three components of the air brake check correctly. Air brake safety devices vary. However, this procedure is designed to see that any safety device operates correctly as air pressure drops from normal to a low air condition. For safety purposes, in areas where an incline is present, the operator will use wheel chocks during the air brake check. The proper procedures for inspecting the air brake system are as follows:
  - 5.2.3.2.7.1. With the air pressure built up to governor cutoff (120 140 pounds per square inch (psi)), shut off the engine, chock the wheels if necessary, release the parking brake (all vehicles) and fully apply the foot brake. Hold the foot brake for one minute. Check the air gauge to see if the air pressure drops more than three pounds in one minute (single vehicle).

- 5.2.3.2.7.2. Without re-starting the engine, turn electrical power to the "on" or "battery charge" position. Begin fanning off the air pressure by rapidly applying and releasing the foot brake. Low air warning devices (buzzer, light, flag) should activate before air pressure drops below 60 psi or level specified by the manufacturer.
- 5.2.3.2.7.3. Continue to fan of the air pressure. On single vehicle types, the parking brake valve should close (pop-out).
- 5.2.3.2.8. Start auxiliary engine.
  - 5.2.3.2.8.1. Check for unusal sounds conditions (interior).
    - 5.2.3.2.8.1.1. Sounds.
    - 5.2.3.2.8.1.2. Odors.
    - 5.2.3.2.8.1.3. Vibrations.
- 5.2.3.2.9. Activate water system. **CAUTION:** Do not run pump dry.
- 5.2.3.2.10. Close hopper door/inspection doors. **Note:** Ensure all personnel are clear of hopper door.
- 5.2.3.2.11. Lower pick-up head, conduct visual inspection of all components.
- 5.2.3.2.12. Activate gutter brooms/inspect broom pattern contact. **CAUTION:** Maintain three points of contact, DO NOT use gutter broom assemblies as a step to enter or exit sweeper.
- 5.2.3.2.13. Lower/engage front bumper magnet, if applicable.
- 5.2.3.2.14. Sign AF Form 1800. Verify Standard Form (SF) 91, Motor Vehicle Accident Report and Department of Defense (DD) Form 518, Accident Identification Card are on-hand.
- 5.2.3.3. Post-opertion inspection.
  - 5.2.3.3.1. Check fuel level (<3/4 tank, refuel).
  - 5.2.3.3.2. Ensure vehicle and components are cleaned after each shift.
    - 5.2.3.3.2.1. Empty hopper.
    - 5.2.3.3.2.2. Wash out hopper/hand suction hose.

- 5.2.3.3.2.3. Leave hopper and inspection doors open for all seals to reshape/dry.
- 5.2.3.3.3. Park vehicle. Ensure transmission in neutral, apply parking brake.
- 5.2.3.3.4. Engine cool down (3-5 minutes). Shut off lights and accessories.
- 5.2.3.3.5. Inspection and clean (replace) air filter(s) daily. **Note:** DO NOT use high pressure/compressed air to clean air filters.
- 5.2.3.3.6. Drain air tanks.
- 5.2.3.3.7. Post 360 walk-around. Check for leaks and damage.
- 5.2.3.3.8. Ensure all hoses and attachments are stowed.

## 5.3. Vehicle Safety and Equipment.

- 5.3.1. Hazards and human factors:
  - 5.3.1.1. Traffic due to size and weight.
  - 5.3.1.2. Jerky starts and stops.
  - 5.3.1.3. Traveling too fast and turning too sharply.
- 5.3.2. Safety clothing and equipment:
  - 5.3.2.1. Safety steel-toed boots must be worn.
  - 5.3.2.2. First aid kit. Conduct inspection of contents.
  - 5.3.2.3. Cones.
  - 5.3.2.4. Inclement weather gear, if needed.
  - 5.3.2.5. Reflective belt during hours of reduced visibility and on flightline.
  - 5.3.2.6. Hearing protection/eye protection.
  - 5.3.2.7. Dust mask.
  - 5.3.2.8. Gloves.
  - 5.3.2.9. Tire gauge.
  - 5.3.2.10. Fire extinguisher.

## 5.3.2.11. AF Form 1800, SF 91 and DD Form 518.

# 5.4. Driving Safety and Precautions.

- 5.4.1. Overview safety and precautions. The following are safety items and procedures to be followed during sweeper operations. The manufacturer's operator's manual will also provide safe operating procedures and the vehicle itself may have warnings, cautions and danger stickers that the vehicle operator should be aware of.
  - 5.4.1.1. Vehicle data plate. Be familiar with the location and information found on the data plate.
  - 5.4.1.2. Plan the route.
    - 5.4.1.2.1. Overhead clearance. Check the clearance height of the vehicle relative to the overhead obstructions such as power lines, trees, and bridges.
    - 5.4.1.2.2. Width restrictions/construction zones, over-the-road.
    - 5.4.1.2.3. Weight restriction (roads, bridges, off-road conditions).
    - 5.4.1.2.4. Inclines.
    - 5.4.1.2.5. Uneven ground.
    - 5.4.1.2.6. Soft surfaces.
- 5.4.2. Street-side operations.
  - 5.4.2.1. Greater vehicle weight. The operator needs to consider the combined weight of the snow broom and the load. This will affect the following:
    - 5.4.2.1.1. Operator's ability to stop. Do not tailgate the vehicle in front. Allow more distance between vehicles in order to increase reaction time.
    - 5.4.2.1.2. Vehicle's ability to accelerate/follow the flow of traffic. Accelerate smoothly and gradually so the truck does not jerk. Rough acceleration causes unnecessary, premature mechanical damage to the truck's drive train. Maintain a safe speed (typically 5 miles per hour (mph) below the posted speed limit).
  - 5.4.2.2. Downgrades/upgrades. The operator will use lower gears more frequently to climb hills or mountains with increasing grade steepness, length and/or heavy load weight. Plan ahead to identify downgrades/upgrades on the route of travel. If possible, talk to other drivers who are familiar with the grades to find out what speeds are safe. When encountering downgrades/upgrades as described, the operator will need to address:

- 5.4.2.2.1. Speed. On downgrades, gravity causes the speed of the vehicle to increase. The operator must select an appropriate safe speed, use a low gear, and proper braking techniques. The operator must go slow enough so as to not overheat the truck brakes.
- 5.4.2.2.2. Stopping. If the brakes become too hot, they may start to "fade". This means the operator will need to apply the brakes harder and harder to acquire equivalent stopping power.
- 5.4.2.3. Sharp turns. Slow down before entering the turn. During the turn, avoid sharp sudden movements with the steering wheel. This reduces the chance of shifting the load in the tank, and also prevents the possibility of tipping over due to the higher center of gravity.
- 5.4.2.4. Surroundings. Operating a snow broom requires the operator's constant attention. Many situations can be avoided by simply paying close attention to the surrounding conditions. Road signs such as "steep grade", "low overhead clearance", "sharp turn ahead", and special speed limits are posted for the driver's safety.
- 5.4.2.5. Size. The operator must take into account, the size/width of the broom head assembly and airblast ducts when operating the vehicle.
- 5.4.3. Air fireld sweeper operations IAW AFI 13-213, *Airfield Driving*, AFMAN 24-306 and local requirements. Maintain:
  - 5.4.3.1. Safe operating distance around aircraft.
  - 5.4.3.2. Proper distance from airfield lights, buildings, hangars, etc.
  - 5.4.3.3. Two-way communications/light singuls with Base Ops and Control Tower, as applicable.
  - 5.4.3.4. Knowledge and adherence to airfield markings/indicators.
  - 5.4.3.5. Alertness to aircraft/vehicle movement.
  - 5.4.3.6. Awareness of prepositioned aerospace ground equipment (AGE), wheel chocks, fire extinguisher/bottle, etc.
  - 5.4.3.7. Awareness of in ground refueling hydrant lids/utilities man-hole covers.
  - 5.4.3.8. Alertness to aircraft arresting system cables/anchor chains.

**CAUTION:** Be aware of frost-heaved/uneven pavements and hidden items in snow windrows.

5.4.4. Backing. **CAUTION:** Do NOT back up with the pick-up head or gutter brooms down.

- 5.4.4.1. Always use a spotter and hand signals.
- 5.4.4.2. Back slowly and keep the spotter in view at all times. If the operator loses sight of the spotter, the operator must immediately stop the vehicle.
- 5.4.4.3. See AFMAN 24-306 for standard AF spotter hand signals and additional guidance on spotter safety.
- 5.4.5. Sweeper filling operations.
  - 5.4.5.1. Ensure transmission is in neutral, apply parking brake.
  - 5.4.5.2. Fire hydrant/fill station. Ensure three points-of-contact when climbing on/off sweeper.
  - 5.4.5.3. Be aware of pinch hazards when connecting hoses.
  - 5.4.5.4. Disconnect and stow fill hose.
- 5.4.6. Pick-up and gutter broom operational adjustments. **CAUTION:** Wear gloves while performing the below tasks.
  - 5.4.6.1. SHUT DOWN all engines before making adjustments on the pick-up head.
  - 5.4.6.2. SHUT DOWN all engines before making adjustments on the on the gutter brooms.
  - 5.4.6.3. Reduce auxiliary engine RPMs before raising the pick-up head.
- 5.4.7. Hand suction hose operations.
  - 5.4.7.1. SHUT DOWN auxiliary engine.

**CAUTION:** Be aware of pinch hazards when inserting shutter plate, latching upper inlet hose, and when closing hand suction hose door. Do NOT point suction hose at anything that is not intended to be suctioned-up.

- 5.4.7.2. Stow equipment.
- 5.4.8. Tire changing safety. **CAUTION:** Wear gloves while performing the below task.
  - 5.4.8.1. Consider where the vehicle is located. If on a bridge, curve, road with no shoulder, etc.; it is safer to move a vehicle with a flat tire to a safer location.
  - 5.4.8.2. Find a location with a firm and level surface for the jack.

- 5.4.8.3. Turn on the four-way flashers.
- 5.4.8.4. Set parking brake.
- 5.4.8.5. Place warning triangles or flares.
- 5.4.8.6. Block the wheels. If changing a front tire, block the rear wheels. If changing a rear tire, block the front wheels.
- 5.4.8.7. As required, place dunnage or cribbage under the jack.

## 5.5. Vehicle Operation.

- 5.5.1. General vehicle operations.
  - 5.5.1.1. Complete a pre-operation vehicle inspection.
  - 5.5.1.2. Sign the current AF Form 1800.
  - 5.5.1.3. Getting into the cab.
    - 5.5.1.3.1. Use three points of contact when climbing into the vehicle.
    - 5.5.1.3.2. The sweeper can be operated from either side of the vehicle. When sweeping the flightline area, the operator normally uses the left side seat. When performing street side operations, the operator will use the right side seat. This allows the operator to have great visibility of the curbing along the side of the road.
  - 5.5.1.4. Adjust the seat and mirrors as needed; fasten seat belt.
- 5.5.2. Left/right side sweeping operations. Refer to operator's manual(s).
- 5.5.3. Hand suction hose operations. Refer to operator's manual(s).
- 5.5.4. To start the vehicle, ensure the parking brake is set and the gear selection is in neutral.
  - 5.5.4.1. Turn the ignition key to the ON position. If sweeper is equipped with a starter button press and release the button once the engines starts. **CAUTION:** Do not engage the starter for more than 10 seconds.
  - 5.5.4.2. Wait 10 to 15 seconds before reengaging the starter if the truck does not start on the first try.
- 5.5.5. Moving the sweeper.

- 5.5.5.1. Before placing the vehicle in motion, ensure the doors are closed and everyone has their seat belt on.
- 5.5.5.2. Make sure the pick-up head assembly and gutter brooms are in the stowed position when traveling to the job site.
- 5.5.5.3. Once at the job site, start the auxiliary engine, deploy the pick up head assembly and/or gutter brooms and begin sweeper operations. **CAUTION:** Do NOT back up with the pick up head or gutter brooms down.
- 5.5.5.4. Follow procedures in **Section 5.2.** for operating the auxiliary engine, pick-up head, and gutter brooms.
- 5.5.6. End of duty day.
  - 5.5.6.1. Perform post-operation procedures as outlined in **Section 5.2.**

## Section 6—EXPLANATION AND DEMONSTRATION.

# 6.1. Instructor's Preparation.

- 6.1.1. Establish a training location.
- 6.1.2. Obtain appropriate vehicle operator's manual.
- 6.1.3. Schedule/reserve a vehicle.
- 6.1.4. Ensure trainee completes AF Form 171.

## 6.2. Safety Procedures and Equipment.

- 6.2.1. The following safety items should be followed by both the instructor and trainee.
  - 6.2.1.1. Chock wheel (if required) when sweeper is parked.
  - 6.2.1.2. Remove all jewelry and identification tags.
  - 6.2.1.3. Personal protective equipment (PPE) and equipment items.

**Note:** Discuss when applicable PPE and equipment items are required.

- 6.2.1.3.1. Steel-toed boots must be worn.
- 6.2.1.3.2. Gloves will be worn during pick-up head and gutter brooms adjustments/maintenance.

- 6.2.1.3.3. Inclement weather gear, if required.
- 6.2.1.3.4. Hearing protection, if required.
- 6.2.1.3.5. Eye protection, if required.
- 6.2.1.3.6. Dust mask, if required.
- 6.2.1.3.7. Reflective belt during hours of reduced visibility or on the flightline.
- 6.2.1.4. The trainer and the trainee should conduct a 360 walk-around the vehicle to become familiar all warning labels and signs.
- 6.2.1.5. Ensure trainee wears seat belt.
- 6.2.1.6. Properly adjust driver's seat and all mirrors.
- 6.2.1.7. Throughout demonstration, practice sweeper operations safety.
- 6.2.2. Practice basic RM process during demonstration:
  - 6.2.2.1. Identify the hazards.
  - 6.2.2.2. Assess the hazards.
  - 6.2.2.3. Develop controls and make decisions.
  - 6.2.2.4. Implement controls.
  - 6.2.2.5. Supervise and evaluate.

## **6.3. Operator Maintenance Demonstration.**

6.3.1. With trainee, accomplish vehicle inspection using AF Form 1800. The vehicle inspection will follow the seven-step method as described in **Attachment 3**. An inspection guide (**Attachment 2**) can be used to ensure all areas of the SWEEPER are covered in addition to the "Operation Demonstration" guidelines provided below.

## **6.4. Operation Demonstration.**

- 6.4.1. Throughout demonstration:
  - 6.4.1.1. Allow for questions.
  - 6.4.1.2. Repeat demonstrations as needed.

- 6.4.2. Demonstrate/discuss pre-operation and during-operation inspection requirements. 6.4.3. Demonstrate the following procedures for operating the sweeper. 6.4.3.1. Forward. 6.4.3.2. Turning. 6.4.3.3. Braking. 6.4.3.4. Backing (use spotter when backing). 6.4.3.5. Parking. 6.4.3.6. Sweeping operations. **Note:** Refer to the techincal manual for additional guidance pertaining to the vehicle being operated. Demostrate: 6.4.3.6.1. Pick-up head and gutter brooms adjustments.

  - 6.4.3.6.2. Filling the tank/water system opeations.
  - 6.4.3.6.3. Left/right seat and hand suction hose operations.
  - 6.4.3.6.4. Hopper clean out operations.
- 6.4.4. Demonstrate/discuss post-operation requirements.
  - 6.4.4.1. Ensure all attachments are properly stowed.
  - 6.4.4.2. Ensure vehicle is clean.
  - 6.4.4.3. Refuel vehicle.
  - 6.4.4.4. Following manufacturer's shut-down procedures.
  - 6.4.4.5. Park.
    - 6.4.4.5.1. Place transmission in neutral.
    - 6.4.4.5.2. Apply brakes.
  - 6.4.4.6. Perform a 360 walk-around inspection.
  - 6.4.4.7. Annotate any discrepancies found on AF Form 1800.
- 6.4.5. Conclude by allowing time for questions and any requested re-demonstrations.

# Section 7—TRAINEE PERFORMANCE AND EVALUATION

## 7.1. Trainee Performance.

- 7.1.1. Instructor will:
  - 7.1.1.1. Ensure safety at all times. **Note:** Stop training when safety items are violated. Proceed only when the trainee fully understands how to avoid repeating the safety infraction(s). Ensure:
    - 7.1.1.1.1. Chock wheel (if required) when sweeper is parked.
    - 7.1.1.2. Remove all jewelry and identification tags.

**Note:** If available, mark vehicle with magnetic sign indicating "Driver-in-Training" or "Trainee Operator."

- 7.1.1.2. PPE and other items:
  - 7.1.1.2.1. Steel-toed boots must be worn.
  - 7.1.1.2.2. Gloves will be worn during pick-up head and gutter broom adjustments and hopper clean out opeartion.
  - 7.1.1.2.3. Hearing protection, if required.
  - 7.1.1.2.4. Eye protection, if required.
  - 7.1.1.2.5. Dust mask, if required.
  - 7.1.1.2.6. Reflective belt during hours of reduced visibility or on the flightline.
  - 7.1.1.2.7. Warning triangles.
  - 7.1.1.2.8. Inclement weather gear, if required.
- 7.1.1.3. Pay particular attention to the cautions and warnings listed in the technical manual.
- 7.1.1.4. Ensure trainee wears seat belt.
- 7.1.1.5. Properly adjust driver's seat and all mirrors.
- 7.1.1.6. Sweeper safety items/procedures.

- 7.1.1.7. Ensure the trainee is aware of tasks to be performed.
- 7.1.1.8. Conduct during/after-action reviews with the trainee. (Demonstration may need to be re-accomplished).
- 7.1.2. Trainee Performance.
  - 7.1.2.1. Conduct operator maintenance (have trainee explain items being inspected).

**Note:** Allow trainee to use **Attachment 2** as a guide while performing inspection.

- 7.1.2.1.1. Pre-operation inspection.
- 7.1.2.1.2. Air brakes test (if equipped).
- 7.1.2.1.3. During-operation inspection.
- 7.1.2.1.4. Post-operation inspection
- 7.1.2.2. Ensure AF Form 1800 is properly documented.
  - 7.1.2.2.1. Identify and explain sweeper gauges, switches, levers and buttons.
  - 7.1.2.2.2. Establish a road course that will have the following: (if the course does not have one of the following, then the trainee should be able to explain the correct operating techniques).
    - 7.1.2.2.2.1. Forward.
    - 7.1.2.2.2.2. Turning.
    - 7.1.2.2.2.3. Braking.
    - 7.1.2.2.2.4. Backing (use spotter when backing).
    - 7.1.2.2.2.5. Parking.
    - 7.1.2.2.2.6. Sweeping operations. **Note:** Refer to the techincal manual for additional guidance pertaining to the vehicle being operated.
      - 7.1.2.2.2.6.1. Pick-up head and gutter brooms adjustments.
      - 7.1.2.2.2.6.2. Filling the tank/water system opeations.
      - 7.1.2.2.2.6.3. Left/right seat and hand suction hose operations.

- 7.1.2.2.2.6.4. Hopper clean out operations.
- 7.1.2.2.3. Perform post-operation inspection.
  - 7.1.2.2.3.1. Ensure vehicle components are cleaned.
  - 7.1.2.2.3.2. Check fuel level. If there is  $< \frac{3}{4}$  tank, refuel the vehicle.
  - 7.1.2.2.3.3. Check diesel exhaust fluid level, if equipped.
  - 7.1.2.2.3.4. Following manufacturer's shut-down procedures.
  - 7.1.2.2.3.5. Park.
    - 7.1.2.2.3.5.1. Place transmission in neutral.
    - 7.1.2.2.3.5.2. Apply parking brake.
  - 7.1.2.2.3.6. Engine cool down (3-5 minutes), shut off lights and accessories.
  - 7.1.2.2.3.7. Drain air tanks.
  - 7.1.2.2.3.8. Perform a 360 walk-around inspection, Check for leaks and damage. Ensure all hoses and attachments are stowed.

## 7.2. Performance Evaluation.

- 7.2.1. Trainee will perform performance evaluation found in **Attachment 3**.
  - 7.2.1.1. Instructor and trainee will review **Attachment 3**.
  - 7.2.1.2. Instructor will answer trainee's questions.

**Note:** If available, mark vehicle with magnetic sign indicating "Driver-in-Training" or "Trainee Operator".

- 7.2.2. Instructor will:
  - 7.2.2.1. Ensure safety at all times.
    - 7.2.2.1.1. Place wheel chocks (if required) when sweeper is parked.
    - 7.2.2.1.2. Remove all jewelry and identification tags.
  - 7.2.2.2. PPE and other items.

- 7.2.2.2.1. Steel-toed boots must be worn.
- 7.2.2.2.2. Gloves will be worn during pick-up head and gutter broom adjustments and hopper clean out opeartion.
- 7.2.2.2.3. Hearing protection, if required.
- 7.2.2.2.4. Eye protection, if required.
- 7.2.2.5. Dust mask, if required.
- 7.2.2.2.6. Reflective belt during hours of reduced visibility or on the flightline.
- 7.2.2.2.7. Warning triangles.
- 7.2.2.2.8. Inclement weather gear, if required
- 7.2.2.3. Pay particular attention to the cautions and warnings listed in the technical manual.
- 7.2.2.4. Ensure trainee wears seat belt.
- 7.2.2.5. Properly adjust driver's seat and all mirrors.
- 7.2.2.6. Sweeper safety items/procedures.
- 7.2.2.7. Ensure the trainee is aware of tasks to be performed.
- 7.2.2.8. Conduct during/after-action reviews with the trainee. (Demonstration may need to be re-accomplished).
- 7.2.3. Explain operating techniques.
- 7.2.4. The trainee will demonstrate and be evaluated on the following procedures:
  - 7.2.4.1. Pre-operation inspection and air brakes test.
  - 7.2.4.2. Forward.
  - 7.2.4.3. Turning.
  - 7.2.4.4. Braking.
  - 7.2.4.5. Backing (use spotter when backing).
  - 7.2.4.6. Parking.

- 7.2.4.7. Sweeping operation. **Note:** Refer to the techincal manual for additional guidance pertaining to the vehicle being operated.
  - 7.2.4.7.1. Pick-up head and gutter brooms adjustments.
  - 7.2.4.7.2. Filling the tank/water system opeations.
  - 7.2.4.7.3. Left/right seat and hand suction hose operations.
  - 7.2.4.7.4. Hopper clean out operations.
- 7.2.4.8. Perform post-operation inspection.
  - 7.2.4.8.1. Ensure vehicle components are cleaned.
  - 7.2.4.8.2. Check fuel level. If there is  $< \frac{3}{4}$  tank, refuel the vehicle.
  - 7.2.4.8.3. Check diesel exhaust fluid level, if equipped.
  - 7.2.4.8.4. Following manufacturer's shut-down procedures.
  - 7.2.4.8.5. Park.
    - 7.2.4.8.5.1. Place transmission in neutral.
    - 7.2.4.8.5.2. Apply parking brake.
  - 7.2.4.8.6. Engine cool down (3-5 minutes), shut off lights and accessories.
  - 7.2.4.8.7. Drain air tanks.
  - 7.2.4.8.8. Perform a 360 walk-around inspection checking for leaks and damage. Ensure all hoses and attachments are stowed.
- 7.2.5. Ensure the trainee is aware of operating situations.
- 7.2.6. Conduct after-action reviews with the trainee.
- 7.2.7. Trainee is not allowed any instructor assists to pass performance evaluation.
- 7.2.8. Evaluation checklist provided in **Attachment 3**.
- 7.2.9. Retraining; retrain No-Go's.
  - 7.2.9.1. Re-demonstrate "No-Go" items.

7.2.9.2. Have trainee re-perform until they show proficiency in operating, critique weaknesses as observed.

7.2.9.3. Re-evaluate.

#### Attachment 1

## GLOSSARY OF REFERENCES AND SUPPORTING INFORMATION

# References

**AFI 13-213**, Airfield Driving, 1 June 2011

AFI 24-301, Ground Transportation, 1 November 2018

AFI 24-302, Vehicle Management, 26 June 2012

AFI 91-203, Air Force Consolidated Safety Instruction, 15 June 2012

AFI 91-207, The U.S. Air Force Traffic Safety Program, 16 February 2017

AFMAN 24-306, Operation of Air Force Government Motor Vehicles, 9 December 2016

**AFPAM 90-803**, Risk Management (RM) Guidelines and Tools, 11 February 2013

#### Adopted Forms

**AF Form 171**, Request for Driver's Training and Addition to U.S. Government Drivers, 1 November 2018

AF Form 847, Recommendation for Change of Publication, 22 September 2009

**AF Form 1800**, Operator's Inspection Guide and Trouble Report, 1 April 2010

## Abbreviations and Acronyms

**AF**—Air Force

**AFI**—Air Force Instruction

**AFIMSC**—Air Force Installation Mission Support Center

**AFMAN**—Air Force Manual

**AFQTP**—Air Force Qualification Training Plan

**DD**—Department of Defense

IAW—In Accordance With

**PTO**—Power Take-off

**PPE**—Personal Protective Equipment

**PSI**—Pounds per Square Inch

**RM**—Risk Management

SF—Standard Form

VCNCO—Vehicle Control Non Commissioned Officer

VCO—Vehicle Control Officer

#### **Attachment 2**

## SWEEPER VEHICLE INSPECTION GUIDE

## **GENERAL**

STEP 1.	VEHICLE OV	<b>VERVIEW</b>

- □ Paperwork
  - AF Form 1800
  - Discrepancy Correction Complete (VM Annotation)
- □ Vehicle Approach
  - Damage
  - Vehicle Leaning
  - Fresh Leakage of Fluids
  - Hazards Surrounding Vehicle

#### **INTERNAL**

## STEP 2. ENGINE COMPARTMENT

- ☐ Leaks/Hoses/Electrical Wiring Insulation
  - Oil Level
  - Coolant Level
  - Power Steering Fluid
  - Windshield Washer Fluid
  - Battery Fluid Level, Connections & Tie downs
  - Automatic Transmission Fluid Level
  - Engine Compartment Belts
  - Hydraulic Fluid
- ☐ Hopper and Hand Suction Hose
- ☐ Auxiliary Engine(s), if applicable

# STEP 3. ENGINE START/CAB CHECK (LEFT/FRONT/RIGHT)


- ☐ Safe Start
- □ Gauges
  - Oil Pressure Gauge
  - Air Pressure Gauge
  - Temperature Gauge (Coolant/Engine Oil)
  - Ammeter/Voltmeter
- □ Warning Lights & Buzzers
- ☐ Mirrors & Windshield
- □ Wipers/Washers

<ul> <li>□ Emergency &amp; Safety Equipment</li> <li>• Red Reflective Triangles</li> <li>• Properly Charged &amp; Rated Fire Extinguisher</li> <li>• Optional (Chains/Tire Changing Equip, Emergency Phone List)</li> <li>□ 3B – Lights/Reflectors/Reflector Tape Condition (Front/Sides/Rear)</li> <li>(Dash Indicators for:)</li> <li>• Left Turn Signal</li> <li>• Right Turn Signal</li> <li>• Four-Way Emergency Flashers</li> <li>• High Beam Headlight</li> <li>• Headlights</li> <li>• Taillights</li> <li>• Backing Lights</li> <li>• Brake Lights</li> <li>• Red Reflectors &amp; Amber Reflectors</li> </ul>
Reflective Tape Condition
□ Horn
☐ Heater/Defroster
□ Brakes
Parking Brake Check
Hydraulic Brake Check
Air Brake Check (if equipped)
Service Brake Check
Safety Belt
(TURN-OFF ENGINE/TURN-ON HEADLIGHTS *LOW BEAM* AND FOUR-WAY
FLASHERS)
STEP 4. WALK-AROUND INSPECTION
□ <b>4A</b> – Steering
Steering Box/Hoses
Steering Linkages
□ 4B – Suspension
Springs/Air/Torque
Mounts
Shock Absorbers
□ 4C – Brakes
Slack Adjustors & Pushrods     Pushs Chambara
Brake Chambers
Brake Hoses/Lines

Drum Brake Brake Linings

<ul> <li>4D – Wheels</li> <li>Rims</li> <li>Tires</li> <li>Hub Oil Seals/Axle Seals</li> <li>Lug Nuts</li> <li>Spacers &amp; Budd Spacing</li> </ul>
DE OF VEHICLE  4E – Doors  4E – Mirrors  4E – Fuel Tank  4E – Storage Bins/Storage Bin Doors  4E – Frame
<ul> <li>ECIAL EQUIPMENT</li> <li>4F – Pick-up Head Assembly</li> <li>Pick-up Head Deck</li> <li>Skid Plates</li> <li>Curtains</li> <li>Springs, Chains, and Shackles/Pins</li> <li>Hydraulic Lift Cylinders</li> <li>Drag Bars</li> <li>Inlet Hose</li> <li>Outlet Hose</li> <li>Pressure Bleeder Door and Cable</li> <li>Agitator Broom, if applicable.</li> </ul>
<ul> <li>4G – Gutter Broom Assemblies</li> <li>Gutter Broom Mounting Plates</li> <li>Control Arms</li> <li>Bristles</li> <li>Springs</li> <li>Hydraulic Motors</li> <li>Hydraulic Lines</li> </ul>
<ul> <li>4H – Water System</li> <li>Tank and Fill Hose</li> <li>Pump(s)</li> <li>Water Filter(s)</li> <li>Water Lines</li> <li>Nozzles</li> <li>4I – Front Bumper Magnet</li> </ul>

Figure A2.1. Sweeper Vehicle Inspection Guide.



#### **Attachment 3**

#### PERFORMANCE TEST

## A3.1. Desired Learning Outcome.

- A3.1.1. Understand the safety precautions to be followed pre-, during-, and post-operation of the sweeper.
- A3.1.2. Understand the purpose of the sweeper and its role in the mission.
- A3.1.3. Know the proper operator maintenance procedures of the sweeper, IAW applicable technical manuals and use of Air Force (AF) Form 1800.
- A3.1.4. Safely and proficiently operate the sweeper.
- **A3.2. Instructions.** Before beginning the performance test, the trainer will brief the trainee on the scenario that will need to be accomplished. He/she will be given additional directions and instructions as needed throughout the scenario.

## A3.3. Scoring.

- A3.3.1. The trainer examiner will be scoring the trainee on sweeper operations and also the general safe driving practices. The examiner will give directions and instructions to the trainee in sufficient time for him/her to execute a driving maneuver. They will not be asked to drive in an unsafe manner.
- A3.3.2. The examiner will be making various marks on the performance test checklist. This does not necessarily mean anything has been done wrong. It is in the best interest to concentrate on the operation of the sweeper. The trainer will explain the test results at the conclusion of the performance test.
- A3.3.3. Tasks being graded are listed on the following page; the trainee will be required to successfully pass all items.
- A3.3.4. The instructor will stop the test at any time safe operations are not being followed or as deemed necessary for safety concerns.

Figure A3.1. Performance Test Checklist:

PER	FORMA	NCE TEST		
Trainees Name: Date:				
Event	Go	No Go		
1. PRE, DURING, AND POST- OPE	RATIO	N		
INSPECTION				
1.1. Operator has required Personal				
Protective Equipment.				
1.2. Follows general pattern of pre-trip				
checklist.				
1.3. Performs brake component check				
1.4. Signs AF Form 1800 to signify				
accomplishment of complete				
inspection.				
1.5. Cleans windshield, windows,				
mirrors, lights and reflectors				
1.6. Continues during operations				
inspection checks.	<u> </u>			
1.7. Knows use of jacks, tools,				
emergency devices, tire chains, fire				
extinguishers, etc.	<u> </u>			
1.8. Performs post trip inspection and				
reports malfunctions to Vehicle				
Management.				
Event	Go	No Go		
2. BASIC CONTROL AND VEHICI	LE OPE	RATION		
2.1. Safety belt is used; obeys all				
traffic signs, signals, and laws;				
completes test without an accident or				
moving violation.				
2.2. Avoids jerky starts and stops.				
2.3. Does not cut corners sharply.				
2.4. Maintains proper speed and space.				
* * *				
2.5. Ensure proper sweeper safety				
practices. List safety violations.				
2.6. Turns - checks traffic in all				
directions; uses turn signals and safely				
get into the lane needed for the turn;				
slows down smoothly, changes gears				
as needed to keep power; checks				
mirrors to ensure proper clearance;				
vehicle should not move into				
oncoming traffic.				

2.7. Stopping - decelerates smoothly,			
brakes evenly, changes gears as			
necessary; brings vehicle to a full stop			
without coasting.			
2.8. Starting - checks traffic, avoids			
jerky starts.			
Event	Go	No Go	Notes
3. KNOWLEDGE OF VEHICLE AN	ID USE C	F	
CONTROLS			
3.1. Engine:			
Uses proper starting procedures			
Allows proper warm-up.			
Understands all gauges.			
Uses proper shutdown procedures.			
Basic knowledge of engines.			
3.2. Clutch and Transmission.			
Understands proper clutching			7
techniques.			
Uses clutch properly through all gears.			
Shifts smoothly.			
Time shifts properly.			
Avoids riding the clutch.			
Proper use of tachometer and shifting			
range.			
3.3. Brakes and Braking Techniques			
Understands the principles of an air			
brake system.			
Knows proper use of the protection			
valve.			
Knows proper use of the hand valve.			
Understands the low air warning.			
Uses proper techniques on			
downgrades.			
Understands the principle of front			
wheel limiting switch.			
Proper use of parking brake.			
Ensures air tank is at full tank pressure			
prior to moving the vehicle.			
Performs brake check before pulling			
out.			

4. BacKING/PARKING 4.1. Backing.  Positions properly.  Inspects before backing.  Uses spotters properly.  Uses mirrors properly.  Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments. 5.2. Filling the tank/water system operation. 5.3. Left/right seat operations. 5.4. Hand suction hose operations. 5.5. Hopper clean out operations.  CERTIFIER COMMENTS:	Event	Go	No Go	Notes	
Positions properly.  Inspects before backing.  Uses spotters properly.  Uses mirrors properly.  Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	4. BACKING/PARKING				
Inspects before backing.  Uses spotters properly.  Uses mirrors properly.  Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	4.1. Backing.				
Uses spotters properly.  Uses mirrors properly.  Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Positions properly.				
Uses mirrors properly.  Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Inspects before backing.				
Avoids blind side backing.  Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Uses spotters properly.				
Controls speed.  4.2. Parking.  Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Uses mirrors properly.				
4.2. Parking. Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely. Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments. 5.2. Filling the tank/water system operation. 5.3. Left/right seat operations. 5.4. Hand suction hose operations. 5.5. Hopper clean out operations.	Avoids blind side backing.				
Checks traffic position before parking.  Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Controls speed.				
Secures vehicle properly.  Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	4.2. Parking.				
Parks legally and safely.  Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Checks traffic position before parking.				
Uses emergency warning devices, if required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Secures vehicle properly.				
required.  5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	Parks legally and safely.				
5. SWEEPER OPERATIONS  5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.					
5.1. Pick-up head and gutter brooms adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.					
adjustments.  5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.		1	,		
5.2. Filling the tank/water system operation.  5.3. Left/right seat operations.  5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	1				
5.3. Left/right seat operations. 5.4. Hand suction hose operations. 5.5. Hopper clean out operations.	5.2. Filling the tank/water system				
5.4. Hand suction hose operations.  5.5. Hopper clean out operations.	operation.				
5.5. Hopper clean out operations.	5.3. Left/right seat operations.				
	5.4. Hand suction hose operations.				
CERTIFIER COMMENTS:					
	<b>CERTIFIER COMMENTS:</b>				

# **Attachment 4**

# SEVEN-STEP INSPECTION PROCESS

Figure A4.1. Seven-Step Inspection Process.

Review the AF Form 1800. Ensure any discrepancy has been corrected. Vehicle Management annotated the discrepancy was completed. Approaching the vehicle. Damage or vehicle leaning to one side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The operator may have to raise the hood,
Ensure any discrepancy has been corrected.  Vehicle Management annotated the discrepancy was completed.  Approaching the vehicle.  Damage or vehicle leaning to one side.  Fresh leakage of fluids.  Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
corrected. Vehicle Management annotated the discrepancy was completed. Approaching the vehicle. Damage or vehicle leaning to one side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
Vehicle Management annotated the discrepancy was completed. Approaching the vehicle. Damage or vehicle leaning to one side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
discrepancy was completed. Approaching the vehicle. Damage or vehicle leaning to one side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
Approaching the vehicle.  Damage or vehicle leaning to one side.  Fresh leakage of fluids.  Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
Damage or vehicle leaning to one side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
side. Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
Fresh leakage of fluids. Hazards around vehicle.  Note: Check that the parking brakes are on and/or wheels chocked. The
Note: Check that the parking brakes are on and/or wheels chocked. The
<b>Note:</b> Check that the parking brakes are on and/or wheels chocked. The
are on and/or wheels chocked. The
tilt the cab (secure loose things so they don't fall and break something), or open the engine compartment door.  Check the following: Engine oil level. Coolant level in radiator; condition of hoses.  Power steering fluid level; hose condition (if so equipped).  Windshield washer fluid level. Battery fluid level, connections and tie-downs (battery may be located elsewhere).  Automatic transmission fluid level (may require engine to be running). Check belts for tightness and excessive wear (alternator, water pump, air compressor)learn how much "give" the belts should have when adjusted right.

	1	
	0	Leaks in the engine compartment (fuel, coolant, oil, power steering fluid, hydraulic fluid, battery fluid). Cracked, worn electrical wiring insulation.
2 Stort Engine and Inspect Inside the Cal-	_	
3. Start Engine and Inspect Inside the Cab (Get in and Start Engine)	•	Make sure parking brake is on. Put gearshift in neutral (or park if automatic). Start engine; listen for unusual noises.
	•	If equipped, check the Anti-lock Braking System (ABS) indicator lights. Light on dash should come on and then turn-off. If it stays on the ABS is not working properly.
	•	Look at the gauges.
	0	Oil pressure. Should come up to normal within seconds after engine is started.
	0	<u>Air pressure</u> . Pressure should build from 50 to 90 psi within 3 minutes.
		Build air pressure to governor cut-out (usually around 120 – 140 psi. Know
		the vehicle's requirements.
	0	Ammeter and/or voltmeter. Should be in normal range(s).
	0	<u>Coolant temperature</u> . Should begin gradual rise to normal operating range.
	0	Engine oil temperature. Should begin gradual rise to normal operating
	0	range. <u>Warning lights and buzzers</u> . Oil, coolant, charging circuit warning,
		and antilock brake system lights should go out right away.
	0	Check Condition of Controls. Check all of the following for looseness,
		sticking, damage, or improper setting:
	0	Steering wheel.
	0	Clutch.
	0	Accelerator (gas pedal).
	0	Brake controls.
	0	Foot brake.
	0	Parking brake.
	0	Transmission controls.
		Tunomiosion controls.

		I-41- 1:ff4:-111-(:f1::-1-
	0	Interaxle differential lock (if vehicle
		has one).
	0	Horn(s).
	0	Windshield wiper/washer.
	0	Lights.
	0	Headlights.
	0	Dimmer switch.
	0	Turn signal.
	0	Four-way flashers.
	0	Parking – clearance – identification – marker switch (switches).
		Check mirrors and windshield.
	0	Inspect mirrors and windshield for
	0	cracks, dirt, illegal stickers, or other
		obstructions to seeing clearly. Clean
		and adjust as necessary.
		•
	-	Check emergency equipment.
	0	Check for safety equipment:
	0	Spare electrical fuses (unless vehicle
		has circuit breakers).
	0	Three red reflective triangles, 6 fuses
		or 3 liquid burning flares.
	0	Properly charged and rated fire
		extinguisher. Check for optional
		items such as:
	0	Chains (where winter conditions
		require).
	0	Tire changing equipment.
	0	List of emergency phone numbers
		Accident reporting kit (packet).
	0	Check safety belt. Check that the
		safety belt is securely mounted,
		adjusts; latches properly and is not
		ripped or frayed.
4. Turn-off Engine	•	Make sure the parking brake is set,
		turn-off the engine, and take the key
		with.
	•	Turn-on headlights (low beams) and
		four-way emergency flashers, and get
		out of the vehicle.
		out of the femele.

#### 5. Do Walk-Around Inspection General. Go to front of vehicle and check that 0 low beams are on and both of the four-way flashers are working. Push dimmer switch and check that 0 high beams work. Turn-off headlights and four-way 0 emergency flashers. Turn-on parking, clearance, side-0 marker, and identification lights. Turn-on right turn signal, and start 0 walk-around inspection. Walk around and inspect. 0 Clean all lights, reflectors, and glass 0 as while doing the walk-around inspection. Left front side. Driver's door glass should be clean. 0 Door latches or locks should work 0 properly. Left front wheel. Condition of wheel and rim--0 missing, bent, broken studs, clamps, lugs, or any signs of misalignment. Condition of tires--properly inflated, 0 valve stem and cap OK, no serious cuts, bulges, or tread wear. Use wrench to test rust-streaked lug 0 nuts, indicating looseness. Hub oil level OK, no leaks. Left 0 front suspension. 0 Condition of spring, spring hangers, shackles, U-bolts. Shock absorber condition. 0 Left front brake. Condition of brake drum or disc. 0 Condition of hoses. 0 Front Condition of front axle. Condition of 0 steering system. No loose, worn, bent, damaged or 0 missing parts. Mustgrab steering mechanism to test 0

for looseness.

0

Condition of windshield.

- o Check for damage and clean if dirty.
- Check windshield wiper arms for proper spring tension.
- Check wiper blades for damage, "stiff" rubber, and securement.
- o Lights and reflectors.
- o Parking, clearance, and identification lights clean, operating, and proper color (amber at front).
- Reflectors clean and proper color (amber at front).
- o Right front turn signal light clean, operating, and proper color (amber or white on signals facing forward).
- Right side
- o Right front: check all items as done on left front.
- Primary and secondary safety cab locks engaged (if cab-over-engine design).
- o Right fuel tank(s).
- o Securely mounted, not damaged, or leaking. Fuel crossover line secure.
- o Tank(s) contain enough fuel. Cap(s) on and secure.
- Condition of visible parts. Rear of engine--not leaking. Transmission-not leaking.
- o Exhaust system--secure, not leaking, not touching wires, fuel, or air-lines.
- o Frame and cross members--no bends or cracks.
- o Spare tire carrier or rack not damaged (if so equipped).
- O Spare tire and/or wheel securely mounted in rack.
- Spare tire and wheel adequate (proper size, properly inflated).
- Curbside cargo compartment doors in good condition, securely closed, latched/locked and required security seals in place.
- Right rear.
- Condition of wheels and rims--no missing, bent, or broken spacers, studs, clamps, or lugs.

- Condition of tires--properly inflated, valve stems and caps OK, no serious cuts, bulges, tread wear, tires not rubbing each other, and nothing stuck between them. Tires same type, e.g., not mixed 0
- radial and bias types.
- Tires evenly matched (same sizes). Wheel bearing/seals not leaking.
- Suspension. 0
- Condition of spring(s), spring 0 hangers, shackles, and u-bolts.
- Axle secure. 0
- Powered axle(s) not leaking lube 0 (gear oil). Condition of torque rod arms, bushings.
- Condition of shock absorber(s). 0
- If retractable axle equipped, check 0 condition of lift mechanism. If air powered, check for leaks.
- Condition of air ride components. 0
- Brakes. 0
- Brake adjustment. 0
- Condition of brake drum(s) or discs. 0
- Condition of hoses--look for any 0 wear due to rubbing.
- Lights and reflectors. 0
- Side-marker lights clean, operating, 0 and proper color (red at rear, others amber).
- Side-marker reflectors clean and 0 proper color (red at rear, others amber).
- Rear.
- Lights and reflectors. 0
- Rear clearance and identification lights clean, operating, and proper color (red at rear).
- Reflectors clean and proper color 0 (red at rear).
- Taillights clean, operating, and 0 proper color (red at rear).
- Right rear turn signal operating, and 0 proper color (red, yellow, or amber at rear).

	0	License plate(s) present, clean, and
		secured.
	0	Splash guards present, not damaged, properly fastened, not dragging on
		ground, or rubbing tires.
	0	Rear doors securely closed, latched/locked.
		Left side.
		Check all items as done on right side,
	0	plus:
	0	Battery (batteries) (if not mounted in engine compartment).
	0	Battery box (boxes) securely
		mounted to vehicle. Box has secure cover.
	0	Battery (batteries) secured against movement. Battery (batteries) not
		broken or leaking.
	0	Fluid in battery (batteries) at proper
		level (except maintenance-free type).
	0	Cell caps present and securely tightened (except maintenance-free
		type).
	0	Vents in cell caps free of foreign
		material (except maintenance-free
		type).
6. Check Signal Lights	•	Get in and turn-off all lights.
	•	Turn-on stop lights (apply trailer
		hand brake or have a helper put on
		the brake pedal).
	•	Turn-on left turn signal lights.
	•	Get out and check lights.
	•	Left front turn signal light clean,
		operating and proper color (amber or white on signals facing the front).
		Left rear turn signal light and both
	-	stop lights clean operating, and
		proper color (red, yellow, or amber).
	•	Get in vehicle.
	0	Turn-off lights not needed for
		driving.
	0	Check for all required papers, trip manifests, permits, etc.

	0	Secure all loose articles in cab (they might interfere with operation of the controls or hit the operator in a crash).
	0	Start the engine.
7. Start the Engine and Check Test for	•	Test for hydraulic leaks.
Hydraulic Leaks	0	If the vehicle has hydraulic brakes,
		pump the brake pedal three times.
	0	Then apply firm pressure to the pedal
		and hold for five seconds.
	0	The pedal should not move. If it
		does, there may be a leak or other problem.
		Brake system.
		Test parking brake.
		Fasten safety belt.
	0	Set parking brake (power unit only).
		Place vehicle into a low gear.
	0	Gently pull forward against parking
		brake to make sure the parking brake
		holds.
	0	If it doesn't hold vehicle, it is faulty; get it fixed.
	•	Test service brake stopping action.
	0	Go about 5 miles per hour.
	0	Push brake pedal firmly.
	0	"Pulling" to one side or the other can mean brake trouble.
	0	Any unusual brake pedal "feel" or
		delayed stopping action can mean
		trouble.
	0	If the trainee finds anything unsafe
		during the Vehicle inspection, get it
		fixed. Federal and state laws forbid
		operating an unsafe vehicle.
	•	Check vehicle operation regularly:
	0	Instruments.
	0	Air pressure gauge (if the vehicle has air brakes). Temperature gauges.
	0	Pressure gauges.
		Ammeter/voltmeter.
	0	Mirrors.
	0	Tires.
	0	Cargo, cargo covers. Lights, etc.

o If the trainee sees, hears, smells, or
feels anything that might mean
trouble, he/she should check it out.
Safety inspection.
<ul> <li>Drivers of trucks and truck tractors</li> </ul>
when transporting cargo must inspect
the securement of the cargo within
the first 50 miles of a trip and every
150 miles or every 3 hours
(whichever comes first) after.
Document any discrepancy on AF
Form 1800. Sign-off AF Form 1800
to signify accomplishment of
inspection.

Figure A4.2. Additional Steps for Inspecting Air Brakes System.

Additional Steps for Inspecting Air Brakes		
Step	Procedure	
2. Engine Compartment Checks	• Check air compressor drive belt condition and tightness (if compressor is belt driven).	
5. Walk-Around Inspecting	Check manual slack adjusters on S-cam brakes. <b>Note:</b> Vehicles with automatic slack adjustors still must be checked.	
	o Park on level ground and chock the wheels.	
	o Release the parking brakes so the operator can move the slack adjusters.	
	Use gloves and pull hard on each slack     adjuster that it can be reached.	
	<ul> <li>Check slack adjuster, more than 1-inch indicates adjustments required (vehicles with too much brake slack can be very hard to stop). Adjust it or have it adjusted.</li> <li>Check brake drums (or discs), linings, and</li> </ul>	
	hoses.	
7. Final Air Brake Check o	Test low pressure warning signal.	
	o Turn the electrical power on.	
	Step on and off the brake pedal to reduce air tank pressure.	
	O Low air pressure warning signal should come on before the pressure drops to less than 60 psi in the air tank with lowest pressure.	

- Check that the spring brakes come on automatically.
- o Chock the wheels.
- o Release the parking brakes when enough air pressure is built up.
- o Shut the engine off.
- Step on and off the brake pedal to reduce the air tank pressure.
- o "Parking brake" knob should pop out when the air pressure falls to the manufacturer's specification.
- Check rate of air pressure buildup
- Refer to manufacturer's recommendation for average buildup time.
- o If not within recommended time, the air pressure may drop too low during driving operations.
- Test air leakage rate.
- O With a fully-charged air system (typically 125 psi).
- o Turn-off the engine.
- o Release the service brake and time the air pressure drop.
- O The loss rate should be less than 2 psi in one minute for single vehicles.
- o Not less than 3 psi in 1 minute for combination vehicles.
- Then apply 90 psi or more with the brake pedal.
- O After the initial pressure drop, if the air pressure falls more than 3 psi in 1 minute for single vehicles.
- o Not more than 4 psi for combination vehicles.
- Check air compressor governor cut-in and cut-out pressures.
- o Air compressor should start at about 100 psi and stop at about 125 psi.
- o Run the engine at a fast idle.
- Air governor should cut-out the air compressor at about the manufacturer's specified pressure.
- o Engine idling, step on and off brake to reduce air tank pressure.
- O Compressor should cut-in at manufacturer's specified cut-in pressure.

