























Comment	Description	Designator	Footprint	LibRef	Quantity
USER	SE PUSHBUTTON	B1	BUTTON	SW PUSHBUTTON	1
CR1220	PUSHBUTTON Battery	BT1	LI1220	BATTERY	1
10uF	C0603, Capacitor	C1, C8, C10, C11, C12, C20, C21, C36, C37, C38, C48, C56, C70	C0805	10uF, Cap	13
0.1uF	C0603, Capacitor	C2, C3, C4, C5, C8, C7, C9, C13, C14, C15, C16, C17, C18, C19, C22, C23, C24, C25, C27, C28, C29, C30, C31, C32, C33, C34, C35, C42, C43, C44, C45, C46, C47, C49, C50, C51, C53, C88, C69, C71, C76, C77, C79, C81,	C0603	0.1uF, Cap	45
		C60, C61, C62,			
2.2uF	C0603	C60, C61, C62, C64, C65, C66,	C0603	0.1uF	4
18pF 100pE/50\/	C0603	C72, C73, C74,	C0603	0.1uF	4
100nF/50V HR911105A	Capacitor	CN1	C0603 HR911105A	Cap HR911105A	4
DC-10B		CN2	DC10B	PJ202A	1
DB9-male CAN					
connector		CN4	DB9/FM	DB9	1
USB2.1	Connector	CN5	USB-B2	USB2.1	1
LED	Typical RED	D3, D4, D5, D6, D7, D8, D9, D10.	LED-0805	LED	11
	GaAs LED	D11, D14, D15			
1N4148	Schottky Diode	D16, D17	D1210	D Schottky	2
LED0	Typical INFRARED GaAs	D18, D19, D20, D21, D22	LED-0805	LED0	5
DS18B20	Header, 3-Pin	DS1	DS18B20	Header 3	1
			JIEKE2EDG5.08	1	
JPIN4		J1, J3	PIN4	JPIN4	2
2PIN		J2, J4, J5, J6, J8,	2PIN	2PIN	6
JATG	 	J11 J7	HDR2X10	JATG	4
Mini SD ‡	1	J9	SD SD	sd+	
OV2640 OLED	1	J10 J17	20pin DIP2.54	HEADER10*2 OLED	1
220R,2.0A,0.05D					1
CR CR	Inductor	L1, L2	R0603	47uH	2
HS0038	Header, 3-Pin	P1	HS0038	Header 3	1
Header 16X2	Header, 16-Pin,	P2, P3, P4, P5	HDR2X16-2.54	Header 16X2	4
	Dual row				
4.87K	Resistor	R1	R0603	R0603	1
2.2k	Resistor	R2, R4, R6, R7, R9, R11, R14, R16, R17	R0603	R0603	9
10K	Resistor	R3, R5, R10, R22, R34, R43, R44, R45, R46, R47, R48, R49, R50, R51, R52, R61, R66, R67, R68, R69, R77, R83, R84, R89	R0603	R0603, Res2	24
33	Resistor	R8, R18, R19, R20, R30, R70, R71, R72, R73, R92, R98, R99,	R0603	R0603	16
		R100, R101,			
1.5k	Resistor	R12 R13, R15, R54,	R0603	R0603	1
470	Resistor	R62, R63, R64, R65	R0603	R0603, Res2	7
10	Resistor	R21, R23, R80,	R0603	R0603	4
	Resistor	R88 R24, R31, R32, R37, R38, R39, R42, R76, R81, R85, R87	R0603	R0603	11
49.9	Resistor	R25, R26, R27,	R0603	R0603	4
4.7K	Resistor	R28 R33, R35, R57, R58, R74, R75,	R0603	R0603	9
		R78, R90, R102 R36, R82, R86,			9
120	Resistor	R91	R1206	R0603, R1206	4
100	Resistor	R40, R41, R55,	R0603	R0603, Res2	5
		R56, R60			,
1M	Resistor	R53	R0603	R0603	1
5.1K	Resistor	R59	R0603	Res2	1
0	Resistor	R79	R0603	Res2	1
33(NC)	Resistor	R105	R0603	R0603	1
SW-PB DP83848IVV	Switch	S1, S2, S3, S4	BUTTON	SW-PB DP83848IVV	4
		U1	LQFP48		1
SPX1117M3		U2	SOT223	SPX1117M3	1
SP485		U3, U6	SO8	MAX485	2
TJA1050		U4, U5	SO8	PCA82C251T	2
MAX232ESA		U7	SO16	max232	1
	STM32F407ZET6	U8	LQFP144	STM32F407ZET6	1
STM32F407ZET6		U9	SO8	AT24C02BN-SH-	1
STM32F407ZET6 AT24C02BN		U10	NRF24L01	NRF24L01	1
STM32F407ZET6 AT24C02BN NRF24L01/W550/					
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522					
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522 SST25VF016B		U11	SST25VF040B	SST25VF080B	
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522 SST25VF016B USB		U11 U12	USB\S	USBD	1
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522 SST25VF016B USB ESP8266		U11 U12 U13	USB\S NRF24L01	USBD ESP8266	1
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522 SST25VF016B USB ESP8266 50Mhz		U11 U12 U13 X1	USB\S NRF24L01 OSC5032	USBD ESP8266 有源晶振	1 1
STM32F407ZET6 AT24C02BN NRF24L01/W550/ RC522	Crystal Crystal	U11 U12 U13	USB\S NRF24L01	USBD ESP8266	1 1 1