

Digial InPins

D1 (Pin 5), D2 (Pin 4), D4 (Pin 2), D5 (Pin 14), D6 (Pin 12), D7 (Pin 13), D8 (Pin 15), D9 (Pin 3), D10 (Pin 1)

onboard LED --> D0 / Pin 16 | onboard LED 2 --> D4 (Pin 2) onboard Button --> D3 / Pin 0

Analog Output

pin 0-15 --> analogWrite(pin, value) | value --> 0-1023 set new value range analogWriteRange(new_range) WM frequency is 1kHz by default. set new frequency --> analogWriteFreq(new_frequency)

Analog Input

ADC pin --> analogRead(A0) | value --> 0-1023