

	2	PLATES ARRAY - ASSEMBLY	2120100	ASM	00	
		Duct tape	00000000	Buy	00	
	#	NAME	DRW No.	SUPPLIAR	CATALOG NO.	QNT
11			[PART NAME		

HYDROGEN
First Aid

	1 //// 1 //////							
		Plo	ates a	rray -	Wrappi	ing		
WWW.HYDROGEN-FIRST-AID.COM								
	Designer	Pavlo K.		DRAWING	NUMBER	MATERIAL		

Drawer Pavlo K.

Approver Pavlo K.

TOLERANCES (MM UNLESS OTHERWISE SPECIFIED)

0.5 UPDATE

0.5° 00



NOTES
----I) ITEM I CAN BE REPLACED WITH SHRINK WRAP