



3	Worm drive clamp 145 MM	0000000	Виу	00	2
2	Filter body	000000	Виу	00	
	Bubbler - Assembly	2120500	ASM	0 0	
#	NAME	DRW No.	SUPPLIAR	CATALOG NO.	QNT

11	PART NAME						
HYDROGEN	Body with bubbler - Assembly						
Tives Aid	WWW.HYDROGEN-FIRST-AID.COM						
First Aid	Designer	Pavlo K.		DRAWING NUMBER	MATERIAL		
	Drawer	Pavlo K.		2120600 -	_		
	Approver	Pavlo K.		2120000			
	TOLERANCES (MM UNLESS OTHERWISE SPECIFIED)		SUPPLIER	CATALOG NUMBER			
			ASM	0 0			
The second secon	±	0.5	·	UPDATE			
Δ3	±	0 5°		0			