

## NOTES

- 1) ITEM I AND 2 ARE PART OF:
  Compression Elbow 1/4" x 3/8" OD TUBE
  2) INSERT THE TUBE INTO THE ELBOW BODY.
- 3) CLOSE THE NUT OVER THE BODY WITH THE TUBE INSIDE.

3	Tube ID 1/4" OD 3/8" length 4"	0000000	Buy	00	
2	Elbow Nut	0000000	Виу	00	
	Elbow body	0000000	Виу	00	
#	NAME	DRW No.	SUPPLIAR	CATALOG NO.	QNT

and the second	PART NAME						
HYDROGEN	Elbow with tube - Assembly						
Fives Aid	<u>WWW.HYDROGEN-FIRST-AID.COM</u>						
First Aid	Designer	Pavlo K.		DRAWING NUMBER	MATERIAL		
	Drawer	Pavlo K.		2120710	_		
	Approver	Pavlo K.		2120110			
	TOLERANCES		SUPPLIER	CATALOG NUMBER			
	(MM UNLESS OTHERWISE SPECIFIED)		ASM	$\bigcirc \bigcirc$			
Total Transfer	±	0.5		UPDATE			
A 3	±	0.5°		0 0			