III. ELECTRICAL CONDUCTORS

A. MATERIAL INFORMATION

- 1. Provide Type XHHW insulated conductors. Color code insulated conductors in conformance with the NEC. Identify grounded (neutral) conductors with white insulation. Identify grounding conductors (ground wires) with green insulation or bare conductors. Identify ungrounded (hot) conductors with any color insulation except green, white, or gray. Keep color scheme consistent throughout the wiring system. Identify conductors 6 American Wire Gauge (AWG) and smaller by continuous color jacket. Identify electrical conductors 4 AWG and larger by continuous color jacket or by colored tape. When identifying conductors with colored tape, mark at least 6 in. of the conductor's insulation with half laps of tape.
- 2. Provide a solid copper 6 AWG grounding electrode conductor to bond the electrical service equipment to the concrete encased grounding electrode or the ground rod at the service location. Connect the grounding electrode conductor to the ground rod with a UL listed connector. Connect the grounding electrode conductor to the concrete encased grounding electrode as shown in the plans.
- 3. Where two or more circuits are present in one conduit or enclosure, permanently identify the conductors of each branch circuit by attaching a non-metallic tag around both circuit conductors at each accessible location. Provide tags with two straps, large enough to indicate circuit number, letter, or other identification as shown in the plans. Print circuit identification on the tag with a permanent marker.
- 4. Use listed taped butt splices, terminal blocks, or split bolt connectors for splicing. Use electrical tape for each individual splice and for all of the splices together to seal the connection a minimum of 2 inches from the end of the cut insulation. Splicing materials, breakaway disconnects, splice covers, and fuse holders are subsidiary to various bid items.

B. CONSTRUCTION METHODS

- 1. Use only a flat, high tensile strength polyester fiber pull tape for pulling conductors through the conduit system. After installing conductors in conduit, perform conductor pull test. If a conductor cannot be freely pulled, make any needed alterations or repairs at no additional cost to the City. Perform insulation resistance tests when required by the City. Ensure that each continuous run of insulated conductor has a minimum DC resistance of 5 Megohms when tested at 1,000 volts DC. Coordinate with the City to witness the tests.
- 2. Leave 6 ft. length of conductor in ground boxes. Leave 1.5 ft. length of conductor at enclosures, weatherheads and pole bases.
- 3. Make splices only in junction boxes, ground boxes, pole bases, or electrical enclosures and use only diapered butt splices for one to one splices or split bolt connectors for many to one splices. Insulate splices with electrical tape, followed by rubber tape, then another layer of electrical tape to provide a watertight splice. Overlap conductor insulation with electrical tape a minimum of 2 in. past both sides of the splice.
- 4. For connections to source power, an insulated multi-tap (block) connector may be used.
- 5. Wire nuts with factory applied waterproof sealant may be used for 8 AWG or smaller conductors in above ground junction boxes, but not in pole bases or ground boxes. Install wire nuts in an upright position to prevent the accumulation of water.
- 6. When terminating conductors, remove the insulation and jacketing material without nicking the individual strands of the conductor. Conductors with nicked individual conductor strands or removed strands will be considered damaged.
- 7. Replace conductors and cables that are damaged beyond repair or that fail an insulation resistance test at no additional cost to the City.
- 8. Do not repair damaged conductors with duct tape or wire nuts. Use only approved splicing methods.
- 9. Do not terminate more than one conductor under a single connector, unless the connector is rated for multiple conductors. Do not exceed the pressure connector's listing for maximum number and size of conductors allowed.
- 10. Install breakaway connectors on conductors whenever those conductors pass through a breakaway support device. Follow manufacturer's instructions when terminating conductors to breakaway connectors. Properly torque threaded connections. Proper terminations are critical to the safe operation of breakaway devices. Trim waterproofing boots on breakaway connectors to fit snugly around the conductor to ensure waterproof connection. Only one conductor may enter a single opening in a boot. Provide waterproof bboots with the correct number of openings. Leave unused openings factory sealed.
- 11. Provide and install a separate stranded equipment grounding conductor in all conduits that contain circuit wiring of 50 volts or more. Unless shown elsewhere, size the EGC to be the same size as the largest current carrying conductor contained in the conduit. Ensure all EGCs are bonded together at every accessible location. For traffic signal installations, provide a minimum size 8 AWG EGC.

CITY OF AUSTIN DEPARTMENT OF PUBLIC WORKS		TRAFFIC SIGNAL ELECTRICAL NOTES AND DETAILS	
ADOF	TED	THE ARCHITECT/ENGINEER ASSUMES RESPONSIBILITY FOR APPROPRIATE USE OF THIS STANDARD.	STANDARD NO. 838-1 3 OF 8