

NOTES:

- 1. 1 X 20 CONDUCTOR PER SIGNAL STANDARD RUN FROM SIGNAL CABINET TO TERMINAL STRIP (SEE WIRING COLOR CODES ON DETAIL
- 2. 1 X 2CS (12 AWG IMSA-50-2) PER PED PUSH BUTTON TO SIGNAL CABINET (NO SPLICES)
- 3. PLACE HIGH VOLTAGE CABLES IN SEPARATE CONDUITS FROM LOW VOLTAGE WHEN POSSIBLE
- 4. WIRING TO SUPPLEMENTAL DEVICES PER MANUFACTURE RQMTS IF UNKNOWN, RUN DIRECTLY TO SIGNAL CABINET (NO SPLICES)
- DETAILED ELEVATION SHEETS MUST BE PROVIDED FOR EACH POLE IN THE DESIGN.
- 6. VERIFY DETECTION EQUIPMENT LOCATION(S) WITH THE CITY PRIOR TO INSTALLATION
- 7. SEE TABLE ON SHEET 3 FOR WIRE TERMINAL ASSIGNMENTS IN THE CABINET AND IN THE POLE BASE

CITY OF AUSTIN DEPARTMENT OF PUBLIC WORKS	PEDESTRIAN AND VEHICULAR SIGNAL WIRING	
ADOPTED	THE ARCHITECT/ENGINEER ASSUMES RESPONSIBILITY FOR APPROPRIATE USE OF THIS STANDARD.	STANDARD NO. 839-1 2 OF 3