THERMAL MANGEMENT SYSTEM OF A DRONE POD SYSTEM

Charlie Nitschelm

Thermal System

INTRODUCTION

The Reaper fitted with a Seaspray 7500E Drone Pod needs an efficient thermal management system to maintain a temperature of 20 °C during its entire flight. The pod will experience outside environments as cold as -20 °C during the peak of its flight, and 50 °C during takeoff. Specifically, given these conditions, what is the best-known refrigerant to use in the drone pods thermal management system that is most efficient for the conditionals it will experience, its environmental impact, safety handling and cost considerations.

REFRIGERANT SELECTION

To narrow down the selection of the desired refrigerant to three top choices, a performance analysis needs to happen on several widely used refrigerants. Once an array of refrigerants are selected for their particular performance in the Seaspray Drone Pod, other considerations can be made regarding to its environmental impact, safety handling and overall cost to determine the most desired refrigerant for the drone pod thermal management system.

PERFORMANCE ANALYSIS

MATLAB and CoolProps is utilized to numerically calculate the coefficient of performance (COP) of any refrigerant that could be used as the working fluid of the drone pod thermal management system. The figure below details the differences in COP of various types of refrigerants used today. All detailed graphs are within the appendix.




Figure 1 - Coefficient of Performance of Several Refrigerants

The graph tests five different types of refrigerants: R-Refrigerants like R410a, water and heavy water, isobutane and isobutene, MDM and cyclohexane, and lastly acetone and ammonia. The top four refrigerants with the highest COP with respect to the thermal management system of the drone pod at takeoff are acetone with a COP of 7.88, R123 with a COP of 7.55, ammonia with a COP of 7.40, and lastly R290 with a COP of 6.87.

ENVIRONMENT, SAFETY, COST & FLOW RATE

Very low to zero environmental harm, safe when the refrigerant is handled and the cost per kilogram of the refrigerant are all-important factors in choosing the desired propellant. The majority of acetone is released into the atmosphere by industrial purposes. It is flammable at room temperature and is a risk to the oxygen depletion in aquatic systems due to microbial consumption [1]. R123, the second most efficient refrigerant analyzed, has little to zero effect on the environment but can be toxic to people when applied to the body by accident [2]. Ammonia is the third most efficient refrigerant for the system, and has huge risks to the environment and people [3]. R290 is the fourth most efficient refrigerant, and has little to zero impact on the environment and is non-toxic to people when handling [4]. The required mass flow rate of the working fluid is also important to the final desired refrigerant. The figure below shows that amount of mass flow rate the thermal management system requires for a given outside temperature and refrigerant




Figure 2 - Mass Flow Rate of the Most Efficient Refrigerants

The monetary cost of the working fluid must also be reasonable. Acetone, R123, ammonia and R290 has a price per kilogram of \$20.00, \$3.00, \$8.00 and \$7.00,

respectively [4] [5] [6]. All of the prices are in reasonable range for the Department of Defense. This information on environmental impact, safety handling, cost and mass flow rate yields a desired refrigerant for the thermal management system of the drone pod. Acetone, although the most efficient and second least mass flow rate, is too dangerous regarding its environmental impact and safety. R123, the second most efficient refrigerant and highest mass flow rate, has nearly zero impact to the environment but can be toxic to people when handling. The third most efficient refrigerant, ammonia, is efficient and requires the least mass flow rate, but has huge risk to the environment and people. With the considerations of efficiency, mass flow rate, environmental impact, safety handling and cost, R290 is clearly the most desired refrigerant for the system.

VARIOUS ENVIRONMENTAL TEMPERATURES

R290, the fourth most efficient refrigerant and third least required mass flow rate, is non-toxic to people, thermally stable, and has little to zero effect on the environment. Now that the desired refrigerant, R290, is chosen, a more in depth look of the cycle can be brought forward. Below are the T-s, P-h and P-v diagrams of the R290 refrigeration cycle with the expected takeoff and apogee outside temperatures.




Figure 3 - T-s Refrigeration Cycle of R290




Figure 4 - P-h Refrigeration Cycle of R290




Figure 5 - P-v Refrigeration Cycle of R290

As the Drone Pod is taking off, it can encounter an outside temperature of almost 50 degrees Celsius. With that huge difference in outside temperature to a desired temperature of 20 degrees Celsius, a COP is calculated to be 6.67. However, when the Drone Pod rises to an altitude that causes the outside temperature to fall below the desired temperature inside the Drone Pod, the Drone Pod is assumed to be perfectly insulated. This then creates the outside temperature to just be the change in temperature for the condenser, which was selected to be 5 Kelvin. That COP is much higher at 55 because of the small temperature variation of the entire refrigeration cycle. If the Drone Pod was considered not perfectly insulated, a thermal management system must be designed to switch to a heat pump when the outside temperature falls below the desired internal temperature of the pod.

FINAL RECOMMENDATION

This report investigated the effect of different refrigerants applied to a thermal management system of the Seaspray Drone Pod with respect to its calculated COP. The best refrigerants for the system could then be investigated further for its environmental impact, safety handling and cost. The refrigerant is desired to have little to zero impact to the environment, poses little risk to overall handling, and minimal material cost. R290, the fourth most efficient refrigerant analyzed, was then selected as the desired refrigerant for the system as it is very efficient comparatively, low mass flow rate, safe to the environment, poses little to no threat to people, and has a very low material cost. If the requirements and preferences of the selected refrigerant changes, then another analysis could be required to determine the best refrigerant for the given conditions.

REFERENCES

- [1] "Risks and Benefits." Acetone, badacetone. weebly.com/risks-and-benefits.html.
- [2] Refrigerants, National. "R123 Safety Data Sheet." SDS, www.refrigerants.com/pdf/SDS%20R123.pdf.
- [3] "R290 (CARE 40) Propane." Linde Gas, www.linde-
- $gas.com/en/products_and_supply/refrigerants/natural_refrigerants/r290_propane/index.html.$
- [4] "Acetone | Price | per Kg | USD." PharmaCompass.com, www.pharmacompass.com/price/acetone.
- [5] "Buy Chemicals 99.9% Purity Cyclohexane 110-82-7 Buy Cyclohexane, Cyclohexane Price, Cas:110-82-7 Product on Alibaba.com." Www.alibaba.com, www.alibaba.com/product-detail/buy-chemicals-99-9-purity-Cyclohexane 60579895295.html?spm=a2700.7724838.2017115.51.4424711fe06nk3.
- [6] "Refrigerant Gas Cyclohexane R134a Buy Refrigerant Hfc 134a Good, Hfc R134a Refrigerant, Hfc 134a Refrigerant Product on Alibaba.com." Www.alibaba.com, www.alibaba.com/product-detail/refrigerant-gas-cyclohexane-R134a_1384971567.html.

APPENDIX

Detailed Figures




Figure 6 - Coefficient of Performance of Several Refrigerants




Figure 7 - Mass Flow Rate of Most Efficient Refrigerants




Figure 8 - T-s Refrigeration Cycle of R290




Figure 9 - P-h Refrigeration Cycle of R290




Figure 10 - P-v Refrigeration Cycle of R290

MATLAB Code

The code below utilized a single script with desired for loops to create the information necessary to write this report. Functions could have been used, but it would not have made debugging as easy, and was not necessary for the structure of this code.

```
clear all; close all
clc;
응응응응응응응응응응응응
% COP vs Outside Temperature for 3 Different Refrigerants
응응응응응응응응응응응응
Working Fluid 1 = {'R410a'};
Working Fluid 2 = \{'R290'\};
Working Fluid 3 = {'Ammonia'};
Working Fluid 4 = {'Water'};
Working Fluid 5 = \{'R22'\};
Working Fluid 6 = {'R114'};
Working Fluid 7 = {'IsoButane'};
Working Fluid 8 = {'MDM'};
Working Fluid 9 = {'R12'};
Working Fluid 10 = {'R143a'};
Working Fluid 11 = {'R123'};
Working Fluid 12 = {'Acetone'};
Working Fluid 13 = {'R404a'};
Working Fluid 14 = {'R125'};
Working Fluid 15 = \{'R134a'\};
Working Fluids
[Working Fluid 1, Working Fluid 2, Working Fluid 3, Working Fluid 4, Working Fluid 5, Working Flu
id 6, Working Fluid 7,...
Working Fluid 8, Working Fluid 9, Working Fluid 10, Working Fluid 11, Working Fluid 12, Working F
luid 13, Working Fluid 14, Working Fluid 15];
Outside Temperature = linspace(273 + 18 - 1, 273 + 50 + 2, 1000);
COP_R410a = zeros(1000);
\frac{-}{\text{COP R290}} = \text{zeros}(1000);
COP\_Ammonia = zeros(1000);
COP Water = zeros(1000);
               = zeros(1000);
COP R22
COP_R114 = zeros(1000);
COP_IsoButane = zeros(1000);
COP\_MDM = zeros(1000);
COP R12
                = zeros(1000);
COP_R123 = zeros(1000);

COP_R123 = zeros(1000);

COP_Acetone = zeros(1000);

COP_R404a = zeros(1000);

COP_R125 = zeros(1000);
COP_R134a
               = zeros(1000);
```

```
MFR_R410a = zeros(1000);

MFR_R290 = zeros(1000);

MFR_Ammonia = zeros(1000);
MFR Water = zeros(1000);
              = zeros(1000);
MFR R22
MFR R114 = zeros(1000);
MFR IsoButane = zeros(1000);
MFR\_MDM = zeros(1000);
MFR R12
              = zeros(1000);
MFR R143a
              = zeros(1000);
           = zeros(1000);
MFR R123
MFR R125
              = zeros(1000);
MFR R134a
              = zeros(1000);
\dot{1}=1;
for i = Working Fluids
    k=1;
    for temps = Outside Temperature
        Working Fluid 1 = Working Fluids{j};
        응응응응응응응응응응응응
        % Constants for the Refridgeration Cycle for Durham, NH
        Cold Space = 273+20; % Kelvin - Temperature of Cold Space of Pod
        88888888888888
        % Location 1 - Between Evaporator and Compressor
        8888888888888
        % Finding all values of the fluid at location 1
        Q 1 = 1; % Saturated Vapor
        T 1 = Cold Space; % Temperature from 4 to 1
        P 1 = CoolProp.PropsSI('P', 'T', T 1, 'Q', Q 1, Working Fluid 1);
        H 1 = CoolProp.PropsSI('H', 'T', T 1, 'Q', Q 1, Working Fluid 1);
        U 1 = CoolProp.PropsSI('U', 'T', T_1, 'Q', Q_1, Working_Fluid_1);
        S_1 = CoolProp.PropsSI('S', 'T', T_1, 'Q', Q_1, Working_Fluid_1);
        V 1 = 1/CoolProp.PropsSI('D', 'T', T 1, 'Q', Q 1, Working Fluid 1);
        88888888888888
        % Location 3 - Between Condensor and Expansion Valve - Saturated Liquid
        응응응응응응응응응응응응
        \mbox{\%} Finding all values of the fluid at location 3
        Q 3 = 0; % Saturated Liquid
        T 3 Summer = temps + 5; % Temperature from 4 to 1
        P 3 Summer = CoolProp.PropsSI('P', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
        H 3 Summer = CoolProp.PropsSI('H', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
        U 3 Summer = CoolProp.PropsSI('U', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
        S 3 Summer = CoolProp.PropsSI('S', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
```

```
V 3 Summer = 1/CoolProp.PropsSI('D', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
        8888888888888
        % Location 2 - Between Condensor and Expansion Valve Super-Heated Vapor
       % Finding all values of the fluid at location 2
        S 2 Summer = S 1; % Constant Entropy
        P 2 Summer = P 3 Summer; % Constant Pressure Isobar
        T 2 Summer = CoolProp.PropsSI('T', 'P', P 2 Summer, 'S', S 2 Summer,
Working Fluid 1);
        H 2 Summer = CoolProp.PropsSI('H', 'P', P 2 Summer, 'S', S 2 Summer,
Working Fluid 1);
        U 2 Summer = CoolProp.PropsSI('U', 'P', P 2 Summer, 'S', S 2 Summer,
Working Fluid 1);
        V 2 Summer = 1/CoolProp.PropsSI('D', 'P', P 2 Summer, 'S', S 2 Summer,
Working Fluid 1);
        응응응응응응응응응응응응
        % Location 2a - On Vapor Dome During the process 2 to 3 in condensor
        888888888888888
        % Finding all values of the fluid at location 2a
        Q 2a=1; % On Vapor Dome as Saturdated Vapor
        P 2a Summer = P 2 Summer; % Isobar = Constant Pressure
        T 2a Summer = T 3 Summer; % Constant Temperature from T3
        S 2a Summer = CoolProp.PropsSI('S', 'P', P 2a Summer, 'Q', Q 2a, Working Fluid 1);
        H 2a Summer = CoolProp.PropsSI('H', 'P', P 2a Summer, 'Q', Q 2a, Working Fluid 1);
        U_2a_Summer = CoolProp.PropsSI('U', 'P', P_2a_Summer, 'Q', Q_2a, Working_Fluid_1);
        V 2a Summer = 1/CoolProp.PropsSI('D', 'P', P 2a Summer, 'Q', Q 2a, Working Fluid 1);
        88888888888888
        \mbox{\ensuremath{\$}} Location 4 - Mixture between the expansion valve and evaporator
        응응응응응응응응응응응응
        % Finding all values of the fluid at location 4
        T 4 = T 1; % Constant Temperature from 4 to 1 Process
        H 4 Summer = H 3 Summer; % Expansion Valve is ~ constant enthalpy process
        P 4 Summer = P 1; % Isobaric Process
        U 4 Summer = CoolProp.PropsSI('U', 'P', P_4_Summer, 'H', H_4_Summer,
Working Fluid 1);
        S 4 Summer = CoolProp.PropsSI('S', 'P', P 4 Summer, 'H', H 4 Summer,
Working Fluid 1);
        V 4 Summer = 1/CoolProp.PropsSI('D', 'P', P 4 Summer, 'H', H 4 Summer,
Working Fluid 1);
        % Co-Efficient of Performance where COP = (QL/Wnet) = ((h1-h4)/(h2-h1))
        COP Summer = (H 1 - H 4 Summer)/(H 2 Summer - H 1);
        % Mass Flow Rate where flow rate = Cooling Capacity / Q L
```

```
dH Evaporator Summer = H 1 - H 4 Summer;
Cooling Capacity = 500; % Watts
Mass Flow Rate Summer = Cooling Capacity / dH Evaporator Summer;
% Compressor Power
Compressor Power Summer = Mass Flow Rate Summer * (H 2 Summer - H 1); % [J/s]
if j == 1
   COP R410a(k) = COP Summer;
   MFR R410a(k) = Mass Flow Rate Summer;
elseif j == 2
   COP R290(k) = COP Summer;
   MFR R290(k) = Mass Flow Rate Summer;
elseif j == 3
   COP Ammonia(k) = COP Summer;
   MFR_Ammonia(k) = Mass_Flow_Rate_Summer;
elseif j == 4
   COP Water(k) = COP Summer;
   MFR_Water(k) = Mass_Flow_Rate_Summer;
elseif j == 5
   COP_R22(k) = COP_Summer;
   MFR R22(k) = Mass Flow Rate Summer;
elseif j == 6
   COP R114(k) = COP Summer;
   MFR_R114(k) = Mass_Flow_Rate_Summer;
elseif j == 7
   COP IsoButane(k) = COP Summer;
   MFR IsoButane(k) = Mass Flow Rate Summer;
elseif j == 8
   COP MDM(k) = COP Summer;
   MFR MDM(k) = Mass Flow Rate Summer;
elseif j == 9
   COP R12(k) = COP Summer;
   MFR_R12(k) = Mass_Flow_Rate_Summer;
elseif j == 10
   COP R143a(k) = COP Summer;
   MFR R143a(k) = Mass Flow Rate Summer;
elseif j == 11
   COP R123(k) = COP Summer;
   MFR_R123(k) = Mass_Flow_Rate_Summer;
elseif j == 12
   COP Acetone(k) = COP Summer;
   MFR Acetone(k) = Mass Flow Rate Summer;
elseif j == 13
   COP R404a(k) = COP Summer;
   MFR R404a(k) = Mass Flow Rate Summer;
elseif j == 14
   COP R125(k) = COP Summer;
   MFR_R125(k)
                = Mass Flow Rate Summer;
else
   COP R134a(k) = COP Summer;
   MFR R134a(k)
                 = Mass Flow Rate Summer;
```

```
end
        k=k+1;
    end
    j=j+1;
end
for pos = 1:1000
    COP R410a(pos) = abs(COP R410a(pos));
    COP R290 (pos) = abs(COP R290 (pos));
    COP Ammonia (pos) = abs (COP Ammonia (pos));
    COP Water(pos) = abs(COP Water(pos));
    COP R22(pos) = abs(COP R22(pos));
    COP R114(pos) = abs(COP R114(pos));
    COP IsoButane(pos) = abs(COP IsoButane(pos));
    COP MDM(pos) = abs(COP MDM(pos));
    COP_R12 (pos) = abs (COP_R12 (pos));
    COP R143a(pos) = abs(COP R143a(pos));
    COP R123(pos) = abs(COP R123(pos));
    COP Acetone(pos) = abs(COP Acetone(pos));
    COP R404a(pos) = abs(COP R404a(pos));
    COP_R125(pos) = abs(COP_R125(pos));
    COP R134a(pos) = abs(COP R134a(pos));
end
% Plotting COP vs Outside Temperature
figure(1)
% R Refrigerants
semilogx(COP R410a,Outside Temperature-273,'r',COP R290,Outside Temperature-273,'r')
semilogx(COP_R404a,Outside_Temperature-273,'r',COP_R125,Outside_Temperature-
273, 'r', COP R134a, Outside Temperature-273, 'r', COP R22, Outside Temperature-273, 'r')
semilogx(COP R123,Outside Temperature-273,'r',COP R12,Outside Temperature-
273, 'r', COP R143a, Outside Temperature-273, 'r', COP R114, Outside Temperature-273, 'r')
hold on
semilogx(COP Water,Outside Temperature-273,'b')
semilogx(COP IsoButane,Outside Temperature-273,'k')
semilogx(COP MDM,Outside Temperature-273,'m')
semilogx(COP Acetone, Outside Temperature-273, 'g', COP Ammonia, Outside Temperature-273, 'g')
plot([5,100],[20,20],[5,150],[50,50])
hold off
text(20,49,'Takeoff Environment Temperature')
text(20,19,'Cold Space Environment Temperature')
% Plot Syntax
xlabel('Coefficient of Performance', 'FontSize', 22)
set(gca, 'fontsize', 20)
ylabel('Temperature', 'FontSize', 22)
set(gca, 'fontsize', 20)
xlim([5 100])
vlim([15 55])
```

```
lgd = legend('\color{red} R-Refrigerants','\color{blue} Water Refrigerants','\color{black}
IsoButane Refrigerants','\color{magenta} MDM Refrigerants','\color{green} Acetone/Ammonia');
lgd.FontSize = 22;
hold off
% Plotting COP vs Outside Temperature
figure(2)
% R Refrigerants
semilogx(COP R410a,Outside Temperature-273,'r',COP R290,Outside Temperature-273,'r')
semilogx(COP R404a,Outside Temperature-273,'r',COP R125,Outside Temperature-
273, 'r', COP R134a, Outside Temperature-273, 'r', COP R22, Outside Temperature-273, 'r')
semilogx(COP R123,Outside Temperature-273,'r',COP R12,Outside Temperature-
273, 'r', COP R143a, Outside Temperature-273, 'r', COP R114, Outside Temperature-273, 'r')
hold on
semilogx(COP Water,Outside Temperature-273,'b')
semilogx(COP IsoButane,Outside Temperature-273,'k')
semilogx(COP MDM,Outside Temperature-273,'m')
semilogx(COP Acetone,Outside Temperature-273,'g',COP Ammonia,Outside Temperature-273,'g')
plot([5,100],[20,20],[5,150],[50,50])
hold off
text(20,49, 'Takeoff Environment Temperature')
text(20,19,'Cold Space Environment Temperature')
% Plot Syntax
xlabel('Coefficient of Performance', 'FontSize', 22)
set(gca,'fontsize',20)
ylabel('Temperature', 'FontSize', 22)
set(gca,'fontsize',20)
xlim([5 100])
ylim([15 55])
hold off
% Create a list from best to worst refrigerants in respect to its COP
COP R410a Max
                  = COP R410a(915); % The index selection for Takeoff Temperature
COP R290 Max
                  = COP R290(915);
COP Ammonia Max = COP Ammonia(915);
COP Water Max
                  = COP Water(915);
COP R22 Max
                   = COP R22(915);
COP_R22_Max = COP_R22(915);

COP_R114_Max = COP_R114(915);
COP IsoButane Max = COP IsoButane (915);
COP MDM Max
                 = COP MDM(915);
COP R12 Max
                  = COP R12(915);
                  = COP R143a(915);
COP_R143a_Max
COP R123 Max
                  = COP R123(915);
COP Acetone Max
                  = COP Acetone (915);
COP R404a Max
                   = COP R404a(915);
                   = COP R125(915);
COP R125 Max
COP_R134a_Max
                   = COP R134a(915);
```

```
COP TakeOff Sorted
=sortrows({COP R410a Max,'R410a';COP R290 Max,'R290';COP Ammonia Max,'Ammonia';COP Water Max
,'Water'; COP R22 Max, 'R22'; COP R114 Max, 'R114';...
COP IsoButane Max, 'IsoButane'; COP MDM Max, 'MDM'; COP R12 Max, 'R12'; COP R143a Max, 'R143a'; COP
R123 Max, 'R123'; COP Acetone Max, 'Acetone'; COP R404a Max, 'R404a'; COP R125 Max, 'R125'; COP R134
a Max, 'R125'},1);
figure(3)
plot(Outside Temperature-273, MFR Acetone, 'r', Outside Temperature-
273,MFR R123,'b',Outside Temperature-273,MFR Ammonia,'m',Outside Temperature-
273,MFR R290, 'q')
xlabel('Temperature (C)','FontSize',22)
set(gca,'fontsize',20)
ylabel('Mass Flow Rate (kg/s)', 'FontSize', 22)
set(gca,'fontsize',20)
lgd = legend('\color{red} Acetone','\color{blue} R123','\color{magenta}
Ammonia','\color{green} R290');
lgd.FontSize = 22;
hold off
figure(4)
plot(Outside Temperature-273, MFR Acetone, 'r', Outside Temperature-
273, MFR R123, 'b', Outside Temperature-273, MFR Ammonia, 'm', Outside Temperature-
273,MFR R290, 'g')
xlabel('Temperature (C)','FontSize',22)
set(gca, 'fontsize', 20)
ylabel('Mass Flow Rate (kg/s)','FontSize',22)
set(gca, 'fontsize', 20)
hold off
%Once the best COPs are chosen from the above analysis, the final full analysis of the
desired working fluid is calculated and plotted
Working Fluid 1 = \{'R290'\};
Working_Fluid_1 = Working_Fluid_1{1};
Max Pressure = 4250000;
응응응용용용용용용용용용용
% Constants for the Refridgeration Cycle for Durham, NH
응응응응응응응응응응응응
Cold Space = 273+20; % Kelvin - Temperature of Cold Space of Pod
Hot Space Liftoff = 273 + 49; % Hottest Outside Environment
Cold Space Apogee = 273 - 18; % Coldest Outside Environment
```

Summer is used to refer to Liftoff, and Winter is for Apogee %%%

```
88888888888888
% Location 1 - Between Evaporator and Compressor
응응응응응응응응응응응용
% Finding all values of the fluid at location 1
Q 1 = 1; % Saturated Vapor
T 1 = Cold Space; % Temperature from 4 to 1
P_1 = CoolProp.PropsSI('P', 'T', T_1, 'Q', Q_1, Working_Fluid_1);
H 1 = CoolProp.PropsSI('H', 'T', T 1, 'Q', Q 1, Working Fluid 1);
U 1 = CoolProp.PropsSI('U', 'T', T 1, 'Q', Q 1, Working Fluid 1);
S 1 = CoolProp.PropsSI('S', 'T', T 1, 'Q', Q 1, Working Fluid 1);
V_1 = 1/CoolProp.PropsSI('D', 'T', T_1, 'Q', Q_1, Working_Fluid_1);
Q 1 Apogee = 1; % Saturated Vapor
T 1 Apogee = Cold Space; % Temperature from 4 to 1
P_1_Apogee = CoolProp.PropsSI('P', 'T', T_1_Apogee, 'Q', Q_1, Working_Fluid_1);
H 1 Apogee = CoolProp.PropsSI('H', 'T', T 1 Apogee, 'Q', Q 1, Working Fluid 1);
U_1_Apogee = CoolProp.PropsSI('U', 'T', T_1_Apogee, 'Q', Q_1, Working_Fluid_1);
S 1 Apogee = CoolProp.PropsSI('S', 'T', T 1 Apogee, 'Q', Q 1, Working Fluid 1);
V 1 Apogee = 1/CoolProp.PropsSI('D', 'T', T 1 Apogee, 'Q', Q 1, Working Fluid 1);
% Location 3 - Between Condensor and Expansion Valve - Saturated Liquid
88888888888888
% Finding all values of the fluid at location 3
Q 3 = 0; % Saturated Liquid
T 3 Summer = Hot Space Liftoff; % Temperature from 4 to 1
P 3 Summer = CoolProp.PropsSI('P', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
H 3 Summer = CoolProp.PropsSI('H', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
U_3_Summer = CoolProp.PropsSI('U', 'T', T_3_Summer, 'Q', Q_3, Working_Fluid_1);
S 3 Summer = CoolProp.PropsSI('S', 'T', T 3 Summer, 'Q', Q 3, Working Fluid 1);
V_3_Summer = 1/CoolProp.PropsSI('D', 'T', T_3_Summer, 'Q', Q_3, Working_Fluid_1);
T 3 Winter = Cold Space + 5; % Temperature from 4 to 1
P_3_Winter = CoolProp.PropsSI('P', 'T', T_3_Winter, 'Q', Q_3, Working_Fluid_1);
H 3 Winter = CoolProp.PropsSI('H', 'T', T 3 Winter, 'Q', Q 3, Working Fluid 1);
U 3 Winter = CoolProp.PropsSI('U', 'T', T 3 Winter, 'Q', Q 3, Working Fluid 1);
S_3_Winter = CoolProp.PropsSI('S', 'T', T_3_Winter, 'Q', Q_3, Working_Fluid_1);
V 3 Winter = 1/CoolProp.PropsSI('D', 'T', T 3 Winter, 'Q', Q 3, Working Fluid 1);
응응응응응응응응응응응응
% Location 2 - Between Condensor and Expansion Valve Super-Heated Vapor
% Finding all values of the fluid at location 2
S 2 Summer = S_1; % Constant Entropy
P 2 Summer = P 3 Summer; % Constant Pressure Isobar
T 2 Summer = CoolProp.PropsSI('T', 'P', P 2 Summer, 'S', S 2 Summer, Working Fluid 1);
H 2 Summer = CoolProp.PropsSI('H', 'P', P 2 Summer, 'S', S 2 Summer, Working Fluid 1);
U 2 Summer = CoolProp.PropsSI('U', 'P', P 2 Summer, 'S', S 2 Summer, Working Fluid 1);
```

```
V 2 Summer = 1/CoolProp.PropsSI('D', 'P', P 2 Summer, 'S', S 2 Summer, Working Fluid 1);
P 2 Winter = P 3 Winter; % Constant Pressure Isobar
S 2 Winter = S_1_Apogee; % Constant Entropy
T 2 Winter = CoolProp.PropsSI('T', 'P', P 2 Winter, 'S', S 2 Winter, Working Fluid 1);
H 2 Winter = CoolProp.PropsSI('H', 'P', P 2 Winter, 'S', S 2 Winter, Working Fluid 1);
U 2 Winter = CoolProp.PropsSI('U', 'P', P 2 Winter, 'S', S 2 Winter, Working Fluid 1);
V 2 Winter = 1/CoolProp.PropsSI('D', 'P', P 2 Winter, 'S', S 2 Winter, Working Fluid 1);
응응응응응응응응응응응응
% Location 2a - On Vapor Dome During the process 2 to 3 in condensor
88888888888888
% Finding all values of the fluid at location 2a
Q 2a=1; % On Vapor Dome as Saturdated Vapor
P 2a Summer = P 2 Summer; % Isobar = Constant Pressure
T 2a Summer = T 3 Summer; % Constant Temperature from T3
S 2a Summer = CoolProp.PropsSI('S', 'P', P 2a Summer, 'Q', Q 2a, Working Fluid 1);
H_2a_Summer = CoolProp.PropsSI('H', 'P', P_2a_Summer, 'Q', Q_2a, Working_Fluid_1);
U_2a_Summer = CoolProp.PropsSI('U', 'P', P_2a_Summer, 'Q', Q_2a, Working_Fluid_1);
V 2a Summer = 1/CoolProp.PropsSI('D', 'P', P 2a Summer, 'Q', Q 2a, Working Fluid 1);
P 2a Winter = P 2 Winter; % Isobar = Constant Pressure
T 2a Winter = T 3 Winter; % Constant Temperature from T3
S 2a Winter = CoolProp.PropsSI('S', 'P', P 2a Winter, 'Q', Q 2a, Working Fluid 1);
H 2a Winter = CoolProp.PropsSI('H', 'P', P 2a Winter, 'Q', Q 2a, Working Fluid 1);
U_2a_Winter = CoolProp.PropsSI('U', 'P', P_2a_Winter, 'Q', Q_2a, Working_Fluid_1);
V 2a Winter = 1/CoolProp.PropsSI('D', 'P', P 2a Winter, 'Q', Q 2a, Working Fluid 1);
88888888888888
% Location 4 - Mixture between the expansion valve and evaporator
88888888888888
% Finding all values of the fluid at location 4
T 4 = T 1; % Constant Temperature from 4 to 1 Process
H 4 Summer = H 3 Summer; % Expansion Valve is ~ constant enthalpy process
P 4 Summer = P 1; % Isobaric Process
U 4 Summer = CoolProp.PropsSI('U', 'P', P 4 Summer, 'H', H 4 Summer, Working Fluid 1);
S 4 Summer = CoolProp.PropsSI('S', 'P', P 4 Summer, 'H', H 4 Summer, Working Fluid 1);
V_4_Summer = 1/CoolProp.PropsSI('D', 'P', P_4_Summer, 'H', H_4_Summer, Working_Fluid_1);
T 4 Winter = T 1 Apogee; % Constant Temperature from 4 to 1 Process
H 4 Winter = H 3 Winter; % Expansion Valve is ~ constant enthalpy process
P 4 Winter = P 1 Apogee; % Isobaric Process
U_4_Winter = CoolProp.PropsSI('U', 'P', P_4_Winter, 'H', H_4_Winter, Working Fluid 1);
S 4 Winter = CoolProp.PropsSI('S', 'P', P 4 Winter, 'H', H 4 Winter, Working Fluid 1);
V_4_Winter = 1/CoolProp.PropsSI('D', 'P', P_4_Winter, 'H', H_4_Winter, Working_Fluid_1);
응응응응응응응응응응응응
% Calculations of the Vapor Dome for the Refridgeration Cycle
% Will be plotted as a T-s and P-h Diagram
% Two curves will be plotted for each graph, one for the Saturated Liquid and one for
Saturdated Vapor Sections
```

```
8888888888888
% Constant Variables and Pressure Array to Calculate Graph Values
Q SL = 0; % Saturated Liquid
Q SV = 1; % Saturated Vapor
P SL SV = linspace(100000, Max Pressure, 1000); % Pressures for the Saturated Liquid Curve
T SL = zeros(length(P SL SV));
S SL = zeros(length(P SL SV));
H SL = zeros(length(P SL SV));
V SL = zeros(length(P SL SV));
T SV = zeros(length(P SL SV));
S SV = zeros(length(P SL SV));
H SV = zeros(length(P SL SV));
V SV = zeros(length(P SL SV));
% Looping 1000 times to provide values for the Vapor Dome Curves for T, s, h and v. P array
will be graphed with them
for index=1:1000
    T SL(index) = CoolProp.PropsSI('T', 'P', P SL SV(index), 'Q', Q SL, Working Fluid 1) -
273;
    S SL(index) = CoolProp.PropsSI('S', 'P', P SL SV(index), 'Q', Q SL, Working Fluid 1);
    H SL(index) = CoolProp.PropsSI('H', 'P', P SL SV(index), 'Q', Q SL, Working Fluid 1);
    V_SL(index) = 1/CoolProp.PropsSI('D','P',P_SL_SV(index), 'Q', Q_SL, Working_Fluid_1);
    T SV(index) = CoolProp.PropsSI('T', 'P', P SL SV(index), 'Q', Q SV, Working Fluid 1) -
273;
    S SV(index) = CoolProp.PropsSI('S', 'P', P SL SV(index), 'Q', Q SV, Working Fluid 1);
    H SV(index) = CoolProp.PropsSI('H', 'P', P SL SV(index), 'Q', Q SV, Working Fluid 1);
    V SV(index) = 1/CoolProp.PropsSI('D','P',P SL SV(index), 'Q', Q SV, Working Fluid 1);
end
8888888888888
% Calculations of Every Point during the Refridgeration Cycle
응응응응응응응응응응응용
% Compressor Points - Points 1 to 2 - Constant Entropy
S Compressor Liftoff = S 1; % Constant Entropy Process
S Compressor Apogee = S 1 Apogee; % Constant Entropy Process
P_Compressor_Summer = linspace(P_1,P_2_Summer,1000);
P Compressor Winter = linspace(P 1 Apogee, P 2 Winter, 1000);
T Compressor Summer = zeros(length(P Compressor Summer));
T Compressor Winter = zeros(length(P Compressor Summer));
S Compressor Summer = zeros(length(P Compressor Summer));
S Compressor Winter = zeros(length(P Compressor Summer));
H Compressor Summer = zeros(length(P Compressor Summer));
H Compressor Winter = zeros(length(P Compressor Summer));
V Compressor Summer = zeros(length(P Compressor Summer));
V Compressor Winter = zeros(length(P Compressor Summer));
for index = 1:1000
    T Compressor Summer(index) = CoolProp.PropsSI('T', 'P', P Compressor Summer(index), 'S',
S Compressor Liftoff, Working Fluid 1) - 273;
```

```
T Compressor Winter(index) = CoolProp.PropsSI('T', 'P', P Compressor Winter(index), 'S',
S Compressor Apogee, Working Fluid 1) - 273;
    S Compressor Summer(index) = CoolProp.PropsSI('S', 'P', P Compressor Summer(index), 'S',
S Compressor Liftoff, Working Fluid 1);
    S Compressor Winter(index) = CoolProp.PropsSI('S', 'P', P Compressor Winter(index), 'S',
S Compressor Apogee, Working Fluid 1);
    H Compressor Summer(index) = CoolProp.PropsSI('H', 'P', P Compressor Summer(index), 'S',
S Compressor Liftoff, Working Fluid 1);
    H Compressor Winter(index) = CoolProp.PropsSI('H', 'P', P Compressor Winter(index), 'S',
S Compressor Apogee, Working Fluid 1);
   V Compressor Summer(index) = 1/CoolProp.PropsSI('D', 'P', P Compressor Summer(index),
'S', S Compressor Liftoff, Working Fluid 1);
   V Compressor Winter(index) = 1/CoolProp.PropsSI('D', 'P', P Compressor Winter(index),
'S', S Compressor Apogee, Working Fluid 1);
% Condensor - Points 2 to 2a - Constant Pressure
P Condensor Summer = P 2 Summer; % Constant Pressure Process
P Condensor Winter = P 2 Winter; % Constant Pressure Process
T Condensor Summer = linspace(T 2 Summer, T 2a Summer+.25,1000); % Added constant .25 so it
does not go to the mixture
T Condensor Winter = linspace(T 2 Winter, T 2a Winter+.25,1000); % Added constant .25 so it
does not go to the mixture
S Condensor Summer = zeros(length(P Condensor Summer));
S Condensor Winter = zeros(length(P Condensor Summer));
H Condensor Summer = zeros(length(P Condensor Summer));
H Condensor Winter = zeros(length(P Condensor Summer));
V Condensor Summer = zeros(length(P Condensor Summer));
V_Condensor_Winter = zeros(length(P_Condensor_Summer));
for index = 1:1000
    S Condensor Summer(index) = CoolProp.PropsSI('S', 'T', T Condensor Summer(index), 'P',
P Condensor Summer, Working Fluid 1);
    S Condensor Winter(index) = CoolProp.PropsSI('S', 'T', T Condensor Winter(index), 'P',
P Condensor Winter, Working Fluid 1);
    H Condensor Summer(index) = CoolProp.PropsSI('H', 'T', T Condensor Summer(index), 'P',
P Condensor Summer, Working Fluid 1);
    H Condensor Winter(index) = CoolProp.PropsSI('H', 'T', T Condensor Winter(index), 'P',
P Condensor Winter, Working Fluid 1);
    V Condensor Summer(index) = 1/CoolProp.PropsSI('D', 'T', T Condensor Summer(index), 'P',
P Condensor Summer, Working Fluid 1);
    V Condensor Winter(index) = 1/CoolProp.PropsSI('D', 'T', T Condensor Winter(index), 'P',
P Condensor Winter, Working Fluid 1);
end
% Condensor - Points 2a to 3 - Constant Pressure - Straight Line inside Vapor Dome
T Condensora Summer = [T 2a Summer, T 3 Summer]; % Constant Temperature
T Condensora Winter = [T 2a Winter, T 3 Winter]; % Constant Temperature
P Condensora Summer = [P 2a Summer, P 3 Summer];
P Condensora Winter = [P 2a Winter, P 3 Winter];
S Condensora Summer = [S 2a Summer, S 3 Summer];
S_Condensora_Winter = [S_2a_Winter,S_3_Winter];
```

```
H Condensora Summer = [H 2a Summer, H 3 Summer];
H Condensora Winter = [H 2a Winter, H 3 Winter];
V Condensora Summer = [V 2a Summer, V 3 Summer];
V_Condensora_Winter = [V_2a_Winter, V_3_Winter];
% Expansion Valve - Points 3 to 4 - Constant Enthalpy
H Valve Summer = H 3 Summer; % Constant Enthlpy Process
H Valve Winter = H 3 Winter; % Constant Enthlpy Process
P Valve Summer = linspace(P 3 Summer,P 4 Summer,1000); % Added constant .5 so it does not go
to the mixture
P Valve Winter = linspace(P 3 Winter,P 4 Winter,1000); % Added constant .5 so it does not go
to the mixture
S Valve Summer = zeros(length(P Valve Summer));
S Valve Winter = zeros(length(P Valve Summer));
T Valve Summer = zeros(length(P Valve Summer));
T Valve Winter = zeros(length(P Valve Summer));
V Valve Summer = zeros(length(P Valve Summer));
V Valve Winter = zeros(length(P Valve Summer));
for index = 1:1000
    S Valve Summer(index) = CoolProp.PropsSI('S', 'H', H Valve Summer, 'P',
P Valve Summer (index), Working Fluid 1);
    S Valve Winter(index) = CoolProp.PropsSI('S', 'H', H Valve Winter, 'P',
P_Valve_Winter(index), Working_Fluid_1);
    T Valve Summer(index) = CoolProp.PropsSI('T', 'H', H Valve Summer, 'P',
P Valve Summer(index), Working Fluid 1);
    T Valve Winter(index) = CoolProp.PropsSI('T', 'H', H Valve Winter, 'P',
P Valve Winter(index), Working Fluid 1);
    V Valve Summer(index) = 1/CoolProp.PropsSI('D', 'H', H Valve Summer, 'P',
P_Valve_Summer(index), Working_Fluid_1);
    V_Valve_Winter(index) = 1/CoolProp.PropsSI('D', 'H', H_Valve Winter, 'P',
P Valve Winter(index), Working Fluid 1);
% Evaporator - Points 4 to 1 - Constant Temperature - Straight Line inside Vapor Dome
T Evaporator Summer = [T 4,T 1]; % Constant Temperature
T Evaporator Winter = [T 4 Winter, T 1 Apogee]; % Constant Temperature
P Evaporator Summer = [P 4 Summer, P 1];
P_Evaporator_Winter = [P_4_Winter,P_1_Apogee];
S Evaporator Summer = [S 4 Summer, S 1];
S Evaporator Winter = [S_4_Winter,S_1_Apogee];
H Evaporator Summer = [H 4 Summer, H 1];
H Evaporator Winter = [H 4 Winter, H 1 Apogee];
V Evaporator Summer = [V 4 Summer, V 1];
V Evaporator Winter = [V 4 Winter, V 1 Apogee];
응응응응응응응응응응응응
% Calculation COP for each temperature
응응응응응응응응응응응응
COP Summer = (H 1 - H 4 Summer) / (H 2 Summer - H 1);
COP_Winter = (H_1_Apogee - H_4_Winter)/(H_2_Winter - H_1_Apogee);
```

```
888888888888
% Graphing the T-s and P-h and P-vGraphs with Vapor Dome and Labels
응응응응응응응응응응응응
% T-s Graph for the Summer
figure(5)
% Vapor Dome
plot(S SL/1000, T SL, 'k', S SV/1000, T SV, 'k')
% Processes
% Winter
plot(S Compressor Winter/1000, T Compressor Winter, 'b', S Condensor Winter/1000,
T Condensor Winter-273, 'b', S Condensora Winter/1000, T Condensora Winter-
273, 'b', S Valve Winter/1000, T Valve Winter-273, 'b', S Evaporator Winter/1000,
T Evaporator Winter-273, 'b')
text(S 1 Apogee/1000, T 1 Apogee-273, '\leftarrow State 1')
text(S 2 Winter/1000,T 2 Winter-273, '\leftarrow State 2')
text(S 2a Winter/1000-.03,T 2a Winter-273-1, 'State 2a', 'FontSize', 8)
text(S 3 Winter/1000-.06,T 3 Winter-273, 'State 3')
text(S 4 Winter/1000-.02,T 4 Winter-273-1, 'State 4')
text(1.8,27, strcat('Apogee COP: ' , num2str(COP Winter)))
% Summer
plot(S Compressor Summer/1000, T Compressor Summer, 'r', S Condensor Summer/1000,
T Condensor Summer-273, 'r', S Condensora Summer/1000, T Condensora Summer-
273, 'r', S Valve Summer/1000, T Valve Summer-273, 'r', S Evaporator Summer/1000,
T Evaporator Summer-273, 'm')
plot(S_Compressor_Winter/1000,T_Compressor_Winter,'m')
text(S 2 Summer/1000,T 2 Summer-273, '\leftarrow State 2')
text(S 2a Summer/1000,T 2a Summer-273, '\leftarrow State 2a')
text(S 3 Summer/1000-.07, T 3 Summer-273, 'State 3')
text(S 4 Summer/1000-.01,T 4-273-1, 'State 4')
text(1.8,51, strcat('Takeoff COP: ', '6.87'))
% Syntax
xlabel('Entropy (J/K)', 'FontSize', 22)
set(gca, 'fontsize', 20)
ylabel('Temperature (Celcius)', 'FontSize', 22)
set(gca, 'fontsize', 20)
lgd = legend('\color{red} Takeoff','\color{blue} Apogee','\color{black} Vapor Dome');
lgd.FontSize = 22;
xlim([1 2.5])
ylim([15 100])
hold off
% T-s Graph for the Summer
figure (6)
% Vapor Dome
plot(S_SL/1000,T_SL,'k',S_SV/1000,T_SV,'k')
hold on
% Processes
```

```
% Winter
plot(S Compressor Winter/1000, T Compressor Winter, 'b', S Condensor Winter/1000,
T Condensor Winter-273, 'b', S Condensora Winter/1000, T Condensora Winter-
273, 'b', S Valve Winter/1000, T Valve Winter-273, 'b', S Evaporator Winter/1000,
T Evaporator Winter-273, 'b')
text(1.8,27, strcat('Apogee COP: ', num2str(COP Winter)))
% Summer
plot(S Compressor Summer/1000, T Compressor Summer, 'r', S Condensor Summer/1000,
T Condensor Summer-273, 'r', S Condensora Summer/1000, T Condensora Summer-
273, 'r', S Valve Summer/1000, T Valve Summer-273, 'r', S Evaporator Summer/1000,
T Evaporator Summer-273, 'm')
plot(S Compressor Winter/1000, T Compressor Winter, 'm')
text(1.8,51, strcat('Takeoff COP: ', '6.87'))
% Syntax
xlabel('Entropy (J/K)', 'FontSize', 22)
set(gca, 'fontsize', 20)
ylabel('Temperature (Celcius)', 'FontSize', 22)
set(gca,'fontsize',20)
xlim([1 2.5])
ylim([15 100])
hold off
% P-h Graph for the Summer
figure(7)
% Vapor Dome
plot(H SL/1000, P SL SV/1000, 'k', H SV/1000, P SL SV/1000, 'k')
hold on
% Processes
%Winter
P_Condensor_Winter = [P_2_Winter,P 2a Winter];
H_Condensor_Winter = [H_2_Winter, H_2a_Winter];
P Valve Winter Ph = [P 3 Winter, P 4 Winter];
H Valve Winter Ph = [H 3 Winter, H 4 Winter];
plot(H Compressor Winter/1000, P Compressor Winter/1000, 'b', H Condensor Winter/1000,
P Condensor Winter/1000, 'b', H Condensora Winter/1000,
P Condensora Winter/1000,'b',H Valve Winter Ph/1000,P Valve Winter Ph/1000,'b',H Evaporator
Winter/1000, P Evaporator Winter/1000, 'b')
text(H 1 Apogee/1000, P 1 Apogee/1000, '\leftarrow State 1')
text(H_2_Winter/1000,P_2_Winter/1000, '\leftarrow State 2')
text(H 3 Winter/1000-16,P 3 Winter/1000, 'State 3')
text(H 4 Winter/1000-5,P 4 Winter/1000-35, 'State 4')
text(450,1000, strcat('Apogee COP: ' , num2str(COP_Winter)))
% Summer
```

```
P Condensor Summer = [P 2 Summer, P 2a Summer];
H Condensor Summer = [H 2 Summer, H 2a Summer];
P Valve Summer Ph = [P 3 Summer, P 4 Summer];
H Valve Summer Ph = [H 3 Summer, H 4 Summer];
plot(H Compressor Summer/1000, P Compressor Summer/1000, 'r', H Condensor Summer/1000,
P Condensor Summer/1000, 'r', H Condensora Summer/1000,
P Condensora Summer/1000,'r',H Valve Summer Ph/1000,P Valve Summer Ph/1000,'r',H Evaporator
Summer/1000, P Evaporator Summer/1000, 'm')
plot(H Compressor Winter/1000, P Compressor Winter/1000, 'm')
text(H 2 Summer/1000,P 2 Summer/1000, '\leftarrow State 2')
text(H 3 Summer/1000-14,P 3 Summer/1000, 'State 3')
text(H 4 Summer/1000-5,P 4 Summer/1000-50, 'State 4')
text(450,1800, strcat('Takeoff COP: ', '6.87'))
% Plot Syntax
xlabel('Enthalpy (KJ/K)', 'FontSize', 22)
set(gca,'fontsize',20)
vlabel('Pressure (KPa)', 'FontSize', 22)
set(gca, 'fontsize', 20)
lgd = legend('\color{red} Takeoff','\color{blue} Apogee','\color{black} Vapor Dome');
lgd.FontSize = 22;
xlim([225 650])
ylim([500 4500])
hold off
% P-h Graph for the Summer
figure(8)
% Vapor Dome
plot(H SL/1000, P SL SV/1000, 'k', H SV/1000, P SL SV/1000, 'k')
hold on
% Processes
%Winter
P Condensor Winter = [P 2 Winter, P 2a Winter];
H Condensor Winter = [H 2 Winter, H 2a Winter];
P Valve Winter Ph = [P 3 Winter, P 4 Winter];
H_Valve_Winter_Ph = [H_3_Winter,H_4_Winter];
plot(H Compressor Winter/1000, P Compressor Winter/1000, 'b', H Condensor Winter/1000,
P Condensor Winter/1000, 'b', H Condensora Winter/1000,
P Condensora Winter/1000,'b',H Valve Winter Ph/1000,P Valve Winter Ph/1000,'b',H Evaporator
Winter/1000, P Evaporator Winter/1000, 'b')
text(450,1100, strcat('Apogee COP: ' , num2str(COP Winter)))
% Summer
P Condensor Summer = [P 2 Summer, P 2a Summer];
H Condensor Summer = [H 2 Summer, H 2a Summer];
P Valve Summer Ph = [P 3 Summer, P 4 Summer];
H Valve Summer Ph = [H 3 Summer, H 4 Summer];
```

```
plot(H Compressor Summer/1000, P Compressor Summer/1000, 'r', H Condensor Summer/1000,
P Condensor Summer/1000, 'r', H Condensora Summer/1000,
P Condensora Summer/1000,'r',H Valve Summer Ph/1000,P Valve Summer Ph/1000,'r',H Evaporator
Summer/1000, P Evaporator Summer/1000, 'm')
plot(H Compressor Winter/1000, P Compressor Winter/1000, 'm')
text(450,1800, strcat('Takeoff COP: ', '6.87'))
% Plot Syntax
xlabel('Enthalpy (KJ/K)', 'FontSize', 22)
set(gca,'fontsize',20)
ylabel('Pressure (KPa)', 'FontSize', 22)
set(gca,'fontsize',20)
xlim([225 650])
ylim([500 4500])
hold off
% P-h Graph for the Summer
figure(9)
% Vapor Dome
plot(V SL/1000,P SL SV/1000,'k',V SV/1000,P SL SV/1000,'k')
% Processes
%Winter
P Condensor Winter = [P 2 Winter, P 2a Winter];
V Condensor Winter = [V 2 Winter, V 2a Winter];
plot(V_Compressor_Winter/1000,P_Compressor_Winter/1000,'b',V_Condensor_Winter/1000,
P Condensor Winter/1000, 'b', V Condensora Winter/1000,
P Condensora Winter/1000, 'b', V Valve Winter/1000, P Valve Winter/1000, 'b', V Evaporator Winter
/1000, P Evaporator Winter/1000, 'b')
text(V 1/1000,P 1/1000+20, '\leftarrow State 1')
text(V 2 Winter/1000,P 2 Winter/1000+20, '\leftarrow State 2')
text(V 3 Winter/1000+.000001,P 3 Winter/1000-35, 'State 3')
text(V 4 Winter/1000,P 4 Winter/1000-35, 'State 4')
text(.000015,1000, strcat('Apogee COP: ' , num2str(COP Winter)))
P Condensor Summer = [P 2 Summer, P 2a Summer];
V Condensor Summer = [V 2 Summer, V 2a Summer];
plot(V Compressor Summer/1000, P Compressor Summer/1000, 'r', V Condensor Summer/1000,
P Condensor Summer/1000, 'r', V Condensora Summer/1000,
P Condensora Summer/1000, 'r', V_Valve_Summer/1000, P_Valve_Summer/1000, 'r', V_Evaporator_Summer
/1000, P Evaporator Summer/1000, 'm')
plot(V Compressor Winter/1000,P Compressor Winter/1000,'m')
text(V 2 Summer/1000,P 2 Summer/1000+20, '\leftarrow State 2')
text(V 3 Summer/1000+.0000005,P 3 Summer/1000-65, 'State 3')
text(V 4 Summer/1000,P 4 Summer/1000-70, 'State 4')
text(.000015,1750, strcat('Takeoff COP: ', '6.87'))
% Plot Syntax
```

```
xlabel('Specific Volume (m3/Kg)','FontSize',22)
set(gca,'fontsize',20)
ylabel('Pressure (KPa)', 'FontSize', 22)
set(gca,'fontsize',20)
lqd = legend('\color{red} Takeoff','\color{blue} Apogee','\color{black} Vapor Dome');
lgd.FontSize = 22;
xlim([.0000005 .00006])
vlim([250 4500])
hold off
% P-h Graph for the Summer
figure(10)
% Vapor Dome
plot(V SL/1000, P SL SV/1000, 'k', V SV/1000, P SL SV/1000, 'k')
hold on
% Processes
%Winter
P_Condensor_Winter = [P_2_Winter,P_2a_Winter];
V Condensor Winter = [V 2 Winter, V 2a Winter];
plot(V Compressor Winter/1000, P Compressor Winter/1000, 'b', V Condensor Winter/1000,
P Condensor Winter/1000, 'b', V Condensora Winter/1000,
P_Condensora_Winter/1000,'b',V_Valve_Winter/1000,P_Valve_Winter/1000,'b',V_Evaporator_Winter
/1000, P Evaporator Winter/1000, 'b')
text(.000015,1150, strcat('Apogee COP: ' , num2str(COP_Winter)))
% Summer
P Condensor Summer = [P 2 Summer, P 2a Summer];
V_Condensor_Summer = [V_2_Summer, V_2a_Summer];
plot(V Compressor Summer/1000, P Compressor Summer/1000, 'r', V Condensor Summer/1000,
P Condensor Summer/1000, 'r', V Condensora Summer/1000,
P Condensora Summer/1000, 'r', V Valve Summer/1000, P Valve Summer/1000, 'r', V Evaporator Summer
/1000, P Evaporator Summer/1000, 'm')
plot(V Compressor Winter/1000, P Compressor Winter/1000, 'm')
text(.000010,1850, strcat('Takeoff COP: ' , '6.87'))
% Plot Syntax
xlabel('Specific Volume (m3/Kg)','FontSize',22)
set(gca, 'fontsize', 20)
ylabel('Pressure (KPa)', 'FontSize', 22)
set(gca,'fontsize',20)
xlim([.0000005 .00006])
ylim([250 4500])
hold off
```

22