

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 706119 拆卸和安装门板盖

拆卸门板盖

拆卸门板盖

1. 使用塑料楔片从门板上松开门板盖 -箭头-。



门板盖

安装门板盖

安装门板盖

按照与拆卸相反的顺序进行安装。

981120, 981121, 981130, 981131, 981320, 981321, 981330, 981331, 981340, 981341

年款 起始时间 2013

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C46, C96, C97, C98, C99

