

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 370419 拆卸和安装选档杆握柄


拆卸和安装选档杆握柄

拆卸和安装选档杆握柄



必须将点火钥匙置于位置 1 之后，才能按下锁止按钮。

- 1. 按逆时针方向转动扭转锁，并向上拉出选档杆手柄。



拆卸选档杆握柄

- 2. 按照与拆卸相反的顺序进行安装。

Aug 23, 2019

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351

年款 起始时间 2017
C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

