

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 408519 拆卸和安装前弹簧滑柱

拆卸和安装前弹簧滑柱

拆卸和安装前弹簧滑柱

已拆下前弹簧滑柱，然后将其与车轮轴承壳体一同安装 → 405019 拆卸和安装车轮轴承壳。

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351

年款 起始时间 2017

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

baochi123D

baochimingcheservice@gmail.com

Aug 23, 2019

