

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 465302 检查后制动盘 - 磨损评估

检查后制动盘

检查后制动盘



信息

检查后制动盘的方法与前桥上使用的方法相同。

1. 检查制动盘。 → 465002 检查前制动盘 - 磨损评估

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351

年款 起始时间 2017

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

baochi123D

baochimingcheservice@gmail.com

Aug 23, 2019

