

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 465304 测量后制动盘

测量后制动盘

测量后制动盘



信息

测量后制动盘的方法与前桥上使用的方法相同。

- 1. 测量制动盘。 → 465004 测量前制动盘

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351

年款 起始时间 2017
C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

baochi123D

baochimingcheservice@gmail.com

Aug 23, 2019

