

当前文件在印刷时是有效的。更新的版本可以在线获得。

WM 665619 拆卸和安装侧进气盖

部件信息

侧进气盖的安装位置



baochiming@163.com 侧进气盖的安装位置

拆卸和安装侧进气盖

Aug 23, 2019


拆卸和安装侧进气盖



信息

以驾驶员侧为例；步骤与乘客侧相同。

1. 将进气盖 -1- 从固定卡子 -A- 上松开，然后将其拆下。



拆卸进气盖 (以 981 为例)

2. 按照与拆卸相反的顺序进行安装。

982120, 982121, 982130, 982131, 982140, 982141, 982150, 982151, 982320, 982321, 982330, 982331, 982340, 982341, 982350, 982351

年款 起始时间 2017

C00, C02, C05, C06, C07, C08, C09, C10, C11, C12, C13, C14, C15, C16, C17, C18, C19, C20, C21, C22, C23, C24, C25, C26, C27, C28, C32, C33, C34, C35, C36, C37, C38, C39, C41, C45, C45, C46, C96, C97, C98, C99

