

982 , 2014 =>

Diagnosis information - Sound actuator

C104A4B.....	1
C113C01.....	2
C113C13.....	3
P138500.....	4
P160A00.....	5
U101100.....	6
U101200.....	7
U10D900.....	8
U112100.....	9
U112200.....	10
U112300.....	11
U120000.....	12
U140000.....	13
U140100.....	14

C104A4B

Diagnostic information - DME control unit

C104A4B Overtemperature in control unit

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Control unit overtemperature

Monitored component or system

- ♦ Control unit

Fault finding notes

- ♦ Check ventilation
- ♦ Check plug connections
- ♦ Control unit faulty

Functional restrictions

- ♦ No sound creation function

C113C01

Diagnostic information - DME control unit

C113C01 Short circuit in line to sound actuator

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Short circuit in actuator line(s)

Monitored component or system

- ♦ Sound actuator

Fault finding notes

- ♦ Check plug connections
- ♦ Check internal resistance of sound actuator (OK = 7...12 Ohm)
- ♦ Perform line test between control unit and sound actuator
- ♦ Sound actuator faulty
- ♦ Control unit faulty

Functional restrictions

- ♦ No sound creation function

C113C13

Diagnostic information - DME control unit

C113C13 Open circuit in line to sound actuator

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Open circuit in actuator line(s)

Monitored component or system

- ♦ Sound actuator

Fault finding notes

- ♦ Check plug connections
- ♦ Check internal resistance of sound actuator (OK = 7...12 Ohm)
- ♦ Perform line test between control unit and sound actuator
- ♦ Sound actuator faulty
- ♦ Control unit faulty

Functional restrictions

- ♦ No sound creation function

P138500

Diagnosis information DME control module

P138500 Internal fault in control unit

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Internal fault in control unit

Monitored component or system

- ♦ Control unit

Fault finding notes

- ♦ Control unit faulty, replace

Function restrictions

- ♦ No sound creation function

P160A00

Diagnosis information DME control module

P160A00 Control unit checksum error

Diagnostic conditions

- Engine started/running

Fault setting condition(s)

- Checksum error in control unit

Monitored component or system

- ♦ Control unit

Fault finding notes

- ♦ Control unit faulty, replace

Function restrictions

- ♦ No sound creation function

U101100

Diagnosis information DME control module

U101100 Supply voltage below lower limit value

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Supply voltage permanently too low
- Supply voltage < 9.3 V

Monitored component or system

- ♦ Control unit, power supply

Fault finding notes

- ♦ Check power supply

Function restrictions

- ♦ No sound creation function

U101200

Diagnosis information DME control module

U101200 Supply voltage above upper limit value

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Supply voltage permanently too high
- Supply voltage > 16.5 V

Monitored component or system

- ♦ Control unit, power supply

Fault finding notes

- ♦ Check power supply

Function restrictions

- ♦ No sound creation function

U10D900

Diagnosis information DME control module

U10D900 Installed incorrectly in vehicle, will not function

Diagnostic conditions

- Engine started/running

Fault setting condition(s)

- Vehicle and engine not detected due to CAN message

Monitored component or system

- ♦ Control unit

Fault finding notes

- ♦ Install correct software

Function restrictions

- ♦ No sound creation function

U112100

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Communication with control unit

INFORMATION

Communication with the control unit designated in the fault text is/was not possible.

Possible fault causes

- ♦ The power supply for the designated control unit is not present or is present only to a limited extent.
- ♦ The CAN line CAN-High and/or CAN-Low is interrupted between the control unit connector of the designated control unit and the first splice behind the control unit.
- ♦ Control unit faulty

Fault effects

- ♦ Cross-vehicle functions are not available
- ♦ Existing substitute/emergency functions of the control units are active
- ♦ Functions in the control units are available only with restrictions
- ♦ Functions in the control units are not available

U112300

Diagnostic information - valid for all control units

Read out control unit fault memory content

INFORMATION

This fault code indicates one or more faults/notes in the fault memory of the designated control unit.

Existing faults/notes in the designated control unit must be processed first.

NOTE

Use the [F7] button to show/hide notes in the fault memory.

Possible fault causes

- ◆ Fault in the designated control unit
- ◆ Note in the designated control unit

Fault effects

- ◆ Functions in the control unit are available only with restrictions
- ◆ Functions in the control unit are not available

Diagnostic information - valid for all control units

Communication with CAN bus

INFORMATION

Communication with the CAN bus designated in the fault text is/was not possible.

Possible fault causes

- ◆ Short circuit of the CAN-High line to ground
- ◆ Short circuit of the CAN-High line to B+
- ◆ Short circuit of the CAN-High line to interference signal
- ◆ Open circuit in the CAN-High line

- ◆ Short circuit of the CAN-Low line to ground
- ◆ Short circuit of the CAN-Low line to B+
- ◆ Short circuit of the CAN-Low line to interference signal
- ◆ Open circuit in the CAN-Low line

- ◆ Defective control unit in combination with the designated CAN bus

Fault effects

- ◆ Cross-vehicle functions are not available
- ◆ Existing substitute/emergency functions in the control units are active
- ◆ Functions in the control units are available only with restrictions
- ◆ Functions in the control units are not available

U140000

Diagnosis information DME control module

U140000 Function restriction due to undervoltage

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Temporary undervoltage in the supply
- Supply voltage < 9.3 V

Monitored component or system

- ♦ Control unit, power supply

Fault finding notes

- ♦ Check power supply

Function restrictions

- ♦ No sound creation function

U140100

Diagnosis information DME control module

U140100 Function restriction due to overvoltage

Diagnostic conditions

- Ignition on
- Diagnostics runs cyclically (10 ms)

Fault setting condition(s)

- Temporary overvoltage in the supply
- Supply voltage > 16.5 V

Monitored component or system

- ♦ Control unit, power supply

Fault finding notes

- ♦ Check power supply

Function restrictions

- ♦ None