

991 + 981 , MY 2014 =>

Diagnosis information - Adaptive cruise control (ACC)

C11005.....	1
C11006.....	2
D00000.....	3
D00002.....	4
D00004.....	5
D00008.....	6
D00009.....	7

C11005

Diagnosis information - Adaptive cruise control (ACC)

Control module faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Internal control unit fault

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

C11006

Diagnosis information - Adaptive cruise control (ACC)

Vehicle reaction implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Vehicle reaction not as expected upon acceleration
- Distance sensor control unit incorrectly coded, engine type naturally aspirated engine or turbo engine
- Vehicle reaction not as expected upon braking
- In trailer mode; trailer not detected
- DME control unit and / or PSM incorrectly coded

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

D00000

Diagnosis information - Adaptive cruise control (ACC)

Sensor Malfunction

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- System in diagnostic mode
- Sensor not available
- Function block active
- System malfunctioning

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

D00002

Diagnosis information - Adaptive cruise control (ACC)

Sensor blind

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Preceding trip with distance control

Fault setting condition(s)

- Sensor lens covered
- Sensor lens dirty
- Sensor lens covered in ice
- Sensor does not see obstacle for a long time
- Sensor lens damaged irreparably
- Sensor incorrectly adjusted

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

D00004

Diagnosis information - Adaptive cruise control (ACC)

Sensor Incorrectly adjusted

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Preceding drive with distance control

Fault setting condition(s)

- Deviation between driving axis and sensor beam larger (1.5° <)
See also Workshop Manual
- Distance measuring sensor out of adjustment
- **Control module** New, initial adjustment/setting procedure (under "Maintenance/Adjustment" in the PIWIS Tester) not carried out
- Distance measuring sensor mount loose or bent
- Driving axis of chassis displaced
- Wheel settings of rear axle not correct

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

Diagnosis information - Adaptive cruise control (ACC)

Sensor Incorrectly adjusted

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- Preceding drive with distance control

Fault setting condition(s)

- Deviation between driving axis and sensor beam larger (1.5° <)
See also Workshop Manual
- Distance measuring sensor out of adjustment
- **Control module** New, initial adjustment/setting procedure (under "Maintenance/Adjustment" in the PIWIS Tester) not carried out
- Distance measuring sensor mount loose or bent
- Driving axis of chassis displaced
- Wheel settings of rear axle not correct

Fault effects

- ♦ System switches off
- ♦ Display on instrument cluster

Diagnosis information - Adaptive cruise control (ACC)

**Vehicle identification, different Vehicle Identification Number (VIN)
Vehicle Identification Number (VIN) , implausible**

NOTE

This fault is set when the control unit's Vehicle Identification Number (VIN) is not identical to the one reported over CAN.

A new control unit receives the Vehicle Identification Number (VIN) when it is connected for the first time.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Coded Vehicle Identification Number (VIN) in the control unit is not identical to the vehicle's VIN sent via CAN.
- Control unit is new, initial commissioning / vehicle handover not yet performed.
- Control unit originates from another vehicle.
- Vehicle Identification Number (VIN) not correctly entered in the **Control module Adaptive cruise control (ACC)** .

► Check and correct the Vehicle Identification Number (VIN) of the **Control module Adaptive cruise control (ACC)** (in the PIWIS Tester ⇒ **Control module Adaptive cruise control (ACC)** ⇒ Extended identification ⇒ Chassis number)

Fault effects

- ♦ System does not function
- ♦ Display on instrument cluster