

001204

Diagnosis information - PDCC control unit

Valve block - Front axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Valve block Front axle** Faulty :
 Direction valve Front axle stuck
 Pressure sensor Front axle Faulty

Fault effects

- ♦ No function / Limp-home

Diagnosis information - PDCC control unit

Valve block - Rear axle

Diagnostic conditions

- Engine running

or while driving or Commissioning performed

Possible fault causes

- ♦ **Valve block** Rear axle Faulty :
 - Direction valve** Rear axle stuck
 - Pressure sensor** Rear axle Faulty

Fault effects

- ♦ No function / Limp-home

002000

Diagnosis information - PDCC control unit

Roll test not OK

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Roll test or Commissioning not performed
- ♦ Roll test or Commissioning performed and Faulty

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

Diagnosis information - PDCC control unit

Roll test Faulty

Diagnostic conditions

- Roll test or Commissioning performed

Possible fault causes

- ♦ Level Hydraulic fluid too low / Too high
- ♦ **Hydraulic system** Mechanical fault

Fault effects

- ♦ only Fault entry

C11000

Diagnosis information - Control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Supply voltage** Limit exceeded
- **Supply voltage** Below limit

Fault effects

- ♦ Function not available or available only to a limited extent

C11001

Diagnosis information - Control module

Supply voltage

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- **Supply voltage** Limit exceeded
- **Supply voltage** Below limit

Fault effects

- ♦ Function not available or available only to a limited extent

Diagnosis information - PDCC control unit

Control module not or incorrectly programmed

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ **Control module** PDCC not or incorrectly programmed

Fault effects

- ♦ Limited function

D00001

Diagnosis information - PDCC control unit

Regulator inactive

Diagnostic conditions

- Ignition on

Fault setting condition(s)

- Commissioning **PDCC control unit** not or Faulty performed

Fault effects

- ♦ Function not available or available only to a limited extent