

000042

Diagnosis information - Parking brake control unit

Spreader device Faulty

Diagnostic conditions

- Ignition on
- Actuation **Parking brake**

Fault setting condition(s)

- **Spreader device** Faulty

Fault effects

none or Limited function **Parking brake**

000043

Diagnosis information - Parking brake control unit

Drive Away Release (DAR)

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Signal Reversing-light switch implausible (**Rear-end electronics**)
- ♦ Signal Gear information implausible (Fault memory **DME control module** or **PDK control unit**)

Fault effects

- ♦ DAR (DriveAwayRelease) not available

000044

Diagnosis information - Parking brake control unit

Drive Away Release (DAR)

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Signal Reversing-light switch implausible (**Rear-end electronics**)
- ♦ Signal Gear information implausible (Fault memory **DME control module** or **PDK control unit**)

Fault effects

- ♦ DAR (DriveAwayRelease) not available

Diagnosis information - Clutch sensor

Signal implausible

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on
- while driving

Fault setting condition(s)

- The signal of the clutch sensor is outside the value range
- During driving (10 - 80 km/h / 6 - 50 mph), a gear change is recognized based on the monitored transmission ratio, but no corresponding clutch actuation is determined. This state must exist at least 20 times per ignition change for the fault to be entered.
- The vehicle accelerates from standstill to 120 km/h (75 mph) without a clutch actuation being detected. This state must exist 3 times per ignition change for the fault to be entered.

Possible fault causes

- Old Software version **Parking brake control unit** (if a control unit with the part number 991.618.145.02 and a software version < 1600 is installed, please refer to the corresponding symptom-based Workshop Manual)
- Short circuit to B+/ground/between lines or open circuit in the lines
- **Clutch sensor** Function restriction
- **Parking brake control unit** Function restriction

Fault effects

- DAR (DriveAwayRelease) not available

Nominal values Line test

Short circuit to B+ :

♦ Setpoint voltage **- 0.5 V** ⇒ **+ 0.5 V**

Short circuit to ground :

◆ Setpoint resistance > **0.9 MOhm**

Open circuit:

◆ Setpoint resistance < **2 Ohm**

Diagnosis information - Parking brake control unit

Deviation VIN

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Parking brake control unit off another Vehicle installed

Fault effects

- ♦ Limited function

00C058

Diagnosis information - Parking brake control unit

Production mode Active

Diagnostic conditions

- Ignition on

Possible fault causes

- ♦ Production mode Active

Fault setting condition(s)

- Production mode Active switched

Diagnosis information - Control module

Power supply

WARNING

- ♦ Danger of injury and crushing when components are moved.
- ♦ Open or close the rear lid only if there are neither persons, animals nor objects in the movement range of the lid.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Power supply - Below limit - 9 V
- Power supply - Limit exceeded - 16 V

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Control module

Power supply

WARNING

- ◆ Danger of injury and crushing when components are moved.
- ◆ Open or close the rear lid only if there are neither persons, animals nor objects in the movement range of the lid.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- Power supply - Below limit - 9 V
- Power supply - Limit exceeded - 16 V

Fault effects

Function not available or available only to a limited extent

Diagnosis information - Parking brake control unit

Parking brake control unit - Faulty

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Possible fault causes

- ♦ Parking brake control unit Faulty

Fault effects

- ♦ none or Limited function **Parking brake**

Diagnosis information - Control module

No/incorrect coding

WARNING

- ♦ Danger of injury and crushing when components are moved.
- ♦ Open or close the rear lid only if there are neither persons, animals nor objects in the movement range of the lid.

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

Coding incorrect or not carried out

Fault effects

Function not available or available only to a limited extent