

Diagnosis information - Power steering

Power steering Faulty

NOTE

In the event of a fault, check whether the fault is permanently "present". To perform the check, clear the fault memory, meet the diagnostic conditions and read out the fault memory again.

Diagnostic conditions

- Ignition on or Engine running
- Modification Steering angle

Possible fault causes

- ♦ Damage Power steering gear
- ♦ Damage Wiring harness
- ♦ Control unit faulty

Fault effects

Power steering No function

C11006

Diagnosis information - Control module Power steering

Coding

Diagnostic conditions

The control unit must be active in order to test internal function sequences and diagnosable inputs/outputs.

In the event of a fault, check whether the fault is permanently >present<. To perform the check, erase the fault memory, meet the diagnostic conditions and read out the fault memory again.

- Ignition on

Fault setting condition(s)

- incorrectly coded
- not coded

Fault effects

- ♦ Function not available or available only to a limited extent