

U110000

Diagnostic information - amplifier

Amplifier - component protection active/no basic setting

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Component protection active

Possible fault cause(s)

- Component protection not taught
- Component protection active

Fault effect(s)

- Function not available or available only to a limited extent

Diagnostic information - amplifier

Amplifier - component protection active/no basic setting

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Component protection active

Possible fault cause(s)

- Component protection not taught
- Component protection active

Fault effect(s)

- Function not available or available only to a limited extent

Diagnostic information - amplifier

Amplifier - component protection active/no basic setting

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Component protection active

Possible fault cause(s)

- Component protection not taught
- Component protection active

Fault effect(s)

- Function not available or available only to a limited extent

Diagnostic information - amplifier

Amplifier - component protection active/no basic setting

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Component protection active

Possible fault cause(s)

- Component protection not taught
- Component protection active

Fault effect(s)

- Function not available or available only to a limited extent

Diagnostic information - amplifier

Amplifier - component protection active/no basic setting

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Component protection active

Possible fault cause(s)

- Component protection not taught
- Component protection active

Fault effect(s)

- Function not available or available only to a limited extent

Diagnostic information - amplifier

MOST (Media Oriented Systems Transport) bus - function restriction

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- No message/implausible message
- Fault value received

Possible fault cause(s)

- Messages are not transmitted or are not transmitted fully
- Fault memory entries for one or more MOST components prevent complete and plausible data transmission
- Messages received/sent by one or more MOST components are implausible
- Received/sent messages contain fault values

Fault effect(s)

- Amplifier has limited functionality or does not work
- PCM has limited functionality or does not work
- TV tuner has limited functionality or does not work
- Extended environment data in fault memory entries invalid

Diagnostic information - amplifier

MOST (Media Oriented Systems Transport) bus - function restriction

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- No message/implausible message
- Fault value received

Possible fault cause(s)

- Messages are not transmitted or are not transmitted fully
- Fault memory entries for one or more MOST components prevent complete and plausible data transmission
- Messages received/sent by one or more MOST components are implausible
- Received/sent messages contain fault values

Fault effect(s)

- Amplifier has limited functionality or does not work
- PCM has limited functionality or does not work
- TV tuner has limited functionality or does not work
- Extended environment data in fault memory entries invalid

Diagnostic information - amplifier

MOST (Media Oriented Systems Transport) bus - function restriction

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- No message/implausible message
- Fault value received

Possible fault cause(s)

- Messages are not transmitted or are not transmitted fully
- Fault memory entries for one or more MOST components prevent complete and plausible data transmission
- Messages received/sent by one or more MOST components are implausible
- Received/sent messages contain fault values

Fault effect(s)

- Amplifier has limited functionality or does not work
- PCM has limited functionality or does not work
- TV tuner has limited functionality or does not work
- Extended environment data in fault memory entries invalid

U140000

Diagnostic information - amplifier

Amplifier supply voltage below limit value

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Amplifier detects a supply voltage that is too low

Possible fault cause(s)

- Supply voltage too low

Fault effect(s)

- Amplifier has limited functionality

U140100

Diagnostic information - amplifier

Amplifier supply voltage above limit value

Diagnostic conditions

- Ignition on
- PCM on
- Amplifier on

Fault setting condition(s)

- Amplifier detects a supply voltage that is too high

Possible fault cause(s)

- Supply voltage too high

Fault effect(s)

- Amplifier has limited functionality