# Pitching Moment of an Airfoil

Charles Keer

**AE 315** 

Department of Aerospace Engineering

Embry-Riddle Aeronautical University, Daytona Beach, FL, 32114-3900

### Introduction

A wind tunnel can give invaluable insight into the aerodynamic characteristics of any object that is tested in it. For this lab, a NACA 0012 airfoil with semi-span length of 30.94 in and chord length of 12 in was tested in a wind tunnel at different angles of attack. By measuring the lift, drag, and moments on the airfoil as it is turned through different angels of attack, the airfoil can be accurately




Figure 1. Schematic of experimental cross section in wind tunnel.

characterized. The experiment was performed at two velocities: 100ft/s and 150ft/s. For each trial, a "dry run" was done with the tunnel turned off to gather gravity tare data. At each velocity, a positive and negative angle sweep was done from 0 to 20 and 0 to -20 degrees respectively.

**Table 1.** Experimental Conditions.

Velocity	Reynolds Number
100 ft/s	7268208
150 ft/s	10892870

#### **Results and Discussion**

The by taking the lift data gathered from the lab and plotting it against the angle of attack, there is a clear indication of flow separation near the highest angles. This is seen in Figure two where there

are two "loops" at either end of the datapoints. As the airfoil is turned to higher angles of attack,






Figure 2. Lift coefficient plotted against angle of attack.

the flow will eventually separate from the wing and rapidly become turbulent. As the angle goes from -20 to 0, the flow will reattach itself and become more laminar, increasing the lift and subsequently the lift coefficient. Note how the maximum lift coefficient is at the highest angle.



**Figure 3.** Drag coefficient plotted against angle of attack.

Similarly, the drag coefficient can also be found. By plotting it against the angle of attack, the lowest and highest drag coefficient can be attained. For this airfoil, the maximum occurs around 20 and -20 degrees with a CD of approximately 0.27. The lowest occurs at 0 angle of attack and is approximately 0.01. This is accurate as a more turbulent flow will have higher drag.



**Figure 4.** Lift coefficient over drag coefficient vs angle of attack.

By combining the lift and drag data, the best lift to drag ratio can be found for this airfoil. This can be found in Figure 4. The best lift to drag ratio is approximately 27 and occurs at an AOA of 4 degrees. Figure 5, which shows the lift vs drag coefficient can also be useful in characterizing




Figure 5. Lift vs drag coefficient.

the airfoil.

The pitching moment of the quarter chord is also a useful metric in the characterization of airfoils. This is the region of the airfoil that will consistently stay fixed in reference to the freestream




Figure 6. Pitching moment vs Alpha




Figure 7. Aerodynamic center of pressure vs Alpha

As can be seen in Figure 7, the aerodynamic center of the airfoil remains relatively constant throughout the angle of attacks. However, near where the airfoil stalls, approximately 12 degrees, the center moves towards the front of the airfoil and is then located at the leading edge.

## **Conclusions**

An airfoil can be characterized thoroughly through the use of a wind tunnel. By calculating the lift and drag coefficients across several angles of attack, the best lift to drag ratio can be found. Additionally, the pitching moment can be found at any point, usually at the quarter chord, as well as the aerodynamic center.

## References

Department of Aerospace Engineering. AE 315 Experimental Aerodynamics Lab 5. Canvas

#### MATLAB Code

```
clear;
clc;
close all
%load the data into MATLAB
Group1 Pos0=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722 142008 Sec18 Grp1 pos 0.csv');
Group1 Neg0=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722 142654 Sec18 Grp1 neg 0.csv');
Group1 Pos100=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722 143659 Sec18 Grp1 pos 100.csv');
Group1_Neg100=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722_144425_Sec18_Grp1_neg_100.csv');
Group2_Pos0=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722 153011 Sec18 Grp2 pos 0.csv');
Group2 Neg0=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722_153703_Sec18_Grp2_neg_0.csv');
Group2_Pos150=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722 154753 Sec18 Grp2 pos 150.csv');
Group2_Neg150=readtable('D:\Github\School\Aero Lab\Lab
5\Data\Sec18\040722_155535_Sec18_Grp2_neg_150.csv');
%Define Constants
Area=30.94*12;
%Find dynamic pressure for each case
Q Pos100=Group1 Pos100.DynamicPressure-Group1 Pos0.DynamicPressure;
Q Neg100=Group1 Neg100.DynamicPressure-Group1 Neg0.DynamicPressure;
O Pos150=Group2 Pos150.DynamicPressure-Group2 Pos0.DynamicPressure;
Q Neg150=Group2 Neg150.DynamicPressure-Group2 Neg0.DynamicPressure;
%Find the CL for each case
LiftForcePos100=Group1_Pos100.WAFBCSide-Group1_Pos0.WAFBCSide;
LiftForceNeg100=Group1 Neg100.WAFBCSide-Group1 Neg0.WAFBCSide;
LiftForcePos150=Group2 Pos150.WAFBCSide-Group2 Pos0.WAFBCSide;
LiftForceNeg150=Group2 Neg150.WAFBCSide-Group2 Neg0.WAFBCSide;
CL Pos100=LiftForcePos100./(Q Pos100.*Area);
CL_Neg100=LiftForceNeg100./(Q_Neg100.*Area);
CL_Pos150=LiftForcePos150./(Q_Pos150.*Area);
CL Neg150=LiftForceNeg150./(Q Neg150.*Area);
%Find the CD for each case
DragPos100=Group1 Pos100.WAFBCDrag-Group1 Pos0.WAFBCDrag;
DragNeg100=Group1_Neg100.WAFBCDrag-Group1_Neg0.WAFBCDrag;
DragPos150=Group2_Pos150.WAFBCDrag-Group2_Pos0.WAFBCDrag;
```

```
DragNeg150=Group2 Pos150.WAFBCDrag-Group2 Neg0.WAFBCDrag;
CD Pos100=DragPos100./(Q Pos100.*Area);
CD Neg100=DragNeg100./(Q Neg100.*Area);
CD_Pos150=DragPos150./(Q_Pos150.*Area);
CD Neg150=DragNeg150./(Q Neg150.*Area);
%Find CL/CD
CL CDPos100=CL Pos100./CD Pos100;
CL CDNeg100=CL Neg100./CD Neg100;
CL CDPos150=CL Pos150./CD Pos150;
CL_CDNeg150=CL_Neg150./CD_Neg150;
%Find CMac/4
MomentPos100=(Group1_Pos100.WAFBCYaw-Group1_Pos0.WAFBCYaw)./(Q_Pos100*Area*12);
MomentNeg100=(Group1 Neg100.WAFBCYaw-Group1 Neg0.WAFBCYaw)./(Q Neg100*Area*12);
MomentPos150=(Group2 Pos150.WAFBCYaw-Group2 Pos0.WAFBCYaw)./(Q Pos150*Area*12);
MomentNeg150=(Group2 Neg150.WAFBCYaw-Group2 Neg0.WAFBCYaw)./(O Neg150*Area*12);
Moment4Pos100=MomentPos100+CL Pos100*0.25;
Moment4Neg100=MomentNeg100+CL_Neg100*0.25;
Moment4Pos150=MomentPos150+CL Pos150*0.25;
Moment4Neg150=MomentNeg150+CL_Neg150*0.25;
%Find Center of pressure vs Alpha
xcpnorm Pos100=0.25-Moment4Pos100./CL Pos100;
xcpnorm_Neg100=0.25-Moment4Neg100./CL_Neg100;
xcpnorm Pos150=0.25-Moment4Pos150./CL Pos150;
xcpnorm Neg150=0.25-Moment4Neg150./CL Neg150;
hold on
%CL vs Alpha
%plot(Group1_Pos100.Yaw,CL_Pos100,"x","Color","B")
%plot(Group1_Neg100.Yaw,CL_Neg100,"x","Color",
%plot(Group2_Pos150.Yaw,CL_Pos150,"*",'Color',
%plot(Group2 Neg150.Yaw,CL Neg150,"*",'Color','r')
%xlabel("Alpha")
%ylabel("CL")
%legend("150ft/s Positive", "150ft/s Negative", "100ft/s Positive", "100ft/s
Negative","Location","Northwest")
%CD vs Alpha
%0plot(Group1 Pos100.Yaw,CD Pos100,"x","Color","B")
%plot(Group1_Neg100.Yaw,CD_Neg100,"x","Color",
%plot(Group2_Pos150.Yaw,CD_Pos150,"*","Color","r")
%plot(Group2 Neg150.Yaw,CD Neg150,"*","Color","r")
%xlabel("Alpha")
%ylabel("CD")
%legend("100ft/s Positive","100ft/s Negative","150ft/s Positive","150ft/s
Negative","Location","North")
```

```
%CL vs CD
%plot(CD_Pos100,CL_Pos100,"x","Color","B")
%plot(CD_Neg100,CL_Neg100,"x","Color","B")
%plot(CD_Pos150,CL_Pos150,"*","Color","r")
%plot(CD_Neg150,CL_Neg150,"*","Color","r")
%xlabel("CD")
%ylabel("CL")
%legend("100ft/s Positive","100ft/s Negative","150ft/s Positive","150ft/s
Negative", "Location", "best")
%CL/CD vs Alpha
%plot(Group1_Pos100.Yaw,CL_CDPos100,"x","Color","b")
%plot(Group1_Neg100.Yaw,CL_CDNeg100,"x","Color","b")
%plot(Group2_Pos150.Yaw,CL_CDPos150,"*","Color","r")
%plot(Group2_Neg150.Yaw,CL_CDNeg150,"*","Color","r")
%xlabel("Alpha")
%ylabel("CL/CD")
%legend("100ft/s Positive", "100ft/s Negative", "150ft/s Positive", "150ft/s
Negative", "Location", "Northwest")
%Quarter Cord Pitching Moment vs Alpha
%plot(Group1_Pos100.Yaw,Moment4Pos100,"x","Color","B")
%plot(Group1_Neg100.Yaw,Moment4Neg100,"x","Color","B")
%plot(Group2 Pos150.Yaw, Moment4Pos150, "*", "Color", "r")
%plot(Group2 Neg150.Yaw, Moment4Neg150, "*", "Color", "r")
%xlabel("Alpha")
%ylabel("Pitching Moment Coefficient Quarter Cord")
%legend("100ft/s Positive", "100ft/s Negative", "150ft/s Positive", "150ft/s
Negative","Location","Northwest")
%Center of pressure vs Alpha
plot(Group1_Pos100.Yaw,xcpnorm_Pos100,"x","Color","B")
plot(Group1_Neg100.Yaw,xcpnorm_Neg100,"x","Color"
plot(Group2_Pos150.Yaw,xcpnorm_Pos150,"*","Color","r")
plot(Group2_Neg150.Yaw,xcpnorm_Neg150,"*","Color","r")
xlabel("Alpha")
ylabel("Center of Pressure")
legend("100ft/s Positive","100ft/s Negative","150ft/s Positive","150ft/s
Negative","Location","Northwest")
```