



Alpha Aerosols

Standard Operating Procedure (SOP) Planning and Procurement Department

SOP #: AER-PL-002
DATE: June 2026
REVISION: 00

Title: Material Requirements Planning

Effective Date: June 2026

Purpose: To calculate what materials are needed and by when, so production is never held up by missing stock.

Scope: All confirmed production orders for the Aerosol Plant.

Responsibility: Planning and Procurement Lead; Stores Team; Supply Chain Manager

Procedure:

1. Confirm the Production Quantity

- Confirm total units to produce from the Sales Order or approved production plan.

2. Calculate Total Material Needed

- Multiply each material's unit requirement by the total production quantity.
- The result is the total amount needed before checking what is already in stock.

3. Check Stock and Calculate What to Order

- Pull current inventory from the ERP system or the daily Stores report.
- Subtract current stock and open PO quantities from the total material needed.
- Any material where the result is zero or less does not need to be ordered.

4. Check Supplier Lead Times

- Confirm how long each supplier takes to deliver.
- Count back from the production start date to set the latest PO placement date.

5. Prepare and Submit the Requisition

- Assign each material a priority level — P1, P2, P3, or P4 — based on urgency.
- Submit the list with quantities, delivery dates, and priorities to Supply Chain.

6. Track Until Received

- Track deliveries via the ERP system and daily inventory report.
- Follow up on any material at risk of arriving after the production start date.

Created by:	Reviewed by:	Approved by: