BUILD AND USER GUIDE

PfeilZaehler3000

Automatic arrow counter for recurve, barebow and compound bows.
Release 2.1 · 17 October 2026

Part	Version
Pod firmware	2.1 (`firmware/PfeilZaehler3000`)
Debug firmware	2.1-debug (`firmware/PfeilZaehler3000Debug`)
Phone page	2.1 (`app/index.html`), English, German, Polish
Garmin watch app	2.1 (`garmin/PfeilZaehler3000Watch`), English, German, Polish
Housing	v3 (`housing/`)



Software: MIT License · Housing, drawings and documentation: CC BY-SA 4.0 · Hobby project, no warranty.

1. What it is


PfeilZaehler3000 is a small sensor pod that is screwed into a stabilizer bushing of the bow. It detects each shot from the vibration of the riser and stores the time of every arrow, together with details of the shot: how long the raise, the draw and the hold took, how much the bow moved while aiming, the bow angle and cant at the release and the follow-through. A web page on the phone reads the pod over Bluetooth and shows arrows per end, session, day, week and month, and the details of every arrow. An optional Garmin watch app shows the current end and vibrates on every arrow.

The pod only measures the bow it is mounted on. Shots from other archers on the same target or the same line are not counted. It does not record scores or arrow positions.

Size	65 × 35 × 27 mm
Weight	about 65 g including the bolt (measured; base printed with 100 % infill, steel bolt about 14 g)
Mount	5/16"-24 UNF bolt into a stabilizer bushing
Battery	LiPo 3.7 V, 300–320 mAh, charged over USB-C
Memory	about 1,400 arrows with details between two syncs
Connection	Bluetooth Low Energy, up to 3 devices at the same time
Bluetooth name	PfeilZaehler3000-XXXX (XXXX = last 4 characters of the pod's Bluetooth address)
Approx. cost	€ 55–70 for all parts (2026 prices)

> World Archery rules do not allow electronic devices on the bow in competition. Remove the pod for tournaments.

2. How a shot is detected



Shot pattern seen by the pod

The pod contains two sensors: the gyroscope of the XIAO board and a high-g accelerometer (ADXL375, ±200 g). An arrow is counted only when these three things happen in this order:

1. **Holding still.** The bow turns less than 25 °/s for at least 0.6 s (aiming).
2. **Release jolt.** The accelerometer sees a peak above 12 g when the string stops.
3. **Ringing.** The riser keeps vibrating above 2 g for at least 6 samples within 10–150 ms after the peak.

After a counted shot, the pod ignores further jolts for 1.5 s. Putting the bow on a stand, bumping it or carrying it does not produce this sequence. All thresholds can be changed in the firmware (see section 11).

Power saving. After 3 minutes without movement the pod switches the sensors to a low-power mode and only checks for movement 4 times per second. Picking up the bow wakes it. Bluetooth stays available while it is idle, so the phone and the watch can connect at any time.

Shot details. The pod keeps the bow angle and rotation of the last 30 seconds in memory. At every release it looks back and works out the phases of the shot:

Detail	How it is measured
Raise	From the moment the lowered bow (pre-draw, at least 15° below or above the aiming angle) starts to move, until it is within 4° of the aiming angle
Draw & set	From reaching the aiming angle until the final hold starts
Hold	The bow turns less than 8 °/s until the release
Aim movement	How much the bow moves during the last second before the release (drift removed), in degrees; the phone page converts it to cm at the shooting distance
Bow angle	Angle of the arrow axis at the release (+ = aiming up)
Cant	Sideways tilt of the bow at the release (+ = top limb to the right), relative to the zero set on the phone page
Follow-through	How far the bow tips forward/down and sideways in the first 0.5 s after the release

The thresholds are first estimates and can be adjusted (section 11). Raise and draw are only found when the bow was lowered before the shot. Bow angle, cant and follow-through need the pod on the back or the front of the riser, and the mounting point set (section 3).

Ends and sessions. The phone page groups arrows into ends and sessions by the pauses between them: by default a pause longer than 100 s starts a new end, and a pause longer than 45 minutes starts a new session. "New end" on the phone or DOWN on the watch also starts a new end. Arrows per end and the end pause are stored in the pod, so the phone page and the watch use the same values.

3. Bow compatibility

The pod is fastened with a **5/16"-24 UNF** bolt, the standard thread of stabilizer and weight bushings on target bows. It fits any riser with a free bushing of this thread, for example the lowest bushing on the back of the **Kinetic Sovren** barebow riser (the side facing the archer, below the grip), and equally the stabilizer, V-bar or weight bushings of other recurve, barebow and compound risers.



The pod on a Kinetic Sovren 25" riser: archer's side, lowest bushing below the grip; lid with the hole for the hex key

Check before building:

- **Thread.** The bushing must be 5/16"-24 UNF. Metric bushings (for example M6 or M8) need a different bolt and a different hole in the bolt column.
- **Depth.** About 11 mm of the 5/8" (16 mm) bolt sticks out of the pod. If the bolt bottoms out before the pod sits tight, use a 1/2" (12.7 mm) bolt.
- **Space.** The bolt is at one end of the pod, so the pod reaches about 50 mm to one side of the bushing. It must not touch the limbs, the arrow rest, the plunger or the string.
- **Flat seat.** The pod sits on the flat face around the bushing. Its underside has ribs that keep it from turning once the bolt is tight.

Mounting point. The pod knows three mounting points. Set it on the phone page or the watch, or let the calibration find it (section 9, *Calibration*):

Mounting point	Example	Measured
Back of the riser (archer's side)	Lowest bushing on the back of a Kinetic Sovren, as in the picture	Everything: arrows, phase times, aim movement, bow angle, cant, follow-through
Front of the riser (target side)	Long-rod (front stabilizer) bushing	Everything, as on the back
Side bushing	V-bar or a weight bushing on the side of the riser	Arrows, phase times and aim movement; no bow angle, cant or follow-through

On the back and the front the bolt points towards the target or the archer, roughly along the arrow, which the angle measurements need. The bushing does not have to be exactly level: on the Sovren in the picture it sits on the curved lower part of the riser and is tilted by some degrees. The calibration measures this tilt, and also sets the cant zero, so neither the tilt nor how far the pod is turned around the bolt matters. The extra 65 g changes the balance of the bow, so other weights may need adjusting.

4. Parts and tools

Qty	Part	Notes
1	Seeed Studio XIAO nRF52840 **Sense**	Must be the "Sense" version (built-in gyroscope). Bluetooth, battery charger and USB-C on board.
1	Adafruit ADXL375 breakout (STEMMA QT, ±200 g)	High-g accelerometer. Normal ±16 g sensors clip at the release jolt.

Qty	Part	Notes
1	LiPo cell 3.7 V, 300–320 mAh, size 402535 (4 × 25 × 35 mm), with protection circuit	Fits the pocket in the lid. A 502535 also fits without the foam pad.
4	Silicone wire AWG 28–30, about 6 cm each (red, black, yellow, blue)	Sensor to XIAO. The STEMMA QT plugs do not fit in the closed pod.
1	5/16"-24 UNF socket head cap screw, 5/8" (16 mm), steel or A2 stainless (DE: Zylinderschraube mit Innensechskant 5/16-24 UNF × 5/8)	Mounting bolt. Turns freely in the pod.
8	M2 brass heat-set inserts, 4 mm long, 3.2 mm outside diameter	4 for the sensor, 4 for the lid.
8	M2 × 12 mm countersunk screws (DIN 965 / ISO 7046)	4 hold the sensor, 4 hold the lid.
1	1 mm foam sheet (EVA or neoprene), 35 × 25 mm	Pad on the battery.
—	Heat-shrink tubing, thread locker (Loctite 243, optional)	
~35 g	PETG-CF and plain PETG filament	Base and lid in PETG-CF, clamp frame in plain PETG.
1	STEMMA QT to jumper-wire cable (optional)	Only for the bench test before soldering.


Optional vibration motor (a buzz on every counted arrow): 10 mm coin vibration motor 3 V, NPN transistor (2N2222 or S8050), 1 kΩ resistor, 1N4148 diode.

Tools: 3D printer with a hardened nozzle (for PETG-CF), soldering iron with a fine tip, side cutters, 1/4" hex key with a long arm (at least 30 mm), USB-C data cable, a computer with the Arduino IDE, and a phone with Chrome (Android) or the Bluefy browser (iPhone).

5. Print the housing

File	Material	Infill	Orientation
`PfeilZaehler3000-base.stl`	PETG-CF	100 % rectilinear	open side up
`PfeilZaehler3000-frame.stl`	PETG (no carbon fibre)	40 % gyroid	fingers up
`PfeilZaehler3000-lid.stl` or `PfeilZaehler3000-lid-2color.3mf`	PETG-CF	40 % gyroid	top face down

- 0.2 mm layers, 4 walls, no supports.
- **Base with 100 % infill.** With a lower infill, the change to solid layers inside the 8 mm floor leaves a visible line on the outside wall at about 7 mm.
- **Frame in plain PETG**, so its fingers stay slightly springy. Carbon-filled PETG is too stiff and brittle for them.
- **Lid.** `PfeilZaehler3000-lid.stl` has the logo and "PFEILZÄHLER 3000" engraved 0.6 mm deep. For a two-colour lid (e.g. Bambu Lab with AMS), open `PfeilZaehler3000-lid-2color.3mf`, split the object into parts and put the small parts on the second filament. The text looks mirrored in the slicer because the lid prints face down.
- The insert holes are 2.9 mm. `PfeilZaehler3000-insert-test.stl` (in the repository) has holes from 2.7 to 3.0 mm for checking other inserts.
- `pod.scad` (OpenSCAD) is the source of all parts. Sizes such as the insert holes or the USB-C slot can be changed there.




Exploded view: base with sensor and XIAO, clamp frame, battery and foam pad, lid


6. How the parts fit together

No tape or glue is used inside the pod.

- **Base:** bolt column at one end, 4 bosses with inserts for the sensor, inserts in the 4 corner posts for the lid, and a cradle for the XIAO with 4 support pads, corner guides and an end stop.
- **ADXL375:** screwed onto the bosses next to the bolt column, so the release jolt reaches it without damping.
- **XIAO:** lies on 2.5 mm pads with its USB-C socket in the wall slot. The battery wires run underneath.
- **Clamp frame:** sits on the shoulders of the corner posts. Two fingers press on the XIAO's corners and a third on its USB-C socket.
- **Battery and foam pad:** lie on the frame inside the pocket of the lid.
- **Lid:** the walls of the battery pocket press the frame down when the 4 lid screws are tightened. A hole above the bolt column lets the hex key through.




Top view without frame and battery, to scale



Section through the middle. Faded parts sit behind the cut.

Section through the middle of the pod

7. Wiring



Wiring

From	To	Wire
ADXL375 VIN (header pin 1)	XIAO 3V3	red
ADXL375 GND (pin 3)	XIAO GND	black
ADXL375 SCL (pin 4)	XIAO D5	yellow
ADXL375 SDA (pin 5)	XIAO D4	blue
LiPo red	XIAO BAT+ pad (back of the board)	check polarity twice
LiPo black	XIAO BAT− pad	
Motor (optional)	3V3 → motor → transistor collector; emitter → GND; D2 → 1 kΩ → base	diode across the motor, stripe to 3V3; set `USE_MOTOR 1`

8. Build steps

8.1 Inserts and bolt

1. Set the soldering iron to about 230–240 °C. Put each insert straight on its hole and let it sink in with light pressure until it is flush. First the 4 sensor bosses, then the 4 corner posts. Keep the iron vertical.
2. Drop the bolt into the bolt column from the top, thread first. It must turn freely. About 11 mm of thread sticks out of the bottom.
3. Test-fit the empty base on the bow (see section 3).

8.2 Arduino IDE

1. Install the Arduino IDE 2.
2. In **File → Preferences → Additional boards manager URLs** add `https://files.seeedstudio.com/arduino/package_seeeduino_boards_index.json`
3. In the Boards Manager install **Seeed nRF52 Boards**. Do not use the package called "Seeed nRF52 mbed-enabled Boards".
4. Select the board **Seeed XIAO nRF52840 Sense**. No additional libraries are needed.

8.3 Flash and bench test

1. Connect the ADXL375 to the XIAO with the STEMMA QT cable or 4 jumper wires (no soldering yet) and connect the XIAO to the computer.
2. Open `firmware/PfeilZaehler3000/PfeilZaehler3000.ino` and click **Upload**. If the upload fails, double-tap the reset button on the XIAO and upload again.
3. A long green flash means both sensors were found. Repeating red blinks mean a sensor is missing (see section 13).
4. Open the **Serial Monitor** at 115200 baud. Hold the board still for a second, then tap it sharply with a screwdriver handle. The monitor shows `jolt peak=… aim=… ring=… -> SHOT` or `-> ignored`. A light tap on the table is usually ignored, which is correct. After a counted shot a `details:` line follows (raise, draw, hold, aim movement, angle, cant, follow-through); on the bench most of these values are meaningless.
5. Leave the board untouched for 3 minutes. The monitor shows `-> idle`, and `-> active` when it is moved again. Both lines include the pod's name, e.g. `-> idle (PfeilZaehler3000-A3F2)`.
6. **Write the 4 characters of the name on the pod** (marker or label), e.g. *A3F2*. They come from the chip and never change. They tell this pod apart from other pods at the same range.

8.4 Assembly

1. Screw the ADXL375 onto its bosses with 4 M2 × 12 mm screws, component side up, with the header row facing the XIAO. Tighten until snug. The board must not rock, and it must not be bent.
2. Solder the 4 wires into the ADXL375 header holes (VIN, GND, SCL, SDA). Keep the joints flat.
3. Solder the battery to the BAT+ and BAT− pads on the back of the XIAO and cover the joints with heat-shrink.
4. Put the XIAO into its cradle, USB-C first into the wall slot, with the battery wires underneath.
5. Route the sensor wires between the corner guides and solder them to 3V3, GND, D4 and D5. Cut them short enough that they stay below the height of the frame.
6. Place the clamp frame, fingers down, onto the post shoulders. Lead the battery wires through the side opening.
7. Put the battery on the frame and the foam pad on the battery. Fit the lid so the battery sits in its pocket, then tighten the 4 lid screws evenly.
8. Shake the pod. Nothing may rattle. Charge it over USB-C (about 3–4 hours from empty, at 100 mA).

> Never pinch or puncture the LiPo cell. If the lid does not close without force, a wire is lying under the battery.

8.5 Mounting on the bow

1. Hold the pod against the bushing and start the bolt by hand with the hex key through the lid.
2. Align the pod, hold it in place and tighten the bolt firmly. The pod must not move.
3. To remove the pod, loosen the bolt through the lid. The pod does not need to be opened.

9. Phone page

The phone page is a single file, `app/index.html`, that runs entirely in the phone's browser. It only contains the program: each phone connects to its own pod over Bluetooth and stores its history in its own browser. Nothing is sent to the web server or to anyone else, so many people can use the same web address without seeing each other's data.

Web Bluetooth only works on pages loaded over https, so the page is opened from a web address:

- **Published page:** the address in the README of this repository can be used by everyone.
- **Own copy:** fork the repository on GitHub and switch on Pages for the fork (Settings → Pages → Deploy from branch → `main`, folder `/ (root)`). The page is then at `https://<user>.github.io/<repository>/app/`. Alternatively drag the `app` folder onto app.netlify.com/drop.

Language: the page follows the phone's language (English, German or Polish); *Settings* → *Language* changes it.

Trying it without a pod: adding `?demo` to the address (e.g. `…/app/?demo`) opens the page with six weeks of example arrows, so every function can be tried without hardware. Nothing is saved, and the real history is not touched; *Back to my data* returns to the normal page.

The history belongs to the exact web address. To move to another address, make a **Backup** on the old page and **Restore** it on the new one.

Supported browsers: Chrome or Edge on Android, Windows, macOS, Linux and ChromeOS; on iPhone and iPad the **Bluefy** browser (Safari and the other iOS browsers have no Web Bluetooth). Add the page to the home screen for quick access. If Bluefy asks for "Paste" permission at every start, set **Settings → Apps → Bluefy → Paste from Other Apps → Deny**.

All data is stored in the browser (local storage of that web address). Use **Backup** regularly.

Functions

Connection

- **Connect pod & sync** – first connection: choose your pod (*PfeilZaehler3000-XXXX*) in the list. The page remembers it from then on, sets the pod's clock and time zone and downloads all new arrows.
- **Update now** – while connected: downloads new arrows and reads the battery voltage again.
- **Reconnect & update** – when the connection was lost.
- **Choose pod** – pick a different pod (the page then remembers that one).
- **Disconnect** – ends the connection.
- While connected, the page updates by itself after every arrow. When the page is opened again, it reconnects automatically, only to the remembered pod.

Finding your pod: every pod has its own name, e.g. *PfeilZaehler3000-A3F2* (see 8.3). Connect for the first time with only your own pod nearby. If several pods are listed, choose one and look for the blue LED: it lights on the pod that is connected.

Status line (on a computer, pointing at a symbol shows a short explanation):

Symbol	Shows
Bluetooth	The pod's name, e.g. *Pod A3F2*: green when connected, amber while connecting, red while reconnecting, grey when not connected
Battery	Pod battery voltage; amber below 3.7 V, red below 3.6 V
Memory	How full the pod's memory is; it is cleared after a sync once it is fuller than the set value
Circular arrows	Time of the last sync

Below the symbols a short message appears after a sync (e.g. *3 new arrows synced*) or when something went wrong.

This end: arrows in the current end out of the set number per end (green when complete, orange when more). **New end** starts a new end immediately, without confirmation. The pod and the watch start a new end too.

Totals: arrows today, this week (from Monday), this month and all time.

History: bar chart of arrows per day (30 days), per week (12 weeks) or per month (12 months).

Sessions: the last 40 sessions with date, time span, number of ends and arrows, and the average hold time, aim movement and cant spread. Ends with a different number of arrows than set are highlighted. **Tap an end** to see its arrows and the averages of that end. Each arrow shows the time of the first arrow (hours:minutes), then the time since the previous arrow (+minutes:seconds), and its hold time.

- **Tap an arrow** to open its details: raise, draw & set, hold, aim movement (degrees and cm), bow angle, cant, follow-through and jolt strength. With the pod in a side bushing, bow angle, cant and follow-through show "–".
- **Red bin:** delete a single arrow, e.g. a bump that was counted. The arrow is greyed out and can be restored with the green arrow.
- **Delete end**, with **Undo** in the status line.
- Deleted arrows are removed from all statistics and are also deleted on the pod and on the watch.

Settings

Setting	Default	Effect
Language	Automatic	English, German or Polish; Automatic follows the phone
Arrows per end	6	Target for the end display and highlighting; stored in the pod, shared with the watch
New end after a pause of (s)	100	Pause that separates ends; stored in the pod, shared with the watch
New session after a pause of (min)	45	Pause that separates sessions
Shooting distance for the aim movement (m)	18	Converts the aim movement from degrees to cm on the target
Clear pod memory after sync when fuller than (%)	50	Frees the pod's memory once the arrows are safely on the phone
Pod mounted on	back of the riser	Back, front or side bushing (section 3); stored in the pod, shared with the watch, set by the calibration
Calibrate…	–	See below

Changes to arrows per end and the end pause only apply from the moment they are changed; earlier ends keep their grouping. A change on the watch shows up here, and the other way round; the last change counts.

Calibration (once after mounting the pod, about 10 seconds; the pod must be connected):

1. Hold the bow upright as when aiming, without cant and with the arrow level (horizontal), and keep it still; a bubble level helps. Tap **Next**. This position becomes cant 0 and bow angle 0, which also removes the tilt of the bushing.
2. Point the arrow at the ground, about 45° down, keep the bow upright and still. Tap **Finish**. From the way the pod turned, it finds its mounting point (back, front or side) and stores it.

The settings show the result, e.g. *Calibrated: pod mounted on the back of the riser*. If the bow was not tilted far enough, the calibration asks to start again. Until it is calibrated, the first shot counts as cant 0.

Export & backup

- **Export CSV** – one line per arrow: index, local date and time, unix time, jolt (g), still time before the release (s), raise, draw and hold (s), aim movement, bow angle and cant (°), follow-through down and right (°), clock exact (1/0), deleted (1/0). On iPhone it opens the share sheet.
- **Backup** – the complete history as a JSON file.
- **Restore** – reads a backup from a file or from pasted text and merges it with the existing data.

Reset (both ask for confirmation)

- **Reset today** – deletes today's arrows on the phone, the pod and the watch.
- **Reset all stats** – deletes the whole history on this phone and, if the pod is connected, clears the pod's memory and its day counters. Make a backup first.

10. Garmin watch app

The watch app has been built for the **Garmin Epix (Gen 2)**. It connects to the pod directly; the phone is not needed while shooting. Other Garmin watches with Connect IQ 3.2 or newer and Bluetooth Low Energy support may work after adding them in `manifest.xml`; this has not been tested.

Screen

From top to bottom:

- Time of day.
- The pod's ID and battery voltage, e.g. *Pod A3F2 3.95 V* (orange when getting low, red when it needs charging), or the connection state: *Looking for Pod A3F2…*, *Pod A3F2 in range?*, *Connecting…*, *Reconnecting…*.
- End number and time since the last arrow.
- The big number: arrows in the current end (green when complete, orange with an extra arrow), or the session or today's arrows, as chosen in the settings.
- The other counters in a row: this end (e.g. *4/6*), session, today and week, without the one shown big. Today, week and month come from the pod and match the phone page, including arrows shot while the watch app was closed.
- Arrows this month.
- Recording time, or *START: record*.
- Time to sunset, if switched on.

Buttons

Button	Function
START	Start / stop recording a Garmin activity "Bogenschiessen"
BACK	Saves a running activity; pressed again, leaves the app
DOWN	Start a new end now (also shown on the phone page)
UP	Delete the last arrow, after a confirmation (also deleted on the phone page)
hold UP	Settings

The touchscreen has no function, so a touch can't start a recording or change anything.

Settings (hold UP)

Setting	Values	Stored
Arrows per end	3–12 (default 6)	in the pod, shared with the phone page
New end after	30 s – 5 min (default 100 s)	in the pod, shared with the phone page
Big number	this end, session or today	on the watch
Time to sunset	on / off	on the watch; uses the weather position from Garmin Connect or the last GPS position
Mounting point	back of riser, front of riser, side bushing	in the pod, shared with the phone page
Language	Automatic (as the watch), English, Deutsch, Polski	on the watch
Use a different pod	after a confirmation, connects to the next pod found	on the watch

- **Vibration:** short on every arrow, double when the end is complete.
- **Ends:** a pause longer than the set time, or DOWN, starts a new end.
- **Recording:** a recorded activity contains duration, heart rate and calories like any other activity, plus the number of arrows and ends in the summary, a chart of the arrow count and one lap per end with its number of arrows. Garmin's own Archery activity cannot be used by Connect IQ apps, so the recording is saved as a generic activity; its type can be changed afterwards in Garmin Connect.
- **Reconnecting:** if the pod is out of range, the watch reconnects by itself when it is back.
- **Own pod:** the watch remembers the first pod it connects to and from then on only connects to that one, even when other pods are nearby. Open the app for the first time with only your own pod nearby. Use *Use a different pod* in the settings to change it.
- **Deleted on the phone:** an arrow deleted on the phone page is also taken off the watch's session and end; a restored one comes back without a vibration.

Build and install

1. Install **Java** (JDK 17 or newer, e.g. Temurin from adoptium.net). Check with `/usr/libexec/java_home -V` on a Mac.
2. Install the **Connect IQ SDK Manager** (developer.garmin.com/connect-iq/sdk), sign in, download the newest SDK and set it as active. Under *Devices* download **epix (Gen 2)** (listed under API level 5.2).
3. Install **Visual Studio Code** and the extension **Monkey C** (Garmin).
4. In VS Code: *Monkey C: Verify Installation*, then *Monkey C: Generate a Developer Key*. Keep the key private and safe; updates of the app must be built with the same key.
5. Open the folder `garmin/PfeilZaehler3000Watch` and run *Monkey C: Build for Device* → **epix2**. The result is a `.prg` file.
6. Copy the `.prg` file to `GARMIN/APPS` on the watch. On a Mac this needs an MTP tool such as **OpenMTP**; quit Garmin Express first. If the watch's folders do not show, switch OpenMTP between its legacy and Kalam mode.
7. Unplug the watch. Press START, scroll to the end of the activity list, choose **Add** and add **PfeilZaehler3000**.

11. Calibration and tuning

1. Shoot 3–4 normal ends and sync. Check whether every end shows the right number of arrows.
2. Use **Export CSV** and look at the `peak_g` column: it shows how hard the releases hit the riser. Light draw weights give smaller values.
3. **Arrows missing:** set `SPIKE_G` to about half of the lowest `peak_g` and upload the firmware again.
4. **Extra arrows:** raise `MIN_AIM_MS` (e.g. to 1000) or `SPIKE_G`.

Shot phases. Upload the debug firmware (section 14), open the Serial Monitor and shoot a few arrows. After every shot it prints the details and a trace of the last 12 s (bow angle / rotation, 5 values per second). If raise, draw or hold look wrong, adjust `HOLD_DPS`, `AWAY_DEG` or `LEVEL_DEG`. Sending a few of these traces makes tuning easier.

The values are at the top of the firmware file:

Name	Default	Meaning
`SPIKE_G`	12	Release jolt threshold (g)
`RING_G`	2	Ringing level (g)
`RING_MIN_SAMPLES`	6	Ringing samples needed 10–150 ms after the jolt
`STILL_DPS`	25	Rotation below this counts as holding still (°/s)
`MIN_AIM_MS`	600	Minimum holding time before the release (ms)
`REFRACTORY_MS`	1500	Dead time after a counted shot (ms)
`IDLE_AFTER_MS`	180000	Time without movement before power saving (ms)
`HOLD_DPS`	8	Rotation below this counts as the final hold (°/s)
`AWAY_DEG`	15	Angle away from the aiming angle that counts as lowered (pre-draw) (°)
`LEVEL_DEG`	4	Angle within this of the aiming angle counts as raised (°)
`REST_DPS`	5	Rotation below this for 0.3 s while lowered counts as resting (°/s)
`FOLLOW_MS`	500	Time after the release for the follow-through (ms)
`CALIBRATION_LOG`	1	Print every jolt to the Serial Monitor
`USE_MOTOR`	0	1 = vibration motor on D2

12. Daily use and charging

- Shoot as usual. A short green flash on the pod confirms a counted arrow.
- Open the phone page after training (or keep it connected). The watch app can run at the same time.
- Charge when the voltage is below about 3.6 V. The watch shows this in orange and red.
- Battery life depends on how long the pod is moved and awake. A pod lying unused switches to power saving after 3 minutes (shown as `-> idle` on the Serial Monitor).

Pod LED

LED	Meaning
Green, 0.3 s after switching on	Both sensors found
Short green flash	Arrow counted and stored
Short red flash after a shot	Arrow not stored: memory full, sync with the phone
Red, 1 blink repeating	Gyroscope (XIAO) not found
Red, 2 blinks repeating	ADXL375 not found
Blue	Phone or watch connected

13. Troubleshooting

Problem	Solution
Upload fails, or no port appears	Double-tap reset (bootloader mode). Use a USB cable that carries data.
macOS: `exec: "python" not found` during upload	In Terminal: `sudo ln -sf "$(which python 3)" /usr/local/bin/python`
macOS: error about ASCII / locale during upload	`launchctl setenv LANG en_US.UTF-8` and `launchctl setenv LC_ALL en_US.UTF-8`, then restart the Arduino IDE
Red, 1 blink repeating	Wrong board selected. Use "Seeed XIAO nRF52840 Sense" from the non-mbed package.
Red, 2 blinks repeating	Check the ADXL375 wiring: SDA to D4, SCL to D5, VIN to 3V3.
Pod hangs after the battery was soldered	Flash the debug firmware and read the Serial Monitor (section 14).
Ends often one arrow short	Lower `SPIKE_G`. Check that the sensor screws and the mounting bolt are tight.
Extra arrows	Raise `MIN_AIM_MS` or `SPIKE_G`. Putting the bow down hard can look like a shot.
Battery empty after a few days	Check on the Serial Monitor that the pod shows `-> idle` after 3 minutes. The debug firmware never sleeps.
"No Web Bluetooth" on the phone page	Open it over https in Chrome or Edge, or in Bluefy on iPhone.
Arrows listed without a date	The pod restarted with an empty battery and had no clock. Connect the phone page after charging.
Watch shows "Update pod firmware"	Flash the current pod firmware (2.1).
Watch stays at "Pod … in range?"	Check the distance to the pod and that the pod is charged.

Problem	Solution
Phone or watch connected to another archer's pod	Phone: **Choose pod** and pick your own name. Watch: hold UP → *Use a different pod*, confirm, and keep only your own pod nearby.
No raise / draw times	The bow was not lowered before the shot, or the history was empty after the pod woke up. Hold and the other details are still measured.
Cant values look offset	Calibrate again (phone settings → *Calibrate…*) with the bow exactly upright.
Bow angle negative when aiming up, cant or follow-through reversed	The mounting point is set wrong: calibrate, or set *Pod mounted on* in the settings (section 3).
Bow angle, cant and follow-through show "–"	The mounting point is set to *side bushing*.
Which name is my pod?	Connect and look for the blue LED, or read the name on the Serial Monitor (section 8.3).

14. Debug firmware

`firmware/PfeilZaehler3000Debug` has the same functions and Bluetooth interface as firmware 2.1, so the phone page and the watch work with it. In addition it:

- waits up to 5 s for the Serial Monitor and prints the reset reason,
- prints every start-up step including the pod's name and Bluetooth address, the state of both I2C buses and the I2C addresses found,
- prints a status line every 2 s: sensors, awake/idle, Bluetooth connections and advertising, records, arrows today/week/month, battery voltage, the current accelerometer values, the bow angle and the rotation,
- prints the shot details and a 12 s trace of bow angle and rotation after every arrow,
- blinks the blue LED briefly every 2 s while nothing is connected,
- never switches to power saving, so it empties the battery within a few days.

Use it for diagnosis only, then upload the normal firmware again.

15. Files

Path	Content
`firmware/PfeilZaehler3000/`	Pod firmware 2.1 (Arduino)
`firmware/PfeilZaehler3000Debug/`	Debug firmware
`app/index.html`	Phone page 2.1
`garmin/PfeilZaehler3000Watch/`	Garmin watch app 2.1 (Connect IQ project)
`housing/`	STL and 3MF files, OpenSCAD source `pod.scad`, insert test
`docs/`	This guide, Bluetooth protocol, images

16. Licence and safety

Software (firmware, phone page, watch app) is published under the **MIT License**; the housing models, drawings and this guide under **Creative Commons Attribution-ShareAlike 4.0 (CC BY-SA 4.0)**. See `LICENSE` and `LICENSE-hardware`.

> This is a hobby project without any warranty. Lithium polymer cells can catch fire if they are damaged, short-circuited or charged incorrectly: use cells with a protection circuit, never puncture or squeeze them, and do not charge the pod unattended. Kinetic, Garmin, Epix, Seeed, Adafruit and Bluefy are trademarks of their respective owners; this project is not affiliated with them.