IoT Sensing SDK

Getting started with IoT Sensing SDK (ISSDK) v1.7
middleware

Rev. 1.4 — 3 April 2018

User guide

Document information

Information	Content
Keywords	IoT Sensing SDK, ISSDK, MCUXpresso, middleware
Abstract	Getting started with IoT Sensing SDK (ISSDK) v1.7 middleware



1 Prerequisites

This document assumes completion of the following prerequisites prior to attempting to use the ISSDK v1.7 middleware:

- One of the recommended IDEs is installed on the development PC (see the release notes)
- A FRDM-K64F-AGM01 sensor kit is connected to the development PC
- User understanding of the debug environment set up for the Freedom family of development boards using OpenSDA or third-party debugger with their IDE of choice
- User familiarity with the MCUXpresso SDK and MCUXpresso SDK Builder


2 Overview

The IoT Sensing Software Development Kit (ISSDK) is the embedded software framework enabling NXP's digital and analog sensors platforms for IoT applications. ISSDK provides a unified set of sensor support models that target NXP's portfolio of sensors across a broad range of ARM Cortex core-based Microcontrollers. ISSDK is offered as a middleware component in MCUXpresso SDK for supported microcontrollers. ISSDK relies on the SDK 2.x drivers and project release infrastructure to create a unified user experience. ISSDK v1.7 combines a set of robust sensor drivers and algorithms along with example applications to allow a user to get started using NXP sensors quickly.

For more information on ISSDK, go to www.nxp.com/iotsensingsdk.

2.1 ISSDK architecture

Figure 1 shows the high-level *layer cake* architecture of the ISSDK v1.7 middleware. ISSDK is designed to provide separable layers of functionality that a customer can choose to use or ignore based on their specific needs. In addition, the ISSDK architecture is portable due to the use of open APIs (ARM Ltd. CMSIS Driver APIs). ISSDK is designed to allow users to start with as small a production footprint (memory and CPU load) as is practical for their particular application. This is typically done by selecting the Bare Metal option; however, some applications may prefer using one of the RTOSs supplied with MCUXpresso SDK 2.4.




In the following sections, this guide focuses on how ISSDK can be deployed via MCUXpresso for a specific Freedom Sensor Toolbox sensor demonstration kit called the FRDM-K64F-AGM01. This kit combines the Kinetis FRDM-K64F development board with a FRDM-STBC-AGM01 sensor shield to provide a stand-alone, low cost sensor development platform.

3 NXP Freedom Sensor Toolbox Sensor Development Ecosystem

NXP provides a sensor development ecosystem called the Freedom Sensor Toolbox. This ecosystem is designed to provide solutions for hardware and software that enable customers to evaluate and prototype with sensors quickly and easily. ISSDK v1.7 is deployed on top of the Freedom Sensor Toolbox hardware platforms and is expected to become the embedded software support platform for the ecosystem.

The following figure shows how the Freedom Sensor Toolbox development hardware can be used to explore the ISSDK v1.7 software. In this example, the MCUXpresso IDE is used to compile, load and launch an existing project into the FRDM-K64F-AGM01 kit. The customer may then launch a terminal emulator to examine the debug console output provided for many ISSDK v1.7 projects.



More information about the Freedom Sensor Toolbox development ecosystem can be found at http://nxp.com/sensortoolbox. The remainder of this document focuses on the steps involved to use the FRDM-K64F-AGM01 development kit with the ISSDK enablement software.

4 Project deployment

ISSDK v1.7 is fully integrated into the MCUXpresso Web and SDK Builder delivery system. MCUXpresso includes both cloud and locally based tools to collect and build projects from the MCUXpresso SDK repositories. MCUXpresso SDK 2.x is built using a hierarchy of deployed Git repositories. Specific project codebases are built through the online tool. A given codebase is specified by its target (device, board, or kit desired), the version of MCUXpresso SDK 2.x, the supported IDEs (MCUXpresso IDE, IAR, Keil, GCC), and the target Host OS (Windows, Mac, or Linux).


4.1 MCUXpresso Web & SDK Builder

MCUXpresso Web & SDK Builder is a cloud-based system used to build MCUXpresso SDK 2.x packages. ISSDK is an optional component that can be deployed by MCUXpresso in two ways:

- If the customer selects a FRDM sensor kit, such as the FRDM-K64F-AGM01, then the ISSDK sensor drivers and example applications appropriate for that kit are deployed into the package.
- If the customer selects a supported device or FRDM board and checks the box for optional ISSDK support, then all the sensor drivers and example applications are deployed into the package.


It should be noted that in both cases the MCUXpresso SDK 2.x drivers and example applications are also deployed alongside the ISSDK files.

Figure 3 shows the MCUXpresso environment for deploying ISSDK (see https://mcuxpresso.nxp.com/en/configuration-settings). In this example, the customer has selected the FRDM-K64F-AGM01 kit, the MCUXpresso IDE, and Windows host operating system. Notice that ISSDK middleware component has been selected by default because the target is a board/shield kit. When the customer selects the Build SDK Package, the request is sent to the build servers. Requests for packages are served in order and when the package is ready, a notification is returned to the customer. At this point, the customer may download the package (a zip file) and deploy it into their local system.



4.2 Deployment directory structure

Once the MCUXpresso package has been downloaded, the user can extract the package on their local machine. Figure 4 displays the MCUXpresso directory structure.



The CMSIS, devices, docs, RTOS, and tools directories are unchanged from standard

MCUXpresso SDK 2.x deployments. ISSDK v1.7 projects appear as new targets in the boards directory. Figure 5 illustrates the directory where frdmk64f_agm01 (ISSDK) reference example projects are available, as well as the base projects for the frdmk64f.



In addition, a new middleware component is created that contains the ISSDK drivers, algorithms and other support files as shown in Figure 6.




Build and run a sensor driver example 5

Choose FRDM-K64F-AGM01 kit configuration and download SDK package from MCUXpresso SDK Builder. Figure 7 and Figure 8 illustrate how to get the FRDM-K64F-AGM01 SDK package from MCUXpresso configuration.


ISSDKGETSTARTEDUG

All information provided in this document is subject to legal disclaimers.

© NXP B.V. 2018. All rights reserved.



Install downloaded SDK package into MCUXpresso IDE (drag and drop SDK package into "Installed SDKs" view). Start SDK import wizard, import any existing ISSDK example by choosing frdmk64_agm01 board for your project, build the imported project and load the image to FRDM-K64FAGM01 kit. This creates a standalone project in your workspace. Refer to Figure 8.



Notice that the code is ready to start in the file *fxos8700_interrupt.c*, which is the main application for this example.

Start the program execution. The blue LED begins to flash on the FRDM-K64F board. Next, start a terminal emulation program with the serial port set as shown in Figure 9.





Figure 10 displays the debug console window and output.



In this example, each data ready interrupt from the FXOS8700 triggers the application to read the raw X-, Y-, Z-axis accelerometer values. These raw values are then converted to 16-bit unsigned integers and output in real time to the debug console.


6 Build and run sensor fusion

Start SDK import wizard and import ISSDK sensor fusion example by choosing frdmk64_agm01 board for your project. This creates a standalone project in your workspace. Refer to Figure 11.


ISSDKGETSTARTEDUG

All information provided in this document is subject to legal disclaimers.

© NXP B.V. 2018. All rights reserved



Build the sensor fusion project in the MCUXpresso IDE and load the image to FRDM-K64F-AGM01 kit. Refer to Figure 12.



Notice the code is ready to start in the file *main_agm01_freertos_two_tasks.c*, which is the main application for this example.

Start the program execution. The green LED begins to flash on the FRDM-K64F board.

You can now install the Sensor Fusion GUI application in order to visualize the operation of the Sensor Fusion application. Go to http://nxp.com/sensorfusion, download the latest Sensor Fusion for Windows GUI and install it. Launch the Sensor Fusion GUI. Select the Port from the pull-down menu. The GUI main screen should resemble Figure 13.



This completes the exercise to run the ISSDK 1.7 Sensor Fusion project.

7 Revision history

Table 1. Revision history

Revision number	Date	Description
1.4	20180403	Updates for ISSDK v1.7
1.3	20170525	Updates for ISSDK v1.6
1.2	20170306	Updates for ISSDK v1.5
1.1	20161123	Updates for ISSDK v1.1
1.0	20160803	Initial public release

8 Legal information

8.1 Definitions

Draft — The document is a draft version only. The content is still under internal review and subject to formal approval, which may result in modifications or additions. NXP Semiconductors does not give any representations or warranties as to the accuracy or completeness of information included herein and shall have no liability for the consequences of use of such information.

8.2 Disclaimers

Limited warranty and liability — Information in this document is believed to be accurate and reliable. However, NXP Semiconductors does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information and shall have no liability for the consequences of use of such information. NXP Semiconductors takes no responsibility for the content in this document if provided by an information source outside of NXP Semiconductors. In no event shall NXP Semiconductors be liable for any indirect, incidental, punitive, special or consequential damages (including - without limitation - lost profits, lost savings, business interruption, costs related to the removal or replacement of any products or rework charges) whether or not such damages are based on tort (including negligence), warranty, breach of contract or any other legal theory. Notwithstanding any damages that customer might incur for any reason whatsoever, NXP Semiconductors' aggregate and cumulative liability towards customer for the products described herein shall be limited in accordance with the Terms and conditions of commercial sale of NXP Semiconductors.

Right to make changes — NXP Semiconductors reserves the right to make changes to information published in this document, including without limitation specifications and product descriptions, at any time and without notice. This document supersedes and replaces all information supplied prior to the publication hereof.

Suitability for use — NXP Semiconductors products are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of an NXP Semiconductors product can reasonably be expected to result in personal injury, death or severe property or environmental damage. NXP Semiconductors and its suppliers accept no liability for inclusion and/or use of NXP Semiconductors products in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk

Applications — Applications that are described herein for any of these products are for illustrative purposes only. NXP Semiconductors makes no representation or warranty that such applications will be suitable

for the specified use without further testing or modification. Customers are responsible for the design and operation of their applications and products using NXP Semiconductors products, and NXP Semiconductors accepts no liability for any assistance with applications or customer product design. It is customer's sole responsibility to determine whether the NXP Semiconductors product is suitable and fit for the customer's applications and products planned, as well as for the planned application and use of customer's third party customer(s). Customers should provide appropriate design and operating safeguards to minimize the risks associated with their applications and products. NXP Semiconductors does not accept any liability related to any default, damage, costs or problem which is based on any weakness or default in the customer's applications or products, or the application or use by customer's third party customer(s). Customer is responsible for doing all necessary testing for the customer's applications and products using NXP Semiconductors products in order to avoid a default of the applications and the products or of the application or use by customer's third party customer(s). NXP does not accept any liability in this respect.

Export control — This document as well as the item(s) described herein may be subject to export control regulations. Export might require a prior authorization from competent authorities.

Non-automotive qualified products — Unless this data sheet expressly states that this specific NXP Semiconductors product is automotive qualified, the product is not suitable for automotive use. It is neither qualified nor tested in accordance with automotive testing or application requirements. NXP Semiconductors accepts no liability for inclusion and/or use of nonautomotive qualified products in automotive equipment or applications. In the event that customer uses the product for design-in and use in automotive applications to automotive specifications and standards, customer (a) shall use the product without NXP Semiconductors' warranty of the product for such automotive applications, use and specifications, and (b) whenever customer uses the product for automotive applications beyond NXP Semiconductors' specifications such use shall be solely at customer's own risk, and (c) customer fully indemnifies NXP Semiconductors for any liability, damages or failed product claims resulting from customer design and use of the product for automotive applications beyond NXP Semiconductors' standard warranty and NXP Semiconductors' product specifications.

Translations — A non-English (translated) version of a document is for reference only. The English version shall prevail in case of any discrepancy between the translated and English versions.

8.3 Trademarks

Notice: All referenced brands, product names, service names and trademarks are the property of their respective owners.

Kinetis — is a trademark of NXP B.V.

IoT Sensing SDK

Getting started with IoT Sensing SDK (ISSDK) v1.7 middleware

Contents

1	Prerequisites	2
2	Overview	
2.1	ISSDK architecture	2
3	NXP Freedom Sensor Toolbox Sensor	
	Development Ecosystem	3
4	Project deployment	
4.1	MCUXpresso Web & SDK Builder	
4.2	Deployment directory structure	
5	Build and run a sensor driver example	
6	Build and run sensor fusion	8
7	Revision history	. 11
R	Legal information	12

Please be aware that important notices concerning this document and the product(s) described herein, have been included in section 'Legal information'.