Continuous-time systems 2

Properties of state-space representation

- 2 Transfer functions
 - Impulse response and time constant
 - Relationship between state space and transfer functions

Outline

Properties of state-space representation

- Transfer functions
 - Impulse response and time constant
 - Relationship between state space and transfer functions

Observability

A measure of how well a system's internal states \mathbf{x} can be inferred by knowledge of its outputs \mathbf{y} .

Observability

A measure of how well a system's internal states \mathbf{x} can be inferred by knowledge of its outputs \mathbf{y} .

Formally, a system is said to be observable if, for any possible sequence of state and control vectors, the current state can be determined in finite time using only the outputs.

Observability

A measure of how well a system's internal states x can be inferred by knowledge of its outputs y.

Formally, a system is said to be observable if, for any possible sequence of state and control vectors, the current state can be determined in finite time using only the outputs.

This holds for linear, time-invariant systems with n states if:

$$rank(\mathcal{O}) = n, \quad \mathcal{O} = \begin{bmatrix} \mathbf{C} \\ \mathbf{CA} \\ \vdots \\ \mathbf{CA}^{n-1} \end{bmatrix}, \quad \mathcal{O} : \mathbf{observability \ matrix}$$

Controllability

A measure of the ability to move a system around in its entire configuration space using only certain admissible manipulations.

Controllability

A measure of the ability to move a system around in its entire configuration space using only certain admissible manipulations.

A system is controllable if its state can be moved from any initial state \mathbf{x}_0 to any final state \mathbf{x}_f via some finite sequence of inputs $\mathbf{u}_0 \dots \mathbf{u}_f$.

Controllability

A measure of the ability to move a system around in its entire configuration space using only certain admissible manipulations.

A system is controllable if its state can be moved from any initial state \mathbf{x}_0 to any final state \mathbf{x}_f via some finite sequence of inputs $\mathbf{u}_0 \dots \mathbf{u}_f$.

A linear, time-invariant system with n states is controllable if:

$$rank(\mathcal{C}) = n, \quad \mathcal{C} = \begin{bmatrix} \mathbf{B} & \mathbf{A}\mathbf{B} & \dots & \mathbf{A}^{n-1}\mathbf{B} \end{bmatrix},$$

where C is called the **controllability matrix**.

Outline

1 Properties of state-space representation

- Transfer functions
 - Impulse response and time constant
 - Relationship between state space and transfer functions

Transfer function

The transfer function of input i to output j is defined as:

$$H_{i,j}(s) = \frac{Y_j(s)}{U_i(s)}, \quad \mathbf{U}(s) = \mathcal{L}\{u(t)\}, \quad \mathbf{Y}(s) = \mathcal{L}\{y(t)\}.$$

MIMO systems with n inputs and m outputs have $n \times m$ transfer functions, one for each input-output pair.

Transfer function

The transfer function of input i to output j is defined as:

$$H_{i,j}(s) = rac{Y_j(s)}{U_i(s)}, \quad \mathbf{U}(s) = \mathcal{L}\{u(t)\}, \quad \mathbf{Y}(s) = \mathcal{L}\{y(t)\}.$$

MIMO systems with n inputs and m outputs have $n \times m$ transfer functions, one for each input-output pair.

The complex Laplace variable can be rewritten: $s = \sigma + j\omega$.

Transfer function

The transfer function of input i to output j is defined as:

$$H_{i,j}(s) = rac{Y_j(s)}{U_i(s)}, \quad \mathbf{U}(s) = \mathcal{L}\{u(t)\}, \quad \mathbf{Y}(s) = \mathcal{L}\{y(t)\}.$$


MIMO systems with n inputs and m outputs have $n \times m$ transfer functions, one for each input-output pair.

The complex Laplace variable can be rewritten: $s = \sigma + j\omega$.

The frequency response of a system can be analyzed via $\mathbf{H}(j\omega)$:

$$e^{\sigma+j\omega}=e^{\sigma}(\cos\omega+j\sin\omega).$$

Illustration of Euler's formula



In general, the transfer function can be written as:

$$H(s) = \frac{N(s)}{D(s)}.$$

In general, the transfer function can be written as:

$$H(s) = \frac{N(s)}{D(s)}.$$

The poles of H(s) are zeros of D(s), ie $\{s : D(s) = 0\}$.

• $|H(s)| = \infty$ if s is a pole.

In general, the transfer function can be written as:

$$H(s) = \frac{N(s)}{D(s)}.$$

The poles of H(s) are zeros of D(s), ie $\{s : D(s) = 0\}$.

• $|H(s)| = \infty$ if s is a pole.

The zeros of H(s) are zeros of N(s), ie $\{s : N(s) = 0\}$.

• H(s) = 0 if s is a zero.

In general, the transfer function can be written as:

$$H(s) = \frac{N(s)}{D(s)}.$$

The poles of H(s) are zeros of D(s), ie $\{s : D(s) = 0\}$.

• $|H(s)| = \infty$ if s is a pole.

The zeros of H(s) are zeros of N(s), ie $\{s : N(s) = 0\}$.

• H(s) = 0 if s is a zero.

Poles and zeros may cancel, ie. if D(s) = N(s) = 0 for some s.

Steady-state response

The output of a linear time-invariant system yields consists of:

- a steady-state output $y_{ss}(t)$, which similar periodicity to u(t)
 - $ightarrow y_{ss}$ comprises the same frequencies as u(t)
- a transient output $y_{tr}(t)$
 - ightarrow if the system is stable, then $\lim_{t
 ightarrow \infty} y_{tr}(t) = 0$
 - $\rightarrow y_{tr}(t)$ depends on the initial state $\mathbf{x}_0(t)$ of the system

Steady-state response

The output of a linear time-invariant system yields consists of:

- a steady-state output $y_{ss}(t)$, which similar periodicity to $u(t) \rightarrow y_{ss}$ comprises the same frequencies as u(t)
- a transient output $y_{tr}(t)$
 - \rightarrow if the system is stable, then $\lim_{t\to\infty}y_{tr}(t)=0$
 - $\rightarrow y_{tr}(t)$ depends on the initial state $\mathbf{x}_0(t)$ of the system

If we apply an input $u(t) = cos(\alpha t + \theta)$, then:

$$y_{ss}(t) = |H(j\alpha)|cos(\alpha t + \theta + \angle H(j\alpha))|$$

Steady-state response

The output of a linear time-invariant system yields consists of:

- a steady-state output $y_{ss}(t)$, which similar periodicity to u(t) $\rightarrow y_{ss}$ comprises the same frequencies as u(t)
- a transient output $y_{tr}(t)$
 - \rightarrow if the system is stable, then $\lim_{t\to\infty} y_{tr}(t)=0$
 - $\rightarrow y_{tr}(t)$ depends on the initial state $\mathbf{x}_0(t)$ of the system

If we apply an input $u(t) = cos(\alpha t + \theta)$, then:

$$y_{ss}(t) = |H(j\alpha)|cos(\alpha t + \theta + \angle H(j\alpha))|$$

The steady-state output $y_{ss}(t)$ of a linear time invariant system:

- ullet consists of signals of same frequencies as the input signal u(t)
- which may have been magnified and/or phase changed

Outline

Properties of state-space representation

- Transfer functions
 - Impulse response and time constant
 - Relationship between state space and transfer functions

The impulse response h(t) of input i to output j is the output $y_j(t)$ of a system when an impulse $\delta(t)$ is applied at input $u_i(t)$.

The impulse response h(t) of input i to output j is the output $y_j(t)$ of a system when an impulse $\delta(t)$ is applied at input $u_i(t)$.

The impulse response is the inverse Laplace transform of the transfer function $h(t) = \mathcal{L}^{-1}\{H(s)\}$.

The impulse response h(t) of input i to output j is the output $y_j(t)$ of a system when an impulse $\delta(t)$ is applied at input $u_i(t)$.

The impulse response is the inverse Laplace transform of the transfer function $h(t) = \mathcal{L}^{-1}\{H(s)\}.$

For stable continuous time systems the impulse response always converges to 0:

$$\lim_{t\to\infty} h(t) = 0$$
, because $\mathbf{D} = 0$ and $\lim_{t\to\infty} \mathbf{x}(t) = 0$.

The impulse response h(t) of input i to output j is the output $y_j(t)$ of a system when an impulse $\delta(t)$ is applied at input $u_i(t)$.

The impulse response is the inverse Laplace transform of the transfer function $h(t) = \mathcal{L}^{-1}\{H(s)\}.$

For stable continuous time systems the impulse response always converges to 0:

$$\lim_{t\to\infty} h(t)=0, \text{ because } \mathbf{D}=0 \text{ and } \lim_{t\to\infty} \mathbf{x}(t)=0.$$

The speed of convergence depends on the position of the poles.

Time constant

The transfer function of first order systems can be written as:

$$H(s) = \frac{K}{\tau s + 1} \quad \leftrightarrow \quad h(t) = \frac{K}{\tau} e^{-t/\tau},$$

where τ is called the system's **time constant**.

Time constant

The transfer function of first order systems can be written as:


$$H(s) = rac{K}{ au s + 1} \quad \leftrightarrow \quad h(t) = rac{K}{ au} e^{-t/ au},$$

where τ is called the system's **time constant**.


The time constant summarizes the speed of a system's dynamics:

- after τ seconds, the impulse response reaches h(0)/e.
- after au seconds, the step response has reached $1-e^{-1} \approx 63\%$ of its regime value.

Impulse response $H(s) = 5/(5s+1) \leftrightarrow h(t) = exp(-t/5)$



Step response $H(s) = 5/(5s+1) \leftrightarrow h(t) = exp(-t/5)$



Outline

Properties of state-space representation

- Transfer functions
 - Impulse response and time constant
 - Relationship between state space and transfer functions

From state-space to transfer functions

We start from the linear state-space representation:

time domain

$$\begin{cases} \dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t) \\ \mathbf{y}(t) = \mathbf{C}\mathbf{x}(t) + \mathbf{D}\mathbf{u}(t) \end{cases} \leftrightarrow \begin{cases} s\mathbf{X}(s) = \mathbf{A}\mathbf{X}(s) + \mathbf{B}\mathbf{U}(s) \\ \mathbf{Y}(s) = \mathbf{C}\mathbf{X}(s) + \mathbf{D}\mathbf{U}(s) \end{cases}$$

From state-space to transfer functions

We start from the linear state-space representation:

time domain

Laplace domain

$$\begin{cases} \dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t) \\ \mathbf{y}(t) = \mathbf{C}\mathbf{x}(t) + \mathbf{D}\mathbf{u}(t) \end{cases} \leftrightarrow \begin{cases} s\mathbf{X}(s) = \mathbf{A}\mathbf{X}(s) + \mathbf{B}\mathbf{U}(s) \\ \mathbf{Y}(s) = \mathbf{C}\mathbf{X}(s) + \mathbf{D}\mathbf{U}(s) \end{cases}$$

A transfer function $\mathbf{H}(s) = \frac{\mathbf{Y}(s)}{\mathbf{U}(s)}$ relates an input and an output in the Laplace-domain \to to obtain it, we must eliminate $\mathbf{X}(s)$.

From state-space to transfer functions

We start from the linear state-space representation:

time domain

Laplace domain

$$\begin{cases} \dot{\mathbf{x}}(t) = \mathbf{A}\mathbf{x}(t) + \mathbf{B}\mathbf{u}(t) \\ \mathbf{y}(t) = \mathbf{C}\mathbf{x}(t) + \mathbf{D}\mathbf{u}(t) \end{cases} \leftrightarrow \begin{cases} s\mathbf{X}(s) = \mathbf{A}\mathbf{X}(s) + \mathbf{B}\mathbf{U}(s) \\ \mathbf{Y}(s) = \mathbf{C}\mathbf{X}(s) + \mathbf{D}\mathbf{U}(s) \end{cases}$$

A transfer function $\mathbf{H}(s) = \frac{\mathbf{Y}(s)}{\mathbf{U}(s)}$ relates an input and an output in the Laplace-domain \to to obtain it, we must eliminate $\mathbf{X}(s)$.

$$(sI - A)X(s) = BU(s)$$

$$X(s) = (sI - A)^{-1}BU(s)$$

$$\Rightarrow Y(s) = C(sI - A)^{-1}BU(s) + DU(s)$$

$$\Rightarrow H(s) = C(sI - A)^{-1}B + D$$

Poles are zeros of the denominator of $\mathbf{H}(s)$, e.g. those values of s for which $\mathbf{H}(s)$ is singular.

Relationship between poles and eigenvalues of \mathbf{A} 1/2

Poles are zeros of the denominator of $\mathbf{H}(s)$, e.g. those values of s for which $\mathbf{H}(s)$ is singular.

The relationship between state-space representation (matrices A, B, C and D) and transfer functions is given by

$$\mathbf{H}(s) = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + \mathbf{D}$$

Poles are zeros of the denominator of $\mathbf{H}(s)$, e.g. those values of s for which $\mathbf{H}(s)$ is singular.

The relationship between state-space representation (matrices A, B, C and D) and transfer functions is given by

$$\mathbf{H}(s) = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + \mathbf{D}$$

H(s) cannot be computed when $(s\mathbf{I} - \mathbf{A})^{-1}$ does not exist, ie.

$$\det(s\mathbf{I}-\mathbf{A})=0$$

Relationship between poles and eigenvalues of \mathbf{A} 1/2

Poles are zeros of the denominator of $\mathbf{H}(s)$, e.g. those values of s for which $\mathbf{H}(s)$ is singular.

The relationship between state-space representation (matrices $\bf A$, $\bf B$, $\bf C$ and $\bf D$) and transfer functions is given by

$$\mathbf{H}(s) = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + \mathbf{D}$$

H(s) cannot be computed when $(s\mathbf{I} - \mathbf{A})^{-1}$ does not exist, ie.

$$\det(s\mathbf{I}-\mathbf{A})=0$$

The determinant is zero if s is an eigenvalue of \mathbf{A} .

Relationship between poles and eigenvalues of \mathbf{A} 1/2

Poles are zeros of the denominator of $\mathbf{H}(s)$, e.g. those values of s for which $\mathbf{H}(s)$ is singular.

The relationship between state-space representation (matrices A, B, C and D) and transfer functions is given by

$$\mathbf{H}(s) = \mathbf{C}(s\mathbf{I} - \mathbf{A})^{-1}\mathbf{B} + \mathbf{D}$$

H(s) cannot be computed when $(s\mathbf{I} - \mathbf{A})^{-1}$ does not exist, ie.

$$\det(s\mathbf{I}-\mathbf{A})=0$$

The determinant is zero if s is an eigenvalue of A.

 \rightarrow all poles of $\mathbf{H}(s)$ are eigenvalues of \mathbf{A}

Transfer functions only capture what is relevant to describe an input-output relationship, but not all states necessarily contribute.

Transfer functions only capture what is relevant to describe an input-output relationship, but not all states necessarily contribute.

 \rightarrow unobservable modes of **A** are not poles in **H**(s).

Transfer functions only capture what is relevant to describe an input-output relationship, but not all states necessarily contribute.

 \rightarrow unobservable modes of **A** are not poles in **H**(s).

Consider the following SISO system with 2 states:

$$\begin{bmatrix}
sX_1(s) \\
sX_2(s)
\end{bmatrix} = \begin{bmatrix}
\alpha & 0 \\
0.2 & 1
\end{bmatrix} \begin{bmatrix}
X_1(s) \\
X_2(s)
\end{bmatrix} + \begin{bmatrix}
\beta \\
2
\end{bmatrix} U(s)$$

$$Y(s) = \begin{bmatrix} 1 & 0 \end{bmatrix} \begin{bmatrix}
X_1(s) \\
X_2(s)
\end{bmatrix}$$

Transfer functions only capture what is relevant to describe an input-output relationship, but not all states necessarily contribute. \rightarrow *unobservable* modes of **A** are not poles in **H**(s).

Consider the following SISO system with 2 states:

$$\begin{bmatrix}
sX_1(s) \\
sX_2(s)
\end{bmatrix} = \begin{bmatrix}
\alpha & 0 \\
0.2 & 1
\end{bmatrix} \begin{bmatrix}
X_1(s) \\
X_2(s)
\end{bmatrix} + \begin{bmatrix}
\beta \\
2
\end{bmatrix} U(s)$$

$$Y(s) = \begin{bmatrix} 1 & 0 \end{bmatrix} \begin{bmatrix} X_1(s) \\
X_2(s) \end{bmatrix}$$

The transfer function $H(s) = \frac{\beta}{s-\alpha}$ has only one pole $(s_1 = \alpha)$. \rightarrow not all eigenvalues of **A** are poles in transfer functions **H**(s).