Bricks

A LEGO® BRICK MODEL OF

VHS Cassette


A 1:1 VHS tape, within a few millimetres of the real 187 x 103 x 25 mm cassette. Swing the dust flap up to see the tape; watch the reels turn through the windows.

370 pieces · 131 steps · 14 sections

Unofficial fan-made building instructions

Built with real bricks. This model has been built from these instructions, and it works. Every part is a real LEGO element, and the model was also checked on a computer (connections, collisions, every step, balance, mechanism).

Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. VHS Cassette and related names belong to their owners. Made with brickkit · 2026-10-13



Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

Built with real bricks

These steps have been followed with real bricks from start to finish, and the finished model works, moving parts and all. The instructions were corrected from that build. They were also checked on a computer: every part/colour is a real LEGO element, all 962 connections between parts were matched in 3D, no two parts overlap and every part can be pushed into place in its step. Take your time and support the model while you work.

The finished model

About 18.4 × 10.2 cm and 2.6 cm tall, about 306 g (estimated).

Built like a real cassette, from the inside out. First the chassis: the bottom with its drive holes and screw heads, the lamp tube, the reel-lock release, the guide rollers and the tape stretched across the mouth. Two reels drop into their drive holes: the supply reel and the take-up reel. The end walls go on, then the top shell, built upside down with its grip bands, recessed label, spine label and two big windows, is lowered over everything. Last, the full-length dust flap hangs on two Technic pins.

You will need

- The 370 pieces in 5 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips

- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.
- Each reel has a white drive hub underneath, in a square drive hole in the bottom, like a real cassette's. Put a fingertip on its four pegs and turn: the reel turns with it.
- Lower the top shell straight down so the window hangers find their ledges and the reel hubs slide under the windows.
- The write-protect tab on the back is a single tile: pull it off to protect your recording.

The 5 colours

- Black: 319
- White: 34
- Trans-Clear: 10
- Flat Silver: 5
- Red: 2

How to read the steps

Parts and step number

7




2x

The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



1x

A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below


When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction


Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.

Build overview


The model is built in 14 sections. Each is finished before it is used.



1. Chassis
steps 1–47




2. Supply reel (full)
steps 48–52




3. VHS Cassette
steps 53, 59–60, 123, 131




4. Take-up reel
steps 54–58




5. Top shell
steps 61–81, 83, 85, 88–89, 91, 95–99, 105–116, 121–122




6. Top shell: strip 1
step 82




7. Top shell: strip 2
step 84




8. Top shell: strip 3
steps 86–87




9. Top shell: strip 4
step 90



10. Top shell: strip 5
step 92



11. Top shell: strip 6
steps 93–94




12. Face label
steps 100–104







CHASSIS

1




Chassis, bottom layer: the two square gaps are the reel drive holes, the Technic plate's middle hole is the lamp hole; silver screw heads sit flush underneath







From below: the outlined pieces click in here.

2










From below: the outlined piece clicks in here.


3





4






5



2x



6




1x

1x
1 × 3


1x
1 × 6







From below: the outlined pieces click in here.


7







8






9






10






11






12








From below: the outlined piece clicks in here.


13



2x
1 × 3



14




1x

1x
1 × 3

1x






From below: the outlined pieces click in here.


15



1x
1 × 4


1x
1 × 6





From below: the outlined piece clicks in here.

16





1x

1x
1 × 8

1x
1 × 3


4x
1 × 4







From below: the outlined pieces click in here.

17










From below: the outlined piece clicks in here.

18









From below: the outlined pieces click in here.


19



3x
1 × 4


1x
1 × 12






From below: the outlined pieces click in here.


20



1x
1 × 3


1x
1 × 4






From below: the outlined piece clicks in here.

21




1x
1 × 2

1x
2 × 4



22





3x
1 × 4


1x
2 × 4



23










From below: the outlined pieces click in here.


24







25






26










From below: the outlined pieces click in here.

27










From below: the outlined pieces click in here.

28










From below: the outlined pieces click in here.


29







30






31









From below: the outlined pieces click in here.


32







33







34







35







36






37









From below: the outlined pieces click in here.

38





39




1x


1x
1 × 3

1x

The lamp tube: a black 2 x 2 round brick over the lamp hole




40



2x
1 × 6

Ledges the window hangers land on





41



2x 1x

White tape guide rollers at the front corners, a white guide post and the posts the top shell's flap pivots land on






From behind: the outlined pieces.


42




2x




43







44




The tape run: a black 1 x N plate stood on its edge




45



1x
1 × 8



46




1x


1x
1 × 3

1x
1 × 6

Black tiles on it: the tape stretched across the front




47



1x
1 × 3

1x
1 × 6



SUPPLY REEL (FULL)

48



2x
8 × 8


The lower flange and the tape pack: two black 8 x 8 round plates with a hole in the middle, one on the other






From below: the outlined piece clicks in here.

49



The hub: a round plate with an axle hole, and a flat white ring round it



50



Tape wound round the hub




51



4x
4 × 4

Clear upper flange



52





1x




1x

The red spindle and the drive hub: push the axle up through the reel, then a white round plate onto its lower end, studs down. Its four studs are the pegs you turn the reel by from underneath






From below: the outlined piece clicks in here.



From behind and below: the outlined pieces.

VHS CASSETTE

53



Take the chassis and drop the supply reel into the right-hand drive hole: the white drive hub under the reel goes down into the small square between the four tiles






From below: the outlined piece clicks in here.

TAKE-UP REEL

54




The lower flange and the tape pack: two black 8 x 8 round plates with a hole in the middle, one on the other






From below: the outlined piece clicks in here.

55



The hub: a round plate with an axle hole, and a flat white ring round it




56



Just a few turns of tape left on the hub




57




4x
4 × 4

Clear upper flange





58




1x **1x**

The red spindle and the drive hub: push the axle up through the reel, then a white round plate onto its lower end, studs down. Its four studs are the pegs you turn the reel by from underneath





From below: the outlined piece clicks in here.



From behind and below: the outlined pieces.

VHS CASSETTE


59



The take-up reel into the left-hand drive hole




60



End walls




61




2x
1 × 2

1x

Top shell, built upside down: the grip-band grilles and the black rims go face down, then plates on them



62





2x
1 × 2

2x
1 × 4

1x
1 × 12

1x
1 × 6






From below: the outlined pieces click in here.


63



2x
1 × 2


2x
1 × 3





From below: the outlined pieces click in here.


64



1x
1 × 3





2x
1 × 3



65









From below: the outlined pieces click in here.

66








From below: the outlined pieces click in here.

67




1x
1 × 3



68

Top shell



4x
1 × 2


1x
1 × 4

1x
1 × 12



1x
1 × 6





From below: the outlined pieces click in here.


69



1x
1 × 2

1x

1x
1 × 3




70




2x
1 × 2

2x
1 × 3




71



1x
1 × 3


1x
1 × 3




72




2x




1x
1 × 3






From below: the outlined pieces click in here.

73










From below: the outlined piece clicks in here.

74










From below: the outlined pieces click in here.

75










From below: the outlined piece clicks in here.

76








From below: the outlined pieces click in here.


77



1x




78




2x
1 × 2



2x






From below: the outlined pieces click in here.

79




1x
1 × 2

1x




80



2x
1 × 2




2x



81




1x



TOP SHELL: STRIP 1

82





2x
1 × 2



2x

Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down







From below: the outlined pieces click in here.


TOP SHELL

83



A third layer, with the flap's pivot blocks (plates with a pin hole)







From behind and below: the outlined piece.


TOP SHELL: STRIP 2

84



Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down








From below: the outlined pieces click in here.

TOP SHELL

85









From behind and below: the outlined piece.


TOP SHELL: STRIP 3

86




Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down





From below: the outlined pieces click in here.


87




1x
1 × 3

1x
1 × 4

1x
1 × 8






From below: the outlined piece clicks in here.


TOP SHELL


88



1x


1x
1 × 4





From behind: the outlined pieces.


89



2x


1x
1 × 3

1x
1 × 4



TOP SHELL: STRIP 4

90





2x
1 × 2



2x

Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down








From below: the outlined pieces click in here.

TOP SHELL

91









From below: the outlined piece clicks in here.


TOP SHELL: STRIP 5

92




Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down







From below: the outlined pieces click in here.

93




Build this strip apart, the way up it is drawn. Once built, it goes on with the piece that locks it down






From below: the outlined pieces click in here.

94








From below: the outlined piece clicks in here.

TOP SHELL


95




1x




1x




1x
1 × 6






From below: the outlined pieces click in here.


96




1x
1 × 8




1x
1 × 4




97



2x
1 × 6




98




1x


1x
1 × 6



1x
1 × 4




99




1x

1x
1 × 3




FACE LABEL
100

Face label




1x
2 × 3




3x
1 × 10

The face label: black plates running front to back ...




101




1x
1 × 10

1x
2 × 4




102

Face label




3x
1 × 10

1x
2 × 4




Face label


103




2x
2 × 3




104



1x
2 × 4




TOP SHELL
105




1x

The face label panel: it ties the front and back grip bands together




106




1x
1 × 4

1x

Bricks with side studs for the spine label




107



1x
1 × 4

1x




108



1x




109



1x
2 × 4

1x
2 × 6

Spine label: plates stood on edge





110



1x
2 × 4

1x
2 × 3






From behind: the outlined pieces.


111



1x
2 × 6



112



1x
1 × 8



1x
1 × 3


White tiles: the spine label; black tiles at the ends

Top shell

seen from behind




113



seen from behind




114




Top shell

seen from behind



115




seen from behind

The write-protect tab: a tile you can pull off to protect your recording




116




Top shell

seen from behind



WINDOW · BUILD 2X


117




A window: a 2 x 6 plate stood on its edge, studs to the front, and the door frame 1 x 6 x 6 laid flat and pushed onto the plate's top row



118



The glass




119



1x
1 × 6

A tile caps the frame's front studs





120



6x

Six hangers on the plate's back row






From below: the outlined piece clicks in here.



From behind: the outlined pieces.


TOP SHELL

121




1x


The window, hung on its six hangers



122




1x



VHS CASSETTE


123



1x

seen from behind


Lower the top shell onto the chassis



DUST FLAP

124

Dust flap



1x
2 × 3


1x

1x
2 × 16

1x
2 × 6


Dust flap, built flat: one long 2 x 16 plate with a short one at each end, locked together by 2 x N tiles. The tiles' top halves hang over the plates: they are the flap's top row






From below: the outlined pieces click in here.

125




1x
2 × 3

2x
2 × 4



126


Dust flap




1x
2 × 3

1x


1x
2 × 6





From below: the outlined pieces click in here.

127



1x
1 × 4

1x
1 × 6

Bottom row of tiles




128



1x
1 × 4


1x
1 × 3



129



1x
1 × 6



130



2x

Turn it over: a 1 x 2 plate with a pin hole on the back of each end, on two studs, its hole at the flap's top edge. These are the flap's hinges


Dust flap

seen from below





VHS CASSETTE

131




Hold the dust flap in place and push a pin through each hinge






First the outlined pieces: the others go on over them.

It works!



Dust flap

The whole front edge is the flap. It swings up and out 90 degrees on two Technic pins through the hinge plates at its ends, uncovering the tape between two white guide rollers.



Turning reels

Each reel lies loose inside, as in a real cassette, and turns in its drive hole. Turn a drive hub underneath with a fingertip, as a VCR's spindle does, and watch the supply and take-up packs through the clear windows.



Underneath


Two square drive holes, each with a reel's white drive hub in it: four pegs round the red spindle end. Between them the lamp hole; then the reel-lock release hole, five silver screw heads and the open mouth where the VCR's head drum goes in.

Parts inventory

370 pieces in 55 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



2x
300526
Black
BrickLink 3005



2x
300826
Black
BrickLink 3008




1x
306226
Black
BrickLink 3062b



1x
614326
Black
BrickLink 3941



6x
4558954
Black
BrickLink 87087



2x
4162443
Black
BrickLink 30414



2x
6391342
Black
BrickLink 42205



13x
302426
Black
BrickLink 3024



8x
447726
Black
BrickLink 4477



5x
4514845
Black
BrickLink 60479



45x
302326
Black
BrickLink 3023



45x
362326
Black
BrickLink 3623



29x
371026
Black
BrickLink 3710



11x
366626
Black
BrickLink 3666




7x
346026
Black
BrickLink 3460



1x
428226
Black
BrickLink 4282



1x
302226
Black
BrickLink 3022



3x
302126
Black
BrickLink 3021



2x
302026
Black
BrickLink 3020



4x
379526
Black
BrickLink 3795



1x
614126
Black
BrickLink 6141



1x
403226
Black
BrickLink 4032a



4x
6393938
Black
BrickLink 74611



12x
6424674
Black
BrickLink 3386



2x
6192309
Black
BrickLink 18677



2x
6114987
Black
BrickLink 11458



2x
6279875
Black
BrickLink 2780



1x
6280168
Black
BrickLink 32124



1x
370926
Black
BrickLink 3709



9x
307026
Black
BrickLink 3070b



1x
306926
Black
BrickLink 3069



11x
4558170
Black
BrickLink 63864



7x
243126
Black
BrickLink 2431




14x
663626
Black
BrickLink 6636



2x
416226
Black
BrickLink 4162



1x
6162892
Black
BrickLink 26603



10x
4560182
Black
BrickLink 87079



2x
6318582
Black
BrickLink 69729



8x
6434275
Black
BrickLink 79393



38x
241226
Black
BrickLink 2412b

Parts inventory (continued)

370 pieces in 55 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



5x
4633691
Flat Silver
BrickLink 6141



2x
4142865
Red
BrickLink 32062



2x
6511024
Trans-Clear
BrickLink 42509



8x
6544432
Trans-Clear
BrickLink 27507



3x
306201
White
BrickLink 3062b



1x
302301
White
BrickLink 3023



1x
362301
White
BrickLink 3623



3x
614101
White
BrickLink 6141



4x
403201
White
BrickLink 4032a



2x
307001
White
BrickLink 3070b




4x
243101
White
BrickLink 2431




2x
416201
White
BrickLink 4162



8x
6172674
White
BrickLink 27925



3x
6156667
White
BrickLink 26603



3x
4560178
White
BrickLink 87079

About this model

Built like a real cassette, from the inside out. First the chassis: the bottom with its drive holes and screw heads, the lamp tube, the reel-lock release, the guide rollers and the tape stretched across the mouth. Two reels drop into their drive holes: the supply reel and the take-up reel. The end walls go on, then the top shell, built upside down with its grip bands, recessed label, spine label and two big windows, is lowered over everything. Last, the full-length dust flap hangs on two Technic pins.

Checked on a computer

PASS	**real elements**	55 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	962 connections (933 stud, 21 pin, 4 axle, 4 hinge); 3 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 370 parts
PASS	**buildability**	249 insertions tried across 14 submodel(s); 0 problem(s)
PASS	**stability**	about 306 g; centre of mass inside the base (98% margin); tips at 74.7 deg
PASS	**mechanism**	24 poses swept for 3 moving group(s); 0 gear pair(s); 0 problem(s)
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Built with real bricks

The computer checks catch most mistakes a designer can make; a real build caught the rest, and these instructions were corrected from it. If you build it too, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer: **bricks.superfun.games/m/vhs_tape**

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.