Bricks

A LEGO® BRICK MODEL OF

Chainsaw Face

BLOOD-SPATTERED COLOURWAY

A masked, chainsaw-swinging slasher in a butcher's apron, 31 cm (12 in) tall on a floorboard stand, his chainsaw raised high overhead in both fists. Every joint poses, like LEGO's big football figures.

838 pieces · 139 steps · 25 sections

Unofficial fan-made building instructions

Not physically build-tested. Every part is a real LEGO element and the model was checked on a computer (connections, collisions, every step, balance, mechanism), but nobody has built it with real bricks yet.

Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. Chainsaw Face and related names belong to their owners. Made with brickkit · 2026-10-14

Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

Not physically build-tested

The model and these steps were checked on a computer only: every part/colour is a real LEGO element, all 3431 connections between parts were matched in 3D, no two parts overlap, every part can be pushed into place in its step, and the model's balance was estimated; the mechanism was swept through its whole range. Not tested: how firmly parts hold, part tolerances and how it copes with handling. Take your time and support the model while you work.

The finished model

About 18.5 × 11.4 cm and 39.8 cm tall, about 1.0 kg (estimated).

Built from the ground up: the stand with its floorboards and blank nameplate, the shoes on its studs, the legs (ball joints at the ankles and hips, ratchet disks at the knees) and the hips, pinned to the stand's post from behind, with the apron's skirt pressed onto the front. The torso turns on a turntable at the waist and carries the bib, the tie and the shoulder balls; the head is a mask on a ball joint under a shaggy mop of hair. The arms swing on ball-joint shoulders, bend at ratchet elbows and end in fists on ball-joint wrists. Last, the chainsaw's two handles clip into his fists.

You will need

- The 838 pieces in 10 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips

- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.
- The face is a smooth panel of Tan tiles, the mask ready for painting: add its stitches, wrinkles and a snarl with a fine brush or a sticker if you like.
- The elbows and knees are LEGO's big rotation joint disks (44224 + 44225): they click in steps and hold the pose, even with the saw overhead.
- The two long pins from the stand's black post go into the back of the hips, so he stands firm on his shoes' studs whatever you do with his arms.
- To swing the saw, turn both arms together at the shoulders: the fists keep hold of the handles.
- The nameplate at the front of the stand is left blank for your own sticker.

The 10 colours

- Black: 160
- Dark Blue: 154
- White: 144
- Tan: 125
- Dark Brown: 103
- Yellow: 103
- Reddish Brown: 16
- Light Bluish Gray: 15
- Dark Red: 13
- Dark Bluish Gray: 5

How to read the steps

Parts and step number



The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below

When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction

Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.

Build overview

The model is built in 25 sections. Each is finished before it is used.

1. Display stand
steps 1–10

2. Chainsaw Face
steps 11, 16, 34, 52 … 130, 139



3. Shoe ×2
steps 12–15

4. Shin (left)
steps 17–23



5. Left leg
steps 24–26, 33



6. Thigh (left)
steps 27–32



7. Shin (right)
steps 35–41



8. Right leg
steps 42–44, 51



9. Thigh (right)
steps 45–50



10. Hips
steps 53–57, 60



11. Apron (lower part)
steps 58–59



12. Torso
steps 63–73, 76



13. Apron bib
steps 74–75

Build overview (continued)

14. Head
steps 78–85, 89



15. Face (the mask)
steps 86–88



16. Upper arm (left)
steps 91–96



17. Left arm
steps 97–99, 105, 109



18. Forearm (left)
steps 100–104



19. Fist (left)
steps 106–108



20. Upper arm (right)
steps 111–116



21. Right arm
steps 117–119, 125, 129



22. Forearm (right)
steps 120–124



23. Fist (right)
steps 126–128



24. Chainsaw
steps 131–135, 138



25. Guide bar
steps 136–137

1



1x
6 × 16

1x
8 × 16

The base: two layers of black plates, crosswise

2



1x
2 × 4

1x
4 × 12

2x
6 × 14



3



A frame of bricks with ribs under the shoes and the post



4



The deck: plates over the frame



5



The support post: black bricks behind where the figure stands



6





7





8

Technic bricks at the top: the pins into the hips go through their holes



9

seen from below



Floorboards

10

Display stand

seen from below



A black border, and the nameplate raised on a plate: leave it blank for a sticker

CHAINSAW FACE

11



The display stand



SHOE · BUILD 2X

12



The sole

13



2x
2 × 4

2x
2 × 3



14



1x

The ankle socket: a ball socket brick with its socket facing the heel



15



A rounded toe cap; smooth tiles round the ankle



CHAINSAW FACE

16

Shoes on the studs either side

Chainsaw Face

seen from below

SHIN (LEFT)

17



1x
1 × 4

1x
2 × 4

Shin, from the ankle up: a brick with three axle holes



18



2x
2 × 4



19



Technic bricks for the knee joint's pins



20

Shin (left)





21





22

Shin (left)



The knee cap round the disk slot: a brick, two plates and smooth tiles close the gap under the thigh, so the knee disks hide inside



23



seen from below

The ankle ball on a 2L axle, pushed up into the bottom brick



LEFT LEG

24



The shin



25



The knee: the lower disk (turned over) slides down into the shin's slot; push two long pins through the Technic bricks and its beam



26



The upper disk clicks onto it



THIGH (LEFT)

27



Thigh, from the knee up: Technic bricks for the knee joint's pins, a gap for the knee disk



Thigh (left)

28





29



1x
2 × 3

1x
1 × 4

1x
1 × 3

2x



30



2x
2 × 4



31



2x
1 × 4

1x
2 × 4

A brick with three axle holes on top



32

1x

1x

The hip ball on a 2L axle



LEFT LEG

33



Lower the thigh over the upper disk's beam; push two long pins through



CHAINSAW FACE

34



Pop the left leg's ankle ball into its shoe



SHIN (RIGHT)

35



1x
1 × 4

1x
2 × 4

Shin, from the ankle up: a brick with three axle holes



36



2x
2 × 4



37



Technic bricks for the knee joint's pins



38

Shin (right)





39



40

Shin (right)



The knee cap round the disk slot: a brick, two plates and smooth tiles close the gap under the thigh, so the knee disks hide inside



41



seen from below

The ankle ball on a 2L axle, pushed up into the bottom brick



RIGHT LEG

42



The shin



43



The knee: the lower disk (turned over) slides down into the shin's slot; push two long pins through the Technic bricks and its beam



44



The upper disk clicks onto it



THIGH (RIGHT)

45



3x 2x 1x 1 × 3 2x

Thigh, from the knee up: Technic bricks for the knee joint's pins, a gap for the knee disk



Thigh (right)

46



2x 2 × 3 2x 2x 1 × 3 2x 1 × 4



47



1x 2 × 3 **1x** 1 × 4 **1x** 1 × 3 **2x**



48



2x 2 × 4



49



2x
1 × 4

1x
2 × 4

A brick with three axle holes on top



50

1x

1x

The hip ball on a 2L axle



RIGHT LEG

51



Lower the thigh over the upper disk's beam; push two long pins through



CHAINSAW FACE

52



Pop the right leg's ankle ball into its shoe



53



Hips, from the bottom up: the two hip sockets face outwards



54



The second post hole, a course of bricks (room above the balls) and a plate layer to tie them together



55



The front row: bricks with studs on the side hold the apron



56

Hips



The waist: a locking turntable base in the middle



57



Smooth tiles round it, so the torso can turn over them



APRON (LOWER PART)

58

Apron (lower part)



The lower apron, built flat: plates



59





HIPS

60



Press the apron onto the studs at the front of the hips

CHAINSAW FACE

61

1x

Lower the hips onto both hip balls

62



2x

Push two long pins through the post into the back of the hips



63



Torso: a round plate with a pin hole (the turntable's top), a plate layer, bricks with studs on the side at the front (the belly) and a course of bricks

64





65


3x
1x
2 × 4
2x
2 × 8
1x
1 × 8
1x
1 × 8
2x
2 × 4
2x
4 × 8
2x
2x
2x
1 × 8
2x
1 × 8
4x
4x



66


3x
1x
2 × 4
2x
2 × 8
2x
1 × 8
1x
2 × 4
1x
4 × 8
1x
6 × 8
4x
2x
1 × 8
2x
1 × 4
8x



67



Shirt front over the belly bricks' top studs: the tie and the apron's straps



68



The shoulders: Technic bricks for the shoulder axles; bricks with side studs at the front



69



The tie's knot and the straps



70



Axles and balls for the shoulders



71



The neck: a brick with axle holes; the collar round it



72



Round the shoulders off; the apron's straps run over them

73



The neck ball on a 2L axle



APRON BIB

74



The apron's bib, built flat: plates



75





TORSO

76



Press the apron's bib onto the studs on the belly



CHAINSAW FACE

77



1x

The torso on the waist turntable

HEAD

78

Head



3x

2x
2 × 3

2x

1x

1x

Head: the neck socket, a ball socket brick facing back; bricks with side studs for the face



79



80

2x

The ears: round plates on the side studs



Unofficial fan-made building instructions created by a computer, not yet built with real bricks · bricks.superfun.games

81





82

Head





Unofficial fan-made instructions - checked by computer, not yet built with real bricks - bricks.superfun.games

83



2x
4 × 8

The crown: plates of hair a stud wider than the head all round, so the hair overhangs the brow, the sides and the back



84



16x **8x** **4x**
2 × 4

Messy hair: curved slopes falling over the edges all round, a fringe over the brow, and more falling every which way on top



85



seen from below

Hair hanging down the sides and the back: bricks under the crown's overhang



FACE (THE MASK)

86



The mask, built flat: a 6 x 6 plate



87



Tiles, the eyes, the teeth and the nose



88

The heavy brow over the eyes



HEAD
89



1x

Press the face onto the side studs



CHAINSAW FACE
90

1x

The head on the neck ball

91



2x
1 × 3

Upper arm, from the elbow up: the elbow's side cover, 1 x 3 bricks



92

Upper arm (left)



1 x 1 Technic bricks for the elbow's pins, and plates over them (skin, then the sleeve's hem)



93





94





95



The shoulder socket: a ball socket brick facing the body



Upper arm (left)

96



The shoulder cap: plates reaching over the socket, rounded off outwards



LEFT ARM

97



The upper arm



98



The elbow: the upper disk slides up into the upper arm's slot; push two long pins through the Technic bricks and its beam



99



1x

seen from below

The lower disk (turned over) clicks onto it



FOREARM (LEFT)

100

2x

Forearm, built upside down from the elbow end: 1 x 1 Technic bricks





101



seen from below



102



Forearm (left)

seen from below



103

seen from below



1x
2 × 3

2x
1 × 2

1x

1x
1 × 3

1x

1x
1 × 3

The wrist: plates, then tiles round a round plate in the middle



104

seen from below

1x

1x

1x

A round plate with an axle hole on the middle stud, the axle and the wrist ball



LEFT ARM
105



seen from below

Push the forearm up over the lower disk's beam; two long pins through



FIST (LEFT)
106



Fist: a ball socket brick is the palm and wrist



107



A clip plate: the fingers curled round the handle; curved slopes for the knuckles



108



A plate under the palm makes the fist chunkier



LEFT ARM
109



1x

seen from below

Press the fist onto the wrist ball



CHAINSAW FACE
110



1x

The left arm: its socket clicks onto the shoulder ball



UPPER ARM (RIGHT)

111



2x
1 × 3

Upper arm, from the elbow up: the elbow's side cover, 1 x 3 bricks



Upper arm (right)

112



1 x 1 Technic bricks for the elbow's pins, and plates over them (skin, then the sleeve's hem)



113





114





115



The shoulder socket: a ball socket brick facing the body



Upper arm (right)

116



The shoulder cap: plates reaching over the socket, rounded off outwards



RIGHT ARM

117



The upper arm



118



The elbow: the upper disk slides up into the upper arm's slot; push two long pins through the Technic bricks and its beam



119



1x

seen from below

The lower disk (turned over) clicks onto it



FOREARM (RIGHT)

120

2x

Forearm, built upside down from the elbow end: 1 x 1 Technic bricks





121



seen from below



122



Forearm (right)

seen from below



123

seen from below



1x
2 × 3

2x
1 × 2

1x

1x
1 × 3

1x

1x
1 × 3

The wrist: plates, then tiles round a round plate in the middle



124

Forearm (right)

seen from below

1x

1x

1x

A round plate with an axle hole on the middle stud, the axle and the wrist ball



RIGHT ARM
125



seen from below

Push the forearm up over the lower disk's beam; two long pins through



FIST (RIGHT)
126



Fist: a ball socket brick is the palm and wrist



127



A clip plate: the fingers curled round the handle; curved slopes for the knuckles



128



A plate under the palm makes the fist chunkier



RIGHT ARM
129



1x

seen from below

Press the fist onto the wrist ball



CHAINSAW FACE
130



1x

The right arm: its socket clicks onto the shoulder ball



131



Chainsaw engine: bricks with studs on the side will carry the guide bar



132





133





134



The handles: clip plates hold bars out in front and behind



135



Smooth the top



GUIDE BAR

136

Guide bar



The guide bar, built flat: black plates

137



Tiles: a grey cover over the engine end, the bar, and the chain along its top edge

CHAINSAW

138



The guide bar along the left-hand side

Chainsaw

seen from below



CHAINSAW FACE

139



1x

Put the chainsaw in his fists: the handles clip into the fists



It works!

Chainsaw raised

The hero pose: the saw held high overhead, the right fist on the front handle and the left on the rear handle, the bar pointing out to his right, the head thrown back.

Chainsaw lowered

Swing both arms forward and down together at the shoulders and the saw comes down across his hips, still in both fists; turn his waist and drop his head to look at it.

Every joint poses

Ball joints at the neck, shoulders, wrists, hips and ankles; ratchet disks at the elbows and knees; a turntable at the waist.

Parts inventory

838 pieces in 193 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.

2x
6116604
Black
BrickLink 30374

20x
300426
Black
BrickLink 3004



6x
362226
Black
BrickLink 3622



4x
301026
Black
BrickLink 3010



8x
300826
Black
BrickLink 3008

7x
4103587
Black
BrickLink 3003

4x
300226
Black
BrickLink 3002



5x
300126
Black
BrickLink 3001

1x
6037390
Black
BrickLink 3007

4x
6053077
Black
BrickLink 15068

1x
302326
Black
BrickLink 3023

2x
371026
Black
BrickLink 3710

1x
302226
Black
BrickLink 3022

2x
302026
Black
BrickLink 3020

2x
303426
Black
BrickLink 3034

1x
302926
Black
BrickLink 3029

2x
303226
Black
BrickLink 3032

2x
345626
Black
BrickLink 3456

2x
302726
Black
BrickLink 3027

2x
6094066
Black
BrickLink 92438

1x
4515350
Black
BrickLink 60474

4x
6308000
Black
BrickLink 61252

7x
4109810
Black
BrickLink 32062

7x
4286267
Black
BrickLink 53585

6x
370026
Black
BrickLink 3700



2x
6360825
Black
BrickLink 67696

8x
6279875
Black
BrickLink 2780

23x
307026
Black
BrickLink 3070

2x
306926
Black
BrickLink 3069

12x
243126
Black
BrickLink 2431

1x
416226
Black
BrickLink 4162

2x
4560182
Black
BrickLink 87079

2x
6284070
Black
BrickLink 98138

4x
241226
Black
BrickLink 2412b



1x
4517986
Black
BrickLink 61485

8x
4255413
Dark Blue
BrickLink 3005

7x
4249891
Dark Blue
BrickLink 3004



8x
6233955
Dark Blue
BrickLink 3622



17x
4264569
Dark Blue
BrickLink 3010



3x
6277303
Dark Blue
BrickLink 3008

Parts inventory (continued)

838 pieces in 193 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.

5x
6385309
Dark Blue
BrickLink 3002



14x
6275133
Dark Blue
BrickLink 3001



1x
6100239
Dark Blue
BrickLink 2456



4x
6482811
Dark Blue
BrickLink 3007



4x
6384912
Dark Blue
BrickLink 39789



10x
4528981
Dark Blue
BrickLink 3023



10x
4177735
Dark Blue
BrickLink 3623

10x
4502089
Dark Blue
BrickLink 3710



2x
6250216
Dark Blue
BrickLink 3460

2x
6037890
Dark Blue
BrickLink 3022



10x
4530028
Dark Blue
BrickLink 3021

1x
4667595
Dark Blue
BrickLink 3020

1x
6097420
Dark Blue
BrickLink 3795

1x
6200659
Dark Blue
BrickLink 3033

16x
6293318
Dark Blue
BrickLink 6541



2x
6479467
Dark Blue
BrickLink 67696

4x
4631385
Dark Blue
BrickLink 3070

6x
4528488
Dark Blue
BrickLink 3069

2x
6103985
Dark Blue
BrickLink 2431

2x
4507080
Dark Blue
BrickLink 4162

2x
4205004
Dark Blue
BrickLink 3068



1x
4569836
Dark Blue
BrickLink 87079

1x
6326191
Dark Blue
BrickLink 69729

4x
4182751
Dark Bluish Gray
BrickLink 44224



1x
4560184
Dark Bluish Gray
BrickLink 87079

4x
6226437
Dark Brown
BrickLink 3005

27x
6058257
Dark Brown
BrickLink 3004

3x
6092677
Dark Brown
BrickLink 3003



2x
6353072
Dark Brown
BrickLink 3001

16x
6046943
Dark Brown
BrickLink 11477

8x
6047037
Dark Brown
BrickLink 15068

2x
6259071
Dark Brown
BrickLink 54200

2x
6194729
Dark Brown
BrickLink 3024

1x
6058221
Dark Brown
BrickLink 3023

6x
6252667
Dark Brown
BrickLink 3710

1x
6223039
Dark Brown
BrickLink 3666

1x
6494115
Dark Brown
BrickLink 3022

5x
6226792
Dark Brown
BrickLink 3020

3x
4518687
Dark Brown
BrickLink 3795

2x
6447571
Dark Brown
BrickLink 3035

Parts inventory (continued)

838 pieces in 193 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.

8x
6516867
Dark Brown
BrickLink 3070

6x
4566688
Dark Brown
BrickLink 3069

4x
6313874
Dark Brown
BrickLink 2431

1x
6295366
Dark Brown
BrickLink 6636

1x
6447565
Dark Brown
BrickLink 4162



2x
4539090
Dark Red
BrickLink 3069

6x
6284585
Dark Red
BrickLink 98138

5x
6311890
Dark Red
BrickLink 25269

2x
4211815
Light Bluish Gray
BrickLink 4519

2x
4211807
Light Bluish Gray
BrickLink 3673



4x
6332151
Light Bluish Gray
BrickLink 44225

1x
4211415
Light Bluish Gray
BrickLink 3070



3x
4211414
Light Bluish Gray
BrickLink 3069

1x
4558169
Light Bluish Gray
BrickLink 63864

1x
4211549
Light Bluish Gray
BrickLink 6636

1x
6176433
Light Bluish Gray
BrickLink 25269

6x
4211288
Reddish Brown
BrickLink 3070



1x
4211151
Reddish Brown
BrickLink 3069

4x
6100769
Reddish Brown
BrickLink 63864

4x
4211194
Reddish Brown
BrickLink 2431

1x
4585337
Reddish Brown
BrickLink 4162



10x
4162465
Tan
BrickLink 3622



1x
4113916
Tan
BrickLink 3010



4x
4159739
Tan
BrickLink 3002



1x
4181134
Tan
BrickLink 2456

2x
6046922
Tan
BrickLink 11477



3x
4624086
Tan
BrickLink 85984

2x
4579260
Tan
BrickLink 87087

9x
6214334
Tan
BrickLink 22885

6x
4159553
Tan
BrickLink 3024



12x
4113917
Tan
BrickLink 3023

6x
4121921
Tan
BrickLink 3623



5x
4113233
Tan
BrickLink 3710



1x
4124067
Tan
BrickLink 3666

4x
4114084
Tan
BrickLink 3022



6x
4118790
Tan
BrickLink 3021



3x
4114309
Tan
BrickLink 3020



2x
4113993
Tan
BrickLink 3795



1x
4125217
Tan
BrickLink 3958

4x
4161734
Tan
BrickLink 4073

Parts inventory (continued)

838 pieces in 193 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.

2x
4140562
Tan
BrickLink 4032

2x
6313119
Tan
BrickLink 11476

2x
6559236
Tan
BrickLink 53585

12x
4179771
Tan
BrickLink 6541



3x
6559239
Tan
BrickLink 67696



8x
6321305
Tan
BrickLink 32556

5x
4125253
Tan
BrickLink 3070



2x
4114026
Tan
BrickLink 3069

3x
6131896
Tan
BrickLink 63864

1x
4550324
Tan
BrickLink 2431



1x
6175367
Tan
BrickLink 26603

2x
6145570
Tan
BrickLink 25269

2x
300551
White
BrickLink 3005

2x
4613964
White
BrickLink 3004



6x
362201
White
BrickLink 3622



4x
301001
White
BrickLink 3010



4x
300801
White
BrickLink 3008



2x
4103592
White
BrickLink 3003



7x
300101
White
BrickLink 3001



1x
4249698
White
BrickLink 2456



7x
6033776
White
BrickLink 3007

2x
6034044
White
BrickLink 11477

4x
6047220
White
BrickLink 15068

8x
306201
White
BrickLink 3062

8x
4504369
White
BrickLink 54200

2x
4558952
White
BrickLink 87087

1x
6058177
White
BrickLink 11211

3x
6218823
White
BrickLink 22885



1x
6244919
White
BrickLink 39789

3x
302301
White
BrickLink 3023

12x
362301
White
BrickLink 3623

2x
371051
White
BrickLink 3710

7x
346001
White
BrickLink 3460



5x
302001
White
BrickLink 3020



1x
379501
White
BrickLink 3795



6x
303501
White
BrickLink 3035



1x
303651
White
BrickLink 3036

16x
614101
White
BrickLink 4073

4x
654101
White
BrickLink 6541

4x
370001
White
BrickLink 3700

Parts inventory (continued)

838 pieces in 193 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



2x
6360826
White
BrickLink 67696

6x
307001
White
BrickLink 3070

6x
306901
White
BrickLink 3069

1x
243101
White
BrickLink 2431

2x
306801
White
BrickLink 3068



1x
4560178
White
BrickLink 87079

1x
241201
White
BrickLink 2412b

1x
4613966
Yellow
BrickLink 3004



2x
301024
Yellow
BrickLink 3010



1x
300924
Yellow
BrickLink 3009



2x
300824
Yellow
BrickLink 3008



3x
4181143
Yellow
BrickLink 2456

4x
306844
Yellow
BrickLink 3062

13x
6313592
Yellow
BrickLink 22885

1x
302324
Yellow
BrickLink 3023

2x
362324
Yellow
BrickLink 3623



3x
371024
Yellow
BrickLink 3710

2x
366624
Yellow
BrickLink 3666

4x
346024
Yellow
BrickLink 3460

1x
302124
Yellow
BrickLink 3021



2x
302024
Yellow
BrickLink 3020



3x
379524
Yellow
BrickLink 3795



4x
303224
Yellow
BrickLink 3032



2x
6376458
Yellow
BrickLink 3958

8x
614124
Yellow
BrickLink 4073

6x
307024
Yellow
BrickLink 3070



8x
306924
Yellow
BrickLink 3069

3x
4558172
Yellow
BrickLink 63864

12x
243124
Yellow
BrickLink 2431

1x
6388482
Yellow
BrickLink 4162



1x
6388487
Yellow
BrickLink 3068



2x
6388483
Yellow
BrickLink 26603



12x
6388490
Yellow
BrickLink 87079

About this model

Built from the ground up: the stand with its floorboards and blank nameplate, the shoes on its studs, the legs (ball joints at the ankles and hips, ratchet disks at the knees) and the hips, pinned to the stand's post from behind, with the apron's skirt pressed onto the front. The torso turns on a turntable at the waist and carries the bib, the tie and the shoulder balls; the head is a mask on a ball joint under a shaggy mop of hair. The arms swing on ball-joint shoulders, bend at ratchet elbows and end in fists on ball-joint wrists. Last, the chainsaw's two handles clip into his fists.

Checked on a computer

PASS	**real elements**	193 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	3431 connections (3284 stud, 110 pin, 22 axle, 9 ball, 6 clip); 1 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 838 parts
PASS	**buildability**	765 insertions tried across 25 submodel(s); 0 problem(s)
PASS	**stability**	about 1035 g; centre of mass inside the base (88% margin); tips at 16.2 deg
PASS	**mechanism**	24 poses swept for 14 moving group(s); 0 gear pair(s); 0 problem(s)
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Not yet built with real bricks

These checks catch most mistakes a designer can make, but not all: clutch power, part tolerances, how stiff a long axle is and how the model survives handling can only be judged with real bricks. If you build it, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer: **bricks.superfun.games/m/chainsaw_face**

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.