
Bricks

A LEGO® BRICK MODEL OF

BMO

The little living game console, with a face, buttons and arms that swing, in 44 pieces.

44 pieces · 12 steps · 3 sections



Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. BMO and related names belong to their owners.
Made with brickkit · 2026-11-05

Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

Not physically build-tested

The model and these steps were checked on a computer only: every part/colour is a real LEGO element, all 70 connections between parts were matched in 3D, no two parts overlap, every part can be pushed into place in its step, and the model's balance was estimated. Not tested: how firmly parts hold, part tolerances and how it copes with handling. Take your time and support the model while you work.

The finished model

About 4.3 × 2.5 cm and 4.8 cm tall, about 22 g (estimated).

Build the body on its two legs first: a core of small bricks with studs on their sides, and the lid. Then make the buttons and the screen, each a 2 x 3 plate with tiles on, and press them onto the front. The side tiles go on last, and an arm on each side's one stud.

You will need

- The 44 pieces in 9 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips

- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.
- Most of the core's bricks have a stud on one side, and the two at the front corners have studs on two sides. Check each step's picture for which way the studs point.
- Each arm is on a single stud: turn it to make BMO wave.


The 9 colours

- Dark Turquoise: 28
- Light Bluish Gray: 4
- Light Aqua: 4
- White: 3
- Black: 1
- Bright Green: 1
- Yellow: 1
- Medium Azure: 1
- Red: 1

How to read the steps

Parts and step number

7




2x

The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



1x

A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below


When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction


Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.

Build overview


The model is built in 3 sections. Each is finished before it is used.



1. BMO
steps 1–5, 10–12




2. Buttons
steps 6–7




3. Screen
steps 8–9


1




Two feet: a 1 x 3 plate each, front to back, with a round brick on the middle stud for a leg. Join the legs with a 2 x 3 plate, its front row on them




2




A second 2 x 3 plate, then the front row of the core: a grey brick with studs on two sides at each end, studs forward and out, and a teal one between them, stud forward







From behind: the outlined pieces.

3




The back row: a brick with a stud on its side at each end, studs out, and a plain one between. Two more 2 x 3 plates on top






From behind: the outlined pieces.





From behind and below: the outlined pieces.

4



The same six bricks again: the front row with studs forward and out, the back row with studs out






From behind: the outlined pieces.

5




3x
1 × 3

The lid: three 1 x 3 tiles side by side, front to back, each sticking out a stud over the front



BUTTONS

6




1x
1 × 2

1x
2 × 3

1x


The buttons: on a teal 2 x 3 plate, the grille tile along one long row for the slot, and the small green button beside it



7




The other row: the yellow D-pad (a 1 x 1 plate) under the slot's end, the blue triangle (a little slope, its high edge to the slot) and the big red button




SCREEN


8




The screen: on a light green 2 x 3 plate, a round tile with a black dot on each end of one long row for the eyes, each dot towards the other, and a light green tile between them



9




The other row: the round tile with a curved line in the middle, turned so it smiles, and a light green tile either side




BMO


10




Press the buttons onto the lower row of studs on the front, and the screen onto the upper row, under the lid, eyes up




11




His left side: the tile with one stud on the lower front studs, the plain 2 x 2 tile above it, and the 1 x 4 tile up the back. Then an arm on the one stud, thick end down







From below: the outlined pieces click in here.

12




His right side, the same: the tile with one stud on the lower front studs, the plain 2 x 2 tile above it, and the 1 x 4 tile up the back. Then an arm on the one stud, thick end down





From below: the outlined piece clicks in here.



From behind: the outlined pieces.

Parts inventory

44 pieces in 20 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



1x
241226
Black
BrickLink 2412b



1x
6109808
Bright Green
BrickLink 4073



2x
6236772
Dark Turquoise
BrickLink 3005




2x
6249427
Dark Turquoise
BrickLink 11477




2x
6325955
Dark Turquoise
BrickLink 3062




6x
6213781
Dark Turquoise
BrickLink 87087



2x
6546186
Dark Turquoise
BrickLink 3623



5x
6249417
Dark Turquoise
BrickLink 3021



2x
6290269
Dark Turquoise
BrickLink 87580




3x
6213787
Dark Turquoise
BrickLink 63864



2x
6292786
Dark Turquoise
BrickLink 2431



2x
6273853
Dark Turquoise
BrickLink 3068



1x
6426724
Light Aqua
BrickLink 3021



3x
6251846
Light Aqua
BrickLink 3070



4x
6267495
Light Bluish Gray
BrickLink 26604



1x
4619520
Medium Azure
BrickLink 54200



1x
6284574
Red
BrickLink 98138



2x
6384891
White
BrickLink 98138pb265



1x
6433502
White
BrickLink 98138pb364



1x
302424
Yellow
BrickLink 3024

About this model

Build the body on its two legs first: a core of small bricks with studs on their sides, and the lid. Then make the buttons and the screen, each a 2 x 3 plate with tiles on, and press them onto the front. The side tiles go on last, and an arm on each side's one stud.

Checked on a computer

PASS	**real elements**	20 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	70 connections (70 stud); 1 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 44 parts
PASS	**buildability**	42 insertions tried across 3 submodel(s); 0 problem(s)
PASS	**stability**	about 22 g; centre of mass inside the base (97% margin); tips at 22.7 deg
PASS	**mechanism**	no moving parts defined
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Not yet built with real bricks

These checks catch most mistakes a designer can make, but not all: clutch power, part tolerances, how stiff a long axle is and how the model survives handling can only be judged with real bricks. If you build it, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer: **bricks.vhsgarage.com/m/bmo**

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.