Bricks


A LEGO® BRICK MODEL OF

Frankenstein

A flat-topped monster with sleepy eyes and neck bolts, in 17 pieces.

Designed by Agosami Brickworks

17 pieces · 11 steps · 1 sections



Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. Frankenstein and related names belong to their owners. Made with brickkit · 2026-11-05

Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

The model was designed by Agosami Brickworks (https://rebrickable.com/mocs/MOC-215912/). These steps were worked out from it here; they are not the designer's own instructions.

Not physically build-tested

The model and these steps were checked on a computer only: every part/colour is a real LEGO element, all 22 connections between parts were matched in 3D, no two parts overlap, every part can be pushed into place in its step, and the model's balance was estimated. Not tested: how firmly parts hold, part tolerances and how it copes with handling. Take your time and support the model while you work.

The finished model

About 2.6 × 1.6 cm and 4.5 cm tall, about 7 g (estimated).

Frankenstein, small enough to stand on your hand: build up from his black base and legs, give him his grey arms, then set on the big grey head. Add the white neck bolts, his mouth and sleepy eyes, and finish with the brow bar and the flat black top.

You will need

- The 17 pieces in 3 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips

- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.

The 3 colours

- Black: 7
- Light Bluish Gray: 6
- White: 4

How to read the steps

Parts and step number

7



2x

The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



1x

A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below


When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction

Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.


Build overview

The model is built in 1 sections. Each is finished before it is used.




1. Frankenstein
steps 1–11

1



1x

The base: a 2 x 2 tile with two studs along its back edge




2



1x

A 1 x 2 plate on the two studs




3



2x

Two bricks with a side stud, the studs facing out to each side





4



2x

A 1 x 1 plate on each side stud, its stud facing out






From behind: the outlined pieces.

5



2x

A half-round tile on each: the arms




6



1x

The head: a brick with studs on its front and both ends




7




2x

The neck bolts: a round plate on the lower stud at each end




8



1x

A 1 x 2 plate with a stud across the two lower studs in front: the mouth




9



2x

Sleepy eyes on the two upper studs in front




10



1x

A 1 x 2 brick with two studs in front, on top of the head




11



1x
1 × 2

1x
1 × 2

A black tile on top, and the grey brow bar on the two studs in front



Parts inventory

17 pieces in 12 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.




2x
407026
Black
BrickLink 4070



2x
302426
Black
BrickLink 3024



1x
302326
Black
BrickLink 3023



1x
6192346
Black
BrickLink 33909




1x
306926
Black
BrickLink 3069



1x
6015344
Light Bluish Gray
BrickLink 11211




1x
6301870
Light Bluish Gray
BrickLink 67329



1x
6066097
Light Bluish Gray
BrickLink 15573



2x
6250597
Light Bluish Gray
BrickLink 24246



1x
6134378
Light Bluish Gray
BrickLink 99563



2x
614101
White
BrickLink 4073



2x
6434345
White
BrickLink 98138pb366

About this model

Frankenstein, small enough to stand on your hand: build up from his black base and legs, give him his grey arms, then set on the big grey head. Add the white neck bolts, his mouth and sleepy eyes, and finish with the brow bar and the flat black top.

Checked on a computer

PASS	**real elements**	12 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	22 connections (22 stud); 1 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 17 parts
PASS	**buildability**	16 insertions tried across 1 submodel(s); 0 problem(s)
PASS	**stability**	about 7 g; centre of mass inside the base (65% margin); tips at 13.8 deg
PASS	**mechanism**	no moving parts defined
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Not yet built with real bricks

These checks catch most mistakes a designer can make, but not all: clutch power, part tolerances, how stiff a long axle is and how the model survives handling can only be judged with real bricks. If you build it, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer: **bricks.vhsgarage.com/m/frankenstein**

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.