Bricks

A LEGO® BRICK MODEL OF

Hamburger

A life-size cheeseburger in six layers. Build each one, then stack them up: every layer clicks onto the next.

590 pieces · 96 steps · 8 sections



Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. Hamburger and related names belong to their owners. Made with brickkit · 2026-11-05

Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

Not physically build-tested

The model and these steps were checked on a computer only: every part/colour is a real LEGO element, all 1942 connections between parts were matched in 3D, no two parts overlap, every part can be pushed into place in its step, and the model's balance was estimated; the mechanism was swept through its whole range. Not tested: how firmly parts hold, part tolerances and how it copes with handling. Take your time and support the model while you work.

The finished model

About 12.5 × 12.5 cm and 9.6 cm tall, about 533 g (estimated).

A cheeseburger as big as the real thing, about 12.5 cm (5 inches) across and nearly 10 cm tall. You build it the way it is put together: the bottom bun, the patty, the cheese, the lettuce, the tomato and the sesame top bun, each one on its own. Every layer under the top bun has the same 4 x 4 square of studs in the middle of its top, and every layer above the bottom bun has open anti-studs under its middle, so the fillings click on in any order and pull apart again. The buns and the patty are octagons 14 studs across; their four corners are small walls turned to the diagonals, each held by a single stud and wedged between its neighbours. The top bun is a dome: its edge turns over in a quarter-round brick, then leans in through a slope and a ring of curved slopes to a crown of curved slopes with rounded corners. Its sesame seeds are small white tiles in three shapes, closest together on the crown and fewer toward the edge.

You will need

- The 590 pieces in 9 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips

- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.
- The four turned corners of the buns and the patty each sit on one stud over smooth tiles. Press them down gently and line them up with their neighbours before you add anything on top. The top bun has four more, smaller ones in the ring of curved slopes round its crown.
- A curved slope stands on two levels: its low end on one plate, its high end on a plate one higher. In the top bun's ring and crown, put the upper plate on first and press the slope down at both ends.
- The two sesame seeds on the crown's jumper plates each sit on a single stud, so they turn freely. Turn them different ways: seeds on a real bun never line up.
- The cheese's four tips hang on clips, so you can swing them up or down. They hang best over the patty, which dips under each tip; on other layers they rest a little higher.
- To take the burger apart, lift each layer straight up, starting with the top bun. Hold a layer by its middle when you pull it off.

The 9 colours

- Medium Nougat: 272
- Bright Light Orange: 83
- Reddish Brown: 78
- Bright Green: 46
- Tan: 44
- Red: 25
- White: 18
- Dark Brown: 16
- Coral: 8

How to read the steps

Parts and step number

7




2x

The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



1x

A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below


When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction


Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.

Build overview


The model is built in 8 sections. Each is finished before it is used.




1. Bottom bun
steps 1–16




2. Hamburger
steps 17, 33, 45, 54, 60, 96




3. Patty
steps 18–32




4. Cheese
steps 34–42, 44



5. Cheese tip ×4
step 43



6. Lettuce
steps 46–53




7. Tomato
steps 55–59



8. Top bun
steps 61–95


BOTTOM BUN

1




4x

The base: four wedge plates make a 12-stud octagon




2




4x
2 × 4

4x


A floor: plates, with smooth tiles and a pin under each corner (1/4)




3




A floor: plates, with smooth tiles and a pin under each corner (2/4)




4



A floor: plates, with smooth tiles and a pin under each corner (3/4)




5




1x

A floor: plates, with smooth tiles and a pin under each corner (4/4)



6

Bottom bun




2x

2x
1 × 6


2x
1 × 4

2x


The four sides of the crust curve inward (1/3)



7




The four sides of the crust curve inward (2/3)




8


Bottom bun




The four sides of the crust curve inward (3/3)



9




The four corners, turned to the diagonals, each on its pin (1/2)




10




The four corners, turned to the diagonals, each on its pin (2/2)




11




Build up the middle (1/4)




12




Build up the middle (2/4)



13




Build up the middle (3/4)




14


Bottom bun




Build up the middle (4/4)




15




The cut face: pale crumb, studs in the middle (1/2)




16




The cut face: pale crumb, studs in the middle (2/2)




HAMBURGER
17




Set the bottom bun on the table



PATTY
18



The base: a 14-stud octagon (1/2)




19




1x

The base: a 14-stud octagon (2/2)




20


Patty



A floor of plates, with smooth tiles and a pin under each corner (1/5)



21




A floor of plates, with smooth tiles and a pin under each corner (2/5)




22


Patty




A floor of plates, with smooth tiles and a pin under each corner (3/5)



23




A floor of plates, with smooth tiles and a pin under each corner (4/5)




24




A floor of plates, with smooth tiles and a pin under each corner (5/5)




25




The rounded edge on the four sides, low where the cheese droops over it (1/2)




26



The rounded edge on the four sides, low where the cheese droops over it (2/2)




27




Build up the middle (1/2)




28



Build up the middle (2/2)



29




2x
1 × 4


3x
1 × 4

3x
2 × 4

The seared corners, turned to the diagonals, each on its pin (1/2)



30




2x
1 × 4


1x
1 × 4

1x
2 × 4


The seared corners, turned to the diagonals, each on its pin (2/2)




31




The top: grill marks across the meat, studs in the middle (1/2)



32




The top: grill marks across the meat, studs in the middle (2/2)



HAMBURGER

33




Click on the patty




CHEESE

34


Cheese




Lay out the slice (1/3)




35




Lay out the slice (2/3)



36



Lay out the slice (3/3)




37




8x


Four pairs of plates with handles pointing to the tips



38




1x
4 × 4




7x


Tile the slice smooth, studs in the middle (1/5)




39




Tile the slice smooth, studs in the middle (2/5)




40




Tile the slice smooth, studs in the middle (3/5)




41




Tile the slice smooth, studs in the middle (4/5)



42




Tile the slice smooth, studs in the middle (5/5)




CHEESE TIP · BUILD 4X

43




A clip plate and a plate, joined by two triangle tiles




CHEESE

44




Clip on the four tips and let them hang




HAMBURGER

45



1x


Click on the cheese



LETTUCE

46


Lettuce



4x
2 × 4

4x

The leaf: an octagon, cut back between the ruffles on the four sides (1/2)




47



1x

The leaf: an octagon, cut back between the ruffles on the four sides (2/2)




48




8x


A plate under each ruffle, and the middle built up (1/2)



49




A plate under each ruffle, and the middle built up (2/2)



50



Ruffles: leafy rosettes all round the edge (1/2)




51




4x

Ruffles: leafy rosettes all round the edge (2/2)




52




2x
2 × 4

2x
2 × 8


Build up the middle



53




Tiles, and studs in the middle




HAMBURGER

54




Click on the lettuce




TOMATO

55




8x
4 × 4

Two round slices, four quarter plates each




56




1x
4 × 4


The studs in the middle join the slices




57



Skin, flesh and the pale middle (1/3)




58




Skin, flesh and the pale middle (2/3)



59




Skin, flesh and the pale middle (3/3)




HAMBURGER

60




Click on the tomato




TOP BUN

61




4x


The cut face underneath: four wedge plates of pale crumb



62




4x
1 × 2




4x


A floor: plates, with smooth tiles and a pin under each corner (1/4)




63




A floor: plates, with smooth tiles and a pin under each corner (2/4)




64



A floor: plates, with smooth tiles and a pin under each corner (3/4)




65



1x
1 × 4

A floor: plates, with smooth tiles and a pin under each corner (4/4)




66




4x
2 × 4


A plate under each of the four sides, reaching a stud past the floor




67




The four sides: quarter-round bricks outside, a brick and the slope inside (1/4)




68




The four sides: quarter-round bricks outside, a brick and the slope inside (2/4)




69




The four sides: quarter-round bricks outside, a brick and the slope inside (3/4)



70



The four sides: quarter-round bricks outside, a brick and the slope inside (4/4)




71



8x


seen from below

A 1 x 1 plate under each end of the four sides, pressed on from below



72

Top bun




2x
2 × 6


4x
1 × 6

2x
1 × 4


Build up the middle: bricks (1/2)



73




Build up the middle: bricks (2/2)




74


Top bun




The four corners of the rim, turned to the diagonals, each on its pin (1/4)




75




The four corners of the rim, turned to the diagonals, each on its pin (2/4)




76




The four corners of the rim, turned to the diagonals, each on its pin (3/4)



77




The four corners of the rim, turned to the diagonals, each on its pin (4/4)




78

Top bun



A layer of plates across the middle (1/2)




79




1x
2 × 4

A layer of plates across the middle (2/2)



80




1x
2 × 8


3x
1 × 4

4x


The deck: plates, with smooth tiles and a pin where the ring's corners will sit (1/4)




81




The deck: plates, with smooth tiles and a pin where the ring's corners will sit (2/4)




82




The deck: plates, with smooth tiles and a pin where the ring's corners will sit (3/4)




83




The deck: plates, with smooth tiles and a pin where the ring's corners will sit (4/4)



84




The crown's core: two layers of plates, a round plate and a 4 x 4 plate (1/2)




85




The crown's core: two layers of plates, a round plate and a 4 x 4 plate (2/2)




86




The ring's plates: on each side a 2 x 2 with a 1 x 2 on its inner half




87




The ring's corners, turned to the diagonals, each on its pin: a 2 x 3 plate with a 1 x 3 on its inner row




88




The ring: curved slopes on each side, their high ends on the upper plate




89




Curved slopes on the ring's four corners (1/2)



90




Curved slopes on the ring's four corners (2/2)




91




A round plate and a tile in each gap of the ring (1/2)




92



A round plate and a tile in each gap of the ring (2/2)




93



The crown: curved slopes round the 4 x 4 plate, quarter circles on its corners (1/2)




94



The crown: curved slopes round the 4 x 4 plate, quarter circles on its corners (2/2)



95




The middle of the crown: jumper plates and sesame seeds




HAMBURGER

96



Click on the top bun



It works!



Stack it any way

Every layer under the top bun has the same 4 x 4 studs in the middle of its top, and every layer above the bottom bun has open anti-studs under its middle, so the fillings go on in any order. At least sixteen studs hold every joint, so the whole burger can be picked up by its top bun.



Take it apart

Lift the layers off one by one: sesame bun, tomato, lettuce, cheese, patty and bottom bun.

Parts inventory


590 pieces in 98 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.




12x
6345196
Bright Green
BrickLink 15469




13x
6357612
Bright Green
BrickLink 3022




8x
6141590
Bright Green
BrickLink 3020




4x
6399478
Bright Green
BrickLink 3034



1x
4617799
Bright Green
BrickLink 3031



4x
6282120
Bright Green
BrickLink 87079



4x
6471113
Bright Green
BrickLink 6106



4x
6073040
Bright Light Orange
BrickLink 3024



10x
6028736
Bright Light Orange
BrickLink 3023



4x
6073042
Bright Light Orange
BrickLink 3623




2x
6020073
Bright Light Orange
BrickLink 3710



2x
6020074
Bright Light Orange
BrickLink 3666



4x
6192205
Bright Light Orange
BrickLink 3460



1x
6093272
Bright Light Orange
BrickLink 3031



4x
6337271
Bright Light Orange
BrickLink 60470b



8x
6248671
Bright Light Orange
BrickLink 60478




8x
6065504
Bright Light Orange
BrickLink 3070



16x
6099725
Bright Light Orange
BrickLink 63864



4x
6072668
Bright Light Orange
BrickLink 2431



16x
6479470
Bright Light Orange
BrickLink 35787



6x
6250024
Coral
BrickLink 27925



2x
6258405
Coral
BrickLink 14769



8x
6259071
Dark Brown
BrickLink 54200




4x
6167928
Dark Brown
BrickLink 63864




4x
6313874
Dark Brown
BrickLink 2431




2x
4569382
Medium Nougat
BrickLink 3004




10x
6223183
Medium Nougat
BrickLink 3010



4x
6099341
Medium Nougat
BrickLink 3009



2x
6135191
Medium Nougat
BrickLink 3001



2x
6350413
Medium Nougat
BrickLink 2456



20x
6334102
Medium Nougat
BrickLink 37352



14x
6356566
Medium Nougat
BrickLink 11477



19x
6312473
Medium Nougat
BrickLink 15068



4x
6585090
Medium Nougat
BrickLink 5852



21x
6167690
Medium Nougat
BrickLink 54200



11x
6218358
Medium Nougat
BrickLink 85984




8x
6215606
Medium Nougat
BrickLink 3024



8x
6218360
Medium Nougat
BrickLink 3023



4x
4645057
Medium Nougat
BrickLink 3623




24x
6167700
Medium Nougat
BrickLink 3710

Parts inventory (continued)

590 pieces in 98 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



10x
6295464
Medium Nougat
BrickLink 3666



6x
6347603
Medium Nougat
BrickLink 3460




6x
6056383
Medium Nougat
BrickLink 3022




4x
6334099
Medium Nougat
BrickLink 3021



19x
6093494
Medium Nougat
BrickLink 3020



2x
6313600
Medium Nougat
BrickLink 3795



7x
6226644
Medium Nougat
BrickLink 3034




1x
6397823
Medium Nougat
BrickLink 3031




12x
6167641
Medium Nougat
BrickLink 4073



1x
6345302
Medium Nougat
BrickLink 11213



2x
6292154
Medium Nougat
BrickLink 15573



8x
6102994
Medium Nougat
BrickLink 87580



20x
6177146
Medium Nougat
BrickLink 3070




12x
6021997
Medium Nougat
BrickLink 3069



5x
6248536
Medium Nougat
BrickLink 25269




4x
6346548
Medium Nougat
BrickLink 6106



1x
4243814
Red
BrickLink 3031



8x
6297811
Red
BrickLink 30565




4x
4178178
Red
BrickLink 3069



6x
6375825
Red
BrickLink 79393



6x
6458177
Red
BrickLink 27507



8x
6146858
Reddish Brown
BrickLink 15068



4x
4221744
Reddish Brown
BrickLink 3024



4x
4211152
Reddish Brown
BrickLink 3623



2x
4211190
Reddish Brown
BrickLink 3710



4x
4221590
Reddish Brown
BrickLink 3666



4x
4216945
Reddish Brown
BrickLink 3460



2x
4613975
Reddish Brown
BrickLink 3022



2x
4211189
Reddish Brown
BrickLink 3021



4x
4211186
Reddish Brown
BrickLink 3020



4x
4211247
Reddish Brown
BrickLink 3795



2x
4211211
Reddish Brown
BrickLink 3034




1x
4243838
Reddish Brown
BrickLink 3031



4x
4216581
Reddish Brown
BrickLink 4073



5x
4211288
Reddish Brown
BrickLink 3070



3x
4211151
Reddish Brown
BrickLink 3069




7x
6100769
Reddish Brown
BrickLink 63864



8x
4211194
Reddish Brown
BrickLink 2431




2x
4211204
Reddish Brown
BrickLink 6636



2x
4271949
Reddish Brown
BrickLink 3068

Parts inventory (continued)

590 pieces in 98 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.




2x
4579690
Reddish Brown
BrickLink 87079




4x
6357957
Reddish Brown
BrickLink 6106




8x
4159553
Tan
BrickLink 3024




2x
4113917
Tan
BrickLink 3023



2x
4113233
Tan
BrickLink 3710




2x
4124067
Tan
BrickLink 3666




4x
4114324
Tan
BrickLink 3460



6x
4114084
Tan
BrickLink 3022



2x
4113988
Tan
BrickLink 3034




3x
4243824
Tan
BrickLink 3031




4x
4550324
Tan
BrickLink 2431




4x
4157277
Tan
BrickLink 6636



1x
4185177
Tan
BrickLink 3068



2x
6122047
Tan
BrickLink 87079



4x
6036485
Tan
BrickLink 6106



4x
6284572
White
BrickLink 98138



5x
6250591
White
BrickLink 24246



9x
6172366
White
BrickLink 25269

About this model

A cheeseburger as big as the real thing, about 12.5 cm (5 inches) across and nearly 10 cm tall. You build it the way it is put together: the bottom bun, the patty, the cheese, the lettuce, the tomato and the sesame top bun, each one on its own. Every layer under the top bun has the same 4 x 4 square of studs in the middle of its top, and every layer above the bottom bun has open anti-studs under its middle, so the fillings click on in any order and pull apart again. The buns and the patty are octagons 14 studs across; their four corners are small walls turned to the diagonals, each held by a single stud and wedged between its neighbours. The top bun is a dome: its edge turns over in a quarter-round brick, then leans in through a slope and a ring of curved slopes to a crown of curved slopes with rounded corners. Its sesame seeds are small white tiles in three shapes, closest together on the crown and fewer toward the edge.

Checked on a computer

PASS	**real elements**	98 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	1942 connections (1918 stud, 16 pin, 8 clip); 1 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 590 parts
PASS	**buildability**	521 insertions tried across 8 submodel(s); 0 problem(s)
PASS	**stability**	about 533 g; centre of mass inside the base (100% margin); tips at 47.6 deg
PASS	**mechanism**	24 poses swept for 5 moving group(s); 0 gear pair(s); 0 problem(s)
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Not yet built with real bricks

These checks catch most mistakes a designer can make, but not all: clutch power, part tolerances, how stiff a long axle is and how the model survives handling can only be judged with real bricks. If you build it, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer:
bricks.vhsgarage.com/m/hamburger

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.