Bricks

A LEGO® BRICK MODEL OF

Finn the Human

A lanky, posable Finn with his backpack and his golden sword, in 121 pieces.

121 pieces · 45 steps · 10 sections



Not produced, sponsored or endorsed by the LEGO Group. LEGO® is a trademark of the LEGO Group. Finn the Human and related names belong to their owners. Made with brickkit · 2026-11-05

Before you start

An unofficial fan-made manual

This booklet is not a LEGO product. It was generated from the model file by a computer program and checked part by part.

Not physically build-tested

The model and these steps were checked on a computer only: every part/colour is a real LEGO element, all 319 connections between parts were matched in 3D, no two parts overlap, every part can be pushed into place in its step, and the model's balance was estimated. Not tested: how firmly parts hold, part tolerances and how it copes with handling. Take your time and support the model while you work.

The finished model

About 11.3 × 3.8 cm and 19.4 cm tall, about 92 g (estimated).

Finn goes together in sections that you build apart and then join. Start with his hips and shirt, which hold a pin for each leg and each arm. Build the two legs from the shoe up, then the two arms, the backpack, the head with its sideways face, and the sword. Push the legs and arms onto their pins, press the backpack onto his back and the head onto the turntable, and clip the sword into his right hand.

You will need

- The 121 pieces in 12 colours listed at the back, with their LEGO element IDs and BrickLink numbers.
- A brick separator for pieces that sit too deep for a finger.

Tips


- Sort the pieces by colour before you start.
- Build the sections in order: each sub-assembly is finished before it is used.
- New pieces in a step have a yellow outline; earlier pieces are drawn paler.
- His hips and shoulders turn on Technic pins, his elbows on a clip, his forearms on the stud above the elbow, and his head on a turntable. Pose him with his weight over his shoes: he is tall, and his head is the heaviest part of him.
- Two bars run down the inside of each leg, through the holes in the round bricks. Push them all the way down before the shorts go on.

The 12 colours

- Light Nougat: 34
- White: 29
- Black: 20
- Blue: 12
- Medium Azure: 11
- Green: 7
- Lime: 2
- Yellow: 2
- Light Bluish Gray: 1
- Dark Red: 1
- Pearl Gold: 1
- Red: 1

How to read the steps

Parts and step number




The parts for the step and how many of each, then the step number. The parts of a step are drawn at one scale, so a longer one looks longer; a tile or a long plate also has its size in studs under it.

New parts

The parts added in a step have a yellow outline and are drawn in full colour; the parts from earlier steps are drawn paler.

Sub-assemblies



A yellow-framed picture means: put in the sub-assembly you built in its own section. "Build 4x" means you need four of them.

Sections

Each section starts with its name at the top of the page. Sections are built in the order they appear.

Seen from below

When a step adds parts underneath, the picture shows the model from below. A small label says so (and "seen from behind" likewise). A piece the picture cannot show gets a small picture beside it, ringed in yellow, from the side it can be seen from: where it clicks in.

Insert direction

Some parts slide in sideways (axles through bearings, gears onto axles). The picture shows where they end up; push them in along their axle.

Build overview

The model is built in 10 sections. Each is finished before it is used.




1. Finn the Human
steps 1–6, 12, 18, 23 … 42, 45




2. Left leg
steps 7–11




3. Right leg
steps 13–17




4. Right arm
steps 19, 22




5. Forearm
steps 20–21




6. Left arm
steps 24, 26




7. Forearm
step 25



8. Backpack
steps 28–31




9. Head
steps 33–41





10. Sword
steps 43–44

1




The hips: a 2 x 2 plate. On its back studs two Technic bricks, their holes across; on its front studs a 1 x 2 brick






From below: the outlined pieces click in here.





From behind: the outlined pieces.

2




A 2 x 2 plate on top, then the waistband: a 2 x 4 plate. Push a black pin into each Technic brick from the outside






From below: the outlined pieces click in here.




From behind: the outlined pieces.





First the outlined piece: the others go on over it.

3




The shirt: a 1 x 4 brick in front, and two bricks with studs on their sides behind it, studs to the back






From behind: the outlined pieces.


4




A 2 x 4 brick




5




The shoulders: a 2 x 2 brick between two Technic bricks, their holes across. Push a black pin into each from the outside






From behind and below: the outlined pieces.

6




The neck: a round white plate and the turntable's base





LEFT LEG

7




The shoe: a 2 x 4 plate. On it, behind the toe's two studs: a 1 x 2 plate, a 1 x 2 plate with one stud, and a slope for the heel






From below: the outlined piece clicks in here.

8



The toe: a curved slope, its high end on the 1 x 2 plate




9




1x

The sock: a white round brick on the single stud




10


Left leg



2x 7x


The leg: 7 round bricks. Push two long bars down through them, one after the other, into the hole in the shoe's stud: they stiffen the leg






First the outlined pieces: the others go on over them.

11



The leg of his shorts: a 1 x 2 plate pointing forward, a small slope on its front stud and a Technic brick on its back stud, the hole across







From below: the outlined pieces click in here.

FINN THE HUMAN

12




Push his left leg onto the pin under the shorts, standing straight





RIGHT LEG

13




The shoe: a 2 x 4 plate. On it, behind the toe's two studs: a 1 x 2 plate, a 1 x 2 plate with one stud, and a slope for the heel






From below: the outlined piece clicks in here.

14



The toe: a curved slope, its high end on the 1 x 2 plate




15




1x

The sock: a white round brick on the single stud





16



2x 7x


The leg: 7 round bricks. Push two long bars down through them, one after the other, into the hole in the shoe's stud: they stiffen the leg





First the outlined pieces: the others go on over them.

17



The leg of his shorts: a 1 x 2 plate pointing forward, a small slope on its front stud and a Technic brick on its back stud, the hole across







From below: the outlined pieces click in here.

FINN THE HUMAN


18




And his right leg




RIGHT ARM
19




The sleeve: a blue Technic brick, its hole across, with a tile on top. Under it two round bricks, and a round plate with a handle: the upper arm



FOREARM
20



A forearm: push the bar of a clip into the top of a round brick, and add a second round brick under it




21



1x

seen from below

The hand: a plate with a clip on its side. Press one of its studs up into the forearm, the other stud to the front, the clip to the right




RIGHT ARM

22



1x

Clip the forearm onto the handle: the elbow




Right arm

seen from below


FINN THE HUMAN

23




1x

Push his right arm onto the pin in his shoulder, its forearm out to his side




LEFT ARM

24



1x 2x 1x 1x


The sleeve: a blue Technic brick, its hole across, with a tile on top. Under it two round bricks, and a round plate with a handle: the upper arm




FOREARM
25




A forearm: push the bar of a clip into the top of a round brick, and add a second round brick under it



LEFT ARM
26




Clip the forearm onto the handle: the elbow




FINN THE HUMAN

27



1x

And his left arm, waving




BACKPACK

28




2x 1x

The backpack: a 2 x 4 wedge plate, wide edge away from you, and a 1 x 1 plate three studs out from each of its near corners (clear of his arms)




29




1x
2 × 3

2x
3 × 3

Green, on the near studs: a 2 x 3 plate in the middle and a round corner plate each side on the 1 x 1 plates, the round corners towards you and out




30




1x
4 × 8

Lime, on the far studs: a half circle, round side away from you




31



1x
2 × 4


1x
2 × 4

A 2 x 4 curved slope on each colour, their high edges meeting in the middle



FINN THE HUMAN

32




1x


Press the backpack onto the four studs on his back

Finn the Human


seen from behind and below




33




The bottom of the hat: the turntable's top, and a 4 x 6 plate pressed onto its four studs, its middle over them. On the plate a 1 x 6 tile along the front (the face stands on this), a 2 x 6 plate and a 1 x 6 plate






From below: the outlined pieces click in here.


34




Behind where the face will go: two 1 x 4 plates and a brick with four studs on its side, studs forward




35




The face: a 4 x 4 plate standing on its edge, on the four studs. A white tile along its top row and a skin one under it: the forehead



36




The eyes, wide apart: a 1 x 1 plate at each end of the row with a round black tile on it, and a 1 x 2 tile between them






From below: the outlined pieces click in here.


37



seen from below


The mouth: a 1 x 2 plate between two tiles, and the half circle on it, flat edge up







First the outlined piece: the others go on over it.

38




The sides and the back of the hat: a tall 1 x 4 brick each side, a tall panel behind with its wall to the back, and a 1 x 4 plate on each





From behind: the outlined pieces.


39




1x
4 × 6

1x
2 × 6

The top: a 4 x 6 plate, and a 2 x 6 plate across its middle




40



2x

4x

Round it off: a curved slope in the middle of the front and of the back, and a 1 x 2 slope each side of them




41




2x

The ears: a 2 x 2 dome on each end of the 2 x 6 plate, standing a plate deep in the top of the hat




FINN THE HUMAN

42




1x


Press the head onto the turntable




SWORD
43




The sword: a long yellow tile. Under one end a round plate with a bar, the bar pointing away from the blade; next to it a 1 x 3 plate across: the guard



44



A red round plate, the hole in its stud pushed onto the end of the bar: the jewel




FINN THE HUMAN

45

1x

Clip the sword's bar into his right hand from behind, blade up, flat side forward



Parts inventory

121 pieces in 59 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.

4x
6116604
Black
BrickLink 30374



2x
6053077
Black
BrickLink 15068



2x
4548180
Black
BrickLink 85984



2x
302326
Black
BrickLink 3023



2x
302026
Black
BrickLink 3020



2x
6092585
Black
BrickLink 15573



4x
6279875
Black
BrickLink 2780



2x
6284070
Black
BrickLink 98138



1x
4613959
Blue
BrickLink 3004




2x
4504380
Blue
BrickLink 54200



2x
302323
Blue
BrickLink 3023



2x
4613973
Blue
BrickLink 3022




1x
4240375
Blue
BrickLink 3020



4x
4119014
Blue
BrickLink 6541




1x
6532669
Dark Red
BrickLink 1748



1x
6401819
Green
BrickLink 88930




2x
302428
Green
BrickLink 3024



1x
302128
Green
BrickLink 3021



2x
6062166
Green
BrickLink 30357



1x
6100220
Green
BrickLink 51739



1x
4540203
Light Bluish Gray
BrickLink 3679




2x
6492195
Light Nougat
BrickLink 48729b



22x
6546466
Light Nougat
BrickLink 3062



2x
6357797
Light Nougat
BrickLink 3024



1x
6369188
Light Nougat
BrickLink 3023



2x
6573538
Light Nougat
BrickLink 26047



1x
6343511
Light Nougat
BrickLink 11476




2x
6480394
Light Nougat
BrickLink 3070



1x
6330199
Light Nougat
BrickLink 3069




1x
6424071
Light Nougat
BrickLink 2431



1x
6075049
Lime
BrickLink 88930




1x
6133225
Lime
BrickLink 22888



1x
6036238
Medium Azure
BrickLink 3010



1x
4653970
Medium Azure
BrickLink 3003



1x
4625629
Medium Azure
BrickLink 3001



2x
6348142
Medium Azure
BrickLink 11211



2x
6145253
Medium Azure
BrickLink 6541



2x
6322828
Medium Azure
BrickLink 3700



2x
4655243
Medium Azure
BrickLink 3070



1x
6335111
Pearl Gold
BrickLink 32828

Parts inventory (continued)

121 pieces in 59 part/colour lines. Bold: the LEGO element ID (what LEGO Pick a Brick sells); below: the colour and the BrickLink part number.



1x
6223427
Red
BrickLink 85861



2x
6256922
White
BrickLink 49311



2x
6047220
White
BrickLink 15068



2x
306201
White
BrickLink 3062



2x
4216652
White
BrickLink 553




4x
4547489
White
BrickLink 85984



1x
4143254
White
BrickLink 30414




1x
4558208
White
BrickLink 60581



5x
371051
White
BrickLink 3710



1x
366601
White
BrickLink 3666



2x
379501
White
BrickLink 3795



1x
4243812
White
BrickLink 3031



2x
303201
White
BrickLink 3032



1x
403201
White
BrickLink 4032




1x
243101
White
BrickLink 2431



1x
663601
White
BrickLink 6636



1x
368001
White
BrickLink 3680



1x
362324
Yellow
BrickLink 3623



1x
6388482
Yellow
BrickLink 4162

About this model

Finn goes together in sections that you build apart and then join. Start with his hips and shirt, which hold a pin for each leg and each arm. Build the two legs from the shoe up, then the two arms, the backpack, the head with its sideways face, and the sword. Push the legs and arms onto their pins, press the backpack onto his back and the head onto the turntable, and clip the sword into his right hand.

Checked on a computer

PASS	**real elements**	59 part/colour combinations: 0 not real, 0 rare
PASS	**connections**	319 connections (282 stud, 18 bar, 16 pin, 3 clip); 1 separate piece(s)
PASS	**collisions**	0 overlapping pair(s) among 121 parts
PASS	**buildability**	119 insertions tried across 10 submodel(s); 0 problem(s)
PASS	**stability**	about 92 g; centre of mass inside the base (88% margin); tips at 6.6 deg
PASS	**mechanism**	no moving parts defined
PASS	**electrics**	no electrics in this model
PASS	**technique**	0 note(s)

Not yet built with real bricks

These checks catch most mistakes a designer can make, but not all: clutch power, part tolerances, how stiff a long axle is and how the model survives handling can only be judged with real bricks. If you build it, we would love to hear how it went.

Files

3D model (LDraw, opens in BrickLink Studio, LeoCAD and LDCad), parts lists for BrickLink and LEGO Pick a Brick, and an interactive 3D viewer: **bricks.vhsgarage.com/m/finn_the_human**

Trademarks

LEGO® is a trademark of the LEGO Group, which does not sponsor, authorize or endorse this booklet. Other names belong to their owners. Part geometry from the LDraw library (CC BY 4.0); connection data from the LDCad shadow library; element data from Rebrickable.