



The Plant app

Omega Logic on the builder's phone: work orders, every unit and its step, the bench scanner, stock, quality holds. Clean Cell USA.

1. What it is and where it lives

WHAT	ADDRESS	SIGN IN
Plant app	silmarillion.clearskyomega.com/plant/app?org=cleancell.us	work Google account of the workspace
Bench scan station	silmarillion.clearskyomega.com/plant/station.html	a station credential from Work orders, pasted once
Try it first (sample data)	silmarillion.clearskyomega.com/app-sandbox/plant · /app-sandbox/bench	any email

Nothing lives only on the phone. The app reads and writes the same work orders and unit records as the plant board and the office, through the same signed-in endpoints, so a scan at a bench is on every other screen the moment it is saved.

2. Put it on your phone

It is a web app: nothing to download from a store, and every update reaches the phone the next time it is opened. Open the address once from the link the office sends; the app remembers the workspace after that. Sign in with the work Google account that is a member of the workspace.

iPhone or iPad (Safari)

1. Open **Safari** and go to the address above.
2. Sign in.
3. Tap the **Share** button (the square with the arrow, at the bottom of the screen).
4. Scroll the sheet and tap **Add to Home Screen**, then **Add**.
5. Open it from the home screen from now on. It opens full screen as **Omega Logic**, ClearSky's app, with your company's workspace shown inside once you sign in.

Android (Chrome)

1. Open **Chrome** and go to the address above.
2. Sign in.
3. Tap the Chrome menu (three dots) and choose **Install app** or **Add to Home screen**.
4. Confirm. The app appears with your other apps, with its own icon.



3. The five tabs

- **Today:** open work orders, late, with holds, mine; today's scans, units that reached Ready, refusals, test fails; **needs a person** (held, stuck, failed, quiet benches, tap to open); **Scan at a bench.**
- **Work:** every open work order, late first, with All / Mine / Late / Holds / Ready filters. Tap one: stage, target, built %, ready units, holds, next operation, what it is **short of**, every unit with its station and step progress.
- **Scan:** opens the bench screen. Paired once as a **roaming phone**, the builder picks the bench they are at on each scan. Look up any serial from here.
- **Stock:** finished units by product (available, assigned, building) and the parts short for the open work.
- **Quality:** units on hold. Open one to place a hold with the reason, or release it with the disposition. A hold stops every scan on that unit until it is released. Once a unit has shipped, its record shows **After the plant:** where it is now, which site it went to, and a link to its custody passport.

The bench

Scan the unit's serial or its label. The screen shows the steps for this bench with each part and quantity for this unit. Scan a part's label, or tap **Issue**, to take it off stock and onto the unit; a lot number travels with it. A check step gets **Done**. When every step is complete the bench says which bench is next; the next bench refuses the unit while anything here is open. Scans queue when the yard has no signal and send when it returns.

Omega Logic
Clean Cell · Plant ·
demo@cleancell.us

u Sign out

[< Back](#)

CC-26-4419
On hold · due 2026-11-14 · line_1

Built
50%
9 of 18 steps

Ready to ship
3 / 5

On hold
1

Next up
—

Kitting EOL test Ready

Short of

LFP cell 280 Ah
CC-CELL-280 · on hand 500 · on order 1000 **1896 ea · late**

Single-bay enclosure
CC-ENC-1B · on hand 0 · on order 0 **5 ea**

Master BMS
CC-BMS-M · on hand 0 · on order 0 **5 ea**

Today Work Scan Stock Quality

Work order: built %, ready units, holds, what is short, every unit's step

Marco's phone
main · roaming · pick the bench per scan

Rack assembly online unpair

CC418-26-44190
Already at Rack assembly.
nothing changed

Pull the trigger on a unit, or i

CC418-26-44190 · Cabinet
works order wo_1 · 0 of 3 steps done

1 **1 · Fit modules** now

5.2 kWh module
CC-MOD-52
0 / 2 ea

lot (optional) **Issue 2 ea**

CC418-26-44190 · 13:03 Use camera

The bench: this unit's steps and parts, issued on scan




Omega Logic · The Plant app

For the builders: work orders, the bench, every unit. Install it, run the work, one system. ClearSky-OMEGA

4. How it links to the main system

1. The office accepts an order on the desktop; when the deposit is paid it is released and a **work order** exists. It appears on the Plant app's Today and Work tabs.
2. Serials are registered on the desktop plant board. The builders build bench by bench with the scanner, issuing parts as they go. The materials plan nets what was issued; Stock in the Omega Logic app shows what is short.
3. A unit that reaches **Ready** is finished stock. The office assigns it to an order from the Omega Logic app, or the plant built it for one already.
4. The office records the shipment on the desktop. From then on the unit's custody chain starts: in transit, received, assigned to the customer's site, commissioned. The Plant app shows that under **After the plant** on the unit, and the customer sees it on their phone.
5. Every unit's full record — the plant trace, the tests, the scans, the custody chain and the warranty — is one passport on the desktop: silmarillion.clearskyomega.com/logic-custody?org=cleancell.us.

Your apps. Today in the Plant app links to the Omega Logic app and the bench. One account, one record: what you build here is what the office ships and the customer places at a site.



5. If something looks wrong

- **"Open the app once from your office link so it knows your workspace"**: open the address with ?org=cleancell.us once; the app remembers it.
- **The app looks stale**: close it fully and open it again. Updates arrive on the next open; data is never shown from a cache.
- **Offline**: the app says so and shows nothing rather than yesterday's list.
- **Questions**: ClearSky Energy Solutions. The full manual is in the workspace documentation.
- **Nothing loads after sign-in**: your email is not a member of the workspace yet. Contact ClearSky or your administrator.
- **The bench says it is not paired**: a plant administrator creates a Roaming phone credential under Work orders on the desktop; paste the token once on the bench screen.