Advanced Card Systems Ltd.



## **ACR120 Contactless Reader**



Unit 1008, 10th Floor, Hongkong International Trade and Exhibition Centre
1 Trademart Drive, Kowloon Bay, Hong Kong


Tel: +852 2796 7873 Fax: +852 2796 1286 Email: info@acs.com.hk Website: www.acs.com.hk

## Special note to customers:

If you are looking for ACR120 readers for wall mounting applications, please kindly notify the sales representative in advance so that you will receive the ACR120 readers with separate PVC stickers. (You will receive the individual PVC stickers at the same time so that after wall mounting, you can put it back to protect the casing.)



## Dimensions of suggested screws (for wall-mounting)



1. Please make sure that no front sticker is attached to the ACR120 reader front casing.



2. Remove the rubber feet at the back so that you can drive in the screws.



3. Tighten the screws.







Advanced Card Systems Ltd.
Unit 1008, 10th Floor
Hongkong International Trade and Exhibition Centre
1 Trademart Drive, Kowloon Bay, Hong Kong

Tel: +852 2796 787 Website: www.acs.com.hk Fax: +852 2796 1286 Email: info@acs.com.hk 3. Tighten the screws (cont'd).



4. Wall mounting is completed. Place the PVC sticker on the front casing to cover the screw holes.

