BUSTER! BASS 200

BUSTER

FRONT PANEL


CHANNEL 1		
Control Function	Type	Mesa Part#
Input	Jack	618102
EQ Ftsw	Jack	618102
Volume	Pot	581739
	Knob	408010
Treble	Pot	581040
	Knob	408010
Middle	Pot	581737
	Knob	408010
Bass	Pot	581040
	Knob	408010
Master	Pot	581055
	Knob	408010

MISC PARTS			
Control Function	Type	Mesa Part#	
Graphic EQ			
Slider (7)	Pot	588536	
(New Style)	Knob	408550	
**original style knob no longer available			
EQ Select	Switch	607303	
Pilot Light			
	Light	703047	
	Lens	703784	
	Holder	703900	
Standby	Switch	602112	
Power	Switch	602112	

REAR PANEL

MISC PARTS		
Control Function	Type	Mesa Part#
Fuse Holder		
Domestic	Cap/Holder	790347
	Fuse	790625
Export	Cap/Holder	790346
	Fuse	795300
AC Receptacle	Jack	613713
FX Loop		
Mix	Pot	518055
	Knob	408010
Send	Jack	618112
Return	Jack	618112
Ground/Lift	Switch	607101
Pin 1 Ground	Switch	607101
Balanced Out	Jack	614028
Speaker Outs (4)	Jack	618112

BASS 200 "BUSTER" BLOCK DIAGRAM



BUSTER

PUR SUPPLIES

