
CRIB SHEET

TEMPO



TEMPO: the pads, row 0 at the top

KEY MOVES


Tap TMP in time	tap tempo (from the 2nd tap)
Hold TMP	overlay, while held
Hold TMP + row 7	±1 / ±5 / ±10, ½×, 2×
Hold TMP + row 9	jump to a preset BPM
Hold TMP + hold row 11	nudge ±4 % while held
Left side buttons	tempo up / down (hold repeats)

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

SEQ



SEQ: the pads, row 0 at the top

KEY MOVES

Tap empty step	on, velocity = pressure
Tap lit step	off
Hold lit step + rows 8-11	edit it (several at once)
Row 14 VIEW hold + tap	copy a page of steps
GEN / MUT (row 15)	new pattern / mutate
Hold CLR 0.5 s	clear all (UNDO restores)
PLY	start / stop

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

SOUND



SOUND: the pads, row 0 at the top

KEY MOVES


Row 0 x0-6	pick the voice
Row 0 x8-10	SOURCE / SHAPE / MOD
Tap a row	set that parameter
– / + (x14, x15)	fine step, hold repeats
AUD (x12)	hear it, pressure = velocity
NEW / MUT (x13, x14)	new or mutated sound
LCK (x15)	keep it through new kits

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

GEN



GEN: the pads, row 0 at the top

KEY MOVES


Row 0	style, then GEN or MUT
Rows 1-2	density, complexity
Row 3 / 4	lock a track / new rhythm for one
Row 6	kit character
Row 12 NEW KIT	a brand-new kit
Row 9	lock sounds you like
UND (row 15)	back to the last kit or pattern

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

MIX



MIX: the pads, row 0 at the top

KEY MOVES


Row 0 / 1	mute / solo (master: limiter)	**Row 11**	pan L / R, both = centre
Rows 2-9	fader: 115 100 90 78 65 50 30 off	**Rows 12 / 13**	delay / reverb send – +
Row 10	fine level – +	**Pads 14-15**	the master strip

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

FX



SPACE bank. COLOUR: rows 1-5 drive, 6-7 ring mod, 8-13 compressor, 14 bits | sample rate.

KEY MOVES


Row 0 x8 / x9	SPACE / COLOUR bank
Row 0 x11	FX ENGINE: CLATTER 12 or PLINKY
Hold x12 / x13	freeze delay / reverb
SPACE rows 1-5	delay: time, fdbk, filter, wet, ping
SPACE rows 7-10	reverb: size, decay, damp, wet
COLOUR row 0	route tracks to drive/ring/comp
MIX rows 12-13	how much each track sends

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

PERFORM



PERFORM: the pads, row 0 at the top

KEY MOVES


Hold any pad	it lasts while held
LAT, then tap	it stays on; tap again to end
REL	let go of everything latched
Hold CMT 0.5 s	write it into the pattern
Tap a scene	recall at the next bar
Hold a scene 1 s	store the mixer and FX
UND	undo a COMMIT

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15

CRIB SHEET

REPEAT



REPEAT: the pads, row 0 at the top

KEY MOVES

Hold a track (rows 0-2)	note repeat, harder = louder
Row 4	rate: straight, triplet, dotted
Row 5 x0-3	what pressure does
Row 7	tap a roll on the target
Hold row 9	beat repeat 1 bar … 1/32T
Row 10	shape and which tracks repeat
LAT	a tap keeps it going

ALWAYS

Row 15: pages 0-7 · TMP 8 · UND 12 · RED 13 · STP 14 · PLY 15