

# **Maintenance Checksheets**

DC Controls. Unit 6, Tallaght Business Centre, Tallaght Dublin 24. 01-4416651 www.dccontrols.ie

**Project: Holiday Inn Express** 

Date: 08/09/2023

Contact: Joe 0851148122

**Engineers: Dean Hayden & Jordan Finlay** 



Project: Holiday Inn Express Date: 08/09/2023

Controller Type/Num: Trend IQ4E Base Controller						
Point Type	Point Number	Description	Units			
ΑI	1	Outside Air Temperature	°C			
ΑI	2	AHU-01 Supply Duct Temperature	°C			
		AHU-01 Supply Air Setpoint	°C			
ΑI	3	AHU-02 Pre-Electric Heater Temperature	°C			
ΑI	4	AHU-02 Supply Duct Temperature	°C			
		AHU-02 Supply Air Setpoint	°C			
ΑI	5	AHU-02 Extract Air Temperature	°C			
ΑI	6	HWS Calorifier Tank Temperature	°C			
ΑI	7	HWS Calorifier Tank Return Temperature	°C			
		DHW Flow Setpoint				
DI	8	DIM4 No.1	On/Off			
DI	9	DIM4 No.2	On/Off			
UI	10	Spare	-			
AVO	11	IO-RMA#1	0-10V			
AV0	12	IO-RM2#1	0-10V			
AVO	13	AHU-01 Electric Heater Battery 3 Modulating Ctrl	0-10V			
AVO	14	IO-RMA#2	0-10V			
AVO	15	AHU-02 Electric Heater Battery Modulating Ctrl	0-10V			
AVO	16	IO-RMA#3	0-10V			

Sta	tus	
Operating Correctly	Faulty	
Yes		
-		
Yes		

		Engineers: Dean Hayden & Jord	aan Finiay
Make	Model	Notes	Engineer
Make	Model		
Trend	TB/TO	7.71'C	DH/JF
Trend	TB/TI-S	19.3'C	DH/JF
		18'C	DH/JF
Trend	TB/TI-S	21'C	DH/JF
Trend	TB/TI-S	22.4'C	DH/JF
		18'C	DH/JF
Trend	TB/TI-S	26'C	DH/JF
Trend	TB/TI-S	66'C	DH/JF
Trend	TB/TI-S	60.15'C	DH/JF
		59'C	DH/JF
Sontay	IO-DIM4		DH/JF
Sontay	IO-DIM4		DH/JF
			DH/JF
Sontay	IO-RMA		DH/JF
Sontay	IO-RM2		DH/JF
			DH/JF
Sontay	IO-RMA		DH/JF
			DH/JF
Sontay	IO-RMA		DH/JF



Project: Holiday Inn Express Date: 08/09/2023

Cont	ontroller Type/Num: Trend 16DI		Status		1	Make	Model	Notes	Engine	
Point Type	Point Number	Description	Units	Operating Correctly	Faulty		Make	Model		
DI	1	Fire Alarm	On/Off	Yes		1 1				DH/JF
DI	2	Gas Dectection Alarm	On/Off	Yes		1 1				DH/JF
DI	3	AHU-01 Supply Fan Airflow Switch	On/Off	Yes		1 1				DH/JF
DI	4	AHU-01 Electric Heater Battery High Limit	On/Off	Yes		1 i				DH/JF
DI	5	AHU-02 Supply Fan Airflow Switch	On/Off	Yes		1 i				DH/JF
DI	6	AHU-02 Electric Heater High Limit	On/Off	Yes		1 I				DH/JF
DI	7	AHU-02 Extract Fan Airflow Switch	On/Off	Yes						DH/JF
DI	8	EF-05 Kitchen Extract CT Switch	On/Off	Yes						DH/JF
DI	9	EF-05 Kitchen Extract CT Switch	On/Off	Yes						DH/JF
DI	10	Mains Water Meter Pulse signal	On/Off	Yes		1 1				DH/JF
DI	11	Main Gas Meter Pulse signal	On/Off	Yes		1 1				DH/JF
DI	12	DHW Cold Feed to Hotel Water Meter signal	On/Off	Yes		1 1				DH/JF
DI	13	CWS Consumption Water Meter signal	On/Off	Yes		1 i				DH/JF
DI	14	BCWS to Kitchens Water Meter signal	On/Off	Yes						DH/JF
DI	15	DHW to Kitchens Water Meter signal	On/Off	Yes						DH/JF
DI	16	DHW Return to Kitchens Water Meter signal	On/Off	Yes						DH/JF



			DC Controls.	Unit 6, Ta	llaght B	usin	ness Centre, Talla	ght Dublin 24.	. 01-4416651 www.dccontrols.ie	
Pro	ect: I	Holiday Inn Express						-	<u> </u>	08/09/2023
Con	Contact: Joe 0851148122 Engineers: Dean Hayden & Jordan Finlay									
Con	trolle	r Type/Num: RMA#1		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI		AHU-01 Supply Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		DH/JF
Con	trolle	r Type/Num: RMA#2			tus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI	1	AHU-02 Supply Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		DH/JF
Con	trolle	r Type/Num: RMA#3		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI	1	AHU-02 Extract Fan Enable & Speed signal	On/Off	Yes			Sontay	IO-RMA		DH/JF
Con	trolle	r Type/Num: RM2#1		Sta	itus		Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty					
DI		AHU-01 Electric Heater Batteries 1 Enable	On/Off	Yes			Sontay	IO-RM2		DH/JF
DI	2	AHU-01 Electric Heater Batteries 2 Enable	On/Off	Yes		]	Sontay	IO-RM2		DH/JF



Project: Holiday Inn Express

Date: 08/09/2023

Contact: Joe 0851148122

Engineers: Dean Hayden & Jordan Finlay

Cont	Controller Type/Num: DIM4#1			Sta	atus	Make	Model	Notes	Engineer
Point Type	Point Number	Description	Units	Operating Correctly	Faulty				
DI	1	AHU-01 Panel Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		DH/JF
DI	2	AHU-01 Bag Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		DH/JF
DI	3	AHU-02 Supply Panel Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		DH/JF
DI	4	AHU-02 Supply Bag Filter D.P Switch	On/Off	Yes		Kromschroder	CPS 330		DH/JF
Cont		r Type/Num: DIM4#2		Sta	atus	Make	Model	Notes	Engineer
Con Point Type		Type/Num: DIM4#2  Description	Units	Operating Correctly	atus Faulty	Make	Model	Notes	Engineer
	Point Number		Units On/Off	Operating		Make	Model	Notes	Engineer  DH/JF
Point Type	Point Number	Description		Operating Correctly		Make	Model	Notes	
Point Type 🗖	Point Number	Description  Cold Water Booster Fault	On/Off	Operating Correctly Se		Make	Model	Notes	DH/JF

#### Notes:

- 1. HWS return pump cover missing off of pump and live cables are exposed. Type; Grundfoss 32-120 F B.- By others.
- 2. ELE Meter 11-20 is reading the same as ELE Meter 21-30 See quote.
- 3. A number of switches were found in hand on the MCC door, Tested and working in auto. Switches were for Gas Fired Heater 1-5- Note.
- 4. Mains water meter is reading 0 for Hourly, Monthly and yearly on BMS See quote.
- 5. BMS IP: 10.1.0.11 Note.
- 6. BMS web Login: Username: InTouch Engineer Password: 4232 Note.



Project: Holiday Inn Express Date: 08/09/2023

Description	Units	Operating Correctly	Faulty	Notes	Engineer
AHU 1	On/Off	Yes		On	DH/JF
AHU 1 Bag Filter	On/Off	Yes		Off	DH/JF
AHU 1 Electric Heater H/L	On/Off	Yes		On	DH/JF
AHU 1 Panel Filter	On/Off	Yes		Off	DH/JF
AHU 1 Speed	Hz	Yes		50Hz	DH/JF
AHU 1 Supply Air Setpoint	°C	Yes		18.0°C	DH/JF
AHU 1 Supply Temperature	°C	Yes		21°C	DH/JF
AHU 1 Supply Fan Airflow	On/Off	Yes		OFF	DH/JF
AHU 2	On/Off	Yes		On	DH/JF
AHU 2 Bag Filter	On/Off	Yes		Off	DH/JF
AHU 2 Electric Heater H/L	On/Off	Yes		On	DH/JF
AHU 2 Extract Fan Airflow	On/Off	Yes		On	DH/JF
AHU 2 Extract Fan Speed	Hz	Yes		50Hz	DH/JF
AHU 2 Extract Temperature	°C	Yes		26°C	DH/JF
AHU 2 Heating Output	%	Yes		0%	DH/JF
AHU 2 Panel Filter	On/Off	Yes		Off	DH/JF
AHU 2 Pre-Heater Temperature	°C	Yes		22.5°C	DH/JF
AHU 2 Speed	Hz	Yes		50Hz	DH/JF
AHU 2 Supply Air Setpoint	°C	Yes		18.0°C	DH/JF
AHU 2 Supply Fan Airflow	On/Off	Yes		On	DH/JF
AHU 2 Supply Temperature	°C	Yes		23°C	DH/JF
AHU 2 Thermal Wheel	%	Yes		0.00%	DH/JF
AHU 2 Speed Control	%	Yes		0.00%	DH/JF
AHU 1 Heating Battery 1&2 Enable	%	Yes		0.00%	DH/JF
AHU 1 Heating Battery 3	%	Yes		0.00%	DH/JF
AHU 1 Supply Fan Enable & Speed	%	Yes		100.00%	DH/JF
AHU 1 Supply Fan Airflow Fail	On/Off	NO		ON	DH/JF
AHU 2 Extract Fan Enable & Speed	%	Yes		100.00%	DH/JF
AHU 2 Extract Fan Airflow Fail	On/Off	Yes		Off	DH/JF
AHU 2 Heating Element	%	Yes		0.00%	DH/JF
AHU 2 Supply Fan Enable & Speed	%	Yes	1	100%	DH/JF
AHU 2 Supply Fan Airflow Fail	On/Off	Yes		Off	DH/JF
BCWS To Kitchen Meter This Year	Ltrs	Yes	1	20776.6 Ltrs	DH/JF
BCWS To Kitchen Meter This Month	Ltrs	Yes		613.5 Ltrs	DH/JF
BCWS To Kitchen Meter Daily	Ltrs	Yes		38.2 Ltrs	DH/JF
BCWS To Kitchen Meter Hourly	Ltrs	Yes		7.6Ltrs	DH/JF
BCWS To Kitchen Water Meter	On/Off	Yes		Off	DH/JF
Cold Water Booster Fault	On/Off	Yes		On	DH/JF
CWS Consumption Daily	m3	Yes		11.3 m3	DH/JF
CWS Consumption Hourly	m3	Yes		2.16m3	DH/JF
CWS Consumption This Year	m3	Yes		6422.6 m3	DH/JF
CWS Consumption Monthly	m3	Yes		203.03 m3	DH/JF
CWS Consumption Water Meter	On/Off	Yes		Off	DH/JF
CWS Tank 1 High Level	On/Off	Yes		Off	DH/JF
CWS Tank 1 Low Level	On/Off	Yes		Off	DH/JF
CWS Tank 2 High Level	On/Off	Yes		Off	DH/JF

CMC Torals 2 Lave Lavel	0/0ff	Vaa	0# 0#/15
CWS Tank 2 Low Level	On/Off	Yes	Off DH/JF
DHW Cold To Hotel Meter	On/Off	Yes	Off DH/JF
DHW Cold To Hotel Monthly	Ltrs	Yes	5.1 Ltrs DH/JF
DHW Cold To Hotel Monthly	Ltrs	Yes	68.88 Ltrs DH/JF
DHW Cold To Hotel Yearly	Ltrs	Yes	2199.15 Ltrs DH/JF
DHW Flow Setpoint	°C	Yes	59.0°C DH/JF
DHW Hot Return	On/Off	Yes	On DH/JF
DHW Hot Return Fail	On/Off	Yes	Off DH/JF
DHW Return To Kitchen Meter	On/Off	Yes	Off DH/JF
DHW Return To Kitchen Meter Hourly	Ltrs	Yes	0 Ltrs DH/JF
DHW Return To Kitchen Meter Monthly	Ltrs	Yes	100 Ltrs DH/JF
DHW Return To Kitchen Meter Yearly	Ltrs	Yes	600 Ltrs DH/JF
DHW Return To Kitchen Meter Daily	Ltrs	Yes	0 Ltrs DH/JF
DHW To Kitchen Meter Daily	Ltrs	Yes	0 Ltrs DH/JF
DHW To Kitchen Meter Hourly	Ltrs	Yes	0 Ltrs DH/JF
DHW To Kitchen Meter Yearly	Ltrs	Yes	10100 Ltrs DH/JF
DHW To Kitchen Meter Monthly	Ltrs	Yes	100 Ltrs DH/JF
DHW To Kitchen Meter	On/Off	Yes	Off DH/JF
DIM4 Multiplexer No.1		Yes	8.35 DH/JF
DIM4 Multiplexer No.2		Yes	120.58 DH/JF
EF 01 Enable	On/Off	Yes	On DH/JF
EF 01 GF Area	On/Off	Yes	On DH/JF
EF 01 Kitchen Extract A/F	On/Off	Yes	On DH/JF
EF 02 Enable	On/Off	Yes	On DH/JF
EF 02 GF Toilet Extract	On/Off	Yes	On DH/JF
EF 02 Kitchen Extract A/F	On/Off	Yes	On DH/JF
EF 03 Bedrooms Enable	On/Off	Yes	On DH/JF
EF 03 Enable Speed	%	Yes	75.00% DH/JF
EF 03 Supply Fan Airflow Fail	On/Off	Yes	Off DH/JF
EF 03 Twin Fan Airflow	On/Off	Yes	On DH/JF
EF 03 Twin Fan Speed Signal	%	Yes	75.00% DH/JF
EF 04 Bedrooms Enable	On/Off	Yes	On DH/JF
EF 04 Enable Speed	%	Yes	63.00% DH/JF
EF 04 Supply Fan Airflow Fail	On/Off	Yes	Off DH/JF
EF 04 Twin Fan Airflow	On/Off	Yes	On DH/JF
EF 04 Twin Fan Speed Signal	%	Yes	63.00% DH/JF
EF 05 Enable	On/Off	Yes	On DH/JF
EF 05 Supply Fan Airflow Fail	On/Off	Yes	Off DH/JF
EF 05 Twin Fan Airflow	On/Off	Yes	On DH/JF
EF 06 Enable	On/Off	Yes	On DH/JF
EF 06 Linen Room Fail	On/Off	Yes	Off DH/JF
EF 06 Twin Fan Airflow	On/Off	Yes	On DH/JF
EF 07 Enable			<del>                                     </del>
EF 07 Etrable EF 07 Extract Plant Room Fail	On/Off On/Off	Yes	
	· · · · · · · · · · · · · · · · · · ·	Yes	Off DH/JF
EF 07 Twin Fan Airflow	On/Off	Yes	On DH/JF
EF 01 & 02 Enable Signal	%	Yes	100.00% DH/JF
ELE Meter 1 kWh	kWh	Yes	1742531 Kwh DH/JF
ELE Meter 2 kWh	kWh	Yes	366592 kwh DH/JF
ELE Meter 3 kWh	kWh	Yes	91340.8 kwh DH/JF
ELE Meter 4 kWh	kWh	Yes	366592 kwh DH/JF
ELE Meter 5 kWh	kWh	Yes	0 kwh DH/JF
ELE Meter 6 kWh	kWh	Yes	218112 kwh DH/JF
ELE Meter 7 kWh	kWh	Yes	108032 kwh DH/JF
ELE Meter 8 kWh	kWh	Yes	230400 kwh DH/JF
ELE Meter 9 kWh	kWh	Yes	276070.4 kwh DH/JF
ELE Meter 10 kWh	kWh	Yes	93184 Kwh DH/JF

CLC Makes 11 LM/b	LAA/In	Vaa	O lavele	DII/IE
ELE Meter 11 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 12 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 13 kWh	kWh	Yes	11366.4 kwh	DH/JF
ELE Meter 14 kWh	kWh	Yes	493158.4 kwh	DH/JF
ELE Meter 15 kWh	kWh	Yes	109568 kwh	DH/JF
ELE Meter 16 kWh	kWh	Yes	118784 kwh	DH/JF
ELE Meter 17 kWh	kWh	Yes	104448 kwh	DH/JF
ELE Meter 18 kWh	kWh	Yes	103424 kwh	DH/JF
ELE Meter 19 kWh	kWh	Yes	110080 kwh	DH/JF
ELE Meter 20 kWh	kWh	Yes	128512 kwh	DH/JF
ELE Meter 21 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 22 kWh	kWh	Yes	0 kwh	DH/JF
ELE Meter 23 kWh	kWh	Yes	11366.4 kwh	DH/JF
ELE Meter 24 kWh	kWh	Yes	493158.4 kwh	DH/JF
ELE Meter 25 kWh	kWh	Yes	109568 kwh	DH/JF
ELE Meter 26 kWh	kWh	Yes	118784 kwh	DH/JF
ELE Meter 27 kWh	kWh	Yes	104448 kwh	DH/JF
ELE Meter 28 kWh	kWh	Yes	103424 kwh	DH/JF
ELE Meter 29 kWh	kWh	Yes	110080 kwh	DH/JF
ELE Meter 30 kWh	kWh	Yes	128512 kwh	DH/JF
EF 01 Fail	On/Off	Yes	Off	DH/JF
EF 02 Fail	On/Off	Yes	Off	DH/JF
Fire Alarm	On/Off	Yes	On	DH/JF
Gas Detection	On/Off	Yes	On	DH/JF
Gas Fired Heater 1	On/Off	Yes	On	DH/JF
Gas Fired Heater 2	On/Off	Yes	On	DH/JF
Gas Fired Heater 3	On/Off	Yes	On	DH/JF
Gas Fired Heater 4	On/Off	Yes	OFF	DH/JF
Gas Fired Heater 5	On/Off	Yes	OFF	DH/JF
Gas Fire Water 1 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 2 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 3 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 4 Fault	On/Off	Yes	Off	DH/JF
Gas Fire Water 5 Fault	On/Off	Yes	Off	DH/JF
Gas Heater Rotate	On/Off	Yes	Off	DH/JF
Gas Meter Usage Daily	m3	Yes	1.2 m3	DH/JF
Gas Meter Usage Monthly	m3	Yes	4.4 m3	DH/JF
Gas Meter Usage Hourly	m3	Yes	0 m3	DH/JF
Gas Meter Usage Yearly	m3	Yes	365.9 m3	DH/JF
Hot Return Spare	1113	163	40	DH/JF
Hot Water Return CT	On/Off	Yes	On	DH/JF
HWS Calorifier Return Temperature	°C	Yes	58.9°C	DH/JF
HWS Calorifier Temperature	°C	Yes	62.4°C	DH/JF
Kitchen DHW Daily	Ltrs	Yes	0 Ltrs	DH/JF
· · · · · · · · · · · · · · · · · · ·	<b>4</b>			
Kitchen DHW Hourly	Ltrs	Yes	0 Ltrs	DH/JF
Kitchen DHW Monthly	Ltrs	Yes	0 Ltrs	DH/JF
Kitchen DHW Yearly	Ltrs	Yes	9500 Ltrs	DH/JF
Main Incomer Daily	kWh	Yes	283.25 kW	DH/JF
Main Incomer Energy	kW	Yes	29 kW	DH/JF
Mains Water Meter Daily Usage	m3	Yes	0 m3	DH/JF
Mains Water Meter Hourly Usage	m3/h	Yes	0 m3/h	DH/JF
Mains Water Meter Hourly Usage	Ltrs/h	Yes	0.5 Ltrs/h	DH/JF
Mains Water Meter Monthly Usage	m3	Yes	0 m3	DH/JF
Mains Water Meter Yearly Usage	m3	Yes	0 m3	DH/JF
Mains Water Meter Usage	m3hh	Yes	0 m3	DH/JF
Min.Number Of Water Heaters		Yes	3	DH/JF

	Yes			
°C	Yes			
On/Off	Yes			
	On/Off	°C         Yes           On/Off         Yes	°C         Yes           On/Off         Yes	°C         Yes           On/Off         Yes

3	DH/JF
36°C	DH/JF
On	DH/JF
On	DH/JF
On	DH/JF
Off	DH/JF
Off	DH/JF
Off	DH/JF
On	DH/JF
On	DH/JF
Off	DH/JF



Project: Holiday Inn Express Date: 08/09/2023

Timeclocks	Hours
AHU 1	Mon-Fri 08:00-18:00,Sat & Sun Off
AHU 2	Mon-Fri 08:00-18:00,Sat & Sun Off
Domestic Hot Water	On 24/7
EF 01 Ground Floor Area	Mon-Fri & Sun 06:00-24:00, Sat 05:00-24:00
EF 02 Toilet Extract	Mon-Sun 05:00-22:00
EF 03 Bedrooms	Mon-Sun 08:00-19:00
EF 04 Bedrooms	Mon-Sun 08:00-19:00
EF 05 Kitchen Extract	Mon-Sun 05:00-23:00
EF 06 Basement Area	Mon-Sun 05:00-24:00
Plantroom Fans(SF01 + EF07)	On 24/7



# **Maintenance Recommendations & Costs**

DC Controls. Unit 6, Tallaght Business Centre, Tallaght Dublin 24. 01-4416651 www.dccontrols.ie

Project: Holiday Inn Express Recommendations Date: 08/09/2023

No.	<b>Description</b>
1	HWS return pump - Cover is missing off of the pump and live cables are exposed. Type; Grundfoss 32-120 F B (noted from previous visit) - By others.
2	Electricity meters - Electricity 11 to 20 is reading the same as the electricity meters 21 to 30. Further investigation required. Trend laptop needed to access program See quote.
3	Switches - A number of switches were found in hand on the MCC door. Spoke to Joe and he asked for them back in auto. Tested and working in auto. Switches were for gas fired heater 1-5 - Note.
4	Mains water meters - Meter is reading 0 for hourly, monthly and yearly. Further investigation required - See quote.
5	ELE meters 5, 11, 12, 21, 22 have readings of 0 kwh - See quote.
6	New boilers and calorifires installed recently. (Not tied into BMS, possibly be tied in future) - Note.
7	Plantroom supply fan needs to be on 24/7 as it has control over the gas supply. If turned off the gas supply knocks off - Note.
8	Calorifires only have main header flow and return sensors installed - Note
9	OAT is reading 30'C, sensor is facing East. Extract fan close enough to sensor. Recommend moving to North facing wall for accurate readings - See quote.
10	Cold water booster set - Preassure stat not mounted onto pipework - By others.
11	BMS IP - 10.1.0.11 - Note.
12	BMS web login - Username: InTouch Engineer/Password: 4232 - Note.