3x Intel RealSense

USB 3.1

Robot Control Box

IP: 192.168.0.10

Ethernet

Ethernet

Ethernet

Client

IP: 192.168.0.7

Router

Server

IP: 192.168.0.138