Extra-points 2 survival guide

CAN BUS == 2 wires



3 mm flat screwdriver to lock the wires in the CAN connector





Board1 - CAN1 ←→ Board2 - CAN1

