

# EFM32 Tiny Gecko 11 Family Reference Manual



The EFM32 Tiny Gecko MCUs are the world's most energy-friendly microcontrollers, featuring new connectivity interfaces and user interface features.


EFM32TG11 includes a powerful 32-bit ARM® Cortex®-M0+ and provides robust security via a unique cryptographic hardware engine supporting AES, ECC, SHA, and True Random Number Generator (TRNG). New features include a CAN bus controller, highly robust capacitive sensing, and LESENSE/PCNT enhancements for smart energy meters. These features, combined with ultra-low current active mode and short wake-up time from energy-saving modes, make EFM32TG11 microcontrollers well suited for any battery-powered application, as well as other systems requiring high performance and low-energy consumption.

Example applications:

- Smart energy meters
- Industrial and factory automation
- Home automation and security
- Entry-level wearables
- Personal medical devices
- IoT devices

## ENERGY FRIENDLY FEATURES

- ARM Cortex-M0+ at 48 MHz
- Ultra low energy operation
- CAN 2.0 Bus Controller
- Low energy analog peripherals: ADC, DAC, OPAMP, Comparator, Segment LCD
- Hardware cryptographic engine supports AES, ECC, SHA, and TRNG
- Robust capacitive touch sense
- Footprint compatible with select EFM32 packages
- 5 V tolerant I/O



Lowest power mode with peripheral operational:

EM0 - Active

EM1 - Sleep

EM2 – Deep Sleep

EM3 - Stop

EM4H - Hibernate

EM4S - Shutoff

# Table of Contents

<b>1. About This Document</b>	<b>29</b>
1.1 Introduction	.29
1.2 Conventions	.29
1.3 Related Documentation	.30
<b>2. System Overview</b>	<b>31</b>
2.1 Introduction	.31
2.2 Features	.31
2.3 Block Diagram	.33
2.4 Energy Modes	.34
2.5 Timers	.35
<b>3. System Processor</b>	<b>36</b>
3.1 Introduction	.36
3.2 Features	.37
3.3 Functional Description	.37
3.3.1 Interrupt Operation	.38
3.3.2 Interrupt Request Lines (IRQ)	.39
<b>4. Memory and Bus System</b>	<b>40</b>
4.1 Introduction	.40
4.2 Functional Description	.41
4.2.1 Peripheral Non-Word Access Behavior	.42
4.2.2 Peripheral Bit Set and Clear	.43
4.2.3 Peripherals	.44
4.2.4 Bus Matrix	.45
4.3 Access to Low Energy Peripherals (Asynchronous Registers)	.48
4.3.1 Writing	.49
4.3.2 Reading	.51
4.3.3 FREEZE Register	.51
4.4 Flash	.51
4.5 SRAM	.52
4.6 DI Page Entry Map	.53
4.7 DI Page Entry Description	.55
4.7.1 CAL - CRC of DI-page and calibration temperature	.55
4.7.2 CUSTOMINFO - Custom information	.55
4.7.3 MEMINFO - Flash page size and misc. chip information	.56
4.7.4 UNIQUEL - Low 32 bits of device unique number	.57
4.7.5 UNIQUEH - High 32 bits of device unique number	.57
4.7.6 MSIZE - Flash and SRAM Memory size in kB	.57
4.7.7 PART - Part description	.58
4.7.8 DEVINFOREV - Device information page revision	.60

4.7.9	EMUTEMP - EMU Temperature Calibration Information	. . . . .	60
4.7.10	ADC0CAL0 - ADC0 calibration register 0	. . . . .	61
4.7.11	ADC0CAL1 - ADC0 calibration register 1	. . . . .	62
4.7.12	ADC0CAL2 - ADC0 calibration register 2	. . . . .	63
4.7.13	ADC0CAL3 - ADC0 calibration register 3	. . . . .	63
4.7.14	HFRCOCAL0 - HFRCO Calibration Register (4 MHz)	. . . . .	64
4.7.15	HFRCOCAL3 - HFRCO Calibration Register (7 MHz)	. . . . .	65
4.7.16	HFRCOCAL6 - HFRCO Calibration Register (13 MHz)	. . . . .	66
4.7.17	HFRCOCAL7 - HFRCO Calibration Register (16 MHz)	. . . . .	67
4.7.18	HFRCOCAL8 - HFRCO Calibration Register (19 MHz)	. . . . .	68
4.7.19	HFRCOCAL10 - HFRCO Calibration Register (26 MHz)	. . . . .	69
4.7.20	HFRCOCAL11 - HFRCO Calibration Register (32 MHz)	. . . . .	70
4.7.21	HFRCOCAL12 - HFRCO Calibration Register (38 MHz)	. . . . .	71
4.7.22	HFRCOCAL13 - HFRCO Calibration Register (48 MHz)	. . . . .	72
4.7.23	AUXHFRCOCAL0 - AUXHFRCO Calibration Register (4 MHz)	. . . . .	73
4.7.24	AUXHFRCOCAL3 - AUXHFRCO Calibration Register (7 MHz)	. . . . .	74
4.7.25	AUXHFRCOCAL6 - AUXHFRCO Calibration Register (13 MHz)	. . . . .	75
4.7.26	AUXHFRCOCAL7 - AUXHFRCO Calibration Register (16 MHz)	. . . . .	76
4.7.27	AUXHFRCOCAL8 - AUXHFRCO Calibration Register (19 MHz)	. . . . .	77
4.7.28	AUXHFRCOCAL10 - AUXHFRCO Calibration Register (26 MHz)	. . . . .	78
4.7.29	AUXHFRCOCAL11 - AUXHFRCO Calibration Register (32 MHz)	. . . . .	79
4.7.30	AUXHFRCOCAL12 - AUXHFRCO Calibration Register (38 MHz)	. . . . .	80
4.7.31	AUXHFRCOCAL13 - AUXHFRCO Calibration Register (48 MHz)	. . . . .	81
4.7.32	VMONCAL0 - VMON Calibration Register 0	. . . . .	82
4.7.33	VMONCAL1 - VMON Calibration Register 1	. . . . .	83
4.7.34	VMONCAL2 - VMON Calibration Register 2	. . . . .	84
4.7.35	DCDCLNVCTRL0 - DCDC Low-noise VREF Trim Register 0	. . . . .	85
4.7.36	DCDCLPVCTRL0 - DCDC Low-power VREF Trim Register 0	. . . . .	85
4.7.37	DCDCLPVCTRL1 - DCDC Low-power VREF Trim Register 1	. . . . .	86
4.7.38	DCDCLPVCTRL2 - DCDC Low-power VREF Trim Register 2	. . . . .	87
4.7.39	DCDCLPVCTRL3 - DCDC Low-power VREF Trim Register 3	. . . . .	88
4.7.40	DCDCLPCMPHYSEL0 - DCDC LPCMPHYSEL Trim Register 0	. . . . .	88
4.7.41	DCDCLPCMPHYSEL1 - DCDC LPCMPHYSEL Trim Register 1	. . . . .	89
4.7.42	VDAC0MAINCAL - VDAC0 Cals for Main Path	. . . . .	90
4.7.43	VDAC0ALTCAL - VDAC0 Cals for Alternate Path	. . . . .	91
4.7.44	VDAC0CH1CAL - VDAC0 CH1 Error Cal	. . . . .	92
4.7.45	OPA0CAL0 - OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=1	. . . . .	93
4.7.46	OPA0CAL1 - OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=1	. . . . .	94
4.7.47	OPA0CAL2 - OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=1	. . . . .	95
4.7.48	OPA0CAL3 - OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=1	. . . . .	96
4.7.49	OPA0CAL4 - OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=0	. . . . .	97
4.7.50	OPA0CAL5 - OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=0	. . . . .	98
4.7.51	OPA0CAL6 - OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=0	. . . . .	99
4.7.52	OPA0CAL7 - OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=0	. . . . .	100
4.7.53	OPA1CAL0 - OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=1	. . . . .	101
4.7.54	OPA1CAL1 - OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=1	. . . . .	102
4.7.55	OPA1CAL2 - OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=1	. . . . .	103
4.7.56	OPA1CAL3 - OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=1	. . . . .	104

4.7.57	OPA1CAL4 - OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=0	. . . . .	105
4.7.58	OPA1CAL5 - OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=0	. . . . .	106
4.7.59	OPA1CAL6 - OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=0	. . . . .	107
4.7.60	OPA1CAL7 - OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=0	. . . . .	108
4.7.61	OPA2CAL0 - OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=1	. . . . .	109
4.7.62	OPA2CAL1 - OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=1	. . . . .	110
4.7.63	OPA2CAL2 - OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=1	. . . . .	111
4.7.64	OPA2CAL3 - OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=1	. . . . .	112
4.7.65	OPA2CAL4 - OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=0	. . . . .	113
4.7.66	OPA2CAL5 - OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=0	. . . . .	114
4.7.67	OPA2CAL6 - OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=0	. . . . .	115
4.7.68	OPA2CAL7 - OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=0	. . . . .	116
4.7.69	OPA3CAL0 - OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=1	. . . . .	117
4.7.70	OPA3CAL1 - OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=1	. . . . .	118
4.7.71	OPA3CAL2 - OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=1	. . . . .	119
4.7.72	OPA3CAL3 - OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=1	. . . . .	120
4.7.73	OPA3CAL4 - OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=0	. . . . .	121
4.7.74	OPA3CAL5 - OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=0	. . . . .	122
4.7.75	OPA3CAL6 - OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=0	. . . . .	123
4.7.76	OPA3CAL7 - OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=0	. . . . .	124
4.7.77	CSENGAINCAL - Cap Sense Gain Adjustment	. . . . .	125
<b>5.</b>	<b>DBG - Debug Interface</b>	. . . . .	<b>126</b>
5.1	Introduction	. . . . .	126
5.2	Features	. . . . .	126
5.3	Functional Description	. . . . .	126
5.3.1	Debug Pins	. . . . .	127
5.3.2	Debug and EM2 DeepSleep/EM3 Stop	. . . . .	127
5.3.3	Authentication Access Point	. . . . .	127
5.3.4	Debug Lock	. . . . .	128
5.3.5	AAP Lock	. . . . .	128
5.3.6	Debugger Reads of Actionable Registers	. . . . .	129
5.3.7	Debug Recovery	. . . . .	129
5.4	Register Map	. . . . .	129
5.5	Register Description	. . . . .	130
5.5.1	AAP_CMD - Command Register	. . . . .	130
5.5.2	AAP_CMDKEY - Command Key Register	. . . . .	130
5.5.3	AAP_STATUS - Status Register	. . . . .	131
5.5.4	AAP_CTRL - Control Register	. . . . .	131
5.5.5	AAP_CRCCMD - CRC Command Register	. . . . .	132
5.5.6	AAP_CRCSTATUS - CRC Status Register	. . . . .	132
5.5.7	AAP_CRCADDR - CRC Address Register	. . . . .	133
5.5.8	AAP_CRCRESULT - CRC Result Register	. . . . .	133
5.5.9	AAP_IDR - AAP Identification Register	. . . . .	134
<b>6.</b>	<b>MSC - Memory System Controller</b>	. . . . .	<b>135</b>
6.1	Introduction	. . . . .	135

6.2 Features . . . . .	136
6.3 Functional Description . . . . .	137
6.3.1 User Data (UD) Page Description . . . . .	137
6.3.2 Lock Bits (LB) Page Description . . . . .	138
6.3.3 Device Information (DI) Page . . . . .	138
6.3.4 Bootloader . . . . .	139
6.3.5 Post-reset Behavior . . . . .	139
6.3.6 Flash Startup . . . . .	139
6.3.7 Wait-states . . . . .	139
6.3.8 Instruction Cache. . . . .	141
6.3.9 Low Voltage Flash Read . . . . .	142
6.3.10 Erase and Write Operations. . . . .	142
6.4 Register Map . . . . .	143
6.5 Register Description . . . . .	144
6.5.1 MSC_CTRL - Memory System Control Register . . . . .	144
6.5.2 MSC_READCTRL - Read Control Register . . . . .	145
6.5.3 MSC_WRITECTRL - Write Control Register . . . . .	146
6.5.4 MSC_WRITECMD - Write Command Register . . . . .	147
6.5.5 MSC_ADDRB - Page Erase/Write Address Buffer . . . . .	148
6.5.6 MSC_WDATA - Write Data Register . . . . .	148
6.5.7 MSC_STATUS - Status Register . . . . .	149
6.5.8 MSC_IF - Interrupt Flag Register . . . . .	150
6.5.9 MSC_IFS - Interrupt Flag Set Register . . . . .	151
6.5.10 MSC_IFC - Interrupt Flag Clear Register . . . . .	152
6.5.11 MSC_IEN - Interrupt Enable Register . . . . .	153
6.5.12 MSC_LOCK - Configuration Lock Register . . . . .	154
6.5.13 MSC_CACHECMD - Flash Cache Command Register . . . . .	155
6.5.14 MSC_CACHEHITS - Cache Hits Performance Counter . . . . .	155
6.5.15 MSC_CACHEMISSES - Cache Misses Performance Counter . . . . .	156
6.5.16 MSC_MASSLOCK - Mass Erase Lock Register . . . . .	157
6.5.17 MSC_IRQLATENCY - Irq Latency Register . . . . .	158
6.5.18 MSC_STARTUP - Startup Control . . . . .	159
6.5.19 MSC_CMD - Command Register . . . . .	160
6.5.20 MSC_BOOTLOADERCTRL - Bootloader Read and Write Enable, Write Once Register . . . . .	160
6.5.21 MSC_AAPUNLOCKCMD - Software Unlock AAP Command Register . . . . .	161
6.5.22 MSC_CACHECONFIG0 - Cache Configuration Register 0 . . . . .	162
<b>7. LDMA - Linked DMA Controller. . . . .</b>	<b>163</b>
7.1 Introduction . . . . .	163
7.1.1 Features . . . . .	164
7.2 Block Diagram . . . . .	165
7.3 Functional Description . . . . .	166
7.3.1 Channel Descriptor . . . . .	166
7.3.2 Channel Configuration . . . . .	171
7.3.3 Channel Select Configuration . . . . .	171
7.3.4 Starting a Transfer . . . . .	171
7.3.5 Managing Transfer Errors . . . . .	172

7.3.6 Arbitration . . . . .	172
7.3.7 Channel Descriptor Data Structure . . . . .	174
7.3.8 Interaction With the EMU . . . . .	178
7.3.9 Interrupts . . . . .	178
7.3.10 Debugging . . . . .	178
<b>7.4 Examples . . . . .</b>	<b>178</b>
7.4.1 Single Direct Register DMA Transfer . . . . .	179
7.4.2 Descriptor Linked List . . . . .	180
7.4.3 Single Descriptor Looped Transfer . . . . .	182
7.4.4 Descriptor List With Looping . . . . .	183
7.4.5 Simple Inter-Channel Synchronization. . . . .	184
7.4.6 2D Copy. . . . .	186
7.4.7 Ping-Pong . . . . .	188
7.4.8 Scatter-Gather . . . . .	189
<b>7.5 Register Map . . . . .</b>	<b>190</b>
<b>7.6 Register Description . . . . .</b>	<b>191</b>
7.6.1 LDMA_CTRL - DMA Control Register . . . . .	191
7.6.2 LDMA_STATUS - DMA Status Register . . . . .	192
7.6.3 LDMA_SYNC - DMA Synchronization Trigger Register (Single-Cycle RMW) . . . . .	193
7.6.4 LDMA_CHEN - DMA Channel Enable Register (Single-Cycle RMW) . . . . .	193
7.6.5 LDMA_CHBUSY - DMA Channel Busy Register . . . . .	194
7.6.6 LDMA_CHDONE - DMA Channel Linking Done Register (Single-Cycle RMW) . . . . .	194
7.6.7 LDMA_DBGHALT - DMA Channel Debug Halt Register . . . . .	195
7.6.8 LDMA_SWREQ - DMA Channel Software Transfer Request Register . . . . .	195
7.6.9 LDMA_REQDIS - DMA Channel Request Disable Register . . . . .	196
7.6.10 LDMA_REQPEND - DMA Channel Requests Pending Register . . . . .	196
7.6.11 LDMA_LINKLOAD - DMA Channel Link Load Register . . . . .	197
7.6.12 LDMA_REQCLEAR - DMA Channel Request Clear Register . . . . .	197
7.6.13 LDMA_IF - Interrupt Flag Register . . . . .	198
7.6.14 LDMA_IFS - Interrupt Flag Set Register . . . . .	198
7.6.15 LDMA_IFC - Interrupt Flag Clear Register . . . . .	199
7.6.16 LDMA_IEN - Interrupt Enable Register . . . . .	199
7.6.17 LDMA_CHx_REQSEL - Channel Peripheral Request Select Register . . . . .	200
7.6.18 LDMA_CHx_CFG - Channel Configuration Register . . . . .	204
7.6.19 LDMA_CHx_LOOP - Channel Loop Counter Register . . . . .	205
7.6.20 LDMA_CHx_CTRL - Channel Descriptor Control Word Register . . . . .	206
7.6.21 LDMA_CHx_SRC - Channel Descriptor Source Data Address Register . . . . .	209
7.6.22 LDMA_CHx_DST - Channel Descriptor Destination Data Address Register . . . . .	209
7.6.23 LDMA_CHx_LINK - Channel Descriptor Link Structure Address Register . . . . .	210
<b>8. RMU - Reset Management Unit . . . . .</b>	<b>211</b>
8.1 Introduction . . . . .	211
8.2 Features . . . . .	211
8.3 Functional Description . . . . .	212
8.3.1 Reset Levels . . . . .	213
8.3.2 RMU_RSTCAUSE Register . . . . .	214
8.3.3 Power-On Reset (POR) . . . . .	215

8.3.4	Brown-Out Detector (BOD)	215
8.3.5	RESETn Pin Reset	216
8.3.6	Watchdog Reset	216
8.3.7	Lockup Reset	216
8.3.8	System Reset Request	216
8.3.9	Reset State	216
8.3.10	Register Reset Signals	216
8.4	Register Map	218
8.5	Register Description	219
8.5.1	RMU_CTRL - Control Register	219
8.5.2	RMU_RSTCAUSE - Reset Cause Register	221
8.5.3	RMU_CMD - Command Register	222
8.5.4	RMU_RST - Reset Control Register	222
8.5.5	RMU_LOCK - Configuration Lock Register	223
<b>9.</b>	<b>EMU - Energy Management Unit</b>	<b>224</b>
9.1	Introduction	224
9.2	Features	225
9.3	Functional Description	226
9.3.1	Energy Modes	227
9.3.2	Entering Low Energy Modes	231
9.3.3	Exiting a Low Energy Mode	233
9.3.4	Power Configurations	234
9.3.5	DC-to-DC Interface	238
9.3.6	Analog Peripheral Power Selection	239
9.3.7	Digital LDO Power Selection	240
9.3.8	IOVDD Connection	240
9.3.9	Voltage Scaling	240
9.3.10	EM2/EM3 Peripheral Retention Disable	242
9.3.11	Brown Out Detector (BOD)	242
9.3.12	Voltage Monitor (VMON)	243
9.3.13	Powering Off SRAM Blocks	244
9.3.14	Temperature Sensor	245
9.3.15	Registers latched in EM4	245
9.3.16	Register Resets	245
9.3.17	Backup Power Domain	246
9.4	Register Map	249
9.5	Register Description	251
9.5.1	EMU_CTRL - Control Register	251
9.5.2	EMU_STATUS - Status Register	253
9.5.3	EMU_LOCK - Configuration Lock Register	255
9.5.4	EMU_RAM0CTRL - Memory Control Register	256
9.5.5	EMU_CMD - Command Register	257
9.5.6	EMU_EM4CTRL - EM4 Control Register	258
9.5.7	EMU_TEMPLIMITS - Temperature Limits for Interrupt Generation	259
9.5.8	EMU_TEMP - Value of Last Temperature Measurement	259
9.5.9	EMU_IF - Interrupt Flag Register	260

9.5.10	EMU_IFS - Interrupt Flag Set Register . . . . .	262
9.5.11	EMU_IFC - Interrupt Flag Clear Register . . . . .	264
9.5.12	EMU_IEN - Interrupt Enable Register . . . . .	267
9.5.13	EMU_PWRLOCK - Regulator and Supply Lock Register . . . . .	269
9.5.14	EMU_PWRCTRL - Power Control Register . . . . .	270
9.5.15	EMU_DCDCCTRL - DCDC Control . . . . .	271
9.5.16	EMU_DCDCMISCCTRL - DCDC Miscellaneous Control Register . . . . .	272
9.5.17	EMU_DCDCZDETCTRL - DCDC Power Train NFET Zero Current Detector Control Register . . . . .	274
9.5.18	EMU_DCDCLIMCTRL - DCDC Power Train PFET Current Limiter Control Register . . . . .	275
9.5.19	EMU_DCDCLNCOMPCTRL - DCDC Low Noise Compensator Control Register . . . . .	276
9.5.20	EMU_DCDCLNVCTRL - DCDC Low Noise Voltage Register . . . . .	277
9.5.21	EMU_DCDCLPVCTRL - DCDC Low Power Voltage Register . . . . .	278
9.5.22	EMU_DCDCLPCTRL - DCDC Low Power Control Register . . . . .	279
9.5.23	EMU_DCDCLNFREQCTRL - DCDC Low Noise Controller Frequency Control . . . . .	280
9.5.24	EMU_DCDCSYNC - DCDC Read Status Register . . . . .	280
9.5.25	EMU_VMONAVDDCTRL - VMON AVDD Channel Control . . . . .	281
9.5.26	EMU_VMONALTAVDDCTRL - Alternate VMON AVDD Channel Control . . . . .	282
9.5.27	EMU_VMONDVDDCTRL - VMON DVDD Channel Control . . . . .	283
9.5.28	EMU_VMONIO0CTRL - VMON IOVDD0 Channel Control . . . . .	284
9.5.29	EMU_VMONBUVDDCTRL - VMON BUVDD Channel Control . . . . .	285
9.5.30	EMU_BUCTRL - Backup Power Configuration Register . . . . .	286
9.5.31	EMU_DCDCLPEM01CFG - Configuration Bits for Low Power Mode to Be Applied During EM01, This Field is Only Relevant If LP Mode is Used in EM01 . . . . .	288
9.5.32	EMU_EM23PERNORETAINCMD - Clears Corresponding Bits in EM23PERNORETAINSTATUS Unlocking Access to Peripheral . . . . .	289
9.5.33	EMU_EM23PERNORETAINSTATUS - Status Indicating If Peripherals Were Powered Down in EM23, Subsequently Locking Access to It . . . . .	291
9.5.34	EMU_EM23PERNORETAINCTRL - When Set Corresponding Peripherals May Get Powered Down in EM23 . . . . .	293

<b>10.</b>	<b>CMU - Clock Management Unit . . . . .</b>	<b>295</b>
10.1	Introduction. . . . .	295
10.2	Features . . . . .	295
10.3	Functional Description . . . . .	296
10.3.1	System Clocks . . . . .	298
10.3.2	Oscillators . . . . .	303
10.3.3	Configuration for Operating Frequencies . . . . .	320
10.3.4	Energy Modes . . . . .	321
10.3.5	Clock Output on a Pin . . . . .	322
10.3.6	Clock Input From a Pin . . . . .	322
10.3.7	Clock Output on PRS . . . . .	322
10.3.8	Error Handling . . . . .	322
10.3.9	Interrupts . . . . .	322
10.3.10	Wake-up . . . . .	323
10.3.11	Protection . . . . .	323
10.3.12	Digital Phase-Locked Loop . . . . .	323
10.4	Register Map . . . . .	325
10.5	Register Description . . . . .	327

10.5.1	CMU_CTRL - CMU Control Register	. . . . .	327
10.5.2	CMU_HFRCOCTRL - HFRCO Control Register	. . . . .	329
10.5.3	CMU_AUXHFRCOCTRL - AUXHFRCO Control Register	. . . . .	331
10.5.4	CMU_LFRCOCTRL - LFRCO Control Register	. . . . .	332
10.5.5	CMU_HFXOCTRL - HFXO Control Register	. . . . .	334
10.5.6	CMU_HFXOCTRL1 - HFXO Control 1	. . . . .	336
10.5.7	CMU_HFXOSTARTUPCTRL - HFXO Startup Control	. . . . .	337
10.5.8	CMU_HFXOSTEADYSTATECTRL - HFXO Steady State Control	. . . . .	338
10.5.9	CMU_HFXOTIMEOUTCTRL - HFXO Timeout Control	. . . . .	339
10.5.10	CMU_LFXOCTRL - LFXO Control Register	. . . . .	341
10.5.11	CMU_DPLLCTRL - DPLL Control Register	. . . . .	343
10.5.12	CMU_DPLLCTRL1 - DPLL Control Register	. . . . .	344
10.5.13	CMU_CALCTRL - Calibration Control Register	. . . . .	345
10.5.14	CMU_CALCNT - Calibration Counter Register	. . . . .	347
10.5.15	CMU_OSCENCMD - Oscillator Enable/Disable Command Register	. . . . .	348
10.5.16	CMU_CMD - Command Register	. . . . .	349
10.5.17	CMU_DBGCLKSEL - Debug Trace Clock Select	. . . . .	350
10.5.18	CMU_HFCLKSEL - High Frequency Clock Select Command Register	. . . . .	351
10.5.19	CMU_LFACLKSEL - Low Frequency A Clock Select Register	. . . . .	352
10.5.20	CMU_LFBCLKSEL - Low Frequency B Clock Select Register	. . . . .	352
10.5.21	CMU_LFECLKSEL - Low Frequency E Clock Select Register	. . . . .	353
10.5.22	CMU_STATUS - Status Register	. . . . .	354
10.5.23	CMU_HFCLKSTATUS - HFCLK Status Register	. . . . .	356
10.5.24	CMU_HFXOTRIMSTATUS - HFXO Trim Status	. . . . .	357
10.5.25	CMU_IF - Interrupt Flag Register	. . . . .	358
10.5.26	CMU_IFS - Interrupt Flag Set Register	. . . . .	360
10.5.27	CMU_IFC - Interrupt Flag Clear Register	. . . . .	362
10.5.28	CMU_IEN - Interrupt Enable Register	. . . . .	364
10.5.29	CMU_HFBUSCLKEN0 - High Frequency Bus Clock Enable Register 0	. . . . .	366
10.5.30	CMU_HFPERCLKEN0 - High Frequency Peripheral Clock Enable Register 0	. . . . .	367
10.5.31	CMU_HFPERCLKEN1 - High Frequency Peripheral Clock Enable Register 1	. . . . .	368
10.5.32	CMU_LFACLKEN0 - Low Frequency a Clock Enable Register 0 (Async Reg)	. . . . .	369
10.5.33	CMU_LFBCLKEN0 - Low Frequency B Clock Enable Register 0 (Async Reg)	. . . . .	369
10.5.34	CMU_LFECLKEN0 - Low Frequency E Clock Enable Register 0 (Async Reg)	. . . . .	370
10.5.35	CMU_HFPRESC - High Frequency Clock Prescaler Register	. . . . .	371
10.5.36	CMU_HFBUSPRES - High Frequency Bus Clock Prescaler Register	. . . . .	372
10.5.37	CMU_HFCOREPRES - High Frequency Core Clock Prescaler Register	. . . . .	372
10.5.38	CMU_HFPERPRES - High Frequency Peripheral Clock Prescaler Register	. . . . .	373
10.5.39	CMU_HFEXPPRES - High Frequency Export Clock Prescaler Register	. . . . .	373
10.5.40	CMU_HFPERPRESB - High Frequency Peripheral Clock Prescaler B Register	. . . . .	374
10.5.41	CMU_HFPERPRESCC - High Frequency Peripheral Clock Prescaler C Register	. . . . .	374
10.5.42	CMU_LFAPRES0 - Low Frequency a Prescaler Register 0 (Async Reg)	. . . . .	375
10.5.43	CMU_LFBPRES0 - Low Frequency B Prescaler Register 0 (Async Reg)	. . . . .	377
10.5.44	CMU_LFEPRES0 - Low Frequency E Prescaler Register 0 (Async Reg)	. . . . .	378
10.5.45	CMU_SYNCBUSY - Synchronization Busy Register	. . . . .	379
10.5.46	CMU_FREEZE - Freeze Register	. . . . .	382
10.5.47	CMU_PCNTCTRL - PCNT Control Register	. . . . .	383
10.5.48	CMU_ADCCTRL - ADC Control Register	. . . . .	384

10.5.49	CMU_ROUTEOPEN - I/O Routing Pin Enable Register	385
10.5.50	CMU_ROUTELOC0 - I/O Routing Location Register	386
10.5.51	CMU_ROUTELOC1 - I/O Routing Location Register	387
10.5.52	CMU_LOCK - Configuration Lock Register	388
10.5.53	CMU_HFRCOSS - HFRCO Spread Spectrum Register	389
<b>11.</b>	<b>SMU - Security Management Unit</b>	<b>390</b>
11.1	Introduction.	390
11.2	Features	390
11.3	Functional Description	391
11.3.1	PPU - Peripheral Protection Unit	391
11.3.2	Programming Model	392
11.4	Register Map	393
11.5	Register Description.	394
11.5.1	SMU_IF - Interrupt Flag Register	394
11.5.2	SMU_IFS - Interrupt Flag Set Register	394
11.5.3	SMU_IFC - Interrupt Flag Clear Register	395
11.5.4	SMU_IEN - Interrupt Enable Register	395
11.5.5	SMU_PPUCtrl - PPU Control Register	396
11.5.6	SMU_PPUPATD0 - PPU Privilege Access Type Descriptor 0	397
11.5.7	SMU_PPUPATD1 - PPU Privilege Access Type Descriptor 1	399
11.5.8	SMU_PPUFS - PPU Fault Status	400
<b>12.</b>	<b>RTCC - Real Time Counter and Calendar</b>	<b>402</b>
12.1	Introduction.	402
12.2	Features	402
12.3	Functional Description	403
12.3.1	Counter	404
12.3.2	Capture/Compare Channels	408
12.3.3	Interrupts and PRS Output	410
12.3.4	Energy Mode Availability	411
12.3.5	Register Lock	411
12.3.6	Oscillator Failure Detection	411
12.3.7	Retention Registers	411
12.3.8	Timestamp	411
12.3.9	Debug Session	411
12.4	Register Map	412
12.5	Register Description.	413
12.5.1	RTCC_CTRL - Control Register (Async Reg)	413
12.5.2	RTCC_PRECNT - Pre-Counter Value Register (Async Reg)	415
12.5.3	RTCC_CNT - Counter Value Register (Async Reg)	415
12.5.4	RTCC_COMBCNT - Combined Pre-Counter and Counter Value Register	416
12.5.5	RTCC_TIME - Time of Day Register (Async Reg)	417
12.5.6	RTCC_DATE - Date Register (Async Reg)	418
12.5.7	RTCC_IF - RTCC Interrupt Flags	419
12.5.8	RTCC_IFS - Interrupt Flag Set Register	420

12.5.9	RTCC_IFC - Interrupt Flag Clear Register	421
12.5.10	RTCC_IEN - Interrupt Enable Register	422
12.5.11	RTCC_STATUS - Status Register	423
12.5.12	RTCC_CMD - Command Register (Async Reg)	423
12.5.13	RTCC_SYNCBUSY - Synchronization Busy Register	424
12.5.14	RTCC_POWERDOWN - Retention RAM Power-down Register (Async Reg)	424
12.5.15	RTCC_LOCK - Configuration Lock Register (Async Reg)	425
12.5.16	RTCC_EM4WUEN - Wake Up Enable	425
12.5.17	RTCC_CCx_CTRL - CC Channel Control Register (Async Reg)	426
12.5.18	RTCC_CCx_CCV - Capture/Compare Value Register (Async Reg)	428
12.5.19	RTCC_CCx_TIME - Capture/Compare Time Register (Async Reg)	429
12.5.20	RTCC_CCx_DATE - Capture/Compare Date Register (Async Reg)	430
12.5.21	RTCC_RETx_REG - Retention Register	430
<b>13.</b>	<b>WDOG - Watchdog Timer</b>	<b>431</b>
13.1	Introduction.	431
13.2	Features	431
13.3	Functional Description	431
13.3.1	Clock Source	432
13.3.2	Debug Functionality	432
13.3.3	Energy Mode Handling	432
13.3.4	Register Access.	432
13.3.5	Warning Interrupt	432
13.3.6	Window Interrupt	433
13.3.7	PRS as Watchdog Clear	434
13.3.8	PRS Rising Edge Monitoring	434
13.4	Register Map	435
13.5	Register Description	436
13.5.1	WDOG_CTRL - Control Register (Async Reg)	436
13.5.2	WDOG_CMD - Command Register (Async Reg)	439
13.5.3	WDOG_SYNCBUSY - Synchronization Busy Register	440
13.5.4	WDOGn_PCHx_PRSCTRL - PRS Control Register (Async Reg)	441
13.5.5	WDOG_IF - Watchdog Interrupt Flags	442
13.5.6	WDOG_IFS - Interrupt Flag Set Register	443
13.5.7	WDOG_IFC - Interrupt Flag Clear Register	444
13.5.8	WDOG_IEN - Interrupt Enable Register	445
<b>14.</b>	<b>PRS - Peripheral Reflex System</b>	<b>446</b>
14.1	Introduction.	446
14.2	Features	446
14.3	Functional Description	447
14.3.1	Channel Functions	447
14.3.2	Producers	448
14.3.3	Consumers	449
14.3.4	Event on PRS	450
14.3.5	DMA Request on PRS	450
14.3.6	Example	451

14.4 Register Map . . . . .	451
14.5 Register Description . . . . .	452
14.5.1 PRS_SWPULSE - Software Pulse Register . . . . .	452
14.5.2 PRS_SWLEVEL - Software Level Register . . . . .	453
14.5.3 PRS_ROUTEOPEN - I/O Routing Pin Enable Register . . . . .	454
14.5.4 PRS_ROUTELOC0 - I/O Routing Location Register . . . . .	455
14.5.5 PRS_ROUTELOC1 - I/O Routing Location Register . . . . .	457
14.5.6 PRS_CTRL - Control Register . . . . .	458
14.5.7 PRS_DMAREQ0 - DMA Request 0 Register . . . . .	459
14.5.8 PRS_DMAREQ1 - DMA Request 1 Register . . . . .	460
14.5.9 PRS_PEEK - PRS Channel Values . . . . .	461
14.5.10 PRS_CHx_CTRL - Channel Control Register . . . . .	462
14.5.11 PRS_TRACECTRL - MTB Trace Control Register . . . . .	469
<b>15. LCD - Liquid Crystal Display Driver . . . . .</b>	<b>471</b>
15.1 Introduction. . . . .	471
15.2 Features . . . . .	471
15.3 Functional Description . . . . .	472
15.3.1 Power Supply . . . . .	472
15.3.2 LCD Driver Enable . . . . .	472
15.3.3 LCD Frame Rate and Power Reduction . . . . .	473
15.3.4 Multiplexing, Bias, and Wave Settings . . . . .	474
15.3.5 LCD Contrast . . . . .	476
15.3.6 Voltage Levels and Mode Selection . . . . .	476
15.3.7 Frame Rate . . . . .	476
15.3.8 Data Update . . . . .	477
15.3.9 Direct Segment Control (DSC) . . . . .	478
15.3.10 Frame Counter (FC) . . . . .	479
15.3.11 LCD Interrupt . . . . .	479
15.3.12 Blink, Blank, and Animation Features . . . . .	479
15.3.13 LCD in Low Energy Modes . . . . .	482
15.3.14 Register Access . . . . .	482
15.3.15 Waveform Examples. . . . .	482
15.4 Register Map . . . . .	503
15.5 Register Description . . . . .	504
15.5.1 LCD_CTRL - Control Register (Async Reg) . . . . .	504
15.5.2 LCD_DISPCTRL - Display Control Register . . . . .	505
15.5.3 LCD_SEGEN - Segment Enable Register . . . . .	507
15.5.4 LCD_BACTRL - Blink and Animation Control Register (Async Reg) . . . . .	508
15.5.5 LCD_STATUS - Status Register . . . . .	510
15.5.6 LCD_AREGA - Animation Register a (Async Reg) . . . . .	510
15.5.7 LCD_AREGB - Animation Register B (Async Reg) . . . . .	511
15.5.8 LCD_IF - Interrupt Flag Register . . . . .	511
15.5.9 LCD_IFS - Interrupt Flag Set Register . . . . .	511
15.5.10 LCD_IFC - Interrupt Flag Clear Register . . . . .	512
15.5.11 LCD_IEN - Interrupt Enable Register . . . . .	512
15.5.12 LCD_BIASCTRL - Analog BIAS Control . . . . .	513

15.5.13	LCD_SEGD0L - Segment Data Low Register 0 (Async Reg)	513
15.5.14	LCD_SEGD1L - Segment Data Low Register 1 (Async Reg)	514
15.5.15	LCD_SEGD2L - Segment Data Low Register 2 (Async Reg)	514
15.5.16	LCD_SEGD3L - Segment Data Low Register 3 (Async Reg)	515
15.5.17	LCD_SEGD0H - Segment Data High Register 0 (Async Reg)	515
15.5.18	LCD_SEGD1H - Segment Data High Register 1 (Async Reg)	516
15.5.19	LCD_SEGD2H - Segment Data High Register 2 (Async Reg)	516
15.5.20	LCD_SEGD3H - Segment Data High Register 3 (Async Reg)	517
15.5.21	LCD_SEGD4L - Segment Data Low Register 4 (Async Reg)	517
15.5.22	LCD_SEGD5L - Segment Data Low Register 5 (Async Reg)	518
15.5.23	LCD_SEGD6L - Segment Data Low Register 6 (Async Reg)	518
15.5.24	LCD_SEGD7L - Segment Data Low Register 7 (Async Reg)	519
15.5.25	LCD_SEGD4H - Segment Data High Register 4 (Async Reg)	519
15.5.26	LCD_SEGD5H - Segment Data High Register 5 (Async Reg)	520
15.5.27	LCD_SEGD6H - Segment Data High Register 6 (Async Reg)	520
15.5.28	LCD_SEGD7H - Segment Data High Register 7 (Async Reg)	521
15.5.29	LCD_FREEZE - Freeze Register	522
15.5.30	LCD_SYNCBUSY - Synchronization Busy Register	523
15.5.31	LCD_FRAMERATE - Frame Rate	524
15.5.32	LCD_SEGEN2 - Segment Enable (32 to 39)	525

## 16. PCNT - Pulse Counter . . . . . 526

16.1	Introduction.	526
16.2	Features	526
16.3	Functional Description	527
16.3.1	Pulse Counter Modes	527
16.3.2	Hysteresis	534
16.3.3	Auxiliary Counter	535
16.3.4	Triggered Compare and Clear	536
16.3.5	Register Access.	537
16.3.6	Clock Sources	537
16.3.7	Input Filter	537
16.3.8	Edge Polarity	537
16.3.9	PRS and PCNTn_S0IN,PCNTn_S1IN Inputs	538
16.3.10	Interrupts	538
16.3.11	Cascading Pulse Counters	540
16.4	Register Map	541
16.5	Register Description	542
16.5.1	PCNTn_CTRL - Control Register (Async Reg)	542
16.5.2	PCNTn_CMD - Command Register (Async Reg)	545
16.5.3	PCNTn_STATUS - Status Register	546
16.5.4	PCNTn_CNT - Counter Value Register	546
16.5.5	PCNTn_TOP - Top Value Register	547
16.5.6	PCNTn_TOPB - Top Value Buffer Register (Async Reg)	547
16.5.7	PCNTn_IF - Interrupt Flag Register	548
16.5.8	PCNTnIFS - Interrupt Flag Set Register	549
16.5.9	PCNTnIFC - Interrupt Flag Clear Register	550

16.5.10	PCNTn_IEN - Interrupt Enable Register . . . . .	551
16.5.11	PCNTn_ROUTELOC0 - I/O Routing Location Register . . . . .	552
16.5.12	PCNTn_FREEZE - Freeze Register . . . . .	553
16.5.13	PCNTn_SYNCBUSY - Synchronization Busy Register . . . . .	553
16.5.14	PCNTn_AUXCNT - Auxiliary Counter Value Register . . . . .	554
16.5.15	PCNTn_INPUT - PCNT Input Register . . . . .	555
16.5.16	PCNTn_OVSCFG - Oversampling Config Register (Async Reg) . . . . .	556
<b>17.</b>	<b>I2C - Inter-Integrated Circuit Interface . . . . .</b>	<b>557</b>
17.1	Introduction. . . . .	557
17.2	Features . . . . .	557
17.3	Functional Description . . . . .	558
17.3.1	I2C-Bus Overview . . . . .	559
17.3.2	Enable and Reset . . . . .	563
17.3.3	Safely Disabling and Changing Slave Configuration. . . . .	563
17.3.4	Clock Generation . . . . .	563
17.3.5	Arbitration . . . . .	564
17.3.6	Buffers . . . . .	564
17.3.7	Master Operation . . . . .	566
17.3.8	Bus States . . . . .	574
17.3.9	Slave Operation . . . . .	574
17.3.10	Transfer Automation . . . . .	578
17.3.11	Using 10-bit Addresses . . . . .	579
17.3.12	Error Handling . . . . .	579
17.3.13	DMA Support . . . . .	581
17.3.14	Interrupts . . . . .	581
17.3.15	Wake-up . . . . .	581
17.4	Register Map . . . . .	582
17.5	Register Description . . . . .	583
17.5.1	I2Cn_CTRL - Control Register . . . . .	583
17.5.2	I2Cn_CMD - Command Register . . . . .	586
17.5.3	I2Cn_STATE - State Register . . . . .	587
17.5.4	I2Cn_STATUS - Status Register . . . . .	588
17.5.5	I2Cn_CLKDIV - Clock Division Register . . . . .	589
17.5.6	I2Cn_SADDR - Slave Address Register . . . . .	589
17.5.7	I2Cn_SADDRMASK - Slave Address Mask Register . . . . .	590
17.5.8	I2Cn_RXDATA - Receive Buffer Data Register (Actionable Reads) . . . . .	590
17.5.9	I2Cn_RXDOUBLE - Receive Buffer Double Data Register (Actionable Reads) . . . . .	591
17.5.10	I2Cn_RXDATAP - Receive Buffer Data Peek Register . . . . .	591
17.5.11	I2Cn_RXDOUBLEP - Receive Buffer Double Data Peek Register . . . . .	592
17.5.12	I2Cn_TXDATA - Transmit Buffer Data Register . . . . .	592
17.5.13	I2Cn_TXDOUBLE - Transmit Buffer Double Data Register . . . . .	593
17.5.14	I2Cn_IF - Interrupt Flag Register . . . . .	594
17.5.15	I2CnIFS - Interrupt Flag Set Register . . . . .	596
17.5.16	I2CnIFC - Interrupt Flag Clear Register . . . . .	598
17.5.17	I2Cn_IEN - Interrupt Enable Register . . . . .	600
17.5.18	I2CnROUTEOPEN - I/O Routing Pin Enable Register . . . . .	601

17.5.19	I2Cn_ROUTELOC0 - I/O Routing Location Register . . . . .	602
<b>18. USART - Universal Synchronous Asynchronous Receiver/Transmitter</b>	. . . . .	<b>603</b>
18.1	Introduction. . . . .	603
18.2	Features . . . . .	604
18.3	Functional Description . . . . .	605
18.3.1	Modes of Operation . . . . .	606
18.3.2	Asynchronous Operation . . . . .	606
18.3.3	Synchronous Operation . . . . .	623
18.3.4	Hardware Flow Control . . . . .	630
18.3.5	Debug Halt . . . . .	630
18.3.6	PRS-triggered Transmissions . . . . .	630
18.3.7	PRS RX Input . . . . .	630
18.3.8	PRS CLK Input . . . . .	631
18.3.9	DMA Support . . . . .	631
18.3.10	Timer . . . . .	632
18.3.11	Interrupts . . . . .	637
18.3.12	IrDA Modulator/ Demodulator . . . . .	638
18.4	Register Map . . . . .	639
18.5	Register Description . . . . .	640
18.5.1	USARTn_CTRL - Control Register . . . . .	640
18.5.2	USARTn_FRAME - USART Frame Format Register . . . . .	645
18.5.3	USARTn_TRIGCTRL - USART Trigger Control Register . . . . .	647
18.5.4	USARTn_CMD - Command Register . . . . .	649
18.5.5	USARTn_STATUS - USART Status Register . . . . .	650
18.5.6	USARTn_CLKDIV - Clock Control Register . . . . .	651
18.5.7	USARTn_RXDATABX - RX Buffer Data Extended Register (Actionable Reads) . . . . .	652
18.5.8	USARTn_RXDATA - RX Buffer Data Register (Actionable Reads) . . . . .	652
18.5.9	USARTn_RXDOUBLEX - RX Buffer Double Data Extended Register (Actionable Reads) . . . . .	653
18.5.10	USARTn_RXDOUBLE - RX FIFO Double Data Register (Actionable Reads) . . . . .	654
18.5.11	USARTn_RXDATABXP - RX Buffer Data Extended Peek Register . . . . .	654
18.5.12	USARTn_RXDOUBLEXP - RX Buffer Double Data Extended Peek Register . . . . .	655
18.5.13	USARTn_TXDATABX - TX Buffer Data Extended Register . . . . .	656
18.5.14	USARTn_TXDATA - TX Buffer Data Register . . . . .	657
18.5.15	USARTn_TXDOUBLEX - TX Buffer Double Data Extended Register . . . . .	658
18.5.16	USARTn_TXDOUBLE - TX Buffer Double Data Register . . . . .	659
18.5.17	USARTn_IF - Interrupt Flag Register . . . . .	660
18.5.18	USARTn_IFS - Interrupt Flag Set Register . . . . .	662
18.5.19	USARTn_IFC - Interrupt Flag Clear Register . . . . .	664
18.5.20	USARTn_IEN - Interrupt Enable Register . . . . .	666
18.5.21	USARTn_IRCTRL - IrDA Control Register . . . . .	668
18.5.22	USARTn_INPUT - USART Input Register . . . . .	670
18.5.23	USARTn_I2SCTRL - I2S Control Register . . . . .	672
18.5.24	USARTn_TIMING - Timing Register . . . . .	674
18.5.25	USARTn_CTRLX - Control Register Extended . . . . .	676
18.5.26	USARTn_TIMECMP0 - Used to Generate Interrupts and Various Delays . . . . .	677
18.5.27	USARTn_TIMECMP1 - Used to Generate Interrupts and Various Delays . . . . .	679

18.5.28	USARTn_TIMECMP2 - Used to Generate Interrupts and Various Delays	681
18.5.29	USARTn_ROUTEOPEN - I/O Routing Pin Enable Register	683
18.5.30	USARTn_ROUTELOC0 - I/O Routing Location Register	685
18.5.31	USARTn_ROUTELOC1 - I/O Routing Location Register	687
<b>19.</b>	<b>UART - Universal Asynchronous Receiver/ Transmitter</b>	<b>688</b>
19.1	Introduction.	688
19.2	Features	689
19.3	Functional Description	689
19.4	Register Map	689
19.5	Register Description	689
<b>20.</b>	<b>LEUART - Low Energy Universal Asynchronous Receiver/Transmitter</b>	<b>690</b>
20.1	Introduction.	690
20.2	Features	691
20.3	Functional Description	692
20.3.1	Frame Format	693
20.3.2	Clock Source	693
20.3.3	Clock Generation	694
20.3.4	Data Transmission	694
20.3.5	Data Reception	696
20.3.6	Loopback	699
20.3.7	Half Duplex Communication	699
20.3.8	Transmission Delay	700
20.3.9	PRS RX Input	700
20.3.10	DMA Support	701
20.3.11	Pulse Generator/ Pulse Extender	701
20.3.12	Register Access	702
20.4	Register Map	702
20.5	Register Description	703
20.5.1	LEUARTn_CTRL - Control Register (Async Reg)	703
20.5.2	LEUARTn_CMD - Command Register (Async Reg)	706
20.5.3	LEUARTn_STATUS - Status Register	707
20.5.4	LEUARTn_CLKDIV - Clock Control Register (Async Reg)	708
20.5.5	LEUARTn_STARTFRAME - Start Frame Register (Async Reg)	708
20.5.6	LEUARTn_SIGFRAME - Signal Frame Register (Async Reg)	709
20.5.7	LEUARTn_RXDATA - Receive Buffer Data Extended Register (Actionable Reads)	709
20.5.8	LEUARTn_RXDATA - Receive Buffer Data Register (Actionable Reads)	710
20.5.9	LEUARTn_RXDATAXP - Receive Buffer Data Extended Peek Register	710
20.5.10	LEUARTn_TXDATA - Transmit Buffer Data Extended Register (Async Reg)	711
20.5.11	LEUARTn_TXDATA - Transmit Buffer Data Register (Async Reg)	712
20.5.12	LEUARTn_IF - Interrupt Flag Register	713
20.5.13	LEUARTn_IFS - Interrupt Flag Set Register	714
20.5.14	LEUARTn_IFC - Interrupt Flag Clear Register	715
20.5.15	LEUARTn_IEN - Interrupt Enable Register	716
20.5.16	LEUARTn_PULSECTRL - Pulse Control Register (Async Reg)	717

20.5.17	LEUARTn_FREEZE - Freeze Register	718
20.5.18	LEUARTn_SYNCBUSY - Synchronization Busy Register	719
20.5.19	LEUARTn_ROUTEPEN - I/O Routing Pin Enable Register	720
20.5.20	LEUARTn_ROUTELOC0 - I/O Routing Location Register	721
20.5.21	LEUARTn_INPUT - LEUART Input Register	722
<b>21.</b>	<b>TIMER/WTIMER - Timer/Counter</b>	<b>723</b>
21.1	Introduction.	723
21.2	Features	724
21.3	Functional Description	725
21.3.1	Counter Modes	726
21.3.2	Compare/Capture Channels	732
21.3.3	Dead-Time Insertion Unit	742
21.3.4	Debug Mode	746
21.3.5	Interrupts, DMA and PRS Output	746
21.3.6	GPIO Input/Output	746
21.4	Register Map	747
21.5	Register Description	748
21.5.1	TIMERn_CTRL - Control Register	748
21.5.2	TIMERn_CMD - Command Register	751
21.5.3	TIMERn_STATUS - Status Register	752
21.5.4	TIMERn_IF - Interrupt Flag Register	755
21.5.5	TIMERn_IFS - Interrupt Flag Set Register	756
21.5.6	TIMERn_ICF - Interrupt Flag Clear Register	757
21.5.7	TIMERn_IEN - Interrupt Enable Register	759
21.5.8	TIMERn_TOP - Counter Top Value Register	760
21.5.9	TIMERn_TOPB - Counter Top Value Buffer Register	760
21.5.10	TIMERn_CNT - Counter Value Register	761
21.5.11	TIMERn_LOCK - TIMER Configuration Lock Register	761
21.5.12	TIMERn_ROUTEPEN - I/O Routing Pin Enable Register	762
21.5.13	TIMERn_ROUTELOC0 - I/O Routing Location Register	763
21.5.14	TIMERn_ROUTELOC2 - I/O Routing Location Register	765
21.5.15	TIMERn_CCx_CTRL - CC Channel Control Register	767
21.5.16	TIMERn_CCx_CCV - CC Channel Value Register (Actionable Reads)	770
21.5.17	TIMERn_CCx_CCVP - CC Channel Value Peek Register	770
21.5.18	TIMERn_CCx_CCVB - CC Channel Buffer Register	771
21.5.19	TIMERn_DTCTRL - DTI Control Register	772
21.5.20	TIMERn_DTTIME - DTI Time Control Register	774
21.5.21	TIMERn_DTFC - DTI Fault Configuration Register	776
21.5.22	TIMERn.DTOGEN - DTI Output Generation Enable Register	778
21.5.23	TIMERn.DTFAULT - DTI Fault Register	779
21.5.24	TIMERn.DTFAULTC - DTI Fault Clear Register	780
21.5.25	TIMERn.DTLOCK - DTI Configuration Lock Register	781
<b>22.</b>	<b>LETIMER - Low Energy Timer</b>	<b>782</b>
22.1	Introduction.	782
22.2	Features	782

<b>22.3 Functional Description</b>	783
22.3.1 Timer	783
22.3.2 Compare Registers	783
22.3.3 Top Value	784
22.3.4 Underflow Output Action	790
22.3.5 PRS Output	792
22.3.6 Examples	792
22.3.7 Register Access	795
<b>22.4 Register Map</b>	796
<b>22.5 Register Description</b>	797
22.5.1 LETIMERn_CTRL - Control Register (Async Reg)	797
22.5.2 LETIMERn_CMD - Command Register (Async Reg)	799
22.5.3 LETIMERn_STATUS - Status Register	799
22.5.4 LETIMERn_CNT - Counter Value Register	800
22.5.5 LETIMERn_COMP0 - Compare Value Register 0 (Async Reg)	800
22.5.6 LETIMERn_COMP1 - Compare Value Register 1 (Async Reg)	801
22.5.7 LETIMERn REP0 - Repeat Counter Register 0 (Async Reg)	801
22.5.8 LETIMERn REP1 - Repeat Counter Register 1 (Async Reg)	802
22.5.9 LETIMERn_IF - Interrupt Flag Register	802
22.5.10 LETIMERn_IFS - Interrupt Flag Set Register	803
22.5.11 LETIMERn_IFC - Interrupt Flag Clear Register	804
22.5.12 LETIMERn_IEN - Interrupt Enable Register	805
22.5.13 LETIMERn_SYNCBUSY - Synchronization Busy Register	805
22.5.14 LETIMERn_ROUTEPEN - I/O Routing Pin Enable Register	806
22.5.15 LETIMERn_ROUTELOC0 - I/O Routing Location Register	807
22.5.16 LETIMERn_PRSSEL - PRS Input Select Register	808
<b>23. CRYOTIMER - Ultra Low Energy Timer/Counter</b>	811
23.1 Introduction.	811
23.2 Features	811
23.3 Functional Description	811
23.3.1 Block Diagram	812
23.3.2 Operation	813
23.3.3 Debug Mode	813
23.3.4 Energy Mode Availability	813
23.4 Register Map	814
23.5 Register Description	815
23.5.1 CRYOTIMER_CTRL - Control Register	815
23.5.2 CRYOTIMER_PERIODSEL - Interrupt Duration	817
23.5.3 CRYOTIMER_CNT - Counter Value	818
23.5.4 CRYOTIMER_EM4WUEN - Wake Up Enable	818
23.5.5 CRYOTIMER_IF - Interrupt Flag Register	819
23.5.6 CRYOTIMER_IFS - Interrupt Flag Set Register	819
23.5.7 CRYOTIMER_IFC - Interrupt Flag Clear Register	820
23.5.8 CRYOTIMER_IEN - Interrupt Enable Register	820
<b>24. VDAC - Digital to Analog Converter</b>	821

24.1	Introduction	821
24.2	Features	822
24.3	Functional Description	822
24.3.1	Power Supply	823
24.3.2	I/O Pin Considerations	823
24.3.3	Enabling and Disabling a Channel	823
24.3.4	Conversions	824
24.3.5	Reference Selection	824
24.3.6	Warmup Time and Initial Conversion	825
24.3.7	Analog Output	825
24.3.8	Output Mode	825
24.3.9	Async Mode	826
24.3.10	Refresh Timer	826
24.3.11	Clock Prescaling	826
24.3.12	High Speed	826
24.3.13	Sine Generation Mode	827
24.3.14	Interrupt Flags	827
24.3.15	PRS Outputs	828
24.3.16	DMA Request	828
24.3.17	LESENSE Trigger Mode	828
24.3.18	Opamps	828
24.3.19	Calibration	828
24.3.20	Warmup Mode	829
24.4	Register Map	830
24.5	Register Description	832
24.5.1	VDACn_CTRL - Control Register	832
24.5.2	VDACn_STATUS - Status Register	835
24.5.3	VDACn_CH0CTRL - Channel 0 Control Register	837
24.5.4	VDACn_CH1CTRL - Channel 1 Control Register	839
24.5.5	VDACn_CMD - Command Register	841
24.5.6	VDACn_IF - Interrupt Flag Register	842
24.5.7	VDACn_IFS - Interrupt Flag Set Register	844
24.5.8	VDACn_IFC - Interrupt Flag Clear Register	846
24.5.9	VDACn_IEN - Interrupt Enable Register	848
24.5.10	VDACn_CH0DATA - Channel 0 Data Register	850
24.5.11	VDACn_CH1DATA - Channel 1 Data Register	850
24.5.12	VDACn_COMBDATA - Combined Data Register	851
24.5.13	VDACn_CAL - Calibration Register	852
24.5.14	VDACn_OPAX_APORTRQ - Operational Amplifier APORTRQ Request Status Register	853
24.5.15	VDACn_OPAX_APORTRCONFLICT - Operational Amplifier APORTRCONFLICT Conflict Status Register	854
24.5.16	VDACn_OPAX_CTRL - Operational Amplifier Control Register	855
24.5.17	VDACn_OPAX_TIMER - Operational Amplifier Timer Control Register	858
24.5.18	VDACn_OPAX_MUX - Operational Amplifier Mux Configuration Register	859
24.5.19	VDACn_OPAX_OUT - Operational Amplifier Output Configuration Register	862
24.5.20	VDACn_OPAX_CAL - Operational Amplifier Calibration Register	864
<b>25.</b>	<b>OPAMP - Operational Amplifier</b>	<b>.866</b>

25.1	Introduction	866
25.2	Features	866
25.3	Functional Description	867
25.3.1	Opamp Configuration	868
25.3.2	Interrupts and PRS Output	871
25.3.3	APORT Request and Conflict Status	871
25.3.4	Opamp Modes	871
25.3.5	Opamp VDAC Combination	878
25.4	Register Map	879
25.5	Register Description	879
<b>26.</b>	<b>ACMP - Analog Comparator</b>	<b>880</b>
26.1	Introduction	880
26.2	Features	881
26.3	Functional Description	882
26.3.1	Power Supply	882
26.3.2	Warm-up Time	883
26.3.3	Response Time	883
26.3.4	Hysteresis	884
26.3.5	Input Pin Considerations	885
26.3.6	Input Selection	885
26.3.7	Capacitive Sense Mode	886
26.3.8	Interrupts and PRS Output	888
26.3.9	Output to GPIO	888
26.3.10	APORT Conflicts	888
26.3.11	Supply Voltage Monitoring	888
26.3.12	External Override Interface	889
26.4	Register Map	889
26.5	Register Description	890
26.5.1	ACMPn_CTRL - Control Register	890
26.5.2	ACMPn_INPUTSEL - Input Selection Register	893
26.5.3	ACMPn_STATUS - Status Register	898
26.5.4	ACMPn_IF - Interrupt Flag Register	899
26.5.5	ACMPn_IFS - Interrupt Flag Set Register	899
26.5.6	ACMPn_IFC - Interrupt Flag Clear Register	900
26.5.7	ACMPn_IEN - Interrupt Enable Register	901
26.5.8	ACMPn_APORTREQ - APORTR Request Status Register	902
26.5.9	ACMPn_APORTRCONFLICT - APORTR Conflict Status Register	903
26.5.10	ACMPn_HYSTERESIS0 - Hysteresis 0 Register	905
26.5.11	ACMPn_HYSTERESIS1 - Hysteresis 1 Register	906
26.5.12	ACMPn_ROUTEOPEN - I/O Routing Pipe Enable Register	907
26.5.13	ACMPn_ROUTELOC0 - I/O Routing Location Register	907
26.5.14	ACMPn_EXTIFCTRL - External Override Interface Control	908
<b>27.</b>	<b>ADC - Analog to Digital Converter</b>	<b>910</b>
27.1	Introduction	910

27.2 Features . . . . .	911
27.3 Functional Description . . . . .	912
27.3.1 Clock Selection . . . . .	913
27.3.2 Conversions . . . . .	913
27.3.3 ADC Modes . . . . .	914
27.3.4 Warm-up Time . . . . .	915
27.3.5 Power Supply . . . . .	916
27.3.6 Input Pin Considerations . . . . .	916
27.3.7 Input Selection . . . . .	917
27.3.8 Reference Selection and Input Range Definition . . . . .	921
27.3.9 Programming of Bias Current . . . . .	925
27.3.10 Feature Set . . . . .	925
27.3.11 Interrupts, PRS Output . . . . .	932
27.3.12 DMA Request . . . . .	932
27.3.13 Calibration . . . . .	932
27.3.14 EM2 DeepSleep or EM3 Stop Operation . . . . .	933
27.3.15 ASYNC ADC_CLK Usage Restrictions and Benefits . . . . .	934
27.3.16 Window Compare Function . . . . .	934
27.3.17 ADC Programming Model . . . . .	935
27.4 Register Map . . . . .	936
27.5 Register Description . . . . .	937
27.5.1 ADCn_CTRL - Control Register . . . . .	937
27.5.2 ADCn_CMD - Command Register . . . . .	940
27.5.3 ADCn_STATUS - Status Register . . . . .	941
27.5.4 ADCn_SINGLECTRL - Single Channel Control Register . . . . .	943
27.5.5 ADCn_SINGLECTRLX - Single Channel Control Register Continued . . . . .	948
27.5.6 ADCn_SCANCTRL - Scan Control Register . . . . .	951
27.5.7 ADCn_SCANCTRLX - Scan Control Register Continued . . . . .	954
27.5.8 ADCn_SCANMASK - Scan Sequence Input Mask Register . . . . .	957
27.5.9 ADCn_SCANINPUTSEL - Input Selection Register for Scan Mode . . . . .	959
27.5.10 ADCn_SCANNEGSEL - Negative Input Select Register for Scan . . . . .	962
27.5.11 ADCn_CMPTHRESHOLD - Compare Threshold Register . . . . .	964
27.5.12 ADCn_BIASPROG - Bias Programming Register for Various Analog Blocks Used in ADC Operation . . . . .	965
27.5.13 ADCn_CAL - Calibration Register . . . . .	966
27.5.14 ADCn_IF - Interrupt Flag Register . . . . .	968
27.5.15 ADCn_IFS - Interrupt Flag Set Register . . . . .	970
27.5.16 ADCn_IFC - Interrupt Flag Clear Register . . . . .	972
27.5.17 ADCn_IEN - Interrupt Enable Register . . . . .	974
27.5.18 ADCn_SINGLEDATA - Single Conversion Result Data (Actionable Reads) . . . . .	975
27.5.19 ADCn_SCANDATA - Scan Conversion Result Data (Actionable Reads) . . . . .	975
27.5.20 ADCn_SINGLEDATAP - Single Conversion Result Data Peek Register . . . . .	976
27.5.21 ADCn_SCANDATAP - Scan Sequence Result Data Peek Register . . . . .	976
27.5.22 ADCn_SCANDATAXP - Scan Sequence Result Data + Data Source Register (Actionable Reads) . . . . .	977
27.5.23 ADCn_SCANDATAXP - Scan Sequence Result Data + Data Source Peek Register . . . . .	977
27.5.24 ADCn_APORTRQ - APORTR Request Status Register . . . . .	978
27.5.25 ADCn_APORTCONFLICT - APORTR Conflict Status Register . . . . .	979

27.5.26	ADCn_SINGLEFIFOCOUNT - Single FIFO Count Register	. . . . .	.980
27.5.27	ADCn_SCANFIFOCOUNT - Scan FIFO Count Register	. . . . .	.980
27.5.28	ADCn_SINGLEFIFOCLEAR - Single FIFO Clear Register	. . . . .	.981
27.5.29	ADCn_SCANFIFOCLEAR - Scan FIFO Clear Register	. . . . .	.981
27.5.30	ADCn_APORMASTERDIS - APOR Bus Master Disable Register	. . . . .	.982
<b>28.</b>	<b>LESENSE - Low Energy Sensor Interface</b>	. . . . .	<b>985</b>
28.1	Introduction	. . . . .	985
28.2	Features	. . . . .	986
28.3	Functional Description	. . . . .	986
28.3.1	Channel Configuration	. . . . .	987
28.3.2	Scan Sequence	. . . . .	988
28.3.3	Sensor Timing	. . . . .	989
28.3.4	Sensor Interaction	. . . . .	991
28.3.5	Sensor Sampling	. . . . .	992
28.3.6	Sensor Evaluation	. . . . .	993
28.3.7	Decoder	. . . . .	995
28.3.8	Measurement Results	. . . . .	998
28.3.9	VDAC Interface	. . . . .	999
28.3.10	ACMP Interface	. . . . .	999
28.3.11	ACMP and VDAC Duty Cycling	. . . . .	999
28.3.12	ADC Interface	. . . . .	999
28.3.13	DMA Requests	. . . . .	1000
28.3.14	PRS Output	. . . . .	1000
28.3.15	RAM	. . . . .	1000
28.3.16	Application Examples	. . . . .	1000
28.4	Register Map	. . . . .	1006
28.5	Register Description	. . . . .	1008
28.5.1	LESENSE_CTRL - Control Register (Async Reg)	. . . . .	1008
28.5.2	LESENSE_TIMCTRL - Timing Control Register (Async Reg)	. . . . .	1011
28.5.3	LESENSE_PERCTRL - Peripheral Control Register (Async Reg)	. . . . .	1013
28.5.4	LESENSE_DECCTRL - Decoder Control Register (Async Reg)	. . . . .	1016
28.5.5	LESENSE_BIASCTRL - Bias Control Register (Async Reg)	. . . . .	1018
28.5.6	LESENSE_EVALCTRL - LESENSE Evaluation Control (Async Reg)	. . . . .	1019
28.5.7	LESENSE_PRSCTRL - PRS Control Register (Async Reg)	. . . . .	1020
28.5.8	LESENSE_CMD - Command Register (Async Reg)	. . . . .	1021
28.5.9	LESENSE_CHEN - Channel Enable Register (Async Reg)	. . . . .	1021
28.5.10	LESENSE_SCANRES - Scan Result Register (Async Reg)	. . . . .	1022
28.5.11	LESENSE_STATUS - Status Register (Async Reg)	. . . . .	1023
28.5.12	LESENSE_PTR - Result Buffer Pointers (Async Reg)	. . . . .	1024
28.5.13	LESENSE_BUFDATA - Result Buffer Data Register (Async Reg) (Actionable Reads)	. . . . .	1024
28.5.14	LESENSE_CURCH - Current Channel Index (Async Reg)	. . . . .	1025
28.5.15	LESENSE_DECSTATE - Current Decoder State (Async Reg)	. . . . .	1025
28.5.16	LESENSE_SENSORSTATE - Decoder Input Register (Async Reg)	. . . . .	1026
28.5.17	LESENSE_IDLECONF - GPIO Idle Phase Configuration (Async Reg)	. . . . .	1027
28.5.18	LESENSE_ALTEXCONF - Alternative Excite Pin Configuration (Async Reg)	. . . . .	1031
28.5.19	LESENSE_IF - Interrupt Flag Register	. . . . .	1034

28.5.20	LESENSE_IFS - Interrupt Flag Set Register	1036
28.5.21	LESENSE_IFC - Interrupt Flag Clear Register	1038
28.5.22	LESENSE_IEN - Interrupt Enable Register	1040
28.5.23	LESENSE_SYNCBUSY - Synchronization Busy Register	1041
28.5.24	LESENSE_ROUTEPEN - I/O Routing Register (Async Reg)	1042
28.5.25	LESENSE_STx_TCONFA - State Transition Configuration a (Async Reg)	1044
28.5.26	LESENSE_STx_TCONFb - State Transition Configuration B (Async Reg)	1046
28.5.27	LESENSE_BUFX_DATA - Scan Results (Async Reg)	1047
28.5.28	LESENSE_CHx_TIMING - Scan Configuration (Async Reg)	1048
28.5.29	LESENSE_CHx_INTERACT - Scan Configuration (Async Reg)	1049
28.5.30	LESENSE_CHx_EVAL - Scan Configuration (Async Reg)	1051
<b>29.</b>	<b>GPCRC - General Purpose Cyclic Redundancy Check</b>	<b>1053</b>
29.1	Introduction	1053
29.2	Features	1053
29.3	Functional Description	1054
29.3.1	Polynomial Specification	1055
29.3.2	Input and Output Specification	1055
29.3.3	Initialization	1055
29.3.4	DMA Usage	1055
29.3.5	Byte-Level Bit Reversal and Byte Reordering	1056
29.4	Register Map	1058
29.5	Register Description	1059
29.5.1	GPCRC_CTRL - Control Register	1059
29.5.2	GPCRC_CMD - Command Register	1060
29.5.3	GPCRC_INIT - CRC Init Value	1060
29.5.4	GPCRC_POLY - CRC Polynomial Value	1061
29.5.5	GPCRC_INPUTDATA - Input 32-bit Data Register	1061
29.5.6	GPCRC_INPUTDATAHWORD - Input 16-bit Data Register	1062
29.5.7	GPCRC_INPUTDATABYTE - Input 8-bit Data Register	1062
29.5.8	GPCRC_DATA - CRC Data Register	1063
29.5.9	GPCRC_DATAREV - CRC Data Reverse Register	1063
29.5.10	GPCRC_DATABYTTEREV - CRC Data Byte Reverse Register	1064
<b>30.</b>	<b>TRNG - True Random Number Generator</b>	<b>1065</b>
30.1	Introduction	1065
30.2	Features	1065
30.3	Functional Description	1066
30.3.1	Built-In Tests	1066
30.3.2	FIFO Interface	1066
30.3.3	Data Format - Byte Ordering	1067
30.3.4	TRNG Usage	1067
30.4	Register Map	1069
30.5	Register Description	1070
30.5.1	TRNGn_CONTROL - Main Control Register	1070
30.5.2	TRNGn_FIFOLEVEL - FIFO Level Register (Actionable Reads)	1072

30.5.3	TRNGn_FIFODEPTH - FIFO Depth Register	1072
30.5.4	TRNGn_KEY0 - Key Register 0	1073
30.5.5	TRNGn_KEY1 - Key Register 1	1073
30.5.6	TRNGn_KEY2 - Key Register 2	1074
30.5.7	TRNGn_KEY3 - Key Register 3	1074
30.5.8	TRNGn_TESTDATA - Test Data Register	1075
30.5.9	TRNGn_STATUS - Status Register	1076
30.5.10	TRNGn_INITWAITVAL - Initial Wait Counter	1077
30.5.11	TRNGn_FIFO - FIFO Data (Actionable Reads)	1077
<b>31.</b>	<b>CRYPTO - Crypto Accelerator.</b>	<b>1078</b>
31.1	Introduction	1078
31.2	Features	1079
31.3	Usage and Programming Interface	1079
31.4	Functional Description	1080
31.4.1	Data and Key Registers	1081
31.4.2	Instructions and Execution	1083
31.4.3	Repeated Sequence	1088
31.4.4	AES	1089
31.4.5	SHA	1091
31.4.6	ECC	1091
31.4.7	GCM and GMAC	1092
31.4.8	DMA	1092
31.4.9	Debugging	1093
31.5	Register Map	1094
31.6	Register Description	1096
31.6.1	CRYPTO_CTRL - Control Register	1096
31.6.2	CRYPTO_WAC - Wide Arithmetic Configuration	1099
31.6.3	CRYPTO_CMD - Command Register	1101
31.6.4	CRYPTO_STATUS - Status Register	1106
31.6.5	CRYPTO_DSTATUS - Data Status Register	1107
31.6.6	CRYPTO_CSTATUS - Control Status Register	1108
31.6.7	CRYPTO_KEY - KEY Register Access (No Bit Access) (Actionable Reads)	1109
31.6.8	CRYPTO_KEYBUF - KEY Buffer Register Access (No Bit Access) (Actionable Reads)	1110
31.6.9	CRYPTO_SEQCTRL - Sequence Control	1111
31.6.10	CRYPTO_SEQCTRLB - Sequence Control B	1112
31.6.11	CRYPTO_IF - AES Interrupt Flags	1112
31.6.12	CRYPTO_IFS - Interrupt Flag Set Register	1113
31.6.13	CRYPTO_IFC - Interrupt Flag Clear Register	1113
31.6.14	CRYPTO_IEN - Interrupt Enable Register	1114
31.6.15	CRYPTO_SEQ0 - Sequence Register 0	1114
31.6.16	CRYPTO_SEQ1 - Sequence Register 1	1115
31.6.17	CRYPTO_SEQ2 - Sequence Register 2	1115
31.6.18	CRYPTO_SEQ3 - Sequence Register 3	1116
31.6.19	CRYPTO_SEQ4 - Sequence Register 4	1116
31.6.20	CRYPTO_DATA0 - DATA0 Register Access (No Bit Access) (Actionable Reads)	1117
31.6.21	CRYPTO_DATA1 - DATA1 Register Access (No Bit Access) (Actionable Reads)	1117

31.6.22	CRYPTO_DATA2 - DATA2 Register Access (No Bit Access) (Actionable Reads)	1118
31.6.23	CRYPTO_DATA3 - DATA3 Register Access (No Bit Access) (Actionable Reads)	1118
31.6.24	CRYPTO_DATA0XOR - DATA0XOR Register Access (No Bit Access) (Actionable Reads)	1119
31.6.25	CRYPTO_DATA0BYTE - DATA0 Register Byte Access (No Bit Access) (Actionable Reads)	1119
31.6.26	CRYPTO_DATA1BYTE - DATA1 Register Byte Access (No Bit Access) (Actionable Reads)	1120
31.6.27	CRYPTO_DATA0XORBYTE - DATA0 Register Byte XOR Access (No Bit Access) (Actionable Reads)	1120
31.6.28	CRYPTO_DATA0BYTE12 - DATA0 Register Byte 12 Access (No Bit Access)	1121
31.6.29	CRYPTO_DATA0BYTE13 - DATA0 Register Byte 13 Access (No Bit Access)	1121
31.6.30	CRYPTO_DATA0BYTE14 - DATA0 Register Byte 14 Access (No Bit Access)	1122
31.6.31	CRYPTO_DATA0BYTE15 - DATA0 Register Byte 15 Access (No Bit Access)	1122
31.6.32	CRYPTO_DDATA0 - DDATA0 Register Access (No Bit Access) (Actionable Reads)	1123
31.6.33	CRYPTO_DDATA1 - DDATA1 Register Access (No Bit Access) (Actionable Reads)	1123
31.6.34	CRYPTO_DDATA2 - DDATA2 Register Access (No Bit Access) (Actionable Reads)	1124
31.6.35	CRYPTO_DDATA3 - DDATA3 Register Access (No Bit Access) (Actionable Reads)	1124
31.6.36	CRYPTO_DDATA4 - DDATA4 Register Access (No Bit Access) (Actionable Reads)	1125
31.6.37	CRYPTO_DDATA0BIG - DDATA0 Register Big Endian Access (No Bit Access) (Actionable Reads)	1125
31.6.38	CRYPTO_DDATA0BYTE - DDATA0 Register Byte Access (No Bit Access) (Actionable Reads)	1126
31.6.39	CRYPTO_DDATA1BYTE - DDATA1 Register Byte Access (No Bit Access) (Actionable Reads)	1126
31.6.40	CRYPTO_DDATA0BYTE32 - DDATA0 Register Byte 32 Access (No Bit Access)	1127
31.6.41	CRYPTO_QDATA0 - QDATA0 Register Access (No Bit Access) (Actionable Reads)	1127
31.6.42	CRYPTO_QDATA1 - QDATA1 Register Access (No Bit Access) (Actionable Reads)	1128
31.6.43	CRYPTO_QDATA1BIG - QDATA1 Register Big Endian Access (No Bit Access) (Actionable Reads)	1128
31.6.44	CRYPTO_QDATA0BYTE - QDATA0 Register Byte Access (No Bit Access) (Actionable Reads)	1129
31.6.45	CRYPTO_QDATA1BYTE - QDATA1 Register Byte Access (No Bit Access) (Actionable Reads)	1129
<b>32. GPIO - General Purpose Input/Output</b>		<b>1130</b>
32.1	Introduction	1130
32.2	Features	1131
32.3	Functional Description	1132
32.3.1	Pin Configuration	1133
32.3.2	EM4 Wake-up	1136
32.3.3	EM4 Retention	1136
32.3.4	Alternate Functions	1137
32.3.5	Interrupt Generation	1137
32.3.6	Output to PRS	1139
32.3.7	Synchronization	1139
32.4	Register Map	1140
32.5	Register Description	1142
32.5.1	GPIO_Px_CTRL - Port Control Register	1142

32.5.2	GPIO_Px_MODEL - Port Pin Mode Low Register . . . . .	1144
32.5.3	GPIO_Px_MODEH - Port Pin Mode High Register . . . . .	1149
32.5.4	GPIO_Px_DOUT - Port Data Out Register . . . . .	1154
32.5.5	GPIO_Px_DOUTTGL - Port Data Out Toggle Register . . . . .	1154
32.5.6	GPIO_Px_DIN - Port Data in Register . . . . .	1155
32.5.7	GPIO_Px_PINLOCKN - Port Unlocked Pins Register . . . . .	1155
32.5.8	GPIO_Px_OVTDIS - Over Voltage Disable for All Modes . . . . .	1156
32.5.9	GPIO_EXTIPSELL - External Interrupt Port Select Low Register . . . . .	1157
32.5.10	GPIO_EXTIPSELH - External Interrupt Port Select High Register . . . . .	1160
32.5.11	GPIO_EXTIPINSELL - External Interrupt Pin Select Low Register . . . . .	1163
32.5.12	GPIO_EXTIPINSELH - External Interrupt Pin Select High Register . . . . .	1166
32.5.13	GPIO_EXTIRISE - External Interrupt Rising Edge Trigger Register . . . . .	1168
32.5.14	GPIO_EXTIFALL - External Interrupt Falling Edge Trigger Register . . . . .	1169
32.5.15	GPIO_EXTILEVEL - External Interrupt Level Register . . . . .	1170
32.5.16	GPIO_IF - Interrupt Flag Register . . . . .	1171
32.5.17	GPIO_IFS - Interrupt Flag Set Register . . . . .	1171
32.5.18	GPIO_IFC - Interrupt Flag Clear Register . . . . .	1172
32.5.19	GPIO_IEN - Interrupt Enable Register . . . . .	1172
32.5.20	GPIO_EM4WUEN - EM4 Wake Up Enable Register . . . . .	1173
32.5.21	GPIO_ROUTEOPEN - I/O Routing Pin Enable Register . . . . .	1174
32.5.22	GPIO_INSENSE - Input Sense Register . . . . .	1175
32.5.23	GPIO_LOCK - Configuration Lock Register . . . . .	1176
<b>33.</b>	<b>APORT - Analog Port . . . . .</b>	<b>1177</b>
33.1	Introduction . . . . .	1177
33.2	Features . . . . .	1177
33.3	Functional Description . . . . .	1178
33.3.1	I/O Pin Considerations . . . . .	1178
33.3.2	APORT ABUS Naming . . . . .	1179
33.3.3	Managing ABUSes . . . . .	1182
<b>34.</b>	<b>CSEN - Capacitive Sense Module . . . . .</b>	<b>1184</b>
34.1	Introduction. . . . .	1184
34.2	Features . . . . .	1185
34.3	Timing . . . . .	1185
34.3.1	Clocks . . . . .	1185
34.3.2	Conversion Triggers . . . . .	1185
34.3.3	Shutdown and Warmup . . . . .	1186
34.4	Conversion Types . . . . .	1186
34.4.1	SAR Conversion Type . . . . .	1186
34.4.2	Delta Modulation Conversion Type . . . . .	1187
34.5	Input Configuration . . . . .	1189
34.6	Converison Modes . . . . .	1189
34.6.1	Single Channel Conversions . . . . .	1190
34.6.2	Scan Conversions . . . . .	1191
34.6.3	Bonded Channel Conversions . . . . .	1192

34.7 Output Data . . . . .	1193
34.8 Low Frequency Noise Filter (Chopping) . . . . .	1194
34.9 Wake on Threshold and Exponential Moving Average . . . . .	1195
34.10 Analog Adjustments . . . . .	1196
34.10.1 Current Reference and Gain . . . . .	1196
34.10.2 Current Drive . . . . .	1196
34.10.3 Reset (Discharge) Timing . . . . .	1196
34.11 DMA Interface . . . . .	1197
34.12 Register Map . . . . .	1198
34.13 Register Description . . . . .	1199
34.13.1 CSEN_CTRL - Control . . . . .	1199
34.13.2 CSEN_TIMCTRL - Timing Control . . . . .	1203
34.13.3 CSEN_CMD - Command . . . . .	1204
34.13.4 CSEN_STATUS - Status . . . . .	1204
34.13.5 CSEN_PRSSEL - PRS Select . . . . .	1205
34.13.6 CSEN_DATA - Output Data . . . . .	1205
34.13.7 CSEN_SCANMASK0 - Scan Channel Mask 0 . . . . .	1206
34.13.8 CSEN_SCANINPUTSEL0 - Scan Input Selection 0 . . . . .	1207
34.13.9 CSEN_SCANMASK1 - Scan Channel Mask 1 . . . . .	1209
34.13.10 CSEN_SCANINPUTSEL1 - Scan Input Selection 1 . . . . .	1210
34.13.11 CSEN_APORTRREQ - APORTR Request Status . . . . .	1212
34.13.12 CSEN_APORTRCONFLICT - APORTR Request Conflict . . . . .	1213
34.13.13 CSEN_CMPTHRESHOLD - Comparator Threshold . . . . .	1214
34.13.14 CSEN_EMA - Exponential Moving Average . . . . .	1214
34.13.15 CSEN_EMACTRL - Exponential Moving Average Control . . . . .	1215
34.13.16 CSEN_SINGLECTRL - Single Conversion Control . . . . .	1216
34.13.17 CSEN_DMBASELINE - Delta Modulation Baseline . . . . .	1217
34.13.18 CSEN_DMCFG - Delta Modulation Configuration . . . . .	1218
34.13.19 CSEN_ANACTRL - Analog Control . . . . .	1219
34.13.20 CSEN_IF - Interrupt Flag . . . . .	1220
34.13.21 CSEN_IFS - Interrupt Flag Set . . . . .	1221
34.13.22 CSEN_IFC - Interrupt Flag Clear . . . . .	1222
34.13.23 CSEN_IEN - Interrupt Enable . . . . .	1223
<b>35. CAN - Controller Area Network . . . . .</b>	<b>1224</b>
35.1 Introduction . . . . .	1224
35.2 Features . . . . .	1225
35.3 Functional Description . . . . .	1225
35.3.1 Operating Modes . . . . .	1225
35.3.2 Message Interface Register Sets . . . . .	1230
35.3.3 Message Object in the Message Memory . . . . .	1230
35.3.4 Management of Message Objects . . . . .	1231
35.3.5 Data Transfer From/to Message RAM . . . . .	1231
35.3.6 Transmission of Messages . . . . .	1231
35.3.7 Acceptance Filtering of Received Messages . . . . .	1231
35.3.8 Receive/Transmit Priority . . . . .	1232

35.3.9 Configuration of a Transmit Object . . . . .	1232
35.3.10 Updating a Transmit Object . . . . .	1233
35.3.11 Configuration of a Receive Object . . . . .	1234
35.3.12 Handling of Received Messages . . . . .	1234
35.3.13 Configuration of a FIFO Buffer . . . . .	1234
35.3.14 Reception of Messages With FIFO Buffers . . . . .	1234
35.3.15 Reading From a FIFO Buffer . . . . .	1235
35.3.16 Handling of Interrupts . . . . .	1235
35.3.17 Configuration of the Bit Timing . . . . .	1235
<b>35.4 Register Map . . . . .</b>	<b>1237</b>
<b>35.5 Register Description . . . . .</b>	<b>1238</b>
35.5.1 CANn_CTRL - Control Register . . . . .	1238
35.5.2 CANn_STATUS - Status Register . . . . .	1239
35.5.3 CANn_ERRCNT - Error Count Register . . . . .	1240
35.5.4 CANn_BITTIMING - Bit Timing Register . . . . .	1241
35.5.5 CANn_INTID - Interrupt Identification Register . . . . .	1242
35.5.6 CANn_TEST - Test Register . . . . .	1243
35.5.7 CANn_BRPE - BRP Extension Register . . . . .	1244
35.5.8 CANn_TRANSREQ - Transmission Request Register . . . . .	1244
35.5.9 CANn_MESSAGEDATA - New Data Register . . . . .	1245
35.5.10 CANn_MESSAGESTATE - Message Valid Register . . . . .	1245
35.5.11 CANn_CONFIG - Configuration Register . . . . .	1246
35.5.12 CANn_IF0IF - Message Object Interrupt Flag Register . . . . .	1246
35.5.13 CANn_IF0IFS - Message Object Interrupt Flag Set Register . . . . .	1247
35.5.14 CANn_IF0IFC - Message Object Interrupt Flag Clear Register . . . . .	1247
35.5.15 CANn_IF0IEN - Message Object Interrupt Enable Register . . . . .	1248
35.5.16 CANn_IF1IF - Status Interrupt Flag Register . . . . .	1248
35.5.17 CANn_IF1IFS - Message Object Interrupt Flag Set Register . . . . .	1249
35.5.18 CANn_IF1IFC - Message Object Interrupt Flag Clear Register . . . . .	1249
35.5.19 CANn_IF1IEN - Status Interrupt Enable Register . . . . .	1250
35.5.20 CANn_ROUTE - I/O Routing Register . . . . .	1251
35.5.21 CANn_MIRx_CMDMASK - Interface Command Mask Register . . . . .	1253
35.5.22 CANn_MIRx_MASK - Interface Mask Register . . . . .	1254
35.5.23 CANn_MIRx_ARB - Interface Arbitration Register . . . . .	1255
35.5.24 CANn_MIRx_CTRL - Interface Message Control Register . . . . .	1256
35.5.25 CANn_MIRx_DATAL - Interface Data a Register . . . . .	1257
35.5.26 CANn_MIRx_DATAH - Interface Data B Register . . . . .	1257
35.5.27 CANn_MIRx_CMDREQ - Interface Command Request Register . . . . .	1258
<b>36. Revision History . . . . .</b>	<b>1259</b>
<b>Appendix 1. Abbreviations . . . . .</b>	<b>1260</b>

# 1. About This Document

## 1.1 Introduction

This document contains reference material for the EFM32 Tiny Gecko 11 devices. All modules and peripherals in the EFM32 Tiny Gecko 11 devices are described in general terms. Not all modules are present in all devices and the feature set for each device might vary. Such differences, including pinout, are covered in the device data sheets and applicable errata documents.

## 1.2 Conventions

### Register Names

Register names are given with a module name prefix followed by the short register name:

TIMERn\_CTRL - Control Register

The "n" denotes the module number for modules which can exist in more than one instance.

Some registers are grouped which leads to a group name following the module prefix:

GPIO\_Px\_DOUT - Port Data Out Register

The "x" denotes the different ports.

### Bit Fields

Registers contain one or more bit fields which can be 1 to 32 bits wide. Bit fields wider than 1 bit are given with start (x) and stop (y) bit [y:x].

Bit fields containing more than one bit are unsigned integers unless otherwise is specified.

Unspecified bit field settings must not be used, as this may lead to unpredictable behaviour.

### Address

The address for each register can be found by adding the base address of the module found in the Memory Map (see [Figure 4.2 System Address Space With Core and Code Space Listing on page 41](#)), and the offset address for the register (found in module Register Map).

### Access Type

The register access types used in the register descriptions are explained in [Table 1.1 Register Access Types on page 29](#).

Table 1.1. Register Access Types

Access Type	Description
R	Read only. Writes are ignored
RW	Readable and writable
RW1	Readable and writable. Only writes to 1 have effect
(R)W1	Sometimes readable. Only writes to 1 have effect. Currently only used for IFC registers (see <a href="#">3.3.1.2 IFC Read-clear Operation</a> )
W1	Read value undefined. Only writes to 1 have effect
W	Write only. Read value undefined.
RWH	Readable, writable, and updated by hardware
RW(nB), RWH(nB), etc.	"(nB)" suffix indicates that register explicitly does not support peripheral bit set or clear (see <a href="#">4.2.2 Peripheral Bit Set and Clear</a> )

Access Type	Description
RW(a), R(a), etc.	"(a)" suffix indicates that register has actionable reads (see <a href="#">5.3.6 Debugger Reads of Actionable Registers</a> )

### Number format

**0x** prefix is used for hexadecimal numbers

**0b** prefix is used for binary numbers

Numbers without prefix are in decimal representation.

### Reserved

Registers and bit fields marked with **reserved** are reserved for future use. These should be written to 0 unless otherwise stated in the Register Description. Reserved bits might be read as 1 in future devices.

### Reset Value

The reset value denotes the value after reset.

Registers denoted with X have unknown value out of reset and need to be initialized before use. Note that read-modify-write operations on these registers before they are initialized results in undefined register values.

### Pin Connections

Pin connections are given with a module prefix followed by a short pin name:

CMU\_CLKOUT1 (Clock management unit, clock output pin number 1)

The location for the pin names given in the module documentation can be found in the device-specific data sheet.

## 1.3 Related Documentation

Further documentation on the EFM32 Tiny Gecko 11 devices and the ARM Cortex-M0+ can be found at the Silicon Labs and ARM web pages:

[www.silabs.com](http://www.silabs.com)

[www.arm.com](http://www.arm.com)

## 2. System Overview

### 2.1 Introduction

The EFM32 MCUs are the world's most energy friendly microcontrollers. With a unique combination of the powerful 32-bit ARM Cortex-M0+, innovative low energy techniques, short wake-up time from energy saving modes, and a wide selection of peripherals, the EFM32 Tiny Gecko 11 microcontroller is well suited for any battery operated application as well as other systems requiring high performance and low-energy consumption.

### 2.2 Features

- **ARMCortex-M0+ CPU Platform**
  - High Performance 32-bit processor @ up to 48 MHz
  - Memory Protection Unit
  - Wake-up Interrupt Controller
- **Flexible Energy Management System**
  - Power routing configurations including integrated DCDC converter
  - Voltage Monitoring and Brown Out Detection
  - State Retention
- **Up to 128 kB Flash**
- **32 kB RAM Data Memory**
- **Up to 67 General Purpose I/O Pins**
  - Configurable push-pull, open-drain, pull-up/down, input filter, drive strength, slew rate
  - Configurable peripheral I/O locations
  - 5 V tolerance on select pins
  - Asynchronous external interrupts
  - Output state retention and wake-up from Shutoff Mode
- **8 Channel Linked Direct Memory Access (LDMA) Controller**
  - Single or linked list of descriptors
  - Supports circular and ping-pong buffers, scatter-gather, looping
  - Sophisticated, flexible flow control for performing complex multi-step operations without CPU intervention
- **Up to 8 Channel Peripheral Reflex System for Autonomous Inter-peripheral Signaling**
- **Integrated LCD Controller for up to 4 × 36 Segments or 8 × 32 Segments in Octaplex Mode**
  - Voltage boost, contrast and autonomous animation
  - Patented low-energy LCD driver
- **CRYPTO Advanced Encryption Standard Accelerator**
  - AES encryption / decryption, with 128 or 256 bit keys
  - Multiple AES modes of operation, including Counter (CTR), Galois/Counter Mode (GCM), Cipher Block Chaining (CBC), Cipher Feedback (CFB) and Output Feedback (OFB).
  - Accelerated SHA-1 and SHA-2
  - Accelerated Elliptic Curve Cryptography (ECC), with binary or prime fields
  - Flexible 256-bit ALU and sequencer
- **True Random Number Generator (TRNG)**
- **Hardware CRC Engine**
  - Single-cycle computation with 8/16/32-bit data and 16-bit (programmable)/32-bit (fixed) polynomial
- **Security Management Unit (SMU)**
  - Fine-grained access control for on-chip peripherals

- **Additional Communication Interfaces**

- CAN Bus Controller
  - Version 2.0A and 2.0B up to 1 Mbps
- Up to 4×Universal Synchronous/Asynchronous Receiver/Transmitter
  - UART/SPI/SmartCard (ISO 7816)/IrDA/I2S/LIN
  - Triple buffered full/half-duplex operation
  - Hardware flow control
  - 4-16 data bits
- 1×Universal Asynchronous Receiver/Transmitter
  - Triple buffered full/half-duplex operation
  - 8-9 data bits
- 1× Low Energy UART
  - Autonomous operation with DMA in Deep Sleep Mode
- 2 ×I<sup>2</sup>C Interface with SMBus support
  - Address recognition in EM3 Stop Mode

- **Timers/Counters**

- 2× 32-bit Timer/Counter
  - 3/4 Compare/Capture/PWM channels
  - Dead-Time Insertion
- 2× 16-bit Timer/Counter
  - 3 Compare/Capture/PWM channels
  - Dead-Time Insertion
- 1×16-bit Low Energy Timer
- 32-bit Ultra Low Energy Timer/Counter (CRYOTIMER) for periodic wake-up from any Energy Mode
- 32-bit Real-Time Counter and Calendar (RTCC)
- 1× 16-bit Pulse Counter
  - Asynchronous pulse counting/quadrature decoding
- 1× Watchdog Timer

- **Backup Power Domain**

- RTCC and retention registers in a separate power domain, available in all energy modes
- Operation from backup battery when main power absent/insufficient

- **Ultra Low Power Precision Analog Peripherals**

- Up to 62 GPIO pins are analog-capable. Flexible analog peripheral-to-pin routing via Analog Port (APORT)
- 1× 12-bit 1 Msamples/s Analog to Digital Converter (ADC)
  - Single ended or differential operation
  - Conversion tailgating for predictable latency
  - On-chip temperature sensor
- 12-bit 500 ksamples/s Digital to Analog Converter (VDAC)
  - 2 single ended channels/1 differential channel
- Up to 4 Operational Amplifiers
  - Supports rail-to-rail inputs and outputs
  - Programmable gain
- 2× Analog Comparator (ACMP)
  - Programmable speed/current
  - Capacitive sensing with up to 8 inputs
- Capacitive Sense Module (CSEN)
  - Robust current-based capacitive sensing with up to 38 inputs and wake-on-touch
- Supply Voltage Monitor (VMON)

- **Ultra Low Power Sensor Interface (LESENSE)**
  - Autonomous sensor monitoring in Deep Sleep Mode
  - Wide range of sensors supported, including LC sensors and capacitive buttons
  - Up to 16 inputs
- **Ultra Efficient Power-on Reset and Brown-Out Detector**
- **Debug Interface**
  - 2-pin Serial Wire Debug interface
  - 4-pin JTAG interface
  - Micro Trace Buffer (MTB)

## 2.3 Block Diagram

A block diagram of EFM32 Tiny Gecko 11 is shown in the figure below. The color indicates peripheral availability in energy modes as described in [2.4 Energy Modes](#).




Figure 2.1. Diagram of EFM32 Tiny Gecko 11

**Note:**






In the block diagram, color indicates availability in different energy modes.

## 2.4 Energy Modes

There are five different Energy Modes (EM0 Active-EM4 Hibernate/Shutoff) in the EFM32 Tiny Gecko 11, see [Table 2.1 Energy Mode Description on page 34](#). The EFM32 Tiny Gecko 11 is designed to achieve a high degree of autonomous operation in low energy modes. The intelligent combination of peripherals, RAM with data retention, DMA, low-power oscillators and short wake-up times, makes it attractive to remain in low energy modes for long periods and thus saving energy consumption.

Throughout this document, the first figure in every module description contains an Energy Mode Indicator that shows in which energy mode(s) the module can operate (see [Table 2.1 Energy Mode Description on page 34](#)).

**Table 2.1. Energy Mode Description**

Energy Mode	Name	Description
	EM0 Active – Energy Mode 0 (Run mode)	In EM0 Active, the CPU is actively running code. All peripherals can also be activated.
	EM1 Sleep – Energy Mode 1 (Sleep Mode)	In EM1 Sleep, the CPU is sleeping in a low-power state. All peripherals, including DMA, PRS, and the memory system are still available.
	EM2 DeepSleep – Energy Mode 2 (Deep Sleep Mode)	In EM2 DeepSleep the high frequency oscillator is turned off, but with the 32.768 kHz oscillator running, selected low energy peripherals (LCD, RTC, LETIMER, PCNT, WDOG, LEUART, I <sup>2</sup> C, ACMP, LESENSE,) are still available, giving a high degree of autonomous operation with very low current consumption and fast wake times. Power-on Reset, Brown-out Detection and full RAM and CPU retention is also included.
	EM3 Stop - Energy Mode 3 (Stop Mode)	In EM3 Stop the low-frequency oscillator is disabled, but there is still full CPU and RAM retention, as well as Power-on Reset, Pin reset EM4 Hibernate/Shutoff wake-up and Brown-out Detector, with very low current consumption. The low-power ACMP, asynchronous external interrupt, PCNT, and I <sup>2</sup> C can quickly wake the device.
	EM4 Hibernate/Shutoff – Energy Mode 4 (Shutoff Mode)	In EM4 Hibernate/Shutoff, the current is extremely low and all chip functionality is turned off except the pin reset, GPIO pin wake-up, GPIO pin retention and the power on reset. All pins are put into their reset state.

## 2.5 Timers

EFM32 Tiny Gecko 11 includes multiple timers as shown in [Table 2.2 EFM32 Tiny Gecko 11 Timers Overview](#) on page 35.



**Table 2.2. EFM32 Tiny Gecko 11 Timers Overview**

Timer	Number of Instances	Typical Clock Source	Overview
RTCC	1	Low frequency (LFXO or LFRCO)	32 bit Real Time Counter and Calendar, typically used to accurately time inactive periods and enable wakeup on compare match.
TIMER	2	High frequency (HFXO or HFRCO)	16 bit general purpose timer.
WTIMER	2	High frequency (HFXO or HFRCO)	32 bit general purpose timer.
SysTick timer	1	High frequency (HFXO or HFRCO) or low frequency (LFXO, LFRCO or ULFRCO)	32 bit SysTick timer integrated in the Cortex-M0+. Typically used as an Operating System timer.
WDOG	1	Low frequency (LFXO, LFRCO or ULFRCO)	Watch dog timer. Once enabled, this module must be periodically accessed. If not, this is considered an error and the EFM32 Tiny Gecko 11 is reset in order to recover the system.
LETIMER	1	Low frequency (LFXO, LFRCO or ULFRCO)	Low energy general purpose timer.
PCNT	1	Low frequency (LFXO, LFRCO or ULFRCO) or external pin	Low energy pulse counter with quadrature mode.
CRYOTIMER	1	Low frequency (LFXO, LFRCO or ULFRCO)	Ultra Low energy 32 bit timer available in all Energy Modes

Advanced interconnect features allows synchronization between timers. This includes:

- Start / stop any high frequency timer synchronized with the RTCC

### 3. System Processor



#### Quick Facts

##### What?

The industry leading Cortex-M0+ processor from ARM is the CPU in the EFM32 Tiny Gecko 11 devices.

##### Why?

The ARM Cortex-M0+ is designed for exceptionally short response time, high code density, and high 32-bit throughput while maintaining a strict cost and power consumption budget.

##### How?

Combined with the ultra low energy peripherals available in EFM32 Tiny Gecko 11 devices, the Cortex-M0+ processor's Harvard architecture, 2 stage pipeline, single cycle instructions, Thumb-2 instruction set support, and fast interrupt handling make it perfect for 8-bit, 16-bit, and 32-bit applications.

#### 3.1 Introduction

The ARM Cortex-M0+ 32-bit RISC processor provides outstanding computational performance and exceptional system response to interrupts while meeting low cost requirements and low power consumption.

The ARM Cortex-M0+ implemented is revision r0p1.


### 3.2 Features

- Harvard architecture
  - Separate data and program memory buses (No memory bottleneck as in a single bus system)
- 2-stage pipeline
- Thumb-2 instruction set
  - Enhanced levels of performance, energy efficiency, and code density
- Single cycle multiply instructions
  - 32-bit multiplication in a single cycle
- 1.08 DMIPS/MHz
- Configurable IRQ-latency
  - Allows developers to select a trade-off between interrupt response time and predictability
- Memory Protection Unit
  - Up to 8 protected memory regions
- 24 bits System Tick Timer for Real Time OS
- Excellent 32-bit migration choice for 8/16 bit architecture based designs
  - Simplified stack-based programmer's model is compatible with traditional ARM architecture and retains the programming simplicity of legacy 8-bit and 16-bit architectures
- Aligned or unaligned data storage and access
  - Contiguous storage of data requiring different byte lengths
  - Data access in a single core access cycle
- Integrated power modes
  - Sleep Now mode for immediate transfer to low power state
  - Sleep on Exit mode for entry into low power state after the servicing of an interrupt
  - Ability to extend power savings to other system components
- Optimized for low latency, nested interrupts

### 3.3 Functional Description

For a full functional description of the ARM Cortex-M0+ implementation in the EFM32 Tiny Gecko 11 family, the reader is referred to the ARM Cortex-M0+ documentation provided by ARM.

### 3.3.1 Interrupt Operation



**Figure 3.1. Interrupt Operation**

The interrupt request (IRQ) lines are connected to the Cortex-M0+. Each of these lines (shown in [Table 3.1 Interrupt Request Lines \(IRQ\) on page 39](#)) is connected to one or more interrupt flags in one or more modules. The interrupt flags are set by hardware on an interrupt condition. It is also possible to set/clear the interrupt flags through the IFS/IFC registers. Each interrupt flag is then qualified with its own interrupt enable bit (IEN register), before being OR'ed with the other interrupt flags to generate the IRQ. A high IRQ line will set the corresponding pending bit (can also be set/cleared with the SETPEND/CLRPEND bits in ISPR0/ICPR0) in the Cortex-M0+ NVIC. The pending bit is then qualified with an enable bit (set/cleared with SETENA/CLRENA bits in ISER0/ICER0) before generating an interrupt request to the core. [Figure 3.1 Interrupt Operation on page 38](#) illustrates the interrupt system. For more information on how the interrupts are handled inside the Cortex-M0+, the reader is referred to the **ARM Cortex-M0+ Technical Reference Manual**.

The EFM32TG11 devices have a CortexM0+ which has only 32 interrupts, but the system has 40 module interrupts. Some interrupt sources are merged to share a single CortexM0+ interrupt. CRYPTO/TRNG module interrupts merged to a single interrupt, USART\*\_RX, USART\*\_TX module interrupts merged to single interrupt and UART0\_RX, UART0\_TX module interrupts are merged to single interrupt source.

#### 3.3.1.1 Avoiding Extraneous Interrupts

There can be latencies in the system such that clearing an interrupt flag could take longer than leaving an Interrupt Service Routine (ISR). This can lead to the ISR being re-entered as the interrupt flag has yet to clear immediately after leaving the ISR. To avoid this, when clearing an interrupt flag at the end of an ISR, the user should execute ARM's Data Synchronization Barrier (DSB) instruction. Another approach is to clear the interrupt flag immediately after identifying the interrupt source and then service the interrupt as shown in the pseudo-code below. The ISR typically is sufficiently long to more than cover the few cycles it may take to clear the interrupt status, and also allows the status to be checked for further interrupts before exiting the ISR.

```
irqXServiceRoutine() {
    do {
        clearIrqXstatus();
        serviceIrqX();
    } while(irqXStatusIsActive());
}
```

#### 3.3.1.2 IFC Read-clear Operation



In addition to the normal interrupt setting and clearing operations via the IFS/IFC registers, there is an additional atomic Read-clear operation that can be enabled by setting IFCREADCLEAR=1 in the MSC\_CTRL register. When enabled, reads of peripheral IFC registers will return the interrupt vector (mirroring the IF register), while at the same time clearing whichever interrupt flags are set. This operation is functionally equivalent to reading the IF register and then writing the result immediately back to the IFC register.

### 3.3.2 Interrupt Request Lines (IRQ)

**Table 3.1. Interrupt Request Lines (IRQ)**

IRQ #	Source(s)
0	EMU
1	WDOG0
2	LDMA
3	GPIO_EVEN
4	SMU
5	TIMER0
6	USART0
7	ACMP0 ACMP1
8	ADC0
9	I2C0
10	I2C1
11	GPIO_ODD
12	TIMER1
13	USART1
14	USART2
15	UART0
16	LEUART0
17	LETIMER0
18	PCNT0
19	RTCC
20	CMU
21	MSC
22	CRYPTO0 TRNG0
23	CRYOTIMER
24	USART3
25	WTIMER0
26	WTIMER1
27	VDAC0
28	CSEN
29	LESENSE
30	LCD
31	CAN0

## 4. Memory and Bus System



### Quick Facts

#### What?

A low latency memory system including low energy Flash and RAM with data retention which makes the energy modes attractive.

#### Why?

RAM retention reduces the need for storing data in Flash and enables frequent use of the ultra low energy modes EM2 DeepSleep and EM3 Stop.

#### How?

Low energy and non-volatile Flash memory stores program and application data in all energy modes and can easily be reprogrammed in system. Low leakage RAM with data retention in EM0 Active to EM3 Stop removes the data restore time penalty, and the DMA ensures fast autonomous transfers with predictable response time.

### 4.1 Introduction

The EFM32 Tiny Gecko 11 contains an AMBA AHB Bus system to allow bus masters to access the memory mapped address space. A multilayer AHB bus matrix connects the 2 master bus interfaces to the AHB slaves (Figure 4.1 EFM32 Tiny Gecko 11 Bus System on page 40). The bus matrix allows several AHB slaves to be accessed simultaneously. An AMBA APB interface is used for the peripherals, which are accessed through an AHB-to-APB bridge connected to the AHB bus matrix. The 2 AHB bus masters are:

- **Cortex-M0+ ICode:** Used for instruction fetches from Code memory (valid address range: 0x00000000 - 0x1FFFFFFF)
- **Cortex-M0+ DCode:** Used for debug and data access to Code memory (valid address range: 0x00000000 - 0x1FFFFFFF)
- **Cortex-M0+ System:** Used for data and debug access to system space. It can access entire memory space except Code memory (valid address range: 0x20000000 - 0xFFFFFFFF)
- **DMA:** Can access the entire memory space except the internal core memory region and the DMEM code region





Figure 4.1. EFM32 Tiny Gecko 11 Bus System


## 4.2 Functional Description

The memory segments are mapped together with the internal segments of the Cortex-M0+ into the system memory map shown by [Figure 4.2 System Address Space With Core and Code Space Listing on page 41](#).



**Figure 4.2. System Address Space With Core and Code Space Listing**

Additionally, the peripheral address map is detailed by [Figure 4.3 System Address Space With Peripheral Listing on page 42](#).

**Figure 4.3. System Address Space With Peripheral Listing**

The embedded SRAM is located at address 0x20000000 in the memory map of the EFM32 Tiny Gecko 11. When running code located in SRAM starting at this address, the Cortex-M0+ uses the System bus interface to fetch instructions. This results in reduced performance as the Cortex-M0+ accesses stack, other data in SRAM and peripherals using the System bus interface. To be able to run code from SRAM efficiently, the SRAM is also mapped in the code space at address 0x10000000.

The SRAM mapped into the code space can however only be accessed by the CPU and not any other bus masters, e.g. DMA. See [4.5 SRAM](#) for more detailed info on the system SRAM.

#### 4.2.1 Peripheral Non-Word Access Behavior

When writing to peripheral registers, all accesses are treated as 32-bit accesses. This means that writes to a register need to be large enough to cover all bits of register, otherwise, any uncovered bits may become corrupted from the partial-word transfer. Thus, the safest practice is to always do 32-bit writes to peripheral registers.

When reading, there is generally no issue with partial word accesses, however, note that any read action (e.g. FIFO popping) will be triggered regardless of whether the actual FIFO bit-field was included in the transfer size.

**Note:** The implementation of bit-banding in the core is such that bit-band accesses forward the transfer size info into the actual bus transfer size, so the same restrictions apply to bit-band accesses as apply to normal read/write accesses.

#### 4.2.2 Peripheral Bit Set and Clear

The EFM32 Tiny Gecko 11 supports bit set and bit clear access to all peripherals except those listed in [Table 4.1 Peripherals that Do Not Support Bit Set and Bit Clear on page 43](#). The bit set and bit clear functionality (also called Bit Access) enables modification of bit fields (single bit or multiple bit wide) without the need to perform a read-modify-write (though it is functionally equivalent). Also, the operation is contained within a single bus access (for HF peripherals).

The bit clear aliasing region starts at 0x44000000 and the bit set aliasing region starts at 0x46000000. Thus, to apply a bit set or clear operation, write the bit set or clear mask to the following addresses:

`bit_clear_address = address + 0x04000000`

`bit_set_address = address + 0x06000000`

For bit set operations, bit locations that are 1 in the bit mask will be set in the destination register:

`register = (register OR mask)`

For bit clear operations, bit locations that are 1 in the bit mask will be cleared in the destination register:

`register = (register AND (NOT mask))`

**Note:** It is possible to combine bit clear and bit set operations in order to arbitrarily modify multi-bit register fields, without affecting other fields in the same register. In this case, care should be taken to ensure that the field does not have intermediate values that can lead to erroneous behavior. For example, if bit clear and bit set operations are used to change an analog tuning register field from 25 to 26, the field would initially take on a value of zero. If the analog module is active at the time, this could lead to undesired behavior.

The peripherals listed in [Table 4.1 Peripherals that Do Not Support Bit Set and Bit Clear on page 43](#) do not support Bit Access for any registers. All other peripherals do support Bit Access, however, there may be cases of certain registers that do not support it. Such registers have a note regarding this lack of support.

**Table 4.1. Peripherals that Do Not Support Bit Set and Bit Clear**

Module
EMU
RMU
CAN0
CRYOTIMER
TRNG0

#### 4.2.3 Peripherals

The peripherals are mapped into the peripheral memory segment, each with a fixed size address range according to [Table 4.2 Peripherals on page 44](#), [Table 4.3 Low Energy Peripherals on page 44](#), and [Table 4.4 Core Peripherals on page 45](#).

**Table 4.2. Peripherals**

Address Range	Module Name
0x400E6000 - 0x400E6400	PRS
0x4008F000 - 0x4008F400	CRYOTIMER
0x4008E000 - 0x4008E400	CSEN
0x40089400 - 0x40089800	I2C1
0x40089000 - 0x40089400	I2C0
0x40088000 - 0x40089000	GPIO
0x40086000 - 0x40086400	VDAC0
0x40082000 - 0x40082400	ADC0
0x40080400 - 0x40080800	ACMP1
0x40080000 - 0x40080400	ACMP0
0x40020000 - 0x40020400	SMU
0x4001D000 - 0x4001D400	TRNG0
0x4001C000 - 0x4001C400	GPCRC
0x4001A400 - 0x4001A800	WTIMER1
0x4001A000 - 0x4001A400	WTIMER0
0x40018400 - 0x40018800	TIMER1
0x40018000 - 0x40018400	TIMER0
0x40014000 - 0x40014400	UART0
0x40010C00 - 0x40011000	USART3
0x40010800 - 0x40010C00	USART2
0x40010400 - 0x40010800	USART1
0x40010000 - 0x40010400	USART0
0x40004000 - 0x40004400	CAN0

**Table 4.3. Low Energy Peripherals**

Address Range	Module Name
0x4006E000 - 0x4006E400	PCNT0
0x4006A000 - 0x4006A400	LEUART0
0x40066000 - 0x40066400	LETIMER0
0x40062000 - 0x40062400	RTCC
0x40055000 - 0x40055400	LESENSE
0x40054000 - 0x40054400	LCD
0x40052000 - 0x40052400	WDOG0

**Table 4.4. Core Peripherals**

Address Range	Module Name
0xF0040000 - 0xF0080000	MTB
0xE0000000 - 0xE0040000	CM0P
0x400F0000 - 0x400F0400	CRYPTO0
0x40002000 - 0x40003000	LDMA
0x40000000 - 0x40000800	MSC

#### 4.2.4 Bus Matrix

The Bus Matrix connects the memory segments to the bus masters as detailed in [4.1 Introduction](#).

##### 4.2.4.1 Arbitration

The Bus Matrix uses a round-robin arbitration algorithm which enables high throughput and low latency, while starvation of simultaneous accesses to the same bus slave are eliminated. Round-robin does not assign a fixed priority to each bus master. The arbiter does not insert any bus wait-states during peak interaction. However, one wait state is inserted for master accesses occurring after a prolonged inactive time. This wait state allows for increased power efficiency during master idle time.

##### 4.2.4.2 Peripheral Access Performance

The Bus Matrix is a multi-layer energy optimized AMBA AHB compliant bus with an internal bandwidth of 2x a single AHB interface.

The Cortex-M0+, DMA Controller, and peripherals (not peripherals in the low frequency clock domain) run on clocks which can be pre-scaled separately. Clocks and prescaling are described in more detail in [10. CMU - Clock Management Unit](#). This section describes the expected bus wait states for a peripheral based on its frequency relative to the HFCLK frequency. For this discussion, PERCLK refers to a selected peripheral's clock frequency, which is some integer division of the HFCLK frequency.

#### 4.2.4.2.1 WS0 Mode

In general, when accessing a peripheral, the latency in number of HFCLK cycles, not including master arbitration, is given by:

$$N_{bus\ cycles} = N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK}, \text{ best-case write accesses}$$

$$N_{bus\ cycles} = N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK} + 1, \text{ best-case read accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK} - 1, \text{ worst-case write accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK}, \text{ worst-case read accesses}$$

where  $N_{slave\ cycles}$  is the throughput of the slave's bus interface in number of PERCLK cycles per transfer, including any wait cycles introduced by the slave.

**Figure 4.4. Bus Access Latency (General Case)**

Note that a latency of **1** cycle corresponds to **0** wait states.

Additionally, for back-to-back accesses to the same peripheral, the throughput in number of cycles per transfer is given by:

$$N_{bus\ cycles} = N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK}, \text{ write accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK}, \text{ read accesses}$$

**Figure 4.5. Bus Access Throughput (Back-to-Back Transfers)**

Lastly, in the highest performing case, where PERCLK equals HFCLK and the slave does not introduce any additional wait states, the access latency in number of cycles is given by:

$$N_{bus\ cycles} = 1, \text{ write accesses}$$

$$N_{bus\ cycles} = 2, \text{ read accesses}$$

**Figure 4.6. Bus Access Latency (Max Performance)**

#### 4.2.4.2.2 WS1 Mode

In general, when accessing a peripheral, the latency in number of HFCLK cycles, not including master arbitration, is given by:

$$N_{bus\ cycles} = N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK} + 2, \text{ best-case write accesses}$$

$$N_{bus\ cycles} = N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK} + 1, \text{ best-case read accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK} + 1, \text{ worst-case write accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK}, \text{ worst-case read accesses}$$

where  $N_{slave\ cycles}$  is the throughput of the slave's bus interface in number of PERCLK cycles per transfer, including any wait cycles introduced by the slave.

**Figure 4.7. Bus Access Latency (General Case)**

Note that a latency of **1** cycle corresponds to **0** wait states.

Additionally, for back-to-back accesses to the same peripheral, the throughput in number of cycles per transfer is given by:

$$N_{bus\ cycles} = \max\{f_{HFCLK}/f_{PERCLK}, 2\} + N_{slave\ cycles} \times f_{HFCLK}/f_{PERCLK}, \text{ write accesses}$$

$$N_{bus\ cycles} = (N_{slave\ cycles} + 1) \times f_{HFCLK}/f_{PERCLK}, \text{ read accesses}$$

**Figure 4.8. Bus Access Throughput (Back-to-Back Transfers)**

Lastly, in the highest performing case, where PERCLK equals HFCLK and the slave does not introduce any additional wait states, the access latency in number of cycles is given by:

$$N_{bus\ cycles} = 3, \text{ write accesses}$$

$$N_{bus\ cycles} = 2, \text{ read accesses}$$

**Figure 4.9. Bus Access Latency (Max Performance)**

#### 4.2.4.2.3 Core Access Latency

Note that the cycle counts in the equations above is in terms of the HFCLK. When the core is prescaled from the bus clock, the core will see a reduced number of latency cycles given by:

$$N_{core\ cycles} = \text{ceiling}(N_{bus\ cycles} \times f_{HFCoreCLK}/f_{HFCLK})$$

where master arbitration is not included.

**Figure 4.10. Core Access Latency**

#### 4.2.4.3 Bus Faults

System accesses from the core can receive a bus fault in the following condition(s):

- The core attempts to access an address that is not assigned to any peripheral or other system device. These faults can be enabled or disabled by setting the ADDRFAULTEN bit appropriately in MSC\_CTRL.
- The core attempts to access a peripheral or system device that has its clock disabled. These faults can be enabled or disabled by setting the CLKDISFAULTEN bit appropriately in MSC\_CTRL.
- The bus times out during an access. For example, this could happen while trying to synchronize volatile read data during an LE peripheral access. See [10.3.1.1 HFCLK - High Frequency Clock](#). These faults can be enabled or disabled by setting the TIMEOUTFAULTEN bit appropriately in MSC\_CTRL.

In addition to any condition-specific bus fault control bits, the bus fault interrupt itself can be enabled or disabled in the same way as all other internal core interrupts.

**Note:** The icache flush is not triggered at the event of a bus fault. As a result, when an instruction fetch results in a bus fault, invalid data may be cached. This means that the next time the instruction that caused the bus fault is fetched, the processor core will get the invalid cached data without any bus fault. In order to avoid invalid cached data propagation to the processor core, software should manually invalidate cache by writing 1 to MSC\_CMD\_INVCACHE bitfield at the event of a bus fault.

### 4.3 Access to Low Energy Peripherals (Asynchronous Registers)

The Low Energy Peripherals are capable of running when the high frequency oscillator and core system is powered off, i.e. in energy mode EM2 DeepSleep and in some cases also EM3 Stop. This enables the peripherals to perform tasks while the system energy consumption is minimal.

The Low Energy Peripherals are listed in [Table 4.3 Low Energy Peripherals on page 44](#).

All Low Energy Peripherals are memory mapped, with automatic data synchronization. Because the Low Energy Peripherals are running on clocks asynchronous to the high frequency system clock, there are some constraints on how register accesses are performed, as described in the following sections.

#### 4.3.1 Writing

Every Low Energy Peripheral has one or more registers with data that needs to be synchronized into the Low Energy clock domain to maintain data consistency and predictable operation. There are two different synchronization mechanisms on the EFM32TG11, immediate synchronization, and delayed synchronization. Immediate synchronization is available for the RTCC, LESENSE and LETIMER, and results in an immediate update of the target registers. Delayed synchronization is used for the remaining Low Energy Peripherals, and for these peripherals, a write operation requires 3 positive edges of the clock on the Low Energy Peripheral being accessed. Registers requiring synchronization are marked "Async Reg" in their description header.

**Note:** On the Gecko series of devices, all LE peripherals are subject to delayed synchronization.





Figure 4.11. Write Operation to Low Energy Peripherals

#### 4.3.1.1 Delayed Synchronization

After writing data to a register which value is to be synchronized into the Low Energy Peripheral using delayed synchronization, a corresponding busy flag in the <module\_name>\_SYNCBUSY register (e.g. LETIMER\_SYNCBUSY) is set. This flag is set as long as synchronization is in progress and is cleared upon completion.

**Note:** Subsequent writes to the same register before the corresponding busy flag is cleared is not supported. Write before the busy flag is cleared may result in undefined behavior. In general the SYNCBUSY register only needs to be observed if there is a risk of multiple write access to a register (which must be prevented). It is not required to wait until the relevant flag in the SYNCBUSY register is cleared after writing a register. E.g., EM2 DeepSleep can be entered directly after writing a register.

See [Figure 4.12 Write Operation to Low Energy Peripherals on page 50](#) for an overview of the writing mechanism operation.



**Figure 4.12. Write Operation to Low Energy Peripherals**

#### 4.3.1.2 Immediate Synchronization

In contrast to the peripherals with delayed synchronization, peripherals with immediate synchronization do not experience a register write delay for most registers. Registers are updated immediately on the peripheral write access. If such a write is done close to an edge on the clock of the peripheral, the write can be delayed until after that clock edge. This will introduce wait-states on the peripheral access.

One exception is made for commands (writing to the CMD register) in peripherals with immediate synchronization. Peripherals with immediate synchronization each have a SYNCBUSY register with a bit for the CMD register status. Commands written to a peripheral with immediate synchronization are not executed before the first peripheral clock after the write. In this period, the SYNCBUSY flag for the command register is set, indicating that the command has not yet been performed.


To maintain compatibility with earlier Gecko series, the SYNCBUSY register reserves placeholders where other register synchronization bits resided. These bits always read 0, indicating that register writes are always safe.

**Note:** If compatibility with earlier Gecko series is a requirement for a given application, the rules that apply to delayed synchronization with respect to SYNCBUSY should also be followed for the peripherals that support immediate synchronization.

#### 4.3.2 Reading

When reading from a Low Energy Peripheral, the data read is synchronized regardless if it originates in the Low Energy clock domain or High Frequency clock domain. See [Figure 4.13 Read Operation From Low Energy Peripherals on page 51](#) for an overview of the reading operation.

**Note:** Writing a register and then immediately reading the new value of the register may give the impression that the write operation is complete. This may not be the case. Refer to the SYNCBUSY register for correct status of the write operation to the Low Energy Peripheral.



**Figure 4.13. Read Operation From Low Energy Peripherals**

#### 4.3.3 FREEZE Register

In all Low Energy Peripheral with delayed synchronization there is a <module\_name>\_FREEZE register (e.g. RTCC\_FREEZE). The register contains a bit named REGFREEZE. If precise control of the synchronization process is required, this bit may be utilized. When REGFREEZE is set, the synchronization process is halted allowing the software to write multiple Low Energy registers before starting the synchronization process, thus providing precise control of the module update process. The synchronization process is started by clearing the REGFREEZE bit.

**Note:** The FREEZE register is also present on peripherals with immediate synchronization, but there it has no effect

### 4.4 Flash

The Flash retains data in any state and typically stores the application code, special user data and security information. The Flash memory is typically programmed through the debug interface, but can also be erased and written to from software.

- Up to 128 kB of memory
- Page size of 2 kB (minimum erase unit)
- Minimum 10K erase cycles endurance
- Greater than 10 years data retention at 85 °C
- Lock-bits for memory protection
- Data retention in any state

## 4.5 SRAM

The primary task of the SRAM memory is to store application data. Additionally, it is possible to execute instructions from SRAM, and the DMA may be set up to transfer data between the SRAM, flash and peripherals.

- Up to 32 kB of memory
- Set of RAM blocks may be powered down when not in use
- Data retention of the entire memory in EM0 Active to EM3 Stop

The SRAM memory may be split among two or more different AHB slaves (e.g., RAM0, RAM1, ...) in order to allow simultaneous access to different sections of the memory from two different AHB masters. For example, the Cortex-M0+ can access RAM0 while the DMA controller accesses RAM1 in parallel. See [4.1 Introduction](#) for AHB slave connectivity details.

## 4.6 DI Page Entry Map

The DI page contains production calibration data as well as device identification information. See the peripheral chapters for how each calibration value is to be used with the associated peripheral.

The offset address is relative to the start address of the DI page (see [6.3 Functional Description](#)).

Offset	Name	Type	Description
0x000	CAL	RO	CRC of DI-page and calibration temperature
0x030	CUSTOMINFO	RO	Custom information
0x034	MEMINFO	RO	Flash page size and misc. chip information
0x040	UNIQUEL	RO	Low 32 bits of device unique number
0x044	UNIQUEH	RO	High 32 bits of device unique number
0x048	MSIZE	RO	Flash and SRAM Memory size in kB
0x04C	PART	RO	Part description
0x050	DEVINFOREV	RO	Device information page revision
0x054	EMUTEMP	RO	EMU Temperature Calibration Information
0x060	ADC0CAL0	RO	ADC0 calibration register 0
0x064	ADC0CAL1	RO	ADC0 calibration register 1
0x068	ADC0CAL2	RO	ADC0 calibration register 2
0x06C	ADC0CAL3	RO	ADC0 calibration register 3
0x080	HFRCOCAL0	RO	HFRCO Calibration Register (4 MHz)
0x08C	HFRCOCAL3	RO	HFRCO Calibration Register (7 MHz)
0x098	HFRCOCAL6	RO	HFRCO Calibration Register (13 MHz)
0x09C	HFRCOCAL7	RO	HFRCO Calibration Register (16 MHz)
0x0A0	HFRCOCAL8	RO	HFRCO Calibration Register (19 MHz)
0x0A8	HFRCOCAL10	RO	HFRCO Calibration Register (26 MHz)
0x0AC	HFRCOCAL11	RO	HFRCO Calibration Register (32 MHz)
0x0B0	HFRCOCAL12	RO	HFRCO Calibration Register (38 MHz)
0x0B4	HFRCOCAL13	RO	HFRCO Calibration Register (48 MHz)
0x0E0	AUXHFRCOCAL0	RO	AUXHFRCO Calibration Register (4 MHz)
0x0EC	AUXHFRCOCAL3	RO	AUXHFRCO Calibration Register (7 MHz)
0x0F8	AUXHFRCOCAL6	RO	AUXHFRCO Calibration Register (13 MHz)
0x0FC	AUXHFRCOCAL7	RO	AUXHFRCO Calibration Register (16 MHz)
0x100	AUXHFRCOCAL8	RO	AUXHFRCO Calibration Register (19 MHz)
0x108	AUXHFRCOCAL10	RO	AUXHFRCO Calibration Register (26 MHz)
0x10C	AUXHFRCOCAL11	RO	AUXHFRCO Calibration Register (32 MHz)
0x110	AUXHFRCOCAL12	RO	AUXHFRCO Calibration Register (38 MHz)
0x114	AUXHFRCOCAL13	RO	AUXHFRCO Calibration Register (48 MHz)
0x140	VMONCAL0	RO	VMON Calibration Register 0
0x144	VMONCAL1	RO	VMON Calibration Register 1

Offset	Name	Type	Description
0x148	VMONCAL2	RO	VMON Calibration Register 2
0x168	DCDCLNVCTRL0	RO	DCDC Low-noise VREF Trim Register 0
0x16C	DCDCLPVCTRL0	RO	DCDC Low-power VREF Trim Register 0
0x170	DCDCLPVCTRL1	RO	DCDC Low-power VREF Trim Register 1
0x174	DCDCLPVCTRL2	RO	DCDC Low-power VREF Trim Register 2
0x178	DCDCLPVCTRL3	RO	DCDC Low-power VREF Trim Register 3
0x17C	DCDCLPCMPHYSEL0	RO	DCDC LPCMPHYSEL Trim Register 0
0x180	DCDCLPCMPHYSEL1	RO	DCDC LPCMPHYSEL Trim Register 1
0x184	VDAC0MAINCAL	RO	VDAC0 Cals for Main Path
0x188	VDAC0ALTCAL	RO	VDAC0 Cals for Alternate Path
0x18C	VDAC0CH1CAL	RO	VDAC0 CH1 Error Cal
0x190	OPA0CAL0	RO	OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=1
0x194	OPA0CAL1	RO	OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=1
0x198	OPA0CAL2	RO	OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=1
0x19C	OPA0CAL3	RO	OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=1
0x1A0	OPA0CAL4	RO	OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=0
0x1A4	OPA0CAL5	RO	OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=0
0x1A8	OPA0CAL6	RO	OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=0
0x1AC	OPA0CAL7	RO	OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=0
0x1B0	OPA1CAL0	RO	OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=1
0x1B4	OPA1CAL1	RO	OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=1
0x1B8	OPA1CAL2	RO	OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=1
0x1BC	OPA1CAL3	RO	OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=1
0x1C0	OPA1CAL4	RO	OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=0
0x1C4	OPA1CAL5	RO	OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=0
0x1C8	OPA1CAL6	RO	OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=0
0x1CC	OPA1CAL7	RO	OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=0
0x1D0	OPA2CAL0	RO	OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=1
0x1D4	OPA2CAL1	RO	OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=1
0x1D8	OPA2CAL2	RO	OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=1
0x1DC	OPA2CAL3	RO	OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=1
0x1E0	OPA2CAL4	RO	OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=0
0x1E4	OPA2CAL5	RO	OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=0
0x1E8	OPA2CAL6	RO	OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=0
0x1EC	OPA2CAL7	RO	OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=0
0x1F0	OPA3CAL0	RO	OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=1
0x1F4	OPA3CAL1	RO	OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=1

Offset	Name	Type	Description
0x1F8	OPA3CAL2	RO	OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=1
0x1FC	OPA3CAL3	RO	OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=1
0x200	OPA3CAL4	RO	OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=0
0x204	OPA3CAL5	RO	OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=0
0x208	OPA3CAL6	RO	OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=0
0x20C	OPA3CAL7	RO	OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=0
0x210	CSENGAINCAL	RO	Cap Sense Gain Adjustment

## 4.7 DI Page Entry Description

### 4.7.1 CAL - CRC of DI-page and calibration temperature

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Access	RO												RO																		
Name	TEMP												CRC																		
Bit	Name												Access												Description						
31:24	Reserved												Reserved for future use																		
23:16	TEMP												RO												Calibration temperature as an usigned int in DegC (25 = 25DegC)						
15:0	CRC												RO												CRC of DI-page (CRC-16-CCITT)						

### 4.7.2 CUSTOMINFO - Custom information

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Access	RO												RO																		
Name	PARTNO												RO																		
Bit	Name												Access												Description						
31:16	PARTNO												RO												Custom part identifier as unsigned integer (e.g. 903) 65535 for standard product						
15:0	Reserved												RO												Reserved for future use						

## 4.7.3 MEMINFO - Flash page size and misc. chip information

Offset	Bit Position																																					
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Name	FLASH_PAGE_SIZE				RO				RO				RO				RO				RO				TEMPGRADE													
Bit	Name						Access				Description																											
31:24	FLASH_PAGE_SIZE						RO				Flash page size in bytes coded as $2 ^ ((MEM\_INFO\_FLASH\_PAGE\_SIZE + 10) \& 0xFF)$ . I.e. the value 0xFF = 512 bytes.																											
23:16	PINCOUNT						RO				Device pin count as unsigned integer (eg. 48)																											
15:8	PKGTYPE						RO				Package Identifier as character																											
	Value						Mode				Description																											
	74						WLCSP				WLCSP package																											
	76						BGA				BGA package																											
	77						QFN				QFN package																											
	81						QFP				QFP package																											
7:0	TEMPGRADE						RO				Temperature Grade of product as unsigned integer enumeration																											
	Value						Mode				Description																											
	0						N40TO85				-40 to 85degC																											
	1						N40TO125				-40 to 125degC																											
	2						N40TO105				-40 to 105degC																											
	3						N0TO70				0 to 70degC																											

**4.7.4 UNIQUEL - Low 32 bits of device unique number**

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RO																															
Name	UNIQUEL																															

Bit	Name	Access	Description
31:0	UNIQUEL	RO	Low 32 bits of device unique number

**4.7.5 UNIQUEH - High 32 bits of device unique number**

Offset	Bit Position																															
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RO																															
Name	UNIQUEH																															

Bit	Name	Access	Description
31:0	UNIQUEH	RO	High 32 bits of device unique number

**4.7.6 MSIZE - Flash and SRAM Memory size in kB**

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RO																															
Name	SRAM																															

Bit	Name	Access	Description
31:16	SRAM	RO	Ram size, kbyte count as unsigned integer (eg. 16)
15:0	FLASH	RO	Flash size, kbyte count as unsigned integer (eg. 128)

## 4.7.7 PART - Part description

Offset	Bit Position																															
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RO				RO																				RO							
Name	PROD_REV				DEVICE_FAMILY																				DEVICE_NUMBER	RO						

Bit	Name	Access	Description
31:24	PROD_REV	RO	Production revision as unsigned integer
23:16	DEVICE_FAMILY	RO	Device Family

Value	Mode	Description
16	EFR32MG1P	EFR32 Mighty Gecko Family Series 1 Device Config 1
17	EFR32MG1B	EFR32 Mighty Gecko Family Series 1 Device Config 1
18	EFR32MG1V	EFR32 Mighty Gecko Family Series 1 Device Config 1
19	EFR32BG1P	EFR32 Blue Gecko Family Series 1 Device Config 1
20	EFR32BG1B	EFR32 Blue Gecko Family Series 1 Device Config 1
21	EFR32BG1V	EFR32 Blue Gecko Family Series 1 Device Config 1
25	EFR32FG1P	EFR32 Flex Gecko Family Series 1 Device Config 1
26	EFR32FG1B	EFR32 Flex Gecko Family Series 1 Device Config 1
27	EFR32FG1V	EFR32 Flex Gecko Family Series 1 Device Config 1
28	EFR32MG12P	EFR32 Mighty Gecko Family Series 1 Device Config 2
29	EFR32MG12B	EFR32 Mighty Gecko Family Series 1 Device Config 2
30	EFR32MG12V	EFR32 Mighty Gecko Family Series 1 Device Config 2
31	EFR32BG12P	EFR32 Blue Gecko Family Series 1 Device Config 2
32	EFR32BG12B	EFR32 Blue Gecko Family Series 1 Device Config 2
33	EFR32BG12V	EFR32 Blue Gecko Family Series 1 Device Config 2
37	EFR32FG12P	EFR32 Flex Gecko Family Series 1 Device Config 2
38	EFR32FG12B	EFR32 Flex Gecko Family Series 1 Device Config 2
39	EFR32FG12V	EFR32 Flex Gecko Family Series 1 Device Config 2
40	EFR32MG13P	EFR32 Mighty Gecko Family Series 1 Device Config 3
41	EFR32MG13B	EFR32 Mighty Gecko Family Series 1 Device Config 3
42	EFR32MG13V	EFR32 Mighty Gecko Family Series 1 Device Config 3
43	EFR32BG13P	EFR32 Blue Gecko Family Series 1 Device Config 3
44	EFR32BG13B	EFR32 Blue Gecko Family Series 1 Device Config 3

Bit	Name	Access	Description
45	EFR32BG13V		EFR32 Blue Gecko Family Series 1 Device Config 3
46	EFR32ZG13P		EFR32 Zen Gecko Family Series 1 Device Config 3
49	EFR32FG13P		EFR32 Flex Gecko Family Series 1 Device Config 3
50	EFR32FG13B		EFR32 Flex Gecko Family Series 1 Device Config 3
51	EFR32FG13V		EFR32 Flex Gecko Family Series 1 Device Config 3
52	EFR32MG14P		EFR32 Mighty Gecko Family Series 1 Device Config 4
53	EFR32MG14B		EFR32 Mighty Gecko Family Series 1 Device Config 4
54	EFR32MG14V		EFR32 Mighty Gecko Family Series 1 Device Config 4
55	EFR32BG14P		EFR32 Blue Gecko Family Series 1 Device Config 4
56	EFR32BG14B		EFR32 Blue Gecko Family Series 1 Device Config 4
57	EFR32BG14V		EFR32 Blue Gecko Family Series 1 Device Config 4
58	EFR32ZG14P		EFR32 Zen Gecko Family Series 1 Device Config 4
61	EFR32FG14P		EFR32 Flex Gecko Family Series 1 Device Config 4
62	EFR32FG14B		EFR32 Flex Gecko Family Series 1 Device Config 4
63	EFR32FG14V		EFR32 Flex Gecko Family Series 1 Device Config 4
71	EFM32G		EFM32 Gecko Device Family
72	EFM32GG		EFM32 Giant Gecko Device Family
73	EFM32TG		EFM32 Tiny Gecko Device Family
74	EFM32LG		EFM32 Leopard Gecko Device Family
75	EFM32WG		EFM32 Wonder Gecko Device Family
76	EFM32ZG		EFM32 Zero Gecko Device Family
77	EFM32HG		EFM32 Happy Gecko Device Family
81	EFM32PG1B		EFM32 Pearl Gecko Family Series 1 Device Config 1
83	EFM32JG1B		EFM32 Jade Gecko Family Series 1 Device Config 1
85	EFM32PG12B		EFM32 Pearl Gecko Family Series 1 Device Config 2
87	EFM32JG12B		EFM32 Jade Gecko Family Series 1 Device Config 2
100	EFM32GG11B		EFM32 Giant Gecko Family Series 1 Device Config 1
103	EFM32TG11B		EFM32 Tiny Gecko Family Series 1 Device Config 1
106	EFM32GG12B		EFM32 Giant Gecko Family Series 1 Device Config 2
120	EZR32LG		EZR32 Leopard Gecko Device Family
121	EZR32WG		EZR32 Wonder Gecko Device Family
122	EZR32HG		EZR32 Happy Gecko Device Family
15:0	DEVICE_NUMBER	RO	Part number as unsigned integer (e.g. 233 for EFR32BG1P233F256GM48-B0)

**4.7.8 DEVINFOREV - Device information page revision**

Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																									RO	RO	RO	RO				
Name																									MAJOR	MINOR	RO	RO				

Bit	Name	Access	Description
31:8	Reserved		<i>Reserved for future use</i>
7:5	MAJOR	RO	Major DEVINFO revision as unsigned integer (initially 1)
4:0	MINOR	RO	Minor DEVINFO layout revision as unsigned integer (initially 0)

**4.7.9 EMUTEMP - EMU Temperature Calibration Information**

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																									RO							
Name																										EMUTEMPROOM						

Bit	Name	Access	Description
31:8	Reserved		<i>Reserved for future use</i>
7:0	EMUTEMPROOM	RO	EMU_TEMP temperature reading at room

#### 4.7.10 ADC0CAL0 - ADC0 calibration register 0

Offset	Bit Position							
Access								
Name								
0x060		31	30	29	28	27	26	25
	RO							
GAIN2V5								
		24	23	22	21	20	19	18
NEGSEOFFSET2V5	RO							
OFFSET2V5	RO							
GAIN1V25	RO							
NEGSEOFFSET1V25	RO							
OFFSET1V25	RO							

Bit	Name	Access	Description
31	<i>Reserved</i>		<i>Reserved for future use</i>
30:24	GAIN2V5	RO	Gain for 2.5V reference
23:20	NEGSEOFFSET2V5	RO	Negative single ended offset for 2.5V reference
19:16	OFFSET2V5	RO	Offset for 2.5V reference
15	<i>Reserved</i>		<i>Reserved for future use</i>
14:8	GAIN1V25	RO	Gain for 1.25V reference
7:4	NEGSEOFFSET1V25	RO	Negative single ended offset for 1.25V reference
3:0	OFFSET1V25	RO	Offset for 1.25V reference

## 4.7.11 ADC0CAL1 - ADC0 calibration register 1

Offset	Bit Position																																			
0x064	31	30	29	28	RO	27	26	25	24	23	22	RO	21	20	19	18	17	16	15	14	13	12	RO	11	10	9	8	7	6	5	4	3	2	1	0	
Access					RO							RO											RO													
Name					GAIN5VDIFF					NEGSEOFFSET5VDIFF					OFFSET5VDIFF								GAINVDD													

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:24	GAIN5VDIFF	RO	Gain for for 5V differential reference
23:20	NEGSEOFFSET5VDIFF	RO	Negative single ended offset with for 5V differential reference
19:16	OFFSET5VDIFF	RO	Offset for 5V differential reference
15	Reserved		<i>Reserved for future use</i>
14:8	GAINVDD	RO	Gain for VDD reference
7:4	NEGSEOFFSETVDD	RO	Negative single ended offset for VDD reference
3:0	OFFSETVDD	RO	Offset for VDD reference

#### 4.7.12 ADC0CAL2 - ADC0 calibration register 2

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:24	Reserved		<i>Reserved for future use</i>
23:20	Reserved		<i>Reserved for future use</i>
19:16	Reserved		<i>Reserved for future use</i>
15:8	Reserved		<i>Reserved for future use</i>
7:4	NEGSEOFFSET2XVDD	RO	Negative single ended offset for 2XVDD reference
3:0	OFFSET2XVDD	RO	Offset for 2XVDD reference

#### 4.7.13 ADC0CAL3 - ADC0 calibration register 3

Bit	Name	Access	Description
31:16	<i>Reserved</i>		<i>Reserved for future use</i>
15:4	TEMPREAD1V25	RO	Temperature reading at 1V25 reference
3:0	<i>Reserved</i>		<i>Reserved for future use</i>

#### 4.7.14 HFRCOCAL0 - HFRCO Calibration Register (4 MHz)

Bit	Name	Access	Description
31:28	VREFTC	RO	HFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	HFRCO enable reference for fine tuning
26:25	CLKDIV	RO	HFRCO Clock Output Divide
24	LDOHP	RO	HFRCO LDO High Power Mode
23:21	CMPBIAS	RO	HFRCO Comparator Bias Current
20:16	FREQRANGE	RO	HFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	HFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	HFRCO Tuning Value

## 4.7.15 HFRCOCAL3 - HFRCO Calibration Register (7 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC			FINETUNINGEN	RO		CLKDIV	RO	RO	RO																					TUNING	
Bit	Name																													Description		
31:28	VREFTC																												HFRCO Temperature Coefficient Trim on Comparator Reference			
27	FINETUNINGEN																												HFRCO enable reference for fine tuning			
26:25	CLKDIV																												HFRCO Clock Output Divide			
24	LDOHP																												HFRCO LDO High Power Mode			
23:21	CMPBIAS																												HFRCO Comparator Bias Current			
20:16	FREQRANGE																												HFRCO Frequency Range			
15:14	Reserved																												<i>Reserved for future use</i>			
13:8	FINETUNING																												HFRCO Fine Tuning Value			
7	Reserved																												<i>Reserved for future use</i>			
6:0	TUNING																												HFRCO Tuning Value			

## 4.7.16 HFRCOCAL6 - HFRCO Calibration Register (13 MHz)

Offset	Bit Position																																
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Name	VREFTC	FINETUNINGEN	CLKDIV	LDOHP	CMPBIAS	FREQRANGE																										TUNING	RO
31:28	HFRCO Temperature Coefficient Trim on Comparator Reference																																
27	HFRCO enable reference for fine tuning																																
26:25	HFRCO Clock Output Divide																																
24	HFRCO LDO High Power Mode																																
23:21	HFRCO Comparator Bias Current																																
20:16	HFRCO Frequency Range																																
15:14	<i>Reserved for future use</i>																																
13:8	HFRCO Fine Tuning Value																																
7	<i>Reserved for future use</i>																																
6:0	HFRCO Tuning Value																																

#### 4.7.17 HFRCOCAL7 - HFRCO Calibration Register (16 MHz)

Bit	Name	Access	Description
31:28	VREFTC	RO	HFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	HFRCO enable reference for fine tuning
26:25	CLKDIV	RO	HFRCO Clock Output Divide
24	LDOHP	RO	HFRCO LDO High Power Mode
23:21	CMPBIAS	RO	HFRCO Comparator Bias Current
20:16	FREQRANGE	RO	HFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	HFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	HFRCO Tuning Value

#### 4.7.18 HFRCOCAL8 - HFRCO Calibration Register (19 MHz)

Offset	Bit Position							
Access	31	30	29	28	27	26	25	24
Name	VREFTC	RO	RO	FINETUNINGEN	RO	CLKDIV	RO	LDOHP
0x0A0								
FREQRANGE	RO	18	17	16	15	14	13	12
FINETUNING	RO	10	9	8	7	6	5	4
TUNING	RO	3	2	1	0			

Bit	Name	Access	Description
31:28	VREFTC	RO	HFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	HFRCO enable reference for fine tuning
26:25	CLKDIV	RO	HFRCO Clock Output Divide
24	LDOHP	RO	HFRCO LDO High Power Mode
23:21	CMPBIAS	RO	HFRCO Comparator Bias Current
20:16	FREQRANGE	RO	HFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	HFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	HFRCO Tuning Value

## 4.7.19 HFRCOCAL10 - HFRCO Calibration Register (26 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC			FINETUNINGEN	RO		CLKDIV	RO		RO		RO		FREQRANGE																	TUNING	RO
Bit	Name																Description															
31:28	VREFTC																HFRCO Temperature Coefficient Trim on Comparator Reference															
27	FINETUNINGEN																HFRCO enable reference for fine tuning															
26:25	CLKDIV																HFRCO Clock Output Divide															
24	LDOHP																HFRCO LDO High Power Mode															
23:21	CMPBIAS																HFRCO Comparator Bias Current															
20:16	FREQRANGE																HFRCO Frequency Range															
15:14	Reserved																<i>Reserved for future use</i>															
13:8	FINETUNING																HFRCO Fine Tuning Value															
7	Reserved																<i>Reserved for future use</i>															
6:0	TUNING																HFRCO Tuning Value															

## 4.7.20 HFRCOCAL11 - HFRCO Calibration Register (32 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC			FINETUNINGEN	RO		CLKDIV	RO		RO		RO		FREQRANGE																	TUNING	RO
Bit	Name																Description															
31:28	VREFTC																HFRCO Temperature Coefficient Trim on Comparator Reference															
27	FINETUNINGEN																HFRCO enable reference for fine tuning															
26:25	CLKDIV																HFRCO Clock Output Divide															
24	LDOHP																HFRCO LDO High Power Mode															
23:21	CMPBIAS																HFRCO Comparator Bias Current															
20:16	FREQRANGE																HFRCO Frequency Range															
15:14	Reserved																<i>Reserved for future use</i>															
13:8	FINETUNING																HFRCO Fine Tuning Value															
7	Reserved																<i>Reserved for future use</i>															
6:0	TUNING																HFRCO Tuning Value															

## 4.7.21 HFRCOCAL12 - HFRCO Calibration Register (38 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC			FINETUNINGEN	RO		CLKDIV	RO		RO		RO		FREQRANGE																	TUNING	RO
31:28	HFRCO Temperature Coefficient Trim on Comparator Reference																															
27	HFRCO enable reference for fine tuning																															
26:25	HFRCO Clock Output Divide																															
24	HFRCO LDO High Power Mode																															
23:21	HFRCO Comparator Bias Current																															
20:16	HFRCO Frequency Range																															
15:14	Reserved for future use																															
13:8	HFRCO Fine Tuning Value																															
7	Reserved for future use																															
6:0	HFRCO Tuning Value																															

## 4.7.22 HFRCOCAL13 - HFRCO Calibration Register (48 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC			FINETUNINGEN	RO		CLKDIV	RO		RO		RO		FREQRANGE																	TUNING	RO
Bit	Name																Description															
31:28	VREFTC																HFRCO Temperature Coefficient Trim on Comparator Reference															
27	FINETUNINGEN																HFRCO enable reference for fine tuning															
26:25	CLKDIV																HFRCO Clock Output Divide															
24	LDOHP																HFRCO LDO High Power Mode															
23:21	CMPBIAS																HFRCO Comparator Bias Current															
20:16	FREQRANGE																HFRCO Frequency Range															
15:14	Reserved																<i>Reserved for future use</i>															
13:8	FINETUNING																HFRCO Fine Tuning Value															
7	Reserved																<i>Reserved for future use</i>															
6:0	TUNING																HFRCO Tuning Value															

#### 4.7.23 AUXHFRCOCAL0 - AUXHFRCO Calibration Register (4 MHz)

Offset	Bit Position							
Access	31	30	29	28	27	26	25	24
Name	VREFTC	RO	RO	FINETUNINGEN	RO	CLKDIV	RO	LDOHP
0x0E0								
FREQRANGE	RO	18	17	16	15	14	13	12
FINETUNING	RO	10	9	8	7	6	5	4
TUNING	RO	3	2	1	0			

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

## 4.7.24 AUXHFRCOCAL3 - AUXHFRCO Calibration Register (7 MHz)

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	VREFTC	FINETUNINGEN	CLKDIV	LDOHP	CMPBIAS	FREQRANGE	FINETUNING	TUNING																								
31:28	VREFTC																												AUXHFRCO Temperature Coefficient Trim on Comparator Reference			
27	FINETUNINGEN																												AUXHFRCO enable reference for fine tuning			
26:25	CLKDIV																												AUXHFRCO Clock Output Divide			
24	LDOHP																												AUXHFRCO LDO High Power Mode			
23:21	CMPBIAS																												AUXHFRCO Comparator Bias Current			
20:16	FREQRANGE																												AUXHFRCO Frequency Range			
15:14	Reserved																												<i>Reserved for future use</i>			
13:8	FINETUNING																												AUXHFRCO Fine Tuning Value			
7	Reserved																												<i>Reserved for future use</i>			
6:0	TUNING																												AUXHFRCO Tuning Value			

#### 4.7.25 AUXHFRCOCAL6 - AUXHFRCO Calibration Register (13 MHz)

Offset	Bit Position							
Access	31	30	29	28	27	26	25	24
Name	VREFTC	RO	RO	FINETUNINGEN	RO	CLKDIV	RO	LDOHP
0x0F8								
FREQRANGE	RO	18	17	16	15	14	13	12
FINETUNING	RO	10	9	8	7	6	5	4
TUNING	RO	3	2	1	0			

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.26 AUXHFRCOCAL7 - AUXHFRCO Calibration Register (16 MHz)

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.27 AUXHFRCOCAL8 - AUXHFRCO Calibration Register (19 MHz)

#### 4.7.28 AUXHFRCOCAL10 - AUXHFRCO Calibration Register (26 MHz)

Offset	Bit Position							
Access	31	30	29	28	27	26	25	24
Name	VREFTC	RO	RO	FINETUNINGEN	RO	CLKDIV	RO	LDOHP
0x108								
FREQRANGE	RO	18	17	16	15	14	13	12
FINETUNING	RO	10	9	8	7	6	5	4
TUNING	RO	3	2	1	0			

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.29 AUXHFRCO<sub>CAL</sub>11 - AUXHFRCO Calibration Register (32 MHz)

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.30 AUXHFRCO<sub>CAL</sub>12 - AUXHFRCO Calibration Register (38 MHz)

Offset	Bit Position							
Access	31	30	29	28	27	26	25	24
Name	VREFTC	RO	RO	FINETUNINGEN	RO	CLKDIV	RO	LDOHP
0x110								
FREQRANGE	RO	18	17	16	15	14	13	12
FINETUNING	RO	10	9	8	7	6	5	4
TUNING	RO	3	2	1	0			

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.31 AUXHFRCOCAL13 - AUXHFRCO Calibration Register (48 MHz)

Bit	Name	Access	Description
31:28	VREFTC	RO	AUXHFRCO Temperature Coefficient Trim on Comparator Reference
27	FINETUNINGEN	RO	AUXHFRCO enable reference for fine tuning
26:25	CLKDIV	RO	AUXHFRCO Clock Output Divide
24	LDOHP	RO	AUXHFRCO LDO High Power Mode
23:21	CMPBIAS	RO	AUXHFRCO Comparator Bias Current
20:16	FREQRANGE	RO	AUXHFRCO Frequency Range
15:14	<i>Reserved</i>		<i>Reserved for future use</i>
13:8	FINETUNING	RO	AUXHFRCO Fine Tuning Value
7	<i>Reserved</i>		<i>Reserved for future use</i>
6:0	TUNING	RO	AUXHFRCO Tuning Value

#### 4.7.32 VMONCAL0 - VMON Calibration Register 0

Bit	Name	Access	Description
31:28	ALTAVDD2V98THRESCOARSE	RO	ALTAVDD 2.98 V Coarse Threshold Adjust
27:24	ALTAVDD2V98THRESFINE	RO	ALTAVDD 2.98 V Fine Threshold Adjust
23:20	ALTAVDD1V86THRESCOARSE	RO	ALTAVDD 1.86 V Coarse Threshold Adjust
19:16	ALTAVDD1V86THRESFINE	RO	ALTAVDD 1.86 V Fine Threshold Adjust
15:12	AVDD2V98THRESCOARSE	RO	AVDD 2.98 V Coarse Threshold Adjust
11:8	AVDD2V98THRESFINE	RO	AVDD 2.98 V Fine Threshold Adjust
7:4	AVDD1V86THRESCOARSE	RO	AVDD 1.86 V Coarse Threshold Adjust
3:0	AVDD1V86THRESFINE	RO	AVDD 1.86 V Fine Threshold Adjust

#### 4.7.33 VMONCAL1 - VMON Calibration Register 1

## 4.7.34 VMONCAL2 - VMON Calibration Register 2

Offset	Bit Position			
Access	31	30	29	28
Name	FVDD2V98THRESCOARSE	RO	26	27
0x148				
Access	25	24	23	22
Name	FVDD2V98THRESFINE	RO	21	20
Access	19	18	17	16
Name	FVDD1V86THRESCOARSE	RO	17	16
Access	18	17	16	15
Name	FVDD1V86THRESFINE	RO	17	16
Access	14	13	12	11
Name	BUVDD2V98THRESCOARSE	RO	13	12
Access	10	9	8	7
Name	BUVDD2V98THRESFINE	RO	9	8
Access	6	5	4	3
Name	BUVDD1V86THRESCOARSE	RO	5	2
Access	4	3	2	1
Name	BUVDD1V86THRESFINE	RO	1	0

**4.7.35 DCDCLNVCTRL0 - DCDC Low-noise VREF Trim Register 0**

Offset	Bit Position																															
Access	3V0LNATT1								1V8LNATT1								1V2LNATT0								RO							
Name	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

Bit	Name	Access	Description
31:24	3V0LNATT1	RO	DCDC LNVREF Trim for 3.0V output, LNATT=1
23:16	1V8LNATT1	RO	DCDC LNVREF Trim for 1.8V output, LNATT=1
15:8	1V8LNATT0	RO	DCDC LNVREF Trim for 1.8V output, LNATT=0
7:0	1V2LNATT0	RO	DCDC LNVREF Trim for 1.2V output, LNATT=0

**4.7.36 DCDCLPVCTRL0 - DCDC Low-power VREF Trim Register 0**

Offset	Bit Position																															
Access	1V8LPATT0LPCMPBIAS1								1V2LPATT0LPCMPBIAS1								1V8LPATT0LPCMPBIAS0								RO							
Name	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0

Bit	Name	Access	Description
31:24	1V8LPATT0LPCMPBIAS1	RO	DCDC LPVREF Trim for 1.8V output, LPATT=0, LPCMPBIAS=1
23:16	1V2LPATT0LPCMPBIAS1	RO	DCDC LPVREF Trim for 1.2V output, LPATT=0, LPCMPBIAS=1
15:8	1V8LPATT0LPCMPBIAS0	RO	DCDC LPVREF Trim for 1.8V output, LPATT=0, LPCMPBIAS=0
7:0	1V2LPATT0LPCMPBIAS0	RO	DCDC LPVREF Trim for 1.2V output, LPATT=0, LPCMPBIAS=0

#### 4.7.37 DCDCLPVCTRL1 - DCDC Low-power VREF Trim Register 1

#### 4.7.38 DCDCLPVCTRL2 - DCDC Low-power VREF Trim Register 2

**4.7.39 DCDCLPVCTRL3 - DCDC Low-power VREF Trim Register 3**

Offset	Bit Position																															
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name	3V0LPATT1LPCMPBIAS3				1V8LPATT1LPCMPBIAS3				3V0LPATT1LPCMPBIAS2				1V8LPATT1LPCMPBIAS2																			
31:24	3V0LPATT1LPCMPBIAS3	RO	DCDC LPVREF Trim for 3.0V output, LPATT=1, LPCMPBIAS=3																													
23:16	1V8LPATT1LPCMPBIAS3	RO	DCDC LPVREF Trim for 1.8V output, LPATT=1, LPCMPBIAS=3																													
15:8	3V0LPATT1LPCMPBIAS2	RO	DCDC LPVREF Trim for 3.0V output, LPATT=1, LPCMPBIAS=3																													
7:0	1V8LPATT1LPCMPBIAS2	RO	DCDC LPVREF Trim for 1.8V output, LPATT=1, LPCMPBIAS=2																													

**4.7.40 DCDCLPCMPHYSSEL0 - DCDC LPCMPHYSSEL Trim Register 0**

Offset	Bit Position																																
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Name	LPCMPHYSSELLPATT1				LPCMPHYSSELLPATT0																												
31:16	Reserved	Reserved for future use																															
15:8	LPCMPHYSSELLPATT1	RO	DCDC LPCMPHYSSEL Trim, LPATT=1																														
7:0	LPCMPHYSSELLPATT0	RO	DCDC LPCMPHYSSEL Trim, LPATT=0																														

#### 4.7.41 DCDCLPCMPHYSSEL1 - DCDC LPCMPHYSSEL Trim Register 1

#### **4.7.42 VDAC0MAINCAL - VDAC0 Cals for Main Path**

Bit	Name	Access	Description
31:30	Reserved		<i>Reserved for future use</i>
29:24	GAINERRTRIMVDDANAEXTPIN	RO	Gain Error Trim Value for DAC main output using references VDDANA and EXTPIN
23:18	GAINERRTRIM2V5	RO	Gain Error Trim Value for DAC main output using reference 2V5
17:12	GAINERRTRIM1V25	RO	Gain Error Trim Value for DAC main output using reference 1V25
11:6	GAINERRTRIM2V5LN	RO	Gain Error Trim Value for DAC main output using reference 2V5LN
5:0	GAINERRTRIM1V25LN	RO	Gain Error Trim Value for DAC main output using reference 1V25LN

## 4.7.43 VDAC0ALTCAL - VDAC0 Cals for Alternate Path

Offset	Bit Position																																						
Access	31	30	29	28	27	26	25	24	23	22	21	RO	20	19	18	17	16	15	RO	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0					
Name																																							
GAINERRTRIMVDDANAEXTPINALT																																							
GAINERRTRIM2V5ALT																																							
GAINERRTRIM1V25ALT																																							
GAINERRTRIM2V5LNALT																																							
GAINERRTRIM1V25LNALT																																							

Bit	Name	Access	Description
31:30	Reserved		<i>Reserved for future use</i>
29:24	GAINERRTRIMVDDANAEXTPINALT	RO	Gain Error Trim Value for DAC alternative output using references VDDANA and EXTPIN
23:18	GAINERRTRIM2V5ALT	RO	Gain Error Trim Value for DAC alternative output using reference 2V5
17:12	GAINERRTRIM1V25ALT	RO	Gain Error Trim Value for DAC alternative output using reference 1V25
11:6	GAINERRTRIM2V5LNALT	RO	Gain Error Trim Value for DAC alternative output using reference 2V5LN
5:0	GAINERRTRIM1V25LNALT	RO	Gain Error Trim Value for DAC alternative output using reference 1V25LN

## 4.7.44 VDAC0CH1CAL - VDAC0 CH1 Error Cal

Offset	Bit Position																																			
Access	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Name																																				

Bit	Name	Access	Description
31:12	Reserved		<i>Reserved for future use</i>
11:8	GAINERRTRIMCH1B	RO	Gain Error Trim Value for Channel 1 Main Output for references 2V5LN, 2V5
7:4	GAINERRTRIMCH1A	RO	Gain Error Trim Value for Channel 1 Main Output for references 1V25LN, 1V25, VDDANA, EXTPIN
3	Reserved		<i>Reserved for future use</i>
2:0	OFFSETTRIM	RO	Input Buffer Offset Calibration Value for all DAC references

## 4.7.45 OPA0CAL0 - OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=1

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																		CM1			
31	<i>Reserved</i>																									<i>Reserved for future use</i>							
30:26	OFFSETN																									OPA Inverting Input Offset Configuration Value.							
25	<i>Reserved</i>																									<i>Reserved for future use</i>							
24:20	OFFSETP																									OPA Non-Inverting Input Offset Configuration Value.							
19	<i>Reserved</i>																									<i>Reserved for future use</i>							
18:17	GM3																									Gm3 Trim Value							
16	<i>Reserved</i>																									<i>Reserved for future use</i>							
15:13	GM																									Gm Trim Value							
12	<i>Reserved</i>																									<i>Reserved for future use</i>							
11:10	CM3																									Compensation cap Cm3 trim value							
9	<i>Reserved</i>																									<i>Reserved for future use</i>							
8:5	CM2																									Compensation cap Cm2 trim value							
4	<i>Reserved</i>																									<i>Reserved for future use</i>							
3:0	CM1																									Compensation cap Cm1 trim value							

#### 4.7.46 OPA0CAL1 - OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=1

Offset	Bit Position																
Access	NAME	TYPE	OFFSETN	RO	28	29	30	31	0x194	25	26	27	28	29	30	31	
Name	GM3	RO	17	18	19	20	21	22	OFFSETP	23	24	25	26	27	28	29	30
									GM	15	16	17	18	19	20	21	22
									CM3	11	12	13	14	15	16	17	18
									CM2	7	8	9	10	11	12	13	14
									CM1	2	3	4	5	6	7	8	9
										0	1	2	3	4	5	6	7

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.47 OPA0CAL2 - OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.48 OPA0CAL3 - OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.49 OPA0CAL4 - OPA0 Calibration Register for DRIVESTRENGTH 0, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.50 OPA0CAL5 - OPA0 Calibration Register for DRIVESTRENGTH 1, INCBW=0

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																		CM1			
31	<i>Reserved for future use</i>																																
30:26	OFFSETN		RO																														
25	<i>Reserved for future use</i>																																
24:20	OFFSETP		RO																														
19	<i>Reserved for future use</i>																																
18:17	GM3		RO																														
16	<i>Reserved for future use</i>																																
15:13	GM		RO																														
12	<i>Reserved for future use</i>																																
11:10	CM3		RO																														
9	<i>Reserved for future use</i>																																
8:5	CM2		RO																														
4	<i>Reserved for future use</i>																																
3:0	CM1		RO																														

#### 4.7.51 OPA0CAL6 - OPA0 Calibration Register for DRIVESTRENGTH 2, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.52 OPA0CAL7 - OPA0 Calibration Register for DRIVESTRENGTH 3, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.53 OPA1CAL0 - OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.54 OPA1CAL1 - OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=1

Offset	Bit Position																
Access	NAME	TYPE	OFFSETN	RO	28	29	30	31	0x1B4	25	26	27	28	29	30	31	
Name	GM3	RO	17	18	19	20	21	22	RO	OFFSETP	23	24	25	26	27	28	29
									GM	14	15	16	17	18	19	20	
									CM3	10	11	12	13	14	15	16	
									CM2	6	7	8	9	10	11	12	
									CM1	0	1	2	3	4	5	6	

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.55 OPA1CAL2 - OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=1

Offset	Bit Position																
Access	NAME	TYPE	OFFSETN	RO	28	29	30	31	0x1B8	25	26	27	28	29	30	31	
Name	GM3	RO	17	18	19	20	21	22	RO	OFFSETP	23	24	25	26	27	28	29
									GM	14	15	16	17	18	19	20	
									CM3	10	11	12	13	14	15	16	
									CM2	6	7	8	9	10	11	12	
									CM1	0	1	2	3	4	5	6	

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.56 OPA1CAL3 - OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=1

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO							OFFSETP	RO																			CM1			
31	<i>Reserved for future use</i>																																
30:26	OFFSETN		RO																														
25	<i>Reserved for future use</i>																																
24:20	OFFSETP		RO																														
19	<i>Reserved for future use</i>																																
18:17	GM3		RO																														
16	<i>Reserved for future use</i>																																
15:13	GM		RO																														
12	<i>Reserved for future use</i>																																
11:10	CM3		RO																														
9	<i>Reserved for future use</i>																																
8:5	CM2		RO																														
4	<i>Reserved for future use</i>																																
3:0	CM1		RO																														

#### 4.7.57 OPA1CAL4 - OPA1 Calibration Register for DRIVESTRENGTH 0, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.58 OPA1CAL5 - OPA1 Calibration Register for DRIVESTRENGTH 1, INCBW=0

Offset	Bit Position																															
Access		31	30	29	28	27	26	25	24	23	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																CM2	CM1	RO		
31	<i>Reserved for future use</i>																															
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.																													
25	<i>Reserved for future use</i>																															
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.																													
19	<i>Reserved for future use</i>																															
18:17	GM3	RO	Gm3 Trim Value																													
16	<i>Reserved for future use</i>																															
15:13	GM	RO	Gm Trim Value																													
12	<i>Reserved for future use</i>																															
11:10	CM3	RO	Compensation cap Cm3 trim value																													
9	<i>Reserved for future use</i>																															
8:5	CM2	RO	Compensation cap Cm2 trim value																													
4	<i>Reserved for future use</i>																															
3:0	CM1	RO	Compensation cap Cm1 trim value																													

#### 4.7.59 OPA1CAL6 - OPA1 Calibration Register for DRIVESTRENGTH 2, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.60 OPA1CAL7 - OPA1 Calibration Register for DRIVESTRENGTH 3, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.61 OPA2CAL0 - OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=1

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO							OFFSETP	RO																			CM1			
31	<i>Reserved</i>																									<i>Reserved for future use</i>							
30:26	OFFSETN																									OPA Inverting Input Offset Configuration Value.							
25	<i>Reserved</i>																									<i>Reserved for future use</i>							
24:20	OFFSETP																									OPA Non-Inverting Input Offset Configuration Value.							
19	<i>Reserved</i>																									<i>Reserved for future use</i>							
18:17	GM3																									Gm3 Trim Value							
16	<i>Reserved</i>																									<i>Reserved for future use</i>							
15:13	GM																									Gm Trim Value							
12	<i>Reserved</i>																									<i>Reserved for future use</i>							
11:10	CM3																									Compensation cap Cm3 trim value							
9	<i>Reserved</i>																									<i>Reserved for future use</i>							
8:5	CM2																									Compensation cap Cm2 trim value							
4	<i>Reserved</i>																									<i>Reserved for future use</i>							
3:0	CM1																									Compensation cap Cm1 trim value							

#### 4.7.62 OPA2CAL1 - OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.63 OPA2CAL2 - OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.64 OPA2CAL3 - OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.65 OPA2CAL4 - OPA2 Calibration Register for DRIVESTRENGTH 0, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.66 OPA2CAL5 - OPA2 Calibration Register for DRIVESTRENGTH 1, INCBW=0

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																		CM1			
31	<i>Reserved</i>																									<i>Reserved for future use</i>							
30:26	OFFSETN																									OPA Inverting Input Offset Configuration Value.							
25	<i>Reserved</i>																									<i>Reserved for future use</i>							
24:20	OFFSETP																									OPA Non-Inverting Input Offset Configuration Value.							
19	<i>Reserved</i>																									<i>Reserved for future use</i>							
18:17	GM3																									Gm3 Trim Value							
16	<i>Reserved</i>																									<i>Reserved for future use</i>							
15:13	GM																									Gm Trim Value							
12	<i>Reserved</i>																									<i>Reserved for future use</i>							
11:10	CM3																									Compensation cap Cm3 trim value							
9	<i>Reserved</i>																									<i>Reserved for future use</i>							
8:5	CM2																									Compensation cap Cm2 trim value							
4	<i>Reserved</i>																									<i>Reserved for future use</i>							
3:0	CM1																									Compensation cap Cm1 trim value							

#### 4.7.67 OPA2CAL6 - OPA2 Calibration Register for DRIVESTRENGTH 2, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.68 OPA2CAL7 - OPA2 Calibration Register for DRIVESTRENGTH 3, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.69 OPA3CAL0 - OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=1

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																			CM1		
31	<i>Reserved</i>																									<i>Reserved for future use</i>							
30:26	OFFSETN																									OPA Inverting Input Offset Configuration Value.							
25	<i>Reserved</i>																									<i>Reserved for future use</i>							
24:20	OFFSETP																									OPA Non-Inverting Input Offset Configuration Value.							
19	<i>Reserved</i>																									<i>Reserved for future use</i>							
18:17	GM3																									Gm3 Trim Value							
16	<i>Reserved</i>																									<i>Reserved for future use</i>							
15:13	GM																									Gm Trim Value							
12	<i>Reserved</i>																									<i>Reserved for future use</i>							
11:10	CM3																									Compensation cap Cm3 trim value							
9	<i>Reserved</i>																									<i>Reserved for future use</i>							
8:5	CM2																									Compensation cap Cm2 trim value							
4	<i>Reserved</i>																									<i>Reserved for future use</i>							
3:0	CM1																									Compensation cap Cm1 trim value							

## 4.7.70 OPA3CAL1 - OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=1

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																		CM1			
<b>Bit</b>																																	
31	<i>Reserved</i>																																
30:26	OFFSETN																																
25	<i>Reserved</i>																																
24:20	OFFSETP																																
19	<i>Reserved</i>																																
18:17	GM3																																
16	<i>Reserved</i>																																
15:13	GM																																
12	<i>Reserved</i>																																
11:10	CM3																																
9	<i>Reserved</i>																																
8:5	CM2																																
4	<i>Reserved</i>																																
3:0	CM1																																

#### 4.7.71 OPA3CAL2 - OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

#### 4.7.72 OPA3CAL3 - OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=1

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.73 OPA3CAL4 - OPA3 Calibration Register for DRIVESTRENGTH 0, INCBW=0

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO							OFFSETP	RO																			CM1			
31	<i>Reserved</i>																									<i>Reserved for future use</i>							
30:26	OFFSETN																									OPA Inverting Input Offset Configuration Value.							
25	<i>Reserved</i>																									<i>Reserved for future use</i>							
24:20	OFFSETP																									OPA Non-Inverting Input Offset Configuration Value.							
19	<i>Reserved</i>																									<i>Reserved for future use</i>							
18:17	GM3																									Gm3 Trim Value							
16	<i>Reserved</i>																									<i>Reserved for future use</i>							
15:13	GM																									Gm Trim Value							
12	<i>Reserved</i>																									<i>Reserved for future use</i>							
11:10	CM3																									Compensation cap Cm3 trim value							
9	<i>Reserved</i>																									<i>Reserved for future use</i>							
8:5	CM2																									Compensation cap Cm2 trim value							
4	<i>Reserved</i>																									<i>Reserved for future use</i>							
3:0	CM1																									Compensation cap Cm1 trim value							

## 4.7.74 OPA3CAL5 - OPA3 Calibration Register for DRIVESTRENGTH 1, INCBW=0

Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO								OFFSETP	RO																CM2	CM1	RO	RO		
31	<i>Reserved for future use</i>																																
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.																														
25	<i>Reserved for future use</i>																																
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.																														
19	<i>Reserved for future use</i>																																
18:17	GM3	RO	Gm3 Trim Value																														
16	<i>Reserved for future use</i>																																
15:13	GM	RO	Gm Trim Value																														
12	<i>Reserved for future use</i>																																
11:10	CM3	RO	Compensation cap Cm3 trim value																														
9	<i>Reserved for future use</i>																																
8:5	CM2	RO	Compensation cap Cm2 trim value																														
4	<i>Reserved for future use</i>																																
3:0	CM1	RO	Compensation cap Cm1 trim value																														

#### 4.7.75 OPA3CAL6 - OPA3 Calibration Register for DRIVESTRENGTH 2, INCBW=0

Bit	Name	Access	Description
31	Reserved		<i>Reserved for future use</i>
30:26	OFFSETN	RO	OPA Inverting Input Offset Configuration Value.
25	Reserved		<i>Reserved for future use</i>
24:20	OFFSETP	RO	OPA Non-Inverting Input Offset Configuration Value.
19	Reserved		<i>Reserved for future use</i>
18:17	GM3	RO	Gm3 Trim Value
16	Reserved		<i>Reserved for future use</i>
15:13	GM	RO	Gm Trim Value
12	Reserved		<i>Reserved for future use</i>
11:10	CM3	RO	Compensation cap Cm3 trim value
9	Reserved		<i>Reserved for future use</i>
8:5	CM2	RO	Compensation cap Cm2 trim value
4	Reserved		<i>Reserved for future use</i>
3:0	CM1	RO	Compensation cap Cm1 trim value

## 4.7.76 OPA3CAL7 - OPA3 Calibration Register for DRIVESTRENGTH 3, INCBW=0



Offset	Bit Position																																
Access		31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Name		OFFSETN	RO							OFFSETP	RO																				CM1		
<b>Bit</b>																																	
31	<i>Reserved</i>																																
30:26	OFFSETN																																
25	<i>Reserved</i>																																
24:20	OFFSETP																																
19	<i>Reserved</i>																																
18:17	GM3																																
16	<i>Reserved</i>																																
15:13	GM																																
12	<i>Reserved</i>																																
11:10	CM3																																
9	<i>Reserved</i>																																
8:5	CM2																																
4	<i>Reserved</i>																																
3:0	CM1																																

**4.7.77 CSENGAINCAL - Cap Sense Gain Adjustment**

Offset	Bit Position																															
0x210	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																										RO						
Name																										GAINCAL						

Bit	Name	Access	Description
31:8	Reserved		<i>Reserved for future use</i>
7:0	GAINCAL	RO	Gain Adjustment for Cap Sense. Gain should be scaled by GAINCAL/128

## 5. DBG - Debug Interface



### Quick Facts

#### What?

The Debug Interface is used to program and debug EFM32 Tiny Gecko 11 devices.

#### Why?

The Debug Interface makes it easy to re-program and update the system in the field, and allows debugging with minimal I/O pin usage.

#### How?

The Cortex-M0+ supports advanced debugging features. EFM32 Tiny Gecko 11 devices can use a minimum of two port pins for debugging or programming. The internal and external state of the system can be examined with debug extensions supporting instruction or data access break and watch points.

### 5.1 Introduction

The EFM32 Tiny Gecko 11 devices include hardware debug support through a 2-pin serial-wire debug (SWD) interface or a 4-pin Joint Test Action Group (JTAG) interface.

For more technical information about the debug interface the reader is referred to:

- ARM Cortex-M0+ Technical Reference Manual
- ARM CoreSight Components Technical Reference Manual
- ARM Debug Interface v5 Architecture Specification
- IEEE Standard for Test Access Port and Boundary-Scan Architecture, IEEE 1149.1-2013

### 5.2 Features

- Debug Access Port Serial Wire JTAG (DAP SWJ-DP)
  - Implements the ADIv5 debug interface
- Authentication Access Point (AAP)
  - Implements various user commands
- Flash Patch and Breakpoint (FPB) unit
  - Implement breakpoints and code patches
- Data Watch point and Trace (DWT) unit
  - Implement watch points, trigger resources and system profiling

### 5.3 Functional Description

Operation of the available debug interface is described in the following sections.

### 5.3.1 Debug Pins

The following pins are the debug connections for the device:

- Serial Wire Clock Input and Test Clock Input (SWCLKTCK) : This pin is enabled after power-up and has a built-in pull down.
- Serial Wire Data Input/Output and Test Mode Select Input (SWDIOTMS) : This pin is enabled after power-up and has a built-in pull-up.
- Test Data Output (TDO): This pin is assigned to JTAG functionality after power-up. However, it remains in high-Z state until the first valid JTAG command is received.
- Test Data Input (TDI): This pin is assigned to JTAG functionality after power-up. However, it remains in high-Z state until the first valid JTAG command is received. Once enabled, the pin has a built-in pull-up.

The debug pins have pull-down and pull-up enabled by default, so leaving them enabled may increase the current consumption if left connected to supply or ground. The debug pins can be enabled and disabled through GPIO\_ROUTEOPEN, see [32.3.4.2.3 Disabling Debug Connections](#). Remember that upon disabling the debug pins, debug contact with the device is lost once the DAP SWJ-DP power request bits are deasserted. By default after power cycle the part's debug pins are in JTAG mode. If during debugging session the pins are switched to SWD mode, a power cycle is required to bring restore the pins to JTAG mode.

### 5.3.2 Debug and EM2 DeepSleep/EM3 Stop

Leaving the debugger connected when issuing a WFI or WFE to enter EM2 DeepSleep or EM3 Stop will make the system enter a special EM2 DeepSleep. This mode differs from regular EM2 DeepSleep and EM3 Stop in that the high frequency clocks are still enabled, and certain core functionality is still powered in order to maintain debug-functionality. Because of this, the current consumption in this mode is closer to EM1 Sleep and it is therefore important to deassert the power requests in the DAP SWJ-DP and disconnect the debugger before doing current consumption measurements.

### 5.3.3 Authentication Access Point

The Authentication Acces Point (AAP) is a set of registers that provide a minimal amount of debugging and system level commands. The AAP registers contain commands to issue a FLASH erase, a system reset, a CRC of user code pages, and stalling the system bus. The user must program the APSEL bit field to 255 inside of the ARM DAP SWJ Debug Port SELECT register to access the AAP. The AAP is only accessible from a debugger and not from the core.

#### 5.3.3.1 System Bus Stall

The system bus can be stalled at any time using the SYSBUSSTALL register bit. Once the SYSBUSSTALL is set, the system bus will remain stalled until SYSBUSSTALL is cleared. While the system bus is stalled, only the registers inside the Cortex-M0+, AAP and the debugger can be accessed. The SYSBUSSTALL register is available at all times through the AAP.

#### 5.3.3.2 Command Key

The AAP uses a command key to enable the DEVICEERASE and SYSRESETREQ AAP commands. The command key must be written with the correct key in order for the commands to execute.

#### 5.3.3.3 Device Erase

The device can be erased by stalling the system bus, writing AAP\_CMDKEY, and then writing the DEVICEERASE register bit. Upon writing the command bit, the ERASEBUSY bit is asserted. The ERASEBUSY bit will be de-asserted once the erase is complete. The SYSRESETREQ bit must then be set to resume a normal debugger session. The DEVICEERASE register is available at all times through the AAP once the CMDKEY is entered.

#### 5.3.3.4 System Reset

The system can be reset by writing AAP\_CMDKEY followed by writing the SYSRESTREQ register bit. This must be done after asserting DEVICEERASE or CRCREQ. Depending on the reset level setting for system reset, asserting SYSRESETREQ will either reset the entire AAP register space or just the SYSRESETREQ bit. See [8.3.1 Reset Levels](#) for more details on reset levels. The SYSRESETREQ register is available at all times through the AAP once the CMDKEY is enetered.


### 5.3.3.5 User Flash Page CRC

The CRCREQ command initiates a CRC calculation on a given Flash Page. The CRC is only available on the Main, User Data, and Lock Bit pages. It is highly recommended that the system bus is stalled before any CRCREQ commands are issued. The CRC calculation uses the on chip CRC block configured in 32 bit CRC mode. The Flash Page address for the CRCREQ command is written to the CRCADDR register. After issuing the CRCREQ, the CRCBUSY flag is asserted. Once the CRCBUSY flag is de-asserted, the resulting page CRC can be found in the CRCRESULT register. Once issuing a CRC command, the CPU is stalled and remains stalled until a system reset occurs. Multiple CRC requests can occur before resetting the system. However, a CRC request that occurs while the CRCBUSY flag is asserted will be ignored. The CRC registers are available at all times through the AAP.

### 5.3.4 Debug Lock

The debug access to the Cortex-M0+ is locked by clearing the Debug Lock Word (DLW) and resetting the device, see [6.3.2 Lock Bits \(LB\) Page Description](#).

When debug access is locked, the debugger can access the DAP SWJ-DP and AAP registers. However, the connection to the Cortex-M0+ core and the whole bus-system is blocked. This mechanism is controlled by the Authentication Access Port (AAP) as illustrated by [Figure 5.1 AAP - Authentication Access Port on page 128](#).



**Figure 5.1. AAP - Authentication Access Port**

If the DLW is cleared, the device is locked. If the device is locked and the the AAP Lock Word (ALW) has not been cleared, it can be unlocked by writing a valid key to the AAP\_CMDKEY register and then setting the DEVICEERASE bit of the AAP\_CMD register via the debug interface. This operation erases the main block of flash, clears all lock bits, and debug access to the Cortex-M0+ and bus-system is enabled. The operation takes tens of mili seconds to complete. Note that the SRAM contents will also be deleted during a device erase, while the UD-page is not erased.

The debugger may read the status of the device erase from the AAP\_STATUS register. When the ERASEBUSY bit is set low after DEVICEERASE of the AAP\_CMD register is set, the debugger may set the SYSRESETREQ bit in the AAP\_CMD register. After reset, the debugger may resume a normal debug session through the AHB-AP.

### 5.3.5 AAP Lock

Take extreme caution when using this feature. Once the AAP has been locked, the state of the FLASH can not be changed via the debugger.

### 5.3.6 Debugger Reads of Actionable Registers

Some peripheral registers cause particular actions when read, e.g FIFOs which pop and IFC registers which clear the IF flags when read. This can cause problems when debugging and the user wants to read the value without triggering the read action. For this reason, by default, the peripherals will not execute these triggered actions when an attached debugger is performing the read accesses through the AAP. To override this behavior, the debugger can configure the MASTERTYPE bitfield of the Cortex-M0+ AHB Access Port CSW register in order to emulate a core access when performing system bus transfers.

**Note:**

- Registers with actionable reads are noted in their register descriptions. Refer to [Table 1.1 Register Access Types on page 29](#).
- The following peripherals do not respect the debugger master override, and so may still cause their triggered actions to occur (e.g., when reading IFC):
  - CAN

### 5.3.7 Debug Recovery

Debug recovery is the ability to stall the system bus before the Cortex-M0+ executes code. For example, the first few instructions may disconnect the debugger pins. When this occurs it is difficult to connect the debugger and halt the Cortex-M0+ before the Cortex-M0+ starts to execute. By holding down pin reset, issuing the System Bus Stall AAP instruction, then releasing pin reset, the debugger can stall the system bus before the Cortex-M0+ has a chance to execute. Because the system is under reset during this procedure the Debugger can not look for ACK's from the part. Once the system bus is stalled, the FLASH can be erased by issuing the AAP\_CMDKEY and then the writing the DEVICEERASE in the AAP\_CMD register.

## 5.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	AAP_CMD	W1	Command Register
0x004	AAP_CMDKEY	W1	Command Key Register
0x008	AAP_STATUS	R	Status Register
0x00C	AAP_CTRL	RW	Control Register
0x010	AAP_CRCCMD	W1	CRC Command Register
0x014	AAP_CRCSTATUS	R	CRC Status Register
0x018	AAP_CRCADDR	RW	CRC Address Register
0x01C	AAP_CRCRESULT	R	CRC Result Register
0x0FC	AAP_IDR	R	AAP Identification Register

## 5.5 Register Description

### 5.5.1 AAP\_CMD - Command Register

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	SYSRESETREQ	0	W1	<b>System Reset Request</b>  A system reset request is generated when set to 1. This register is write enabled from the AAP_CMDKEY register.
0	DEVICEERASE	0	W1	<b>Erase the Flash Main Block, SRAM and Lock Bits</b>  When set, all data and program code in the main block is erased, the SRAM is cleared and then the Lock Bit (LB) page is erased. This also includes the Debug Lock Word (DLW), causing debug access to be enabled after the next reset. The information block User Data page (UD) is left unchanged, but the User data page Lock Word (ULW) is erased. This register is write enabled from the AAP_CMDKEY register.

### 5.5.2 AAP\_CMDKEY - Command Key Register

Bit	Name	Reset	Access	Description
31:0	WRITEKEY	0x00000000	W1	<b>CMD Key Register</b>
The key value must be written to this register to write enable the AAP_CMD register.				
Value	Mode	Description		
0xCFACC118	WRITEEN	Enable write to AAP_CMD		

**5.5.3 AAP\_STATUS - Status Register**

Offset	Bit Position																																	
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																															0			
Access																															R	0		
Name																																	LOCKED	0
																																	ERASEBUSY	R

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	LOCKED	0	R	<b>AAP Locked</b>  Set when the AAP is locked, .e.g the AAP Lock Word AAP lsb bits are not 0xF
0	ERASEBUSY	0	R	<b>Device Erase Command Status</b>  This bit is set when a device erase is executing.

**5.5.4 AAP\_CTRL - Control Register**

Offset	Bit Position																																			
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset																																	0			
Access																																				
Name																																		SYSBUSSTALL	RW	

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	SYSBUSSTALL	0	RW	<b>Stall the System Bus</b>  When this bit is set, the system bus is stalled. Only the Cortex registers are accessible

**5.5.5 AAP\_CRCCMD - CRC Command Register**

Offset	Bit Position																																CRCREQ	W1	0	
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0			
<b>Reset</b>																																				
<b>Access</b>																																				
<b>Name</b>																																				

Bit	Name	Reset	Access	Description
31:1	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
0	CRCREQ	0	W1	<b>CRC Request</b>

A CRC request is generated when set to 1. This command is not available if debug access or AAP is locked.

**5.5.6 AAP\_CRCSTATUS - CRC Status Register**

Offset	Bit Position																																				
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0				
<b>Reset</b>																																					
<b>Access</b>																																					
<b>Name</b>																																					

Bit	Name	Reset	Access	Description
31:1	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
0	CRCBUSY	0	R	<b>CRC Calculation is Busy</b>

Set when the CRC calculation is executing. Will transition from 1 to 0 on valid data.

**5.5.7 AAP\_CRCADDR - CRC Address Register**

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	CRCADDR																															

Bit	Name	Reset	Access	Description
31:0	CRCADDR	0x00000000	RW	<b>Starting Page Address for CRC Execution</b>
Set this to the address the CRC executes on.				

**5.5.8 AAP\_CRCRESULT - CRC Result Register**

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	CRCRESULT																															


Bit	Name	Reset	Access	Description
31:0	CRCRESULT	0x00000000	R	<b>CRC Result of the CRCADDRESS</b>
Result of the CRC calculation using the CRCADDRESS.				

### 5.5.9 AAP\_IDR - AAP Identification Register

Offset	Bit Position																															
0x0FC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x26E60011																															
Access	R																															
Name	ID																															

Bit	Name	Reset	Access	Description
31:0	ID	0x26E60011	R	<b>AAP Identification Register</b>
Access port identification register in compliance with the ARM ADI v5 specification (JEDEC Manufacturer ID) .				

## 6. MSC - Memory System Controller



```

01000101011011100110010101110010
01100111011110010010000001001101
01101001011000110111001001101111
00100000011100100111010101101100
01100101011100110010000001110100
01101000011001010010000001110111
0110111011100100110110001100100
00100000011011110110011000100000
01101100011011110111011100101101
01100101011011100110010101110010
01100111011110010010000001101101
01101001011000110111001001101111
01100011011011110110111001110100
01110010011011110110110001101100
01100101011100100010000001100100
01100101011100110110100101100111
01101110001000010100010101101110

```

### Quick Facts

#### What?

The user can perform flash memory read, read configuration and write operations through the Memory System Controller (MSC).

#### Why?

The MSC allows the application code, user data and flash lock bits to be stored in non-volatile flash memory. Certain memory system functions, such as program memory wait-states and bus faults are also configured from the MSC peripheral register interface, giving the developer the ability to dynamically customize the memory system performance, security level, energy consumption and error handling capabilities to the requirements at hand.

#### How?

The MSC integrates a low-energy flash IP with a charge pump, enabling minimum energy consumption while eliminating the need for external programming voltage to erase the memory. An easy to use write and erase interface is supported by an internal, fixed-frequency oscillator and autonomous flash timing and control reduces software complexity while not using other timer resources.

Application code may dynamically scale between high energy optimization and high code execution performance through advanced read modes.

A highly efficient low energy instruction cache reduces the number of flash reads significantly, thus saving energy. Performance is also improved when wait-states are used, since many of the wait-states are eliminated. Built-in performance counters can be used to measure the efficiency of the instruction cache.

### 6.1 Introduction

The Memory System Controller (MSC) is the program memory unit of the EFM32 Tiny Gecko 11 microcontroller. The flash memory is readable and writable from both the Cortex-M0+ and DMA. The flash memory is divided into two blocks; the main block and the information block. Program code is normally written to the main block. Additionally, the information block is available for special user data and flash lock bits. There is also a read-only page in the information block containing system and device calibration data, and bootloader. Read and write operations are supported in the energy modes EM0 Active and EM1 Sleep.

## 6.2 Features

- AHB read interface
  - Scalable access performance to optimize the Cortex-M0+ code interface
    - Zero wait-state access up to 25 MHz
    - Advanced energy optimization functionality
      - Instruction Cache
  - DMA read support in EM0 Active and EM1 Sleep
- Command and status interface
  - Flash write and erase
    - Accessible from Cortex-M0+ in EM0 Active
    - DMA write support in EM0 Active and EM1 Sleep
  - Core clock independent flash timing
    - Internal oscillator and internal timers for precise and autonomous flash timing
      - General purpose timers are not occupied during flash erase and write operations
  - Configurable interrupt erase abort
    - Improved interrupt predictability
  - Memory and bus fault control
- Security features
  - Lockable debug access
  - Page lock bits
  - SW mass erase lock bits
  - Authentication Access Port (AAP) lock bits
  - End-of-write and end-of-erase interrupts

### 6.3 Functional Description

The size of the main block is device dependent. The largest size available is 128 kB (64 pages). The information block has 2 kB available for user data. The information block also contains chip configuration data located in a reserved area. The main block is mapped to address 0x00000000 and the information block is mapped to address 0x0FE00000. Table 6.1 MSC Flash Memory Mapping on page 137 outlines how the flash is mapped in the memory space. All flash memory is organized into 2 kB pages.

**Table 6.1. MSC Flash Memory Mapping**

Block	Page	Base address	Write/Erase by...	Software Readable?	Purpose/Name	Size
Main <sup>1</sup>	0	0x00000000	Software, debug	Yes	User code and data	64 kB - 128 kB
	...		Software, debug	Yes		
	63	0x0001F800	Software, debug	Yes		
Reserved	-	0x00040000	-	-	Reserved for flash expansion	~24 MB
Information	0	0x0FE00000	Software, debug	Yes	User Data (UD)	2 kB
	-	0x0FE00800	-	-	Reserved	-
	1	0x0FE04000	Write: Software, debug Erase: Debug only	Yes	Lock Bits (LB)	2 kB
	-	0x0FE04800	-	-	Reserved	-
	2	0x0FE081B0	-	Yes	Device Information (DI)	1 kB
	-	0x0FE08400	-	-	Reserved	-
	2	0x0FE0C000	-	-		1 kB
	-	0x0FE0C400	-	-	Reserved	-
	3	0x0FE10000	Software, debug	Yes	Bootloader (BL)	18 kB
	...		-	-		
	11	0x0FE14000	-	-		
Reserved	-	0x0FE14800	-	Reserved for flash expansion	Rest of code space	-

**Note:**

- 1. Block/page erased by a device erase.

#### 6.3.1 User Data (UD) Page Description

This is the user data page in the information block. The page can be erased and written by software. The page is erased by the ERA-SEPAGE command of the MSC\_WRITECMD register. Note that the page is not erased by a device erase operation. The device erase operation is described in [5.3.3 Authentication Access Point](#).

### 6.3.2 Lock Bits (LB) Page Description

This page contains the following information:

- Main block Page Lock Words (PLWs)
- User data page Lock Word (ULW)
- Debug Lock Word (DLW)
- Mass erase Lock Word (MLW)
- Authentication Access Port (AAP) lock word (ALW)
- Bootloader enable (CLW0)
- Pin reset soft (CLW0)

The words in this page are organized as shown in [Table 6.2 Lock Bits Page Structure on page 138](#):

**Table 6.2. Lock Bits Page Structure**

127	DLW
126	ULW
125	MLW
124	ALW
122	CLW0
N	PLW[N]
...	...
1	PLW[1]
0	PLW[0]

There are 32 page lock bits per page lock word (PLW). Bit 0 refers to the first page and bit 31 refers to the last page within a PLW. Thus, PLW[0] contains lock bits for page 0-31 in the main block, PLW[1] contains lock bits for page 32-63 etc. A page is locked when the bit is 0. A locked page cannot be erased or written.

Word 127 is the debug lock word (DLW). The four LSBs of this word are the debug lock bits. If these bits are 0xF, then debug access is enabled. Debug access to the core is disabled from power-on reset until the DLW is evaluated immediately before the Cortex-M0+ starts execution of the user application code. If the bits are not 0xF, then debug access to the core remains blocked.

Word 126 is the user page lock word (ULW). Bit 0 of this word is the User Data Page lock bit. Bit 1 in this word locks the Lock Bits Page. The lock bits can be reset by a device erase operation initiated from the Authentication Access Port (AAP) registers. The AAP is described in more detail in [5.3.3 Authentication Access Point](#). Note that the AAP is only accessible from the debug interface, and cannot be accessed from the Cortex-M0+ core.

Word 125 is the mass erase lock word (MLW). Bit 0 locks the entire flash. The mass erase lock bits will not have any effect on device erases initiated from the Authentication Access Port (AAP) registers. The AAP is described in more detail in [5.3.3 Authentication Access Point](#).

Word 124 is the Authentication Access Port (AAP) lock word (ALW) and the four LSBs of this word are the lock bits. If these bits are 0xF, then AAP access is enabled. If the bits are not 0xF, AAP is disabled and it is impossible to access the device through the AAP. Bit 31 of the ALW may be used to allow AAP access under controlled conditions. If bit 31 is set to 1, software running on the device can unlock AAP access using the MSC\_AAPUNLOCKCMD register. If bit 31 is cleared to 0, software will not be able to use MSC\_AAPUNLOCKCMD to unlock AAP access. **NOTE - locking the AAP completely (including the LSBs and bit 31) is irreversible. Once the AAP is locked, it will be impossible to perform an external mass erase and the AAP lock cannot be reset.** The only way to program the device when the AAP is locked is through a boot loader or by SW already loaded into the FLASH.

Word 122 is Configuration Lock Word 0 (CLW0). Bit 2 is the Pin Reset Soft bit. By default, a pin reset is handled as a soft reset (See [8.3.5 RESETn Pin Reset](#)). Bit 1 is the bootloader enable bit. Because the state of erased flash bits is 1, the bootloader is enabled by default.

### 6.3.3 Device Information (DI) Page

This read-only page holds calibration data from the production test as well as a unique device ID. The page is further described in [4. Memory and Bus System](#).

### 6.3.4 Bootloader

The system is configured by default to boot from a pre-programmed bootloader automatically after system reset. The bootloader is described in *AN0003: UART Bootloader* ([www.silabs.com/32bit-appnotes](http://www.silabs.com/32bit-appnotes)). Users can bypass the bootloader by clearing bit 1 in Configuration Lock Word 0 (CLW0) at word 122 in the lock bits page.

After any device reset, the bootloader area is accessible to both software reads and writes. Reading and writing of this area may be disabled with the MSC\_BOOTLOADERCTRL register. Note that this register is write-once, so after writing the register, a reset of the system is required in order to change permissions again.

The bootloader size is 18 kB for this device family.

**Note:** Software should never erase "Reserved" pages when bootloader write/erase is enabled. Doing so may cause the device to become non-functional and irrevocably locked.

### 6.3.5 Post-reset Behavior

Calibration values are automatically written to registers by the MSC before application code startup. The values are also available to read from the DI page for later reference by software. Other information such as the device ID and production date is also stored in the DI page and is readable from software.

If the bootloader is not bypassed, the system will boot up from the bootloader at address 0x0FE10000.

### 6.3.6 Flash Startup

On transitions from EM2/3 to EM0, the flash must be powered up. The time this takes depends on the current operating conditions. To have a deterministic startup-time, set STDLY0 in MSC\_STARTUP to 0x64 and clear STDLY1, ASTWAIT, STWSEN and STWS. This will result in a 10 us delay before the flash is ready. The system will wake up before this, but the Cortex will stall on the first access to the flash until it is ready. Execute code from RAM or cache to get a quicker startup.

To get the fastest possible startup when waking, i.e. a startup that depends on the current operating conditions, set STDLY0 to 0x28 and set ASTWAIT in MSC\_STARTUP. When configured this way, the system will poll the flash to determine when it is ready, and then start execution.

For even quicker startup, run code in beginning with a set of wait-states. Set STDLY0 to 0x32, STDLY1 to 0x32, and set ASTWAIT and STWSEN. Then configure STWS in MSC\_STARTUP to the number of waitstates to run with. With this setup, sampling will begin with the given number of waitstates after 5 us, and the system will run with this number of waitstates for the remaining 5 us before returning to normal operation.

A recommended setting for MSC\_STARTUP register is to leave STDLY0 at its reset value and set ASTWAIT to one for active sampling. Set STWSEN to zero to bypass the second delay period.

Flash wakeup on demand is supported when wakeup from EM2/3 to EM0. Set bit PWRUPONDEMAND of register MSC\_CTRL to one to enable the power up on demand. When enabled during powerup, flash will enter sleep mode and waiting for either pending flash read transaction or software command to MSC\_CMD.PWRUP bit. If software command wakeup, and interrupt of MSC\_IF.PWRUPF will be flagged if the MSC\_IEN.PWRUPF is set

### 6.3.7 Wait-states

Table 6.3. Flash Wait-States

Wait-States	Frequency
WS0	no more than 25 MHz
WS1	above 25 MHz and no more than 48 MHz

### 6.3.7.1 One Wait-state Access

After reset, the HFCORECLK is normally 19 MHz from the HFRCO and the MODE field of the MSC\_READCTRL register is set to WS1 (one wait-state). Software must not select a zero wait-state mode unless the clock is guaranteed to be 25 MHz or below, otherwise the resulting behavior is undefined. If a HFCORECLK frequency above 25 MHz is to be set by software, the MODE field of the MSC\_READCTRL register must be set to WS1 or WS1SCBTP before the core clock is switched to the higher frequency clock source.

When changing to a lower frequency, the MODE field of the MSC\_READCTRL register must be set to WS0 or WS0SCBTP only after the frequency transition has completed. If the HFRCO is used, wait until the oscillator is stable on the new frequency. Otherwise, the behavior is unpredictable.

To run at a frequency higher than 48 MHz, WS2 or WS2SCBTP must be selected to insert two wait-states for every flash access.


### 6.3.7.2 Zero Wait-state Access

At 25 MHz and below, read operations from flash may be performed without any wait-states. Zero wait-state access greatly improves code execution performance at frequencies from 25 MHz and below. By default, the Cortex-M0+ uses speculative prefetching to maximize code execution performance at the cost of additional flash accesses and energy consumption.

### 6.3.8 Instruction Cache

The MSC includes an instruction cache. The instruction cache for the internal flash memory is enabled by default, but can be disabled by setting IFCDIS in MSC\_READCTRL. When enabled, the instruction cache typically reduces the number of flash reads significantly, thus saving energy. In most cases a cache hit-rate of more than 70 % is achievable. When a 32-bit instruction fetch hits in the cache the data is returned to the processor in one clock cycle. Thus, performance is also improved when wait-states are used (i.e. running at frequencies above 25 MHz).

The instruction cache is connected directly to the ARM core and functions as a memory access filter between the processor and the memory system, as illustrated in [Figure 6.1 Instruction Cache on page 141](#). The cache consists of an access filter, lookup logic, SRAM, and two performance counters. The access filter checks that the address for the access is to on-chip flash memory (instructions in RAM are not cached). If the address matches, the cache lookup logic and SRAM is enabled. Otherwise, the cache is bypassed and the access is forwarded to the memory system. The cache is then updated when the memory access completes. The access filter also disables cache updates for interrupt context accesses if caching in interrupt context is disabled. The performance counters, when enabled, keep track of the number of cache hits and misses. The cachelines are filled up continuously one word at a time as the individual words are requested by the processor. Thus, not all words of a cacheline might be valid at a given time.



**Figure 6.1. Instruction Cache**

By default, the instruction cache is automatically invalidated when the contents of the flash is changed (i.e. written or erased). In many cases, however, the application only makes changes to data in the flash, not code. In this case, the automatic invalidate feature can be disabled by setting AIDIS in MSC\_READCTRL. The cache can (independent of the AIDIS setting) be manually invalidated by writing 1 to INV CACHE in MSC\_CMD.

**Note:** The instruction cache flush is not triggered at the event of a bus fault. As a result, when an instruction fetch results in a bus fault, invalid data may be cached. This means that the next time the instruction that caused the bus fault is fetched, the processor core will get the invalid cached data without any bus fault. In order to avoid invalid cached data propagation to the processor core, software should manually invalidate the instruction cache by writing 1 to INV CACHE in MSC\_CMD at the event of a bus fault.

In general it is highly recommended to keep the cache enabled all the time. However, for some sections of code with very low cache hit-rate more energy-efficient execution can be achieved by disabling the cache temporarily. To measure the hit-rate of a code-section, the built-in performance counters can be used. Before the section, start the performance counters by writing 1 to STARTPC in MSC\_CMD. This starts the performance counters, counting from 0. At the end of the section, stop the performance counters by writing 1 to STOPPC in MSC\_CMD. The number of cache hits and cache misses for that section can then be read from MSC\_CACHEHITS and MSC\_CACHEMISSES respectively. The total number of 32-bit instruction fetches will be MSC\_CACHEHITS + MSC\_CACHEMISSES. Thus, the cache hit-ratio can be calculated as MSC\_CACHEHITS / (MSC\_CACHEHITS + MSC\_CACHEMISSES). When MSC\_CACHEHITS overflows the CHOF interrupt flag is set. When MSC\_CACHEMISSES overflows the CMOF interrupt flag is set. These flags must be cleared explicitly by software. The range of the performance counters can thus be extended by increasing a counter in the MSC interrupt routine. The performance counters only count when a cache lookup is performed. If the lookup fails, MSC\_CACHEMISSES is increased. If the lookup is successful, MSC\_CACHEHITS is increased. For example, a cache lookup is not performed if the cache is disabled or the code is executed from RAM.

The cache content is not retained in EM2, EM3 and EM4. The cache is therefore invalidated regardless of the setting of AIDIS in MSC\_READCTRL when entering these energy modes. Applications that switch frequently between EM0 and EM2/3 and executes the very same non-looping code almost every time will most likely benefit from putting this code in RAM. The interrupt vectors can also be put in RAM to reduce current consumption even further.

### 6.3.9 Low Voltage Flash Read

The devices support low voltage flash reads. Because it takes more time to read from flash with a lower voltage supply MSC\_READCTRL.MODE should be programmed accordingly. It is recommended that software should follow certain sequences for supply voltage scaling up and down. See the EMU chapter for details.

Flash write/erase is not supported in low voltage mode. Any write/erase command will be ignored if flash is operated in a low voltage mode and the interrupt flag MSC\_IF.LVEWRITE will be set.

### 6.3.10 Erase and Write Operations

Both page erase and write operations require that the address is written into the MSC\_ADDRB register. For erase operations, the address may be any within the page to be erased. Load the address by writing 1 to the LADDRIM bit in the MSC\_WRITECMD register. The LADDRIM bit only has to be written once when loading the first address. After each word is written the internal address register ADDR will be incremented automatically by 4. The INVADDR bit of the MSC\_STATUS register is set if the loaded address is outside the flash and the LOCKED bit of the MSC\_STATUS register is set if the page addressed is locked. Any attempts to command erase of or write to the page are ignored if INVADDR or the LOCKED bits of the MSC\_STATUS register are set. To abort an ongoing erase, set the ERASEABORT bit in the MSC\_WRITECMD register.

When a word is written to the MSC\_WDATA register, the WDATAREADY bit of the MSC\_STATUS register is cleared. When this status bit is set, software or DMA may write the next word.

A single word write is commanded by setting the WRITEONCE bit of the MSC\_WRITECMD register. The operation is complete when the BUSY bit of the MSC\_STATUS register is cleared and control of the flash is handed back to the AHB interface, allowing application code to resume execution.

For a DMA write the software must write the first word to the MSC\_WDATA register and then set the WRITETRIG bit of the MSC\_WRITECMD register. DMA triggers when the WDATAREADY bit of the MSC\_STATUS register is set.

It is possible to write words twice between each erase by keeping at 1 the bits that are not to be changed. Let us take as an example writing two 16 bit values, 0xAAAA and 0x5555. To safely write them in the same flash word this method can be used:

- Write 0xFFFFAAAA (word in flash becomes 0xFFFFAAAA)
- Write 0x5555FFFF (word in flash becomes 0x5555AAAA)

#### Note:

- There is a maximum of two writes to the same word between each erase due to a physical limitation of the flash.
- Flash write/erase is not supported in low voltage mode. Any write/erase command will be ignored if flash is operated in a low voltage mode and the interrupt flag MSC\_IF.LVEWRITE will be set.
- During a write or erase, flash read accesses will be stalled, effectively halting code execution from flash. Code execution continues upon write/erase completion. Code residing in RAM may be executed during a write/erase operation.

#### 6.3.10.1 Mass Erase

A mass erase can be initiated from software using ERASEMAIN0 MSC\_WRITECMD. This command will start a mass erase of the entire flash. Prior to initiating a mass erase, MSC\_MASSLOCK must be unlocked by writing 0x631A to it. After a mass erase has been started, this register can be locked again to prevent runaway code from accidentally triggering a mass erase.

The regular flash page lock bits will not prevent a mass erase. To prevent software from initiating mass erases, use the mass erase lock bits in the mass erase lock word (MLW).

## 6.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	MSC_CTRL	RWH	Memory System Control Register
0x004	MSC_READCTRL	RWH	Read Control Register
0x008	MSC_WRITECTRL	RW	Write Control Register
0x00C	MSC_WRITECMD	W1	Write Command Register
0x010	MSC_ADDRB	RW	Page Erase/Write Address Buffer
0x018	MSC_WDATA	RW	Write Data Register
0x01C	MSC_STATUS	R	Status Register
0x030	MSC_IF	R	Interrupt Flag Register
0x034	MSCIFS	W1	Interrupt Flag Set Register
0x038	MSCIFC	(R)W1	Interrupt Flag Clear Register
0x03C	MSC_IEN	RW	Interrupt Enable Register
0x040	MSC_LOCK	RWH	Configuration Lock Register
0x044	MSC_CACHECMD	W1	Flash Cache Command Register
0x048	MSC_CACHEHITS	R	Cache Hits Performance Counter
0x04C	MSC_CACHEMISSES	R	Cache Misses Performance Counter
0x054	MSC_MASSLOCK	RWH	Mass Erase Lock Register
0x058	MSC_IRQLATENCY	RW	Irq Latency Register
0x05C	MSC_STARTUP	RW	Startup Control
0x074	MSC_CMD	W1	Command Register
0x090	MSC_BOOTLOADERCTRL	RW	Bootloader Read and Write Enable, Write Once Register
0x094	MSC_AAPUNLOCKCMD	W1	Software Unlock AAP Command Register
0x098	MSC_CACHECONFIG0	RW	Cache Configuration Register 0

## 6.5 Register Description

### 6.5.1 MSC\_CTRL - Memory System Control Register

Offset	Bit Position																												
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5		
Reset																													
Access																													
Name																													

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	TIMEOUTFAULTEN	0	RW	<b>Timeout Bus Fault Response Enable</b>
				When this bit is set, bus faults are generated when the bus system times out during an access, e.g., when reading a register from an LE peripheral that is changing too fast to get a stable value
3	IFCREADCLEAR	0	RW	<b>IFC Read Clears IF</b>
				This bit controls what happens when an IFC register in a module is read.
	Value			Description
	0			IFC register reads 0. No side-effect when reading.
	1			IFC register reads the same value as IF, and the corresponding interrupt flags are cleared.
2	PWRUPONDEMAND	0	RW	<b>Power Up on Demand During Wake Up</b>
				When set, during wake up, pending AHB transfer will cause MSC to issue power up request to CMU. If not set, will always issue power up request if PWRUPONCMD is not set either.
1	CLKDISFAULTEN	0	RW	<b>Clock-disabled Bus Fault Response Enable</b>
				When this bit is set, busfaults are generated on accesses to peripherals/system devices with clocks disabled
0	ADDRFAULTEN	1	RW	<b>Invalid Address Bus Fault Response Enable</b>
				When this bit is set, busfaults are generated on accesses to unmapped parts of system and code address space

## 6.5.2 MSC\_READCTRL - Read Control Register

Offset	Bit Position																																
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset				0			0x1																	0	1			0	0	0			
Access			RW			RWH																		RW	RW	RW	RW	RW	RW				
Name		SCBTP			MODE																			USEHPROT	PREFETCH			ICCDIS	AIDIS	IFCIDS			

Bit	Name	Reset	Access	Description
31:29	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
28	SCBTP	0	RW	<b>Suppress Conditional Branch Target Prefetch</b>
				Enable suppressed Conditional Branch Target Prefetch (SCBTP) function. SCBTP saves energy by delaying Cortex-M conditional branch target prefetches until the conditional branch instruction is in the execute stage. When the instruction reaches this stage, the evaluation of the branch condition is completed and the core does not perform a speculative prefetch of both the branch target address and the next sequential address. With the SCBTP function enabled, one instruction fetch is saved for each branch not taken, with a negligible performance penalty.
27:26	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
25:24	MODE	0x1	RWH	<b>Read Mode</b>
				After reset, the core clock is 19 MHz from the HFRCO and the MODE field of MSC_READCTRL register is set to WS1. The reset value is WS1 because the HFRCO may produce a frequency above 19 MHz before it is calibrated. A large wait states is associated with high frequency. When changing to a higher frequency, this register must be set to a large wait states first before the core clock is switched to the higher frequency. When changing to a lower frequency, this register should be set to lower wait states after the frequency transition has been completed. If the HFRCO is used as clock source, wait until the oscillator is stable on the new frequency to avoid unpredictable behavior. See Flash Wait-States table for the corresponding threshold for different wait-states.
	Value	Mode		Description
	0	WS0		Zero wait-states inserted in fetch or read transfers
	1	WS1		One wait-state inserted for each fetch or read transfer. See Flash Wait-States table for details
	2	WS2		Two wait-states inserted for each fetch or read transfer. See Flash Wait-States table for details
	3	WS3		Three wait-states inserted for each fetch or read transfer. See Flash Wait-States table for details
23:10	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
9	USEHPROT	0	RW	<b>AHB_HPROT Mode</b>
				Use ahb_hprot to determine if the instruction is cacheable or not
8	PREFETCH	1	RW	<b>Prefetch Mode</b>
				Set to configure level of prefetching.
7:6	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>

Bit	Name	Reset	Access	Description
5	ICCDIS	0	RW	<b>Interrupt Context Cache Disable</b>  Set this bit to automatically disable caching of vector fetches and instruction fetches in interrupt context. Cache lookup will still be performed in interrupt context. When set, the performance counters will not count when these types of fetches occur.
4	AIDIS	0	RW	<b>Automatic Invalidate Disable</b>  When this bit is set the cache is not automatically invalidated when a write or page erase is performed.
3	IFCDIS	0	RW	<b>Internal Flash Cache Disable</b>  Disable instruction cache for internal flash memory.
2:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

### 6.5.3 MSC\_WRITECTRL - Write Control Register

Offset	Bit Position																														
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	
<b>Reset</b>																													0	1	
<b>Access</b>																													RW	RW	
<b>Name</b>																													IRQERASEABORT	WREN	

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	IRQERASEABORT	0	RW	<b>Abort Page Erase on Interrupt</b>  When this bit is set to 1, any Cortex-M interrupt aborts any current page erase operation. Executing that interrupt vector from Flash will halt the CPU.
0	WREN	0	RW	<b>Enable Write/Erase Controller</b>  When this bit is set, the MSC write and erase functionality is enabled

#### 6.5.4 MSC WRITECMD - Write Command Register

Bit	Name	Reset	Access	Description
31:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	CLEARWDATA	0	W1	<b>Clear WDATA State</b>  Will set WDATAREADY and DMA request. Should only be used when no write is active.
11:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8	ERASEMAIN0	0	W1	<b>Mass Erase Region 0</b>  Initiate mass erase of region 0. Before use MSC_MASSLOCK must be unlocked. To completely prevent access from software, clear bit 0 in the mass erase lock-word (MLW)
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	ERASEABORT	0	W1	<b>Abort Erase Sequence</b>  Writing to this bit will abort an ongoing erase sequence.
4	WRITETRIG	0	W1	<b>Word Write Sequence Trigger</b>  Start write of the first word written to MSC_WDATA, then add 4 to ADDR and write the next word if available within a 30us timeout. When ADDR is incremented past the page boundary, ADDR is set to the base of the page. If WDOUBLE is set, two words are required every time, and ADDR is incremented by 8.
3	WRITEONCE	0	W1	<b>Word Write-Once Trigger</b>  Write the word in MSC_WDATA to ADDR. Flash access is returned to the AHB interface as soon as the write operation completes. The WREN bit in the MSC_WRITECTRL register must be set in order to use this command. Only a single word is written, but the internal address is also incremented to allow a direct write of a new word without loading a new address
2	WRITEEND	0	W1	<b>End Write Mode</b>  Write 1 to end write mode when using the WRITETRIG command.
1	ERASEPAGE	0	W1	<b>Erase Page</b>  Erase any user defined page selected by the MSC_ADDRB register. The WREN bit in the MSC_WRITECTRL register must be set in order to use this command.
0	LADDRIM	0	W1	<b>Load MSC_ADDRB Into ADDR</b>  Load the internal write address register ADDR from the MSC_ADDRB register. The internal address register ADDR is incremented automatically by 4 after each word is written. When ADDR is incremented past the page boundary, ADDR is set to the base of the page.

**6.5.5 MSC\_ADDRB - Page Erase/Write Address Buffer**

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>	0x00000000																															
<b>Access</b>	RW																															
<b>Name</b>	ADDRB																															

Bit	Name	Reset	Access	Description
31:0	ADDRB	0x00000000	RW	<b>Page Erase or Write Address Buffer</b>
This register holds the page address for the erase or write operation. This register is loaded into the internal MSC_ADDR register when the LADDRIM field in MSC_WRITECMD is set.				

**6.5.6 MSC\_WDATA - Write Data Register**

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>	0x00000000																															
<b>Access</b>	RW																															
<b>Name</b>	WDATA																															

Bit	Name	Reset	Access	Description
31:0	WDATA	0x00000000	RW	<b>Write Data</b>
The data to be written to the address in MSC_ADDR. This register must be written when the WDATAREADY bit of MSC_STATUS is set.				

## 6.5.7 MSC\_STATUS - Status Register

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset					0x0																				R	0	0	0	0	0	0	
Access					R																				R	0	0	0	0	0	0	
Name	PWRUPCKBDFAILCOUNT					WDATAVALID																				PCRUNNING	ERASEABORTED	WORDTIMEOUT	WDATAREADY	INVADDR	LOCKED	BUSY

Bit	Name	Reset	Access	Description
31:28	PWRUPCKBDFAIL-COUNT	0x0	R	<b>Flash Power Up Checkerboard Pattern Check Fail Count</b>
				This field tells how many times checkboard pattern check fail occurred after a reset sequence.
27:24	WDATAVALID	0x0	R	<b>Write Data Buffer Valid Flag</b>
				This field tells how many valid data in the write buffer, each bit indicates one buffer entry
23:7	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
6	PCRUNNING	0	R	<b>Performance Counters Running</b>
				This bit is set while the performance counters are running. When one performance counter reaches the maximum value, this bit is cleared.
5	ERASEABORTED	0	R	<b>The Current Flash Erase Operation Aborted</b>
				When set, the current erase operation was aborted by interrupt.
4	WORDTIMEOUT	0	R	<b>Flash Write Word Timeout</b>
				When this bit is set, MSC_WDATA was not written within the timeout. The flash write operation timed out and access to the flash is returned to the AHB interface. This bit is cleared when the ERASEPAGE, WRITETRIG or WRITEONCE commands in MSC_WRITECMD are triggered.
3	WDATAREADY	1	R	<b>WDATA Write Ready</b>
				When this bit is set, the content of MSC_WDATA is read by MSC Flash Write Controller and the register may be updated with the next 32-bit word to be written to flash. This bit is cleared when writing to MSC_WDATA.
2	INVADDR	0	R	<b>Invalid Write Address or Erase Page</b>
				Set when software attempts to load an invalid (unmapped) address into ADDR
1	LOCKED	0	R	<b>Access Locked</b>
				When set, the last erase or write is aborted due to erase/write access constraints
0	BUSY	0	R	<b>Erase/Write Busy</b>
				When set, an erase or write operation is in progress and new commands are ignored

## 6.5.8 MSC\_IF - Interrupt Flag Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0	0	0	0	0	0		
Access																									R	0	0	0	0	0		
Name																									LVIEWRITE	R	0	0	0	0	0	

Bit	Name	Reset	Access	Description
31:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
8	LVIEWRITE	0	R	<b>Flash LVE Write Error Flag</b>  If one, flash controller write command received while in LVE mode
7	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
6	WDATAOV	0	R	<b>Flash Controller Write Buffer Overflow</b>  If one, flash controller write buffer overflow detected
5	ICACHERR	0	R	<b>iCache RAM Parity Error Flag</b>  If one, iCache RAM parity Error detected
4	PWRUPF	0	R	<b>Flash Power Up Sequence Complete Flag</b>  Set after MSC_CMD.PWRUP received, flash powered up complete and ready for read/write
3	CMOF	0	R	<b>Cache Misses Overflow Interrupt Flag</b>  Set when MSC_CACHEMISSES overflows
2	CHOF	0	R	<b>Cache Hits Overflow Interrupt Flag</b>  Set when MSC_CACHEHITS overflows
1	WRITE	0	R	<b>Write Done Interrupt Read Flag</b>  Set when a write is done
0	ERASE	0	R	<b>Erase Done Interrupt Read Flag</b>  Set when erase is done

## 6.5.9 MSC\_IFS - Interrupt Flag Set Register

Offset	Bit Position																																					
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Reset																																						
Access																																						
Name																										LVEWRITE	W1	0	8	7	6	5	4	3	2	1	0	0

Bit	Name	Reset	Access	Description
31:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8	LVEWRITE	0	W1	<b>Set LVEWRITE Interrupt Flag</b>  Write 1 to set the LVEWRITE interrupt flag
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	WDATAOV	0	W1	<b>Set WDATAOV Interrupt Flag</b>  Write 1 to set the WDATAOV interrupt flag
5	ICACHERR	0	W1	<b>Set ICACHERR Interrupt Flag</b>  Write 1 to set the ICACHERR interrupt flag
4	PWRUPF	0	W1	<b>Set PWRUPF Interrupt Flag</b>  Write 1 to set the PWRUPF interrupt flag
3	CMOF	0	W1	<b>Set CMOF Interrupt Flag</b>  Write 1 to set the CMOF interrupt flag
2	CHOF	0	W1	<b>Set CHOFOF Interrupt Flag</b>  Write 1 to set the CHOFOF interrupt flag
1	WRITE	0	W1	<b>Set WRITE Interrupt Flag</b>  Write 1 to set the WRITE interrupt flag
0	ERASE	0	W1	<b>Set ERASE Interrupt Flag</b>  Write 1 to set the ERASE interrupt flag

## 6.5.10 MSC\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																																
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8	LVEWRITE	0	(R)W1	<b>Clear LVEWRITE Interrupt Flag</b>
				Write 1 to clear the LVEWRITE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6	WDATAOV	0	(R)W1	<b>Clear WDATAOV Interrupt Flag</b>
				Write 1 to clear the WDATAOV interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	ICACHERR	0	(R)W1	<b>Clear ICACHERR Interrupt Flag</b>
				Write 1 to clear the ICACHERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	PWRUPF	0	(R)W1	<b>Clear PWRUPF Interrupt Flag</b>
				Write 1 to clear the PWRUPF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	CMOF	0	(R)W1	<b>Clear CMOF Interrupt Flag</b>
				Write 1 to clear the CMOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	CHOF	0	(R)W1	<b>Clear CHOF Interrupt Flag</b>
				Write 1 to clear the CHOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	WRITE	0	(R)W1	<b>Clear WRITE Interrupt Flag</b>
				Write 1 to clear the WRITE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	ERASE	0	(R)W1	<b>Clear ERASE Interrupt Flag</b>
				Write 1 to clear the ERASE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 6.5.11 MSC\_IEN - Interrupt Enable Register

Offset	Bit Position																															
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																
Bit	Name	Reset	Access	Description																												
31:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																														
8	LVEWRITE	0	RW	<b>LVEWRITE Interrupt Enable</b>																												
	Enable/disable the LVEWRITE interrupt																															
7	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																														
6	WDATAOV	0	RW	<b>WDATAOV Interrupt Enable</b>																												
	Enable/disable the WDATAOV interrupt																															
5	ICACHERR	0	RW	<b>ICACHERR Interrupt Enable</b>																												
	Enable/disable the ICACHERR interrupt																															
4	PWRUPF	0	RW	<b>PWRUPF Interrupt Enable</b>																												
	Enable/disable the PWRUPF interrupt																															
3	CMOF	0	RW	<b>CMOF Interrupt Enable</b>																												
	Enable/disable the CMOF interrupt																															
2	CHOF	0	RW	<b>CHOF Interrupt Enable</b>																												
	Enable/disable the CHOFR interrupt																															
1	WRITE	0	RW	<b>WRITE Interrupt Enable</b>																												
	Enable/disable the WRITE interrupt																															
0	ERASE	0	RW	<b>ERASE Interrupt Enable</b>																												
	Enable/disable the ERASE interrupt																															

## 6.5.12 MSC\_LOCK - Configuration Lock Register

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x0000							
Access																									RWH							
Name																										LOCKKEY						

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:0	LOCKKEY	0x0000	RWH	<b>Configuration Lock</b>
Write any other value than the unlock code to lock access to MSC_CTRL, MSC_READCTRL, MSC_WRITECMD, MSC_STARTUP and MSC_AAPUNLOCKCMD. Write the unlock code to enable access. When reading the register, bit 0 is set when the lock is enabled.				
<hr/>				
Mode		Value	Description	
Read Operation				
UNLOCKED	0		MSC registers are unlocked	
LOCKED	1		MSC registers are locked	
<hr/>				
Write Operation				
LOCK	0		Lock MSC registers	
UNLOCK	0x1B71		Unlock MSC registers	
<hr/>				

## 6.5.13 MSC\_CACHECMD - Flash Cache Command Register

Offset	Bit Position																															
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:3	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	STOPPC	0	W1	<b>Stop Performance Counters</b>
				Use this command bit to stop the performance counters.
1	STARTPC	0	W1	<b>Start Performance Counters</b>
				Use this command bit to start the performance counters. The performance counters always start counting from 0.
0	INVCACHE	0	W1	<b>Invalidate Instruction Cache</b>
				Use this register to invalidate the instruction cache.

## 6.5.14 MSC\_CACHEHITS - Cache Hits Performance Counter

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																														R		
<b>Name</b>																														CACHEHITS		

Bit	Name	Reset	Access	Description
31:20	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
19:0	CACHEHITS	0x00000	R	<b>Cache Hits Since Last Performance Counter Start Command</b>
				Use to measure cache performance for a particular code section.

## 6.5.15 MSC\_CACHEMISSES - Cache Misses Performance Counter

Offset	Bit Position																															
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																															0x000000	
Access																															R	
Name																																CACHEMISSES

Bit	Name	Reset	Access	Description
31:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
19:0	CACHEMISSES	0x00000	R	<b>Cache Misses Since Last Performance Counter Start Command</b>  Use to measure cache performance for a particular code section.

## 6.5.16 MSC\_MASSLOCK - Mass Erase Lock Register

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x00001							
Access																									RWH							
Name																										LOCKKEY						

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

15:0    LOCKKEY    0x0001    RWH    **Mass Erase Lock**

Write any other value than the unlock code to lock access the the ERASEMAINn commands. Write the unlock code 631A to enable access. When reading the register, bit 0 is set when the lock is enabled. Locked by default.

Mode	Value	Description
<b>Read Operation</b>		
UNLOCKED	0	Mass erase unlocked
LOCKED	1	Mass erase locked
<b>Write Operation</b>		
LOCK	0	Lock mass erase
UNLOCK	0x631A	Unlock mass erase

## 6.5.17 MSC\_IRQLATENCY - Irq Latency Register

Offset	Bit Position																																
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0x00		
Access																															RW		
Name																																	IRQLATENCY

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	IRQLATENCY	0x00	RW	<b>Irq Latency Register</b>

Specify the minimum number of HCORECLK-cycles to wait before handling an interrupt after it has been asserted. This can be used to achieve deterministic (zero-jitter) behavior when handling interrupts, at the cost of speed. To achieve zero-jitter with zero wait-states in flash, set this to 9.

IRQLATENCY	Description
0	Interrupts will be handled as quickly as possible.
1 - 255	The CM0+ will use at least IRQLATENCY+6 HFCORECLK-cycles to handle interrupts.

## 6.5.18 MSC\_STARTUP - Startup Control

Offset	Bit Position																																	
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset			0x1																															
Access		RW		RW		RW		RW								RW																		
Name		STWS		STWSAEN		STWSEN		ASTWAIT								STDLY1																	STDLY0	

Bit	Name	Reset	Access	Description
31	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
30:28	STWS	0x1	RW	<b>Startup Waitstates</b>  Active wait for flash startup startup after STDLY0.
27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
26	STWSAEN	0	RW	<b>Startup Waitstates Always Enable</b>  Use the number of waitstates given by STWS during startup always.
25	STWSEN	1	RW	<b>Startup Waitstates Enable</b>  Use the number of waitstates given by STWS during startup. During the optional STDLY1 timeout.
24	ASTWAIT	1	RW	<b>Active Startup Wait</b>  Active wait for flash startup startup after STDLY0.
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:12	STDLY1	0x001	RW	<b>Startup Delay 0</b>  Number of cycles with startup waitstates, and also the maximum number of cycles startup sampling will be attempted before starting up system. Note that the reset value of this field may differ from the value shown in this description. The reset value programmed in the device is the optimal value.
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9:0	STDLY0	0x04D	RW	<b>Startup Delay 0</b>  Number of idle cycles from exiting sleep mode. Note that the reset value of this field may differ from the value shown in this description. The reset value programmed in the device is the optimal value.

## 6.5.19 MSC\_CMD - Command Register

Offset	Bit Position																																
0x074	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																															PWRUP	W1	0

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	PWRUP	0	W1	<b>Flash Power Up Command</b>

Write to this bit to power up the Flash. IRQ PWRUPF will be fired when power up sequence completed.

## 6.5.20 MSC\_BOOTLOADERCTRL - Bootloader Read and Write Enable, Write Once Register

Offset	Bit Position																												BLWDIS	RW	0	1						
0x090	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	BLRDIS	RW	0	0				
Reset																																						
Access																																						
Name																																						

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	BLWDIS	0	RW	<b>Flash Bootloader Write/Erase Disable</b>

Controls write/erase access of the flash bootloader pages. When cleared, write/erase is enabled. When set, write/erase is disabled.

Bit	Name	Reset	Access	Description
0	BLRDIS	0	RW	<b>Flash Bootloader Read Disable</b>

Controls read access of the flash bootloader pages. When cleared, read is enabled. When set, read is disabled.

### **6.5.21 MSC\_AAPUNLOCKCMD - Software Unlock AAP Command Register**

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	UNLOCKAAP	0	W1	<b>Software Unlock AAP Command</b>  Write to this bit to unlock AAP. This is only possible when bit 31 of the AAP Lock Word (ALW) in flash is set to 1. If bit 31 of the ALW has been cleared to 0, this command has no effect. Register is writable only when MSC_LOCK is unlocked



## 6.5.22 MSC\_CACHECONFIG0 - Cache Configuration Register 0

Offset	Bit Position																																			
0x098	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset	0x3																																			
Access																																				
Name																																				CACHELEVEL

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

1:0	CACHELEVEL	0x3	RW	<b>Instruction Cache Low-Power Level</b>	
Use this to set the low-power level of the cache. In general, the default setting is best for most applications.					
Value		Mode	Description		
0		BASE	Base instruction cache functionality.		
1		ADVANCED	Advanced buffering mode, where the cache uses the fetch pattern to predict highly accessed data and store it in low-energy memory.		
3		MINACTIVITY	Minimum activity mode, which allows the cache to minimize activity in logic that it predicts has a low probability being used. This mode can introduce wait-states into the instruction fetch stream when the cache exits one of its low-activity states. The number of wait-states introduced is small, but users running with 0-wait-state memory and wishing to reduce the variability that the cache might introduce with additional wait-states may wish to lower the cache low-power level. Note, this mode includes the advanced buffering mode functionality.		

## 7. LDMA - Linked DMA Controller



### Quick Facts

#### What?

The LDMA controller can move data without CPU intervention, effectively reducing the energy consumption for a data transfer.

#### Why?

The LDMA can perform data transfers more energy efficiently than the CPU and allows autonomous operation in low energy modes. For example the LEUART can provide full UART communication in EM2 DeepSleep, consuming only a few  $\mu$ A by using the LDMA to move data between the LEUART and RAM.

#### How?

The LDMA controller has multiple highly configurable, prioritized DMA channels. A linked list of flexible descriptors makes it possible to tailor the controller to the specific needs of an application.

### 7.1 Introduction


The Linked Direct Memory Access (LDMA) controller performs memory transfer operations independently of the CPU. This has the benefit of reducing the energy consumption and the workload of the CPU, and enables the system to stay in low energy modes while still routing data to memory and peripherals. For example, moving data from the LEUART to memory or memory to LEUART. Each of the DMA channels on the EFM32 can be connected to any of the EFM32 peripherals.

### 7.1.1 Features

- Flexible Source and Destination transfers
  - Memory-to-memory
  - Memory-to-peripheral
  - Peripheral-to-memory
  - Peripheral-to-peripheral
- DMA transfers triggered by peripherals, software, or linked list
- Single or multiple data transfers for each peripheral or software request
- Inter-channel and hardware event synchronization via trigger and wait functions
- Supports single or multiple descriptors
  - Single descriptor
  - Linked list of descriptors
  - Circular and ping-pong buffers
  - Scatter-Gather
  - Looping
  - Pause and restart triggered by other channels
  - Sophisticated flow control which can function without CPU interaction
- Channel arbitration includes:
  - Fixed priority
  - Simple round robin
  - Round robin with programmable multiple interleaved entries for higher priority requesters
- Programmable data size and source and destination address strides
- Programmable interrupt generation at the end of each DMA descriptor execution
- Little-endian/big-endian conversion
- DMA write-immediate function

## 7.2 Block Diagram

An overview of the LDMA and the modules it interacts with is shown in [Figure 7.1 LDMA Block Diagram on page 165](#).



**Figure 7.1. LDMA Block Diagram**

The Linked DMA Controller consists of three main parts

- A DMA core that executes transfers and communicates status to the core
- A channel select block that routes peripheral DMA requests and acknowledge signals to the DMA
- A set of internal channel configuration registers for tracking the progress of each DMA channel

The DMA has access to all system memory through the AHB bus and the AHB->APB bridge. It can load channel descriptors from memory with no CPU intervention.

## 7.3 Functional Description

The Linked DMA Controller is highly flexible. It is capable of transferring data between peripherals and memory without involvement from the processor core. This can be used to increase system performance by off-loading the processor from copying large amounts of data or avoiding frequent interrupts to service peripherals needing more data or having available data. It can also be used to reduce the system energy consumption by making the LDMA work autonomously with some EM2/3 peripherals for data transfer without having to wake up the processor core from sleep.

The Linked DMA Controller has 8 independent channels. Each of these channels can be connected to any of the available peripheral DMA transfer request input sources by writing to the channel configuration registers, see [7.3.2 Channel Configuration](#). In addition, each channel can also be triggered directly by software, which is useful for memory-to-memory transfers.

The channel descriptors determine what the Linked DMA Controller will do when it receives DMA transfer request. The initial descriptor is written directly to the LDMA's channel registers. If desired, the initial descriptor can link to additional linked descriptors stored in memory (RAM or Flash). Alternatively, software may also load the initial descriptor by writing the descriptor address to the LDMA\_CHx\_LINK register and then setting the corresponding bit the LDMA\_LINKLOAD register.

Before enabling a channel, the software must take care to properly configure the channel registers including the link address and any linked descriptors. When a channel is triggered, the Linked DMA Controller will perform the memory transfers as specified by the descriptors. A descriptor contains the memory address to read from, the memory address to write to, link address of the next descriptor, the number of bytes to be transferred, etc. The channel descriptor is described in detail in [7.3.7 Channel Descriptor Data Structure](#).

The Linked DMA Controller supports both fixed priority and round robin arbitration. The number of fixed and round robin channels is programmable. For round robin channels, the number of arbitration slots requested for each channel is programmable. Using this scheme, it is possible to ensure that timing-critical transfers are serviced on time.

DMA transfers take place by reading a block of data at a time from the source, storing it in the LDMA's local FIFO, then writing the block out to the destination from the FIFO. Interrupts may optionally be signaled to the CPU's interrupt controller at the end of any DMA transfer or at the completion of a descriptor if the DONEIFSEN bit is set. An AHB error will always generate an interrupt.

### 7.3.1 Channel Descriptor

Each DMA channel has descriptor registers. A transfer can be initialized by software writing to the registers or by the DMA itself copying a descriptor from RAM to memory. When using a linked list of descriptors the first descriptor should be initialized by the CPU. The DMA itself will then copy linked descriptors to its descriptor registers as required. In addition to manually initializing the first transfer, software may also cause the LDMA to load the initial descriptor by writing the descriptor address to the LDMA\_CHx\_LINK register and then setting the corresponding bit the LDMA\_LINKLOAD register.

The contents of the descriptor registers are dynamically updated during the DMA transfer. The contents of descriptors in memory are not edited by the controller.

Some descriptor field values are only used for linked descriptors. For example, the SRCMODE and DSTMODE bits of the LDMA\_CHx\_CTRL registers determine if a linked descriptor is using relative or absolute addressing. Software writes to the address registers will always use absolute addressing and never set these bits. Therefore, these bits are read only.

#### 7.3.1.1 DMA Transfer Size

A DMA transfer is the smallest unit of data that can be transferred by the LDMA. The LDMA supports byte, half-word and word sized transfers. The SIZE field in the LDMA\_CHx\_CTRL register specifies the data width of one DMA transfer.

#### 7.3.1.2 Source/Destination Increments

The SRCINC and DSTINC in the LDMA\_CHx\_CTRL register determines the increment between DMA transfers. The increment is in units of DMA transfers and using an increment size of 1 will transfer contiguous bytes, half-words, or words depending on the value of the SIZE field. Multiple unit increments are useful for transferring or packing/unpacking aligned data. For example using an increment of 4 with a size of BYTE will transfer word aligned bytes. An increment of 2 units with a size of HALFWORD is suitable for the transfer of word aligned half-word data. The LDMA can also pack or unpack data by using a different increment size for source and destination. For example - to convert from word aligned byte data (unpacked) to contiguous byte data (packed), set the SIZE to BYTE, SRCINC to 4, and DSTINC to 1.

SRCINC or DSTINC may also be set to NONE which will cause the LDMA to read or write the same location for every DMA transfer. This is useful for accessing peripheral FIFO or data registers.

### 7.3.1.3 Block Size

The block size defines the amount of data transferred in one arbitration. It consists of one or more DMA transfers. See [7.3.6.1 Arbitration Priority](#) for more details.

### 7.3.1.4 Transfer Count

The descriptor transfer count defines how many DMA transfers to perform. The number of bytes transferred by the descriptor will depend on both the transfer count XFERCNT and the SIZE field settings.  $\text{TOTAL\_BYTES} = \text{XFERCNT} * \text{SIZE}$

### 7.3.1.5 Descriptor List

A descriptor list consists of one or more descriptors which are executed in serially. This list may be a simple sequence of descriptors, a loop of descriptors, or a combination of the two.

Each descriptor in the list can be one of several types.

- Single Transfer descriptor: Transfers TOTAL\_BYT $E$ S of data and then stops.
- Linked Transfer descriptor: Transfers TOTAL\_BYT $E$ S of data and then loads the next linked descriptor.
- Loop Transfer descriptor: Transfers TOTAL\_BYT $E$ S of data and performs loop control (see [7.3.2.2 Loop Counter](#)).
- Sync descriptor: Handle synchronization of the list with other entities (see [7.3.7.2 SYNC Descriptor Structure](#)).
- WRI descriptor: Writes a value to a location in memory (see [7.3.7.3 WRI Descriptor Structure](#)).

### 7.3.1.6 Addresses

Before initiating a transfer, software should write the source address, destination address, and if applicable the link address to the descriptor registers. Alternatively, software may load a descriptor from memory by writing the descriptor address to the LDMA\_CHx\_LINK register and setting the corresponding bit in the LDMA\_LINKLOAD register.

During a DMA transfer, the DMA source and destination address registers are pointers to the next transfer address. The LDMA will update the SRC and DST addresses after each transfer. If software halts a DMA transfer by clearing the enable bit, the SRC and DST addresses will indicate the next transfer address.

When a descriptor is finished the DMA will either halt or load the next (linked) descriptor depending on the value of the LINK field in the LDMA\_CHx\_LINK register. After loading a linked descriptor, the descriptor registers will reflect the content of the loaded descriptor. Note that the linked descriptor must be word aligned in memory. The two least significant bits of the LDMA\_CHx\_LINK register are used by the LINK and LINKMODE bits. The two least significant bits of the link address are always zero.

### 7.3.1.7 Addressing Modes

The DMA descriptors support absolute addressing or relative addressing. When using relative addressing, the offset is relative to the current contents of the respective address registers. Regardless of the descriptor addressing modes, the address registers always indicate the absolute address. For example, when loading a descriptor using relative SRC addressing, the LDMA will add the descriptor source address (offset) to the contents of the SRCADDR register (base address). After loading, the SRCADDR register will indicate the absolute address of the loaded descriptor.

The initial descriptor must use absolute addressing. The LDMA will ignore the DSTMODE, SRCMODE, and LINKMODE bits for the initial descriptor and interpret the addresses as an absolute addresses.

Relative addressing is most useful for the link address. The initial descriptor will indicate the absolute address of the linked descriptors in memory. The linked descriptors might be an array of structures. In this case the offset between descriptors is constant and is always 4 words or 16 bytes (each descriptor has 4 words). The LINK address is not incremented or decremented after each transfer. Thus, a relative offset of 0x10 may be used for all linked descriptors.

The source and destination addresses also support relative addressing. When using relative addressing with the source or destination address registers, the LDMA adds the relative offset to the current contents of the respective address register. Since the source and destination addresses are normally incremented after each transfer, the final address will point to one unit past the last transfer. Thus, an offset of zero will give the next sequential data address.

See the example [7.4.6 2D Copy](#) for an common use of relative addressing.

### 7.3.1.8 Byte Swap

Enabling byte swap reverses the endianness of the incoming source data read into the LDMA's FIFO. Byte swap is only valid for transfer sizes of word and half-word. Note that linked structure reads are not byte swapped.





Figure 7.2. Word and Half-Word Endian Byte Swap Examples


### 7.3.1.9 DMA Size and Source/Destination Increment Programming

The DMA channels' SIZE, SRCINC, and DSTINC bit-fields are programmed to best utilize memory resources. They provide a means for memory packing and unpacking, as well as for matching the size of data being transmitted to or received from an IO peripheral. The following figure shows how 32-bit words of data are read from a memory source into the DMA's internal transfer FIFO, and then written out to the memory destination. The memory organization in bytes is shown as well as the first read to and write from the DMA's FIFO.



**Figure 7.3. Memory-to-Memory Transfer WORD Size Example**

The next example shows four variations of half-word sized transfers, with all possible combinations of half- and full-word source and destination increments. Note that when the size and source/destination increments are all configured for half-word, the resulting DMA transfer organization is equivalent to the full-word sized transfer in the previous example. The difference is that the half-word configuration requires twice as many DMA transfers.



**Figure 7.4. Memory-to-Memory Transfer HALF Size Examples**

Fields SRCINCSIGN and DSTINCSIGN allow for address decrement. These can be used to mirror an image, for example, in the pixel copy application.

### 7.3.2 Channel Configuration

Each DMA channel has associated configuration and loop counter registers for controlling direction of address increment , arbitration slots, and descriptor looping.

#### 7.3.2.1 Address Increment/Decrement

Normally DMA transfers increment the source and destination addresses after each DMA transfer. Each channel is also capable of decrementing the source and/or destination addresses after each DMA transfer. This may be useful for flipping an array or copying data from tail to head. For example, a data packet might be prepared as an array of data with increasing addresses and then transmitted from the highest address to the lowest address, from tail to head.

After reset the SRCINCSIGN and DSTINCSIGN bits in the LDMA\_CHx\_CFG register are cleared causing the source and destination addresses to increment after each transfer. If the SRCINCSIGN bit is set , the DMA will decrement the source address after each transfer. If the DSTINCSIGN bit in the LDMA\_CHx\_CFG register is set , the DMA will decrement the destination address after each transfer. Setting only one of these bits will flip the data. Setting both bits will copy from tail to head, but will not flip the data.

The SRCINCSIGN and DSTINCSIGN bits apply to all descriptors used by that channel. Software should take care to set the starting source and/or destination address to the highest data address when decrementing.

#### 7.3.2.2 Loop Counter

Each channel has a LDMA\_CHx\_LOOP register that includes a loop counter field. To use looping, software should initialize the loop counter with the desired number of repetitions before enabling the transfer. A descriptor with the DECLOOOPCNT bit set to TRUE will repeat the loop and decrement the loop counter until LOOPCNT = 0.

For a looping descriptor, with DECLOOOPCNT=1, the LINK address in the LDMA\_CHx\_LINK register is used as the loop address. While LOOPCNT is greater than zero, the descriptor will execute and then the LDMA will load the next descriptor using the address specified in the LDMA\_CHx\_LINK register. This feature enables looping of multiple descriptors. To repeat a single descriptor, the LINK address of the descriptor should point to itself.

After LOOPCNT reaches zero, if the LINK bit in the descriptor LINK word is clear the transfer stops. If the LINK bit is set, the LDMA will load the next sequential descriptor located immediately following the looping descriptor. The behavior of the LINK bit is different for a looping descriptor. This is necessary because the LINK address is re-purposed as the loop address for a looping descriptor.

Note that LOOPCNT sets the number of repeats, not the number of iterations. The total number of loop iterations will be LOOPCNT plus 1. Normally, the LOOPCNT should be set to one or more repeats.

Also note that because there is only one LOOPCNT per channel, software intervention is required to update the LOOPCNT if a sequence of transfers contains multiple loops. It is also possible to use a write immediate DMA data transfer to update the LDMA\_CHx\_LOOP register.

### 7.3.3 Channel Select Configuration

The channel select block determines which peripheral request signal connects to each DMA channel.

This configuration is done by software through the SOURCESEL and SIGSEL fields of the LDMA\_CHn\_REQSEL register. SOURCESEL selects the peripheral and SIGSEL picks which DMA request signals to use from the selected peripheral.

### 7.3.4 Starting a Transfer

A transfer may be started by software, a peripheral request, or a descriptor load.

Software may initiate a transfer by setting the bit for the desired channel in the LDMA\_SREQ register. In this case the channel should set SOURCESEL to NONE to prevent unintentional triggering of the channel by a peripheral.

A peripheral may trigger the channel by configuring the peripheral source and signal as described in [7.3.3 Channel Select Configuration](#)

The LDMA may also be configured to begin a transfer immediately after a new descriptor is loaded by setting the STRUCTREQ field of the LDMA\_CHx\_CTRL register or descriptor word.

This configuration is done by software through the SOURCESEL and SIGSEL fields of the LDMA\_CHn\_REQSEL register. SOURCESEL selects the peripheral and SIGSEL picks which DMA request signals to use from the selected peripheral.

### 7.3.4.1 Peripheral Transfer Requests

By default peripherals issue a Single Request (SREQ) when any data is present. For peripherals with a data buffer or FIFO this occurs any time the FIFO is not empty. Upon receiving an SREQ the LDMA will perform one DMA transfer and stop till another request is made.

It is generally more efficient to wait for a peripheral to accumulate data and transfer in a burst. This both reduces overhead of the DMA engine and allows EM2 peripherals to save power by using the LDMA less often. To enable this set the IGNORESREQ bit in the LDMA\_CHx\_CTRL register (or descriptor) which will cause the LDMA to ignore SREQ's and wait for a full Request (REQ) signal. When the REQ is received the entire descriptor will be executed. For most peripherals with a FIFO the REQ signal is set when the FIFO is full, or a predetermined threshold has been reached. See the individual peripheral chapters for more information.

### 7.3.5 Managing Transfer Errors

LDMA transfer errors are normally managed using interrupts. Software should clear the ERROR flag in the bit in the LDMA\_IF register and enable error interrupts by setting the ERROR bit in the LDMA\_IEN register before initiating a DMA transfer.

The LDMA interrupt handler should check the ERROR flag bit in the LDMA\_IF register. If the ERROR flag bit is set, it should then read the CHERROR field in the LDMA\_STATUS register to determine the errant channel. The interrupt handler should reset the channel and clear the ERROR flag bit in the LDMA\_IF register before returning.

### 7.3.6 Arbitration

While multiple channels are configured simultaneously the LDMA engine can only be actively copying data for one channel at a time. Arbitration determines which channel is being serviced at any point in time. The LDMA will choose a channel through arbitration, transfer BLOCK\_SIZE elements of that channel and then arbitrate again choosing another channel to service. This allows high priority channels to be serviced while lower priority channels are in the middle of a transfer.

#### 7.3.6.1 Arbitration Priority

There are two modes in determining priority when the controller arbitrates: fixed priority and round robin priority.

In fixed priority mode, channel 0 has the highest priority. As the channel number increases, the priority decreases. When the LDMA controller is idle or when a transfer completes, the highest priority channel with an active request is granted the transfer. This mode guarantees smallest latency for the highest priority requesters. It is best suited for systems where peak bandwidth is well below LDMA controller's maximum ability to serve. The drawback of this mode is the possibility of starvation for lowest priority requesters.

In the round robin priority mode, each active requesting channel is serviced in the order of priority. A late arriving request on a higher priority channel will not get serviced until the next round. This mode minimizes the risk of starving low-priority latency-tolerant requesters. The drawback of this mode is higher risk of starving low-latency requesters.

The NUMFIXED field in the LDMA\_CTRL register determines which channels are fixed priority and which are round robin. Channels lower than NUMFIXED are fixed priority while those above it are round robin. A value of 0x0 implies all channels are round robin. A value of 0x4 implies channels 0 through 3 are fixed priority and 4 through 7 are round robin. A value of 7 implies that channels 0 through 6 are fixed and channel 7 is round robin. This is functionally equivalent to having 8 fixed priority channels.

Fixed priority channels always take priority over round robin. As long as NUMFIXED is greater than 0, there is a possibility that a higher priority channel can starve the remaining channels.

To address the drawbacks of using fixed priority or round robin priority the LDMA implements the concept of arbitration slots. This allows for channels to have high bandwidth and low latency while preventing starvation of latency tolerant low priority channels.

Each channel has a two bit ARBSLOT field in its LDM\_CHx\_CFG register. This field only applies to channels marked as round robin (determined by NUMFIXED). The channels in the same arbitration slot are treated equally with round robin scheduling. Channels marked with a higher arbitration slot will get serviced more frequently. By default all channels are placed in arbitration slot 1.

Every time the channels in slot 1 get serviced the channels in slot 2 get serviced twice, those in slot 4 get serviced 4 times, and those in slot 8 get serviced 7 times. The specific arbitration allocation can be seen by the following table. The highest arbitration slot is serviced every other arbitration cycle, allowing for low latency response. If there are no requests from channels in arbitration slot then that slot is immediately skipped.

**Table 7.1. Arbitration Slot Order**

Arbslot order	8	4	8	2	8	4	8	1	8	4	8	2	8	4
Arbslot1								1						
Arbslot2				1								1		
Arbslot4		1				1				1				1
Arbslot8	1		1		1		1		1		1		1	

The top row shows the order at which the arbitration slots are executed. The remaining part of the table shows a more visual interpretation of the arbitration order.

For example, if we have one low latency channel (CHNL0) and two latency tolerant channels (CHNL1 and CHNL2). We could use the following settings.

LDMA\_CTRL.NUMFIXED = 0; set round robin for all channels.

CHNL0\_CFG.ARBSLOTS = TWO;

CHNL1\_CFG.ARBSLOTS = ONE;

CHNL2\_CFG.ARBSLOTS = ONE;

If all channels are constantly requesting transfers, then the arbitration order is: CHNL0, CHNL1, CHNL0, CHNL2, CHNL0, CHNL1, CHNL0, CHNL2, CHNL0, etc

Note, there are no channels assigned to arbitration slot four or eight in this example, so those slots are skipped and the final sequence is ARBSLOT2, ARBSLOT1, ARBSLOT2, ARBSLOT1, etc...

Channel 1 and Channel 2 are selected in round robin order when arbitration slot 1 is executed.

If we replace the ARBSLOTS value for channel 0 with EIGHT, then the sequence would look like the following:

CHNL0, CHNL0, CHNL0, CHNL0, CHNL1, CHNL0, CHNL0, CHNL0, CHNL2, CHNL0, CHNL0, CHNL0, CHNL1, etc.

### 7.3.6.2 DMA Transfer Arbitration

In addition to the inter channel arbitration, software can configure when the controller arbitrates during a DMA transfer. This provides reduced latency to higher priority channels when configuring low priority transfers with more arbitration cycles.

The LDMA provides four bits that configure how many DMA transfers occur before it re-arbitrates. These bits are known as the BLOCKSIZE bits and they map to the arbitration rate as shown below. For example, if BLOCKSIZE = 4 then the arbitration rate is 6, that is, the controller arbitrates every 6 DMA transfers.

[Table 7.2 AHB Bus Transfer Arbitration Interval on page 174](#) lists the arbitration rates.

**Table 7.2. AHB Bus Transfer Arbitration Interval**

BLOCKSIZE	Arbitrate After x DMA transfers
0	x = 1
1	x = 2
2	x = 3
3	x = 4
4	x = 6
5	x = 8
6	x = 12
7	x = 16
8	x = 24
9	x = 32
10	x = 64
11	x = 128
12	x = 256
13	x = 512
14	x = 1024
15	x = lock

**Note:** Software must take care not to assign a low-priority channel with a large BLOCKSIZE because this prevents the controller from servicing high-priority requests, until it re-arbitrates.

The number of DMA transfers that need to be done is specified by the user in XFERCNT. When XFERCNT > BLOCKSIZE and is not an integer multiple of BLOCKSIZE then the controller always performs sequences of BLOCKSIZE transfers until XFERCNT < BLOCKSIZE remain to be transferred. The controller performs the remaining XFERCNT transfers at the end of the DMA cycle.

Software must store the value of the BLOCKSIZE bits in the channel control data structure. See [7.3.7.1 XFER Descriptor Structure](#) for more information about the location of the BLOCKSIZE bits in the data structure.

### 7.3.7 Channel Descriptor Data Structure

Each channel descriptor consists of four 32-bit words:

- CTRL - control word contains information like transfer count and block size.
- SRC - source address points to where to copy data from
- DST - destination address points to where to copy data to
- LINK - link address points to where to load the next linked descriptor

These words map directly to the LDMA\_CHx\_CTRL, LDMA\_CHx\_SRC, LDMA\_CHx\_DST, and LDMA\_CHx\_LINK registers. The usage of the SRC and DST fields may differ depending on the structure type

There are three different types of descriptor data structures: **XFER**, **SYNC**, and **WRI**

### 7.3.7.1 XFER Descriptor Structure

This descriptor defines a typical data transfer which may be a Normal, Link, or Loop transfer.

Only this structure type can be written directly into LDMA's registers by the CPU. All descriptors may be linked to. Refer to the register descriptions for additional information.

For specifying XFER structure type, set STRUCTTYPE to 0. See the peripheral register descriptions for information on the fields in this structure.

		Bit Position																																							
		DSTMODE	31	SRCMODE	30	DSTINC	29	SRCINC	28	SIZE	27	IGNORESREQ	23	DECLOOPCNT	22	REQMODE	21	DONEIFSEN	20	BLOCKSIZE	18	BYTESWAP	15	14	13	12	11	10	XFERCNT	9	8	7	6	5	4	STRUCTREQ	3	2	1	STRUCTTYPE	0
DST	SRC	SRCADDR										DSTADDR										LINKADDR										LINK	LINKMODE								
LINK																																									

### 7.3.7.2 SYNC Descriptor Structure

This descriptor defines an intra-channel synchronizing structure. It allows the channel to wait for some external stimulus before continuing on to the next descriptor. This structure is also used to provide stimulus to another channel to indicate that it may continue.

For example channel 1 may be configured to transfer a header into a buffer while channel 2 is simultaneously transferring data into the same structure. When channel 1 has completed it can wait for a sync signal from channel 2 before transferring the now complete buffer to a peripheral.

Synch descriptors do nothing until a condition is met. The condition is formed by the SYNCTRIG field in the LDMA\_SYNC register and the MATCHEN and MATCHVAL fields of the descriptor. When  $(\text{SYNCTRIG} \& \text{MATCHEN}) == (\text{MATCHVAL} \& \text{MATCHEN})$  the next descriptor is loaded. In addition to waiting for the condition a Link descriptor can set or clear bits in SYNCTRIG to meet the conditions of another channel and cause it to continue. The CPU also has the ability to set and clear the SYNCTRIG bits from software.

This structure type can only be linked in from memory.

For specifying SYNC structure type, set STRUCTTYPE to 1.

Name	Bit Position																STRUCTTYPE																
CTRL	31	30	29	28	27	26	25	24	23	22	21	DONEIFSEN	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
SRC											SYNCCLR				SYNCSET																		
DST											MATCHEN				MATCHVAL																		
LINK	LINKADDR																												LINK	LINKMODE			

Bit	Name	Description
1:0	STRUCTTYPE	<b>Descriptor Type</b> This field indicates which type of descriptor this is. It must be 1 for a SYNC descriptor.
20	DONEIFSEN	<b>Done if Set indicator</b> If set the interrupt flag will be set when descriptor completes.
15:8	SYNCCLR	<b>Sync Trigger Clear</b> This bit-field is used to clear corresponding bits within the SYNCTRIG field of the SYNC LDMA_SYNC register. To clear a given bit, a one should be loaded to the corresponding bit. Set is given priority over clear if both corresponding bits are loaded with a one. The sync trigger clear function can only be used when loaded from a linked structure. Alternately, the user can directly write the SYNCTRIG bit-field if required.
7:0	SYNCSET	<b>Sync Trigger Set</b> This bit-field is used to set corresponding bits within the SYNCTRIG bit-field. To set a given bit, a one should be loaded to the corresponding bit. Set is given priority over clear if both corresponding bits are loaded with a one. The sync trigger set function can only be used when loaded from a linked structure. Alternately, the user can directly write the SYNCTRIG bit-field if required.
15:8	MATCHEN	<b>Sync Trigger Match Enable</b> This bit-field serves as the SYNCTRIG match enable. A sync match triggers the load of the next linked DMA structure as specified by link_mode, when: (SYNCTRIG & MATCHEN) == (MATCHVAL & MATCHEN).
7:0	MATCHVAL	<b>Sync Trigger Match Value</b>

This bit-field serves as the SYNCTRIG match value. A sync match triggers the load of the next linked DMA structure as specified by link\_mode, when:  $(\text{SYNCTRIG} \& \text{MATCHEN}) == (\text{MATCHVAL} \& \text{MATCHEN})$ .

### 7.3.7.3 WRI Descriptor Structure

This descriptor defines a write-immediate structure. This allows a list of descriptors to write a value to a register or memory location. For example, if a channel wishes to perform two loops in a descriptor sequence a WRI may be used to program the loop count for the second loop.

This structure type can only be linked in from memory.

For specifying WRI structure type, set STRUCTTYPE to 2.

		Name	Bit Position	
DST	SRC		IMMVAL	
LINK			DSTADDR	
			LINKADDR	
CTRL		DONEIFSEN	20	STRUCTTYPE
			19	1
			18	0
			17	
			16	
			15	
			14	
			13	
			12	
			11	
			10	
			9	
			8	
			7	
			6	
			5	
			4	
			3	
			2	
			1	
			0	

<b>Bit</b>	<b>Name</b>	<b>Description</b>
1:0	STRUCTTYPE	<b>Descriptor Type</b> This field indicates which type of descriptor this is. It must be 2 for a WRI descriptor.
20	DONEIFSEN	<b>Done if Set indicator</b> If set the interrupt flag will be set when descriptor completes.
31:0	IMMVAL	<b>Immediate Value for Write</b> This bit-field specifies the immediate data value that is to be written to the address pointed to by DSTADDR. Only one write occurs for WRI structures.
31:0	DSTADDR	<b>Address to write</b> This bit-field specifies the address the immediate data should be written to.

### 7.3.8 Interaction With the EMU

The LDMA interacts with the Energy Management Unit (EMU) to allow transfers from a low energy peripheral while in EM2 DeepSleep. For example, when using the LEUART in EM2 DeepSleep the EMU can wake up the LDMA sufficiently long to allow data transfers to occur. See section "DMA Support" in the LEUART documentation.

Similarly, when using the ADC in EM2 DeepSleep or EM3 Stop the EMU can wake up the LDMA as needed to allow data transfers to occur.

[Table 7.3 List of Peripherals Capable of Waking Up LDMA in EM2 DeepSleep or EM3 Stop on page 178](#) shows complete list of peripherals that are capable of waking up LDMA via EMU in EM2 DeepSleep or EM3 Stop

**Table 7.3. List of Peripherals Capable of Waking Up LDMA in EM2 DeepSleep or EM3 Stop**

Peripheral
ADC0
CSEN
LESENSE
LEUART0

### 7.3.9 Interrupts

The LDMA\_IF Interrupt flag register contains one DONE bit for each channel and one combined ERROR bit. When enabled, these interrupts are available as interrupts to the Cortex-M0+ core. They are combined into one interrupt vector, DMA\_INT. If the interrupt for the DMA is enabled in the ARM Cortex-M0+ core, an interrupt will be made if one or more of the interrupt flags in LDMA\_IF and their corresponding bits in LDMA\_IEN are set.

When a descriptor finishes execution the interrupt flag for that channel will be set if the DONEIFSEN field of the LDMA\_CHx\_LOOP register is set. If LINK and DONEIFSEN are both set when the descriptor completes the interrupt and the linked descriptor will be immediately loaded. When the final descriptor in a linked list (LINK = 0) is finished the interrupt flag is always set regardless of the state of DONEIFSEN.

### 7.3.10 Debugging

For a peripheral request DMA transfer, if software sets a bit for a channel in the LDMA\_DBGHALT register then the DMA will halt during a debug halt and the SRC and DST registers in the debug window will show the transfer in progress. Otherwise, during debug halt the DMA will continue to run and complete the entire transfer causing the descriptor registers to indicate the transfer has completed.

## 7.4 Examples

This section provides examples of common LDMA usage. All examples assume the LDMA is in the reset state with the channel being configured disabled and LDAM\_CHx\_CFG, LDMA\_CHx\_LOOP, and LDMA\_CHx\_LINK cleared.

#### 7.4.1 Single Direct Register DMA Transfer

This simple example uses only the Channel Descriptor registers directly and does not use linking. Software writes directly to the LDMA channel registers. This example does not use a memory based descriptor list.

This example is suitable for most simple transfers that are limited to transferring one block of data. It supports anything that can be done using a single descriptor. This includes endian conversion and packing/unpacking data. Channel 0 is used for this example.

The LDMA will be used to copy 127 contiguous half words (254 bytes) from 0x0 to 0x1000. It will allow arbitration every 4 transfers and is triggered by a CPU write to the LDMA\_SWREQ register. The CH0 interrupt flag will be set when the transfer completes since the descriptor does not link to another descriptor.

- Configure LDMA\_CH0\_CTRL
  - DSTMODE = 0 (absolute)
  - SRCMODE = 0 (absolute)
  - SIZE = HALFWORD (16 bits)
  - DSTINC = 0 (1 half-word)
  - SRCINC = 0 (1 half-word)
  - DECLOOPCNT=0 (unused)
  - REQMODE = 1 (one request transfers all data)
  - BLOCKSIZE = 3 (4 transfers)
  - BYTESWAP=0 (no byte swap)
  - XFERCNT=127 (transfer 127 half words)
  - STRUCTTPYE=0 (TRANSFER)
- Write source address to LDMA\_CH0\_SRC register
- Write destination address to LDMA\_CH0\_DST register
- Configure the LDMA\_CH0REQSEL register for the desired peripheral or select none for a memory-to-memory transfer
- Clear and enable interrupts.
  - Write a 1 to bit 0 of the LDMA\_IFC register to clear the CH0 DONE flag
  - Write a 1 to bit 0 of the LDMA\_IEN register to enable the CH0 interrupt
- Write a 1 to bit 0 of the LDMA\_CHEN register to enable CH0

The REQMODE field is normally cleared to zero for a peripheral request transfer and will transfer the specified block size for each peripheral request. The REQMODE may be set to 1 for a memory-to-memory transfer or any time it is desired for a single DMA request to initiate complete transfer.

#### 7.4.2 Descriptor Linked List


This example shows how to use a Linked List of descriptors. Each descriptor has a link address which points to the next descriptor in the list. A descriptor may be removed from the Linked list by altering the Link address of the one before it to point to the one after it. Descriptor Linked lists are useful when handling an array of buffers for communication data. For example, a bad packet can be removed from a receiver queue by simply removing the descriptor from the linked list.

Software loads the first descriptor into the DMA by writing the descriptor address to LDMA\_CHx\_LINK and setting the bit for that channel in the LDMA\_LINKLOAD register. This method is preferred when using a linked list in memory since it treats the first descriptor just like all the others. However, it is also allowed for software to write the first descriptor directly to the LDMA registers.

In this example 4 descriptors are executed in series. the interrupt flag is set after the 2nd and 4th (last) descriptors have completed.

- Prepare a list of descriptors using the XFER structure type in RAM
- Initialize the CTRL, SRC, and DST members as desired
  - Setting STRUCTREQ in the CTRL word for descriptors 2-4 will cause them to begin transferring data as soon as they are loaded.
- Write 0x00000013 to the LINK member of all but the last descriptor
  - LINKMODE = 1 (relative addressing)
  - LINK = 1 (Link to the next descriptor)
  - LINKADDR = 0x00000010 (size of descriptor)
- Set the DONEIFSEN bit in the CTRL member of the 2nd structure so that the interrupt flag will be set when it completes
- Write 0x00000000 to the LINK member of the last descriptor
  - LINK = 0 (Do not link to the next descriptor)
  - LINKMODE = 0 (don't care)
  - LINKADDR = 0x00000000 (don't care)

Each descriptor now points to the start of the next descriptor as shown on the left in [Figure 7.5 Descriptor Linked List on page 180](#). To remove a descriptor from the linked list modify the LINK address of the descriptor of the one before to point to the one after. For example to remove the third descriptor, add 0x00000010 to the LINK register of the second descriptor. The second descriptor will now point to the forth descriptor and skip over the third descriptor as shown on the right in [Figure 7.5 Descriptor Linked List on page 180](#).



**Figure 7.5. Descriptor Linked List**

To start execution of the linked list of descriptors:

- Write the absolute address of the first descriptor to the LINKADR field of the LDMA\_CH0\_LINK register
- Set the LINK bit of LDMA\_CH0\_LINK register.
- Configure the LDMA\_CH0REQSEL register for the desired peripheral or select none for memory-to-memory
- Clear and enable interrupts as desired
- Set bit 0 in the LDMA\_LINKLOAD register to initiate loading and execution of the first descriptor

Alternativley, software can manually copy the first descriptor contents to the LDMA\_CH0\_CTRL, LDMA\_CH0\_SRC, LDMA\_CH0\_DST, and LDMA\_CH0\_LINK registers and then enable the channel in the LDMA\_CHEN register.


### 7.4.3 Single Descriptor Looped Transfer

This example demonstrates how to use looping using a single descriptor. This method allows a single DMA transfer to be repeated a specified number of times. The looping descriptor is stored in memory and reloaded by hardware. After a specified number of iterations, the transfer stops.

CH0 is setup to copy 4 words from the ADC FIFO into a 15 word buffer at 0x1000. It repeats 4 times to fill the entire 16 word buffer. An interrupt will fire when the entire 16 words have been transferred.

Initialize the Linked descriptor in memory as follows:

- Configure CTRL member
  - DSTMODE = 0 (absolute)
  - SRCMODE = 0 (absolute)
  - SIZE = WORD
  - DSTINC = 0 (1 WORD)
  - SRCINC = 3 (0 WORDS)
  - DECLOOPCNT=1 (decrement loop count)
  - REQMODE=1 (Use XFERCNT)
  - BLOCKSIZE = 4 (4 words)
  - BYTESWAP=0 (no swap)
  - XFERCNT= 4 (4 words)
  - STRUCTTPYE=0 (TRANSFER)
  - IGNORESREQ=1 (ignore single requests)
- Write the address ADC0\_SINGLEDATA register to the SRC member
- Write 0x1000 address to DST member
- Configure the LINKLink member
  - LINK = 0 (stop after loop)
  - MODE = 1 (relative link address)
  - LINKADDR = 0 (point to ourself)
- Configure the Channel
  - Write the desired number of repeats to the LDMA\_CH0\_LOOP register
  - SOURCESEL in LDMA\_CH0REQSEL = ADC0 (select the ADC)
  - SIG in LDMA\_CH0REQSEL = ADC0SCAN (select the scan conversion request)
- Clear and enable interrupts
- Load the descriptor using LINKLOAD as described in [7.4.2 Descriptor Linked List](#)




**Figure 7.6. Single Descriptor Looped Transfer**

Note that the looping descriptor must be stored in memory, because it must load itself from the link address in memory on each iteration.

#### 7.4.4 Descriptor List With Looping

This example uses a descriptor list in memory with looping over multiple descriptors. This example also uses the looping feature and continues on with the next sequential descriptor after looping completes.

The descriptor list in memory is shown in figure [Figure 7.7 Descriptor List With Looping on page 183](#). Descriptor A links to descriptor B. Descriptor B has the DECLOOPCNT bit enabled and loops back to the start of descriptor A. The LINK address of descriptor B is used for the loop address. The LINK bit is set to indicate that execution will continue after completion of looping. Once the LOOPCNT reaches zero, the LDMA will load descriptor C. Descriptor C must be located immediately following descriptor B.



**Figure 7.7. Descriptor List With Looping**

Initialization is similar to the single looping descriptor with the following modifications.

- Set the LINK bit in descriptors A and B
- write the address of descriptor A into the LIKADDRESS of descriptor B
- write the address of descriptor B into the LIKADDRESS of descriptor A
- Descriptor C must be located immediately after descriptor B in memory

#### 7.4.5 Simple Inter-Channel Synchronization

The LDMA controller features synchronization structures which allow differing channels and/or hardware events to pause a DMA sequence, and wait for a synchronizing event to restart it.

In this example DMA channel 0 and 1 are tasked with the transfer of different sets of data. Channel 0 has two transfer structures, and channel 1 just one, but channel 0 must wait until channel 1 has completed its transfer before it starts its second transfer structure.

Pausing channel 0 is accomplished by inserting a sync wait structure between the two transfer structures. This sync structure waits on SYNCTRIG[7] to be set by a sync set/clear structure which is controlled by channel 1. Sync structures do not transfer data, they can only set, clear, or wait to match the SYNCTRIG[7:0] bits. Note that sync structures cannot decrement loop counter.


```
LDMA_SYNC
SYNCTRIG=0x0 (at time 0)

LDMA_CH0

Structure A @ 0x00          Structure B @ 0x10          Structure C @ 0x20
CTRL                         CTRL                         CTRL
    STRUCTTYPE=XFER          STRUCTTYPE=SYNC          STRUCTTYPE=XFER
LINK                         LINK                         LINK
    LINKADDR[29:0]=0x00000004  LINKADDR[29:0]=0x00000008  LINKADDR[29:0]=NA
    LINK=1                     LINK=1                     LINK=0
DST
    MATCHEN=0x80
    MATCHVAL=0x80 (waits for SYNCTRIG[7]=1)

LDMA_CH1

Structure Y @ 0x30          Structure Z @ 0x40
CTRL                         CTRL
    STRUCTTYPE=XFER          STRUCTTYPE=SYNC
LINK                         LINK
    LINKADDR[29:0]=0x00000010  LINKADDR=NA
    LINK=1                     LINK=0
SRC
    SRCCLR=0x0
    SRCSET=0x80 (sets SYNCTRIG[7])
```



**Figure 7.8. Simple Intra-channel Synchronization Example**

Both A and Y effectively start at the same time. A finishes earlier, then it links to B, which waits for the SYNCTRIG[7] bit to be set before loading C. Y finishes after B is loaded, and it links to sync structure Z, which sets the SYNCTRIG[7] bit. Channel 0 responds to the trigger set by loading C for the final data transfer.

#### 7.4.6 2D Copy

The LDMA can easily perform a 2D copy using a descriptor list with looping. This set up is visualized in Figure 7.9 2D Copy on page 186.

For an application working with graphics, this would mean the ability to copy a rectangle of a given width and height from one picture to another.




Figure 7.9. 2D Copy

The first descriptor will use absolute addressing mode and the source and destination addresses should point to the desired target addresses. The first descriptor will copy only the first row. The XFERCNT of the first descriptor is set to the desired width minus one.

- **CTRL**
  - XFERCNT = WIDTH - 1
  - SRCMD = 0 (absolute)
  - DSTMD = 0 (absolute)
- **SRCADDR** = target source address
- **DSTADDR** = target destination address
- **LINK** = 0x00000013
  - LINK=1
  - LINKMD=1
  - LINKADDR=0x00000010 (point to next descriptor)

The second descriptor will use relative addressing and the source and destination addresses are set to the desired offset. After the completion of the first descriptor, the address registers will point to the last address transferred. Thus, the width must be subtracted from the stride to get the offset. The second descriptor uses looping and the link register has no offset.

- **CTRL**
  - XFERCNT = WIDTH - 1
  - SRCMD = 1 (relative)
  - DSTMD = 1 (relative)
  - DECLOOPCNT = 1
- **SRCADDR** = desired source offset (SRCSTRIDE-WIDTH)
- **DSTADDR** = desired destination offset (DSTSTRIDE-WIDTH)
- **LINK** = 0x00000001
  - LINK=0
  - LINKMD=1 (relative)
  - LINKADDR=0x00000000 (no offset)

Because the first descriptor already transferred one row, the number of looping repeats should be the desired height minus two. Therefore, LOOPCNT should be set to HEIGHT minus two before initiating the transfer.

This same method is easily extended to copy multiple rectangles by linking descriptors together. To initialize the LDMA\_CHx\_LOOP register, precede each descriptor pair described above with a write immediate descriptor which writes the desired value to the LOOPCNT field of the LDMA\_CHx\_LOOP register.

#### 7.4.7 Ping-Pong

Communication peripherals often use ping-pong buffers. Ping-pong buffers allow the CPU to process data in one buffer while a peripheral transmits or receives data in the other buffer.

Both transmit and receive ping-pong buffers are easily implemented using the LDMA. In either case, this requires two descriptors as shown in [Figure 7.10 Infinite Ping-Pong Example on page 188](#). The LINKADDR field of the LINK member should point to the other descriptor. Using two adjacent descriptors and relative link addressing ensures the descriptors are easily reloadable.




Figure 7.10. Infinite Ping-Pong Example

A **receiver** ping-pong buffer controller consists of two buffers and two descriptors stored in memory that point to the two buffers. Once initialized, as the peripheral receives data, it will fill the first buffer. Once the first buffer is full, it will link automatically to the second buffer and generate an interrupt. Software will then process the data in the first buffer while the LDMA is transferring data to the second buffer. For a receiver ping-pong buffer each descriptor should link to the other descriptor. The link bit should be set to provide infinite ping pong between the two buffers. The DONIFS bit in each descriptor should be set to generate an interrupt on the completion of each descriptor.

- Descriptor A
  - CTRL
    - DONEIFS = 1
    - other settings as desired
  - SRCADDR = peripheral source address
  - DSTADDR = memory destination address
  - LINK = 0x00000013
    - LINKADDR = 0x00000010 (next descriptor)
    - LINK = 1 (link to next descriptor)
    - LINKMD = 1 (relative addressing)
- Descriptor B
  - CTRL
    - DONEIFS = 1
    - other settings as desired
  - SRCADDR = peripheral source address
  - DSTADDR = memory destination address
  - LINK = 0xFFFFFFF3
    - LINKADDR = 0xFFFFFFF0 (previous descriptor)
    - LINK = 1 (link to previous descriptor)
    - LINKMD = 1 (relative addressing)

For **transmitter** ping-pong buffer, software will fill the first buffer and then initiate the DMA transfer. The LDMA will transmit the first buffer data while software is filling the second buffer. In this case, the two descriptors should point to each other, but not automatically

continue to the second buffer. The LINK bit should be cleared to zero. Once software has loaded the first buffer, it will use the LINK-LOAD bit to load the first descriptor and transmit the data. The DONIFS need not be set in each descriptor. The DMA will stop and then generate an interrupt at the completion of each descriptor.

- Descriptor A
  - CTRL
    - DONEIFS = 0
    - other settings as desired
  - SRCADDR = memory source address
  - DSTADDR = peripheral destination address
  - LINK = 0x00000013
    - LINKADDR = 0x00000010 (next descriptor)
    - LINK = 0 (link to next descriptor)
    - LINKMD = 1 (relative addressing)
- Descriptor B
  - CTRL
    - DONEIFS = 0
    - other settings as desired
  - SRCADDR = memory source address
  - DSTADDR = peripheral destination address
  - LINK = 0xFFFFFFFF3
    - LINKADDR = 0xFFFFFFFF0 (previous descriptor)
    - LINK = 0 (link to previous descriptor)
    - LINKMD = 1 (relative addressing)

#### 7.4.8 Scatter-Gather

Scatter-Gather in general refers to a process that copies data from multiple locations scattered in memory and gathers the data to a single location in memory, or vice versa. A simple descriptor list allows data gathering. For example, data from a discontiguous list of buffers might be copied to a contiguous sequential array of buffers. The inverse is also possible when a sequential array of buffers is scattered to a discontiguous list of available buffers. See section [7.4.2 Descriptor Linked List](#).

Some DMAs which only have two descriptors implement scatter-gather by using one descriptor to modify the other descriptor. While it is possible to implement this same behavior using the LDMA, it is much more straight-forward to just use a simple descriptor list.

## 7.5 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	LDMA_CTRL	RW	DMA Control Register
0x004	LDMA_STATUS	R	DMA Status Register
0x008	LDMA_SYNC	RWH	DMA Synchronization Trigger Register (Single-Cycle RMW)
0x020	LDMA_CHEN	RWH	DMA Channel Enable Register (Single-Cycle RMW)
0x024	LDMA_CHBUSY	R	DMA Channel Busy Register
0x028	LDMA_CHDONE	RWH	DMA Channel Linking Done Register (Single-Cycle RMW)
0x02C	LDMA_DBGHALT	RW	DMA Channel Debug Halt Register
0x030	LDMA_SWREQ	W1	DMA Channel Software Transfer Request Register
0x034	LDMA_REQDIS	RW	DMA Channel Request Disable Register
0x038	LDMA_REQPEND	R	DMA Channel Requests Pending Register
0x03C	LDMA_LINKLOAD	W1	DMA Channel Link Load Register
0x040	LDMA_REQCLEAR	W1	DMA Channel Request Clear Register
0x060	LDMA_IF	R	Interrupt Flag Register
0x064	LDMA_IFS	W1	Interrupt Flag Set Register
0x068	LDMA_IFC	(R)W1	Interrupt Flag Clear Register
0x06C	LDMA_IEN	RW	Interrupt Enable Register
0x080	LDMA_CH0_REQSEL	RW	Channel Peripheral Request Select Register
0x084	LDMA_CH0_CFG	RW	Channel Configuration Register
0x088	LDMA_CH0_LOOP	RWH	Channel Loop Counter Register
0x08C	LDMA_CH0_CTRL	RWH	Channel Descriptor Control Word Register
0x090	LDMA_CH0_SRC	RWH	Channel Descriptor Source Data Address Register
0x094	LDMA_CH0_DST	RWH	Channel Descriptor Destination Data Address Register
0x098	LDMA_CH0_LINK	RWH	Channel Descriptor Link Structure Address Register
...	LDMA_CHx_REQSEL	RW	Channel Peripheral Request Select Register
...	LDMA_CHx_CFG	RW	Channel Configuration Register
...	LDMA_CHx_LOOP	RWH	Channel Loop Counter Register
...	LDMA_CHx_CTRL	RWH	Channel Descriptor Control Word Register
...	LDMA_CHx_SRC	RWH	Channel Descriptor Source Data Address Register
...	LDMA_CHx_DST	RWH	Channel Descriptor Destination Data Address Register
...	LDMA_CHx_LINK	RWH	Channel Descriptor Link Structure Address Register
0x1D0	LDMA_CH7_REQSEL	RW	Channel Peripheral Request Select Register
0x1D4	LDMA_CH7_CFG	RW	Channel Configuration Register
0x1D8	LDMA_CH7_LOOP	RWH	Channel Loop Counter Register
0x1DC	LDMA_CH7_CTRL	RWH	Channel Descriptor Control Word Register
0x1E0	LDMA_CH7_SRC	RWH	Channel Descriptor Source Data Address Register

Offset	Name	Type	Description
0x1E4	LDMA_CH7_DST	RWH	Channel Descriptor Destination Data Address Register
0x1E8	LDMA_CH7_LINK	RWH	Channel Descriptor Link Structure Address Register

## 7.6 Register Description

### 7.6.1 LDMA\_CTRL - DMA Control Register

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Reset							0x7													0x00								0x00			
Access								RW												RW								RW			
Name							NUMFIXED													SYNCPRSCLREN								SYNCPRSSETEN			

Bit	Name	Reset	Access	Description
31:27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
26:24	NUMFIXED	0x7	RW	<b>Number of Fixed Priority Channels</b>  This field defines the number of Fixed Priority Arbitration channels. Channels CH0 through CH(n-1) are fixed, and channels CH(n) through CH7 are round robin, where n is the field value. The reset value will give all fixed channels.
23:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:8	SYNCPRSCLREN	0x00	RW	<b>Synchronization PRS Clear Enable</b>  Setting a bit in this field will enable the corresponding PRS input to clear the respective bit in the SYNCTRIG field of the LDMA_SYNC register. Refer to the PRS section for a list of the PRS inputs.
7:0	SYNCPRSSETEN	0x00	RW	<b>Synchronization PRS Set Enable</b>  Setting a bit in this field will enable the corresponding PRS input to set the respective bit in the SYNCTRIG field of the LDMA_SYNC register. Refer to the PRS section for a list of the PRS inputs.

### 7.6.2 LDMA\_STATUS - DMA Status Register

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28:24	CHNUM	0x08	R	<b>Number of Channels</b>  The value of CHNUM always reads the total number of channels present for this instance of the DMA controller module.
23:21	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
20:16	FIFOLEVEL	0x10	R	<b>FIFO Level</b>  The value of FIFOLEVEL indicates the number of entries currently in the FIFO. (Note when all channels are disabled, this register will read the total number of entries in the FIFO.)
15:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10:8	CHERROR	0x0	R	<b>Errant Channel Number</b>  When the ERROR flag is set in the LDMA_IF register, the CHERROR field will indicate the most recent channel to have a transfer error.
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:3	CHGRANT	0x0	R	<b>Granted Channel Number</b>  The value of this field indicates the currently active channel or last active channel. Note that the reset value for this field is zero.
2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	ANYREQ	0	R	<b>Any DMA Channel Request Pending</b>  The value of this bit will be TRUE (1) if any requests are pending
0	ANYBUSY	0	R	<b>Any DMA Channel Busy</b>  The value of this bit will be TRUE (1) if one or more DMA channels are actively transferring data

## 7.6.3 LDMA\_SYNC - DMA Synchronization Trigger Register (Single-Cycle RMW)

Offset	Bit Position																																
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0x00		
Access																															RWH		
Name																																	SYNCTRIG

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SYNCTRIG	0x00	RWH	<b>Synchronization Trigger</b>

The SYNC trigger field allows a transfer to pause until a specified trigger bit is set or cleared. The SYNC trigger bits may be set and cleared by a SYNC descriptor, PRS signal, or software. Note: software requires to use single-cycle read-modify-write, detailed in [4.2.2 Peripheral Bit Set and Clear](#)

## 7.6.4 LDMA\_CHEN - DMA Channel Enable Register (Single-Cycle RMW)

Offset	Bit Position																																
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0x00	
Access																															RWH		
Name																																	CHEN

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	CHEN	0x00	RWH	<b>Channel Enables</b>

Setting one of these bits will enable the respective DMA channel. If cleared while a transfer is in progress, the current transfer block will complete. The remaining blocks will pause until resumed later by setting this bit again. Note: software requires to use single-cycle read-modify-write, detailed in [4.2.2 Peripheral Bit Set and Clear](#)

## 7.6.5 LDMA\_CHBUSY - DMA Channel Busy Register

Offset	Bit Position																																	
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																	0x00	
Access																																	R	
Name																																		BUSY

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	BUSY	0x00	R	<b>Channels Busy</b>

The bits of this field read 1 when the corresponding channel is busy.

## 7.6.6 LDMA\_CHDONE - DMA Channel Linking Done Register (Single-Cycle RMW)

Offset	Bit Position																																
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0x00	
Access																																RWH	
Name																																	CHDONE

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	CHDONE	0x00	RWH	<b>DMA Channel Linking or Done</b>

Each DMA channel sets the corresponding bit in this register when the entire transfer is done. The interrupt service routine should clear these bits. Enabling a DMA channel will also clear the corresponding LINKDONE bit. Note: software requires to use single-cycle read-modify-write, detailed in 4.2.2 Peripheral Bit Set and Clear

## 7.6.7 LDMA\_DBGHALT - DMA Channel Debug Halt Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																														0x00		
Access																														RW		
Name																														DBGHALT		

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	DBGHALT	0x00	RW	<b>DMA Debug Halt</b>  Setting one of these bits will mask the corresponding DMA channel's peripheral request when debugging and the CPU is halted. This may be useful for debugging DMA software.

## 7.6.8 LDMA\_SWREQ - DMA Channel Software Transfer Request Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x00			
Access																													W1			
Name																														SWREQ		

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	SWREQ	0x00	W1	<b>Software Transfer Requests</b>  Setting one of these bits will trigger a DMA transfer for the corresponding channel. Writing zeros has no effect.

## 7.6.9 LDMA\_REQDIS - DMA Channel Request Disable Register

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																									REQDIS							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	REQDIS	0x00	RW	<b>DMA Request Disables</b>  Setting one of these bits will disable peripheral requests for the corresponding channel. When cleared any pending peripheral requests will be serviced.

## 7.6.10 LDMA\_REQPEND - DMA Channel Requests Pending Register

Offset	Bit Position																															
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									R							
<b>Name</b>																									REQPEND							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	REQPEND	0x00	R	<b>DMA Requests Pending</b>  When a DMA channel has a pending peripheral request the corresponding REQPEND bit will read 1.

## 7.6.11 LDMA\_LINKLOAD - DMA Channel Link Load Register

Offset	Bit Position																																
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0x00	
Access																																W1	
Name																																	LINKLOAD

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	LINKLOAD	0x00	W1	<b>DMA Link Loads</b>  Setting one of these bits will force the corresponding DMA channel to load the next DMA structure and enable the channel. This empowers software to step through a sequence of descriptors.

## 7.6.12 LDMA\_REQCLEAR - DMA Channel Request Clear Register

Offset	Bit Position																																
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0x00	
Access																															W1		
Name																																	REQCLEAR

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	REQCLEAR	0x00	W1	<b>DMA Request Clear</b>  Setting one of these bits will clear any internally registered transfer requests for the corresponding channel.

**7.6.13 LDMA\_IF - Interrupt Flag Register**

Offset	Bit Position																															
0x060	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																														0x00	
Access	R																													R		
Name	ERROR																														DONE	

Bit	Name	Reset	Access	Description
31	ERROR	0	R	<b>Transfer Error Interrupt Flag</b>
				The ERRORIF flag is set when a read or write error occurs. The CERROR field in the LDMA_STATUS register reflects the number of the channel which had the last error.
30:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	DONE	0x00	R	<b>DMA Structure Operation Done Interrupt Flag</b>
				When a channel completes a transfer or sync operation, the corresponding DONE bit is set in the LDMA_IF register.

**7.6.14 LDMA\_IFS - Interrupt Flag Set Register**

Offset	Bit Position																															
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																														0x00	
Access	W1																													W1		
Name	ERROR																														DONE	

Bit	Name	Reset	Access	Description
31	ERROR	0	W1	<b>Set ERROR Interrupt Flag</b>
				Write 1 to set the ERROR interrupt flag
30:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	DONE	0x00	W1	<b>Set DONE Interrupt Flag</b>
				Write 1 to set the DONE interrupt flag

**7.6.15 LDMA\_IFC - Interrupt Flag Clear Register**

Offset	Bit Position																															
0x068	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																								0x00							
Access	(R)W1																								(R)W1							
Name	ERROR																								DONE							

Bit	Name	Reset	Access	Description
31	ERROR	0	(R)W1	<b>Clear ERROR Interrupt Flag</b>
				Write 1 to clear the ERROR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
30:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	DONE	0x00	(R)W1	<b>Clear DONE Interrupt Flag</b>
				Write 1 to clear the DONE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

**7.6.16 LDMA\_IEN - Interrupt Enable Register**

Offset	Bit Position																															
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																								0x00							
Access	RW																								RW							
Name	ERROR																								DONE							

Bit	Name	Reset	Access	Description
31	ERROR	0	RW	<b>ERROR Interrupt Enable</b>
				Enable/disable the ERROR interrupt
30:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	DONE	0x00	RW	<b>DONE Interrupt Enable</b>
				Enable/disable the DONE interrupt

## 7.6.17 LDMA\_CHx\_REQSEL - Channel Peripheral Request Select Register

Offset	Bit Position																															
0x080	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset													0x00												0x0							
Access													RW												RW							
Name													SOURCESEL												SIGSEL							

Bit	Name	Reset	Access	Description
31:22	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
21:16	SOURCESEL	0x00	RW	<b>Source Select</b>  Select input source to DMA channel.
		Value	Mode	Description
		0b000000	NONE	No source selected
		0b000001	PRS	Peripheral Reflex System
		0b001000	ADC0	Analog to Digital Converter 0
		0b001010	VDAC0	Digital to Analog Converter 0
		0b001100	USART0	Universal Synchronous/Asynchronous Receiver/Transmitter 0
		0b001101	USART1	Universal Synchronous/Asynchronous Receiver/Transmitter 1
		0b001110	USART2	Universal Synchronous/Asynchronous Receiver/Transmitter 2
		0b001111	USART3	Universal Synchronous/Asynchronous Receiver/Transmitter 3
		0b010010	UART0	Universal Asynchronous Receiver/Transmitter 0
		0b010100	LEUART0	Low Energy UART 0
		0b010110	I2C0	I2C 0
		0b010111	I2C1	I2C 1
		0b011001	TIMER0	Timer 0
		0b011010	TIMER1	Timer 1
		0b100000	WTIMER0	Wide Timer 0
		0b100001	WTIMER1	Wide Timer 1
		0b110000	MSC	Memory System Controller
		0b110001	CRYPTO0	Advanced Encryption Standard Accelerator
		0b111101	CSEN	Capacitive touch sense module
		0b111110	LESENSE	Low Energy Sensor Interface
15:4	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

Bit	Name	Reset	Access	Description
3:0	SIGSEL	0x0	RW	<b>Signal Select</b>
Select input signal to DMA channel.				
	Value	Mode		Description
	<i>SOURCESEL</i> = 0b000000			(NONE)
	0bxxxx	OFF		Channel input selection is turned off
	<i>SOURCESEL</i> = 0b000001			(PRS)
	0b0000	PRSREQ0		PRSREQ0
	0b0001	PRSREQ1		PRSREQ1
	<i>SOURCESEL</i> = 0b001000			(ADC0)
	0b0000	ADC0SINGLE		ADC0SINGLE REQ/SREQ
	0b0001	ADC0SCAN		ADC0SCAN REQ/SREQ
	<i>SOURCESEL</i> = 0b001010			(VDAC0)
	0b0000	VDAC0CH0		VDAC0CH0
	0b0001	VDAC0CH1		VDAC0CH1
	<i>SOURCESEL</i> = 0b001100			(USART0)
	0b0000	USART0RXDATAV		USART0RXDATAV REQ/SREQ
	0b0001	USART0TXBL		USART0TXBL REQ/SREQ
	0b0010	USART0TXEMPTY		USART0TXEMPTY
	<i>SOURCESEL</i> = 0b001101			(USART1)
	0b0000	USART1RXDATAV		USART1RXDATAV REQ/SREQ
	0b0001	USART1TXBL		USART1TXBL REQ/SREQ
	0b0010	USART1TXEMPTY		USART1TXEMPTY
	0b0011	USART1RXDATAV- RIGHT		USART1RXDATAVRIGHT REQ/SREQ
	0b0100	USART1TXBLRIGHT		USART1TXBLRIGHT REQ/SREQ
	<i>SOURCESEL</i> = 0b001110			(USART2)
	0b0000	USART2RXDATAV		USART2RXDATAV REQ/SREQ
	0b0001	USART2TXBL		USART2TXBL REQ/SREQ
	0b0010	USART2TXEMPTY		USART2TXEMPTY
	<i>SOURCESEL</i> = 0b001111			(USART3)
	0b0000	USART3RXDATAV		USART3RXDATAV REQ/SREQ
	0b0001	USART3TXBL		USART3TXBL REQ/SREQ
	0b0010	USART3TXEMPTY		USART3TXEMPTY
	0b0011	USART3RXDATAV- RIGHT		USART3RXDATAVRIGHT REQ/SREQ
	0b0100	USART3TXBLRIGHT		USART3TXBLRIGHT REQ/SREQ
	<i>SOURCESEL</i> = 0b010010			(UART0)
	0b0000	UART0RXDATAV		UART0RXDATAV REQ/SREQ

Bit	Name	Reset	Access	Description
0b0001	UART0TXBL			UART0TXBL REQ/SREQ
0b0010	UART0TXEMPTY			UART0TXEMPTY
SOURCESEL =	0b010100			(LEUART0)
0b0000	LEUART0RXDATAV			LEUART0RXDATAV
0b0001	LEUART0TXBL			LEUART0TXBL
0b0010	LEUART0TXEMPTY			LEUART0TXEMPTY
SOURCESEL =	0b010110			(I2C0)
0b0000	I2C0RXDATAV			I2C0RXDATAV REQ/SREQ
0b0001	I2C0TXBL			I2C0TXBL REQ/SREQ
SOURCESEL =	0b010111			(I2C1)
0b0000	I2C1RXDATAV			I2C1RXDATAV REQ/SREQ
0b0001	I2C1TXBL			I2C1TXBL REQ/SREQ
SOURCESEL =	0b011001			(TIMER0)
0b0000	TIMER0UFOF			TIMER0UFOF
0b0001	TIMER0CC0			TIMER0CC0
0b0010	TIMER0CC1			TIMER0CC1
0b0011	TIMER0CC2			TIMER0CC2
SOURCESEL =	0b011010			(TIMER1)
0b0000	TIMER1UFOF			TIMER1UFOF
0b0001	TIMER1CC0			TIMER1CC0
0b0010	TIMER1CC1			TIMER1CC1
0b0011	TIMER1CC2			TIMER1CC2
0b0100	TIMER1CC3			TIMER1CC3
SOURCESEL =	0b100000			(WTIMER0)
0b0000	WTIMER0UFOF			WTIMER0UFOF
0b0001	WTIMER0CC0			WTIMER0CC0
0b0010	WTIMER0CC1			WTIMER0CC1
0b0011	WTIMER0CC2			WTIMER0CC2
SOURCESEL =	0b100001			(WTIMER1)
0b0000	WTIMER1UFOF			WTIMER1UFOF
0b0001	WTIMER1CC0			WTIMER1CC0
0b0010	WTIMER1CC1			WTIMER1CC1
0b0011	WTIMER1CC2			WTIMER1CC2
0b0100	WTIMER1CC3			WTIMER1CC3
SOURCESEL =	0b110000			(MSC)
0b0000	MSCWDATA			MSCWDATA REQ/SREQ
SOURCESEL =	0b110001			(CRYPTO0)

Bit	Name	Reset	Access	Description
0b0000		CRYPTO0DATA0WR	CRYPTO0DATA0WR	
0b0001		CRYPTO0DATA0XWR	CRYPTO0DATA0XWR	
0b0010		CRYPTO0DATA0RD	CRYPTO0DATA0RD	
0b0011		CRYPTO0DATA1WR	CRYPTO0DATA1WR	
0b0100		CRYPTO0DATA1RD	CRYPTO0DATA1RD	
SOURCESEL =	<i>0b111101</i>		(CSEN)	
0b0000	CSENDATA		CSENDATA	
0b0001	CSENBSLN		CSENBSLN	
SOURCESEL =	<i>0b111110</i>		(LESENSE)	
0b0000	LESENSEBUFDATAV		LESENSEBUFDATAV REQ/SREQ	

## 7.6.18 LDMA\_CHx\_CFG - Channel Configuration Register

Offset	Bit Position																															
0x084	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																															
Access	RW																															
Name	ARBSLOTS																															

Bit	Name	Reset	Access	Description
31:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
21	DSTINCSIGN	0	RW	<b>Destination Address Increment Sign</b>
	Value	Mode		Description
	0	POSITIVE		Increment destination address
	1	NEGATIVE		Decrement destination address
20	SRCINCSIGN	0	RW	<b>Source Address Increment Sign</b>
	Value	Mode		Description
	0	POSITIVE		Increment source address
	1	NEGATIVE		Decrement source address
19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
17:16	ARBSLOTS	0x0	RW	<b>Arbitration Slot Number Select</b>
	For channels using round robin arbitration, this bit-field is used to select the number of slots in the round robin queue.			
	Value	Mode		Description
	0	ONE		One arbitration slot selected
	1	TWO		Two arbitration slots selected
	2	FOUR		Four arbitration slots selected
	3	EIGHT		Eight arbitration slots selected
15:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 7.6.19 LDMA\_CHx\_LOOP - Channel Loop Counter Register

Offset	Bit Position																																	
0x088	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																	0x00	
Access																																	RWH	
Name																																		LOOPCNT

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	LOOPCNT	0x00	RWH	<b>Linked Structure Sequence Loop Counter</b>  This bit-field specifies the number of iterations when using looping descriptors. Software should write to LOOPCNT before using a looping descriptor.

## 7.6.20 LDMA\_CHx\_CTRL - Channel Descriptor Control Word Register

Offset	Bit Position																																		
0x08C	31	0	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset	R	0	R	0	RWH	0x0	RWH	0x0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	
Access	R	W	R	R	RWH	0x0	RWH	0x0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	RWH	0	
Name	DSTMODE	SRCMODE	DSTINC	SIZE	SRCINC	IGNORESREQ	DECLOOPCNT	REQMODE	DONEIFSEN	BLOCKSIZE	BYTESWAP	XFERCNT	STRUCTREQ	STRUCTTYPE																					

Bit	Name	Reset	Access	Description															
31	DSTMODE	0	R	<b>Destination Addressing Mode</b>															
				This field specifies the destination addressing mode of linked descriptors. After loading a linked descriptor, reading this field will indicate the destination addressing mode of the linked descriptor. Note that the first descriptor always uses absolute addressing mode.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ABSOLUTE</td> <td>The DSTADDR field of LDMA_CHx_DST contains the absolute address of the destination data.</td> </tr> <tr> <td>1</td> <td>RELATIVE</td> <td>The DSTADDR field of LDMA_CHx_DST contains the relative offset of the destination data.</td> </tr> </tbody> </table>	Value	Mode	Description	0	ABSOLUTE	The DSTADDR field of LDMA_CHx_DST contains the absolute address of the destination data.	1	RELATIVE	The DSTADDR field of LDMA_CHx_DST contains the relative offset of the destination data.						
Value	Mode	Description																	
0	ABSOLUTE	The DSTADDR field of LDMA_CHx_DST contains the absolute address of the destination data.																	
1	RELATIVE	The DSTADDR field of LDMA_CHx_DST contains the relative offset of the destination data.																	
30	SRCMODE	0	R	<b>Source Addressing Mode</b>															
				This field specifies the source addressing mode of linked descriptors. After loading a linked descriptor, reading this field will indicate the source addressing mode of the linked descriptor. Note that the first descriptor always uses absolute addressing mode.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ABSOLUTE</td> <td>The SRCADDR field of LDMA_CHx_SRC contains the absolute address of the source data.</td> </tr> <tr> <td>1</td> <td>RELATIVE</td> <td>The SRCADDR field of LDMA_CHx_SRC contains the relative offset of the source data.</td> </tr> </tbody> </table>	Value	Mode	Description	0	ABSOLUTE	The SRCADDR field of LDMA_CHx_SRC contains the absolute address of the source data.	1	RELATIVE	The SRCADDR field of LDMA_CHx_SRC contains the relative offset of the source data.						
Value	Mode	Description																	
0	ABSOLUTE	The SRCADDR field of LDMA_CHx_SRC contains the absolute address of the source data.																	
1	RELATIVE	The SRCADDR field of LDMA_CHx_SRC contains the relative offset of the source data.																	
29:28	DSTINC	0x0	RWH	<b>Destination Address Increment Size</b>															
				This bit-field specifies the stride or number of unit data addresses to increment the destination address after each unit of data is transferred. The unit data width is controlled by the SIZE bit-field and can be a byte, half-word or word.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>ONE</td> <td>Increment destination address by one unit data size after each write</td> </tr> <tr> <td>1</td> <td>TWO</td> <td>Increment destination address by two unit data sizes after each write</td> </tr> <tr> <td>2</td> <td>FOUR</td> <td>Increment destination address by four unit data sizes after each write</td> </tr> <tr> <td>3</td> <td>NONE</td> <td>Do not increment the destination address. Writes are made to a fixed destination address, for example writing to a FIFO.</td> </tr> </tbody> </table>	Value	Mode	Description	0	ONE	Increment destination address by one unit data size after each write	1	TWO	Increment destination address by two unit data sizes after each write	2	FOUR	Increment destination address by four unit data sizes after each write	3	NONE	Do not increment the destination address. Writes are made to a fixed destination address, for example writing to a FIFO.
Value	Mode	Description																	
0	ONE	Increment destination address by one unit data size after each write																	
1	TWO	Increment destination address by two unit data sizes after each write																	
2	FOUR	Increment destination address by four unit data sizes after each write																	
3	NONE	Do not increment the destination address. Writes are made to a fixed destination address, for example writing to a FIFO.																	

Bit	Name	Reset	Access	Description
27:26	SIZE	0x0	RWH	<b>Unit Data Transfer Size</b>  This field specifies the size of data transferred.
	Value	Mode		Description
	0	BYTE		Each unit transfer is a byte
	1	HALFWORD		Each unit transfer is a half-word
	2	WORD		Each unit transfer is a word
25:24	SRCINC	0x0	RWH	<b>Source Address Increment Size</b>  This bit-field specifies the stride or number of unit data addresses to increment the source address after each unit of data is transferred. The unit data width is controlled by the SIZE bit-field and can be a byte, half-word or word.
	Value	Mode		Description
	0	ONE		Increment source address by one unit data size after each read
	1	TWO		Increment source address by two unit data sizes after each read
	2	FOUR		Increment source address by four unit data sizes after each read
	3	NONE		Do not increment the source address. In this mode reads are made from a fixed source address, for example reading FIFO.
23	IGNORESREQ	0	RWH	<b>Ignore Sreq</b>  The channel arbiter will ignore single requests (SREQ) and only respond to multiple requests (REQ) when this bit is set.
22	DECLOOPCNT	0	RWH	<b>Decrement Loop Count</b>  When using looping, setting this bit will decrement the LOOPCNT field in the LDMA_CHx_LOOP register after each descriptor execution.
21	REQMODE	0	RWH	<b>DMA Request Transfer Mode Select</b>  Value Mode Description
	0	BLOCK		The LDMA transfers one BLOCKSIZE per transfer request.
	1	ALL		One transfer request transfers all units as defined by the XFCNT field.
20	DONEIFSEN	0	RWH	<b>DMA Operation Done Interrupt Flag Set Enable</b>  Setting this bit will set the interrupt flag when the transfer is done, or linked in the case where the LINK bit is set, or synchronized in the case of a SYNC transfer.
19:16	BLOCKSIZE	0x0	RWH	<b>Block Transfer Size</b>  This bit-field controls the number of unit data transfers per arbitration cycle
	Value	Mode		Description
	0	UNIT1		One unit transfer per arbitration
	1	UNIT2		Two unit transfers per arbitration
	2	UNIT3		Three unit transfers per arbitration
	3	UNIT4		Four unit transfers per arbitration
	4	UNIT6		Six unit transfers per arbitration

Bit	Name	Reset	Access	Description
5	UNIT8			Eight unit transfers per arbitration
7	UNIT16			Sixteen unit transfers per arbitration
9	UNIT32			32 unit transfers per arbitration
10	UNIT64			64 unit transfers per arbitration
11	UNIT128			128 unit transfers per arbitration
12	UNIT256			256 unit transfers per arbitration
13	UNIT512			512 unit transfers per arbitration
14	UNIT1024			1024 unit transfers per arbitration
15	ALL			Transfer all units as specified by the XFRCNT field
15	BYTESWAP	0	RWH	<b>Endian Byte Swap</b>
				For word and half-word transfers, setting this bit will swap all bytes of each word or half-word.
14:4	XFERCNT	0x000	RWH	<b>DMA Unit Data Transfer Count</b>
				Specifies number of unit data (words, half-words, or bytes) to transfer, as determined by the SIZE field. The value written should be one less than the desired transfer count.
3	STRUCTREQ	0	W1	<b>Structure DMA Transfer Request</b>
				When a linked descriptor is loaded with this bit set, it will immediately trigger a transfer.
2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	STRUCTTYPE	0x0	R	<b>DMA Structure Type</b>
	Value	Mode		Description
	0	TRANSFER		DMA transfer structure type selected.
	1	SYNCHRONIZE		Synchronization structure type selected.
	2	WRITE		Write immediate value structure type selected.

**7.6.21 LDMA\_CHx\_SRC - Channel Descriptor Source Data Address Register**

Offset	Bit Position																																
0x090	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RWH																																
Name	SRCADDR																																

Bit	Name	Reset	Access	Description
31:0	SRCADDR	0x00000000	RWH	<b>Source Data Address</b>
Writing to this register sets the source address. Reading from this register during a DMA transfer will indicate the next source read address. The value of this register is incremented or decremented with each source read.				

**7.6.22 LDMA\_CHx\_DST - Channel Descriptor Destination Data Address Register**

Offset	Bit Position																																
0x094	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RWH																																
Name	DSTADDR																																


Bit	Name	Reset	Access	Description
31:0	DSTADDR	0x00000000	RWH	<b>Destination Data Address</b>
Writing to this register sets the destination address. Reading from this register during a DMA transfer will indicate the next destination write address. This value of this register is incremented or decremented with each destination write.				

## 7.6.23 LDMA\_CHx\_LINK - Channel Descriptor Link Structure Address Register

Offset	Bit Position																															
0x098	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																													0	0	
Access	RWH																													RWH	R	
Name	LINKADDR																														LINK	LINKMODE

Bit	Name	Reset	Access	Description
31:2	LINKADDR	0x00000000	RWH	<b>Link Structure Address</b>
				To use linking, write the address of the the first linked descriptor to this register. When a linked descriptor is loaded, it may also be linked to another descriptor. Reading this register will reflect the address of the next linked descriptor.
1	LINK	0	RWH	<b>Link Next Structure</b>
				After completing the initial transfer, if this bit is set, the DMA will load the next linked descriptor. If the next linked descriptor also has this bit set, the DMA will load the next linked descriptor.
0	LINKMODE	0	R	<b>Link Structure Addressing Mode</b>
				This field specifies the addressing mode of linked descriptors. After loading a linked descriptor, reading this field will indicate the addressing mode of the loaded linked descriptor. Note that the first descriptor always uses absolute addressing mode.
Value	Mode	Description		
0	ABSOLUTE	The LINKADDR field of LDMA_CHx_LINK contains the absolute address of the linked descriptor.		
1	RELATIVE	The LINKADDR field of LDMA_CHx_LINK contains the relative offset of the linked descriptor.		

## 8. RMU - Reset Management Unit



### Quick Facts

#### What?

The RMU ensures correct reset operation. It is responsible for connecting the different reset sources to the reset lines of the EFM32 Tiny Gecko 11.

#### Why?

A correct reset sequence is needed to ensure safe and synchronous startup of the EFM32 Tiny Gecko 11. In the case of error situations such as power supply glitches or software crash, the RMU provides proper reset and startup of the EFM32 Tiny Gecko 11.

#### How?

The Power-on Reset and Brown-out Detector of the EFM32 Tiny Gecko 11 provides power line monitoring with exceptionally low power consumption. The cause of the reset may be read from a register, thus providing software with information about the cause of the reset.

### 8.1 Introduction


The RMU is responsible for handling the reset functionality of the EFM32 Tiny Gecko 11.

### 8.2 Features

- Reset sources
  - Power-on Reset (POR)
  - Brown-out Detection (BOD) on the following power domains:
    - Analog Unregulated Power Domain AVDD
    - Digital Unregulated Power Domain DVDD
    - Regulated Digital Domain DECOUPLE (DEC)
  - RESETn pin reset
  - Watchdog reset
  - Software triggered reset (SYSRESETREQ)
  - Core LOCKUP condition
- EM4 Hibernate/Shutoff Detection
- EM4 Hibernate/Shutoff wakeup reset from GPIO pin
- Configurable reset levels
- A software readable register indicates the cause of the last reset

### 8.3 Functional Description

The RMU monitors each of the reset sources of the EFM32 Tiny Gecko 11. If one or more reset sources go active, the RMU applies reset to the EFM32 Tiny Gecko 11. When the reset sources go inactive the EFM32 Tiny Gecko 11 starts up. At startup the EFM32 Tiny Gecko 11 loads the stack pointer and program entry point from memory, and starts execution. [Figure 8.1 RMU Reset Input Sources and Connections on page 212](#) shows an overview of the reset system on EFM32 Tiny Gecko 11.



**Figure 8.1. RMU Reset Input Sources and Connections**

### 8.3.1 Reset Levels

The reset sources on EFM32 Tiny Gecko 11 can be divided in two main groups; Hard resets and Soft resets.

The soft resets can be configured to be either DISABLED, LIMITED, EXTENDED or FULL. The reset level for soft reset sources is configured in the xxxRMODE bitfields in RMU\_CTRL.

**Table 8.1. Reset Levels**

RMU_CTRL_xxxRMODE	Parts of System Reset
DISABLED	Nothing is reset, request will not be registered in RMU_RSTCAUSE
LIMITED	Everything reset, with exception of CRYOTIMER, DEBUGGER, RTCC, VMON and parts of CMU, RMU and EMU.
EXTENDED	Everything reset, with exception of CRYOTIMER, DEBUGGER, and parts of CMU, RMU and EMU.
FULL	Everything reset, with exception of some registers in RMU and EMU.

The reset sources resulting in a soft reset are:

- Watchdog reset
- Lockup reset
- System reset request
- Pin reset (Pin reset can be configured to be either a soft or a hard reset, see [8.3.5 RESETn Pin Reset](#) for details.)

**Note:** LIMITED and EXTENDED resets are synchronized to HFSRCCLK. If HFSRCCLK is slow, there will be latency on reset assertion. If HFSRCCLK is not running, reset will be asserted after a timeout.

Hard resets will reset the entire chip, the reset sources resulting in a hard reset are:

- Power-on reset
- Brown-out reset
- Pin reset (Pin reset can be configured to be either a soft or a hard reset, see [8.3.5 RESETn Pin Reset](#) for details.)

### 8.3.2 RMU\_RSTCAUSE Register

Whenever a reset source is active, the corresponding bit in the RMU\_RSTCAUSE register is set. At startup the program code may investigate this register in order to determine the cause of the reset. The register is cleared upon POR and software write to RMU\_CMD\_RCCLR. The register should be cleared after the value has been read at startup, otherwise the register may indicate multiple causes for the reset at next startup.

RMU\_RSTCAUSE should be interpreted according to [Table 8.2 RMU Reset Cause Register Interpretation on page 214](#). In [Table 8.2 RMU Reset Cause Register Interpretation on page 214](#), the reset causes are ordered by severity from right to left. A reset cause bit is invalidated (i.e. can not be trusted) if one of the bits to the right of it does not match the table. X bits are don't care.

**Note:** It is possible to have multiple reset causes. For example, an external reset and a watchdog reset may happen simultaneously.


**Table 8.2. RMU Reset Cause Register Interpretation**

RMU_RSTCAUSE											Reset cause
EM4RST	BUMODERST	WDOGRST	SYSREQRST	LOCKUPRST	EXTRST	DECBOD	DVDBDBOD	AVDDBOD	PORST		
X	X	X	X	X	X	X	X	X	1		Power on reset
X	X	X	X	X	X	X	X	1	0		Brown-out on AVDD power
X	X	X	X	X	X	X	1	X	0		Brown-out on DVDD power
X	X	X	X	X	X	1	X	X	0		Brown-out on DEC power
X	X	X	X	X	1	X	X	X	0		Pin reset
X	X	X	X	1	0/X <sup>1</sup>	0	0	0	0		Lockup reset
X	X	X	1	X	0/X <sup>1</sup>	0	0	0	0		System reset request
X	X	1	X	X	0/X <sup>1</sup>	0	0	0	0		Watchdog reset
1	1	X	X	X	0/X <sup>1</sup>	0	0	X <sup>2</sup>	0		System has been in backup mode
1	X	X	X	X	0/X <sup>1</sup>	0	0	0	0		System has been in EM4

1. Pin reset configured as hard/soft  
2. AVDDBOD is set to 1 if the reset is caused by a BOD on BUVDD. AVDDBOD will not be set on AVDD recovery or a hard pin reset.

### 8.3.3 Power-On Reset (POR)


The POR ensures that the EFM32 Tiny Gecko 11 does not start up before the AVDD supply voltage has reached the threshold voltage VPORthr (roughly 1.2V). Before the POR threshold voltage is reached, the EFM32 Tiny Gecko 11 is kept in reset state. The operation of the POR is illustrated in [Figure 8.2 RMU Power-on Reset Operation on page 215](#), with the active low POWERONn reset signal. The reason for the “unknown” region is that the corresponding supply voltage is too low for any reliable operation.



**Figure 8.2. RMU Power-on Reset Operation**

### 8.3.4 Brown-Out Detector (BOD)

The EFM32 Tiny Gecko 11 has 3 brownout detectors, one for the unregulated power (DVDD), one for the regulated internal power (DECOUPLE), and one for the Analog Power Domain (AVDD). The BODs are constantly monitoring these supply voltages. Whenever the unregulated or regulated power drops below the VBODthr value (see the Electrical Characteristics section of the data sheet for details), or if AVDD drops below the voltage at the DECOUPLE pin, the corresponding active low BROWNOUTn line is held low. The BODs also include hysteresis, which prevents instability in the corresponding BROWNOUTn line when the supply is crossing the VBODthr limit or the AVDD supply drops below the DECOUPLE pin. The operation of the BOD is illustrated in [Figure 8.3 RMU Brown-out Detector Operation on page 215](#). The “unknown” regions are handled by the POR module.



**Figure 8.3. RMU Brown-out Detector Operation**

### 8.3.5 RESETn Pin Reset

The pin reset on EFM32 Tiny Gecko 11 can be configured to be either hard or soft. By default, pin reset is configured as a soft reset source. To configure it as a hard reset, clear the PINRESETSOFT bit in CLW0 in the Lock bit page, see [6.3.2 Lock Bits \(LB\) Page Description](#) for details. Forcing the RESETn pin low generates a reset of the EFM32 Tiny Gecko 11. The RESETn pin includes an on-chip pull-up resistor, and can therefore be left unconnected if no external reset source is needed. Also connected to the RESETn line is a filter which prevents glitches from resetting the EFM32 Tiny Gecko 11.

### 8.3.6 Watchdog Reset

The Watchdog circuit is a timer which (when enabled) must be cleared by software regularly. If software does not clear it, a Watchdog reset is activated. This functionality provides recovery from a software stalemate. Refer to the Watchdog section for specifications and description. The Watchdog reset can be configured to cause different levels of reset as determined by WDOGRMODE in the RMU\_CTRL register.

### 8.3.7 Lockup Reset

A Cortex-M0+ lockup is the result of the core being locked up because of an unrecoverable exception following the activation of the processor's built-in system state protection hardware.

A Cortex-M0+ lockup gives immediate indication of seriously errant kernel software. This is the result of the core being locked up due to an unrecoverable exception following the activation of the processor's built in system state protection hardware. For more information about the Cortex-M0+ lockup conditions see the ARMv6-M Architecture Reference Manual. The Lockup reset does not reset the Debug Interface, unless configured as a FULL reset. The Lockup reset can be configured to cause different levels of reset as determined by the LOCKUPRMODE bits in the RMU\_CTRL register. This includes disabling the reset.

### 8.3.8 System Reset Request

Software may initiate a reset (e.g. if it finds itself in a non-recoverable state). By asserting the SYSRESETREQ in the Application Interrupt and Reset Control Register, a reset is issued. The SYSRESETREQ does not reset the Debug Interface, unless configured as a FULL reset. The SYSRESETREQ reset can be configured to cause different levels of reset as determined by SYSRESETRMODE bits in the RMU\_CTRL register. This includes disabling the reset.

### 8.3.9 Reset State

The RESETSTATE bitfield in RMU\_CTRL is a read-write register intended for software use only, and can be used to keep track of state throughout a reset. This bitfield is only reset by POR and hard pin reset.

### 8.3.10 Register Reset Signals

[Figure 8.1 RMU Reset Input Sources and Connections on page 212](#) shows an overview of how the different parts of the design are affected by the different levels of reset. For RMU, EMU and CMU there are some exceptions. These are given in the following tables.

### 8.3.10.1 Registers With Alternate Reset

**Table 8.3. Alternate Reset for Registers in RMU**

<b>RMU Reset Levels</b>	
POR and hard pin reset	RMU_CTRL_WDOGRMODE RMU_CTRL_LOCKUPRMODE RMU_CTRL_SYSRMODE RMU_CTRL_PINRMODE RMU_CTRL_RESETSTATE
FULL reset	RMU_LOCK_LOCKKEY

**Table 8.4. Alternate Reset for Registers in CMU**

<b>CMU Reset Levels</b>	
FULL reset	CMU_LFRCOCTRL CMU_LFXOCTRL
EXTENDED reset	CMU_LFECLKSEL CMU_LFECLKEN0 CMU_LFEPRESC0

**Table 8.5. Alternate Reset for Registers in EMU**

<b>EMU Reset Levels</b>	
POR, BOD, and hard pin reset	EMU_BIASCONF_LSBIAS_SEL
POR, BOD, and hard pin reset	EMU_DCDCLNVCTRL
POR and hard pin reset	EMU_CTRL_EM2BODDIS EMU_BUCTRL
POR, BOD, and hard pin reset	EMU_PWRCTRL EMU_DCDCCTRL EMU_DCDCMISCCTRL EMU_DCDCZDETCTRL EMU_DCDCLIMCTRL EMU_DCDCLNCOMPCTRL EMU_DCDCLPVCTRL EMU_DCDCLPCTRL EMU_DCDCLNFREQCTRL EMU_DCDCLPEM01CFG

EMU Reset Levels	
EXTENDED reset	EMU_VMONAVDDCTRL EMU_VMONALTAVDDCTRL EMU_VMONDVDDCTRL EMU_VMONIO0CTRL EMU_VMONBUVDDCTRL
FULL reset	EMU_EM4CTRL

#### 8.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	RMU_CTRL	RW	Control Register
0x004	RMU_RSTCAUSE	R	Reset Cause Register
0x008	RMU_CMD	W1	Command Register
0x00C	RMU_RST	RW	Reset Control Register
0x010	RMU_LOCK	RWH	Configuration Lock Register

## 8.5 Register Description

### 8.5.1 RMU\_CTRL - Control Register

Offset	Bit Position																																			
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset							0x0												0x4																	
Access		RW																	RW																	
Name		RESETSTATE																PINRMODE																		
																		SYSRMODE																		
																		LOCKUPRMODE																		
																		WDOGRMODE																		

Bit	Name	Reset	Access	Description
31:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
25:24	RESETSTATE	0x0	RW	<b>System Software Reset State</b>
				Bit-field for software use only. This field has no effect on the RMU and is reset by power-on reset and hard pin reset only.
23:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
14:12	PINRMODE	0x4	RW	<b>PIN Reset Mode</b>
				Controls the reset level for Pin reset request. These settings only apply when PINRESETSOFT in CLW0 in the Lock bit page is set.
	Value	Mode		Description
	0	DISABLED		Reset request is blocked.
	1	LIMITED		The CRYOTIMER, DEBUGGER, RTCC, are not reset.
	2	EXTENDED		The CRYOTIMER, DEBUGGER are not reset. RTCC is reset.
	4	FULL		The entire device is reset except some EMU and RMU registers.
11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10:8	SYSRMODE	0x2	RW	<b>Core Sysreset Reset Mode</b>
				Controls the reset level for Core SYSREST reset request.
	Value	Mode		Description
	0	DISABLED		Reset request is blocked.
	1	LIMITED		The CRYOTIMER, DEBUGGER, RTCC, are not reset.
	2	EXTENDED		The CRYOTIMER, DEBUGGER are not reset. RTCC is reset.
	4	FULL		The entire device is reset except some EMU and RMU registers.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

Bit	Name	Reset	Access	Description
6:4	LOCKUPRMODE	0x0	RW	<b>Core LOCKUP Reset Mode</b>
Controls the reset level for Core LOCKUP reset request.				
	Value	Mode		Description
	0	DISABLED		Reset request is blocked.
	1	LIMITED		The CRYOTIMER, DEBUGGER, RTCC, are not reset.
	2	EXTENDED		The CRYOTIMER, DEBUGGER are not reset. RTCC is reset.
	4	FULL		The entire device is reset except some EMU and RMU registers.
3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
2:0	WDOGRMODE	0x4	RW	<b>WDOG Reset Mode</b>
Controls the reset level for WDOG reset request.				
	Value	Mode		Description
	0	DISABLED		Reset request is blocked. This disable bit is redundant with enable/disable bit in WDOG
	1	LIMITED		The CRYOTIMER, DEBUGGER, RTCC, are not reset.
	2	EXTENDED		The CRYOTIMER, DEBUGGER are not reset. RTCC is reset.
	4	FULL		The entire device is reset except some EMU and RMU registers.

### 8.5.2 RMU\_RSTCAUSE - Reset Cause Register

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	EM4RST	0	R	<b>EM4 Reset</b>  Set if the system has been in EM4. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	BUMODERST	0	R	<b>Backup Mode Reset</b>  Set if the system has been in Backup mode. Must be cleared by software. See EMU chapter for details on how to interpret this bit.
11	WDOGRST	0	R	<b>Watchdog Reset</b>  Set if a watchdog reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
10	SYSREQRST	0	R	<b>System Request Reset</b>  Set if a system request reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
9	LOCKUPRST	0	R	<b>LOCKUP Reset</b>  Set if a LOCKUP reset has been requested. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
8	EXTRST	0	R	<b>External Pin Reset</b>  Set if an external pin reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	DECBOD	0	R	<b>Brown Out Detector Decouple Domain Reset</b>  Set if a regulated domain brown out detector reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
3	DVDBOD	0	R	<b>Brown Out Detector DVDD Reset</b>  Set if a unregulated domain brown out detector reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.
2	AVDDBOD	0	R	<b>Brown Out Detector AVDD Reset</b>  Set if a unregulated domain brown out detector reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.

Bit	Name	Reset	Access	Description
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PORST	0	R	<b>Power on Reset</b>  Set if a power on reset has been performed. Must be cleared by software. See <a href="#">8.3.2 RMU_RSTCAUSE Register</a> for details on how to interpret this bit.

### 8.5.3 RMU\_CMD - Command Register

Offset	Bit Position																																				
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0					
<b>Reset</b>																																					
<b>Access</b>																																					
<b>Name</b>																																				RCCLR	W1 0

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	RCCLR	0	W1	<b>Reset Cause Clear</b>  Set this bit to clear the RSTCAUSE register.

### 8.5.4 RMU\_RST - Reset Control Register

Offset	Bit Position																																				
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0					
<b>Reset</b>																																					
<b>Access</b>																																					
<b>Name</b>																																					

Bit	Name	Reset	Access	Description
31:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 8.5.5 RMU\_LOCK - Configuration Lock Register


Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x0000						
Access																										RWH						
Name																										LOCKKEY						

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:0	LOCKKEY	0x0000	RWH	<b>Configuration Lock Key</b>
Write any other value than the unlock code to lock RMU_CTRL and RMU_RST from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.				

Mode	Value	Description
Read Operation		
UNLOCKED	0	RMU registers are unlocked
LOCKED	1	RMU registers are locked
Write Operation		
LOCK	0	Lock RMU registers
UNLOCK	0xE084	Unlock RMU registers

## 9. EMU - Energy Management Unit



### Quick Facts

#### What?

The EMU (Energy Management Unit) handles the different low energy modes in EFM32 Tiny Gecko 11

#### Why?

The need for performance and peripheral functions varies over time in most applications. By efficiently scaling the available resources in real time to match the demands of the application, the energy consumption can be kept at a minimum.

#### How?

With a broad selection of energy modes, a high number of low-energy peripherals available even in EM2 DeepSleep, and short wake-up time (2 µs from EM2 DeepSleep and EM3 Stop), applications can dynamically minimize energy consumption during program execution.

### 9.1 Introduction

The Energy Management Unit (EMU) manages all the low energy modes (EM) in EFM32 Tiny Gecko 11. Each energy mode manages whether the CPU and the various peripherals are available. The energy modes range from EM0 Active to EM4 Shutoff. EM0 Active mode provides the highest amount of features, enabling the CPU, and peripherals with the highest clock frequency. EM4 Shutoff Mode provides the lowest power state, allowing the part to return to EM0 Active on a wake-up condition. The EMU also controls the various power routing configurations, internal regulators settings, and voltage monitoring needed for optimal power configuration and protection.


## 9.2 Features

The primary features of the EMU are listed below:

- Energy Modes control
  - Entry into EM4 Hibernate or EM4 Shutoff
  - Configuration of regulators and clocks for each Energy Mode
  - Configuration of various EM4 Hibernate/Shutoff wake-up conditions
  - Configuration of RAM power and retention settings
  - Configuration of GPIO retention settings
- Power routing configurations
  - DCDC control
  - Internal power switches allowing for extensible system power architecture
- Temperature measurement control and status
- Brown Out Detection
- Voltage Monitoring
  - Four dedicated continuous monitor channels
  - Optional monitor features include interrupt generation and low power mode wake-up
- State Retention
- Voltage Scaling
  - EM0/EM1 voltage scaling
  - EM2/EM3 voltage scaling
  - EM4H voltage scaling

### 9.3 Functional Description

The EMU is responsible for managing the wide range of energy modes available in EFM32 Tiny Gecko 11. The block works in harmony with the entire platform to easily transition between energy modes in the most efficient manner possible. The following diagram [Figure 9.1 EMU Overview on page 226](#), shows the relative connectivity to the various blocks in the system.



**Figure 9.1. EMU Overview**

The EMU is available on the peripheral bus. The energy management state machine controls the internal voltage regulators, oscillators, memories, and interrupt system. Events, interrupts, and resets can trigger the energy management state machine to return to the active state. This is further described in the following sections.

The power architecture is highly configurable to meet system power performance needs. Several external power configurations are supported. The EMU allows flexible control of internal DCDC, Digital LDO Regulator, and internal power switching.

### 9.3.1 Energy Modes

EFM32 Tiny Gecko 11 features six main energy modes, referred to as Energy Mode 0 (EM0 Active) through Energy Mode 4 (EM4 Shutoff). The Cortex-M0+ is only available for program execution in EM0 Active. In EM0 Active/EM1 Sleep any peripheral function can be enabled. EM2 DeepSleep through EM4 Shutoff, also referred to as low energy modes, provide a significantly reduced energy consumption while still allowing a rich set of peripheral functionality. The following [Table 9.1 table on page 227](#) shows the possible transitions between different energy modes.

**Table 9.1. Energy Mode Transitions**

Current Mode	EM Transition Action					
	Enter EM0 Active	Enter EM1 Sleep	Enter EM2 DeepSleep	Enter EM3 Stop	Enter EM4 Hibernate	Enter EM4 Shutoff
EM0 Active		Sleep (WFI, WFE)	Deep Sleep (WFI, WFE)	Deep Sleep (WFI, WFE)	EM4 Entry	EM4 Entry
EM1 Sleep	IRQ		Peripheral wake up done <sup>1</sup>	Peripheral wake up done <sup>1</sup>		
EM2 DeepSleep	IRQ	Peripheral wake up req <sup>1</sup>				
EM3 Stop	IRQ	Peripheral wake up req <sup>1</sup>				
EM4 Hibernate	Wake Up					
EM4 Shutoff	Wake Up					

**Note:**

- Peripheral wake-up from EM2/3 to EM1 and then automatically back to EM2/3 when done.

The CSEN, LESENSE, ADC and LEUART have the ability to temporarily wake up the part from either EM2 DeepSleep or EM3 Stop to EM1 Sleep in order to transfer data. Once completed, the part is automatically placed back into the EM2 DeepSleep or EM3 Stop mode.

The Core can always request to go to EM1 Sleep with the WFI or WFE command during EM0 Active. The core will be prevented from entering EM2 DeepSleep or EM3 Stop if Flash is programming or erasing.

An overview of supported energy modes and available functionality is shown in [Table 9.2 EMU Energy Mode Overview on page 227](#). For each energy mode, the system will typically default to its lowest power configuration, with non-essential clocks and peripherals disabled. Functionality may be then selectively enabled by software.

**Table 9.2. EMU Energy Mode Overview**

	EM0 Active/EM1 Sleep	EM2 Deep-Sleep	EM3 Stop	EM4 Hibernate	EM4 Shutoff
Wake-up time to EM0 Active/EM1 Sleep	—	2 µs <sup>1</sup>	2 µs <sup>1</sup>	160 µs <sup>1</sup>	160 µs <sup>1</sup>
Core Active	Yes, in EM0 only	—	—	—	—
Debug	Available	See Note <sup>2</sup>	See Note <sup>2</sup>	—	—
Digital logic and system RAM retained	Yes	Yes	Yes	—	—
Flash Memory Access	Available	—	—	—	—
LDMA (Linked DMA Controller)	Available	Available <sup>3</sup>	Available <sup>3</sup>	—	—

	EM0 Active/EM1 Sleep	EM2 Deep-Sleep	EM3 Stop	EM4 Hibernate	EM4 Shutoff
High Frequency Oscillators (HFRCO, HFXO) and Clocks (HFSRCLK, HFCLK, HFCORECLK, HFBUSCLK, HPERCLK, HPERBCLK, HPERCCLK, HFCLKLE)	Available	—	—	—	—
Auxiliary High Frequency Oscillator (AUXHFR-CO) and Clock (AUXCLK)	Available	Available <sup>4</sup>	Available <sup>4</sup>	—	—
Low Frequency Oscillators (LFRCO, LFXO)	Available	Available	—	Available	Available
Low Energy Clocks A and B (LFACLK, LFBCLK)	Available	Available	Available <sup>6</sup>	—	—
Low Energy Clock E (LFECLK)	Available	Available	Available <sup>6</sup>	Available	—
ULFRCO (Ultra Low Frequency Oscillator)	On	On	On	On	Available
CRYPTO (Crypto Accelerator)	Available	—	—	—	—
TRNG (True Random Number Generator)	Available	—	—	—	—
GPCRC (Cyclic Redundancy Check)	Available	—	—	—	—
RTCC (Real Time Counter and Calendar)	Available	Available	Available <sup>6</sup>	Available	—
RTCC Memory Retained	Yes	Yes	Yes	Yes	—
USART (USART/SPI)	Available	—	—	—	—
LCD (Liquid Crystal Display)	Available	Available	—	—	—
CAN (Controller Area Network)	Available	—	—	—	—
LEUART (Low Energy UART)	Available	Available <sup>3</sup>	—	—	—
I <sup>2</sup> C	Available	Available <sup>5</sup>	Available <sup>5</sup>	—	—
TIMER (Timer/Counter)	Available	—	—	—	—
LETIMER (Low Energy Timer)	Available	Available	Available <sup>6</sup>	—	—
CRYOTIMER (Ultra Low Energy Timer/Counter)	Available	Available	Available <sup>6</sup>	Available	Available
WDOG (Watchdog)	Available	Available	Available <sup>6</sup>	—	—
PCNT (Pulse Counter)	Available	Available	Available	—	—
CSEN (Capacitive Sense)	Available	Available <sup>3</sup>	—	—	—
ACMP (Analog Comparator)	Available	Available <sup>7</sup>	Available <sup>7</sup>	—	—
ADC (Analog to Digital Converter)	Available	Available <sup>3, 4</sup>	Available <sup>3, 4</sup>	—	—
VDAC (Voltage Digital to Analog Converter)	Available	Available	Available	—	—
OPAMP (Operational Amplifier)	Available	Available	Available	—	—
LESENSE (Low Energy Sensor)	Available	Available <sup>3</sup>	—	—	—
EMU Temperature Sensor	Available	Available	Available	Available	—
DC-DC Converter	Available	Available	Available	Available	—
VMON Wake-up or Reset	Available	Available	Available	Available	—
Brown-Out Detect/Power-on Reset	Available	Available	Available	Available	Available
Pin Reset	Available	Available	Available	Available	Available

	<b>EM0 Active/EM1 Sleep</b>	<b>EM2 Deep-Sleep</b>	<b>EM3 Stop</b>	<b>EM4 Hibernate</b>	<b>EM4 Shutoff</b>
GPIO Pin Interrupts	Available	Available	Available	Available <sup>8</sup>	Available <sup>8</sup>
GPIO Pin State Retention	Yes	Yes	Yes	Available <sup>9</sup>	Available <sup>9</sup>

**Note:**

1. Approximate time. Refer to the data sheet
2. Leaving the debugger connected when in EM2 or EM3 will cause the system to enter a higher power EM2 mode in which the high frequency clocks are still enabled and certain core functionality is still powered-up in order to maintain debug-functionality.
3. The LDMA can be used with some low power peripherals (e.g., ADC, LEUART, LESENSE, CSEN) in EM2/3. Features required by the LDMA which are not supported in EM2/3 (e.g., HFCLK), will be automatically enabled prior to the LDMA transfer and then automatically disabled afterwards.
4. While in EM2/3, an asynchronous event can be routed through PRS (e.g. GPIO IRQ or ACMP output) to wake up the ADC. Features required by the ADC which are not supported in EM2/3 (e.g., AUXHFRCO) will be automatically enabled to allow the ADC to convert a sample, and then automatically disabled afterwards.
5. I2C functionality limited to receive address recognition
6. Must be using ULFRCO
7. ACMP functionality in EM2/3 limited to edge interrupt
8. Pin wake-up in EM4 supported only on GPIO\_EM4WUx pins. Consult data sheet for complete list of pins.
9. If enabled in EMU->EM4CTRL.EM4IORETMODE.

The different energy modes are summarized in the following sections.

### 9.3.1.1 EM0 Active

EM0 Active provides all system features.

- Cortex-M0+ is executing code
- High and low frequency clock trees are active
- All oscillators are available
- All peripheral functionality is available

### 9.3.1.2 EM1 Sleep

EM1 Sleep disables the core but leaves the remaining system fully available.

- Cortex-M0+ is in sleep mode. Clocks to the core are off
- High and low frequency clock trees are active
- All oscillators are available
- All peripheral functionality is available

### 9.3.1.3 EM2 DeepSleep

This is the first level into the low power energy modes. Most of the high frequency peripherals are disabled or have reduced functionality. Memory and registers retain their values.

- Cortex-M0+ is in sleep mode. Clocks to the core are off.
- High frequency clock tree is inactive
- Low frequency clock tree is active
- The following oscillators are available
  - LFRCO, LFXO, ULFRCO, AUXHFRCO (on demand, if used by the ADC)
- The following low frequency peripherals are available
  - RTCC, LCD , WDOG, LEUART, LETIMER, LESENSE, PCNT, CRYOTIMER
- The following analog peripherals are available (with potential limitations on functionality)
  - ADC, VDAC, OPAMP, CSEN
- Wake-up to EM0 Active through
  - Peripheral interrupt, reset pin, power on reset, asynchronous pin interrupt, I2C address recognition, or ACMP edge interrupt
- RAM and register values are preserved
  - RAM blocks may be optionally powered down for lower power
- GPIO pin state is retained
- RTCC memory is retained
- The DC-DC converter can be configured to remain on in Low Power mode.

### 9.3.1.4 EM3 Stop

In this low energy mode, all low frequency oscillators (LFXO, LFRCO) and all low frequency clocks derived from them, are stopped, as well as all high frequency clocks. Most peripherals are disabled or have reduced functionality. Memory and registers retain their values.

- Cortex-M0+ is in sleep mode. Clocks to the core are off.
- High frequency clock tree is inactive
- All low frequency clock trees derived from the low frequency oscillators (LFXO, LFRCO) are inactive
- The following oscillators are available
  - ULFRCO, AUXHFRCO (on demand, if used by the ADC)
- The following low frequency peripherals are available if clocked by the ULFRCO
  - RTCC, WDOG, CRYOTIMER
- The following analog peripherals are available (with potential limitations on functionality)
  - ADC, VDAC, OPAMP, CSEN
- Wake-up to EM0 Active through
  - Peripheral interrupt, reset pin, power on reset, asynchronous pin interrupt, I2C address recognition, or ACMP edge interrupt
- RAM and register values are preserved
  - RAM blocks may be optionally powered down for lower power
- GPIO pin state is retained
- RTCC memory is retained
- The DC-DC converter can be configured to remain on in Low Power mode.

### 9.3.1.5 EM4 Hibernate

The majority of peripherals are shutoff to reduce leakage power. A few selected peripherals are available. System memory and registers do not retain values. GPIO PAD state and RTCC RAM are retained. Wake-up from EM4 Hibernate requires a reset to the system, returning it back to EM0 Active

- Cortex-M0+ is off
- High frequency clock tree is off
- Some low frequency clock trees may be active
- The following oscillators are available
  - LFRCO, LFXO, ULFRCO
- The following low frequency peripherals are available
  - RTCC, CRYOTIMER
- Wake-up to EM0 Active through
  - VMON, EMU Temperature Sensor, RTCC, CRYOTIMER, reset pin, power on reset, asynchronous pin interrupt (on GPIO\_EM4WUx pins only)
- GPIO pin state may be retained (depending on EMU->EM4CTRL.EM4IORETMODE configuration)
- RTCC memory is retained
- The DC-DC converter can be configured to remain on in Low Power mode.

### 9.3.1.6 EM4 Shutoff

EM4 Shutoff is the lowest energy mode of the part. There is no retention except for GPIO PAD state. Wake-up from EM4 Shutoff requires a reset to the system, returning it back to EM0 Active

- Cortex-M0+ is off
- High frequency clock tree is off
- Low frequency clock tree may be active
- The following oscillators are available
  - LFRCO, LFXO, ULFRCO
- The following low frequency peripherals are available
  - CRYOTIMER
- Wake-up to EM0 Active through
  - CRYOTIMER, reset pin, power on reset, asynchronous pin interrupt (on GPIO\_EM4WUx pins only)
- GPIO pin state may be retained (depending on EMU->EM4CTRL.EM4IORETMODE configuration)
- The DC-DC converter configuration is reset to its default Unconfigured configuration (DC-DC converter disabled and bypass switch is off)

## 9.3.2 Entering Low Energy Modes

The following sections describe the requirements for entering the various energy modes.

**Note:** If Voltage scaling is being used to save system energy, it is important to ensure the proper conditions for entry and exit of EM2 DeepSleep, EM3 Stop or EM4 Hibernate be met. See [9.3.9.2.1 EM2/EM3 Voltage Scaling Guidelines](#) and [9.3.9.3.1 EM4H Voltage Scaling Guidelines](#) for details.

### 9.3.2.1 Entry Into EM1 Sleep

Energy mode EM1 Sleep is entered when the Cortex-M0+ executes the Wait For Interrupt (WFI) or Wait For Event (WFE) instruction while the SLEEPDEEP bit the Cortex-M0+ System Control Register is cleared. The MCU can re-enter sleep automatically out of an Interrupt Service Routine (ISR) if the SLEEPONEXIT bit in the Cortex-M0+ System Control Register is set. Refer to ARM documentation on entering Sleep modes.

Alternately, EM1 Sleep can be entered from either EM2 DeepSleep or EM3 Stop from a Peripheral Wake-up Request allowing transfers between the Peripheral and System RAM or Flash. On EFM32, ADC, CSEN, LESENSE, and LEUART peripherals can request this wake-up event. Refer to their respective register specification to enable this option. The system will return back to EM2 DeepSleep or EM3 Stop once the ADC, CSEN, LESENSE, or LEUART have completed its transfers and processing.

### 9.3.2.2 Entry Into EM2 DeepSleep or EM3 Stop

Energy mode EM2 DeepSleep or EM3 Stop may be entered when **all** of the following conditions are true:

- Cortex-M0+ (if present) is in DEEPSLEEP state
- Flash Program/Erase Inactive
- DMA done with all current requests
- A debugger is not currently connected.

Entry into EM2 DeepSleep and EM3 Stop can be blocked by setting the EMU\_CTRL->EM2BLOCK bit.

**Note:** When EM2 DeepSleep or EM3 Stop entry is blocked, the part is not able to enter a lower energy state. The core will be in a sleep state, similar to EM1, where it is waiting for a proper interrupt or other valid wake-up event. Once the blocking conditions are removed, then the part will automatically enter a lower energy state.

Energy mode EM2 DeepSleep is entered from EM0 Active when the Cortex-M0+ executes the Wait For Interrupt (WFI) or Wait For Event (WFE) instruction while the SLEEPDEEP bit in the Cortex-M0+ System Control Register is set. The MCU can re-enter DeepSleep automatically out of an Interrupt Service Routine (ISR) if the SLEEPONEXIT bit in the Cortex-M0+ System Control Register is set. Refer to ARM documentation on entering Sleep modes.

### 9.3.2.3 Entry Into EM4 Hibernate or EM4 Shutoff

Energy mode EM4 Hibernate and EM4 Shutoff is entered through register access.

Software must ensure no modules are active when entering EM4 Hibernate/Shutoff. EM4CTRL->EM4STATE field must be configured to select either Hibernate (EM4H) or Shutoff (EM4S) mode prior to entering EM4.

Software may enter EM4 Hibernate/Shutoff from EM0 Active by writing the sequence 2,3,2,3,2,3,2,3,2 to EM4CTRL->EM4ENTRY bit field. If the EM4BLOCK bit in WDOGn\_CTRL is set, the CPU will be prevented from entering EM4 Hibernate/Shutoff by software request.

An active debugger connection will prevent entry into EM4 Hibernate/Shutoff.

Note that upon entry into EM4 Shutoff, the DC-DC converter configuration is reset to its default (i.e. Unconfigured) configuration. In the Unconfigured configuration, the DC-DC converter will be disabled and the bypass switch will be turned off.

Note also that if entering EM4 Shutoff, additional supply current may result if EMU\_PWRCTRL\_ANASW is set to 1. To properly enter EM4 Shutoff, firmware should first clear EMU\_PWRCTRL\_ANASW to 0, then wait at least 30 us prior to entering EM4 Shutoff.

### 9.3.3 Exiting a Low Energy Mode

A system in EM2 DeepSleep and EM3 Stop can be woken up to EM0 Active through regular interrupt requests from active peripherals. Since state and RAM retention is available, the EFM32 is fully restored and can continue to operate as before it went into the Low Energy Mode.

Wake-Up from EM4 Hibernate or EM4 Shutoff is performed through reset. Wake-Up from a specific module must be enabled in that module's EM4WUEN register.

Enabled interrupts that can cause wake-up from a low energy mode are shown in [Table 9.3 EMU Wake-Up Triggers from Low Energy Modes on page 233](#). The wake-up triggers always return the EFM32 to EM0 Active/EM1 Sleep. Additionally, any reset source will return to EM0 Active. VMON-based EM4 Hibernate wake-ups also set the corresponding rise or fall interrupt flag. These flags serve as the wake-up source for EM4 Hibernate and must be cleared by software on EM4 Hibernate exit. Not doing so will result in an immediate wake-up after next EM4 Hibernate entry.

**Table 9.3. EMU Wake-Up Triggers from Low Energy Modes**

Peripheral	Wake-Up Trigger	EM2 Deep-Sleep	EM3 Stop	EM4 Hibernate	EM4 Shut-off
LEUART (Low Energy UART)	Receive / transmit	Yes	—	—	—
LETIMER	Any enabled interrupt	Yes	—	—	—
WDOG	Any enabled interrupt	Yes	Yes	—	—
LESENSE	Any enabled interrupt	Yes	—	—	—
LFXO	Ready Interrupt	Yes	—	—	—
LFRCO	Ready Interrupt	Yes	—	—	—
LCD	Any enabled interrupt	Yes	—	—	—
I <sup>2</sup> C	Receive address recognition	Yes	Yes	—	—
ACMP	Any enabled edge interrupt	Yes	Yes	—	—
ADC	SINGLE / SCAN FIFO events, window comparator, and VREF overvoltage	Yes	Yes	—	—
CSEN	Wake on threshold	Yes	Yes	—	—
VDAC	Any enabled interrupt except EM23ERRIF	Yes	Yes	—	—
PCNT	Any enabled interrupt	Yes	Yes <sup>1</sup>	—	—
RTCC	Any enabled interrupt	Yes	Yes	Yes <sup>2</sup>	
VMON	Rising or falling edge on any monitored power	Yes	Yes	Yes <sup>2</sup>	—
EMU Temperature Sensor	Measured temperature outside the defined limits	Yes	Yes	Yes <sup>2</sup>	—
CRYOTIMER	Timeout	Yes	Yes	Yes <sup>2</sup>	Yes <sup>2</sup>
Pin Interrupts	Transition	Yes	Yes	Yes <sup>2, 3</sup>	Yes <sup>2, 3</sup>
Reset Pin	Assertion	Yes	Yes	Yes	Yes
Power	Cycle Off/On	Yes	Yes	Yes	Yes

**Note:**

1. When using an external clock
2. Corresponding bit in the module's EM4WUEN must be set.
3. Only available on a subset of the pins. Refer to the data sheet for details.

### 9.3.4 Power Configurations

The EFM32 Tiny Gecko 11 allows several power configurations with additional options giving flexible power architecture selection.

In order to provide the lowest power consuming solutions, the EFM32 Tiny Gecko 11 comes with a DC-DC module to power internal circuits. The DC-DC requires an external inductor and capacitor (refer to the data sheet for recommended values).

The EFM32 Tiny Gecko 11 has multiple internal power domains: IO Supply (IOVDD), Analog & Flash (AVDD), Input to Digital LDO (DVDD), and Low Voltage Digital Supply (DECOUPLE). Additional detail for each configuration and option is given in the following sections.

When assigning supply sources, the following requirement must be adhered to:

- VREGVDD = AVDD (Must be the highest voltage in the system)
- VREGVDD  $\geq$  DVDD
- VREGVDD  $\geq$  IOVDD

### 9.3.4.1 Power Configuration 0: Unconfigured

Upon power-on reset (POR) or entry into EM4 Shutoff, the system is configured in a safe state that supports all of the available Power Configurations. The Unconfigured Configuration is shown in the simplified diagram below.

In the Unconfigured Configuration:

- The DC-DC converter's Bypass switch is OFF.
- The internal digital LDO is powered from the AVDD pin (i.e. REGPWRSEL=0 in EMU\_PWRCTRL). Note the maximum allowable current into the LDO when REGPWRSEL=0 is 20 mA. For this reason, immediately after startup firmware should configure REGPWRSEL=1 to power the digital LDO from DVDD.
- The analog blocks are powered from the AVDD supply pin (i.e., ANASW=0 in EMU\_PWRCTRL).

After power on, firmware can configure the device to based on the external hardware configuration. Note that the PWRCFG register can only be written once to a valid value and is then locked. This should be done immediately out of boot to select the proper power configuration. The DC-DC and PWRCTRL registers will be locked until the PWRCFG register is configured.




Figure 9.2. Unconfigured Power Configuration

### 9.3.4.2 Power Configuration 1: No DC-DC

In Power Configuration 1, the DC-DC converter is programmed in Off mode and the Bypass switch is Off. The DVDD pin must be powered externally - typically, DVDD is connected to the main supply. DVDD powers the internal Digital LDO (i.e., REGPWRSEL=1) which powers the digital circuits. IOVDD and AVDD are powered from the main supply as well.

VREGSW must be left disconnected in this configuration.





Figure 9.3. DC-DC Off Power Configuration

### 9.3.4.3 Power Configuration 2: DC-DC

For the lowest power applications, the DC-DC converter can be used to power the DVDD supply.

In Power Configuration 2, the DC-DC Output ( $V_{DCDC}$ ) is connected to DVDD. DVDD powers the internal Digital LDO (i.e.,  $REGPWRSEL=1$ ) which powers the digital circuits. AVDD is connected to the main supply voltage. The internal analog blocks may be powered from AVDD or DVDD, depending on the ANASW configuration.

IOVDD could be connected to either the main supply (as shown below) or to  $V_{DCDC}$ , depending on the system IO requirements. Because  $V_{DCDC}$  will be unpowered (i.e., floating) at startup, if IOVDD is powered from the DC-DC converter then any circuit attached to IOVDD will not be powered until the DC-DC is configured (or the bypass switch is enabled). Refer to [9.3.8 IOVDD Connection](#) section for further details and issues that may result when connecting IOVDD to  $V_{DCDC}$ .



**Figure 9.4. DC-DC Standard Power Configuration**

As the Main Supply voltage approaches the DC-DC output voltage, it eventually reaches a point where becomes inefficient (or impossible) for the DC-DC module to regulate  $V_{DCDC}$ . At this point, firmware can enable bypass mode, which effectively disables the DC-DC and shorts the Main Supply voltage directly to the DC-DC output. If and when sufficient voltage margin on the Main Supply returns, the system can be switched back into DC-DC regulation mode.

### 9.3.5 DC-to-DC Interface

The EFM32 Tiny Gecko 11 devices feature a DC-DC buck converter which requires a single external inductor and a single external capacitor. The converter takes the VREGVDD input voltage and converts it down to an output voltage between VREGVDD and 1.8 V with a peak efficiency of approximately 90% in Low Noise (LN) mode and 85% in Low Power (LP) mode. Refer to the data sheet for full DC-DC specifications.

The DC-DC converter operates in either Low Noise (LN) or Low Power (LP) mode. LN mode is intended for higher current operation (e.g.,  $\geq 10$  mA), whereas LP mode is intended for very low current operation (e.g.,  $< 10$  mA).

In addition, the DC-DC converter supports an unregulated Bypass mode, in which the input voltage is directly shorted to the DC-DC output.

#### 9.3.5.1 Bypass Mode

In Bypass mode, the VREGVDD input voltage is directly shorted to the DC-DC converter output through an internal switch. Consult the data sheet for the Bypass switch impedance specification.

The Bypass Current Limit limits the maximum current drawn from the input supply in Bypass mode. This current limit is enabled by setting the BYPLIMEN bit in the EMU\_DCDCLIMCTRL register, and the limit value may be adjusted between 20 mA and 320 mA using the BYPLIMSEL bitfield in the EMU\_DCDCMISCTRL register. When the difference between the DC-DC output voltage ( $V_{DCDC}$ ) and the DC-DC input voltage (VREGVDD) is large, applications should enable the Bypass Current Limit before enabling Bypass mode. For example, if Bypass mode is enabled with VREGVDD=3.8 V and  $V_{DCDC}=1.8$  V with a 4.7  $\mu$ F capacitor, the peak current draw may be quite large as it is limited only by the bypass switch on-resistance, which could result in drooping on the input supply voltage. For smaller input / output voltage differences (e.g., VREGVDD=2.4 V and  $V_{DCDC}=1.8$  V), it may not be necessary to enable the Bypass Current Limit at all.

Note that the device will see an additional  $\sim 10$   $\mu$ A of current draw when both the Bypass Current Limiter and Bypass Mode are enabled. Applications should therefore disable the Bypass Current Limiter (i.e., set BYPLIMEN = 0) after the DVDD voltage has reached the main supply voltage in Bypass Mode.

#### 9.3.5.2 Low Power (LP) Mode

The Low Power (LP) controller operates in a hysteretic mode to keep the output voltage within a defined voltage band. Once the DC-DC output voltage drops below a programmable internal reference, the LP controller generates a pulse train to control the powertrain PFET switch, which charges up the DC-DC output capacitor. When the output voltage is at the programmed upper level, the powertrain PFET is turned off. The output ripple voltage may be quite large ( $> 100$  mV) in LP mode.

The LP controller supports load currents up to approximately 10 mA, making it suitable for light loads in EM0 and EM1, as well as EM2, EM3, or EM4 low energy modes.

#### 9.3.5.3 Low Noise (LN) Mode

The Low Noise (LN) controller continuously switches the powertrain NFET and PFET switches to maintain a constant programmed voltage at the DVDD pin. The LN controller supports load current from sub-mA up to 200 mA.

The LN controller switching frequency is programmable using the RCOBAND bitfield in the EMU\_DCDCLNFREQCTRL register. See below for recommended RCOBAND settings for each mode.

The DC-DC Low Noise controller operates in one of two modes:

1. Continuous Conduction Mode (CCM)
2. Discontinuous Conduction Mode (DCM)

##### 9.3.5.3.1 Low Noise (LN) Continuous Conduction Mode (CCM)

CCM operation is configured by setting the LNFORCECCM bit in the EMU\_DCDCMISCTRL register. CCM can be used to improve the DC-DC converter's output transient response time to quick load current changes, which minimizes voltage transients on the DC-DC output.

Note that all references to CCM in the documentation actually refer to Forced Continuous Conduction Mode (FCCM) - that is, if the LNFORCECCM bit is set and the output load current is very low, the DC-DC will be forced to operate in CCM. In this case, the current through the inductor may be negative and current may flow back into the battery.

In CCM, the recommended DC-DC converter switching frequency is 6.4 MHz (RCOBAND = 4).

### 9.3.5.3.2 Low Noise (LN) Discontinuous Conduction Mode (DCM)

To enable DCM, the LNFORCECCM bit in EMU\_DCDCMISCCTRL must be cleared before entering LN. Typically, this configuration would occur while the part was in Bypass mode. Once DCM is enabled, the DC-DC should operate in DCM at light load currents. However, as the load current increases, the DC-DC will automatically transition into CCM without software intervention.

The advantage of DCM is improved efficiency for light load currents. However, in DCM the DC-DC has poorer dynamic response to changes in load current, leading to potentially larger changes in the regulated output voltage. For these reasons, DCM is not recommended for applications that expect large instantaneous load current steps. For example, if the DC-DC is in DCM, firmware may need to increment the core clock frequency in small steps to prevent a large sudden load increase.

In DCM, the recommended DC-DC converter switching frequency is 3 MHz (RCOBAND = 0).

### 9.3.5.4 DC-to-DC Programming Guidelines

**Note:** Refer to Application Note AN0948: *EFM32 and EFR32 Series 1 Power Configurations and DC-DC* for detailed information on programming the DC-DC. Application Notes can be found on the Silicon Labs website ([www.silabs.com/32bit-appnotes](http://www.silabs.com/32bit-appnotes)) or using the [Application Notes] tile in Simplicity Studio.

### 9.3.6 Analog Peripheral Power Selection

The analog peripherals (e.g., ULFRCO, LFRCO, LFXO, HFRCO, AUXHFRCO, VMON, ADC, LCD, CSEN) are powered from an internal analog supply domain, VDDX\_ANA. VDDX\_ANA may be supplied from either the AVDD or DVDD supply pins, depending on the configuration of the ANASW bit in the EMU\_PWRCTRL register. Changes to the ANASW setting should be made immediately out of reset (i.e., in the Unconfigured Configuration), before all clocks (with the exception of HFRCO and ULFRCO) are enabled. If the DCDC converter is used and ANASW is set to 1, the switch will not take effect until after the DCDC output voltage has reached its target level. To prevent supply transients, firmware should configure and enable the DCDC, configure ANASW, and then enable clocks. If the DCDC converter is not used, IMMEDIATEPWRSWITCH should be set prior to setting ANASW so hardware can immediately apply the switch without waiting for the DCDC to settle.

Once ANASW is configured it should not be changed. Note that the flash is always powered from the AVDD pin, regardless of the state of the ANASW bit.

Table 9.4. Analog Peripheral Power Configuration

ANASW	Analog Peripheral Power Supply Source (VDDX_ANA)	Comments
0 (default)	AVDD pin	This configuration may provide a quieter supply to the analog modules, but is less efficient as AVDD is typically at a higher voltage than DVDD.
1	DVDD pin	This configuration may provide a noisier supply to the analog modules, but is more efficient. However, because the maximum allowable input voltage to many of the analog modules using APOR is limited to MIN(VDDX_ANA, IOVDD), this setting could artificially limit your analog input range.

### 9.3.7 Digital LDO Power Selection

The digital LDO may be powered from one of two supply pins, depending on the configuration of the REGPWRSEL bit in the EMU\_PWRCTRL register. At startup, the digital is powered from the AVDD pin. When powered from AVDD, the LDO current is limited to 20 mA. Out of startup, firmware should configure and enable the DCDC (if desired) and then set REGPWRSEL=1 before increasing the core clock frequency.

**Table 9.5. Digital LDO Power Configuration**

REGPWRSEL	Digital LDO Power Source	Comments
0 (default)	AVDD pin	Maximum LDO current in this configuration is 20 mA. Firmware should configure REGPWRSEL to 1 after startup.
1	DVDD pin	This configuration supports all core frequencies, and should be used after startup.

### 9.3.8 IOVDD Connection

The IOVDD supply(s) must be less than or equal to AVDD. IOVDD will typically be connected to either the DC-DC Output ( $V_{DCDC}$ ) or the main supply.

Because  $V_{DCDC}$  will be unpowered (i.e., floating) at startup, if IOVDD is powered from the DC-DC converter then any circuit attached to IOVDD will not be powered until the DC-DC is configured (or the bypass switch is enabled).

**Note:** This constraint can have serious and unintended side-effects. For example, if  $IOVDD = V_{DCDC}$ :

1. It isn't directly possible to program an unprogrammed device on a PCB through the serial wire interface. Programming the device requires IOVDD to be present (i.e., for SWCLK, SWDIO, etc), and IOVDD won't be present until after the part is programmed (i.e., the DC-DC is enabled in firmware to power up  $V_{DCDC}$ ). It is possible to work around this issue, however, by providing an external supply for  $V_{DCDC}$  during programming.
2. Some unprogrammed devices are preloaded with a bootloader. The bootloader is expecting to read a logic high on the SWCLK pin to determine if the bootloader should execute. With no valid IOVDD voltage present, the code may incorrectly decide to execute the bootloader, which will cause the system to wait in the bootloader until a reset occurs.

Additionally, upon entry into EM4 Shutoff, the DC-DC converter configuration is reset to its default (Unconfigured) configuration. If  $IOVDD = V_{DCDC}$ , then any circuits attached to IOVDD will remain unpowered until the system is reset to exit EM4 Shutoff, and the DC-DC is configured (or the bypass switch is enabled).

Any application with powering external loads from the DC-DC converter must take into consideration the maximum allowable DC-DC load current. Refer to the data sheet for DC-DC load current specification.

### 9.3.9 Voltage Scaling

The voltage scaling feature allows for a tradeoff between power and performance. Voltage scaling applies an adjustment to the supply voltage for the on-chip digital logic and memories. For EM0 and EM1 operation, full device performance is supported when the Voltage Scale Level is set to its highest value. The Voltage Scale Level may be set lower when operating the system at slower clock speeds to save power. Voltage scaling does not affect the input or output range for analog peripherals or digital I/O logic levels. For more information about max system frequency supported for different voltage scaling levels. Refer to the CMU chapter and the data sheet specification tables.

**Note:** Some device sub-systems and operations are only supported at Voltage Scale Level 2.

- Flash write/erase is only supported at Voltage Scale Level 2.
- TRNG operation is only supported at Voltage Scale Level 2.

Separate voltage scaling controls are available for the different energy modes. These are as follows:

- EM0/EM1 Voltage Scaling
- EM2/EM3 Voltage Scaling
- EM4H Voltage Scaling

### 9.3.9.1 EM0/EM1 Voltage Scaling

In energy modes EM0 and EM1, the user can dynamically scale voltages between Voltage Scale Level 2 and Voltage Scale Level 0 using the EM01VSCALE2 and EM01VSCALE0 bitfields in EMU\_CMD register. A lower Voltage Scale Level can be used in conjunction with lower processor frequency to reduce power consumption. Once these commands are issued, hardware begins the process of voltage scaling and when done, the VSCALEDONE interrupt is triggered. Users can also poll VSCALEBUSY in EMU\_STATUS which indicates that hardware is busy changing the voltage scale setting when set. VSCALE in EMU\_STATUS shows the current voltage the system is in at any time.

**Note:**

- If more than one voltage scaling command is issued in EMU\_CMD simultaneously, the lower voltage scaling level has higher priority. e.g. priority order: EM01VSCALE0 > EM01VSCALE2.
- The reset value of VSCALE for EM0 and EM1 operation is Voltage Scale Level 2.

When voltage scaling up or down, the user should follow the following sequences in order to ensure proper scaling.

- Voltage Scale Down
  1. Decrease system clock frequency to the target frequency
  2. Update the wait states of Flash for the target frequency
  3. Issue voltage scaling command by setting EM01VSCALE2 or EM01VSCALE0 in EMU\_CMD
  4. Once Hardware completes voltage scaling up, VSCALEDONE interrupt is set.
- Voltage Scale Up
  1. Issue voltage scaling command by setting EM01VSCALE2 or EM01VSCALE0 in EMU\_CMD
  2. Wait for hardware to complete voltage scaling. When done, VSCALEDONE interrupt is set.
  3. Update the wait states of Flash for the target frequency
  4. Increase system clock frequency to the target frequency

Multiple voltage scaling commands are allowed to be issued even when the current voltage scaling is not yet completed. In such a case, the current scaling will be aborted and the last command will be executed. VSCALEDONE interrupt will be issued for every voltage scaling command.

**Note:** When a hard reset occurs, VSCALE will be set to the reset value (Voltage Scale Level 2). In most cases, a soft reset will not affect the current VSCALE level. However, when a soft reset is issued in the middle of the voltage scaling process, the minimum voltage scale level indicated by VSCALE or the EMU\_CMD which triggered the voltage scale operation will be applied and reflected in VSCALE.

### 9.3.9.2 EM2/EM3 Voltage Scaling

The EM23VSCALE bitfield in EMU\_CTRL allows user to independently setup the voltage scaling value for EM2/EM3 energy mode. The EM23VSCALE in EMU\_CTRL should be programmed to a level which is less than or equal to VSCALE in EMU\_STATUS. This means that EM2/EM3 voltage scaling is always a voltage scaling down process. If EM23VSCALE level in EMU\_CTRL is greater than VSCALE level in EMU\_STATUS, the VSCALE level will be implemented in EM2/EM3 instead of EM23VSCALE. Upon EM2/EM3 entry, the system will scale down the voltage to a smaller level between VSCALE or EM23VSCALE.

**Note:** The reset value of EM23VSCALE is Voltage Scale Level 2. Therefore, if user scales EM0/EM1 voltage to Voltage Scale Level 0 (reflected in VSCALE in EMU\_STATUS) and enters EM2/EM3, this VSCALE voltage of Voltage Scale Level 0 is maintained in EM2/EM3 as well since this is smaller level between VSCALE and EM23VSCALE.

#### 9.3.9.2.1 EM2/EM3 Voltage Scaling Guidelines

Note that when using EM23VSCALE in EMU\_CTRL to scale down EM2/EM3, the scaled down voltage in EM2/EM3 is maintained after waking from EM2/EM3 to EM0/EM1. For example, if VSCALE was at Voltage Scale Level 2 prior to EM2/EM3 entry, and EM23VSCALE was set to Voltage Scale Level 0, the system will scale down to Voltage Scale Level 0 on EM2/EM3 entry. When waking up to EM0/EM1, the system maintains its voltage at Voltage Scale Level 0. Therefore, user must ensure the system clock frequency and Flash wait states are programmed to correct values to support waking up to EM0/EM1 at the lower voltages prior to EM2/EM3 entry.

EM23VSCALEAUTOWSEN bitfield in EMU\_CTRL enables hardware to automatically configure the system clock frequency and Flash wait states to support low voltage operation when waking up to EM0/EM1 from EM2/EM3. Therefore, this obviates the need for user to setup the clock frequency and Flash wait states prior to EM2/EM3 entry with EM23VSCALE. When waking up to EM0/EM1, while using EM23VSCALEAUTOWSEN set to 1, the HFRCO will default to its production calibrated 19 MHz frequency.

### 9.3.9.3 EM4H Voltage Scaling

EM4HVSCALE bitfield in EMU\_CTRL allows user to independently setup the voltage scaling levels for EM4H energy mode. The EM4HVSCALE in EMU\_CTRL should be programmed to a level which is smaller than or equal to VSCALE level in EMU\_STATUS or EM23VSCALE in EMU\_CTRL. This means that EM4H voltage scaling is always a voltage scaling down process. If EM4HVSCALE level in EMU\_CTRL is greater than level of VSCALE in EMU\_STATUS or level of EM23VSCALE in EMU\_CTRL, the smaller of VSCALE, EM23VSCALE or EM4HVSCALE levels will be implemented in EM4H.

**Note:** The reset level of EM4HVSCALE is Voltage Scale Level 2. Therefore, if user scales EM0/EM1 voltage to Voltage Scale Level 0 (reflected in VSCALE in EMU\_STATUS) and enters EM4H, this VSCALE voltage of Voltage Scale Level 0 is maintained in EM2/EM3 as well since this is minimum of VSCALE and EM23VSCALE.

#### 9.3.9.3.1 EM4H Voltage Scaling Guidelines

Note that when using EM4HVSCALE in EMU\_CTRL to scale down voltage in EM4H, the scaled down voltage in EM4H is maintained after waking from EM4H to EM0/EM1. For example prior to EM4H entry, if VSCALE was at Voltage Scale Level 2 and EM4HVSCALE was set to Voltage Scale Level 0, the system will scale down to Voltage Scale Level 0 on EM4H entry. When waking up to EM0/EM1, the system maintains its voltage at Voltage Scale Level 0.

#### 9.3.9.4 Voltage Scaling Recommended Use

Refer to the data sheet for the maximum supported system frequencies for different Voltage Scaling Levels. Use of the lowest voltage scaling level is recommended for maximum power savings. For any voltage scaling level, it is recommended to use the highest frequency for performance benefits.

Voltage can then be scaled to higher voltage scale levels only when higher system clock frequency is required by the application for a period of time after which user can dynamically scale the voltage back to lower voltage scale levels to continue saving power.

### 9.3.10 EM2/EM3 Peripheral Retention Disable

Peripherals that are available in EM2 DeepSleep or EM3 Stop can optionally be powered down during EM2 DeepSleep or EM3 Stop. This allows lower energy consumption in these energy modes. However, when powering down, these peripherals are independently reset so the registers lose their configuration values. Therefore, they will have to be reconfigured upon wake-up to EM0 Active if they were previously configured to non reset values.

EMU\_EM23PERNORETAINCTRL register can be used to setup unused peripherals for powering down prior to EM2/EM3 entry. Once setup, upon EM2/EM3 entry, all peripherals in the power-down domain will get powered down if all of them are setup to be disabled.

**Note:** User must ensure that the peripherals being powered down should have their clocks disabled in CMU prior to EM2/EM3 entry.

On waking up from EM2/EM3, EMU\_EM23PERNORETAINSTATUS register indicates if the peripherals were powered down by the system and subsequently locked out from register access. Locking out peripherals prevents users from accidentally using peripherals with configurations at their reset state. EMU\_EM23PERNORETAINCMD allows user to unlock these peripherals and hence grant access to their registers for updating their configurations.

### 9.3.11 Brown Out Detector (BOD)

The EFM32 Tiny Gecko 11 contains multiple supply brown out detectors (BODs).

#### 9.3.11.1 AVDD BOD

The EFM32 Tiny Gecko 11 has a fast response BOD on AVDD that is always active. This BOD ensures the minimal supply is provided to the AVDD supply (typically also connected to VREGVDD). Once triggered, the BOD will cause the system to reset.

**Note:** In EM4 Hibernate/Shutoff a low power version of the AVDD BOD, called EM4BOD, is available to trigger a reset at level lower than in other energy modes. All other BODs are disabled during EM4 Hibernate/Shutoff

#### 9.3.11.2 DVDD and DECOUPLE BOD

Additional BODs will monitor DVDD and DECOUPLE during EM0 Active through EM3 Stop. This can cause a reset to the internal logic, but will not cause a power-on reset or reset the EMU or RTCC.

### 9.3.12 Voltage Monitor (VMON)

The EFM32 features an extremely low energy Voltage Monitor (VMON) capable of running down to EM4 Hibernate. Trigger points are preloaded but may be reconfigured.

- AVDD X 2
- DVDD
- IOVDD0 and IOVDD1
- BUVDD

**Table 9.6. VMON Events**

Feature	Condition	AVDD	DVDD	BUVDD	IOVDD
Hysteresis (separate rise and fall triggers)	—	Yes	—	—	—
Supply switch to/from Backup	Fall/Rise	Yes	—	—	—
Interrupt	Fall or Rise	Yes	Yes	Yes	Yes
Wake-Up from EM4 Hibernate	Fall or Rise	Yes	Yes	Yes	Yes

The status of the VMON is reflected in the EMU\_STATUS register.

The status of the sticky interrupt can be found at EMU\_IF. These interrupt flags also serve as the wake-up source of EM4H when the associated RISEWU and FALLWU bits are set. This means that if these flags are set, EM4H entry will result in an immediate wake-up. To prevent this, these must be cleared by software before EM4H entry.

Note that the VMON has offset high hysteresis, specified in the device Data Sheet. For rising edge detection the threshold will be the threshold setting (as described below) +  $V_{VMON\_HST}$ , and for falling edge detection the threshold will simply be the threshold setting.

VMON channels are calibrated at two voltages: 1.86 V and 2.98 V. The calibration results (coarse thresholds and fine thresholds for 1.86 V and 2.98 V) are placed in the VMONCAL registers in the DI page. Using these thresholds it is possible to calculate thresholds for the entire supported VMON VDD range, i.e., 1.62 V to 3.4 V. Using the values given in VMONCAL registers, one can calculate  $T_{1.86}$ ,  $T_{2.98}$ ,  $V_a$  and  $V_b$ .

$$T_{1.86} = (10 \times \text{VMONCALX\_XVDD1V86THRESCOARSE}) + \text{VMONCALX\_XVDD1V86THRESFINE},$$

$$T_{2.98} = (10 \times \text{VMONCALX\_XVDD2V98THRESCOARSE}) + \text{VMONCALX\_XVDD2V98THRESFINE},$$

$$V_a = (1.12) / (T_{2.98} - T_{1.86}),$$

$$V_b = 1.86 - (V_a \times T_{1.86}),$$

**Figure 9.5. VMON Calibration Equations**

Now if it is required to find the coarse and fine thresholds for a certain voltage  $Y$ , following equation can be used:

$$\text{Thres}_Y = (Y - V_b) / V_a,$$

$$Y_{\text{calib}} = (\text{Thres}_Y \times V_a) + V_b,$$

**Figure 9.6. VMON Threshold Equations**

$\text{Thres}_Y$  should be rounded to the nearest integer. The least significant digit of the rounded  $\text{Thres}_Y$  gives the fine threshold and remaining digits give the coarse threshold for  $Y$ . These can now be programmed in the relevant EMU\_VMONXVDDCTRL register as the coarse and fine thresholds. It may not be possible to set threshold exactly for  $Y$ . In that case the closest possible voltage is used.  $Y_{\text{calib}}$  gives the value of this closest possible voltage.

Consider the example where it is required to set the AVDD rise threshold to 2.2 V (so  $Y=2.2$  V). This means that the EMU\_VMONNAVDDCTRL\_RIETHRESCOARSE and EMU\_VMONNAVDDCTRL\_RIETHRESFINE need to be programmed. Here are the steps that should be followed:

- Check VMONCAL0 register. It has the VMON AVDD channel calibrated thresholds for 1.86 V and 2.98 V. Lets assume that the following values are present in the associated bitfields:
  - AVDD1V86THRESCOARSE = 3
  - AVDD1V86THRESFINE = 5
  - AVDD2V98THRESCOARSE = 8
  - AVDD2V98THRESFINE = 7
- Using the above numbers and the VMON calibration equations:
  - $T_{1.86} = 35$
  - $T_{2.98} = 87$
  - $V_a = 21.53 \text{ mV}$
  - $V_b = 1.106 \text{ V}$
- Using the VMON threshold equations (with  $Y=2.2 \text{ V}$ ),  $\text{Thres}_Y = 51$  (rounded from 50.8) and  $Y_{\text{calib}} = 2.204 \text{ V}$

EMU\_VMONAVDDCTRL\_RIETHRESCOARSE should be programmed to 5 and EMU\_VMONAVDDCTRL\_RIETHRESFINE should be programmed to 1 (since  $\text{Thres}_Y = 51$ ). With these programmed values, VMON AVDD rise threshold is set for  $Y_{\text{calib}} = 2.204 \text{ V}$ , which is the closest programmable threshold.

### 9.3.13 Powering Off SRAM Blocks

SRAM blocks may be powered off using the EMU\_RAMxCTRL RAMPOWERDOWN fields. Selected blocks are powered down in order from the highest to lowest address in each bank. The lowest SRAM block in RAM0 cannot be powered off and will always remain powered on for proper system functionality. The stack must be located in retained memory. Refer to the EMU\_RAMxCTRL register descriptions for power configuration options and the associated address ranges.

### 9.3.14 Temperature Sensor

EMU provides low energy periodic temperature measurement. A temperature measurement is taken every 250 ms, with the 8-bit result stored in EMU->TEMP register.

**Note:** The EMU temperature sensor is always running (except in EM4 Shutoff) and is independent from the ADC temperature sensor.

The EMU provides the following features around temperature changes

- Wake-Up from EM4 Hibernate on Temperature Change
- Interrupt from High Level Trip
- Interrupt from Low Level Trip

During production test, the EMU temperature sensor for each device is calibrated at room temperature, with the corresponding calibration temperature and reading stored off in the DI page as follows:

- DEVINFO->CAL TEMP : This bitfield contains the temperature in degrees C at calibration
- DEVINFO->EMUTEMP : This register contains the EMU->TEMP reading at the calibration temperature stored in DEVINFO->CAL TEMP

The current calibrated EMU temperature sensor result from EMU->TEMP may be converted to degrees C using the following equation:

$$T_{J\_EMU} [^{\circ}\text{C}] = (\text{DEVINFO}->\text{CAL.TEMP}) + (\text{TEMPCO}_{\text{EMxx}}) * [(\text{DEVINFO}->\text{EMUTEMP}) - (\text{EMU}->\text{TEMP})]$$

**Figure 9.7. Temperature Calculation**

$\text{TEMPCO}_{\text{EMxx}}$  is a temperature coefficient that varies based on the energy mode at the time of the EMU temperature sensor reading:

- $\text{TEMPCO}_{\text{EM01}} = 0.278 + (\text{DEVINFO}->\text{EMUTEMP}) / 100$
- $\text{TEMPCO}_{\text{EM234}} = 0.268 + (\text{DEVINFO}->\text{EMUTEMP}) / 100$

For maximum accuracy when using the high/low level temperature interrupts, firmware should ensure that  $\text{TEMPCO}_{\text{EM234}}$  is used to set the temperature thresholds in EMU->TEMPLIMITS before entering EM2/3/4. Similarly, when exiting EM2/3/4, the temperature thresholds should be updated using  $\text{TEMPCO}_{\text{EM01}}$ .

Note that an increasing reading in EMU->TEMP corresponds to a decreasing temperature, and vice-versa. If enabled, the TEMPHIGH High Level Limit in EMU-> TEMPLIMITS causes an interrupt flag on a increasing EMU->TEMP reading (i.e., decreasing temperature). Similarly, the TEMPLOW Low Level Limit causes a interrupt flag on a decreasing EMU->TEMP reading (i.e., increasing temperature).

The EMU temperature sensor accuracy is approximately  $\pm 10^{\circ}\text{C}$  over most of the useable temperature range, but may be  $+15^{\circ}\text{C}$  at higher temperatures. Accordingly, any use of the EMU temperature sensor should include margin to account for that accuracy.

### 9.3.15 Registers latched in EM4

The following registers will be latched when entering EM4. After wake-up from EM4, these registers will be reset and require reprogramming prior to writing the EMU\_CMD\_EM4UNLATCH command.

- CMU\_LFRCOCTRL
- CMU\_LFXOCTRL
- CMU\_LFECLKSEL
- CMU\_LFECLKEN0
- CMU\_LFEPRESC0

### 9.3.16 Register Resets

Each EMU register requires retaining state in various energy modes and power transitions and will consequently need to be reset with a different condition. The following reset conditions will apply to the appropriate set of registers as marked in the Register Description table.

- Reset with POR or Hard Pin Reset
- Reset with POR, Hard Pin Reset, or any BOD reset
- Reset with SYSEXTENDEDRESETn
- Reset with FULLRESETn (default)

If a register field is not marked with a specific reset condition then it is assumed to be reset with FULLRESETn.

### 9.3.17 Backup Power Domain

EFM32 Tiny Gecko 11 has the possibility to be partly powered by backup battery. The backup power input, BU\_VIN, is connected to a power domain in the EFM32 Tiny Gecko 11 containing the RTCC, 128 bytes of data retention and the CRYOTIMER. [Figure 9.8 Backup Power Domain Overview on page 246](#) shows an overview of the backup powering scheme. During normal operation, the entire chip is powered by the main power supply. If the main power supply drains out and the backup mode functionality is enabled, the system enters a low energy mode, equivalent to EM4 Hibernate, and automatically switches over to the backup power supply. The power relationship requirements given in the [9.3.4 Power Configurations](#) must always be adhered to. This means that even when the main supply (VREGVDD/AVDD) falls, the power relationships must stay valid (I.e., IOVDD must be less than or equal to AVDD in all scenarios).

**Note:** If there is no backup battery inserted in the system, then DISMAXCOMP in EMU\_BUCTRL can be set to 1 to save power. This bit must be set to 0 (default value) if the backup battery is present in the system (even if backup mode is not enabled).

Consult the data sheet for the allowable BU\_VIN input voltage range.




Figure 9.8. Backup Power Domain Overview

### 9.3.17.1 Entering Backup Mode

To be able to enter backup mode, the EN bit in EMU\_BUCTRL and the EN bit in EMU\_VMONAVDDCTRL have to be set. When these two are set, the BURDY interrupt flag will be set as soon as the VMON AVDD channel is ready. Status of the backup functionality is also available in the BURDY flag in the EMU\_STATUS register. To enter backup mode, the voltage on AVDD has to drop below the programmed fall threshold of the VMON AVDD channel. This threshold is programmed using FALLTHRESCOARSE and FALLTHRESFINE in EMU\_VMONAVDDCTRL.

In the above mentioned case, EFM32 Tiny Gecko 11 will try to enter backup mode even if there is no backup power supply present. If the EN bit in EMU\_VMONBUVDDCTRL is set as well and AVDD falls below fall threshold, then backup mode will only be entered if BUVDD is above a programmed threshold. This threshold can be programmed using THRESCOARSE and THRESFINE in the EMU\_VMONBUVDDCTRL. BURDY status flag will go high when the EN bit in EMU\_BUCTRL and the EN bit in EMU\_VMONAVDDCTRL are set. If the EN bit in EMU\_VMONBUVDDCTRL is now set, then immediately after that the user should wait on the BURDY status flag to first go low and then go high again (the flag will go high when the VMON BUVDD has also become ready). Note that enabling the BUVDD VMON monitoring causes a drain of 2  $\mu$ A from the backup power supply in EM0 Active.

The BU\_STAT pin can be used to indicate whether or not the system is in backup mode. To enable exporting of the backup mode status to BU\_STAT pin, set STATEN in EMU\_BUCTRL. When enabled, BU\_STAT pin is driven to BU\_VIN if backup mode is active and to ground otherwise.

**Note:**

- When EN in EMU\_BUCTRL is set, then EM4 Shutoff entry is blocked. All software based EM4 Shutoff entries will result in an entry to EM4 Hibernate. This is a safety feature since it is not possible to enter backup mode if the chip is in EM4 Shutoff.
- If DCDC is ON, it is turned off when entering backup mode.
- The RTCC includes functionality for storing a timestamp when the system enters backup mode. See the RTCC chapter for details.

### 9.3.17.2 Exiting Backup Mode

To exit backup mode, the voltage on AVDD has to be above the rise threshold programmed in EMU\_VMONAVDDCTRL. RISETHRESCOARSE and RISETHRESFINE in EMU\_VMONAVDDCTRL decides threshold for backup mode exit. When leaving backup mode, a system reset is triggered (same as EM4 Hibernate exit) in which backup domain is not reset. When backup mode has been active, the BUMODERST bit in RMU\_RSTCAUSE is set (both EM4RST and BUMODERST bits in RMU\_RSTCAUSE will be set if checked after backup mode exit). [Figure 9.9 Entering and Leaving Backup Mode on page 247](#) illustrates how the VMON monitoring on AVDD can be programmed to implement hysteresis on entering and exiting backup mode.

Backup mode is also exited on a hard pin reset or if a brown out occurs on the backup power supply.

**Note:** Exit from backup mode on AVDD rise happens independent of whether the RISEWU bit in EMU\_VMONAVDDCTRL is set or not.




Figure 9.9. Entering and Leaving Backup Mode

### 9.3.17.3 Backup Pads

There are three backup pads, i.e., BU\_VIN, BU\_VOUT and BU\_STAT. When these are being used for backup, then no other module should drive these pads. Following sequence can be followed to ensure this:

- These should be disabled using the Mode register (GPIO\_Px\_MODEL/GPIO\_Px\_MODEH)
- DOUT for these should be set to 0 using GPIO\_Px\_DOUT (if DOUT remains set, then these will be pulled-up even if disabled)
- These should be locked using GPIO\_Px\_PINLOCKN

#### 9.3.17.4 Threshold Calibration

Thresholds for backup entry and backup exit are monitored by VMON. Calibrated threshold values (coarse, fine) for two voltages are given in DI page for all VMON channels. All other values between these two voltages can be found by linear interpolation.

#### 9.3.17.5 Backup Battery Charging

The EFM32 Tiny Gecko 11 includes functionality for charging of the backup battery. This is done by connecting the main power and the backup power through a resistor, and optionally a diode. The connection is configured individually for when in backup mode and when in normal mode. When in normal mode, the connection is configured in BUINACTPWRCON in EMU\_BUCTRL. BUACTPWRCON in EMU\_BUCTRL configures the connection when in backup mode. The series resistance between the two power domains is configured in PWRRES in EMU\_BUCTRL, this configuration applies both to backup mode and normal mode.

#### 9.3.17.6 Supply Voltage Output

To be able to power external devices, the supply voltage for the backup domain is available as an output. Three switches connect the backup supply voltage to the BU\_VOUT pin. To be able to control the series resistance, the switches have different strengths: weak, medium, and strong (strong connection has the lowest resistance). The switches are controlled using the VOUTRES in EMU\_BUCTRL. For resistor values, refer to the device data sheet Electrical Characteristics.

#### 9.3.17.7 Voltage Probing

It is possible to internally probe the voltage levels at AVDD and BU\_VIN using the ADC. To probe AVDD, AVDD needs to be selected in POSSEL of ADCn\_SINGLECTRL before performing the ADC conversion. In order to probe BU\_VIN, BUVINPROBEEN in EMU\_BUCTRL needs to be set first. Then BUVDD needs to be selected in the POSSEL of ADCn\_SINGLECTRL before performing the conversion. The voltage measured by the ADC on the BUVDD channel will be 1/8 of the actual BU\_VIN voltage, meaning that the result needs to be multiplied by 8 to get the correct measurement. BU\_VOUT cannot be probed internally. However, BU\_VOUT can be externally connected to any pin accessible by the ADC. When making the external connection, the user must ensure that the ADC pin is not driven to a voltage higher than the ADC power when the chip is in main mode (i.e., not in backup mode). This is already taken care of in the chip if the ADC is not powered by the DCDC (i.e., in main mode, BU\_VOUT is the same as AVDD and AVDD also powers the ADC). If the DCDC is used to power the ADC, then the user must divide BU\_VOUT outside the chip by at least a factor of 4 before feeding it to the ADC pin. In backup mode, external connection of BU\_VOUT with the ADC pin does not create any issues (as the ADC is not available in backup mode).

#### 9.3.17.8 EM4 Hibernate vs Backup Mode

Backup mode is a special version of EM4 Hibernate, with only three key differences:

- EM4 Hibernate has GPIO retention capability which is not present in backup mode.
- EM4 Hibernate has multiple wakeup sources shown in [Table 9.3 EMU Wake-Up Triggers from Low Energy Modes](#) on page 233. Backup mode can only be exited when AVDD goes above rise threshold, on a hard pin reset or on a brown out on BU\_VIN.

#### 9.3.17.9 Oscillators in Backup Mode

Backup mode is equivalent to EM4 Hibernate, therefore oscillators available in EM4 Hibernate are also available in backup mode. Note that the chosen oscillator may need to be retained (using EMU\_EM4CTRL) in order to keep it running in backup mode (settings done for EM4 Hibernate also apply to backup mode).

#### 9.3.17.10 Brown Out Detection in Backup Mode

When backup mode is entered, the EM4BOD switches from monitoring AVDD to monitoring BU\_VIN. A brown out on BU\_VIN (treated the same as AVDD brown out in EM4 Hibernate) results in an exit from backup mode.

## 9.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	EMU_CTRL	RW	Control Register
0x004	EMU_STATUS	R	Status Register
0x008	EMU_LOCK	RWH	Configuration Lock Register
0x00C	EMU_RAM0CTRL	RW	Memory Control Register
0x010	EMU_CMD	W1	Command Register
0x018	EMU_EM4CTRL	RW	EM4 Control Register
0x01C	EMU_TEMPLIMITS	RW	Temperature Limits for Interrupt Generation
0x020	EMU_TEMP	R	Value of Last Temperature Measurement
0x024	EMU_IF	R	Interrupt Flag Register
0x028	EMU_IFS	W1	Interrupt Flag Set Register
0x02C	EMU_IFC	(R)W1	Interrupt Flag Clear Register
0x030	EMU_IEN	RW	Interrupt Enable Register
0x034	EMU_PWRLOCK	RW	Regulator and Supply Lock Register
0x03C	EMU_PWRCTRL	RW	Power Control Register
0x040	EMU_DCDCCCTRL	RW	DCDC Control
0x04C	EMU_DCDCMISCCTRL	RW	DCDC Miscellaneous Control Register
0x050	EMU_DCDCZDETCTRL	RW	DCDC Power Train NFET Zero Current Detector Control Register
0x054	EMU_DCDCCLIMCTRL	RW	DCDC Power Train PFET Current Limiter Control Register
0x058	EMU_DCDCLNCOMPCTRL	RW	DCDC Low Noise Compensator Control Register
0x05C	EMU_DCDCLNVCTRL	RWH	DCDC Low Noise Voltage Register
0x064	EMU_DCDCLPVCTRL	RW	DCDC Low Power Voltage Register
0x06C	EMU_DCDCLPCTRL	RW	DCDC Low Power Control Register
0x070	EMU_DCDCLNFREQCTRL	RW	DCDC Low Noise Controller Frequency Control
0x078	EMU_DCDCSYNC	R	DCDC Read Status Register
0x090	EMU_VMONAVDDCTRL	RW	VMON AVDD Channel Control
0x094	EMU_VMONALTAVDDCTRL	RW	Alternate VMON AVDD Channel Control
0x098	EMU_VMONDVDDCTRL	RW	VMON DVDD Channel Control
0x09C	EMU_VMONIO0CTRL	RW	VMON IOVDD0 Channel Control
0x0A4	EMU_VMONBUVDDCTRL	RW	VMON BUVDD Channel Control
0x0BC	EMU_BUCTRL	RW	Backup Power Configuration Register
0x0EC	EMU_DCDCLPEM01CFG	RW	Configuration Bits for Low Power Mode to Be Applied During EM01, This Field is Only Relevant If LP Mode is Used in EM01
0x100	EMU_EM23PERNORETAINCMD	W1	Clears Corresponding Bits in EM23PERNORETAINSTATUS Unlocking Access to Peripheral
0x104	EMU_EM23PERNORETAINSTATUS	R	Status Indicating If Peripherals Were Powered Down in EM23, Subsequently Locking Access to It

Offset	Name	Type	Description
0x108	EMU_EM23PERNORETAINCTRL	RW	When Set Corresponding Peripherals May Get Powered Down in EM23

## 9.5 Register Description

### 9.5.1 EMU\_CTRL - Control Register

Offset	Bit Position																																
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10											
Reset																	0x0																
Access																	RW																
Name																	EM4HVSCALE																
																	EM23VSCALE																
																	EM23VSCALEAU-TOWSEN																
																	0																

Bit	Name	Reset	Access	Description												
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
17:16	EM4HVSCALE	0x0	RW	<b>EM4H Voltage Scale</b>  Set EM4H voltage. Entry to EM4H will trigger voltage scaling to this voltage if voltage scale level in EM4HVSCALE is less than that of VSCALE												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>VSCALE2</td> <td>Voltage Scale Level 2</td> </tr> <tr> <td>2</td> <td>VSCALE0</td> <td>Voltage Scale Level 0</td> </tr> <tr> <td>3</td> <td>RESV</td> <td>RESV</td> </tr> </tbody> </table>	Value	Mode	Description	0	VSCALE2	Voltage Scale Level 2	2	VSCALE0	Voltage Scale Level 0	3	RESV	RESV
Value	Mode	Description														
0	VSCALE2	Voltage Scale Level 2														
2	VSCALE0	Voltage Scale Level 0														
3	RESV	RESV														
15:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
9:8	EM23VSCALE	0x0	RW	<b>EM23 Voltage Scale</b>  Set EM23 voltage. Entry to EM2/3 will trigger voltage scaling to this voltage if voltage scale level in EM23VSCALE is lesser than that of VSCALE												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>VSCALE2</td> <td>Voltage Scale Level 2</td> </tr> <tr> <td>2</td> <td>VSCALE0</td> <td>Voltage Scale Level 0</td> </tr> <tr> <td>3</td> <td>RESV</td> <td>RESV</td> </tr> </tbody> </table>	Value	Mode	Description	0	VSCALE2	Voltage Scale Level 2	2	VSCALE0	Voltage Scale Level 0	3	RESV	RESV
Value	Mode	Description														
0	VSCALE2	Voltage Scale Level 2														
2	VSCALE0	Voltage Scale Level 0														
3	RESV	RESV														
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
4	EM23VSCALEAU-TOWSEN	0	RW	<b>Automatically Configures Flash and Frequency to Wakeup From EM2 or EM3 at Low Voltage</b>  With voltage scaling on EM2/3 entry, wakeup to EM0/1 will be at the same voltage as EM2. When this bit is set the Flash wait states and CMU clock frequency are automatically configured to safe value without needing software to configure it prior to EM2/3 entry.												

Bit	Name	Reset	Access	Description
3	EM01LD	0	RW	<b>Reserved for internal use. Do not change.</b>  Reserved for internal use. Do not change.
2	EM2BODDIS	0	RW	<b>Disable BOD in EM2</b>  This bit is used to disable BODs to minimize current in EM2. Reset with POR or Hard Pin Reset
1	EM2BLOCK	0	RW	<b>Energy Mode 2 Block</b>  This bit is used to prevent the MCU from entering Energy Mode 2 or 3.
0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 9.5.2 EMU\_STATUS - Status Register

Offset	Bit Position																																	
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																		
Access		R	0				R	0				R	0	0x0						R							R	0	3	2	1	0		
Name	TEMPACTIVE						EM4IORET			VSCALEBUSY		R		VSCALE				BURDY					VMONFVDD	R	0	8	7	6	5	4	3	2	1	0

Bit	Name	Reset	Access	Description
31:27	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
26	TEMPACTIVE	0	R	<b>Temperature Measurement Active</b>
				This signal is set during EMU Temperature measurement
25:21	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
20	EM4IORET	0	R	<b>IO Retention Status</b>
				The status of IO retention. Will be set upon EM4 entry based on EM4IORETMODE in EMU_EM4CTRL. Cleared by setting EM4UNLATCH in EMU_CMD, and can also be cleared in EM4H by the VMON.
19	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
18	VSCALEBUSY	0	R	<b>System is Busy Scaling Voltage</b>
				Indicates that the system is busy scaling voltage in EM0/1. Writing EM01VSCALE0 or EM01VSCALE2 in EMU_CMD register while this is set will abort the current voltage scaling process and initiate a new one
17:16	VSCALE	0x0	R	<b>Current Voltage Scale Value</b>
				This shows the current system voltage value. This gets updated after VSCALEDONE interrupt or on EM23 exit or EM4H exit
15:13	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
12	BURDY	0	R	<b>Backup Mode Ready</b>
				Set when the Backup power functionality is ready.

Bit	Name	Reset	Access	Description
11:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8	VMONFVDD	0	R	<b>VMON VDDFLASH Channel</b> Indicates the status of the VDDFLASH channel of the VMON.
7	VMONBUVDD	0	R	<b>VMON BUVDD Channel</b> Indicates the status of the BUVDD channel of the VMON.
6:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	VMONIO00	0	R	<b>VMON IOVDD0 Channel</b> Indicates the status of the IOVDD0 channel of the VMON.
3	VMONDVDD	0	R	<b>VMON DVDD Channel</b> Indicates the status of the DVDD channel of the VMON.
2	VMONALTAVDD	0	R	<b>Alternate VMON AVDD Channel</b> Indicates the status of the Alternate AVDD channel of the VMON.
1	VMONAVDD	0	R	<b>VMON AVDD Channel</b> Indicates the status of the AVDD channel of the VMON.
0	VMONRDY	0	R	<b>VMON Ready</b> VMON status. When high, this bit indicates that all the enabled channels are ready. When low, it indicates that one or more of the enabled channels are not ready.

## 9.5.3 EMU\_LOCK - Configuration Lock Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																														0x0000		
Access																														RWH		
Name																															LOCKKEY	

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:0	LOCKKEY	0x0000	RWH	<b>Configuration Lock Key</b>		
Write any other value than the unlock code to lock all EMU registers, except the interrupt registers and regulator control registers, from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.						
<hr/>						
Mode		Value	Description			
<hr/>						
Read Operation						
UNLOCKED	0		EMU registers are unlocked			
LOCKED	1		EMU registers are locked			
<hr/>						
Write Operation						
LOCK	0		Lock EMU registers			
UNLOCK	0xADE8		Unlock EMU registers			
<hr/>						

## 9.5.4 EMU\_RAM0CTRL - Memory Control Register

Offset	Bit Position																																			
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset																														0x0						
Access																															RW					
Name																																				RAMPOWERDOWN

Bit	Name	Reset	Access	Description															
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
2:0	RAMPOWERDOWN	0x0	RW	<b>RAM0 Blockset Power-down</b>															
RAM blockset power-down in EM23 with full access in EM01. Block 0 may never be powered down.																			
<table border="1"> <thead> <tr> <th>Mode</th><th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>NONE</td><td>0x00</td><td>None of the RAM blocks powered down</td></tr> <tr> <td>BLK3</td><td>0x4</td><td>Power down RAM block 3 (address range 0x20006000-0x20007FFF)</td></tr> <tr> <td>BLK2TO3</td><td>0x6</td><td>Power down RAM blocks 2 and above (address range 0x20004000-0x20007FFF)</td></tr> <tr> <td>BLK1TO3</td><td>0x7</td><td>Power down RAM blocks 1 and above (address range 0x20002000-0x20007FFF)</td></tr> </tbody> </table>					Mode	Value	Description	NONE	0x00	None of the RAM blocks powered down	BLK3	0x4	Power down RAM block 3 (address range 0x20006000-0x20007FFF)	BLK2TO3	0x6	Power down RAM blocks 2 and above (address range 0x20004000-0x20007FFF)	BLK1TO3	0x7	Power down RAM blocks 1 and above (address range 0x20002000-0x20007FFF)
Mode	Value	Description																	
NONE	0x00	None of the RAM blocks powered down																	
BLK3	0x4	Power down RAM block 3 (address range 0x20006000-0x20007FFF)																	
BLK2TO3	0x6	Power down RAM blocks 2 and above (address range 0x20004000-0x20007FFF)																	
BLK1TO3	0x7	Power down RAM blocks 1 and above (address range 0x20002000-0x20007FFF)																	

## 9.5.5 EMU\_CMD - Command Register

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	EM01VSCALE2	0	W1	<b>EM01 Voltage Scale Command to Scale to Voltage Scale Level 2</b>  Start EM01 voltage scaling to Voltage Scale Level 2. Write to this register will trigger voltage scaling to Voltage Scale Level 2 followed by an VSCALEDONE interrupt
5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	EM01VSCALE0	0	W1	<b>EM01 Voltage Scale Command to Scale to Voltage Scale Level 0</b>  Start EM01 voltage scaling to Voltage Scale Level 0. Write to this register will trigger voltage scaling to Voltage Scale Level 0 followed by an VSCALEDONE interrupt
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EM4UNLATCH	0	W1	<b>EM4 Unlatch</b>  When entering EM4, several registers will be latched in order to maintain constant functionality throughout EM4. Upon wakeup, these registers will be reset and can have contradictory values to the latched values. To ensure a seamless transition from EM4 to EM0, the unlatch command should be given after properly reconfiguring these latched registers. The unlatch command can be executed after any reset condition but is only needed after EM4 wakeup.

## 9.5.6 EMU\_EM4CTRL - EM4 Control Register

Offset	Bit Position																																			
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset	0x0																		0x0																	
Access	W1																		RW																	
Name	EM4ENTRY																		EM4IORETMODE																	

Bit	Name	Reset	Access	Description
31:18	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
17:16	EM4ENTRY	0x0	W1	<b>Energy Mode 4 Entry</b>  This register is used to enter the Energy Mode 4 sequence. Writing the sequence 2,3,2,3,2,3,2,3,2 will enter the part into Energy Mode 4.
15:6	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
5:4	EM4IORETMODE	0x0	RW	<b>EM4 IO Retention Disable</b>  Determine when IO retention will be applied and removed.
	Value	Mode	Description	
	0	DISABLE	No Retention: Pads enter reset state when entering EM4	
	1	EM4EXIT	Retention through EM4: Pads enter reset state when exiting EM4	
	2	SWUNLATCH	Retention through EM4 and Wakeup: software writes UNLATCH register to remove retention	
3	RETAINULFRCO	0	RW	<b>ULFRCO Retain During EM4S</b>  Retain the ULFRCO upon EM4S entry. If set to 1, an already running ULFRCO will be retained in its running state in EM4. ULFRCO will always be retained if EM4STATE is in EM4H.
2	RETAINLFXO	0	RW	<b>LFXO Retain During EM4</b>  Retain the LFXO upon EM4(SH/H) entry. If set to 1, an already running LFXO will be retained in its running state in EM4.
1	RETAINLFRFCO	0	RW	<b>LFRFCO Retain During EM4</b>  Retain the LFRFCO upon EM4(S/H) entry. If set to 1, an already running LFRFCO will be retained in its running state in EM4.
0	EM4STATE	0	RW	<b>Energy Mode 4 State</b>  When set, the system will enter Hibernate state (EM4H) when entering EM4. In EM4H, the regulator will be on in reduced mode allowing for RTCC. Otherwise, when entering in EM4, the regulator will be disabled allowing for lowest power mode, Shutoff state (EM4S). Only reset with POR or Hard Pin Reset
	Value	Mode	Description	
	0	EM4S	EM4S Shutoff state	
	1	EM4H	EM4H Hibernate state	

## 9.5.7 EMU\_TEMPLIMITS - Temperature Limits for Interrupt Generation

Offset	Bit Position																																
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																	0	0xFF								0x00							
Access																	RW	RW								RW							
Name																	EM4WUEN	TEMPHIGH								TEMPLOW							

Bit	Name	Reset	Access	Description
31:17	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
16	EM4WUEN	0	RW	<b>Enable EM4 Wakeup Due to Low/high Temperature</b>
	Enable EM4 wakeup from low or high temperature from EM4H			
15:8	TEMPHIGH	0xFF	RW	<b>Temperature High Limit</b>
	The TEMPHIGH interrupt flag is set when a periodic temperature measurement is equal to or higher than this value. If the high limit is changed during a temperature measurement (TEMPACTIVE=1), the limit update will be delayed until the end of the temperature measurement.			
7:0	TEMPLOW	0x00	RW	<b>Temperature Low Limit</b>
	The TEMPLOW interrupt flag is set when a periodic temperature measurement is equal to or lower than this value. If the low limit is changed during a temperature measurement (TEMPACTIVE=1), the limit update will be delayed until the end of the temperature measurement.			

## 9.5.8 EMU\_TEMP - Value of Last Temperature Measurement

Offset	Bit Position																																
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																	0	0XXX								0XXX							
Access																	R								TEMP								
Name																	TEMP								TEMP								

Bit	Name	Reset	Access	Description
31:8	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
7:0	TEMP	0XX	R	<b>Temperature Measurement</b>
	Value of last periodic temperature measurement. Value is asynchronously updated. Value is stable for 250 ms after a temperature-based interrupt (TEMPHIGH, TEMPLOW, or TEMP) and can be read with a single read operation. If register is read not in response to a temperature-based interrupt, multiple readings should be taken until two consecutive values are the same.			

## 9.5.9 EMU\_IF - Interrupt Flag Register

Offset	Bit Position																							
Reset	0	30	0	29	28	27	26	0	25	R	0	24	R	0	23	R	0	22	R	0	21	R	0	20
Access	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Name	TEMPHIGH	TEMPLOW	TEMP	VSCALEDONE	EM23WAKEUP	BURDY	DCDCINBYPASS	DCDCLNRUNNING	DCDCLPRUNNING	NFETOVERTCURRENTLIMIT	PFETOVERTCURRENTLIMIT	VMONFVDDRISE	VMONFVDDFALL	VMONBUVDDRISE	VMONBUVDDFALL	VMONIO0RISE	VMONIO0FALL	VMONDVDDRISE	VMONDVDDFALL	VMONALTAVDDRISE	VMONALTAVDDFALL	VMONAVDDRISE	VMONAVDDFALL	

Bit	Name	Reset	Access	Description
31	TEMPHIGH	0	R	<b>Temperature High Limit Reached</b>  Set when the value of a periodic temperature measurement is higher or equal than TEMPHIGH in EMU_TEMPLIMITS
30	TEMPLOW	0	R	<b>Temperature Low Limit Reached</b>  Set when the value of a periodic temperature measurement is lower or equal than TEMPHIGH in EMU_TEMPLIMITS
29	TEMP	0	R	<b>New Temperature Measurement Valid</b>  Set when a new periodic temperature measurement is available
28:26	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
25	VSCALEDONE	0	R	<b>Voltage Scale Steps Done IRQ</b>  Will be set when all the steps needed for voltage scaling is done. For voltage upgrade, the software can start increasing clock frequency after this interrupt. For voltage downgrade, this will indicate that hardware has finished all the steps including updating of BOD levels and regulator controls, but voltage drop may take lot longer due to load current
24	EM23WAKEUP	0	R	<b>Wakeup IRQ From EM2 and EM3</b>  Will be set when the system wakes up from EM2 and EM3. This interrupt can be used to run initialization code need to reconfigure the system when returning from EM2 and EM3.
23	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
22	BURDY	0	R	<b>Backup Functionality Ready Interrupt Flag</b>  Set when the Backup functionality is ready for use.
21	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
20	DCDCINBYPASS	0	R	<b>DCDC is in Bypass</b>  DCDC is in bypass
19	DCDCLNRUNNING	0	R	<b>LN Mode is Running</b>  This flag is set once the DCDC regulator has started to run in LN mode
18	DCDCLPRUNNING	0	R	<b>LP Mode is Running</b>  This flag is set once the DCDC regulator has started to run in LP mode

Bit	Name	Reset	Access	Description
17	NFETOVERCUR-RENTLIMIT	0	R	<b>NFET Current Limit Hit</b>  Reserved for internal use.
16	PFETOVERCUR-RENTLIMIT	0	R	<b>PFET Current Limit Hit</b>  Reserved for internal use.
15	VMONFVDDRISE	0	R	<b>VMON VDDFLASH Channel Rise</b>  A rising edge on VMON VDDFLASH channel has been detected.
14	VMONFVDDFALL	0	R	<b>VMON VDDFLASH Channel Fall</b>  A falling edge on VMON VDDFLASH channel has been detected.
13	VMONBUVDDRISE	0	R	<b>VMON BUVDD Channel Rise</b>  A rising edge on VMON BUVDD channel has been detected.
12	VMONBUVDDFALL	0	R	<b>VMON BACKUP Channel Fall</b>  A falling edge on VMON BUVDD channel has been detected.
11:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	VMONIO0RISE	0	R	<b>VMON IOVDD0 Channel Rise</b>  A rising edge on VMON IOVDD0 channel has been detected.
6	VMONIO0FALL	0	R	<b>VMON IOVDD0 Channel Fall</b>  A falling edge on VMON IOVDD0 channel has been detected.
5	VMONDVDDRISE	0	R	<b>VMON DVDD Channel Rise</b>  A rising edge on VMON DVDD channel has been detected.
4	VMONDVDDFALL	0	R	<b>VMON DVDD Channel Fall</b>  A falling edge on VMON DVDD channel has been detected.
3	VMONALTAVDD-RISE	0	R	<b>Alternate VMON AVDD Channel Rise</b>  A rising edge on Alternate VMON AVDD channel has been detected.
2	VMONALTAVDD-FALL	0	R	<b>Alternate VMON AVDD Channel Fall</b>  A falling edge on Alternate VMON AVDD channel has been detected.
1	VMONAVDDRISE	0	R	<b>VMON AVDD Channel Rise</b>  A rising edge on VMON AVDD channel has been detected.
0	VMONAVDDFALL	0	R	<b>VMON AVDD Channel Fall</b>  A falling edge on VMON AVDD channel has been detected.

## 9.5.10 EMU\_IFS - Interrupt Flag Set Register

Offset	Bit Position																
Reset	31	0	30	0	29	0	28	0	27	0	26	0	25	W1	0	VSCALEDONE	
Access	W1	0	W1	0	W1	0	W1	0	W1	0	W1	0	W1	0	W1	0	EM23WAKEUP
Name	TEMPHIGH	TEMPLOW	TEMP	VSCALEDONE	EM23WAKEUP	BURDY	DCDCINBYPASS	DCDCLNRUNNING	DCDCLPRUNNING	NFETOVERCURRENTLIMIT	PFTETOVERCURRENTLIMIT	VMONFVDDRISE	VMONFVDDFALL	VMONBUVDRISE	VMONBUVDFALL	VMONIO0RISE	
Bit	Bit	Name	Reset	Access	Description												VMONIO0FALL
31	TEMPHIGH	0	W1	<b>Set TEMPHIGH Interrupt Flag</b>													VMONDVDDRISE
				Write 1 to set the TEMPHIGH interrupt flag													VMONDVDDFALL
30	TEMPLOW	0	W1	<b>Set TEMPLOW Interrupt Flag</b>													VMONALTAVDDRISE
				Write 1 to set the TEMPLOW interrupt flag													VMONALTAVDDFALL
29	TEMP	0	W1	<b>Set TEMP Interrupt Flag</b>													VMONAVDDRIS
				Write 1 to set the TEMP interrupt flag													VMONAVDDFALL
28:26	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>													
25	VSCALEDONE	0	W1	<b>Set VSCALEDONE Interrupt Flag</b>													
				Write 1 to set the VSCALEDONE interrupt flag													
24	EM23WAKEUP	0	W1	<b>Set EM23WAKEUP Interrupt Flag</b>													
				Write 1 to set the EM23WAKEUP interrupt flag													
23	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>													
22	BURDY	0	W1	<b>Set BURDY Interrupt Flag</b>													
				Write 1 to set the BURDY interrupt flag													
21	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>													
20	DCDCINBYPASS	0	W1	<b>Set DCDCINBYPASS Interrupt Flag</b>													
				Write 1 to set the DCDCINBYPASS interrupt flag													
19	DCDCLNRUNNING	0	W1	<b>Set DCDCLNRUNNING Interrupt Flag</b>													
				Write 1 to set the DCDCLNRUNNING interrupt flag													
18	DCDCLPRUNNING	0	W1	<b>Set DCDCLPRUNNING Interrupt Flag</b>													
				Write 1 to set the DCDCLPRUNNING interrupt flag													

Bit	Name	Reset	Access	Description
17	NFETOVERCUR- RENTLIMIT	0	W1	<b>Set NFETOVERCURRENTLIMIT Interrupt Flag</b>  Write 1 to set the NFETOVERCURRENTLIMIT interrupt flag
16	PFETOVERCUR- RENTLIMIT	0	W1	<b>Set PFETOVERCURRENTLIMIT Interrupt Flag</b>  Write 1 to set the PFETOVERCURRENTLIMIT interrupt flag
15	VMONFVDDRISE	0	W1	<b>Set VMONFVDDRISE Interrupt Flag</b>  Write 1 to set the VMONFVDDRISE interrupt flag
14	VMONFVDDFALL	0	W1	<b>Set VMONFVDDFALL Interrupt Flag</b>  Write 1 to set the VMONFVDDFALL interrupt flag
13	VMONBUVDDRISE	0	W1	<b>Set VMONBUVDDRISE Interrupt Flag</b>  Write 1 to set the VMONBUVDDRISE interrupt flag
12	VMONBUVDDFALL	0	W1	<b>Set VMONBUVDDFALL Interrupt Flag</b>  Write 1 to set the VMONBUVDDFALL interrupt flag
11:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	VMONIO0RISE	0	W1	<b>Set VMONIO0RISE Interrupt Flag</b>  Write 1 to set the VMONIO0RISE interrupt flag
6	VMONIO0FALL	0	W1	<b>Set VMONIO0FALL Interrupt Flag</b>  Write 1 to set the VMONIO0FALL interrupt flag
5	VMONDVDDRISE	0	W1	<b>Set VMONDVDDRISE Interrupt Flag</b>  Write 1 to set the VMONDVDDRISE interrupt flag
4	VMONDVDDFALL	0	W1	<b>Set VMONDVDDFALL Interrupt Flag</b>  Write 1 to set the VMONDVDDFALL interrupt flag
3	VMONALTAVDD- RISE	0	W1	<b>Set VMONALTAVDDRISE Interrupt Flag</b>  Write 1 to set the VMONALTAVDDRISE interrupt flag
2	VMONALTAVDD- FALL	0	W1	<b>Set VMONALTAVDDFALL Interrupt Flag</b>  Write 1 to set the VMONALTAVDDFALL interrupt flag
1	VMONAVDDRISE	0	W1	<b>Set VMONAVDDRISE Interrupt Flag</b>  Write 1 to set the VMONAVDDRISE interrupt flag
0	VMONAVDDFALL	0	W1	<b>Set VMONAVDDFALL Interrupt Flag</b>  Write 1 to set the VMONAVDDFALL interrupt flag

### **9.5.11 EMU\_IFC - Interrupt Flag Clear Register**

Offset	Bit Position				
Reset	0x02C	31	0	(R)W1	TEMPHIGH
Access	0x02C	30	0	(R)W1	TEMPLOW
Name	TEMP	29	0	(R)W1	TEMP
		28			
		27			
		26			
VSCALEDONE		25	0	(R)W1	EM23WAKEUP
EM23WAKEUP		24	0	(R)W1	BURDY
		23			
DCDCINBYPASS		22	0	(R)W1	DCDCLNRUNNING
DCDCLNRUNNING		21			
DCDCLPRUNNING		20	0	(R)W1	NFETOVERCURRENTLIMIT
NFETOVERCURRENTLIMIT		19	0	(R)W1	PFETOVERCURRENTLIMIT
PFETOVERCURRENTLIMIT		18	0	(R)W1	VMONFVDDRISE
VMONFVDDRISE		17	0	(R)W1	VMONFVDDFALL
VMONFVDDFALL		16	0	(R)W1	VMONBUVDDRISE
VMONBUVDDRISE		15	0	(R)W1	VMONBUVDDFALL
VMONBUVDDFALL		14	0	(R)W1	VMONIO0RISE
VMONIO0RISE		13	0	(R)W1	VMONIO0FALL
VMONIO0FALL		12	0	(R)W1	VMONDVDDRISE
VMONDVDDRISE		11			VMONDVDDFALL
VMONDVDDFALL		10			VMONTAVDDRIVE
VMONTAVDDRIVE		9			VMONTAVDDFALL
VMONTAVDDFALL		8			VMONAVDDRIVE
VMONAVDDRIVE		7	0	(R)W1	VMONAVDDFALL
VMONAVDDFALL		6	0	(R)W1	
		5	0	(R)W1	
		4	0	(R)W1	
		3	0	(R)W1	
		2	0	(R)W1	
		1	0	(R)W1	
		0	0	(R)W1	

Bit	Name	Reset	Access	Description
31	TEMPHIGH	0	(R)W1	<b>Clear TEMPHIGH Interrupt Flag</b>  Write 1 to clear the TEMPHIGH interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
30	TEMPLOW	0	(R)W1	<b>Clear TEMPLOW Interrupt Flag</b>  Write 1 to clear the TEMPLOW interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
29	TEMP	0	(R)W1	<b>Clear TEMP Interrupt Flag</b>  Write 1 to clear the TEMP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
28:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25	VSCALEDONE	0	(R)W1	<b>Clear VSCALEDONE Interrupt Flag</b>  Write 1 to clear the VSCALEDONE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
24	EM23WAKEUP	0	(R)W1	<b>Clear EM23WAKEUP Interrupt Flag</b>  Write 1 to clear the EM23WAKEUP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22	BURDY	0	(R)W1	<b>Clear BURDY Interrupt Flag</b>  Write 1 to clear the BURDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
21	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
20	DCDCINBYPASS	0	(R)W1	<b>Clear DCDCINBYPASS Interrupt Flag</b>  Write 1 to clear the DCDCINBYPASS interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
19	DCDCLNRUNNING	0	(R)W1	<b>Clear DCDCLNRUNNING Interrupt Flag</b>  Write 1 to clear the DCDCLNRUNNING interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
18	DCDCLPRUNNING	0	(R)W1	<b>Clear DCDCLPRUNNING Interrupt Flag</b>  Write 1 to clear the DCDCLPRUNNING interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
17	NFETOVERCUR- RENTLIMIT	0	(R)W1	<b>Clear NFETOVERCURRENTLIMIT Interrupt Flag</b>  Write 1 to clear the NFETOVERCURRENTLIMIT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
16	PFETOVERCUR- RENTLIMIT	0	(R)W1	<b>Clear PFETOVERCURRENTLIMIT Interrupt Flag</b>  Write 1 to clear the PFETOVERCURRENTLIMIT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15	VMONFVDDRISE	0	(R)W1	<b>Clear VMONFVDDRISE Interrupt Flag</b>  Write 1 to clear the VMONFVDDRISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
14	VMONFVDDFALL	0	(R)W1	<b>Clear VMONFVDDFALL Interrupt Flag</b>  Write 1 to clear the VMONFVDDFALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
13	VMONBUVDDRISE	0	(R)W1	<b>Clear VMONBUVDDRISE Interrupt Flag</b>  Write 1 to clear the VMONBUVDDRISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
12	VMONBUVDDFALL	0	(R)W1	<b>Clear VMONBUVDDFALL Interrupt Flag</b>  Write 1 to clear the VMONBUVDDFALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
11:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	VMONIO0RISE	0	(R)W1	<b>Clear VMONIO0RISE Interrupt Flag</b>  Write 1 to clear the VMONIO0RISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
6	VMONIO0FALL	0	(R)W1	<b>Clear VMONIO0FALL Interrupt Flag</b>  Write 1 to clear the VMONIO0FALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	VMONDVDDRISE	0	(R)W1	<b>Clear VMONDVDDRISE Interrupt Flag</b>  Write 1 to clear the VMONDVDDRISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	VMONDVDDFALL	0	(R)W1	<b>Clear VMONDVDDFALL Interrupt Flag</b>  Write 1 to clear the VMONDVDDFALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	VMONALTAVDD- RISE	0	(R)W1	<b>Clear VMONALTAVDDRISE Interrupt Flag</b>  Write 1 to clear the VMONALTAVDDRISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
2	VMONALTAVDD-FALL	0	(R)W1	<b>Clear VMONALTAVDDFALL Interrupt Flag</b>  Write 1 to clear the VMONALTAVDDFALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	VMONAVDDRRISE	0	(R)W1	<b>Clear VMONAVDDRRISE Interrupt Flag</b>  Write 1 to clear the VMONAVDDRRISE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	VMONAVDDFALL	0	(R)W1	<b>Clear VMONAVDDFALL Interrupt Flag</b>  Write 1 to clear the VMONAVDDFALL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 9.5.12 EMU\_IEN - Interrupt Enable Register

Offset	Bit Position																
Reset	31	0	30	0	29	0	28	0	27	0	26	0	25	RW	0	VSCALEDONE	
Access	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	EM23WAKEUP
Name	TEMPHIGH		TEMPLOW		TEMP		BURDY		RW	0	RW	0	RW	0	RW	0	VSCALEDONE
	DCDCINBYPASS		DCDCLNRUNNING		DCDCLPRUNNING		NFETOVERCURRENTLIMIT		RW	0	RW	0	RW	0	RW	0	EM23WAKEUP
	DCDCLPRUNNING		NFETOVERCURRENTLIMIT		PFTOVERCURRENTLIMIT		PFTOVERCURRENTLIMIT		RW	0	RW	0	RW	0	RW	0	VSCALEDONE
	VMONFVDDRISE		VMONFVDDFALL		VMONBUVDDRISE		VMONBUVDDFALL		RW	0	RW	0	RW	0	RW	0	EM23WAKEUP
	VMONBUVDDFALL		VMONBUVDDFALL		VMONBUVDDFALL		VMONBUVDDFALL		RW	0	RW	0	RW	0	RW	0	VSCALEDONE
	VMONIOOIRISE		VMONIOOFALL		VMONDVDDRISE		VMONDVDDFALL		VMONALTAVDDRSE		VMONALTAVDDFALL		VMONNAVDDRSE		VMONNAVDDFALL		EM23WAKEUP
	VMONNAVDDFALL		VMONNAVDDFALL		VMONNAVDDFALL		VMONNAVDDFALL		RW	0	RW	0	RW	0	RW	0	VSCALEDONE

Bit	Name	Reset	Access	Description
31	TEMPHIGH	0	RW	<b>TEMPHIGH Interrupt Enable</b>  Enable/disable the TEMPHIGH interrupt
30	TEMPLOW	0	RW	<b>TEMPLOW Interrupt Enable</b>  Enable/disable the TEMPLOW interrupt
29	TEMP	0	RW	<b>TEMP Interrupt Enable</b>  Enable/disable the TEMP interrupt
28:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25	VSCALEDONE	0	RW	<b>VSCALEDONE Interrupt Enable</b>  Enable/disable the VSCALEDONE interrupt
24	EM23WAKEUP	0	RW	<b>EM23WAKEUP Interrupt Enable</b>  Enable/disable the EM23WAKEUP interrupt
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22	BURDY	0	RW	<b>BURDY Interrupt Enable</b>  Enable/disable the BURDY interrupt
21	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
20	DCDCINBYPASS	0	RW	<b>DCDCINBYPASS Interrupt Enable</b>  Enable/disable the DCDCINBYPASS interrupt
19	DCDCLNRUNNING	0	RW	<b>DCDCLNRUNNING Interrupt Enable</b>  Enable/disable the DCDCLNRUNNING interrupt
18	DCDCLPRUNNING	0	RW	<b>DCDCLPRUNNING Interrupt Enable</b>  Enable/disable the DCDCLPRUNNING interrupt

Bit	Name	Reset	Access	Description
17	NFETOVERCUR- RENTLIMIT	0	RW	<b>NFETOVERCURRENTLIMIT Interrupt Enable</b>  Enable/disable the NFETOVERCURRENTLIMIT interrupt
16	PFETOVERCUR- RENTLIMIT	0	RW	<b>PFETOVERCURRENTLIMIT Interrupt Enable</b>  Enable/disable the PFETOVERCURRENTLIMIT interrupt
15	VMONFVDDRISE	0	RW	<b>VMONFVDDRISE Interrupt Enable</b>  Enable/disable the VMONFVDDRISE interrupt
14	VMONFVDDFALL	0	RW	<b>VMONFVDDFALL Interrupt Enable</b>  Enable/disable the VMONFVDDFALL interrupt
13	VMONBUVDDRISE	0	RW	<b>VMONBUVDDRISE Interrupt Enable</b>  Enable/disable the VMONBUVDDRISE interrupt
12	VMONBUVDDFALL	0	RW	<b>VMONBUVDDFALL Interrupt Enable</b>  Enable/disable the VMONBUVDDFALL interrupt
11:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	VMONIO0RISE	0	RW	<b>VMONIO0RISE Interrupt Enable</b>  Enable/disable the VMONIO0RISE interrupt
6	VMONIO0FALL	0	RW	<b>VMONIO0FALL Interrupt Enable</b>  Enable/disable the VMONIO0FALL interrupt
5	VMONDVDDRISE	0	RW	<b>VMONDVDDRISE Interrupt Enable</b>  Enable/disable the VMONDVDDRISE interrupt
4	VMONDVDDFALL	0	RW	<b>VMONDVDDFALL Interrupt Enable</b>  Enable/disable the VMONDVDDFALL interrupt
3	VMONALTAVDD- RISE	0	RW	<b>VMONALTAVDDRISE Interrupt Enable</b>  Enable/disable the VMONALTAVDDRISE interrupt
2	VMONALTAVDD- FALL	0	RW	<b>VMONALTAVDDFALL Interrupt Enable</b>  Enable/disable the VMONALTAVDDFALL interrupt
1	VMONAVDDRISE	0	RW	<b>VMONAVDDRISE Interrupt Enable</b>  Enable/disable the VMONAVDDRISE interrupt
0	VMONAVDDFALL	0	RW	<b>VMONAVDDFALL Interrupt Enable</b>  Enable/disable the VMONAVDDFALL interrupt

## 9.5.13 EMU\_PWRLOCK - Regulator and Supply Lock Register

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RW															
Name																	LOCKKEY															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

15:0    LOCKKEY    0x0000    RW    **Regulator and Supply Configuration Lock Key**

Write any other value than the unlock code to lock all regulator control registers, from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled. Registers that are locked: PWRCFG, PWRCTRL and DCDC\* registers.

Mode	Value	Description
<b>Read Operation</b>		
UNLOCKED	0	EMU Regulator registers are unlocked
LOCKED	1	EMU Regulator registers are locked
<b>Write Operation</b>		
LOCK	0	Lock EMU Regulator registers
UNLOCK	0xADE8	Unlock EMU Regulator registers

#### 9.5.14 EMU\_PWRCTRL - Power Control Register

Offset	Bit Position																	
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14
Reset																		
Access																		
Name																		
IMMEDIATEPWRSWITCH	RW	0	13									12						
REGPWRSEL	RW	0	10									11						
ANASW	RW	0	5									7						

Bit	Name	Reset	Access	Description
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13	IMMEDIATEPWRSTWITCH	0	RW	<b>Allows Immediate Switching of ANASW and REGPWRSEL Bit-fields</b>  When set, allows immediate ANASW/REGPWRSEL switching. When cleared, Hardware protects switching of ANASW/REGPWRSEL and switching is applied by hardware only when DCDC is stable
12:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	REGPWRSEL	0	RW	<b>This Field Selects the Input Supply Pin for the Digital LDO</b>  Determines the power supply input used by the Digital LDO. Firmware should select DVDD as the input after startup. If DCDC is not configured to drive DVDD, IMMEDIATEPWRSTWITCH needs to be set to prior to setting this bit to immediately make the switch. If DCDC is configured to drive DVDD, hardware will make the switch to DVDD only when DCDC is stable
<hr/>				
	Value	Mode		Description
	0	AVDD		The AVDD pin is the supply for the digital LDO. LDO current is limited to 20 mA in this configuration.
	1	DVDD		The DVDD pin is the supply for the digital LDO. Firmware should set REGPWRSEL=1 after startup, before increasing the core clock frequency.
<hr/>				
9:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	ANASW	0	RW	<b>Analog Switch Selection</b>  Determines the power supply routed to the analog supply (VDDX_ANA) used by the analog peripherals (e.g., ULFRCO, LFRCO, LFXO, HFRCO, AUXHFRCO, VMON, IDAC, and ADC). Reset with POR, Hard Pin Reset, or BOD Reset. If DCDC is not configured to drive DVDD, IMMEDIATEPWRSTWITCH needs to be set to prior to setting this bit to immediately make the switch. If DCDC is configured to drive DVDD, hardware will make the switch to DVDD only when DCDC is stable
<hr/>				
	Value	Mode		Description
	0	AVDD		Select AVDD as the analog power supply
	1	DVDD		Select DVDD as the analog power supply
<hr/>				
4:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 9.5.15 EMU\_DCDCCTRL - DCDC Control

Offset	Bit Position																																			
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset																																			1	0x3
Access																																				RW
Name																																				DCDCMODE

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	DCDCMODEEM4	1	RW	<b>DCDC Mode EM4H</b>
	Determines the DCDC mode in EM4H. This bit is ignored if DCDCMODE=Bypass. Reset with POR, Hard Pin Reset, or BOD Reset.			
	Value	Mode	Description	
	0	EM4SW	DCDC mode is according to DCDCMODE field.	
	1	EM4LOWPOWER	DCDC mode is low power.	
4	DCDCMODEEM23	1	RW	<b>DCDC Mode EM23</b>
	Determines the DCDC mode in EM2 and EM3. This bit is ignored if DCDCMODE=Bypass. Reset with POR, Hard Pin Reset, or BOD Reset.			
	Value	Mode	Description	
	0	EM23SW	DCDC mode is according to DCDCMODE field.	
	1	EM23LOWPOWER	DCDC mode is low power.	
3:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	DCDCMODE	0x3	RW	<b>Regulator Mode</b>
	Determines the operating mode of the DCDC regulator. Reset with POR, Hard Pin Reset, or BOD Reset.			
	Value	Mode	Description	
	0	BYPASS	DCDC regulator is operating in bypass mode. Prior to configuring DCDCMODE=BYPASS, software must set EMU_DCDCCCLIMCTRL.BYPLIMEN=1 to prevent excessive current between VREGVDD and DVDD supplies.	
	1	LOWNOISE	DCDC regulator is operating in low noise mode.	
	2	LOWPOWER	DCDC regulator is operating in low power mode.	
	3	OFF	DCDC regulator is off and the bypass switch is off. Note: DVDD must be supplied externally	

## 9.5.16 EMU\_DCDCMISCCTRL - DCDC Miscellaneous Control Register

Offset	Bit Position																																
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name	LPCMPBIASEM234H	RW	0x0	RW	0x3	RW	0x1	RW	0x1	RW	0x0	RW	0x0	RW	0x7	RW	0x7	RW	0x7	RW	0x7	RW	0x5	RW	0	RW	1	RW	1	RW	0	0	

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:28	LPCMPBIASEM234H	0x0	RW	<b>LP Mode Comparator Bias Selection for EM23 or EM4H</b>
				LP mode comparator bias selection. Reset with POR, Hard Pin Reset, or BOD Reset.
	Value	Mode		Description
	0	BIAS0		Maximum load current less than 75uA.
	1	BIAS1		Maximum load current less than 500uA.
	2	BIAS2		Maximum load current less than 2.5mA.
	3	BIAS3		Maximum load current less than 10mA.
27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
26:24	LNCLIMILIMSEL	0x3	RW	<b>Current Limit Level Selection for Current Limiter in LN Mode</b>
				High-side current limiter's current limit level selection in low noise mode. The recommended setting is calculated by $LNCLIMILIMSEL = (I\_MAX + 40mA) * 1.5 / (5mA * (PFETCNT + 1)) - 1$ , where $I\_MAX$ is the maximum average current allowed to the load, and 40mA represents the current ripple with some margin, and the factor of 1.5 accounts for detecting error and other variations. For strong (i.e., low internal impedance) battery, it is recommended to have $I\_MAX=200mA$ . $I\_MAX$ should never be set higher than 200mA to avoid reliability issues. Reset with POR, Hard Pin Reset, or BOD reset.
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	LPCLIMILIMSEL	0x1	RW	<b>Current Limit Level Selection for Current Limiter in LP Mode</b>
				Sets high-side current limit in low power mode, with maximum current equal to $40\text{ mA} * (1 + LPCLIMILIMSEL)$ . Recommend setting $LPCLIMILIMSEL=1$ , corresponding to a maximum current of 80 mA for optimal efficiency and to support up to 10 mA loads when $LPCMPBIASEM234H=0x3$ . Reset with POR, Hard Pin Reset, or BOD reset.
19:16	BYPLIMSEL	0x0	RW	<b>Current Limit in Bypass Mode</b>
				Set current limit in bypass mode when BYPLIMEN equals one. The limit is from 20mA to 320mA, with 20mA/step. Reset with POR, Hard Pin Reset, or BOD Reset.
15:12	NFETCNT	0x7	RW	<b>NFET Switch Number Selection</b>
				Low Noise mode NFET power switch count number. The selected number of switches are $NFETCNT + 1$ . This may cause a very momentary efficiency hit. Reset with POR, Hard Pin Reset, or BOD Reset.

Bit	Name	Reset	Access	Description
11:8	PFETCNT	0x7	RW	<b>PFET Switch Number Selection</b>  Low Noise mode PFET power switch count number. The selected number of switches are PFETCNT+1. Reset with POR, Hard Pin Reset, or BOD Reset.
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	LNFORCECCMIMM	0	RW	<b>Force DCDC Into CCM Mode Immediately, Based on LNFORCECCM</b>  When set, this bit allows software to change LNFORCECCM bit and have the change take effect while DCDC is running. Otherwise, LNFORCECCM must be programmed prior to enabling the DCDC.
4:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	LPCMPHYSI	1	RW	<b>Comparator Threshold on the High Side</b>  Reserved for internal use. Should always be set to 1.
1	LPCMPHYSDIS	1	RW	<b>Disable LP Mode Hysteresis in the State Machine Control</b>  Reserved for internal use. Should always be set to 1.
0	LNFORCECCM	0	RW	<b>Force DCDC Into CCM Mode in Low Noise Operation</b>  When this bit is set to 0 in low noise mode, the zero detector is configured as zero-crossing detector and the DCDC will be in forced CCM mode. The threshold set by ZDETILIMSEL will be ignored. When this bit is set to 1 in low noise mode, the zero detector is configured as reverse-current limiter and the DCDC will be in DCM mode. The reverse current limit level is set by ZDETILIMSEL. In low power mode, the zero detector is always configured as zero-crossing detector. Reset with POR, Hard Pin Reset, or BOD reset.

## 9.5.17 EMU\_DCDCZDETCTRL - DCDC Power Train NFET Zero Current Detector Control Register

Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																												0x1				
Access																												RW				
Name																												ZDETBLANKDLY				
																												ZDETILIMSEL				

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9:8	ZDETBLANKDLY	0x1	RW	<b>Reserved for internal use. Do not change.</b>  Reserved for internal use. Do not change.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6:4	ZDETILIMSEL	0x5	RW	<b>Reverse Current Limit Level Selection for Zero Detector</b>  Zero detector is reconfigured as low-side reverse current limiter when LNFORCECCM=1 in LN mode. The configuration of this register is calculated by the allowed average reverse current I_RMAX through the equation: ZDETILIMSEL=(I_RMAX +40mA)*1.5/(2.5mA*(NFETCNT+1)), where 40mA represents the current ripple with some margin, and the factor of 1.5 accounts for detecting error and other variations. When the battery can tolerate large reverse current, it is recommended to have I_RMAX=160mA to maximize ZDETILIMSEL to 7 with NFETCNT=15. Note that when LNFORCECCM=1 but ZDETILIMSEL=0, the DCDC's behavior will be very similar to when LNFORCECCM=0 - that is, the DCDC will be in DCM mode. When LNFORCECCM=0, the zero detector will only detect zero-crossings (reverse-current limit=0 mA) and this register is ignored. Reset with POR, Hard Pin Reset, or BOD reset.
3:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 9.5.18 EMU\_DCDCCCLIMCTRL - DCDC Power Train PFET Current Limiter Control Register

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13	BYPLIMEN	0	RW	<b>Bypass Current Limit Enable</b>
				Bypass current limit enable. Setting this bit limits maximum current drawn from DCDC input supply while DCDC is in BY-PASS mode. Note that the device will see an additional ~10 µA of current draw when BYPLIMEN=1 and Bypass Mode is enabled. To prevent this excess current, applications should disable the Bypass Current Limit (BYPLIMEN=0) once the DVDD voltage has reached the main supply voltage in Bypass Mode. Reset with POR, Hard Pin Reset, or BOD Reset.
12:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9:8	CLIMBLANKDLY	0x1	RW	<b>Reserved for internal use. Do not change.</b>
				Reserved for internal use. Do not change.
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 9.5.19 EMU\_DCDCLNCOMPCTRL - DCDC Low Noise Compensator Control Register

Offset	Bit Position																																		
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset			0x5				0x7																												
Access		RW			RW						RW	0x2																							
Name	COMPENC3				COMPENC2					COMPENC1		RW																							RW

Bit	Name	Reset	Access	Description
31:28	COMPENC3	0x5	RW	<b>Low Noise Mode Compensator C3 Trim Value</b>  LN mode compensator C3 trim, 0.5pF-8pF in 0.5pF steps. Reset with POR, Hard Pin Reset, or BOD Reset.
27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
26:24	COMPENC2	0x7	RW	<b>Low Noise Mode Compensator C2 Trim Value</b>  LN mode compensator C2 trim, 1pF-8pF in 1pF steps. Reset with POR, Hard Pin Reset, or BOD Reset.
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	COMPENC1	0x2	RW	<b>Low Noise Mode Compensator C1 Trim Value</b>  LN mode compensator C1 trim, 0.15pF-0.60pF in 0.15pF step. Reset with POR, Hard Pin Reset, or BOD Reset.
19:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:12	COMPENR3	0x4	RW	<b>Low Noise Mode Compensator R3 Trim Value</b>  LN mode compensator r3 trim, 5-80KOhm in 5Khom steps. Reset with POR, Hard Pin Reset, or BOD Reset.
11:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:4	COMPENR2	0x07	RW	<b>Low Noise Mode Compensator R2 Trim Value</b>  LN mode compensator r2 trim, 50-1600KOhm, in 50KOhm steps. Reset with POR, Hard Pin Reset, or BOD Reset.
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	COMPENR1	0x7	RW	<b>Low Noise Mode Compensator R1 Trim Value</b>  LN mode compensator r1 trim, 500-1200kOhm, in 100KOhm steps. Reset with POR, Hard Pin Reset, or BOD Reset.

## 9.5.20 EMU\_DCDCLNVCTRL - DCDC Low Noise Voltage Register

Offset	Bit Position																															
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x71												0			
Access																	RWH												RW			
Name																	LNVREF												LNATT			

Bit	Name	Reset	Access	Description
31:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:8	LNVREF	0x71	RWH	<b>Low Noise Mode VREF Trim</b>  Low noise mode Vref trim. LNATT and LNVREF set the output of the DCDC to $3*(1+LNATT)*(235.48+3.226*LNVREF)$ . Customers should use the emlib functions for configuring this field. Reset with POR, Hard Pin Reset, or BOD Reset.
7:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	LNATT	0	RW	<b>Low Noise Mode Feedback Attenuation</b>  Low noise mode feedback attenuation. Customers should use the emlib functions for configuring this field. Reset with POR, Hard Pin Reset, or BOD Reset.
<hr/>				
	Value	Mode	Description	
	0	DIV3	Feedback Ratio is 1/3	
	1	DIV6	Feedback Ratio is 1/6	
<hr/>				
0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 9.5.21 EMU\_DCDCLPVCTRL - DCDC Low Power Voltage Register

Offset	Bit Position																																
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8:1	LPVREF	0xB4	RW	<b>LP Mode Reference Selection for EM23 and EM4H</b>
				Select Vref level. Maximum available code is 8'b11100111. LPATT and LPVREFSEL set the output of the DCDC to $4*(1+LPATT)*(30+LPVREF)*2.2mV$ . Customers should use the emlib functions for configuring this field. Reset with POR, Hard Pin Reset, or BOD Reset.
0	LPATT	0	RW	<b>Low Power Feedback Attenuation</b>
				Low power feedback attenuation select. Customers should use the emlib functions for configuring this field. Reset with POR, Hard Pin Reset, or BOD Reset.
	Value	Mode		Description
	0	DIV4		Feedback Ratio is 1/4
	1	DIV8		Feedback Ratio is 1/8

## 9.5.22 EMU\_DCDCLPCTRL - DCDC Low Power Control Register

Offset	Bit Position																																						
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0							
Reset													0x1	1																									
Access													RW	1																									
Name													LPBLANK	LPVREFDUTYEN													LPCMPHYSSELLEM234H												

Bit	Name	Reset	Access	Description
31:27	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
26:25	LPBLANK	0x1	RW	<b>Reserved for internal use. Do not change.</b>  Reserved for internal use. Do not change.
24	LPVREFDUTYEN	1	RW	<b>LP Mode Duty Cycling Enable</b>  Allow duty cycling of the bias. This is to minimize DC bias. Reset with POR, Hard Pin Reset, or BOD Reset.
23:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15:12	LPCMPHYSSELLEM234H	0x0	RW	<b>LP Mode Hysteresis Selection for EM23 and EM4H</b>  User-programmable hysteresis level for the low power comparator. Hysteresis voltage at the output is $4 * (1 + LPATT) * LPCMPHYSSEL * 3.13\text{mv}$ . Customers should use the emlib functions for configuring this field. Reset with POR, Hard Pin Reset, or BOD Reset.
11:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

## 9.5.23 EMU\_DCDCLNREQCTRL - DCDC Low Noise Controller Frequency Control

Offset	Bit Position																																
0x070	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x0																																
Access	RW																																
Name	RCOTRIM																																

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
28:24	RCOTRIM	0x10	RW	<b>Reserved for internal use. Do not change.</b>  Reserved for internal use. Do not change.
23:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2:0	RCOBAND	0x0	RW	<b>LN Mode RCO Frequency Band Selection</b>  Low noise mode RCO frequency selection. 0~7: 3~8.95MHz, approximately 0.85MHz/step. Reset with POR, Hard Pin Reset, or BOD Reset.

## 9.5.24 EMU\_DCDCSYNC - DCDC Read Status Register

Offset	Bit Position																															
0x078	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access	R																															
Name	DCDCCTRLBUSY																															

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	DCDCCTRLBUSY	0	R	<b>DCDC CTRL Register Transfer Busy</b>  Indicates the status of the DCDCCTRL transfer to the EMU OSC clock domain. Software cannot re-write the DCDCCTRL register until this signal goes low.

## 9.5.25 EMU\_VMONAVDDCTRL - VMON AVDD Channel Control

Offset	Bit Position																															
0x090	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	RW	0	0	0
Reset					0x0					0x0					0x0					0x0					0	3	2	1	0			
Access					RW					RW					RW					RW					RW	0	2	1	0			
Name					RISETHRESCOARSE					RISETHRESFINE					FALLTHRESCOARSE					FALLTHRESFINE					FALLWU		RISEWU		EN			

Bit	Name	Reset	Access	Description
31:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
23:20	RISETHRES-COARSE	0x0	RW	<b>Rising Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
19:16	RISETHRESFINE	0x0	RW	<b>Rising Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
15:12	FALLTHRES-COARSE	0x0	RW	<b>Falling Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
11:8	FALLTHRESFINE	0x0	RW	<b>Falling Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	FALLWU	0	RW	<b>Fall Wakeup</b>  When set, a wakeup from EM4H will take place upon a falling edge. Reset with SYSEXTEDRESETn.
2	RISEWU	0	RW	<b>Rise Wakeup</b>  When set, a wakeup from EM4H will take place upon a rising edge. Reset with SYSEXTEDRESETn.
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	EN	0	RW	<b>Enable</b>  Set this bit to enable the AVDD VMON. Reset with SYSEXTEDRESETn.

## 9.5.26 EMU\_VMONALTAVDDCTRL - Alternate VMON AVDD Channel Control

Offset	Bit Position																																
0x094	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																	0x0																
Access																	RW									RW	0	0	2	1	0	0	
Name																	THRESCOARSE									FALLWU	RW	0	2	1	0	0	
																	THRESFINE									RISEWU	RW	0	2	1	0	0	
																	EN																

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:12	THRESCOARSE	0x0	RW	<b>Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
11:8	THRESFINE	0x0	RW	<b>Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	FALLWU	0	RW	<b>Fall Wakeup</b>  When set, a wakeup from EM4H will take place upon a falling edge. Reset with SYSEXTEDRESETn.
2	RISEWU	0	RW	<b>Rise Wakeup</b>  When set, a wakeup from EM4H will take place upon a rising edge. Reset with SYSEXTEDRESETn.
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EN	0	RW	<b>Enable</b>  Set this bit to enable the ALTAVDD VMON. Reset with SYSEXTEDRESETn.

## 9.5.27 EMU\_VMONDVDDCTRL - VMON DVDD Channel Control

Offset	Bit Position																																	
0x098	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0	
Reset																	0x0																	
Access																	RW									RW	0	0	2	1	0	0		
Name																	THRESCOARSE									FALLWU	RW	0	0	RISEWU	EN	RW	0	0

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:12	THRESCOARSE	0x0	RW	<b>Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTENDEDRESETn.
11:8	THRESFINE	0x0	RW	<b>Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTENDEDRESETn.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	FALLWU	0	RW	<b>Fall Wakeup</b>  When set, a wakeup from EM4H will take place upon a falling edge. Reset with SYSEXTENDEDRESETn.
2	RISEWU	0	RW	<b>Rise Wakeup</b>  When set, a wakeup from EM4H will take place upon a rising edge. Reset with SYSEXTENDEDRESETn.
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EN	0	RW	<b>Enable</b>  Set this bit to enable the DVDD VMON. Reset with SYSEXTENDEDRESETn.

## 9.5.28 EMU\_VMONIO0CTRL - VMON IOVDD0 Channel Control

Offset	Bit Position																																						
0x09C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0						
Reset																	0x0									0	0	0	0	0	0								
Access																	RW									RW	RW	RW	RW	RW	RW								
Name																	THRESCOARSE									THRESFINE									RETDIS	FALLWU	RISEWU	EN	EN

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:12	THRESCOARSE	0x0	RW	<b>Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
11:8	THRESFINE	0x0	RW	<b>Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	RETDIS	0	RW	<b>EM4 IO0 Retention Disable</b>  When set, the IO0 Retention will be disabled when this IO0 voltage drops below the threshold set. Reset with SYSEXTEDRESETn.
3	FALLWU	0	RW	<b>Fall Wakeup</b>  When set, a wakeup from EM4H will take place upon a falling edge. Reset with SYSEXTEDRESETn.
2	RISEWU	0	RW	<b>Rise Wakeup</b>  When set, a wakeup from EM4H will take place upon a rising edge. Reset with SYSEXTEDRESETn.
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EN	0	RW	<b>Enable</b>  Set this bit to enable the IO0 VMON. Reset with SYSEXTEDRESETn.

## 9.5.29 EMU\_VMONBUVDDCTRL - VMON BUVDD Channel Control

Offset	Bit Position																																
0x0A4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																	0x0																
Access																	RW									RW	0	0					
Name																	THRESCOARSE									FALLWU	RW	0					
																	THRESFINE									RISEWU	RW	0					
																	EN										RW	0					

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15:12	THRESCOARSE	0x0	RW	<b>Threshold Coarse Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
11:8	THRESFINE	0x0	RW	<b>Threshold Fine Adjust</b>  Check VMON section for programming the threshold value. Reset with SYSEXTEDRESETn.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	FALLWU	0	RW	<b>Fall Wakeup</b>  When set, a wakeup from EM4H will take place upon a falling edge. Reset with SYSEXTEDRESETn.
2	RISEWU	0	RW	<b>Rise Wakeup</b>  When set, a wakeup from EM4H will take place upon a rising edge. Reset with SYSEXTEDRESETn.
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	EN	0	RW	<b>Enable</b>  Set this bit to enable the BUVDD VMON.

## 9.5.30 EMU\_BUCTRL - Backup Power Configuration Register

Offset	Bit Position																																	
0x0BC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset	RW	0																																
Access	RW																RW	0x0																
Name	DISMAXCOMP																																	
	BUINACTPWRCON																BUACTPWRCON	0x0																
	PWRRES																VOUTRES	0x0																
	BUVINPROBEEN																STATEN	0x0																
	EN																																	

Bit	Name	Reset	Access	Description
31	DISMAXCOMP	0	RW	<b>Disable MAIN-BU Comparator</b>
				Should be set to 1 if no backup battery is connected.
30:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

21:20	BUINACTPWRCON	0x0	RW	<b>Power Connection Configuration When Not in Backup Mode</b>
<hr/>				
Value		Mode	Description	
0		NONE	No connection.	
1		MAINBU	Main power and backup power are connected through a diode, allowing current to flow from main power source to backup power source, but not the other way.	
2		BUMAIN	Main power and backup power are connected through a diode, allowing current to flow from backup power source to main power source, but not the other way.	
3		NODIODE	Main power and backup power are connected without diode.	

19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
-------	----------	--	--	---

17:16	BUACTPWRCON	0x0	RW	<b>Power Connection Configuration in Backup Mode</b>
<hr/>				
Value		Mode	Description	
0		NONE	No connection.	
1		MAINBU	Main power and backup power are connected through a diode, allowing current to flow from backup power source to main power source, but not the other way.	
2		BUMAIN	Main power and backup power are connected through a diode, allowing current to flow from main power source to backup power source, but not the other way.	
3		NODIODE	Main power and backup power are connected without diode.	

15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
-------	----------	--	--	---

Bit	Name	Reset	Access	Description
13:12	PWRRES	0x0	RW	<b>Power Domain Resistor Select</b>
Select value of series resistor between main power domain and backup power domain.				
	Value	Mode		Description
	0	RES0		Main power and backup power connected with RES0 series resistance.
	1	RES1		Main power and backup power connected with RES1 series resistance.
	2	RES2		Main power and backup power connected with RES2 series resistance.
	3	RES3		Main power and backup power connected with RES3 series resistance.
11:10	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
9:8	VOUTRES	0x0	RW	<b>BU_VOUT Resistor Select</b>
Disconnect or select resistance between backup domain power supply (AVDD in main mode and BU_VIN in backup mode) and BU_VOUT.				
	Value	Mode		Description
	0	DIS		BU_VOUT is not connected
	1	WEAK		Enable weak switch between BU_VOUT and backup domain power supply.
	2	MED		Enable medium switch between BU_VOUT and backup domain power supply.
	3	STRONG		Enable strong switch between BU_VOUT and backup domain power supply.
7:3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
2	BUVINPROBEEN	0	RW	<b>Enable BU_VIN Probing</b>
When enabled, BU_VIN/8 is generated (to be measured using the ADC).				
1	STATEN	0	RW	<b>Enable Backup Mode Status Export</b>
When enabled, BU_STAT will indicate when backup mode is active.				
0	EN	0	RW	<b>Enable Backup Mode</b>
Backup mode will be entered when main power browns out and backup battery is present.				

## 9.5.31 EMU\_DCDCLPEM01CFG - Configuration Bits for Low Power Mode to Be Applied During EM01, This Field is Only Relevant If LP Mode is Used in EM01

Offset	Bit Position																															
0x0EC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15:12	LPCMPHYSSE-LEM01	0x0	RW	<b>LP Mode Hysteresis Selection for EM01</b>
	LP mode hysteresis voltage at the output is $4*(1+LPATT)*LPCMPHYSSEL*3.13mV$ . Customers should use the emlib functions for configuring this field.			
11:10	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
9:8	LPCMPBIASEM01	0x3	RW	<b>LP Mode Comparator Bias Selection for EM01</b>
	Reserved for internal use. Do not change.			
	Value	Mode	Description	
	0	BIAS0	Maximum load current less than 75uA.	
	1	BIAS1	Maximum load current less than 500uA.	
	2	BIAS2	Maximum load current less than 2.5mA.	
	3	BIAS3	Maximum load current less than 10mA.	
7:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

### 9.5.32 EMU\_EM23PERNORETAINCMD - Clears Corresponding Bits in EM23PERNORETAINSTATUS Unlocking Access to Peripheral

Offset	Bit Position															
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18		
Reset																
Access																
Name									LCDUNLOCK	W1	0	17	16	15	14	13
									LEUART0UNLOCK	W1	0	15	14	13	12	11
									CSENUNLOCK	W1	0	13	12	11	10	9
									LESENSE0UNLOCK	W1	0					
									WDOG0UNLOCK	W1	0					
									LETIMER0UNLOCK	W1	0					
									ADC0UNLOCK	W1	0					
									DAC0UNLOCK	W1	0					
									I2C1UNLOCK	W1	0					
									I2C0UNLOCK	W1	0					
									PCNT0UNLOCK	W1	0					
									ACMP1UNLOCK	W1	0					
									ACMP0UNLOCK	W1	0					

Bit	Name	Reset	Access	Description
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	LCDUNLOCK	0	W1	<b>Clears Status Bit of LCD and Unlocks Access to It</b> clears status bit of LCD and unlocks access to it
16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15	LEUART0UNLOCK	0	W1	<b>Clears Status Bit of LEUART0 and Unlocks Access to It</b> clears status bit of LEUART0 and unlocks access to it
14	CSENUNLOCK	0	W1	<b>Clears Status Bit of CSEN and Unlocks Access to It</b> clears status bit of CSEN and unlocks access to it
13	LESENSE0UNLOCK	0	W1	<b>Clears Status Bit of LESENSE0 and Unlocks Access to It</b> clears status bit of LESENSE0 and unlocks access to it
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	WDOG0UNLOCK	0	W1	<b>Clears Status Bit of WDOG0 and Unlocks Access to It</b> clears status bit of WDOG0 and unlocks access to it
10	LETIMER0UNLOCK	0	W1	<b>Clears Status Bit of LETIMER0 and Unlocks Access to It</b> clears status bit of LETIMER0 and unlocks access to it
9	ADC0UNLOCK	0	W1	<b>Clears Status Bit of ADC0 and Unlocks Access to It</b> clears status bit of ADC0 and unlocks access to it
8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	DAC0UNLOCK	0	W1	<b>Clears Status Bit of DAC0 and Unlocks Access to It</b> clears status bit of DAC0 and unlocks access to it
6	I2C1UNLOCK	0	W1	<b>Clears Status Bit of I2C1 and Unlocks Access to It</b> clears status bit of I2C1 and unlocks access to it
5	I2C0UNLOCK	0	W1	<b>Clears Status Bit of I2C0 and Unlocks Access to It</b> clears status bit of I2C0 and unlocks access to it

Bit	Name	Reset	Access	Description
4:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	PCNT0UNLOCK	0	W1	<b>Clears Status Bit of PCNT0 and Unlocks Access to It</b> clears status bit of PCNT0 and unlocks access to it
1	ACMP1UNLOCK	0	W1	<b>Clears Status Bit of ACMP1 and Unlocks Access to It</b> clears status bit of ACMP1 and unlocks access to it
0	ACMP0UNLOCK	0	W1	<b>Clears Status Bit of ACMP0 and Unlocks Access to It</b> clears status bit of ACMP0 and unlocks access to it

**9.5.33 EMU\_EM23PERNORETAINSTATUS - Status Indicating If Peripherals Were Powered Down in EM23, Subsequently Locking Access to It**

Offset	Bit Position																																						
0x104	31	30	29	28	27	26	25	24	23	22	21	20	19	18																									
Reset																																							
Access																																							
Name	LCDLOCKED	R	0	17		16		15		14		13		12		11		10		9		8		7		6		5		4		3		2		1		0	
LEUART0LOCKED	R	0	15		14		13		12		11		10		9		8		7		6		5		4		3		2		1		0						
CSENLOCKED	R	0	14		13		12		11		10		9		8		7		6		5		4		3		2		1		0								
LESENSE0LOCKED	R	0	13		12		11		10		9		8		7		6		5		4		3		2		1		0										
WDOG0LOCKED	R	0	11		10		9		8		7		6		5		4		3		2		1		0														
LETIMER0LOCKED	R	0	10		9		8		7		6		5		4		3		2		1		0																
ADC0LOCKED	R	0	9		8		7		6		5		4		3		2		1		0																		
DAC0LOCKED	R	0	7		6		5		4		3		2		1		0																						
I2C1LOCKED	R	0	6		5		4		3		2		1		0																								
I2C0LOCKED	R	0	5		4		3		2		1		0																										
PCNT0LOCKED	R	0	2		1		0		1		0		0																										
ACMP1LOCKED	R	0	1		0		0		0		0		0																										
ACMP0LOCKED	R	0	0		0		0		0		0		0																										

Bit	Name	Reset	Access	Description
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	LCDLOCKED	0	R	<b>Indicates If LCD Powered Down During EM23</b>  Indicates if LCD powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15	LEUART0LOCKED	0	R	<b>Indicates If LEUART0 Powered Down During EM23</b>  Indicates if LEUART0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
14	CSENLOCKED	0	R	<b>Indicates If CSEN Powered Down During EM23</b>  Indicates if CSEN powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
13	LESENSE0LOCKED	0	R	<b>Indicates If LESENSE0 Powered Down During EM23</b>  Indicates if LESENSE0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	WDOG0LOCKED	0	R	<b>Indicates If WDOG0 Powered Down During EM23</b>  Indicates if WDOG0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
10	LETIMER0LOCKED	0	R	<b>Indicates If LETIMER0 Powered Down During EM23</b>  Indicates if LETIMER0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
9	ADC0LOCKED	0	R	<b>Indicates If ADC0 Powered Down During EM23</b>  Indicates if ADC0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>



Bit	Name	Reset	Access	Description
7	DAC0LOCKED	0	R	<b>Indicates If DAC0 Powered Down During EM23</b>  Indicates if DAC0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
6	I2C1LOCKED	0	R	<b>Indicates If I2C1 Powered Down During EM23</b>  Indicates if I2C1 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
5	I2C0LOCKED	0	R	<b>Indicates If I2C0 Powered Down During EM23</b>  Indicates if I2C0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
4:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	PCNT0LOCKED	0	R	<b>Indicates If PCNT0 Powered Down During EM23</b>  Indicates if PCNT0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
1	ACMP1LOCKED	0	R	<b>Indicates If ACMP1 Powered Down During EM23</b>  Indicates if ACMP1 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD
0	ACMP0LOCKED	0	R	<b>Indicates If ACMP0 Powered Down During EM23</b>  Indicates if ACMP0 powered down during EM23. Access to this peripheral locked until this bit cleared using EM23PERNORETAINCMD

## 9.5.34 EMU\_EM23PERNORETAINCTRL - When Set Corresponding Peripherals May Get Powered Down in EM23

Offset	Bit Position																															
0x108	31	30	29	28	27	26	25	24	23	22	21	20	19	18																		
Reset																																
Access																																
Name	LCDDIS	RW	0	17	16	15	LEUART0DIS	RW	0	14	CSEN DIS	RW	0	13	WDOG0DIS	RW	0	11														
31:18	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>															PCNT0DIS	RW	0													
17	LCDDIS	0	RW	<b>Allow Power Down of LCD During EM23</b>													ACMP1DIS	RW	0													
	Allow power down of LCD during EM23																ACMP0DIS	RW	0													
16	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>															VDAC0DIS	RW	0													
15	LEUART0DIS	0	RW	<b>Allow Power Down of LEUART0 During EM23</b>													I2C1DIS	RW	0													
	Allow power down of LEUART0 during EM23																I2C0DIS	RW	0													
14	CSEN DIS	0	RW	<b>Allow Power Down of CSEN During EM23</b>													PCNT0DIS	RW	0													
	Allow power down of CSEN during EM23																ACMP1DIS	RW	0													
13	LESENSE0DIS	0	RW	<b>Allow Power Down of LESENSE0 During EM23</b>													ACMP0DIS	RW	0													
	Allow power down of LESENSE0 during EM23																VDAC0DIS	RW	0													
12	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>															WDOG0DIS	RW	0													
11	WDOG0DIS	0	RW	<b>Allow Power Down of WDOG0 During EM23</b>													LETIMER0DIS	RW	0													
	Allow power down of WDOG0 during EM23																ADC0DIS	RW	0													
10	LETIMER0DIS	0	RW	<b>Allow Power Down of LETIMER0 During EM23</b>													VDAC0DIS	RW	0													
	Allow power down of LETIMER0 during EM23																I2C1DIS	RW	0													
9	ADC0DIS	0	RW	<b>Allow Power Down of ADC0 During EM23</b>													I2C0DIS	RW	0													
	Allow power down of ADC0 during EM23																PCNT0DIS	RW	0													
8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>															ACMP1DIS	RW	0													
7	VDAC0DIS	0	RW	<b>Allow Power Down of DAC0 During EM23</b>													ACMP0DIS	RW	0													
	Allow power down of DAC0 during EM23																VDAC0DIS	RW	0													
6	I2C1DIS	0	RW	<b>Allow Power Down of I2C1 During EM23</b>													WDOG0DIS	RW	0													
	Allow power down of I2C1 during EM23																LETIMER0DIS	RW	0													
5	I2C0DIS	0	RW	<b>Allow Power Down of I2C0 During EM23</b>													ADC0DIS	RW	0													
4:3	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>															VDAC0DIS	RW	0													

Bit	Name	Reset	Access	Description
2	PCNT0DIS	0	RW	<b>Allow Power Down of PCNT0 During EM23</b> Allow power down of PCNT0 during EM23
1	ACMP1DIS	0	RW	<b>Allow Power Down of ACMP1 During EM23</b> Allow power down of ACMP1 during EM23
0	ACMP0DIS	0	RW	<b>Allow Power Down of ACMP0 During EM23</b> Allow power down of ACMP0 during EM23

## 10. CMU - Clock Management Unit



### Quick Facts

#### What?

The CMU controls oscillators and clocks. EFM32 Tiny Gecko 11 supports 6 different oscillators with minimized power consumption and short start-up time. The CMU has HW support for calibration of RC oscillators.

#### Why?

Oscillators and clocks contribute significantly to the power consumption of an MCU. Low power oscillators combined with a flexible clock control scheme make it possible to minimize the energy consumption in any given application.

#### How?

The CMU can configure different clock sources, enable/disable clocks to peripherals on an individual basis and set the prescaler for the different clocks. The short oscillator start-up times makes duty-cycling between active mode and the different low energy modes (EM2 DeepSleep, EM3 Stop, and EM4 Hibernate/Shutoff) very efficient. The calibration feature ensures high accuracy RC oscillators. Several interrupts are available to avoid CPU polling of flags.

### 10.1 Introduction

The Clock Management Unit (CMU) is responsible for controlling the oscillators and clocks in the EFM32 Tiny Gecko 11. The CMU provides the capability to turn on and off the clock on an individual basis to all peripheral modules in addition to enable/disable and configure the available oscillators. The high degree of flexibility enables software to minimize energy consumption in any specific application by not wasting power on peripherals and oscillators that do not need to be active.

### 10.2 Features


- Multiple clock sources available:
  - 4 MHz - 48 MHz High Frequency Crystal Oscillator (HFXO)
  - 1 MHz - 48 MHz High Frequency RC Oscillator (HFRCO)
  - 1 MHz - 48 MHz Auxiliary High Frequency RC Oscillator (AUXHFRCO)
  - 32768 Hz Low Frequency Crystal Oscillator (LFXO)
  - 32768 Hz Low Frequency RC Oscillator (LFRCO)
  - 1000 Hz Ultra Low Frequency RC Oscillator (ULFRCO)
- All oscillator sources are low power.
- Fast start-up times.
- Spectrum-Spreading Digital Phase-Locked Loop.
- Separate prescalers for High Frequency Core Clocks (HFCORECLK), Bus Clocks (HFBUSCLK), and Peripheral Clocks (HFFPERCLK, HFPERBCLK, HFFPERCCLK).
- Individual clock prescaler selection for each Low Energy Peripheral.
- Clock gating on an individual basis to core modules and all peripherals.
- Selectable clock output to external pins and/or PRS.
- Wakeup interrupt for LFRCO or LFXO ready allows entry into EM2 DeepSleep while waiting for low-frequency oscillator startup. This avoids the need for software polling and saves power during oscillator startup.
- Auxiliary 1 MHz - 48 MHz RC oscillator (AUXHFRCO), which is asynchronous to the HFSRCCCLK system clock, can be selected for ADC operation, LESENSE timing and debug trace.

### 10.3 Functional Description

An overview of the high frequency portion of the CMU is shown in [Figure 10.1 CMU Overview - High Frequency Portion on page 297](#). An overview of the low frequency portion is shown in [Figure 10.2 CMU Overview - Low Frequency Portion on page 298](#). These figures show the CMU for the largest device in the EFM32 family. Refer to the Configuration Summary in the device data sheet to see which core, and peripheral modules, and therefore clock connections, are present in a specific device.

#### Availability of oscillators and clocks in Energy Modes:


- Available in EM0/EM1
  - Available in EM0/EM1/EM2
  - Available in EM0/EM1/EM2/EM3
  - Available in EM0/EM1/EM2/EM3/EM4H
  - Available in EM0/EM1/EM2/EM4H/EM4S
  - Available in EM0/EM1/EM2/EM3/EM4H/EM4S



**Figure 10.1. CMU Overview - High Frequency Portion**

Availability of oscillators and clocks in Energy Modes:

- Available in EM0/EM1
- Available in EM0/EM1/EM2
- Available in EM0/EM1/EM2/EM3
- Available in EM0/EM1/EM2/EM3/EM4H
- Available in EM0/EM1/EM2/EM4H/EM4S
- Available in EM0/EM1/EM2/EM3/EM4H/EM4S



**Figure 10.2. CMU Overview - Low Frequency Portion**

### 10.3.1 System Clocks

Available system clock sources are detailed in the following sections.

### 10.3.1.1 HFCLK - High Frequency Clock

HFSRCCCLK is the selected High Frequency Source Clock. HFCLK is an optionally prescaled version of HFSRCCCLK. The HFSRCCCLK, and therefore HFCLK, can be driven by a high-frequency oscillator, such as HFRCO, HFRCODIV2 (see DPLL [10.3.12.1 Enabling and Disabling](#)) or HFXO, or one of the low-frequency oscillators (LFRCO or LFXO). Additionally, HFSRCCCLK can also be driven from a pin (CLKIN0) described in [10.3.6 Clock Input From a Pin](#). By default the HFRCO is selected. In most applications, one of the high frequency oscillators will be the preferred choice. To change the selected clock source, write to the HF bitfield in CMU\_HFCLKSEL. The high frequency clock source can also be changed automatically by hardware as explained in [10.3.2.4.1 Automatic HFXO Start](#). The currently selected source for HFSRCCCLK and HFCLK can be read from CMU\_HFCLKSTATUS. The HFSRCCCLK is running in EM0 Active and EM1 Sleep and is automatically stopped in EM2 DeepSleep. During Voltage Scaling (see [9.3.9 Voltage Scaling](#)), if a fixed frequency oscillator source (i.e. HFXO or CLKIN0) exceeds the maximum system frequency supported, it must be disabled or not selected. Likewise, an adjustable oscillator source (i.e. HFRCO or AUXHFRCO) must be configured to not exceed the maximum system frequency supported before voltage scaling is applied.

**Note:** If a low frequency clock (i.e. LFRCO or LFXO) is selected as source clock for HFSRCCCLK via the HF bitfield in CMU\_HFCLKSEL, then no register reads should be performed from Low Energy Peripherals for registers which can change value every clock cycle (e.g., a counter register). In addition to the peripherals on LFACLK, LFBCLK and LFECLK, this restriction applies in general to any low frequency peripheral, which is not directly or indirectly clocked from HFSRCCCLK (e.g., WDOGn).

HFCLK can optionally be prescaled by setting PRESC in CMU\_HFPRESC to a non-zero value. This prescales HFCLK to all high frequency components and is typically used to save energy in applications where the system is not required to run at the highest frequency. The prescaler setting can be changed dynamically and the new setting takes effect immediately. HFCLK is used by the CMU and drives the prescalers that generate HFCORECLK, HFBUSCLK and HFFPERCLK, HFFPERBCLK, HFFPERCCLK allowing for flexible clock prescaling. HFCLK is used for Bus and Memory System modules as for example the Bus Matrix, MSC and DMEM. HFCLK is also used to drive the bus interface to the Low Energy Peripherals as described further in [10.3.1.6 LFACLK - Low Frequency a Clock](#), [10.3.1.7 LFBCLK - Low Frequency B Clock](#) and [10.3.1.8 LFECLK - Low Frequency E Clock](#). Some of the modules that are driven by HFCLK can be clock gated completely when not in use. This is done by clearing the clock enable bit for the specific module in CMU\_HFBUSCLKEN0. [Table 10.1 Clock Domain \(HFCLK, HFBUSCLK\) Per Peripheral on page 300](#) shows which peripherals are in the HFCLK domain.

### 10.3.1.2 HFCORECLK - High Frequency Core Clock

HFCORECLK is a prescaled version of HFCLK. This clock drives the Core Modules, which consists of the CPU and modules that are tightly coupled to the CPU (e.g., the cache). The prescale factor for prescaling HFCLK into HFCORECLK is set using the CMU\_HFCOREPRESC register. The setting can be changed dynamically and the new setting takes effect immediately.

**Note:** If HFFPERCLK, HFFPERBCLK, HFFPERCCLK runs faster than HFCORECLK, the number of clock cycles for each bus-access to peripheral modules will increase with the ratio between the clocks. Refer to [4.2.4 Bus Matrix](#) for more details.

### 10.3.1.3 HFBUSCLK - High Frequency Bus Clock

HFBUSCLK is a prescaled version of HFCLK. HFBUSCLK is used to drive modules such as GPIO and GPCRC. The prescale factor for prescaling HFCLK into HFBUSCLK is set using the CMU\_HFBUSPRES register. The setting can be changed dynamically and the new setting takes effect immediately. Some of the modules that are driven by HFBUSCLK can be clock gated completely when not in use. This is done by clearing the clock enable bit for the specific module in CMU\_HFBUSCLKENO.

[Table 10.1 Clock Domain \(HFCLK, HFBUSCLK\) Per Peripheral on page 300](#) shows which peripheral is in what clock domain (HFCLK or HFBUSCLK).

**Table 10.1. Clock Domain (HFCLK, HFBUSCLK) Per Peripheral**

Peripheral	Bus Clock
LE	HFCLK
PRS	HFCLK
LDMA	HFCLK
MSC	HFCLK
SMU	HFCLK
CRYPTO0	HFBUSCLK
GPIO	HFBUSCLK
GPCRC	HFBUSCLK

**10.3.1.4 HFPERCLK, HFPERBCLK, HFPERCCLK - High Frequency Peripheral Clocks**

Like HFCORECLK, also HFPERCLK, HFPERBCLK, and HFPERCCLK are prescaled versions of HFCLK. These clocks drive the High-Frequency Peripherals. All the peripherals that are driven by these clocks can be clock gated individually when not in use. This is done by clearing the clock enable bit for the specific peripheral in CMU\_HFPERCLKEN0 or CMU\_HFPERCLKEN1. All high frequency peripheral clocks can be universally and simultaneously gated by clearing the HFPERCLKEN bit in the CMU\_CTRL register. The prescale factors for prescaling HFCLK into HFPERCLK, HFPERBCLK, and HFPERCCLK are set using the CMU\_HFPERPRES, CMU\_HFPERPRESB, and CMU\_HFPERPRESCC registers respectively. The setting can be changed dynamically and the new setting takes effect immediately.

[Table 10.2 Peripheral Clock Domains \(HFPERCLK, HFPERBCLK, HFPERCCLK\) Per Peripheral on page 301](#) shows which peripheral is in what peripheral clock domain.

**Table 10.2. Peripheral Clock Domains (HFPERCLK, HFPERBCLK, HFPERCCLK) Per Peripheral**

Peripheral	Peripheral Clock
TIMER1	HFPERCLK
WTIMER0	HFPERCLK
WTIMER1	HFPERCLK
USART0	HFPERCLK
USART1	HFPERCLK
USART3	HFPERCLK
UART0	HFPERCLK
CAN0	HFPERCLK
TRNG0	HFPERCLK
TIMER0	HFPERBCLK
USART2	HFPERBCLK
ACMP0	HFPERCCLK
ACMP1	HFPERCCLK
I2C0	HFPERCCLK
I2C1	HFPERCCLK
ADC0	HFPERCCLK
CRYOTIMER	HFPERCCLK
VDAC0	HFPERCCLK
CSEN	HFPERCCLK

**Note:** If HFPERCLK, HFPERBCLK or HFPERCCLK runs faster than HFCORECLK, the number of clock cycles for each bus-access to peripheral modules will increase with the ratio between the clocks. E.g. if a bus-access normally takes three cycles, it will take 9 cycles of HFCORECLK if HFPERCLK runs three times as fast as HFCORECLK.

**10.3.1.5 ADCnCLK - ADC Core Clock**

ADCnCLK is a selectable core clock for ADCn. There are three selectable sources for ADCnCLK: HFSRCCLK, HFXO and AUXHFR-CO. In addition, the ADCnCLK can be disabled, which is the default setting. The selection is configured using the ADCnCLKSEL field in CMU\_ADCCTRL. The ADCnCLKINV bit in CMU\_ADCCTRL can be used to invert ADCnCLK. The ADCnCLKDIV bitfield in CMU\_ADCCTRL can be used to prescale ADCnCLK. The bus interface of ADCn is clocked with HFBUSCLK.

#### 10.3.1.6 LFACLK - Low Frequency a Clock

LFACLK is the selected clock for the Low Energy A Peripherals. There are several selectable sources for LFACLK: LFRCO, LFXO and ULFRCO. In addition, the LFACLK can be disabled, which is the default setting. The selection is configured using the LFA field in CMU\_LFACLKSEL.

The bus interface to the Low Energy A Peripherals is clocked by HFCLK<sub>LE</sub> and this clock therefore needs to be enabled when programming a Low Energy (LE) peripheral.

Each Low Energy Peripheral that is clocked by LFACLK has its own prescaler setting and enable bit. The prescaler settings are configured using CMU\_LFAPRESC0 and the clock enable bits can be found in CMU\_LFACLKEN0.

When operating in oversampling mode, the pulse counters are clocked by LFACLK. This is configured for each pulse counter (n) individually by setting PCNTnCLKSEL in CMU\_PCNTCTRL.

#### 10.3.1.7 LFBCLK - Low Frequency B Clock

LFBCLK is the selected clock for the Low Energy B Peripherals. There are several selectable sources for LFBCLK: LFRCO, LFXO, HFCLKLE and ULFRCO. In addition, the LFBCLK can be disabled, which is the default setting. The selection is configured using the LFB field in CMU\_LFBCLKSEL. The HFCLKLE setting allows the Low Energy B Peripherals to be used as high-frequency peripherals.

The bus interface to the Low Energy B Peripherals is clocked by HFCLK<sub>LE</sub> and this clock therefore needs to be enabled when programming a LE peripheral.

**Note:** If HFCLKLE is selected as LFBCLK, the clock will stop in EM2 DeepSleep and EM3 Stop.

Each Low Energy Peripheral that is clocked by LFBCLK has its own prescaler setting and enable bit. The prescaler settings are configured using CMU\_LFBPRESC0 and the clock enable bits can be found in CMU\_LFBCLKEN0.

#### 10.3.1.8 LFECLK - Low Frequency E Clock

LFECLK is the selected clock for the Low Energy E Peripherals. There are several selectable sources for LFECLK: LFRCO, LFXO and ULFRCO. In addition, the LFECLK can be disabled, which is the default setting. The selection is configured using the LFE field in CMU\_LFECLKSEL.

The bus interface to the Low Energy E Peripherals is clocked by HFCLK<sub>LE</sub> and this clock therefore needs to be enabled when programming a LE peripheral.

**Note:** LFECLK is in a different power domain than LFACLK and LFBCLK, which makes it available all the way down to EM4 Hibernate.

Each Low Energy Peripheral that is clocked by LFECLK has its own prescaler setting and enable bit. The prescaler settings are configured using CMU\_LFEPRESC0 and the clock enable bits can be found in CMU\_LFECLKEN0.

#### 10.3.1.9 PCNTnCLK - Pulse Counter N Clock

Each available pulse counter is driven by its own clock, PCNTnCLK where n is the pulse counter instance number. Each pulse counter can be configured to use an external pin (PCNTn\_S0) or LFACLK as PCNTnCLK.

#### 10.3.1.10 WDOGnCLK - Watchdog Timer Clock

The Watchdog Timer (WDOGn) can be configured to use one of many different clock sources. Refer to CLKSEL field in WDOGn\_CTRL for a complete list.

#### 10.3.1.11 CRYOCLK - CRYOTIMER Clock

The CRYOTIMER clock can be configured to use one of many different clock sources. Refer to OSCSEL field in CRYOTIMER\_CTRL for a complete list. The CRYOTIMER can also run in EM4 Hibernate/Shutoff provided that its selected clock is kept enabled as configured in EMU\_EM4CTRL.

### 10.3.1.12 AUXCLK - Auxiliary Clock

AUXCLK is a 1 MHz - 48 MHz clock driven by a separate RC oscillator, the AUXHFRCO. This clock can be used for ADC operation LESENSE operation. When the AUXHFRCO is selected as the ADCn clock via the ADCnCLKSEL bitfield in the CMU\_ADCCTRL register, or if needed by LESENSE, this clock will become active automatically when needed. Even if the AUXHFRCO has not been enabled explicitly by software, the ADC or LESENSE can automatically start and stop it. The AUXHFRCO is explicitly enabled by writing a 1 to AUXHFRCOEN in CMU\_OSCENCMD. This explicit enabling is required when selecting the AUXCLK for SWO operation.

### 10.3.1.13 Debug Trace Clock

The CMU selects the clock used for debug trace via the DBGCLKSEL register. The user can use HFRCODIV2, AUXHFRCO or the HFCLK. The selected debug trace clock will be used to run the Cortex-M0+ trace logic.

**Note:** When using AUXHFRCO as the debug trace clock, it must be stopped before entering EM2 or EM3.

## 10.3.2 Oscillators

Control of the various oscillators available in the device is detailed in the following sections.

### 10.3.2.1 Enabling and Disabling

The different oscillators can typically be enabled and disabled via both hardware and software mechanisms. Enabling via software is done by setting the corresponding enable bit in the CMU\_OSCENCMD register. Disabling via software is done by setting the corresponding disable bit in CMU\_OSCENCMD. Enabling via hardware can be performed by various peripherals and varies per oscillator. Disabling via hardware is typically performed on entry of low energy modes. The enable and disable mechanisms for each of the oscillators are summarized in [Table 10.3 Software Based and Hardware Based Enabling and Disabling of Oscillators on page 304](#) and described in more detail below.

**Table 10.3. Software Based and Hardware Based Enabling and Disabling of Oscillators**

Oscillator	SW Enable	SW Disable	HW Enable	HW Disable
ULFRCO	-	-	Enabled when in EM0/EM1/EM2/EM3/EM4H.	EM4S entry depending on configuration in EMU_EM4CTRL.
LFRCO	Via LFRCOEN in CMU_OSCENCMD.	Via LFRCODIS in CMU_OSCENCMD.	Via WDOGn if it is configured to use LFRCO as its clock source via the CLKSEL bitfield in WDOGn_CTRL while SWOSCBLOCK is set.	EM3 entry. EM4 entry depending on configuration in EMU_EM4CTRL.
LFXO	Via LFXOEN in CMU_OSCENCMD.	Via LFXODIS in CMU_OSCENCMD.	Via WDOGn if it is configured to use LFXO as its clock source via the CLKSEL bitfield in WDOGn_CTRL while SWOSCBLOCK is set.	EM3 entry. EM4 entry depending on configuration in EMU_EM4CTRL.
HFRCO	Via HFRCOEN in CMU_OSCENCMD.	Via HFRCODIS in CMU_OSCENCMD.	Reset exit. EM2/EM3 exit. Automatic control by LEUART RX/TX DMA wake-up as configured in LEUARTn_CTRL.	EM2/EM3/EM4 entry. Automatic control by LEUART RX/TX DMA wake-up as configured in LEUARTn_CTRL. Automatic start and selection of HFXO causes HFRCO disable.
AUXHFRCO	Via AUXHFRCOEN in CMU_OSCENCMD.	Via AUXHFRCODIS in CMU_OSCENCMD.	Automatic control by ADC and LESENSE.	EM2/EM3/EM4 entry. Automatic control by ADC and LESENSE even in EM2/EM3.
HFXO	Via HFXOEN in CMU_OSCENCMD.	Via HFXODIS in CMU_OSCENCMD.	Automatic start by EM0/EM1 entry as configured in CMU_HFXOCTRL.	EM2/EM3/EM4 entry.

### 10.3.2.1.1 LFRCO and LFXO

The LFXO and LFRCO can be enabled and disabled by software via the CMU\_OSCENCMD register. WDOGn can be configured to force the LFXO or LFRCO to become (and remain) enabled when such an oscillator is selected as its clock source via the CLKSEL bitfield in the WDOGn\_CTRL register while SWOSCBLOCK is set. In that case LFXODIS and LFRCODIS commands are blocked. They are automatically disabled when entering EM3. Upon EM4 entry they are default turned off, but they can optionally be retained depending on the EMU\_EM4CTRL configuration. Retaining of the LFXO or LFRCO in EM4 is needed if such an oscillator is required by a specific peripheral in EM4. Retaining can also be used to guarantee quick oscillator availability after EM4 exit.

The oscillators should never be retained in case they are off before entering EM4. The following are the valid ways of using the LFXO/LFRCO retention mechanism:

- Turn on LFXO/LFRCO always (even in EM4):
  1. POR
  2. Enable LFXO/LFRCO
  3. Enable RETAINLFXO/RETAINLFRCO
  4. EM4 entry
  5. LFXO/LFRCO are retained and remain running in EM4
  6. EM4 wakeup
  7. Enable LFXO/LFRCO
  8. Set EM4UNLATCH in EMU\_CMD
- Turn off LFXO/LFRCO in EM4:
  1. POR
  2. Disable RETAINLFXO/RETAINLFRCO (default)
  3. Enable LFXO/LFRCO
  4. EM4 entry
  5. LFXO/LFRCO are off in EM4
  6. EM4 wakeup
  7. Enable LFXO/LFRCO
  8. Set EM4UNLATCH in EMU\_CMD
- Turn on LFXO/LFRCO after EM4 exit:
  1. POR
  2. Disable RETAINLFXO/RETAINLFRCO (default)
  3. Enable LFXO/LFRCO
  4. EM4 entry
  5. LFXO/LFRCO are off in EM4
  6. EM4 wakeup
  7. Enable LFXO/LFRCO
  8. Set EM4UNLATCH in EMU\_CMD
  9. Enable RETAINLFXO/RETAINLFRCO

In summary RETAINLFXO/RETAINLFRCO should either be changed once after POR and kept static, or they can be changed on-the-fly only after asserting EM4UNLATCH.

**Note:**

- In order to support usage of LFRCO and LFXO in EM4, their settings are automatically latched upon EM4 entry. These settings remain latched upon wake-up from EM4 to EM0 although the related registers (CMU\_LFRCOCTRL, CMU\_LFXOCTRL, CMU\_LFECLKSEL, CMU\_LFECLKEN0 and CMU\_LEEPRES0) will have been reset. The registers can be rewritten by software, but they will only affect the LFRCO and LFXO after unlatching their settings by setting EM4UNLATCH in the EMU\_CMD register.
- Turning off the LFRCO and LFXO upon EM4 Hibernate/Shutoff entry is most easily done by using the RETAINLFRCO and RETAINLFXO bitfields from the EMU\_EM4CTRL register, which are default such that the LFRCO and LFXO are turned off automatically upon EM4 Hibernate/Shutoff entry. Alternatively the LFRCO and LFXO can be disabled via the CMU\_OSCENCMD register, in which case software should wait for the oscillators to be properly disabled before executing the EM4 Hibernate/Shutoff entry routine.

After enabling the LFRCO (or LFXO), it should not be disabled before it has been signaled to be ready. Similarly, after disabling the LFRCO (or LFXO), it should not be re-enabled before it has been signaled to be non-ready. Before entering EM4, software should check that the LFRCO (or LFXO) is signaled to be ready before allowing or initiating the EM4 entry if that oscillator is required in EM4. Also, to guarantee latching the latest settings, no control write should be ongoing upon EM4 entry as can be checked via the CMU\_SYNCBUSY register. Typical enable and disable sequences are as follows:

```
CMU->OSCENCMD = CMU_OSCENCMD_LFRCOEN;
while ((CMU->STATUS & CMU_STATUS_LFRCORDY) != CMU_STATUS_LFRCORDY);

CMU->OSCENCMD = CMU_OSCENCMD_LFRCODIS;
while ((CMU->STATUS & CMU_STATUS_LFRCORDY) == CMU_STATUS_LFRCORDY);
```

When the LFXO is disabled, the interface to the LFXTAL\_N and LFXTAL\_P pins are set in a high-Z state. The XTAL oscillations will not stop immediately when LFXO is disabled, but typically die out gradually over some 100 ms. If the LFXO is enabled before XTAL oscillations have had time to reach zero amplitude, startup time can be significantly shorter.

**Note:** The LFRCORDY and LFXORDY interrupts can be used to wake up the system from EM2 DeepSleep. In this way busy waiting for the LFRCO or LFXO to become ready can be avoided by going into EM2 after enabling these oscillators and sleeping until the interrupt causes a wakeup.

### 10.3.2.1.2 ULFRCO

The ULFRCO is automatically enabled in EM0, EM1, EM2, EM3, and EM4H and cannot be controlled via CMU\_OSCENCMD. It is automatically disabled upon entering EM4S unless prevented by the configuration in EMU\_EM4CTRL.

### 10.3.2.1.3 HFRCO

The HFRCO can be enabled and disabled by software via the CMU\_OSCENCMD register. The HFRCO is disabled automatically when entering EM2, EM3, or EM4. Further hardware based enabling and disabling can be performed by the LEUART when using automatic RX/TX DMA wakeup as controlled by the RXDMAWU and TXDMAWU bits in the LEUARTn\_CTRL register. An automatic start and selection of the HFXO will lead to an automatic HFRCO disabling. Since HFRCO also serves as the local oscillator for DPLL ([10.3.12 Digital Phase-Locked Loop](#)), it is enabled/disabled when DPLL is enabled/disabled.

The supported HFRCO frequency range is from 1 MHz to 48 MHz. The default HFRCO frequency is 19 MHz

### 10.3.2.1.4 HFXO

The HFXO can be enabled and disabled by software via the CMU\_OSCENCMD register. The HFXO is disabled automatically when entering EM2, EM3, or EM4. Hardware based HFXO enabling can be initiated by various peripherals as configured via theAUTOSTARTEM0EM1, and AUTOSTARTSELEM0EM1 bits in the CMU\_HFXOCTRL register. The interaction between hardware based and software based control of the HFXO is further explained in [10.3.2.4.1 Automatic HFXO Start](#).

The supported HFXO frequency range is from 4 MHz to 48 MHz.

After enabling the HFXO, it should not be disabled before it has been signaled to be enabled. Similarly, after disabling the HFXO it should not be re-enabled before it has been signaled to be non-enabled. Typical enable and disable sequences are as follows:

```
CMU->OSCENCMD = CMU_OSCENCMD_HFXOEN;
while ((CMU->STATUS & CMU_STATUS_HFXOENS) != CMU_STATUS_HFXOENS);

CMU->OSCENCMD = CMU_OSCENCMD_HFXODIS;
while ((CMU->STATUS & CMU_STATUS_HFXOENS) == CMU_STATUS_HFXOENS);
```

### 10.3.2.1.5 AUXHFRCO

The AUXHFRCO can be enabled and disabled by software via the CMU\_OSCENCMD register. The AUXHFRCO is disabled automatically when entering EM2, EM3, or EM4. Hardware based AUXHFRCO enabling and disabling is however performed by the ADC module when AUXCLK is selected for its operation and by the LESENSE module making it available even when being in EM2/EM3.

The supported AUXHFRCO frequency range is from 1 MHz to 48 MHz. The default AUXHFRCO frequency is 19 MHz

After enabling the AUXHFRCO, it should not be disabled before it has been signaled to be enabled. Similarly, after disabling the AUXHFRCO, it should not be re-enabled before it has been signaled to be non-enabled. Typical enable and disable sequences are as follows:

```
CMU->OSCENCMD = CMU_OSCENCMD_AUXHFRCOEN;
while ((CMU->STATUS & CMU_STATUS_AUXHFRCOENS) != CMU_STATUS_AUXHFRCOENS);

CMU->OSCENCMD = CMU_OSCENCMD_AUXHFRCODIS;
while ((CMU->STATUS & CMU_STATUS_AUXHFRCOENS) == CMU_STATUS_AUXHFRCOENS);
```

**Note:** When using AUXHFRCO as the debug trace clock (as selected in CMU\_DBGCLKSEL), it must be stopped before entering EM2 or EM3.

### 10.3.2.2 Oscillator Start-up Time and Time-out


The start-up time differs per oscillator and the usage of an oscillator clock can further be delayed by a time-out. The LFRCO, LFXO and the HFXO have a configurable time-out which is set by software in the (various) TIMEOUT bitfields of the CMU\_LFRCOCTRL, CMU\_LFXOCTRL and CMU\_HFXOTIMEOUTCTRL registers respectively. The time-out delays the assertion of the READY signal for LFRCO, LFXO and HFXO and should allow for enough time for the oscillator to stabilize. The time-out can be optimized for the chosen crystal (for LFXO and HFXO) used in the application. In case LFRCO and/or LFXO has been retained throughout EM4 Hibernate/Shut-off, such retained oscillators can be quickly restarted for use as LFACLK, LFBCLK or LFECLK by using the minimum TIMEOUT settings for them. For the other RC oscillators (HFRCO, AUXHFRCO, and ULFRCO), the start-up time is known and a fixed time-out is used.

There are individual bits in the CMU\_STATUS register for each oscillator indicating the status of the oscillator:

- ENABLED - Indicates that the oscillator is enabled
- READY - Start-up time including time-out is exceeded

These status bits are located in the CMU\_STATUS register.

Additionaly, the HFXO has a second time-out counter which can be used to achieve deterministic start-up time based on timing from the LFXO, ULFRCO, or LFRCO. This second counter runs off LFECLK and can be programmed via the LFTIMEOUT bitfield in the CMU\_HFXOCTRL register. It can be used when waking up from EM2 when either ULFRCO, LFRCO or LFXO is already running and stable. In this case the HFXO ready assertion can be delayed with the number of LFECLK cycles as programmed in LFTIMEOUT. The HFXO ready signal is asserted when both the TIMEOUT counter (configured via the CMU\_HFXOTIMEOUTCTRL register) and the LFTIMEOUT counter (configured via CMU\_HFXOCTRL register) have timed out as shown in [Figure 10.3 CMU Deterministic HFXO startup using LFTIMEOUT on page 308](#). The TIMEOUT should cover the actual crystal startup time. Typically the time base used for the TIMEOUT counter is not as accurate as the time base accuracy that can be achieved for the LFTIMEOUT counter, specifically if that one is based on the LFXO timing. If LFTIMEOUT is triggered before TIMEOUT is triggered, then the LFTIMEOUTERR bitfield in CMU\_IF will be set to 1. Note that use of LFTIMEOUT requires that the peripheral causing the wake-up is on the LFECLK domain.



**Figure 10.3. CMU Deterministic HFXO startup using LFTIMEOUT**

The startup behavior of the HFXO also depends on how and how long the HFXO is disabled.

### 10.3.2.3 Switching Clock Source

The HFRCO oscillator is a low energy oscillator with extremely short start-up time. Therefore, this oscillator is always chosen by hardware as the clock source for HFCLK when the device starts up (e.g., after reset and after waking up from EM2 DeepSleep and EM3 Stop). After reset, the HFRCO frequency is 19 MHz.

Software can switch between the different clock sources at run-time. For example, when the HFRCO is the clock source, software can switch to HFXO by writing the field HF in the CMU\_HFCLKSEL command register. See [Figure 10.4 CMU Switching from HFRCO to HFXO before HFXO is ready on page 309](#) for a description of the sequence of events for this specific operation.

**Note:** Before switching the HFCLKSRC to HFXO via the HF bitfield in CMU\_HFCLKSEL it is important to first enable the HFXO. Switching to a disabled oscillator will effectively stop HFSRCCLK and only a reset can recover the system.

When selecting an oscillator which has been enabled, but which is not ready yet, the HFSRCCLK will stop for the duration of the oscillator start-up time since the oscillator driving it is not ready. This effectively stalls the Core Modules and the High-Frequency Peripherals. It is possible to avoid this by first enabling the target oscillator (e.g., HFXO) and then waiting for that oscillator to become ready before switching the clock source. This way, the system continues to run on the HFRCO until the target oscillator (e.g., HFXO) has timed out and provides a reliable clock. This sequence of events is shown in [Figure 10.5 CMU Switching from HFRCO to HFXO after HFXO is ready on page 310](#).

A separate flag is set when the oscillator is ready. This flag can also be configured to generate an interrupt.





Figure 10.4. CMU Switching from HFRCO to HFXO before HFXO is ready



**Figure 10.5. CMU Switching from HFRCO to HFXO after HFXO is ready**


Switching clock source for LFACLK, LFBCLK, and LFECLK is done by setting the LFA, LFB and LFE bitfields in CMU\_LFACLKSEL, CMU\_LFBCLKSEL and CMU\_LFECLKSEL respectively. To ensure no stalls in the Low Energy Peripherals, the clock source should be ready before switching to it.

**Note:** To save energy, remember to turn off all oscillators not in use.

#### 10.3.2.4 HFXO Configuration

The High Frequency Crystal Oscillator needs to be configured to ensure safe startup for the given crystal. Refer to the device data sheet and application notes for guidelines in selecting correct components and crystals as well as for configuration trade-offs.

The HFXO crystal is connected to the HFXTAL\_N/HFXTAL\_P pins as shown in [Figure 10.6 HFXO Pin Connection on page 311](#)



**Figure 10.6. HFXO Pin Connection**

By default the HFXO is started in crystal mode (XTAL), but it is possible to connect an active external sine wave or square wave clock source to the HFXTAL\_N pin of the HFXO. By configuring the MODE field in CMU\_HFXOCTRL to ACBUFEXTCLK (for external AC coupled sine wave) or DCBUFEXTCLK (for external DC coupled sine wave) or DIGEXTCLK (for external square wave), the HFXO can be bypassed and the source clock can be provided through the HFXTAL\_N pin. When using external clock source, the HFXTAL\_P pin is available to be used as regular GPIO.

Upon enabling the HFXO, a hardware state machine sequentially applies the configurable startup state and steady state control settings from the CMU\_HFXOSTARTUPCTRL and CMU\_HFXOSTEADYSTATECTRL registers. Configuration is required for both the startup state and the steady state of the HFXO. After reaching the steady operation state of the HFXO, further optimization can optionally be performed to optimize the HFXO for current consumption by an automatic Peak Detection Algorithm (PDA). HFXO operation is possible without PDA at the cost of higher current consumption than required. Furthermore, the oscillator amplitude can be kept stable by an automatic Peak Monitoring Algorithm (PMA) implemented in hardware. PMA is performed at every rising edge of ULFRCO, when it is enabled via the PEAKMONEN bitfield of CMU\_HFXOSTEADYSTATECTRL register (enabled by default). PDA and PMA can only be activated in XTAL mode.




Figure 10.7. CMU HFXO control state machine

Refer to the device data sheet to find the configuration values for a given crystal. The startup state configuration needs to be written into the IBTRIMXOCORE and CTUNE bitfields of the CMU\_HFXOSTARTUPCTRL register. The duration of the startup phase is configured in the STARTUPTIMEOUT bitfield of the CMU\_HFXOTIMEOUTCTRL register. Similarly, the device data sheet provides the steady state configuration depending on the crystal's CL, RESR and oscillation frequency. This configuration is programmed into the IBTRIMXOCORE and CTUNE bitfields of the CMU\_HFXOSTEADYSTATECTRL register. The duration of the steady phase is configured in the STEADYTIMEOUT bitfield of the CMU\_HFXOTIMEOUTCTRL register.

All HFXO configuration needs to be performed prior to enabling the HFXO via HFXOEN in CMU\_OSCENCMD unless noted otherwise. The HFXOENS flag in CMU\_STATUS indicates if the HFXO has been successfully enabled. Once the HFXO startup time (STARTUPTIMEOUT plus STEADYTIMEOUT) has exceeded, the HFXO is ready for use as indicated by the HFXORDY flag in CMU\_STATUS. If PDA is enabled, the HFXOPEAKDET RDY flag in the CMU\_STATUS register indicates when this algorithm is ready and it is advised to also wait for this flag before using the HFXO.

The HFXO crystal bias current may be optimized and set to a value which decreases output phase noise without sacrificing PSR. This is done by programming the recommended IBTRIMXOCORE value into the CMU\_HFXOSTEADYSTATECTRL register. The built-in Peak Detector Algorithm (PDA) performs further optimization to accommodate for process variations. Once PDA is ready as indicated by the HFXOPEAKDET RDY flag, the VALID flag in CMU\_HFXOTRIMSTATUS register becomes 1 indicating that PDA found optimal bias current setting and this setting is available in the IBTRIMXOCORE bitfield of the CMU\_HFXOTRIMSTATUS register. This IBTRIMXOCORE setting should be saved and can be applied directly during a future HFXO startup as a low power setting by programming it into the corresponding bitfield in CMU\_HFXOSTEADYSTATECTRL while the HFXO is off. This is done automatically if HFXO is started with PEAKDETMODE register field of CMU\_HFXOCTRL set to ONCECMD and in this case PDA is skipped upon repeated HFXO startup.

Default PDA is started automatically once the HFXO has become ready. Repeated PDA can be triggered by writing HFXOPEAKDET-START to 1 in the CMU\_CMD register. PDA can also be triggered only by the command register by configuring PEAKDETMODE to CMD in the CMU\_HFXOCTRL register before starting the HFXO. The PEAKDETTIMEOUT bitfield in the CMU\_HFXOTIMEOUTCTRL register is used to time the PDA steps and needs to be configured according to the device data sheet for the given crystal. The PEAKDETEN bitfield of the CMU\_HFXOSTEADYSTATECTRL register is only used during manual (i.e. fully software controlled) peak detection and is ignored during automatic or command based triggering of the PDA. Note that the manual PDA mode is not recommended for general usage and therefore it is not further described. PDA and PMA should not be used when using an external wave as clock source.

#### 10.3.2.4.1 Automatic HFXO Start

The enabling of the HFXO and its selection as HFSRCCLK source can be performed automatically by hardware. Automatic control of the HFXO is controlled via the AUTOSTARTSELEM0EM1 and AUTOSTARTEM0EM1 bits in the CMU\_HFXOCTRL register. It further depends on the energy mode of the EFM32.

An automatic HFXO enable is performed only if any of the following conditions are met:

- EFM32 is in EM0/EM1 and AUTOSTARTEM0EM1 or AUTOSTARTSELEM0EM1 are set to 1.

An automatic HFXO select is performed only if any of the following conditions is met:


- EFM32 is in EM0/EM1 and AUTOSTARTSELEM0EM1 is set to 1.

Whenever any of the conditions for automatic HFXO enable is met, software is not allowed to disable the HFXO. An attempt to do so (e.g., by writing 1 to the HFXODIS bit) is ignored and causes the HFXODISERR bit in the CMU\_IF register to be set to 1. Similarly, whenever any of the conditions for automatic HFXO selection is met, software is not allowed to deselect the HFXO as clock source for HFSRCCLK. An attempt to do so (e.g., by selecting another clock source via CMU\_HFCLKSEL) is ignored and causes the HFXODISERR bit in the CMU\_IF register to be set to 1. Note that CMUERR is not implied by HFXODISERR. CMUERR will not get set to 1 for the above scenarios in which HFXODISERR gets set.

Software can only disable or deselect the HFXO after removing all of the HFXO automatic enable or select reasons. The HFXO is only disabled by hardware upon EM2, EM3 or EM4 entry.

In case that AUTOSTARTSELEM0EM1 is set to 1 in EM0/EM1 (irrespective of the other autostart bits), the HFXO select will occur immediately, even if HFXO is not ready yet. Upon wake-up into EM0/EM1 this can therefore lead to a relatively long startup time as the system will not start operating from the HFRCO as it would otherwise do.


Note that the user should take care that the settings in the MSC\_READCTRL and CMU\_CTRL registers, as described in [10.3.3 Configuration for Operating Frequencies](#), are compatible with HFXO frequency before enabling the HFXO automatic startup feature. A basic automatic HFXO start scenario is shown in [Figure 10.8 CMU Automatic Startup and Selection of HFXO on page 314](#).



**Figure 10.8. CMU Automatic Startup and Selection of HFXO**

If an automatic selection of HFXO is performed, which switches the clock source used for HFSRCCLK, then the HFXOAUTOSW bit in CMU\_IF is set to 1. After automatic enable and selection of the HFXO, the HFRCO is automatically disabled in case it is running. The disabling of a running HFRCO is signalled via the HFRCODIS bit in CMU\_IF. This only applies to the HFRCO. If for example the LFXO was used as HFSRCCLK at the time of automatic selection of the HFXO, the LFXO remains unaffected.

The interaction between automatic HFXO startup and selection with startup and selection of HFRCO is shown in [Figure 10.9 CMU HFRCO Startup/Selection While Awaiting Automatic HFXO Startup/Selection on page 315](#).



**Figure 10.9. CMU HFRCO Startup/Selection While Awaiting Automatic HFXO Startup/Selection**

### 10.3.2.5 LFXO Configuration


The Low Frequency Crystal Oscillator (LFXO) is default configured to ensure safe startup for all crystals. In order to optimize startup time and power consumption for a given crystal, it is possible to adjust the startup gain in the oscillator by programming the GAIN field in CMU\_LFXOCTRL. Recommendations for the GAIN setting are as follows:

1. C0 must be < 2 pF
2. For 12.5 pF < CL < 18 pF, GAIN = 3
3. For 8 pF < CL < 12.5 pF, GAIN = 2
4. For 6 pF < CL < 8 pF, GAIN = 1
5. For CL = 6 pF, GAIN = 0

Refer to the device data sheet and application notes for guidelines in selecting correct components and crystals as well as for configuration trade-offs.

The LFXO can be retained on in EM4 Hibernate/Shutoff. In that case its required configuration is latched/retained throughout EM4 even though the CMU\_LFXOCTRL register itself will be reset. Upon EM4 exit, the CMU\_LFXOCTRL register therefore needs to be reconfigured to its original settings and the LFXO needs to be restarted via CMU\_OSCENCMD, before optionally unlatching the retained LFXO configuration by writing 1 to EM4UNLATCH in the EMU\_CMD register. The LFXO startup time is configured via the TIMEOUT bitfield of the CMU\_LFXOCTRL register. If the LFXO has been retained throughout EM4 Hibernate/Shutoff, it can be quickly restarted for use as LFACLK, LFBCLK or LFECLK by using its minimum TIMEOUT setting. While retained, the LFXO can be used down to EM4 Hibernate as source for LFECLK and down to EM4 Shutoff as source for CRYOCLK.

The LFXO crystal is connected to the LFXTAL\_N/LFXTAL\_P pins as shown in [Figure 10.10 LFXO Pin Connection on page 316](#).



**Figure 10.10. LFXO Pin Connection**

By configuring the MODE field in CMU\_LFXOCTRL, the LFXO can be bypassed, and an external clock source can be connected to the LFXTAL\_N pin of the LFXO oscillator. If MODE is set to BUFEXTCLK, an external active sine source can be used as clock source. If MODE is set to DIGEXTCLK, an external active CMOS source can be used as clock source.

The LFXO includes on-chip tunable capacitance, which can replace external load capacitors. The TUNING bitfield of the CMU\_LFXOCTRL register is used to tune the internal load capacitance connected between LFXTAL\_P and ground and LFXTAL\_N and ground symmetrically. The capacitance range and step size information is available in the device data sheets. Use the formula below to calculate the TUNING bitfield:

$$\text{TUNING} = ((\text{desiredTotalLoadCap} * 2 - \text{Min}(C_{\text{LFXO\_T}})) / C_{\text{LFXO\_TS}})$$

**Figure 10.11. CMU LFXO Tuning Capacitance Equation**

These tunable capacitors can also be used to compensate for temperature drift of the XTAL in software. Crystals normally have a temperature dependency which is given by a parabolic function. The crystal has highest frequency at its turnover temperature, normally 25C. The frequency is reduced following a parabola for higher and lower temperatures. The LFXO offers a mechanism to internally add capacitance on the LFXTAL\_N and LFXTAL\_P pins (in parallel to an optional external load capacitance). The variation in frequency as a function of temperature can therefore be compensated by adjusting the load capacitance. When the temperature compensation scheme is used, the maximum internal capacitance should be used to obtain good frequency matching at the turnover temperature. For higher and lower temperatures software then has the maximum range available to adjust the tuning. The external load capacitance

must then of course be reduced accordingly. Note that the ADC0 (27. ADC - Analog to Digital Converter) includes an embedded temperature sensor and that the EMU (9. EMU - Energy Management Unit) offers a temperature management interface, both of which can be used in combination with this LFXO temperature compensation scheme.

The XTAL oscillation amplitude can be controlled via the HIGHAMPL bitfield in CMU\_LFXOCTRL. Setting HIGHAMPL to 1 will result in higher amplitude, which in turn provides safer operation, somewhat improved duty cycle, and lower sensitivity to noise at the cost of increased current consumption.

The AGC bit of the CMU\_LFXOCTRL register is used to turn on or off the Automatic Gain Control module that adjusts the amplitude of the XTAL. When disabled, the LFXO will run at the startup current and the XTAL will oscillate rail to rail, again providing safer operation, improved duty cycle, and lower sensitivity to noise at the cost of increased current consumption.

#### 10.3.2.6 HFRCO and AUXHFRCO Configuration

It is possible to calibrate the HFRCO and AUXHFRCO to achieve higher accuracy (see the device data sheets for details on accuracy). The frequency is adjusted by changing the TUNING and FINETUNING bitfields in CMU\_HFRCOCTRL and CMU\_AUXHFRCOCTRL. Changing to a higher value will result in a lower frequency. Refer to the data sheet for stepsize details.

The HFRCO can be set to one of several different frequency bands from 1 MHz to 48 MHz by setting the FREQRANGE field in CMU\_HFRCOCTRL. Similarly the AUXHFRCO can be set to one of several different frequency bands from 1 MHz to 48 MHz by setting the FREQRANGE field in CMU\_AUXHFRCOCTRL. The HFRCO and AUXHFRCO frequency bands are calibrated during production test, and the production tested calibration values can be read from the Device Information (DI) page. The DI page contains separate tuning values for various frequency bands. During reset, HFRCO and AUXHFRCO tuning values are set to the production calibrated values for the 19 MHz band, which is the default frequency band. When changing to a different HFRCO or AUXHFRCO band, make sure to also update the TUNING value and other bitfields in the CMU\_HFRCOCTRL and CMU\_AUXHFRCOCTRL registers. Typically the entire register is written with a value obtained from the Device Information (DI) page. Refer to [4.6 DI Page Entry Map](#) for information on which frequency band settings are stored in the DI page.

The frequency can be tuned more accurately via the FINETUNING bitfield if fine tuning has been enabled via the FINETUNINGEN bit. Note that there will be a slight increase in the oscillator current consumption when fine tuning is enabled. Note also that changing the value of FINETUNINGEN will result in a frequency shift, regardless of the FINETUNING field value. If the oscillator is to be used at different times with fine tuning enabled and disabled, it should be tuned separately for both settings. The HFRCO and AUXHFRCO contain a local prescaler, which can be used in combination with any FREQRANGE setting. These prescalers allow the output clocks to be divided by 1, 2, or 4 as configured in the CLKDIV bitfield.

When using [10.3.2.8 RC Oscillator Calibration](#) to tune HFRCO and AUXHFRCO to the desired frequency, linear search must be used to avoid over clocking the calibration counters. Before changing the FREQRANGE field in CMU\_HFRCOCTRL, TUNING and FINETUNING fields should initially be set to the highest value (slowest frequency). After changing the FREQRANGE, linearly step TUNING value until desired frequency is reached. Likewise, before changing the TUNING field, FINETUNING field should initially be set to the highest value (lowest frequency). After changing the TUNING field, linearly step FINETUNING until accuracy is reached.

#### 10.3.2.7 LFRCO Configuration

It is possible to calibrate the LFRCO to achieve higher accuracy (see the device data sheets for details on accuracy). The frequency is adjusted by changing the TUNING bitfield in CMU\_LFRCOCTRL. Changing to a higher value will result in a lower frequency. Refer to the data sheet for stepsize details.


The LFRCO can be retained on in EM4 Hibernate/Shutoff. In that case its required configuration is latched/retained throughout EM4 even though the CMU\_LFRCOCTRL register itself will be reset. Upon EM4 exit the CMU\_LFRCOCTRL register therefore needs to be reconfigured to its original settings and the LFRCO needs to be restarted via CMU\_OSCENCMD, before optionally unlatching the retained LFRCO configuration by writing 1 to EM4UNLATCH in the EMU\_CMD register. The LFRCO startup time is configured via the TIMEOUT bitfield of the CMU\_LFRCOCTRL register. Default its 16 cycle startup should be used. However, in case the LFRCO has been retained throughout EM4 Hibernate/Shutoff, it can be quickly restarted for use as LFACLK or LFBCLK by using its minimum TIMEOUT setting. While retained, the LFRCO can be used down to EM4 Hibernate as source for LFECLK and down to EM4 Shutoff as source for CRYOCLK.

The LFRCO is also calibrated in production and its TUNING values are set to the correct value during reset.

The LFRCO can be put in duty cycle mode by setting the ENVREF bit in CMU\_LFRCOCTRL to 1 before starting the LFRCO. This will reduce current consumption, but will result in slightly worse accuracy especially at high temperatures. Setting the ENCHOP and/or ENDDEM bitfields to 1 in the CMU\_LFRCOCTRL register will improve the average LFRCO frequency accuracy at the cost of a worse cycle-to-cycle accuracy.


### 10.3.2.8 RC Oscillator Calibration

The CMU has built-in HW support to efficiently calibrate the RC oscillators (LFRCO, HFRCO, AUXHFRCO, etc) at run-time. For a complete list of supported oscillators, refer to DOWNSEL and UPSEL fields in CMU\_CALCTRL. See [Figure 10.12 HW-support for RC Oscillator Calibration on page 318](#) for an illustration of this circuit. The concept is to select a reference and compare the RC frequency with the reference frequency. When the calibration circuit is started, one down-counter running on a selectable clock (DOWNSEL in CMU\_CALCTRL) and one up-counter running on a selectable clock (UPSEL in CMU\_CALCTRL) are started simultaneously. The top value for the down-counter must be written to CMU\_CALCNT before calibration is started. The down-counter counts for CMU\_CALCNT +1 cycles. When the down-counter has reached 0, the up-counter is sampled and the CALRDY interrupt flag is set. If CONT in CMU\_CALCTRL is cleared, the counters are stopped after finishing the ongoing calibration. If continuous mode is selected by setting CONT in CMU\_CALCTRL the down-counter reloads the top value and continues counting and the up-counter restarts from 0. Software can then read out the sampled up-counter value from CMU\_CALCNT. The up-counter has counted (the sampled value)+1 cycles. The ratio between the reference and the oscillator subject to the calibration can easily be found using top+1 and sample+1. Overflows of the up-counter will not occur. If the up-counter reaches its top value before the down-counter reaches 0, the up-counter stays at its top value. Calibration can be stopped by writing CALSTOP in CMU\_CMD. With this HW support, it is simple to write efficient calibration algorithms in software.




**Figure 10.12. HW-support for RC Oscillator Calibration**

The counter operation for single and continuous mode are shown in [Figure 10.13 Single Calibration \(CONT=0\) on page 319](#) and [Figure 10.14 Continuous Calibration \(CONT=1\) on page 319](#) respectively.



**Figure 10.13. Single Calibration (CONT=0)**



**Figure 10.14. Continuous Calibration (CONT=1)**

### 10.3.3 Configuration for Operating Frequencies

The HFXO is capable of frequencies up to 48 MHz, which allows the EFM32 to run at up to this frequency. However, not all High Frequency clocks are allowed to run at this maximum frequency. Clocks need to be limited to the frequencies shown in [Table 10.4 Maximum Allowed Clock Frequencies on page 320](#), for example by prescaling them or by selecting an appropriate clock source. Also modules such as the Memory System Controller (MSC), Low Energy Peripheral Interface, and DMEM must be configured correctly to allow operation at higher frequencies as explained further below.

**Table 10.4. Maximum Allowed Clock Frequencies**

Clock	VSCALE2 (1.2V)	VSCALE0 (1.0V)
HFRCO	<= 48 MHz	<= 20 MHz
AUXHFRCO	<= 48 MHz	<= 20 MHz
HFXO	<= 48 MHz	<= 20 MHz <sup>1</sup>
HFSRCCLK, HFPERBCLK	<= 48 MHz	<= 20 MHz
HFBUSCLK, HFPERCLK, HFPERCCLK	<= 48 MHz	<= 20 MHz

**Note:**

1. 48 MHz allowed when not selected.

The MODE bitfield in MSC\_READCTRL makes sure the flash is able to operate at the given HFCLK frequency by inserting wait states for flash accesses. The required settings for controlling flash wait states are shown in [Table 10.5 MSC Configuration for Operating Frequencies, at VSCALE2: Flash Wait States on page 320](#). The WSHFLE bitfield in CMU\_CTRL is used to ensure that the Low Energy Peripheral Interface is able to operate at the given HFCLK<sub>LE</sub> frequency by inserting wait states when using this interface. The required settings are shown in [Table 10.7 LE Configuration for Operating Frequencies: Low Energy Peripheral Interface on page 320](#).

Before going to a high frequency, make sure the registers in the table have the correct values. When going down in frequency, make sure to keep the registers at the values required by the higher frequency until after the switch has been done.

**Table 10.5. MSC Configuration for Operating Frequencies, at VSCALE2: Flash Wait States**

Condition	MODE in MSC_READCTRL
HFCLK <= 25 MHz	WS0 or above
25 MHz < HFCLK <= 48 MHz	WS1 or above

**Table 10.6. MSC Configuration for Operating Frequencies, at VSCALE0: Flash Wait States**

Condition	MODE in MSC_READCTRL
HFCLK <= 10 MHz	WS0 or above
10 MHz < HFCLK <= 20 MHz	WS1 or above

**Table 10.7. LE Configuration for Operating Frequencies: Low Energy Peripheral Interface**

Condition	WSHFLE in CMU_CTRL
HFCLK <sub>LE</sub> <= 32 MHz	0 / 1
HFCLK <sub>LE</sub> > 32 MHz	1

#### 10.3.4 Energy Modes

The availability of oscillators and system clocks depends on the chosen energy mode. Default the high frequency oscillators (HFRCO, AUXHFRCO, and HFXO) and high frequency clocks (HFSRCLK, HFCLK, HCORECLK, HFBUSCLK, HPERCLK, HPERBCLK, HPERCCLK, HFCLKLE) are available down to EM1 Sleep. From EM2 DeepSleep onwards these oscillators and clocks are normally off, although special cases exist as summarized in [Table 10.8 Oscillator and Clock Availability in Energy Modes on page 321](#) and [Table 9.2 EMU Energy Mode Overview on page 227](#). The CMU overview figure in [Figure 10.1 CMU Overview - High Frequency Portion on page 297](#) and [Figure 10.2 CMU Overview - Low Frequency Portion on page 298](#) also indicate which oscillators and clocks can be used in what energy modes.

The low frequency oscillators (LFRCO and LFXO) are available in all energy modes except in EM3 Stop when they are off by definition. Default these oscillators are also off in EM4 Hibernate and EM4 Shutoff, but they can be retained on in these states as well if needed. The ultra low frequency oscillator (ULFRCO) is default on in all energy modes, except for EM4 Shutoff, but it can be retained on in that mode as well if needed. The low frequency clocks (LFACLK, LFBCLK, LFECLK, WDOGnCLK, and CRYOCLK) are in various power domains and therefore their availability not only depends on the chosen clock source, but also on the chosen energy mode as indicated in [Table 10.8 Oscillator and Clock Availability in Energy Modes on page 321](#).

**Table 10.8. Oscillator and Clock Availability in Energy Modes**

	EM0 Active/EM1 Sleep	EM2 DeepSleep	EM3 Stop	EM4 Hibernate	EM4 Shutoff
HFRCO	On <sup>1</sup>	Off	Off	Off	Off
HFXO	On <sup>1</sup>	Off	Off	Off	Off
AUXHFRCO	On <sup>1</sup>	On <sup>2</sup>	On <sup>2</sup>	Off	Off
LFRCO, LFXO	On <sup>1</sup>	On <sup>1</sup>	Off	Retained on <sup>3</sup>	Retained on <sup>3</sup>
ULFRCO	On	On	On	On	Retained on <sup>3</sup>
HFSRCLK, HFCLK, HCORECLK, HFBUSCLK, HPERCLK, HPERBCLK, HPERCCLK, HFCLKLE	On <sup>1</sup>	Off	Off	Off	Off
AUXCLK	On <sup>1</sup>	On <sup>2</sup>	On <sup>2</sup>	Off	Off
ADCnCLK	On <sup>1</sup>	On <sup>4</sup>	On <sup>4</sup>	Off	Off
LFACLK, LFBCLK	On <sup>1</sup>	On <sup>1</sup>	On <sup>5</sup>	Off	Off
LFECLK	On <sup>1</sup>	On <sup>1</sup>	On <sup>5</sup>	Retained on <sup>3</sup>	Off
WDOGnCLK	On <sup>1</sup>	On <sup>1</sup>	On <sup>5</sup>	Off	Off
CRYOCLK	On <sup>1</sup>	On <sup>1</sup>	On <sup>5</sup>	Retained on <sup>3</sup>	Retained on <sup>3</sup>

**Note:**

- 1. Under software control.
- 2. Default off, but kept active if used by the ADC.
- 3. Default off, but can be retained on.
- 4. Will be kept on if AUXHFRCO is selected as clock source.
- 5. On only if ULFRCO is used as clock source.

### 10.3.5 Clock Output on a Pin

It is possible to configure the CMU to output clocks on the CMU\_CLK0, CMU\_CLK1 and CMU\_CLK2 pins. This clock selection is done using the CLKOUTSEL0, CLKOUTSEL1 and CLKOUTSEL2 bitfields respectively in CMU\_CTRL. The required output pins must be enabled in the CMU\_ROUTEOPEN register and the pin locations can be configured in the CMU\_ROUTELOC0 register. The following clocks can be output on a pin:

- HFSRCCCLK and HFEXPCLK. The HFSRCCCLK is the high frequency clock before any prescaling has been applied. The HFEXPCLK is a prescaled version of HFCLK as controlled by the HFEXPRESV bitfield in the CMU\_HFPRESV register.
- The unqualified clock output from any of the oscillators (ULFRCO, LFRCO, LFXO, HFXO). Note that these unqualified clocks can exhibit glitches or skewed duty-cycle during startup and therefore these clock outputs are normally not used before observing the related ready flag being set to 1 in CMU\_STATUS.
- The qualified clock from any of the oscillators (ULFRCO, LFRCO, LFXO, HFXO, HFRCO, AUXHFRCO). A qualified clock will not have any glitches or skewed duty-cycle during startup. For LFRCO, LFXO and HFXO correct configuration of the TIMEOUT bitfield(s) in CMU\_LFRCOCTRL, CMU\_LFXOCTRL and CMU\_HFXOTIMEOUTCTRL respectively is required to guarantee a properly qualified clock.
- The qualified HFXO clock divided by 2 (HFXODIV2Q).

HFCLK will not have a 50-50 duty cycle when any other division factor than 1 is used in CMU\_HFPRESV (i.e. if PRESV is not equal to 0). In such a case, the exported HFEXPCLK will therefore also not be 50-50 when its division factor is not set to an even number in CMU\_HFEXPRESV.

### 10.3.6 Clock Input From a Pin

It is possible to configure the CMU to input a low-frequency (< 1 MHz) clock from the CMU\_CLKI0. This clock can be selected to drive HFSRCCCLK and DPLL reference using CMU\_HFCLKSEL and CMU\_DPLLCTRL respectively. The required input pin must be enabled in the CMU\_ROUTEOPEN register and the pin location can be configured in the CMU\_ROUTELOC1 register.

### 10.3.7 Clock Output on PRS

The CMU can be used as a PRS producer. It can output clocks onto PRS which can be selected by a consumer as CMUCLKOUT0, CMUCLKOUT1 and CMUCLKOUT2. The clocks which can be produced via CMUCLKOUT0, CMUCLKOUT1 and CMUCLKOUT2 are selected via the CLKOUTSEL0, CLKOUTSEL1 and CLKOUTSEL2 fields respectively in CMU\_CTRL.

Note that the CLKOUTSEL0 and CLKOUTSEL1 fields are also used for selecting which clock is output onto a pin as described in [10.3.5 Clock Output on a Pin](#). In contrast with clock output on a pin however, output of a clock onto PRS does not depend on any configuration of the CMU\_ROUTEOPEN and CMU\_ROUTELOC0 registers.

### 10.3.8 Error Handling

Certain restrictions apply to how and when the CMU registers can be configured as is described for the respective registers. Not adhering to these restrictions can lead to unpredictable and non-defined behaviour. Some of these software restrictions are checked in hardware and not adhering to them will cause the CMUERR interrupt flag in CMU\_IF to be set to 1. The restrictions impacting CMUERR are as follows:

- CMU\_HFRCOCTRL should not be written while HFRCOBSY in the CMU\_SYNCBUSY register is set to 1.
- CMU\_AUXHFRCOCTRL should not be written while AUXHFRCOBSY in the CMU\_SYNCBUSY register is set to 1.
- CMU\_HFXOSTARTUPCTRL, CMU\_HFXOSTEADYSTATECTRL and CMU\_HFXOTIMEOUTCTRL should not be written while HFXOBSY in the CMU\_SYNCBUSY register is set to 1. Note that writes to CMU\_HFXOCTRL do not impact CMUERR. Although most of its bitfields need to be configured before enabling the HFXO, it is allowed to change the AUTOSTART bits (i.e. AUTOSTARTSELEM0EM1 and AUTOSTARTEM0EM1) at any time.
- HFXO should not be enabled before it has been properly disabled (so only enable HFXO when HFXOENS=0 or HFXOBSY=0). Likewise, HFXO should not be disabled before it has been properly enabled (so only disable HFXO when HFXOENS=1 or HFXOBSY=0).
- CMU\_LFRCOCTRL should not be written while LFRCOBSY in the CMU\_SYNCBUSY register is set to 1. The GMCCURTUNE bitfield should not be written with a differing value while the LFRCOVREFBSY flag is set to 1.
- CMU\_LFXOCTRL should not be written while LFXOBSY in the CMU\_SYNCBUSY register is set to 1.

### 10.3.9 Interrupts

The interrupts generated by the CMU module are combined into one interrupt vector. If CMU interrupts are enabled, an interrupt will be made if one or more of the interrupt flags in CMU\_IF and their corresponding bits in CMU\_IEN are set.

### 10.3.10 Wake-up

The CMU can be (partially) active all the way down to EM4 Shutoff. It can wake up the CPU from EM2 upon LFRCO or LFXO becoming ready as LFRCORDY and LFXORDY can be used as wake-up interrupt.

### 10.3.11 Protection

It is possible to lock the control- and command registers to prevent unintended software writes to critical clock settings. This is controlled by the CMU\_LOCK register.

### 10.3.12 Digital Phase-Locked Loop

The Digital Phase-Locked Loop (DPLL) uses the HFRCO to generate a clock as a ratio of a reference clock source. It provides the following features:

- Frequency-lock mode. Only the output frequency is controlled, phase error is allowed to accumulate between the output and reference clock.
- Phase-lock mode. Both the output frequency and phase are controlled.
- Output frequency =  $F_{REF} \times (N+1) / (M+1)$ , where N and M are 12-bit values
- Very fast lock time.
- Very fast transient tracking.
- Low output jitter.
- Lock detection with an interrupt.
- Lock fail detection with interrupts.
- Output spectrum-spreading. The DPLL can randomize the generated output period by a configurable amount of spread.

It is important to note that when DPLL is enabled, the HFRCO output frequency will be generated according to the DPLL configuration.

#### 10.3.12.1 Enabling and Disabling

The DPLL feature can be enabled and disabled by software via the CMU\_OSCENCMD register. The FINETUNINGEN bit in the CMU\_HFRCOCTRL must also be set for proper DPLL operation. When enabled, the DPLL feature controls the output frequency of the HFRCO. Before enabling DPLL, all clock muxes selecting HFRCO should be switched to HFRCODIV2 temporarily until the DPLL is locked, to avoid over-clocking the circuit. After DPLL is enabled and running, the clock muxes may be switched back to HFRCO to use the new output frequency. The DPLL is disabled automatically when entering EM2, EM3, or EM4.

#### 10.3.12.2 Lock Modes

DPLL provides two lock modes, referred to as frequency-lock loop mode (FREQLL) and phase-lock loop mode (PHASELL). FREQLL mode keeps the DCO frequency-locked to the reference clock, which means the DCO frequency will be accurate. But the phase error can accumulate over time and cause the average frequency error non-zero. FREQLL mode also provide better jitter and transient performance. PHASELL mode keeps the DCO phase-locked to the reference clock, which means the phase error does not accumulate over time and make the average frequency error zero. FREQLL mode should be used unless specific phase requirement exists.

#### 10.3.12.3 Configurations

Output frequency =  $F_{REF} \times (N+1) / (M+1)$ . User should calculate N and M to achieve the target frequency. Note that with N increases, the DCO lock time would increase and DCO jitter would decrease. Both directions are approximately linear. This relationship can be used to select N for a given application to strike a compromise between lock time and output jitter. For example if an ratio of 3 is desired, the DPLL could be configured as {N=299, M=99} for fast lock time but high jitter, or as {N=2999, M=999} for lower jitter but longer lock time. For a good balance, N is suggested to be larger than 300 unless specific lock time is required.

**Note:** All configuration setting should be done before enabling the DPLL. They should not be changed when DPLL is running. The final tuning values can be read back from TUNING and FINETUNING in CMU\_HFRCOCTRL, after DPLL is disabled and DPLLENS in CMU\_STATUS is low.

#### 10.3.12.4 Lock Detection

The DPLL has 3 different types of output event: ready, lock fail due to period underflow and lock fail due to period overflow. Each of the event has its own interrupt flag. DPLLRDY is set when DPLL successfully locks to the reference clock based on user's configuration. DPLLLOCKFAILLOW is set when DPLL fails to lock because the period lower boundary is hit. DPLLLOCKFAILHIGH is set when DPLL fail to lock because the period upper boundary is hit. If the interrupt flags are set and the corresponding interrupt enable bits in CMU\_IEN are set, the CMU will send out an interrupt request. Based on different interrupt sequence, user should take different actions:

- If DPLLRDY interrupt is received first, it means target clock is ready and it is safe to switch to use DCO's output.
- If DPLLLOCKFAILLOW interrupt is received first, it indicates the RANGE in CMU\_HFRCOCTRL is too small. User should disable DPLL and write a larger value to RANGE, then enable DPLL again to lock.
- If DPLLLOCKFAILHIGH interrupt is received first, it indicates the RANGE in CMU\_HFRCOCTRL is too large. User should disable DPLL and write a smaller value to RANGE, then enable DPLL again to lock.
- If DPLLRDY interrupt is received first and then DPLLLOCKFAILLOW or DPLLLOCKFAILHIGH is received later, it means reference clock drifted over 2% and made DPLL lost its locked status.
  - If AUTORECOVER in CMU\_DPLLCTRL is not set, user should disable DPLL and enable DPLL again to lock.
  - If AUTORECOVER in CMU\_DPLLCTRL is set, hardware would re-lock automatically. When the target frequency is near the boundary of a range, the drift may cause underflow or overflow. In this case the fail interrupt would still be received. User should disable DPLL and modify RANGE in CMU\_HFRCOCTRL in corresponding direction like the second and third cases. Then enable DPLL again to lock.

#### 10.3.12.5 Spectrum Spreading

Spreading of the DCO output spectrum is accomplished by driving a dedicated 5-bit DCO trim control with a digitally-generated, pseudo-random value. A centered, uniform, random spreading algorithm was selected. The spectrum-spreading pattern is generated by a single 10-bit linear feedback shift register (LFSR). To avoid high correlation between nearby values, a 5-step leap-forward LFSR update method is employed in the DPLL. The DCO output period can be randomized with a peak-to-peak amplitude given approximately by:  $2^{(SSAMP-1)} \times 0.2\%$ , where SSAMP is a register field in CMU\_HFRCOSS. The generated random values are applied at regular intervals given by:  $4 \times T_{DCO} \times (SSINV+1)$ , where  $T_{DCO}$  is DCO period and SSINV is a register field in CMU\_HFRCOSS.

## 10.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	CMU_CTRL	RW	CMU Control Register
0x010	CMU_HFRCOCTRL	RWH	HFRCO Control Register
0x018	CMU_AUXHFRCOCTRL	RW	AUXHFRCO Control Register
0x020	CMU_LFRCOCTRL	RW	LFRCO Control Register
0x024	CMU_HFXOCTRL	RW	HFXO Control Register
0x028	CMU_HFXOCTRL1	RW	HFXO Control 1
0x02C	CMU_HFXOSTARTUPCTRL	RW	HFXO Startup Control
0x030	CMU_HFXOSTEADYSTATECTRL	RW	HFXO Steady State Control
0x034	CMU_HFXOTIMEOUTCTRL	RW	HFXO Timeout Control
0x038	CMU_LFXOCTRL	RW	LFXO Control Register
0x040	CMU_DPLLCTRL	RW	DPLL Control Register
0x044	CMU_DPLLCTRL1	RW	DPLL Control Register
0x050	CMU_CALCTRL	RW	Calibration Control Register
0x054	CMU_CALCNT	RWH	Calibration Counter Register
0x060	CMU_OSCENCMD	W1	Oscillator Enable/Disable Command Register
0x064	CMU_CMD	W1	Command Register
0x070	CMU_DBGCLKSEL	RW	Debug Trace Clock Select
0x074	CMU_HFCLKSEL	W1	High Frequency Clock Select Command Register
0x080	CMU_LFACLKSEL	RW	Low Frequency A Clock Select Register
0x084	CMU_LFBCLKSEL	RW	Low Frequency B Clock Select Register
0x088	CMU_LFECLKSEL	RW	Low Frequency E Clock Select Register
0x090	CMU_STATUS	R	Status Register
0x094	CMU_HFCLKSTATUS	R	HFCLK Status Register
0x09C	CMU_HFXOTRIMSTATUS	R	HFXO Trim Status
0x0A0	CMU_IF	R	Interrupt Flag Register
0x0A4	CMU_IFS	W1	Interrupt Flag Set Register
0x0A8	CMU_IFC	(R)W1	Interrupt Flag Clear Register
0x0AC	CMU_IEN	RW	Interrupt Enable Register
0x0B0	CMU_HFBUSCLKEN0	RW	High Frequency Bus Clock Enable Register 0
0x0C0	CMU_HFFPERCLKEN0	RW	High Frequency Peripheral Clock Enable Register 0
0x0C4	CMU_HFFPERCLKEN1	RW	High Frequency Peripheral Clock Enable Register 1
0x0E0	CMU_LFACLKEN0	RW	Low Frequency a Clock Enable Register 0 (Async Reg)
0x0E8	CMU_LFBCLKEN0	RW	Low Frequency B Clock Enable Register 0 (Async Reg)
0x0F0	CMU_LFECLKEN0	RW	Low Frequency E Clock Enable Register 0 (Async Reg)
0x100	CMU_HFPRESC	RW	High Frequency Clock Prescaler Register

Offset	Name	Type	Description
0x104	CMU_HFBUSPRES	RW	High Frequency Bus Clock Prescaler Register
0x108	CMU_HFCOREPRES	RW	High Frequency Core Clock Prescaler Register
0x10C	CMU_HFPERPRES	RW	High Frequency Peripheral Clock Prescaler Register
0x114	CMU_HFEXPPRES	RW	High Frequency Export Clock Prescaler Register
0x118	CMU_HFPERPRESB	RW	High Frequency Peripheral Clock Prescaler B Register
0x11C	CMU_HFPERPRESCC	RW	High Frequency Peripheral Clock Prescaler C Register
0x120	CMU_LFAPRES0	RW	Low Frequency a Prescaler Register 0 (Async Reg)
0x128	CMU_LFBPRES0	RW	Low Frequency B Prescaler Register 0 (Async Reg)
0x130	CMU_LFEPRES0	RW	Low Frequency E Prescaler Register 0 (Async Reg)
0x140	CMU_SYNCBUSY	R	Synchronization Busy Register
0x144	CMU_FREEZE	RW	Freeze Register
0x150	CMU_PCNTCTRL	RWH	PCNT Control Register
0x15C	CMU_ADCCTRL	RWH	ADC Control Register
0x170	CMU_ROUTEOPEN	RW	I/O Routing Pin Enable Register
0x174	CMU_ROUTELOC0	RW	I/O Routing Location Register
0x178	CMU_ROUTELOC1	RW	I/O Routing Location Register
0x180	CMU_LOCK	RWH	Configuration Lock Register
0x184	CMU_HFRCOSS	RW	HFRCO Spread Spectrum Register

## 10.5 Register Description

### 10.5.1 CMU\_CTRL - CMU Control Register

Offset	Bit Position																																
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset												1				0																	
Access												RW				RW				RW	0x0												
Name												HFPERCLKEN				WSHFLE				CLKOUTSEL2													
																				CLKOUTSEL1													
																				CLKOUTSEL0													

Bit	Name	Reset	Access	Description
31:21	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
20	HFPERCLKEN	1	RW	<b>HFPERCLK Enable</b>
				Set to enable the HFPERCLK.
19:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
16	WSHFLE	0	RW	<b>Wait State for High-Frequency LE Interface</b>
				Set to allow access to LE peripherals when running HFBUSCLK <sub>LE</sub> at frequencies higher than 32 MHz
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
13:10	CLKOUTSEL2	0x0	RW	<b>Clock Output Select 2</b>
				Controls the clock output 2 multiplexer. To actually output on the pin, set CLKOUT2PEN in CMU_ROUTE.
Value	Mode			Description
0	DISABLED			Disabled
1	ULFRCO			ULFRCO (directly from oscillator)
2	LFRCO			LFRCO (directly from oscillator)
3	LFXO			LFXO (directly from oscillator)
5	HFXODIV2Q			HFXO divided by two (qualified)
6	HFXO			HFXO (directly from oscillator)
7	HFEXPCLK			HFEXPCLK
9	ULFRCOQ			ULFRCO (qualified)
10	LFRCOQ			LFRCO (qualified)
11	LFXOQ			LFXO (qualified)
12	HFRCOQ			HFRCO (qualified)
13	AUXHFRCOQ			AUXHFRCO (qualified)
14	HFXOQ			HFXO (qualified)
15	HFSRCCLK			HFSRCCLK

Bit	Name	Reset	Access	Description																																										
9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																																										
8:5	CLKOUTSEL1	0x0	RW	<b>Clock Output Select 1</b>																																										
				Controls the clock output 1 multiplexer. To actually output on the pin, set CLKOUT1PEN in CMU_ROUTE.																																										
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>DISABLED</td><td>Disabled</td></tr> <tr><td>1</td><td>ULFRCO</td><td>ULFRCO (directly from oscillator)</td></tr> <tr><td>2</td><td>LFRCO</td><td>LFRCO (directly from oscillator)</td></tr> <tr><td>3</td><td>LFXO</td><td>LFXO (directly from oscillator)</td></tr> <tr><td>6</td><td>HFXO</td><td>HFXO (directly from oscillator)</td></tr> <tr><td>7</td><td>HFEXPCLK</td><td>HFEXPCLK</td></tr> <tr><td>9</td><td>ULFRCOQ</td><td>ULFRCO (qualified)</td></tr> <tr><td>10</td><td>LFRCOQ</td><td>LFRCO (qualified)</td></tr> <tr><td>11</td><td>LFXOQ</td><td>LFXO (qualified)</td></tr> <tr><td>12</td><td>HFRCOQ</td><td>HFRCO (qualified)</td></tr> <tr><td>13</td><td>AUXHFRCOQ</td><td>AUXHFRCO (qualified)</td></tr> <tr><td>14</td><td>HFXOQ</td><td>HFXO (qualified)</td></tr> <tr><td>15</td><td>HFSRCCCLK</td><td>HFSRCCCLK</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLED	Disabled	1	ULFRCO	ULFRCO (directly from oscillator)	2	LFRCO	LFRCO (directly from oscillator)	3	LFXO	LFXO (directly from oscillator)	6	HFXO	HFXO (directly from oscillator)	7	HFEXPCLK	HFEXPCLK	9	ULFRCOQ	ULFRCO (qualified)	10	LFRCOQ	LFRCO (qualified)	11	LFXOQ	LFXO (qualified)	12	HFRCOQ	HFRCO (qualified)	13	AUXHFRCOQ	AUXHFRCO (qualified)	14	HFXOQ	HFXO (qualified)	15	HFSRCCCLK	HFSRCCCLK
Value	Mode	Description																																												
0	DISABLED	Disabled																																												
1	ULFRCO	ULFRCO (directly from oscillator)																																												
2	LFRCO	LFRCO (directly from oscillator)																																												
3	LFXO	LFXO (directly from oscillator)																																												
6	HFXO	HFXO (directly from oscillator)																																												
7	HFEXPCLK	HFEXPCLK																																												
9	ULFRCOQ	ULFRCO (qualified)																																												
10	LFRCOQ	LFRCO (qualified)																																												
11	LFXOQ	LFXO (qualified)																																												
12	HFRCOQ	HFRCO (qualified)																																												
13	AUXHFRCOQ	AUXHFRCO (qualified)																																												
14	HFXOQ	HFXO (qualified)																																												
15	HFSRCCCLK	HFSRCCCLK																																												
4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																																										
3:0	CLKOUTSEL0	0x0	RW	<b>Clock Output Select 0</b>																																										
				Controls the clock output multiplexer. To actually output on the pin, set CLKOUT0PEN in CMU_ROUTE.																																										
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>DISABLED</td><td>Disabled</td></tr> <tr><td>1</td><td>ULFRCO</td><td>ULFRCO (directly from oscillator)</td></tr> <tr><td>2</td><td>LFRCO</td><td>LFRCO (directly from oscillator)</td></tr> <tr><td>3</td><td>LFXO</td><td>LFXO (directly from oscillator)</td></tr> <tr><td>6</td><td>HFXO</td><td>HFXO (directly from oscillator)</td></tr> <tr><td>7</td><td>HFEXPCLK</td><td>HFEXPCLK</td></tr> <tr><td>9</td><td>ULFRCOQ</td><td>ULFRCO (qualified)</td></tr> <tr><td>10</td><td>LFRCOQ</td><td>LFRCO (qualified)</td></tr> <tr><td>11</td><td>LFXOQ</td><td>LFXO (qualified)</td></tr> <tr><td>12</td><td>HFRCOQ</td><td>HFRCO (qualified)</td></tr> <tr><td>13</td><td>AUXHFRCOQ</td><td>AUXHFRCO (qualified)</td></tr> <tr><td>14</td><td>HFXOQ</td><td>HFXO (qualified)</td></tr> <tr><td>15</td><td>HFSRCCCLK</td><td>HFSRCCCLK</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLED	Disabled	1	ULFRCO	ULFRCO (directly from oscillator)	2	LFRCO	LFRCO (directly from oscillator)	3	LFXO	LFXO (directly from oscillator)	6	HFXO	HFXO (directly from oscillator)	7	HFEXPCLK	HFEXPCLK	9	ULFRCOQ	ULFRCO (qualified)	10	LFRCOQ	LFRCO (qualified)	11	LFXOQ	LFXO (qualified)	12	HFRCOQ	HFRCO (qualified)	13	AUXHFRCOQ	AUXHFRCO (qualified)	14	HFXOQ	HFXO (qualified)	15	HFSRCCCLK	HFSRCCCLK
Value	Mode	Description																																												
0	DISABLED	Disabled																																												
1	ULFRCO	ULFRCO (directly from oscillator)																																												
2	LFRCO	LFRCO (directly from oscillator)																																												
3	LFXO	LFXO (directly from oscillator)																																												
6	HFXO	HFXO (directly from oscillator)																																												
7	HFEXPCLK	HFEXPCLK																																												
9	ULFRCOQ	ULFRCO (qualified)																																												
10	LFRCOQ	LFRCO (qualified)																																												
11	LFXOQ	LFXO (qualified)																																												
12	HFRCOQ	HFRCO (qualified)																																												
13	AUXHFRCOQ	AUXHFRCO (qualified)																																												
14	HFXOQ	HFXO (qualified)																																												
15	HFSRCCCLK	HFSRCCCLK																																												

### 10.5.2 CMU\_HFRCOCTRL - HFRCO Control Register

Write this register to set the frequency band in which the HFRCO is to operate. Always update all fields in this register at once by writing the value for the desired band, which has been obtained from the Device Information page entry for that band. The TUNING, FINE-TUNING, FINETUNINGEN and CLKDIV bitfields can be used to tune a specific band (FREQRANGE) of the oscillator to a non-preconfigured frequency. When changing this setting there will be no glitches on the HFRCO output, hence it is safe to change this setting.

even while the system is running on the HFRCO. Only write CMU\_HFRCOCTRL when it is ready for an update as indicated by HFRCOBSY=0 in CMU\_SYNCBUSY.

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RWH	RWH	0xB	RWH	0	RWH	0x0	RWH	1	RWH	0x2	RWH	22	RWH	0x08	RWH	0x1F	RWH														
Name	VREFTC	FINETUNINGEN	CLKDIV	LDOHP	CMPBIAS	FREQRANGE	FINETUNING	TUNING																								

Bit	Name	Reset	Access	Description
31:28	VREFTC	0xB	RWH	<b>HFRCO Temperature Coefficient Trim on Comparator Reference</b>  Writing this field adjusts the temperature coefficient trim on comparator reference.
27	FINETUNINGEN	0	RWH	<b>Enable Reference for Fine Tuning</b>  Settings this bit enables HFRCO fine tuning.
26:25	CLKDIV	0x0	RWH	<b>Locally Divide HFRCO Clock Output</b>  Writing this field configures the HFRCO clock output divider.
	Value	Mode		Description
	0	DIV1		Divide by 1.
	1	DIV2		Divide by 2.
	2	DIV4		Divide by 4.
24	LDOHP	1	RWH	<b>HFRCO LDO High Power Mode</b>  Settings this bit puts the HFRCO LDO in high power mode.
23:21	CMPBIAS	0x2	RWH	<b>HFRCO Comparator Bias Current</b>  Writing this field adjusts the HFRCO comparator bias current.
20:16	FREQRANGE	0x08	RWH	<b>HFRCO Frequency Range</b>  Writing this field adjusts the HFRCO frequency range.
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13:8	FINETUNING	0x1F	RWH	<b>HFRCO Fine Tuning Value</b>  Writing this field adjusts the HFRCO fine tuning value. Higher value means lower frequency. Fine tuning is only enabled when FINETUNINGEN is set.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:0	TUNING	0x7F	RWH	<b>HFRCO Tuning Value</b>  Writing this field adjusts the HFRCO tuning value. Higher value means lower frequency.

**10.5.3 CMU\_AUXHFRCOCTRL - AUXHFRCO Control Register**

Write this register with the production calibrated values from the Device Info pages. The TUNING, FINETUNING, FINETUNINGEN and CLKDIV bitfields can be used to tune a specific band (FREQRANGE) of the oscillator to a non-preconfigured frequency. Only write CMU\_AUXHFRCOCTRL when it is ready for an update as indicated by AUXHFRCOBSY=0 in CMU\_SYNCBUSY.

Offset	Bit Position																																
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	0x08	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xB				0	0x0				1									0x1F								0x7F						
Access	RW				RW	RW				RW					RW				RW								RW						
Name	VREFTC				FINETUNINGEN	CLKDIV				LDOHP	CMPBIAS				FREQRANGE				FINETUNING								TUNING						

Bit	Name	Reset	Access	Description												
31:28	VREFTC	0xB	RW	<b>AUXHFRCO Temperature Coefficient Trim on Comparator Reference</b>												
Writing this field adjusts the temperature coefficient trim on comparator reference.																
27	FINETUNINGEN	0	RW	<b>Enable Reference for Fine Tuning</b>												
Settings this bit enables AUXHFRCO fine tuning.																
26:25	CLKDIV	0x0	RW	<b>Locally Divide AUXHFRCO Clock Output</b>												
Writing this field configures the AUXHFRCO clock output divider.																
<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DIV1</td> <td>Divide by 1.</td> </tr> <tr> <td>1</td> <td>DIV2</td> <td>Divide by 2.</td> </tr> <tr> <td>2</td> <td>DIV4</td> <td>Divide by 4.</td> </tr> </tbody> </table>					Value	Mode	Description	0	DIV1	Divide by 1.	1	DIV2	Divide by 2.	2	DIV4	Divide by 4.
Value	Mode	Description														
0	DIV1	Divide by 1.														
1	DIV2	Divide by 2.														
2	DIV4	Divide by 4.														
24	LDOHP	1	RW	<b>AUXHFRCO LDO High Power Mode</b>												
Settings this bit puts the AUXHFRCO LDO in high power mode.																
23:21	CMPBIAS	0x2	RW	<b>AUXHFRCO Comparator Bias Current</b>												
Writing this field adjusts the AUXHFRCO comparator bias current.																
20:16	FREQRANGE	0x08	RW	<b>AUXHFRCO Frequency Range</b>												
Writing this field adjusts the AUXHFRCO frequency range.																
15:14	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>														
13:8	FINETUNING	0x1F	RW	<b>AUXHFRCO Fine Tuning Value</b>												
Writing this field adjusts the AUXHFRCO fine tuning value. Higher value means lower frequency. Fine tuning is only enabled when FINETUNINGEN is set.																
7	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>														
6:0	TUNING	0x7F	RW	<b>AUXHFRCO Tuning Value</b>												
Writing this field adjusts the AUXHFRCO tuning value. Higher value means lower frequency.																

## 10.5.4 CMU\_LFRCOCTRL - LFRCO Control Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x100																															
Access	RW																									RW						
Name	GMCCURTUNE																									TUNING						

Bit	Name	Reset	Access	Description															
31:28	GMCCURTUNE	0x8	RW	<b>Tuning of Gmc Current</b>															
				Set to tune GMC current. This field is updated with the production calibrated value during reset, and the reset value might therefore vary between devices.															
27:26	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																	
25:24	TIMEOUT	0x1	RW	<b>LFRCO Timeout</b>															
				Configures the start-up delay for LFRCO. Do not change while LFRCO is enabled. When starting up the LFRCO after it has been completely turned off, use TIMEOUT=16cycles. If the LFRCO has been retained on in EM4, then the TIMEOUT=2cycles configuration is also allowed when re-enabling the LFRCO after EM4 exit (as it is still running).															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>2CYCLES</td><td>Timeout period of 2 cycles</td></tr> <tr> <td>1</td><td>16CYCLES</td><td>Timeout period of 16 cycles</td></tr> <tr> <td>2</td><td>32CYCLES</td><td>Timeout period of 32 cycles</td></tr> </tbody> </table>	Value	Mode	Description	0	2CYCLES	Timeout period of 2 cycles	1	16CYCLES	Timeout period of 16 cycles	2	32CYCLES	Timeout period of 32 cycles			
Value	Mode	Description																	
0	2CYCLES	Timeout period of 2 cycles																	
1	16CYCLES	Timeout period of 16 cycles																	
2	32CYCLES	Timeout period of 32 cycles																	
23:22	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																	
21:20	VREFUPDATE	0x0	RW	<b>Control Vref Update Rate</b>															
				Specify Vref update rate. This field can be updated with the production test value during reset, and the reset value might therefore differ.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>32CYCLES</td><td>32 clocks.</td></tr> <tr> <td>1</td><td>64CYCLES</td><td>64 clocks.</td></tr> <tr> <td>2</td><td>128CYCLES</td><td>128 clocks.</td></tr> <tr> <td>3</td><td>256CYCLES</td><td>256 clocks.</td></tr> </tbody> </table>	Value	Mode	Description	0	32CYCLES	32 clocks.	1	64CYCLES	64 clocks.	2	128CYCLES	128 clocks.	3	256CYCLES	256 clocks.
Value	Mode	Description																	
0	32CYCLES	32 clocks.																	
1	64CYCLES	64 clocks.																	
2	128CYCLES	128 clocks.																	
3	256CYCLES	256 clocks.																	
19	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																	
18	ENDEM	1	RW	<b>Enable Dynamic Element Matching</b>															
				Set to enable dynamic element matching. This improves average frequency accuracy at the cost of increased jitter.															

Bit	Name	Reset	Access	Description
17	ENCHOP	1	RW	<b>Enable Comparator Chopping</b>  Set to enable comparator chopping. This improves average frequency accuracy at the cost of increased jitter.
16	ENVREF	0	RW	<b>Enable Duty Cycling of Vref</b>  Set to enable duty cycling of vref. Clear during calibration of LFRCO. Only change when LFRCO is off.
15:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:0	TUNING	0x100	RW	<b>LFRCO Tuning Value</b>  Writing this field adjusts the LFRCO frequency (the higher the value, the lower the frequency). This field is updated with the production calibrated value during reset, and the reset value might therefore vary between devices.

## 10.5.5 CMU\_HFXOCTRL - HFXO Control Register

Offset	Bit Position																																						
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0							
Reset																																							
Access								RW	0x0																														
Name	AUTOSTARTSELEM1	RW	AUTOSTARTTEM0EM1	RW				RW																															
	LFTIMEOUT																																						
Bit	Name	Reset	Access	Description																																			
31:30	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																			
29	AUTOSTARTSE-LEM0EM1	0	RW	<b>Automatically Start and Select of HFXO Upon EM0/EM1 Entry From EM2/EM3</b>																																			
				This bit enables automatic start-up and immediate selection of the HFXO when in EM0/EM1 (also after entry from EM2/EM3). Note that setting this bit to 1 will stall HFSRCCLK until HFXO becomes ready. Allowed to change at any time.																																			
28	AUTOSTAR-TEM0EM1	0	RW	<b>Automatically Start of HFXO Upon EM0/EM1 Entry From EM2/EM3</b>																																			
				This bit enables automatic start-up of the HFXO when in EM0/EM1 (also after entry from EM2/EM3) without causing an automatic HFXO selection. Allowed to change at any time.																																			
27	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																			
26:24	LFTIMEOUT	0x0	RW	<b>HFXO Low Frequency Timeout</b>																																			
				Configures the start-up delay for HFXO measured in LFECLK cycles. Only change when both HFXO and LFECLK are off.																																			
					Value	Mode																																	
					0	0CYCLES																																	
					1	2CYCLES																																	
					2	4CYCLES																																	
					3	16CYCLES																																	
					4	32CYCLES																																	
					5	64CYCLES																																	
					6	1KCYCLES																																	
					7	4KCYCLES																																	
					23:6	Reserved																																	

Bit	Name	Reset	Access	Description																																							
31:30	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																							
29	AUTOSTARTSE-LEM0EM1	0	RW	<b>Automatically Start and Select of HFXO Upon EM0/EM1 Entry From EM2/EM3</b>																																							
				This bit enables automatic start-up and immediate selection of the HFXO when in EM0/EM1 (also after entry from EM2/EM3). Note that setting this bit to 1 will stall HFSRCCLK until HFXO becomes ready. Allowed to change at any time.																																							
28	AUTOSTAR-TEM0EM1	0	RW	<b>Automatically Start of HFXO Upon EM0/EM1 Entry From EM2/EM3</b>																																							
				This bit enables automatic start-up of the HFXO when in EM0/EM1 (also after entry from EM2/EM3) without causing an automatic HFXO selection. Allowed to change at any time.																																							
27	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																							
26:24	LFTIMEOUT	0x0	RW	<b>HFXO Low Frequency Timeout</b>																																							
				Configures the start-up delay for HFXO measured in LFECLK cycles. Only change when both HFXO and LFECLK are off.																																							
					Value	Mode																																					
					0	0CYCLES																																					
					1	2CYCLES																																					
					2	4CYCLES																																					
					3	16CYCLES																																					
					4	32CYCLES																																					
					5	64CYCLES																																					
					6	1KCYCLES																																					
					7	4KCYCLES																																					
					23:6	Reserved																																					

Bit	Name	Reset	Access	Description
5:4	PEAKDETMODE	0x0	RW	<b>HFXO Automatic Peak Detection Mode</b>
Set to AUTOCMD to allow automatic HFXO peak detection (MANUAL mode provides direct control of IBTRIMXOCORE and PEAKDETEN).				
	Value	Mode	Description	
	0	ONCECMD	Automatic control of HFXO peak detection sequence. Only performs peak detection on initial HFXO startup. CMU_CMD HFXOPEAKDETSTART allowed to be used after HFXORDY=1.	
	1	AUTOCMD	Automatic control of HFXO peak detection sequence. CMU_CMD HFXOPEAKDETSTART allowed to be used after HFXORDY=1.	
	2	CMD	CMU_CMD HFXOPEAKDETSTART can be used to trigger the peak detection sequence after HFXORDY=1.	
	3	MANUAL	CMU_HFXOSTEADYSTATECTRL IBTRIMXOCORE and PEAKDETEN are under full software control and are allowed to be changed once HFXO is ready.	
3:2	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
1:0	MODE	0x0	RW	<b>HFXO Mode</b>
Set this to configure the external source for the HFXO. The oscillator setting takes effect when 1 is written to HFXOEN in CMU_OSCENCMD.				
	Value	Mode	Description	
	0	XTAL	4 MHz - 48 MHz crystal oscillator	
	1	ACBUFEXTCLK	An AC coupled buffer is coupled in series with HFXTAL_N pin, suitable for external sinus wave.	
	2	DCBUFEXTCLK	A DC coupled buffer is coupled in series with HFXTAL_N pin, suitable for external sinus wave.	
	3	DIGEXTCLK	Digital external clock can be supplied on HFXTAL_N pin.	

### **10.5.6 CMU\_HFXOCTRL1 - HFXO Control 1**

Bit	Name	Reset	Access	Description
31:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:12	PEAKDETTHR	0x2	RW	<b>Sets the Amplitude Detection Level (mV)</b>
				Configures the Peak Detection threshold. It is not allowed to change when hardware based Peak Detection Algorithm or Peak Monitoring Algorithm is being performed. Allowed to change when HFXOBSY=0. Allowed to change after completing automatic Peak Detection (HFXOBSY=1, PEAKMONEN=0, HFXOPEAKDET RDY=1). Allowed to change after completing HFXO startup when not using automatic Peak Detection (HFXOBSY=1, PEAKMONEN=0, HFXORDY=1)
Value	Mode			Description
0	THR0			50mV amplitude detection level
1	THR1			75mV amplitude detection level
2	THR2			115mV amplitude detection level
3	THR3			160mV amplitude detection level
4	THR4			220mV amplitude detection level
5	THR5			260mV amplitude detection level
6	THR6			320mV amplitude detection level
7	THR7			Same as THR6
11:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 10.5.7 CMU\_HFXOSTARTUPCTRL - HFXO Startup Control

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset															0x000							0x600										
Access															RW							RW										
Name															CTUNE							IBTRIMXOCORE										

Bit	Name	Reset	Access	Description
31:20	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
19:11	CTUNE	0x000	RW	<b>Sets Oscillator Tuning Capacitance</b>  This CTUNE value is applied during the startup phase of the HFXO. The required CTUNE value is XTAL specific. Capacitance on HFXTAL_N and HFXTAL_P (pF) = C_tune = Min (C_HFXO_T) + CTUNE<8:0> x SS_HFXO. Please find C_HFXO_T and SS_HFXO in the datasheet.
10:0	IBTRIMXOCORE	0x600	RW	<b>Sets the Startup Oscillator Core Bias Current</b>  This IBTRIMXOCORE value is applied during the startup phase of the HFXO. Current (uA) = IBTRIMXOCORE<10:9> X 1280uA + IBTRIMXOCORE<8:0> X 2uA. It is recommended to use IBTRIMXOCORE<8:0>=0.

#### **10.5.8 CMU\_HFXOSTEADYSTATECTRL - HFXO Steady State Control**

Bit	Name	Reset	Access	Description
31:28	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
27	PEAKMONEN	1	RW	<b>Automatically Perform Peak Monitoring Algorithm on Every Rising Edge of ULFRCO</b>
				This bit enables Peak Monitoring Algorithm to be performed on every rising edge of ULFRCO. Allowed to change at any time.
26	PEAKDETEN	0	RW	<b>Enables Oscillator Peak Detectors</b>
				Direct control allowed after completion of automatic Peak Detection (PEAKDETRDY=1) or when HFXO is ready and automatic Peak Detection is not being used (HFXORDY=1).
25:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
19:11	CTUNE	0x000	RW	<b>Sets Oscillator Tuning Capacitance</b>
				This CTUNE value is applied during the steady state phase of the HFXO (as well as during the peak detection and shunt current optimization algorithms). Direct control is allowed when HFXORDY=1. The required CTUNE value is XTAL specific. Capacitance on HFXTAL_N and HFXTAL_P (pF) = C_tune = Min (C_HFXO_T) + CTUNE<8:0> x SS_HFXO. Please find C_HFXO_T and SS_HFXO in the datasheet.
10:0	IBTRIMXOCORE	0x100	RW	<b>Sets the Steady State Oscillator Core Bias Current.</b>
				This IBTRIMXOCORE value is applied during the steady state phase of the HFXO. Required IBTRIMXOCORE is XTAL specific. It is also used as the initial value during the peak detection algorithm. Direct control allowed when PEAKDET-SHUNTOPTMODE=MANUAL and HFXO is ready. Current (uA) = IBTRIMXOCORE<10:9> x 1280uA + IBTRIMXOCORE<8:0> x 2uA. It is recommended to use IBTRIMXOCORE<10:9>=0..

## 10.5.9 CMU\_HFXOTIMEOUTCTRL - HFXO Timeout Control

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0xD					0x8					0xE					
Access																	RW					RW					RW					
Name																	PEAKDETTIMEOUT					STEADYTIMEOUT					STARTUPTIMEOUT					

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:12	PEAKDETTIMEOUT	0xD	RW	<b>Wait Duration in HFXO Peak Detection Wait State</b>
Wait duration depends on the chosen XTAL (expected value is between 25 us and 200 us). Program the desired duration measured in cycles of (at least) 83 ns.				

Value	Mode	Description
0	2CYCLES	Timeout period of 2 cycles
1	4CYCLES	Timeout period of 4 cycles
2	16CYCLES	Timeout period of 16 cycles
3	32CYCLES	Timeout period of 32 cycles
4	64CYCLES	Timeout period of 64 cycles
5	128CYCLES	Timeout period of 128 cycles
6	256CYCLES	Timeout period of 256 cycles
7	1KCYCLES	Timeout period of 1024 cycles
8	2KCYCLES	Timeout period of 2048 cycles
9	4KCYCLES	Timeout period of 4096 cycles
10	8KCYCLES	Timeout period of 8192 cycles
11	16KCYCLES	Timeout period of 16384 cycles
12	32KCYCLES	Timeout period of 32768 cycles
13	64KCYCLES	Timeout period of 65536 cycles
14	128KCYCLES	Timeout period of 131072 cycles

11:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
------	----------	--	--	---

7:4	STEADYTIMEOUT	0x8	RW	<b>Wait Duration in HFXO Startup Steady Wait State</b>
Wait duration depends on the chosen XTAL (expected value is around 100 us). Program the desired duration measured in cycles of (at least) 83 ns.				

Value	Mode	Description

Bit	Name	Reset	Access	Description
0	2CYCLES			Timeout period of 2 cycles
1	4CYCLES			Timeout period of 4 cycles
2	16CYCLES			Timeout period of 16 cycles
3	32CYCLES			Timeout period of 32 cycles
4	64CYCLES			Timeout period of 64 cycles
5	128CYCLES			Timeout period of 128 cycles
6	256CYCLES			Timeout period of 256 cycles
7	1KCYCLES			Timeout period of 1024 cycles
8	2KCYCLES			Timeout period of 2048 cycles
9	4KCYCLES			Timeout period of 4096 cycles
10	8KCYCLES			Timeout period of 8192 cycles
11	16KCYCLES			Timeout period of 16384 cycles
12	32KCYCLES			Timeout period of 32768 cycles
13	64KCYCLES			Timeout period of 65536 cycles
14	128KCYCLES			Timeout period of 131072 cycles

**3:0 STARTUPTIMEOUT 0xE RW Wait Duration in HFXO Startup Enable Wait State**

Wait duration depends on the chosen XTAL (expected value is between 100 us and 1600 us). Program the desired duration measured in cycles of (at least) 83 ns.

Value	Mode	Description
0	2CYCLES	Timeout period of 2 cycles
1	4CYCLES	Timeout period of 4 cycles
2	16CYCLES	Timeout period of 16 cycles
3	32CYCLES	Timeout period of 32 cycles
4	64CYCLES	Timeout period of 64 cycles
5	128CYCLES	Timeout period of 128 cycles
6	256CYCLES	Timeout period of 256 cycles
7	1KCYCLES	Timeout period of 1024 cycles
8	2KCYCLES	Timeout period of 2048 cycles
9	4KCYCLES	Timeout period of 4096 cycles
10	8KCYCLES	Timeout period of 8192 cycles
11	16KCYCLES	Timeout period of 16384 cycles
12	32KCYCLES	Timeout period of 32768 cycles
13	64KCYCLES	Timeout period of 65536 cycles
14	128KCYCLES	Timeout period of 131072 cycles

## 10.5.10 CMU\_LFXOCTRL - LFXO Control Register

Offset	Bit Position																	
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	0	
<b>Reset</b>							0x7					0	0x0				0x00	
<b>Access</b>				RW					RW			RW		RW			RW	
<b>Name</b>				TIMEOUT					BUFCUR			CUR		AGC		HIGHAMPL		TUNING

Bit	Name	Reset	Access	Description
31:27	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
26:24	TIMEOUT	0x7	RW	<b>LFXO Timeout</b>
		Configures the start-up delay for LFXO. Do not change while LFXO is enabled. When starting up the LFXO after it has been completely turned off, use the TIMEOUT setting required by the XTAL. If the LFXO has been retained on in EM4, then the TIMEOUT=2cycles configuration is also allowed when re-enabling the LFXO after EM4 exit (as it is still running).		
	Value	Mode	Description	
	0	2CYCLES	Timeout period of 2 cycles	
	1	256CYCLES	Timeout period of 256 cycles	
	2	1KCYCLES	Timeout period of 1024 cycles	
	3	2KCYCLES	Timeout period of 2048 cycles	
	4	4KCYCLES	Timeout period of 4096 cycles	
	5	8KCYCLES	Timeout period of 8192 cycles	
	6	16KCYCLES	Timeout period of 16384 cycles	
	7	32KCYCLES	Timeout period of 32768 cycles	
23:21	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
20	BUFCUR	0	RW	<b>LFXO Buffer Bias Current</b>
	The default value is intended to cover all use cases and reprogramming is not recommended. Do not change while LFXO is enabled.			
19:18	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
17:16	CUR	0x0	RW	<b>LFXO Current Trim</b>
	The default value is intended to cover all use cases and reprogramming is not recommended. Do not change while LFXO is enabled.			
15	AGC	1	RW	<b>LFXO AGC Enable</b>
	Set this bit to enable automatic gain control which limits XTAL oscillation amplitude. Do not change while LFXO is enabled.			
14	HIGHAMPL	0	RW	<b>LFXO High XTAL Oscillation Amplitude Enable</b>
	Set this bit to enable high XTAL oscillation amplitude. Do not change while LFXO is enabled.			
13	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

Bit	Name	Reset	Access	Description
12:11	GAIN	0x2	RW	<b>LFXO Startup Gain</b>  The optimal value for maximum startup margin depends on the chosen XTAL. Refer to the device data sheet or Simplicity Studio for more information.
10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9:8	MODE	0x0	RW	<b>LFXO Mode</b>  Set this to configure the external source for the LFXO. Do not change while LFXO is enabled. The oscillator setting takes effect when 1 is written to LFXOEN in CMU_OSCENCMD. The oscillator setting is reset to default when 1 is written to LFXODIS in CMU_OSCENCMD.
	Value	Mode		Description
	0	XTAL		32768 Hz crystal oscillator
	1	BUFEXTCLK		An AC coupled buffer is coupled in series with LFXTAL_N pin, suitable for external sinus wave (32768 Hz).
	2	DIGEXTCLK		Digital external clock on LFXTAL_N pin. Oscillator is effectively bypassed.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:0	TUNING	0x00	RW	<b>LFXO Internal Capacitor Array Tuning Value</b>  Writing this field adjusts the internal load capacitance connected between LFXTAL_P and ground and LFXTAL_N and ground symmetrically (the higher the value, the higher the capacitance, the lower the frequency). Only increment or decrement by 1 LSB at a time.

## 10.5.11 CMU\_DPLLCTRL - DPLL Control Register

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0	0x0	0	0	0			
Access																									RW	0	0	0	0			
Name																									DITHEN	REFSEL	AUTORECOVER	EDGESEL	MODE			

Bit	Name	Reset	Access	Description
31:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6	DITHEN	0	RW	<b>Dither Enable Control</b>
	Set to enable the dither function			
5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4:3	REFSEL	0x0	RW	<b>Reference Clock Selection Control</b>
	This field selects which clock as the reference clock			
	Value	Mode	Description	
	0	HFXO	HFXO selected	
	1	LFXO	LFXO selected	
	3	CLKIN0	CLKIN0 selected	
2	AUTORECOVER	0	RW	<b>Automatic Recovery Ctrl</b>
	Set to enable automatic recovery function.			
1	EDGESEL	0	RW	<b>Reference Edge Select</b>
	This bit controls which edge of reference is detected			
	Value	Mode	Description	
	0	FALL	Falling edge	
	1	RISE	Rising edge	
0	MODE	0	RW	<b>Operating Mode Control</b>
	This bit controls which mode DPLL is operating when enabled			
	Value	Mode	Description	
	0	FREQLL	DPLL operates in frequency-lock mode.	
	1	PHASELL	DPLL operates in phase-lock mode.	

## 10.5.12 CMU\_DPLLCTRL1 - DPLL Control Register

Offset	Bit Position																															
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x000																0x000															
Access	RW																RW															
Name	N																M															

Bit	Name	Reset	Access	Description
31:28	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
27:16	N	0x000	RW	<b>Factor N</b>  The locked DCO frequency is given by: $F_{DCO} = F_{REF} * (N + 1) / (M + 1)$ . N is required to be larger than 32.
15:12	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
11:0	M	0x000	RW	<b>Factor M</b>  The locked DCO frequency is given by: $F_{DCO} = F_{REF} * (N + 1) / (M + 1)$ . M can be any value.

## 10.5.13 CMU\_CALCTRL - Calibration Control Register

Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset					0x0					0x0					0x0					0	0x0					0x0						
Access					RW					RW					RW					RW	0x0					RW						
Name					PRSDOWNSEL					PRSUPSEL					CONT					DOWNSEL					UPSEL							

Bit	Name	Reset	Access	Description
31:27	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
26:24	PRSDOWNSEL	0x0	RW	<b>PRS Select for PRS Input When Selected in DOWNSEL</b>
	Select PRS input for PRS based calibration. Only change when calibration circuit is off.			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected as input	
	1	PRSCH1	PRS Channel 1 selected as input	
	2	PRSCH2	PRS Channel 2 selected as input	
	3	PRSCH3	PRS Channel 3 selected as input	
	4	PRSCH4	PRS Channel 4 selected as input	
	5	PRSCH5	PRS Channel 5 selected as input	
	6	PRSCH6	PRS Channel 6 selected as input	
	7	PRSCH7	PRS Channel 7 selected as input	
23:19	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
18:16	PRSUPSEL	0x0	RW	<b>PRS Select for PRS Input When Selected in UPSEL</b>
	Select PRS input for PRS based calibration. Only change when calibration circuit is off.			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected as input	
	1	PRSCH1	PRS Channel 1 selected as input	
	2	PRSCH2	PRS Channel 2 selected as input	
	3	PRSCH3	PRS Channel 3 selected as input	
	4	PRSCH4	PRS Channel 4 selected as input	
	5	PRSCH5	PRS Channel 5 selected as input	
	6	PRSCH6	PRS Channel 6 selected as input	
	7	PRSCH7	PRS Channel 7 selected as input	

Bit	Name	Reset	Access	Description
15:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8	CONT	0	RW	<b>Continuous Calibration</b>  Set this bit to enable continuous calibration
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	DOWNSEL	0x0	RW	<b>Calibration Down-counter Select</b>  Selects clock source for the calibration down-counter. Only change when calibration circuit is off.
	Value	Mode		Description
	0	HFCLK		Select HFCLK for down-counter
	1	HFXO		Select HFXO for down-counter
	2	LFXO		Select LFXO for down-counter
	3	HFRCO		Select HFRCO for down-counter
	4	LFRCO		Select LFRCO for down-counter
	5	AUXHFRCO		Select AUXHFRCO for down-counter
	6	PRS		Select PRS input selected by PRSDOWNSEL as down-counter
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	UPSEL	0x0	RW	<b>Calibration Up-counter Select</b>  Selects clock source for the calibration up-counter. Only change when calibration circuit is off.
	Value	Mode		Description
	0	HFXO		Select HFXO as up-counter
	1	LFXO		Select LFXO as up-counter
	2	HFRCO		Select HFRCO as up-counter
	3	LFRCO		Select LFRCO as up-counter
	4	AUXHFRCO		Select AUXHFRCO as up-counter
	5	PRS		Select PRS input selected by PRSUPSEL as up-counter

## 10.5.14 CMU\_CALCNT - Calibration Counter Register

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:20	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
19:0	CALCNT	0x00000	RWH	<b>Calibration Counter</b>

Write top value before calibration. Read calibration result from this register when Calibration Ready flag has been set.

## 10.5.15 CMU\_OSCENCMD - Oscillator Enable/Disable Command Register

Offset	Bit Position																	
0x060	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14
Reset																	W1	0
Access																	W1	0
Name																	DPLLDIS	LFXODIS
																	DPLLEN	LFXOEN
																		LFRCODIS
																		LFRCOEN
																		AUXHFRCODIS
																		AUXHFRCOEN
																		HFXODIS
																		HFXOEN
																		HFRCODIS
																		HFRCOEN

Bit	Name	Reset	Access	Description
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13	DPLLDIS	0	W1	<b>DPLL Disable</b>  Disables the DPLL.
12	DPLLEN	0	W1	<b>DPLL Enable</b>  Enables the DPLL.
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	LFXODIS	0	W1	<b>LFXO Disable</b>  Disables the LFXO. LFXOEN has higher priority if written simultaneously. WARNING: Do not disable the LFXO if this oscillator is selected as the source for HFCLK. When waking up from EM4 make sure EM4UNLATCH in EMU_CMD is set for this to take effect
8	LFXOEN	0	W1	<b>LFXO Enable</b>  Enables the LFXO. When waking up from EM4 make sure EM4UNLATCH in EMU_CMD is set for this to take effect
7	LFRCODIS	0	W1	<b>LFRCO Disable</b>  Disables the LFRCO. LFRCOEN has higher priority if written simultaneously. WARNING: Do not disable the LFRCO if this oscillator is selected as the source for HFCLK. When waking up from EM4 make sure EM4UNLATCH in EMU_CMD is set for this to take effect
6	LFRCOEN	0	W1	<b>LFRCO Enable</b>  Enables the LFRCO. When waking up from EM4 make sure EM4UNLATCH in EMU_CMD is set for this to take effect
5	AUXHFRCODIS	0	W1	<b>AUXHFRCO Disable</b>  Disables the AUXHFRCO. AUXHFRCOEN has higher priority if written simultaneously.
4	AUXHFRCOEN	0	W1	<b>AUXHFRCO Enable</b>  Enables the AUXHFRCO.
3	HFXODIS	0	W1	<b>HFXO Disable</b>  Disables the HFXO. HFXOEN has higher priority if written simultaneously. WARNING: Do not disable the HFXO if this oscillator is selected as the source for HFCLK.
2	HFXOEN	0	W1	<b>HFXO Enable</b>  Enables the HFXO.

Bit	Name	Reset	Access	Description
1	HFRCODIS	0	W1	<b>HFRCO Disable</b>  Disables the HFRCO. HFRCOEN has higher priority if written simultaneously. WARNING: Do not disable the HFRCO if this oscillator is selected as the source for HFCLK.
0	HFRCOEN	0	W1	<b>HFRCO Enable</b>  Enables the HFRCO.

### **10.5.16 CMU\_CMD - Command Register**

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	HFXOPEAKDET-START	0	W1	<b>HFXO Peak Detection Start</b>
				Starts the HFXO peak detection and runs it one time.
3:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	CALSTOP	0	W1	<b>Calibration Stop</b>
				Stops the calibration counters.
0	CALSTART	0	W1	<b>Calibration Start</b>
				Starts the calibration, effectively loading the CMU_CALCNT into the down-counter and start decrementing.

#### **10.5.17 CMU\_DBGCLKSEL - Debug Trace Clock Select**

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	DBG	0x0	RW	<b>Debug Trace Clock</b>  Select clock used for debug trace.
<hr/>				
Value	Mode	Description		
0	AUXHFRCO	AUXHFRCO is the debug trace clock		
1	HFCLK	HFCLK is the debug trace clock		
2	HFRCODIV2	HFRCO divided by 2 is the debug trace clock		

## 10.5.18 CMU\_HFCLKSEL - High Frequency Clock Select Command Register

Offset	Bit Position																																	
0x074	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
<b>Reset</b>																																0x0		
<b>Access</b>																																	W1	
<b>Name</b>																																		HF

Bit	Name	Reset	Access	Description
31:3	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

2:0 HF 0x0 W1 **HFCLK Select**

Selects the clock source for HFCLK. Note that selecting an oscillator that is disabled will cause the system clock to stop. Check the status register and confirm that oscillator is ready before switching. If the system can deal with a temporarily stopped system clock, then it is okay to switch to an oscillator as soon as the status register indicates that the oscillator has been enabled successfully.

Value	Mode	Description
1	HFRCO	Select HFRCO as HFCLK
2	HFXO	Select HFXO as HFCLK
3	LFRCO	Select LFRCO as HFCLK
4	LFXO	Select LFXO as HFCLK
5	HFRCODIV2	Select HFRCO divided by 2 as HFCLK
7	CLKIN0	Select CLKIN0 as HFCLK

## 10.5.19 CMU\_LFACLKSEL - Low Frequency A Clock Select Register

Offset	Bit Position																											
0x080	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
Reset																												0x0
Access																												RW
Name																												LFA

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	LFA	0x0	RW	<b>Clock Select for LFA</b>
	Selects the clock source for LFACLK.			
	Value	Mode		Description
	0	DISABLED		LFACLK is disabled
	1	LFRCO		LFRCO selected as LFACLK
	2	LFXO		LFXO selected as LFACLK
	4	ULFRCO		ULFRCO selected as LFACLK

## 10.5.20 CMU\_LFBCLKSEL - Low Frequency B Clock Select Register

Offset	Bit Position																											
0x084	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											0x0
Reset																												RW
Access																												LFB
Name																												

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	LFB	0x0	RW	<b>Clock Select for LFB</b>
	Selects the clock source for LFBCLK.			
	Value	Mode		Description
	0	DISABLED		LFBCLK is disabled
	1	LFRCO		LFRCO selected as LFBCLK
	2	LFXO		LFXO selected as LFBCLK
	3	HFCLKLE		HFCLK divided by two/four is selected as LFBCLK
	4	ULFRCO		ULFRCO selected as LFBCLK

## 10.5.21 CMU\_LFECLKSEL - Low Frequency E Clock Select Register

Offset	Bit Position																											
0x088	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
Reset																												0x0
Access																												RW
Name																												LFE

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2:0	LFE	0x0	RW	<b>Clock Select for LFE</b>

Selects the clock source for LFECLK. When waking up from EM4 make sure EM4UNLATCH in EMU\_CMD is set for this to take effect

Value	Mode	Description
0	DISABLED	LFECLK is disabled
1	LFRCO	LFRCO selected as LFECLK
2	LFXO	LFXO selected as LFECLK
4	ULFRCO	ULFRCO selected as LFECLK

#### **10.5.22 CMU STATUS - Status Register**

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	ULFRCOPHASE	0	R	<b>ULFRCO Clock Phase</b> Used to determine if ULFRCO is in high or low phase.
28	LFRCOPHASE	0	R	<b>LFRCO Clock Phase</b> Used to determine if LFRCO is in high or low phase.
27	LFXOPHASE	0	R	<b>LFXO Clock Phase</b> Used to determine if LFXO is in high or low phase.
26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25	HFXOAMPLOW	0	R	<b>HFXO Amplitude Tuning Value Too Low</b> HFXO oscillation amplitude is too low. When using PEAKDETHUNTOPTMODE=MANUAL, the IBTRIMXOCORE value in CMU_HFXOSTEADYSTATECTRL should be tuned up by 1 LSB.
24:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22	HFXOPEAKDET RDY	0	R	<b>HFXO Peak Detection Ready</b> HFXO peak detection is ready.
21:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	CALRDY	1	R	<b>Calibration Ready</b> Calibration is Ready (0 when calibration is ongoing).
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13	DPLL RDY	0	R	<b>DPLL Ready</b> DPLL is enabled and locked
12	DPLLENS	0	R	<b>DPLL Enable Status</b> DPLL is enabled
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
9	LFXORDY	0	R	<b>LFXO Ready</b>  LFXO is enabled and start-up time has exceeded.
8	LFXOENS	0	R	<b>LFXO Enable Status</b>  LFXO is enabled (shows disabled status if EM4 repaint is required).
7	LFRCORDY	0	R	<b>LFRCO Ready</b>  LFRCO is enabled and start-up time has exceeded.
6	LFRCOENS	0	R	<b>LFRCO Enable Status</b>  LFRCO is enabled (shows disabled status if EM4 repaint is required).
5	AUXHFRCORDY	0	R	<b>AUXHFRCO Ready</b>  AUXHFRCO is enabled and start-up time has exceeded.
4	AUXHFRCOENS	0	R	<b>AUXHFRCO Enable Status</b>  AUXHFRCO is enabled.
3	HFXORDY	0	R	<b>HFXO Ready</b>  HFXO is enabled and start-up time has exceeded.
2	HFXOENS	0	R	<b>HFXO Enable Status</b>  HFXO is enabled.
1	HFRCORDY	1	R	<b>HFRCO Ready</b>  HFRCO is enabled and start-up time has exceeded.
0	HFRCOENS	1	R	<b>HFRCO Enable Status</b>  HFRCO is enabled.

## 10.5.23 CMU\_HFCLKSTATUS - HFCLK Status Register

Offset	Bit Position																															
0x094	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x1																															
Access																														R		
Name																															SELECTED	

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2:0	SELECTED	0x1	R	<b>HFCLK Selected</b>

Clock selected as HFCLK clock source.

Value	Mode	Description
1	HFRCO	HFRCO is selected as HFCLK clock source
2	HFXO	HFXO is selected as HFCLK clock source
3	LFRCO	LFRCO is selected as HFCLK clock source
4	LFXO	LFXO is selected as HFCLK clock source
5	HFRCODIV2	HFRCO divided by 2 is selected as HFCLK clock source
7	CLKIN0	CLKIN0 is selected as HFCLK clock source

## 10.5.24 CMU\_HFXOTRIMSTATUS - HFXO Trim Status

Offset	Bit Position																																		
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset	0	0																																	
Access	R	R																													R				
Name	MONVALID	VALID																													IBTRIMXOCORE				
Bit	Name	Reset	Access	Description																															
31	MONVALID	0	R	Peak Detection Algorithm or Peak Monitoring Algorithm Found a Value for IBTRIMXOCOREMON																															
30	VALID	0	R	Peak Detection Algorithm Found a Value for IBTRIMXOCORE																															
29:27	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																															
26:16	IBTRIMXOCORE-MON	0x000	R	Value of IBTRIMXOCORE Found By Automatic HFXO Peak Detection Algorithm or Peak Monitoring Algorithm (completion of Either Algorithm Will Cause an Update of IBTRIMXOCOREMON)																															
15:11	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																															
10:0	IBTRIMXOCORE	0x000	R	Value of IBTRIMXOCORE Found By Automatic HFXO Peak Detection Algorithm																															
				If HFXO is started again with PEAKDETTMODE=ONCECMD this value will be used as steady state value for the HFXO (instead of the IBTRIMXOCORE value from CMU_HFXOSTEADYSTATECTRL) and peak detection algorithm will be skipped																															

## 10.5.25 CMU\_IF - Interrupt Flag Register

Offset	Bit Position																
0x0A0	31	30	29	28	27	26	25	24	23	22	21	20	19	18			
Reset	0		R	0	R	0											
Access	R			R	R	R											
Name	CMUERR	ULFRCOEDGE	LFRCOEDGE	LFXOEDGE								DPLLLOCKFAILHIGH	R	0	17		
												DPLLLOCKFAILLOW	R	0	16		
												DPLLRDY	R	0	15		
												LFTIMEOUTERR	R	0	14		
												HFRCODIS	R	0	13		
															12		
												HFXOPEAKDETRDY	R	0	11		
															10		
												HFXOAUTOSW	R	0	9		
												HFXODISERR	R	0	8		
															7		
													CALOF	R	0	6	
													CALRDY	R	0	5	
													AUXHFRCORDY	R	0	4	
													LFXORDY	R	0	3	
													LFRCORDY	R	0	2	
													HFXORDY	R	0	1	
													HFRCORDY	R	1	0	

Bit	Name	Reset	Access	Description
31	CMUERR	0	R	<b>CMU Error Interrupt Flag</b>  Set upon illegal CMU write attempt (e.g. writing CMU_LFRCOCTRL while LFRCOBSY is set).
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
29	ULFRCOEDGE	0	R	<b>ULFRCO Clock Edge Detected Interrupt Flag</b>  Sets when ULFRCO clock switches phases.
28	LFRCOEDGE	0	R	<b>LFRCO Clock Edge Detected Interrupt Flag</b>  Sets when LFRCO clock switches phases.
27	LFXOEDGE	0	R	<b>LFXO Clock Edge Detected Interrupt Flag</b>  Sets when LFXO clock switches phases.
26:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
17	DPLLLOCKFAIL-HIGH	0	R	<b>DPLL Lock Failure Low Interrupt Flag</b>  Set when DPLL fail to lock because of period overflow.
16	DPLLLOCKFAILLOW	0	R	<b>DPLL Lock Failure Low Interrupt Flag</b>  Set when DPLL fail to lock because of period underflow.
15	DPLLRDY	0	R	<b>DPLL Lock Interrupt Flag</b>  Set when DPLL achieve the lock.
14	LFTIMEOUTERR	0	R	<b>Low Frequency Timeout Error Interrupt Flag</b>  Set when LFTIMEOUT of CMU_HFXOCTRL triggers before the combined STARTUPTIMEOUT plus STEADYTIMEOUT of the CMU_HFXOTIMEOUTCTRL register triggers.
13	HFRCODIS	0	R	<b>HFRCO Disable Interrupt Flag</b>  Set when a running HFRCO is disabled because of automatic HFXO start and selection.
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
11	HFXOPEAKDETRDY	0	R	<b>HFXO Automatic Peak Detection Ready Interrupt Flag</b>  Set when automatic HFXO peak detection is ready.

Bit	Name	Reset	Access	Description
10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	HFXOAUTOSW	0	R	<b>HFXO Automatic Switch Interrupt Flag</b> Set when automatic selection of HFXO causes a switch of the source clock used for HFCLKSRC.
8	HFXODISERR	0	R	<b>HFXO Disable Error Interrupt Flag</b> Set when software tries to disable/deselect the HFXO in case the automatic enable/select reason is met. The HFXO was not disabled/deselected.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	CALOF	0	R	<b>Calibration Overflow Interrupt Flag</b> Set when calibration overflow has occurred (i.e. if a new calibration completes before CMU_CALCNT has been read).
5	CALRDY	0	R	<b>Calibration Ready Interrupt Flag</b> Set when calibration is completed.
4	AUXHFRCORDY	0	R	<b>AUXHFRCO Ready Interrupt Flag</b> Set when AUXHFRCO is ready (start-up time exceeded).
3	LFXORDY	0	R	<b>LFXO Ready Interrupt Flag</b> Set when LFXO is ready (start-up time exceeded). LFXORDY can be used as wake-up interrupt.
2	LFRCORDY	0	R	<b>LFRCO Ready Interrupt Flag</b> Set when LFRCO is ready (start-up time exceeded). LFRCORDY can be used as wake-up interrupt.
1	HFXORDY	0	R	<b>HFXO Ready Interrupt Flag</b> Set when HFXO is ready (start-up time exceeded).
0	HFRCORDY	1	R	<b>HFRCO Ready Interrupt Flag</b> Set when HFRCO is ready (start-up time exceeded).

## 10.5.26 CMU\_IFS - Interrupt Flag Set Register

Offset	Bit Position																									
0x0A4	31	30	29	28	27	26	25	24	23	22	21	20	19	18												
Reset	W1	0																								
Access	W1	0																								
Name	CMUERR		ULFRCOEDGE	LFRCOEDGE	LFXOEDGE							DPLLLOCKFAILHIGH	DPLLLOCKFAILLOW	DPLLRDY	LFTIMEOUTERR	HFRCODIS	HFXOPEAKDETRDY	HFXOAUTOSW	HFXODISERR	CALOF	CALRDY	AUXHFRCORDY	LFXORDY	LFRCORDY	HFXORDY	HFRCORDY
Bit	Name	Reset	Access	Description																						
31	CMUERR	0	W1	<b>Set CMUERR Interrupt Flag</b>																						
				Write 1 to set the CMUERR interrupt flag																						
30	Reserved				<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																					
29	ULFRCOEDGE	0	W1	<b>Set ULFRCOEDGE Interrupt Flag</b>																						
				Write 1 to set the ULFRCOEDGE interrupt flag																						
28	LFRCOEDGE	0	W1	<b>Set LFRCOEDGE Interrupt Flag</b>																						
				Write 1 to set the LFRCOEDGE interrupt flag																						
27	LFXOEDGE	0	W1	<b>Set LFXOEDGE Interrupt Flag</b>																						
				Write 1 to set the LFXOEDGE interrupt flag																						
26:18	Reserved				<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																					
17	DPLLLOCKFAIL-HIGH	0	W1	<b>Set DPLLLOCKFAILHIGH Interrupt Flag</b>																						
				Write 1 to set the DPLLLOCKFAILHIGH interrupt flag																						
16	DPLLLOCKFAILLOW	0	W1	<b>Set DPLLLOCKFAILLOW Interrupt Flag</b>																						
				Write 1 to set the DPLLLOCKFAILLOW interrupt flag																						
15	DPLLRDY	0	W1	<b>Set DPLLRDY Interrupt Flag</b>																						
				Write 1 to set the DPLLRDY interrupt flag																						
14	LFTIMEOUTERR	0	W1	<b>Set LFTIMEOUTERR Interrupt Flag</b>																						
				Write 1 to set the LFTIMEOUTERR interrupt flag																						
13	HFRCODIS	0	W1	<b>Set HFRCODIS Interrupt Flag</b>																						
				Write 1 to set the HFRCODIS interrupt flag																						
12	Reserved				<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																					
11	HFXOPEAKDETRDY	0	W1	<b>Set HFXOPEAKDETRDY Interrupt Flag</b>																						
				Write 1 to set the HFXOPEAKDETRDY interrupt flag																						

Bit	Name	Reset	Access	Description
10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	HFXOAUTOSW	0	W1	<b>Set HFXOAUTOSW Interrupt Flag</b> Write 1 to set the HFXOAUTOSW interrupt flag
8	HFXODISERR	0	W1	<b>Set HFXODISERR Interrupt Flag</b> Write 1 to set the HFXODISERR interrupt flag
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	CALOF	0	W1	<b>Set CALOF Interrupt Flag</b> Write 1 to set the CALOF interrupt flag
5	CALRDY	0	W1	<b>Set CALRDY Interrupt Flag</b> Write 1 to set the CALRDY interrupt flag
4	AUXHFRCORDY	0	W1	<b>Set AUXHFRCORDY Interrupt Flag</b> Write 1 to set the AUXHFRCORDY interrupt flag
3	LFXORDY	0	W1	<b>Set LFXORDY Interrupt Flag</b> Write 1 to set the LFXORDY interrupt flag
2	LFRCORDY	0	W1	<b>Set LFRCORDY Interrupt Flag</b> Write 1 to set the LFRCORDY interrupt flag
1	HFXORDY	0	W1	<b>Set HFXORDY Interrupt Flag</b> Write 1 to set the HFXORDY interrupt flag
0	HFRCORDY	0	W1	<b>Set HFRCORDY Interrupt Flag</b> Write 1 to set the HFRCORDY interrupt flag

## 10.5.27 CMU\_IFC - Interrupt Flag Clear Register

Offset	Bit Position													
0x0A8	31	30	29	28	27	26	25	24	23	22	21	20	19	18
Reset	(R)W1	0	(R)W1	0	(R)W1	0	(R)W1	0	(R)W1	0	(R)W1	0	(R)W1	0
Access														
Name	CMUERR	ULFRCOEDGE	LFRCOEDGE	LFXOEDGE			DPLLLOCKFAILHIGH	(R)W1	0	17	DPLLLOCKFAILLOW	(R)W1	0	16
							DPLLRDY	(R)W1	0	15	LFTIMEOUTERR	(R)W1	0	14
							HFRCODIS	(R)W1	0	13	HFXOPEAKDET RDY	(R)W1	0	12
Bit	Name	Reset	Access	Description										
31	CMUERR	0	(R)W1	<b>Clear CMUERR Interrupt Flag</b>										
				Write 1 to clear the CMUERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>										
29	ULFRCOEDGE	0	(R)W1	<b>Clear ULFRCOEDGE Interrupt Flag</b>										
				Write 1 to clear the ULFRCOEDGE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
28	LFRCOEDGE	0	(R)W1	<b>Clear LFRCOEDGE Interrupt Flag</b>										
				Write 1 to clear the LFRCOEDGE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
27	LFXOEDGE	0	(R)W1	<b>Clear LFXOEDGE Interrupt Flag</b>										
				Write 1 to clear the LFXOEDGE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
26:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>										
17	DPLLLOCKFAIL-HIGH	0	(R)W1	<b>Clear DPLLLOCKFAILHIGH Interrupt Flag</b>										
				Write 1 to clear the DPLLLOCKFAILHIGH interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
16	DPLLLOCKFAILLOW	0	(R)W1	<b>Clear DPLLLOCKFAILLOW Interrupt Flag</b>										
				Write 1 to clear the DPLLLOCKFAILLOW interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
15	DPLLRDY	0	(R)W1	<b>Clear DPLLRDY Interrupt Flag</b>										
				Write 1 to clear the DPLLRDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										
14	LFTIMEOUTERR	0	(R)W1	<b>Clear LFTIMEOUTERR Interrupt Flag</b>										
				Write 1 to clear the LFTIMEOUTERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).										

Bit	Name	Reset	Access	Description
13	HFRCODIS	0	(R)W1	<b>Clear HFRCODIS Interrupt Flag</b>  Write 1 to clear the HFRCODIS interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	HFXOPEAKDETRDY	0	(R)W1	<b>Clear HFXOPEAKDETRDY Interrupt Flag</b>  Write 1 to clear the HFXOPEAKDETRDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	HFXOAUTOSW	0	(R)W1	<b>Clear HFXOAUTOSW Interrupt Flag</b>  Write 1 to clear the HFXOAUTOSW interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	HFXODISERR	0	(R)W1	<b>Clear HFXODISERR Interrupt Flag</b>  Write 1 to clear the HFXODISERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	CALOF	0	(R)W1	<b>Clear CALOF Interrupt Flag</b>  Write 1 to clear the CALOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	CALRDY	0	(R)W1	<b>Clear CALRDY Interrupt Flag</b>  Write 1 to clear the CALRDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	AUXHFRCORDY	0	(R)W1	<b>Clear AUXHFRCORDY Interrupt Flag</b>  Write 1 to clear the AUXHFRCORDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	LFXORDY	0	(R)W1	<b>Clear LFXORDY Interrupt Flag</b>  Write 1 to clear the LFXORDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	LFRCORDY	0	(R)W1	<b>Clear LFRCORDY Interrupt Flag</b>  Write 1 to clear the LFRCORDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	HFXORDY	0	(R)W1	<b>Clear HFXORDY Interrupt Flag</b>  Write 1 to clear the HFXORDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	HFRCORDY	0	(R)W1	<b>Clear HFRCORDY Interrupt Flag</b>  Write 1 to clear the HFRCORDY interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 10.5.28 CMU\_IEN - Interrupt Enable Register

Offset	Bit Position														
0x0AC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	
Reset	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	
Access	RW														
Name	CMUERR	ULFRCOEDGE	LFRCOEDGE	LFXOEDGE											
DPLLLOCKFAILHIGH	RW	0	17	DPLLLOCKFAILLOW	RW	0	16	DPLLRDY	RW	0	15	LFTIMEOUTERR	RW	0	14
HFRCODIS	RW	0	13												12
HFXOPEAKDETRDY	RW	0	11												10
HFXOAUTOSW	RW	0	9												7
HFXODISERR	RW	0	8												6
CALOF	RW	0	6												5
CALRDY	RW	0	5												4
AUXHFRCORDY	RW	0	4												3
LFXORDY	RW	0	3												2
LFRCORDY	RW	0	2												1
HFXORDY	RW	0	1												0
HFRCORDY	RW	0	0												0

Bit	Name	Reset	Access	Description
31	CMUERR	0	RW	<b>CMUERR Interrupt Enable</b>  Enable/disable the CMUERR interrupt
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	ULFRCOEDGE	0	RW	<b>ULFRCOEDGE Interrupt Enable</b>  Enable/disable the ULFRCOEDGE interrupt
28	LFRCOEDGE	0	RW	<b>LFRCOEDGE Interrupt Enable</b>  Enable/disable the LFRCOEDGE interrupt
27	LFXOEDGE	0	RW	<b>LFXOEDGE Interrupt Enable</b>  Enable/disable the LFXOEDGE interrupt
26:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	DPLLLOCKFAIL-HIGH	0	RW	<b>DPLLLOCKFAILHIGH Interrupt Enable</b>  Enable/disable the DPLLLOCKFAILHIGH interrupt
16	DPLLLOCKFAILLOW	0	RW	<b>DPLLLOCKFAILLOW Interrupt Enable</b>  Enable/disable the DPLLLOCKFAILLOW interrupt
15	DPLLRDY	0	RW	<b>DPLLRDY Interrupt Enable</b>  Enable/disable the DPLLRDY interrupt
14	LFTIMEOUTERR	0	RW	<b>LFTIMEOUTERR Interrupt Enable</b>  Enable/disable the LFTIMEOUTERR interrupt
13	HFRCODIS	0	RW	<b>HFRCODIS Interrupt Enable</b>  Enable/disable the HFRCODIS interrupt
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	HFXOPEAKDETRDY	0	RW	<b>HFXOPEAKDETRDY Interrupt Enable</b>  Enable/disable the HFXOPEAKDETRDY interrupt

Bit	Name	Reset	Access	Description
10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	HFXOAUTOSW	0	RW	<b>HFXOAUTOSW Interrupt Enable</b> Enable/disable the HFXOAUTOSW interrupt
8	HFXODISERR	0	RW	<b>HFXODISERR Interrupt Enable</b> Enable/disable the HFXODISERR interrupt
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	CALOF	0	RW	<b>CALOF Interrupt Enable</b> Enable/disable the CALOF interrupt
5	CALRDY	0	RW	<b>CALRDY Interrupt Enable</b> Enable/disable the CALRDY interrupt
4	AUXHFRCORDY	0	RW	<b>AUXHFRCORDY Interrupt Enable</b> Enable/disable the AUXHFRCORDY interrupt
3	LFXORDY	0	RW	<b>LFXORDY Interrupt Enable</b> Enable/disable the LFXORDY interrupt
2	LFRCORDY	0	RW	<b>LFRCORDY Interrupt Enable</b> Enable/disable the LFRCORDY interrupt
1	HFXORDY	0	RW	<b>HFXORDY Interrupt Enable</b> Enable/disable the HFXORDY interrupt
0	HFRCORDY	0	RW	<b>HFRCORDY Interrupt Enable</b> Enable/disable the HFRCORDY interrupt

## 10.5.29 CMU\_HFBUSCLKEN0 - High Frequency Bus Clock Enable Register 0

Offset	Bit Position																									
0x0B0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
Reset																										
Access																										
Name																										

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	GPCRC	0	RW	<b>General Purpose CRC Clock Enable</b>  Set to enable the clock for GPCRC.
4	LDMA	0	RW	<b>Linked Direct Memory Access Controller Clock Enable</b>  Set to enable the clock for LDMA.
3	PRS	0	RW	<b>Peripheral Reflex System Clock Enable</b>  Set to enable the clock for PRS.
2	GPIO	0	RW	<b>General purpose Input/Output Clock Enable</b>  Set to enable the clock for GPIO.
1	CRYPTO0	0	RW	<b>Advanced Encryption Standard Accelerator Clock Enable</b>  Set to enable the clock for CRYPTO0.
0	LE	0	RW	<b>Low Energy Peripheral Interface Clock Enable</b>  Set to enable the clock for LE. Interface used for bus access to Low Energy peripherals.

## 10.5.30 CMU\_HFPERCLKEN0 - High Frequency Peripheral Clock Enable Register 0

Offset	Bit Position																											
0x0C0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13									
Reset																0	0	11	0									
Access																RW	RW	RW	RW									
Name																TRNG0	ADC0	CRYOTIMER	ACMP1	ACMP0	I2C1	I2C0	TIMER1	TIMER0	USART3	USART2	USART1	USART0

Bit	Name	Reset	Access	Description
31:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	TRNG0	0	RW	<b>True Random Number Generator 0 Clock Enable</b>  Set to enable the clock for TRNG0.
11	ADC0	0	RW	<b>Analog to Digital Converter 0 Clock Enable</b>  Set to enable the clock for ADC0.
10	CRYOTIMER	0	RW	<b>CRYOTIMER Clock Enable</b>  Set to enable the clock for CRYOTIMER.
9	ACMP1	0	RW	<b>Analog Comparator 1 Clock Enable</b>  Set to enable the clock for ACMP1.
8	ACMP0	0	RW	<b>Analog Comparator 0 Clock Enable</b>  Set to enable the clock for ACMP0.
7	I2C1	0	RW	<b>I2C 1 Clock Enable</b>  Set to enable the clock for I2C1.
6	I2C0	0	RW	<b>I2C 0 Clock Enable</b>  Set to enable the clock for I2C0.
5	TIMER1	0	RW	<b>Timer 1 Clock Enable</b>  Set to enable the clock for TIMER1.
4	TIMER0	0	RW	<b>Timer 0 Clock Enable</b>  Set to enable the clock for TIMER0.
3	USART3	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 3 Clock Enable</b>  Set to enable the clock for USART3.
2	USART2	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 2 Clock Enable</b>  Set to enable the clock for USART2.
1	USART1	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 1 Clock Enable</b>  Set to enable the clock for USART1.

Bit	Name	Reset	Access	Description
0	USART0	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 0 Clock Enable</b>  Set to enable the clock for USART0.

### 10.5.31 CMU\_HFPERCLKEN1 - High Frequency Peripheral Clock Enable Register 1

Offset	Bit Position																																
0x0C4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	CSEN	RW	0	5			
Reset																														VDAC0	RW	0	4
Access																														CAN0	RW	0	3
Name																														WTIMER1	RW	0	2
																														WTIMER0	RW	0	1
																														UART0	RW	0	0

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	CSEN	0	RW	<b>Capacitive touch sense module Clock Enable</b>  Set to enable the clock for CSEN.
4	VDAC0	0	RW	<b>Digital to Analog Converter 0 Clock Enable</b>  Set to enable the clock for VDAC0.
3	CAN0	0	RW	<b>CAN 0 Clock Enable</b>  Set to enable the clock for CAN0.
2	WTIMER1	0	RW	<b>Wide Timer 1 Clock Enable</b>  Set to enable the clock for WTIMER1.
1	WTIMER0	0	RW	<b>Wide Timer 0 Clock Enable</b>  Set to enable the clock for WTIMER0.
0	UART0	0	RW	<b>Universal Asynchronous Receiver/Transmitter 0 Clock Enable</b>  Set to enable the clock for UART0.

## 10.5.32 CMU\_LFACLKEN0 - Low Frequency a Clock Enable Register 0 (Async Reg)

Offset	Bit Position																																	
0x0E0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																		
Access																																		
Name																																		

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	LCD	0	RW	<b>Liquid Crystal Display Controller Clock Enable</b>  Set to enable the clock for LCD.
1	LETIMER0	0	RW	<b>Low Energy Timer 0 Clock Enable</b>  Set to enable the clock for LETIMER0.
0	LESENSE	0	RW	<b>Low Energy Sensor Interface Clock Enable</b>  Set to enable the clock for LESENSE.

## 10.5.33 CMU\_LFBCLKEN0 - Low Frequency B Clock Enable Register 0 (Async Reg)

Offset	Bit Position																																	
0x0E8	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																		
Access																																		
Name																																		

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	CSEN	0	RW	<b>Capacitive touch sense module Clock Enable</b>  Set to enable the clock for CSEN.
1	LEUART0	0	RW	<b>Low Energy UART 0 Clock Enable</b>  Set to enable the clock for LEUART0.
0	SYSTICK	0	RW	<b>Clock Enable</b>  Set to enable the clock for SYSTICK.

## 10.5.34 CMU\_LFECLKEN0 - Low Frequency E Clock Enable Register 0 (Async Reg)

Offset	Bit Position																																		
0x0F0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																																			
Access																																			
Name																																			
RTCC	0	RW	<b>Real-Time Counter and Calendar Clock Enable</b>																																

Bit	Name	Reset	Access	Description
31:1	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	RTCC	0	RW	<b>Real-Time Counter and Calendar Clock Enable</b>  Set to enable the clock for RTCC.

## 10.5.35 CMU\_HFPRESC - High Frequency Clock Prescaler Register

Offset	Bit Position																															
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0															
Access																	RW															
Name																	HFCLKLEPRESC															
PRESC																																

Bit	Name	Reset	Access	Description
31:26	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
25:24	HFCLKLEPRESC	0x0	RW	<b>HFCLKLE Prescaler</b>
	Specifies the clock divider for HFCLKLE.			
	Value	Mode	Description	
	0	DIV2	HFCLKLE is HFBUSCLK <sub>LE</sub> divided by 2.	
	1	DIV4	HFCLKLE is HFBUSCLK <sub>LE</sub> divided by 4.	
	2	DIV8	HFCLKLE is HFBUSCLK <sub>LE</sub> divided by 8.	
23:13	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
12:8	PRESC	0x00	RW	<b>HFCLK Prescaler</b>
	Specifies the clock divider for HFCLK (relative to HFSRCCLK).			
	Value	Description		
	PRESC	Clock division factor of PRESC+1.		
7:0	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		

**10.5.36 CMU\_HFBUSPRES - High Frequency Bus Clock Prescaler Register**

Offset	Bit Position																															
0x104	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x000															
Access																	RW															
Name																	PRES															

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16:8	PRES	0x000	RW	<b>HFBUSCLK Prescaler</b>
Specifies the clock divider for the HFBUSCLK (relative to HFCLK).				
Value		Description		
PRES		Clock division factor of PRES+1.		
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

**10.5.37 CMU\_HFCOREPRES - High Frequency Core Clock Prescaler Register**

Offset	Bit Position																															
0x108	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x000															
Access																	RW															
Name																	PRES															
Bit	Name	Reset	Access	Description																												
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																												
16:8	PRES	0x000	RW	<b>HFCORECLK Prescaler</b>																												
Specifies the clock divider for HFCORECLK (relative to HFCLK).																																
Value		Description																														
PRES		Clock division factor of PRES+1.																														
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																												

## 10.5.38 CMU\_HFPERPRES - High Frequency Peripheral Clock Prescaler Register

Offset	Bit Position																															
0x10C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x000															
Access																	RW															
Name																	PRES															

Bit	Name	Reset	Access	Description
31:17	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
16:8	PRESC	0x000	RW	<b>HFPERCLK Prescaler</b>
Specifies the clock divider for the HFPERCLK (relative to HFCLK).				
Value		Description		
PRESC		Clock division factor of PRESC+1.		
7:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		

## 10.5.39 CMU\_HFEXPPRES - High Frequency Export Clock Prescaler Register

Offset	Bit Position																															
0x114	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00															
Access																	RW															
Name																	PRES															

Bit	Name	Reset	Access	Description
31:13	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
12:8	PRESC	0x00	RW	<b>HFEXPCLK Prescaler</b>
Specifies the clock divider for HFEXPCLK (relative to HFCLK).				
Value		Description		
PRESC		Clock division factor of PRESC+1.		
7:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		

## 10.5.40 CMU\_HFPERPRESB - High Frequency Peripheral Clock Prescaler B Register

Offset	Bit Position																															
0x118	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x000															
Access																	RW															
Name																	PRESB															

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
16:8	PRESB	0x000	RW	<b>HFPERCLK Prescaler</b>
Specifies the clock divider for the HFPERCLK (relative to HFCLK).				
Value		Description		
PRESB		Clock division factor of PRESB+1.		
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 10.5.41 CMU\_HFPERPRESCC - High Frequency Peripheral Clock Prescaler C Register

Offset	Bit Position																															
0x11C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x000															
Access																	RW															
Name																	PRESB															
Bit	Name	Reset	Access	Description																												
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																												
16:8	PRESB	0x000	RW	<b>HFPERCLK Prescaler</b>																												
Specifies the clock divider for the HFPERCLK (relative to HFCLK).																																
Value		Description																														
PRESB		Clock division factor of PRESB+1.																														
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																												

## 10.5.42 CMU\_LFAPRESC0 - Low Frequency a Prescaler Register 0 (Async Reg)

Offset	Bit Position																															
0x120	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x0		0x0				
Access																										RW	RW	RW	RW	RW		
Name																										LCD	LETIMER0	LETIMER0	LESENSE	LESENSE		

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10:8	LCD	0x0	RW	<b>Liquid Crystal Display Controller Prescaler</b>
	Configure Liquid Crystal Display Controller prescaler			
	Value	Mode		Description
	0	DIV1		LFACLK <sub>LCD</sub> = LFACLK
	1	DIV2		LFACLK <sub>LCD</sub> = LFACLK/2
	2	DIV4		LFACLK <sub>LCD</sub> = LFACLK/4
	3	DIV8		LFACLK <sub>LCD</sub> = LFACLK/8
	4	DIV16		LFACLK <sub>LCD</sub> = LFACLK/16
	5	DIV32		LFACLK <sub>LCD</sub> = LFACLK/32
	6	DIV64		LFACLK <sub>LCD</sub> = LFACLK/64
	7	DIV128		LFACLK <sub>LCD</sub> = LFACLK/128
7:4	LETIMER0	0x0	RW	<b>Low Energy Timer 0 Prescaler</b>
	Configure Low Energy Timer 0 prescaler			
	Value	Mode		Description
	0	DIV1		LFACLK <sub>LETIMER0</sub> = LFACLK
	1	DIV2		LFACLK <sub>LETIMER0</sub> = LFACLK/2
	2	DIV4		LFACLK <sub>LETIMER0</sub> = LFACLK/4
	3	DIV8		LFACLK <sub>LETIMER0</sub> = LFACLK/8
	4	DIV16		LFACLK <sub>LETIMER0</sub> = LFACLK/16
	5	DIV32		LFACLK <sub>LETIMER0</sub> = LFACLK/32
	6	DIV64		LFACLK <sub>LETIMER0</sub> = LFACLK/64
	7	DIV128		LFACLK <sub>LETIMER0</sub> = LFACLK/128
	8	DIV256		LFACLK <sub>LETIMER0</sub> = LFACLK/256
	9	DIV512		LFACLK <sub>LETIMER0</sub> = LFACLK/512

Bit	Name	Reset	Access	Description
10	DIV1024			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/1024$
11	DIV2048			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/2048$
12	DIV4096			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/4096$
13	DIV8192			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/8192$
14	DIV16384			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/16384$
15	DIV32768			$\text{LFACLK}_{\text{LETIMER}0} = \text{LFACLK}/32768$
3:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	LESENSE	0x0	RW	<b>Low Energy Sensor Interface Prescaler</b>
				Configure Low Energy Sensor Interface prescaler
	Value	Mode		Description
	0	DIV1		$\text{LFACLK}_{\text{LESENSE}} = \text{LFACLK}$
	1	DIV2		$\text{LFACLK}_{\text{LESENSE}} = \text{LFACLK}/2$
	2	DIV4		$\text{LFACLK}_{\text{LESENSE}} = \text{LFACLK}/4$
	3	DIV8		$\text{LFACLK}_{\text{LESENSE}} = \text{LFACLK}/8$

## 10.5.43 CMU\_LFBPRESC0 - Low Frequency B Prescaler Register 0 (Async Reg)

Offset	Bit Position																															
0x128	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x0		0x0					
Access																									RW	RW	RW					
Name																									CSEN	LEUART0	SYSTICK					

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9:8	CSEN	0x0	RW	<b>Capacitive touch sense module Prescaler</b>
		Configure Capacitive touch sense module prescaler		
	Value	Mode	Description	
	0	DIV16	$\text{LFBCLK}_{\text{CSEN}} = \text{LFBCLK}/16$	
	1	DIV32	$\text{LFBCLK}_{\text{CSEN}} = \text{LFBCLK}/32$	
	2	DIV64	$\text{LFBCLK}_{\text{CSEN}} = \text{LFBCLK}/64$	
	3	DIV128	$\text{LFBCLK}_{\text{CSEN}} = \text{LFBCLK}/128$	
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:4	LEUART0	0x0	RW	<b>Low Energy UART 0 Prescaler</b>
		Configure Low Energy UART 0 prescaler		
	Value	Mode	Description	
	0	DIV1	$\text{LFBCLK}_{\text{LEUART0}} = \text{LFBCLK}$	
	1	DIV2	$\text{LFBCLK}_{\text{LEUART0}} = \text{LFBCLK}/2$	
	2	DIV4	$\text{LFBCLK}_{\text{LEUART0}} = \text{LFBCLK}/4$	
	3	DIV8	$\text{LFBCLK}_{\text{LEUART0}} = \text{LFBCLK}/8$	
3:0	SYSTICK	0x0	<b>Prescaler</b>	
		Configure prescaler		
	Value	Mode	Description	
	0	DIV1	$\text{LFBCLK}_{\text{SYSTICK}} = \text{LFBCLK}$	

**10.5.44 CMU\_LFEPRESC0 - Low Frequency E Prescaler Register 0 (Async Reg)**

When waking up from EM4 make sure EM4UNLATCH in EMU\_CMD is set for this to take effect

Offset	Bit Position																															
0x130	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																															
Access	RW																															
Name	RTCC																															

Bit	Name	Reset	Access	Description												
31:2	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
1:0	RTCC	0x0	RW	<b>Real-Time Counter and Calendar Prescaler</b>												
Configure Real-Time Counter and Calendar prescaler																
<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DIV1</td> <td><math>\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}</math></td> </tr> <tr> <td>1</td> <td>DIV2</td> <td><math>\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/2</math></td> </tr> <tr> <td>2</td> <td>DIV4</td> <td><math>\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/4</math></td> </tr> </tbody> </table>					Value	Mode	Description	0	DIV1	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}$	1	DIV2	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/2$	2	DIV4	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/4$
Value	Mode	Description														
0	DIV1	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}$														
1	DIV2	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/2$														
2	DIV4	$\text{LFECLK}_{\text{RTCC}} = \text{LFECLK}/4$														

#### 10.5.45 CMU\_SYNCBUSY - Synchronization Busy Register

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

29 LEXOBSY 0 R LEXO Busy

10 E. R. S. COOPER AND J. C. G. VAN DER HORST

Used to check the synchronization status of CMU\_LFXOCTRL.

Value	Description
0	CMU_LFXOCTRL is ready for update
1	CMU_LFXOCTRL is busy synchronizing new value

28 HFXOBSY 0 R **HFXO Busy**

Used to check the synchronization status of CMU\_HFXOCTRL, CMU\_HFXOSTARTUPCTRL, CMU\_HFXOSTEADYSTA-  
TECTRL, CMU\_HFXOTIMEOUTCTRL, CMU\_HFXOCTRL1

TESTRE, CMS\_PIF\_XOTIMESTORE, CMS\_PIF\_XOOTREY.

Value	Description
0	CMU_HFXOCTRL, CMU_HFXOSTARTUPCTRL, CMU_HFXOSTEADYSTATECTRL, CMU_HFXOTIMEOUTCTRL, CMU_HFXOCTRL1 are ready for update

1 CMU\_HFXOCTRL, CMU\_HFXOSTARTUPCTRL, CMU\_HFXOSTEADYSTATECTRL, CMU\_HFXOTIMEOUTCTRL, CMU\_HFXOCTRL1 are busy synchronizing new value. HFXO is also BUSY when these registers are actively being used (e.g. when HFXOENS=1).

---

27 LFRCOVREFBSY 0 R LFRCO VREF Busy

**How Much of the Total Budget is Spent on CMC/CHURCH?**

Used to check the synchronization status of GMCCURTUNE.

Value	Description
-------	-------------

Value	Description
0	CMU_LFRCOCTRL GMCCURTUNE bitfield is ready for update
1	CMU_LFRCOCTRL GMCCURTUNE bitfield is busy synchronizing new value

36 LERCO BX LERCO BX

26 LFRCOBSY 0 R LFRCO Busy

Used to check the synchronization status of CMU\_LFRCOCTRL.

Bit	Name	Reset	Access	Description
	1			CMU_LFRCOCTRL is busy synchronizing new value
25	AUXHFRCOBSY	0	R	<b>AUXHFRCO Busy</b>
				Used to check the synchronization status of CMU_AUXHFRCOCTRL.
	Value			Description
	0			CMU_AUXHFRCOCTRL is ready for update
	1			CMU_AUXHFRCOCTRL is busy synchronizing new value
24	HFRCOBSY	0	R	<b>HFRCO Busy</b>
				Used to check the synchronization status of CMU_HFRCOCTRL.
	Value			Description
	0			CMU_HFRCOCTRL is ready for update
	1			CMU_HFRCOCTRL is busy synchronizing new value
23:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18	LFEPRESC0	0	R	<b>Low Frequency E Prescaler 0 Busy</b>
				Used to check the synchronization status of CMU_LFEPRESC0.
	Value			Description
	0			CMU_LFEPRESC0 is ready for update
	1			CMU_LFEPRESC0 is busy synchronizing new value
17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	LFECLKEN0	0	R	<b>Low Frequency E Clock Enable 0 Busy</b>
				Used to check the synchronization status of CMU_LFECLKEN0.
	Value			Description
	0			CMU_LFECLKEN0 is ready for update
	1			CMU_LFECLKEN0 is busy synchronizing new value
15:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	LFBPRES0	0	R	<b>Low Frequency B Prescaler 0 Busy</b>
				Used to check the synchronization status of CMU_LFBPRES0.
	Value			Description
	0			CMU_LFBPRES0 is ready for update
	1			CMU_LFBPRES0 is busy synchronizing new value
5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
4	LFBCLKEN0	0	R	<b>Low Frequency B Clock Enable 0 Busy</b>
Used to check the synchronization status of CMU_LFBCLKEN0.				
				Value Description
				0 CMU_LFBCLKEN0 is ready for update
				1 CMU_LFBCLKEN0 is busy synchronizing new value
3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
2	LFAPRESC0	0	R	<b>Low Frequency a Prescaler 0 Busy</b>
Used to check the synchronization status of CMU_LFAPRESC0.				
				Value Description
				0 CMU_LFAPRESC0 is ready for update
				1 CMU_LFAPRESC0 is busy synchronizing new value
1	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
0	LFACLKEN0	0	R	<b>Low Frequency a Clock Enable 0 Busy</b>
Used to check the synchronization status of CMU_LFACLKEN0.				
				Value Description
				0 CMU_LFACLKEN0 is ready for update
				1 CMU_LFACLKEN0 is busy synchronizing new value

## 10.5.46 CMU\_FREEZE - Freeze Register

Offset	Bit Position																																	
0x144	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0	
Reset																																	0	
Access																																	RW	
Name																																		REGFREEZE

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	REGFREEZE	0	RW	<b>Register Update Freeze</b>

When set, the update of the Low Frequency clock control registers is postponed until this bit is cleared. Use this bit to update several registers simultaneously.

Value	Mode	Description
0	UPDATE	Each write access to a Low Frequency clock control register is updated into the Low Frequency domain as soon as possible.
1	FREEZE	The LE Clock Control registers are not updated with the new written value.

## 10.5.47 CMU\_PCNTCTRL - PCNT Control Register

Offset	Bit Position																																	
0x150	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																														0	0			
Access																														RW	0			
Name																															PCNT0CLKSEL	RW	0	
																																PCNT0CLKEN	RW	0

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	PCNT0CLKSEL	0	RWH	<b>PCNT0 Clock Select</b>
	This bit controls which clock that is used for the PCNT.			
	Value	Mode	Description	
	0	LFACLK	LFACLK is clocking PCNT0	
	1	PCNT0S0	External pin PCNT0_S0 is clocking PCNT0	
0	PCNT0CLKEN	0	RWH	<b>PCNT0 Clock Enable</b>
	This bit enables/disables the clock to the PCNT.			

## 10.5.48 CMU\_ADCCTRL - ADC Control Register

Offset	Bit Position																															
0x15C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									RWH	0	0x0					
Access																									RWH	0x0						
Name																									ADC0CLKINV							
																									ADC0CLKSEL							
																									ADC0CLKDIV							

Bit	Name	Reset	Access	Description
31:9	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
8	ADC0CLKINV	0	RWH	<b>ADC0 Clock Selected By ADC0CLKSEL</b>
	This bit enables inverting the selected clock to ADC0.			
7:6	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
5:4	ADC0CLKSEL	0x0	RWH	<b>ADC0 Clock Select</b>
	This bit controls which clock is used for ADC0 in case ADCCLKMODE in ADCn_CTRL is set to ASYNC. It should only be changed when ADCCLKMODE in ADCn_CTRL is set to SYNC. HFXO should never be selected as clock source for ADC0 when disabling the HFXO (e.g. because of EM2 entry).			
	Value	Mode	Description	
	0	DISABLED	ADC0 is not clocked	
	1	AUXHFRCO	AUXHFRCO is clocking ADC0	
	2	HFXO	HFXO is clocking ADC0	
	3	HFSRCCCLK	HFSRCCCLK is clocking ADC0	
3:2	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
1:0	ADC0CLKDIV	0x0	RWH	<b>ADC0 Clock Prescaler</b>
	Specifies the clock divider for ADC0.			
	Value	Description		
	PRESC	Clock division factor of PRESC+1.		

## 10.5.49 CMU\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																																			
0x170	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset				0																																
Access				RW																																
Name				CLKINOPEN																																

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
28	CLKIN0OPEN	0	RW	<b>CLKIN0 Pin Enable</b>
				When set, the CLKIN0 pin is enabled.
27:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	CLKOUT2PEN	0	RW	<b>CLKOUT2 Pin Enable</b>
				When set, the CLKOUT2 pin is enabled.
1	CLKOUT1PEN	0	RW	<b>CLKOUT1 Pin Enable</b>
				When set, the CLKOUT1 pin is enabled.
0	CLKOUT0OPEN	0	RW	<b>CLKOUT0 Pin Enable</b>
				When set, the CLKOUT0 pin is enabled.

## 10.5.50 CMU\_ROUTELOC0 - I/O Routing Location Register

Offset	Bit Position																															
0x174	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset													0x00								0x00				0x00							
Access													RW								RW				RW							
Name													CLKOUT2LOC								CLKOUT1LOC				CLKOUT0LOC							

Bit	Name	Reset	Access	Description																					
31:22	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																							
21:16	CLKOUT2LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CLKOUT2.  <table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr> <td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr> <td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr> <td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr> <td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr> <td>5</td><td>LOC5</td><td>Location 5</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5
Value	Mode	Description																							
0	LOC0	Location 0																							
1	LOC1	Location 1																							
2	LOC2	Location 2																							
3	LOC3	Location 3																							
4	LOC4	Location 4																							
5	LOC5	Location 5																							
15:14	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																							
13:8	CLKOUT1LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CLKOUT1.  <table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr> <td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr> <td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr> <td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr> <td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr> <td>5</td><td>LOC5</td><td>Location 5</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5
Value	Mode	Description																							
0	LOC0	Location 0																							
1	LOC1	Location 1																							
2	LOC2	Location 2																							
3	LOC3	Location 3																							
4	LOC4	Location 4																							
5	LOC5	Location 5																							
7:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																							
5:0	CLKOUT0LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CMU CLKOUT0.  <table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> </table>	Value	Mode	Description																		
Value	Mode	Description																							

Bit	Name	Reset	Access	Description
0	LOC0			Location 0
1	LOC1			Location 1
2	LOC2			Location 2
3	LOC3			Location 3
4	LOC4			Location 4
5	LOC5			Location 5

#### 10.5.51 CMU\_ROUTELOC1 - I/O Routing Location Register

Offset	Bit Position																															
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x00			
Access																														RW		
Name																															CLKIN0LOC	

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
5:0	CLKIN0LOC	0x00	RW	<b>I/O Location</b>

Decides the location of the CLKIN0.

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3
4	LOC4	Location 4
5	LOC5	Location 5
6	LOC6	Location 6
7	LOC7	Location 7

## 10.5.52 CMU\_LOCK - Configuration Lock Register

Offset	Bit Position																																
0x180	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
<b>Reset</b>																															0x0000		
<b>Access</b>																															RWH		
<b>Name</b>																																	LOCKKEY


Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

15:0	LOCKKEY	0x0000	RWH	<b>Configuration Lock Key</b>
Write any other value than the unlock code to lock CMU_CTRL, CMU_ROUTEOPEN, CMU_ROUTELOC0, CMU_ROUTELOC1, CMU_HFRCOCTRL, CMU_AUXHFRCOCTRL, CMU_LFRCOCTRL, CMU_ULFRCOCTRL, CMU_HFXOCTRL, CMU_HFXOCTRL1, CMU_HFXOSTARTUPCTRL, CMU_HFXOSTEADYSTATECTRL, CMU_HFXOTIMEOUTCTRL, CMU_LFXOCTRL, CMU_OSCENCMD, CMU_CMD, CMU_DBGCLKSEL, CMU_HFCLKSEL, CMU_LFACLKSEL, CMU_LFBCLKSEL, CMU_LFECLKSEL, CMU_HFBUSCLKEN0, CMU_HFPERCLKEN0, CMU_HFPERCLKEN1, CMU_HFPRESC, CMU_HFBUSPRESC, CMU_HFCOREPRESC, CMU_HFPERPRESC, CMU_HFPERPRESBC, CMU_HFPERPRESCC, CMU_HFEXPPRESC, CMU_LFACLKEN0, CMU_LFBCLKEN0, CMU_LFECLKEN0, CMU_LFAPRESC0, CMU_LFBPRESC0, CMU_LFEPRESC0, CMU_ADCCTRL and CMU_PCNTCTRL from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.				
<b>Mode</b>				
Read Operation				
UNLOCKED 0 CMU registers are unlocked				
LOCKED 1 CMU registers are locked				
<b>Write Operation</b>				
LOCK 0 Lock CMU registers				
UNLOCK 0x580E Unlock CMU registers				

### 10.5.53 CMU\_HFRCOSS - HFRCO Spread Spectrum Register

Bit	Name	Reset	Access	Description
31:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12:8	SSINV	0x00	RW	<b>Spread Spectrum Update Interval</b>  This value sets the update rate of the DCO period for spectrum spreading.
7:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	SSAMP	0x0	RW	<b>Spread Spectrum Amplitude</b>  Randomize DCO output period with a peak-to-peak amplitude. Clear SSAMP would disable spectrum spreading.

## 11. SMU - Security Management Unit



Quick Facts
<b>What?</b>
The Security Management Unit (SMU) forms the control and status/reporting component of bus-level security in the EFM32 Tiny Gecko 11.
<b>Why?</b>
Enables a robust and low-energy security solution at the system level
<b>How?</b>
Hardware context switching and access control provided via BLS components.

### 11.1 Introduction

The Security Management Unit (SMU) peripheral adds hardware access control over all of the MCU peripherals that are managed by low level firmware integrated into a Real Timer Operating System (RTOS). The SMU is used in conjunction with the Cortex-M operating modes (privileged and non-privileged) and the Memory Protection Unit (MPU). The EFM32 Tiny Gecko 11 MCUs include the ARM v7-M MPU that defines configurable access parameters to regions within the entire CPU memory map. The MPU is not covered in detail in this reference manual. For a complete description of the MPU registers etc, consult the ARM v7-M Architecture Reference Manual. The MPU can define up to 8 regions of varying sizes within the memory map, with each region also being able to be split into 8 equal sub-regions. Using these regions, firmware can define rules that enforce privileged and non-privileged accesses to different memory locations. For example, sections of flash can be marked as privileged access, whereas other areas within the flash can be marked as having non-privileged mode access. Only privileged mode regions can access other privileged mode regions. Accesses attempted by a non-privileged region to a privileged region will cause a fault. The access permissions can be extended across the entire memory map including the peripheral region.

The Cortex-M starts up in privileged mode and the MPU is disabled after reset which means all regions in the memory map are accessible to the running application code. For many applications this is sufficient and the MPU remains disabled. However, when using a RTOS the kernel requires protection from user code and will switch to privileged mode and create tasks in non-privileged or thread mode. In addition, security is also a concern, so MCU peripherals should be protected to avoid security holes. Adding peripheral security to systems requires an increased number of MPU regions to protect areas such as the peripheral registers, including bit set/clear and bit banding regions. The defined regions are also dynamic based on the task requirements and in many cases the number of regions required exceeds the number of regions that can be enabled by the MPU.

The SMU is used to extend the access controls of each peripheral beyond the number of regions available using the MPU. The SMU peripheral registers provide the configuration and status bits for the Peripheral Protection Unit (PPU) to the CPU. The PPU is the underlying hardware component that operates on the low level bus interfaces within the SoC to derive the status for each peripheral .


### 11.2 Features

The main features of the SMU are as follows:

- Contains control and status registers for hardware bus level component instances (e.g., the PPU)
- Simplifies RTOS context switching
  - Hardware to complement any software context switching enabled by an MPU
  - Hardware-enforced access control extends capability of the v7-M MPU regions
  - One bit control per peripheral reduces software overhead while dynamically modifying access permissions
- A configurable interrupt line that can be triggered from peripheral access fault events

## 11.3 Functional Description

An overview of the SMU module within the system is shown in [Figure 11.1 Bus-Level Security System View on page 391](#).



**Figure 11.1. Bus-Level Security System View**

### 11.3.1 PPU - Peripheral Protection Unit


The number of peripheral memory regions on the device exceeds the number of configurable regions available using the MPU. While it is possible to manage finer granularity of memory security through software, the PPU provides a hardware solution for fine-grained peripheral-level protection to eliminate the performance degradation associated with a partially software-managed solution.

The PPU provides a hardware access barrier to any peripheral that is configured to be protected. When an attempt is made to access a peripheral without the required privilege level, the PPU detects the fault and intercepts the access. No write or read of the peripheral register space occurs, and an all-zero value is returned if the access is a read. See [11.3.2.2 PPU Control](#) for more details on how access faults are reported to the CPU.

**Note:** The CPU is the only system bus master in the EFM32 Tiny Gecko 11 that can trigger access faults. All other masters are given full access privileges and have no configurable context switching enabled.

### 11.3.2 Programming Model

The SMU does not provide any access control out of reset and needs to be configured by software. SMU access controls should be configured along with the MPU configuration. This is typically performed in a bootloader or other low level RTOS kernel/supervisor code prior to user code or other non-privileged code execution. At least one MPU region will be allocated to the entire peripheral region as a full access region (0x4000\_0000 - 0x4006\_FFFF). An RTOS kernel/supervisor can dynamically allocate peripheral accessibility by maintaining the hardware and software contexts available to each task. In the chart below there are multiple tasks and the system switches between Task A and Task B via the RTOS handler. There are 16 peripherals shown in the example split between two regions. Task A has rights to access peripherals 0, 1, 4, 5 and 7, whereas task B has rights to access the complement of A (2, 3, and 6). After a Task B IRQ, the privileged OS handler is entered which signals the supervisor to reprogram the regions using the SMU based on an access control list. Control is then handed to Task B in non-privileged mode.



**Figure 11.2. Peripheral Access Control Example**

All hardware protections happen immediately in response to SMU configuration register writes without any latency cycles. However, since software instructions may be optimized or pipelined, it is important to make sure that software memory barrier instructions are used as needed after any SMU re-configuration before moving on or changing contexts. This ensures that the hardware context switch has taken full effect.

For the remainder of this section, the programming model is split into general SMU controls and component-specific controls (e.g., PPU).

#### 11.3.2.1 Interrupt Control/Status

The SMU follows the standard EFM32 Tiny Gecko 11 interrupt programming model with SMU\_IF/IFS/IFC/IEN registers.

There is one interrupt bit PPUPRIV that will trigger on privilege faults detected by the PPU. Such fault mechanisms are configured as specified in [11.3.2.2 PPU Control](#).

### 11.3.2.2 PPU Control

The PPU\_CTRL register provides an ENABLE bit that allows bypassing all PPU checking when set to 0. In this case, the rest of the PPU registers have no effect, and no access faults will occur. This is the reset state of the SMU.

When the ENABLE bit of PPU\_CTRL register is asserted, access protection is configured on a peripheral-by-peripheral basis using the SMU\_PPUPATDx register(s). Setting a bit in the SMU\_PPUPATDx register to one configures the corresponding peripheral controlled by that bit to privileged access only. The single bit mode control for each peripheral provides fast hardware context switching for peripheral sharing, while still supporting fast software context switches for task-based CPU context switching.

**Note:** The SMU itself is a peripheral which has protection afforded by the PPU. A proper security/privilege context configuration requires setting of the SMU's access control bits properly at startup so that only a top-level task (e.g., a uVisor from ARM) can perform security/privilege context switches.

When a peripheral has access protection configured and the peripheral is accessed with invalid privilege credentials, then an access fault occurs. The corresponding interrupt flag in SMU\_IF is asserted and the ID of the peripheral for which an unprivileged access was attempted is captured in the PERIPHID bit-field of the [PPU Fault Status](#) register (SMU\_PPUFS). This peripheral ID is held stable until all PPU interrupt flags are cleared to ensure that the first unprivileged access that caused the fault is not overwritten due to subsequent faults before being acknowledged by software.

**Note:** In the case of simultaneously occurring faults (which may be possible in some systems), only one of the faults' peripheral IDs will be captured. There is no inherent peripheral priority defined that would result in one peripheral being recognized before another.

## 11.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x00C	SMU_IF	R	Interrupt Flag Register
0x010	SMUIFS	W1	Interrupt Flag Set Register
0x014	SMUIFC	(R)W1	Interrupt Flag Clear Register
0x018	SMUIEN	RW	Interrupt Enable Register
0x040	SMU_PPUCTRL	RW	PPU Control Register
0x050	SMU_PPUPATD0	RW	PPU Privilege Access Type Descriptor 0
0x054	SMU_PPUPATD1	RW	PPU Privilege Access Type Descriptor 1
0x090	SMU_PPUFS	R	PPU Fault Status

## 11.5 Register Description

### 11.5.1 SMU\_IF - Interrupt Flag Register

Offset	Bit Position																																	
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0	
<b>Reset</b>																																		
<b>Access</b>																																		
<b>Name</b>																																		

Bit	Name	Reset	Access	Description
31:1	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PPUPRIV	0	R	<b>PPU Privilege Interrupt Flag</b>

Triggered when a privilege fault occurs in the Peripheral Protection Unit

### 11.5.2 SMU\_IFS - Interrupt Flag Set Register

Offset	Bit Position																																		
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0		
<b>Reset</b>																																			
<b>Access</b>																																			
<b>Name</b>																																			

Bit	Name	Reset	Access	Description
31:1	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PPUPRIV	0	W1	<b>Set PPUPRIV Interrupt Flag</b>

Write 1 to set the PPUPRIV interrupt flag

### 11.5.3 SMU\_IFC - Interrupt Flag Clear Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PPUPPRIV	0	(R)W1	<b>Clear PPUPPRIV Interrupt Flag</b>  Write 1 to clear the PPUPPRIV interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

#### 11.5.4 SMU\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PPUPRIV	0	RW	<b>PPUPRIV Interrupt Enable</b>  Enable/disable the PPUPRIV interrupt

### 11.5.5 SMU\_PPUCTRL - PPU Control Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	ENABLE	0	RW	Set to enable checking of peripheral access
Value		Description		
0		Privilege/Security-level checking completely bypassed in the PPU		
1		Behavior controlled by PPU_PATD		

**11.5.6 SMU\_PPUPATD0 - PPU Privilege Access Type Descriptor 0**

Set peripheral bits to 1 to mark as privileged access only

Offset	Bit Position													
Reset	0	31	0	30	0	29	0	28	0	27	0	26		
Access	RW	UART2	RW	UART1	RW	UART0	RW	TRNG0	RW	TIMER1	RW	RTCC		
Name		LEUART0	RTIMER0	RMU	PCNT0	SMU	RTCC	TRNG0	TIMER1	UART0	UART2	USART0		
Bit	Name	Reset	Access	Description										
31	USART2	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 2 access control bit</b>	Access control only for USART2									
30	USART1	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 1 access control bit</b>	Access control only for USART1									
29	USART0	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 0 access control bit</b>	Access control only for USART0									
28	UART0	0	RW	<b>Universal Asynchronous Receiver/Transmitter 0 access control bit</b>	Access control only for UART0									
27	TRNG0	0	RW	<b>True Random Number Generator 0 access control bit</b>	Access control only for TRNG0									
26	TIMER1	0	RW	<b>Timer 1 access control bit</b>	Access control only for TIMER1									
25	TIMER0	0	RW	<b>Timer 0 access control bit</b>	Access control only for TIMER0									
24	SMU	0	RW	<b>Security Management Unit access control bit</b>	Access control only for SMU									
23	RTCC	0	RW	<b>Real-Time Counter and Calendar access control bit</b>	Access control only for RTCC									
22	RMU	0	RW	<b>Reset Management Unit access control bit</b>	Access control only for RMU									
21	PCNT0	0	RW	<b>Pulse Counter 0 access control bit</b>	Access control only for PCNT0									
20	LEUART0	0	RW	<b>Low Energy UART 0 access control bit</b>	Access control only for LEUART0									

Bit	Name	Reset	Access	Description
19	LETIMER0	0	RW	<b>Low Energy Timer 0 access control bit</b> Access control only for LETIMER0
18	LESENSE	0	RW	<b>Low Energy Sensor Interface access control bit</b> Access control only for LESENSE
17	LDMA	0	RW	<b>Linked Direct Memory Access Controller access control bit</b> Access control only for LDMA
16	LCD	0	RW	<b>Liquid Crystal Display Controller access control bit</b> Access control only for LCD
15	MSC	0	RW	<b>Memory System Controller access control bit</b> Access control only for MSC
14	I2C1	0	RW	<b>I2C 1 access control bit</b> Access control only for I2C1
13	I2C0	0	RW	<b>I2C 0 access control bit</b> Access control only for I2C0
12	GPIO	0	RW	<b>General purpose Input/Output access control bit</b> Access control only for GPIO
11	GPCRC	0	RW	<b>General Purpose CRC access control bit</b> Access control only for GPCRC
10	EMU	0	RW	<b>Energy Management Unit access control bit</b> Access control only for EMU
9	PRS	0	RW	<b>Peripheral Reflex System access control bit</b> Access control only for PRS
8	VDAC0	0	RW	<b>Digital to Analog Converter 0 access control bit</b> Access control only for VDAC0
7	CSEN	0	RW	<b>Capacitive touch sense module access control bit</b> Access control only for CSEN
6	CRYPTO0	0	RW	<b>Advanced Encryption Standard Accelerator access control bit</b> Access control only for CRYPTO0
5	CRYOTIMER	0	RW	<b>CRYOTIMER access control bit</b> Access control only for CRYOTIMER
4	CMU	0	RW	<b>Clock Management Unit access control bit</b> Access control only for CMU
3	CAN0	0	RW	<b>CAN 0 access control bit</b> Access control only for CAN0
2	ADC0	0	RW	<b>Analog to Digital Converter 0 access control bit</b> Access control only for ADC0

Bit	Name	Reset	Access	Description
1	ACMP1	0	RW	<b>Analog Comparator 1 access control bit</b> Access control only for ACMP1
0	ACMP0	0	RW	<b>Analog Comparator 0 access control bit</b> Access control only for ACMP0

### **11.5.7 SMU\_PPUPATD1 - PPU Privilege Access Type Descriptor 1**

Set peripheral bits to 1 to mark as privileged access only

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	WTIMER1	0	RW	<b>Wide Timer 1 access control bit</b> Access control only for WTIMER1
2	WTIMERO	0	RW	<b>Wide Timer 0 access control bit</b> Access control only for WTIMERO
1	WDOG0	0	RW	<b>Watchdog access control bit</b> Access control only for WDOG0
0	USART3	0	RW	<b>Universal Synchronous/Asynchronous Receiver/Transmitter 3 access control bit</b> Access control only for USART3

## 11.5.8 SMU\_PPUFS - PPU Fault Status

Offset	Bit Position																															
0x090	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																														0x00		
Access																													R			
Name																													PERIPHID			

Bit	Name	Reset	Access	Description
31:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6:0	PERIPHID	0x00	R	

Holds the peripheral ID of the first peripheral that was accessed resulting in an access fault. This ID is not valid unless one of the PPU interrupt flags is set. Any other access faults that occur are not captured until all the PPU interrupt flags are cleared

Value	Mode	Description
0	ACMP0	Analog Comparator 0
1	ACMP1	Analog Comparator 1
2	ADC0	Analog to Digital Converter 0
3	CAN0	CAN 0
4	CMU	Clock Management Unit
5	CRYOTIMER	CRYOTIMER
6	CRYPTO0	Advanced Encryption Standard Accelerator
7	CSEN	Capacitive touch sense module
8	VDAC0	Digital to Analog Converter 0
9	PRS	Peripheral Reflex System
10	EMU	Energy Management Unit
11	GPCRC	General Purpose CRC
12	GPIO	General purpose Input/Output
13	I2C0	I2C 0
14	I2C1	I2C 1
15	MSC	Memory System Controller
16	LCD	Liquid Crystal Display Controller
17	LDMA	Linked Direct Memory Access Controller
18	LESENSE	Low Energy Sensor Interface
19	LETIMER0	Low Energy Timer 0
20	LEUART0	Low Energy UART 0
21	PCNT0	Pulse Counter 0

Bit	Name	Reset	Access	Description
22	RMU			Reset Management Unit
23	RTCC			Real-Time Counter and Calendar
24	SMU			Security Management Unit
25	TIMER0			Timer 0
26	TIMER1			Timer 1
27	TRNG0			True Random Number Generator 0
28	UART0			Universal Asynchronous Receiver/Transmitter 0
29	USART0			Universal Synchronous/Asynchronous Receiver/Transmitter 0
30	USART1			Universal Synchronous/Asynchronous Receiver/Transmitter 1
31	USART2			Universal Synchronous/Asynchronous Receiver/Transmitter 2
32	USART3			Universal Synchronous/Asynchronous Receiver/Transmitter 3
33	WDOG0			Watchdog
34	WTIMER0			Wide Timer 0
35	WTIMER1			Wide Timer 1

## 12. RTCC - Real Time Counter and Calendar



Quick Facts
<b>What?</b>
The Real Time Counter and Calendar (RTCC) is a 32-bit counter ensuring timekeeping in low energy modes. The RTCC also includes a calendar mode for easy time and date keeping. In addition, the RTCC includes 128 bytes of general purpose retention data, allowing persistent data storage in all energy modes except EM4 Shutoff.
<b>Why?</b>
Timekeeping over long time periods while using as little power as possible is required in many low power applications.
<b>How?</b>
A low frequency oscillator is used as clock signal and the RTCC has three different Capture/Compare channels which can trigger wake-up, generate PRS signalling, or capture system events. 32-bit resolution and selectable prescaling allow the system to stay in low energy modes for long periods of time and still maintain reliable timekeeping.

### 12.1 Introduction

The Real Time Counter and Calendar (RTCC) contains a 32-bit counter/calendar in combination with a 15-bit pre-counter to allow flexible prescaling of the main counter. The RTCC is available in all energy modes except EM4 Shutoff.

Three individually configurable Capture/Compare channels are available in the RTCC. These can be used to trigger interrupts, generate PRS signals, capture system events, and to wake the device up from a low energy mode. The RTCC also includes 128 bytes of general purpose storage and a Binary Coded Decimal (BCD) calendar mode, enabling easy time and date keeping.

### 12.2 Features

- 32-bit Real Time Counter.
- 15-bit pre-counter, for flexible frequency scaling or for use as an independent counter.
- EM4 Hibernate operation and wakeup.
- 128 byte general purpose retention data.
- Oscillator failure detection.
- Backup mode Timestamp.
- Can continue through system reset; only reset by power loss, pin, or software reset.
- Calendar mode.
  - BCD encoding.
  - Three programmable alarms.
  - Leap year correction.
- Three Capture/Compare registers.
  - Capture of PRS events from other parts of the system.
  - Compare match or input capture can trigger interrupts.
  - Compare register 1, RTCC\_CC1\_CCV can be used as a top value for the main counter.
  - Compare register 0, RTCC\_CC0\_CCV can be used as a top value for the pre-counter.
  - Compare match events are available to other peripherals through the Peripheral Reflex System (PRS).

### 12.3 Functional Description

The RTCC is a 32-bit up-counter with three Capture/Compare channels. In addition, the RTCC includes a 15-bit pre-counter which can be used as an independent counter or to prescale the main counter. An overview of the RTCC module is shown in [Figure 12.1 RTCC Overview on page 403](#).





Figure 12.1. RTCC Overview

### 12.3.1 Counter

The RTCC consists of two counters; the 32-bit main counter, RTCC\_CNT (RTCC\_TIME and RTCC\_DATE in calendar mode), and a 15-bit pre-counter, RTCC\_PRECNT. The pre-counter can be used as an independent counter or to generate a specific frequency for the main counter. In both configurations, the pre-counter can be used to generate compare match events or be captured in the Capture/Compare channels as a result of an external PRS event. Refer to [12.3.2 Capture/Compare Channels](#) for details on how to configure the Capture/Compare channels for use with the pre-counter.



**Figure 12.2. RTCC counters**

The RTCC is enabled by setting the ENABLE bit in RTCC\_CTRL. When the RTCC is enabled, the pre-counter (RTCC\_PRECNT) increments upon each positive clock edge of LFCLK<sub>RTCC</sub>. If CNTTICK in RTCC\_CTRL is set to PRESC, the pre-counter will continue to count up, wrapping around to zero when it overflows. If CNTTICK in RTCC\_CTRL is set to CCV0MATCH, the pre-counter will wrap around when it hits the value configured in RTCC\_CC0\_CCV.

The main counter of the RTCC, RTCC\_CNT, has two modes; normal mode and calendar mode. In normal mode, the main counter is available in RTCC\_CNT and increments upon each tick given from the pre-counter. Refer to [12.3.1.1 Normal Mode](#) for a description on how to configure the frequency of these ticks. In calendar mode, the counter value is available in RTCC\_TIME and RTCC\_DATE, keeping track of seconds, minutes, hours, day of month, day of week, months, and years, all encoded in BCD format. Refer to [12.3.1.2 Calendar Mode](#) for details on this mode. The mode of the main counter is configured in CNTMODE in RTCC\_CTRL. The differences between the two modes are summarized below.

- **Normal mode**
  - Incremental counter, RTCC\_CNT.
  - RTCC\_CCx\_CCV used for Capture/Compare value.
- **Calendar mode**
  - BCD counters, RTCC\_DATE, RTCC\_TIME.
  - RTCC\_CCx\_TIME and RTCC\_CCx\_DATE used for Capture/Compare value.

**Note:** The mode of the RTCC must be configured for CALENDAR mode in RTCC\_CTRL\_CNTMODE before writing to the mode dependent registers, RTCC\_TIME, RTCC\_DATE, RTCC\_CCx\_TIME, and RTCC\_CCx\_DATE. Writes to these registers when in NORMAL mode will be ignored.

### 12.3.1.1 Normal Mode

The main counter can receive a tick based on different tappings from the pre-counter, allowing the ticks to be power of 2 divisions of the  $F_{LFCLK}_{RTCC}$ . For more accurate configuration of the tick frequency, RTCC\_CC0\_CCV[14:0] can be used as a top value for RTCC\_PRECNT. When reaching the top value, the main counter receives a tick and the pre-counter wraps around. [Table 12.1 RTCC Resolution Vs Overflow,  \$F\_{LFCLK} = 32768\$  Hz on page 405](#) summarizes the resolutions available when using a 32768 Hz oscillator as source for  $F_{LFCLK}_{RTCC}$ .

**Table 12.1. RTCC Resolution Vs Overflow,  $F_{LFCLK} = 32768$  Hz**

RTCC_CTRL_CNTTICK	RTCC_CTRL_CNTPRESC	Main counter period, $T_{CNT}$	Overflow
CCV0MATCH	Don't care	$(RTCC\_CC0\_CCV + 1)/F_{LFCLK}$ s	$2^{32} \cdot T_{CNT}$ seconds
PRESC	DIV1	30.5 µs	36.4 hours
	DIV2	61 µs	72.8 hours
	DIV4	122 µs	145.6 hours
	DIV8	244 µs	12 days
	DIV16	488 µs	24 days
	DIV32	977 µs	48 days
	DIV64	1.95 ms	97 days
	DIV128	3.91 ms	194 days
	DIV256	7.81 ms	388 days
	DIV512	15.6 ms	776 days
	DIV1024	31.25 ms	4.2 years
	DIV2048	62.5 ms	8.5 years
	DIV4096	0.125 s	17 years
	DIV8192	0.25 s	34 years
	DIV16384	0.5 s	68 years
	DIV32768	1 s	136 years

By default, the counter will keep counting until it reaches the top value, 0xFFFFFFFF, before it wraps around and continues counting from zero. By setting CCV1TOP in RTCC\_CTRL, a Capture/Compare channel 1 compare match will result in the main counter wrapping to 0. The timer will then wrap around on a channel 1 compare match (RTCC\_CNT = RTCC\_CC1\_CCV). Before using the CCV1TOP setting, make sure to set this bit prior to or at the same time the RTCC is enabled. Setting CCV1TOP after enabling the RTCC (RTCC\_CTRL\_MODE != DISABLED) may cause unintended operation (e.g. if RTCC\_CNT > RTCC\_CC1\_CCV, RTCC\_CNT will wrap when reaching 0xFFFFFFFF rather than RTCC\_CC1\_CCV).

**Note:** If the RTCC is being reconfigured, and capture compare channel 1 has previously been used, a CCV1TOP wrap event might be pending. This would lead to the first tick of the main counter being a wrap to 0. To clear any pending wrap events, use the following procedure before reconfiguring the RTCC:

1. RTCC->CC[1].CTRL = RTCC\_CC\_CTRL\_MODE\_OFF;
2. RTCC->CTRL = RTCC\_CTRL\_CNTTICK\_PRESC | RTCC\_CTRL\_CNTMODE\_NORMAL | RTCC\_CTRL\_ENABLE;
3. rtcc\_cnt\_pre = RTCC->CNT;
4. while(RTCC->CNT == rtcc\_cnt\_pre);
5. Reconfigure the RTCC

### 12.3.1.2 Calendar Mode

The RTCC includes a calendar mode which implements time and date decoding in hardware. Calendar mode is enabled by configuring CNTMODE in RTCC\_CTRL to CALENDAR. When in calendar mode, the counter value is available in RTCC\_TIME and RTCC\_DATE. RTCC\_TIME shows seconds, minutes, and hours while RTCC\_DATE shows day of month, month, year, and day of week. RTCC\_TIME and RTCC\_DATE are encoded in BCD format. In calendar mode, the pre-counter should be configured to give ticks with a period of one second, i.e. RTCC\_CTRL\_CNTTICK should be set to PRESC, and the CNTPRESC bitfield of the RTCC\_CTRL register should be set to DIV32768 if a 32768 Hz clock source is used.

In calendar mode, the time and date registers of the capture compare channels, RTCC\_CCx\_TIME and RTCC\_CCx\_DATE, are used to set compare values. Compare values can be set on seconds, minutes, hours, days, and months. Whether day of week or day of month is used for a Capture/Compare channel, it is configured in RTCC\_CCx\_CTRL\_DAYCC of the respective Capture/Compare channel.

The RTCC will automatically compensate for 28-, 29- (leap year), 30-, and 31-day months. The day of week counter, RTCC\_DATE\_DAYOW, is a three bit counter incrementing when RTCC\_TIME\_HOURT overflows, wrapping around every seventh day. Automatic leap year correction, extending the month of February from 28 to 29 days every fourth year is by default enabled, but can be disabled by setting the LYEARCORRDIS bit in RTCC\_CTRL. The pseudo-code for leap year correction is as follows:

```
if RTCC_DATE_YEART modulo 2 = 0:
    if RTCC_DATE_YEARU modulo 4 = 0:
        leap_year = true
    else:
        leap_year = false
else:
    if (RTCC_DATE_YEARU + 2) modulo 4 = 0:
        leap_year = true
    else:
        leap_year = false
```

The seconds, minute, hour segments are represented in 24-hour BCD format. The month segments are enumerated as shown in [Table 12.2 RTCC calendar enumeration on page 406](#).

**Table 12.2. RTCC calendar enumeration**

Month	RTCC_DATE_MONTHT	RTCC_DATE_MONTHU
January	0b0	0b0001
February	0b0	0b0010
March	0b0	0b0011
April	0b0	0b0100
May	0b0	0b0101
June	0b0	0b0110
July	0b0	0b0111
August	0b0	0b1000
September	0b0	0b1001
October	0b1	0b0000
November	0b1	0b0001
December	0b1	0b0010


### 12.3.1.3 RTCC Initialization

The counters of the RTCC, RTCC\_CNT (RTCC\_TIME and RTCC\_DATE in calendar mode) and RTCC\_PRECNT, can at any time be written by software, as long as the registers are not locked using RTCC\_LOCKKEY. All RTCC registers use the immediate synchronization scheme, described in [4.3.1 Writing](#).

**Note:** Writing to the RTCC\_PRECNT register may alter the frequency of the ticks for the RTCC\_CNT register.

### 12.3.2 Capture/Compare Channels

Three capture/compare channels are available in the RTCC. Each channel can be configured as input capture or output compare, by setting the corresponding MODE in the RTCC\_CCx\_CTRL register.




**Figure 12.3. RTCC Compare match and PRS output illustration**


In input capture mode the RTCC\_CNT (RTCC\_TIME and RTCC\_DATE in calendar mode) register is captured into the RTCC\_CCx\_CCV (RTCC\_CCx\_TIME and RTCC\_CCx\_DATE in calendar mode) register when an edge is detected on the selected PRS input channel. The active capture edge is configured in the ICEDGE control bits.

In output compare mode the compare values are set by writing to the RTCC compare channel registers RTCC\_CCx\_CCV (RTCC\_CCx\_TIME and RTCC\_CCx\_DATE in calendar mode). These values will be compared to the main counter, RTCC\_CNT (RTCC\_TIME and RTCC\_DATE in calendar mode), or a mixture of the main counter and the pre-counter, as illustrated in [Figure 12.4 RTCC Compare base illustration on page 409](#). Compare base for the capture compare channels is set by configuring COMP-BASE in RTCC\_CCx\_CTRL.

RTCC\_CCx\_CTRL\_COMPBASE = CNT



RTCC\_CCx\_CTRL\_COMPBASE = PRECNT


**Figure 12.4. RTCC Compare base illustration**

[Table 12.3 RTCC Capture/Compare Subjects on page 409](#) summarizes which registers being subject to comparison for different configurations of RTCC\_CTRL\_CNTMODE and RTCC\_CCx\_CTRL\_COMPBASE.


**Table 12.3. RTCC Capture/Compare Subjects**

RTCC_CTRL_CNTMODE	NORMAL	CALENDAR
RTCC_CCx_CTRL_COMPBASE = CNT	RTCC_CNT vs. RTCC_CCx_CCV	RTCC_TIME vs. RTCC_CCx_TIME and RTCC_DATE vs. RTCC_CCx_DATE
RTCC_CCx_CTRL_COMPBASE = PRECNT	{RTCC_CNT[16:0],RTCC_PRECNT[14:0]} vs. RTCC_CCx_CCV	RTCC_PRECNT vs. RTCC_CCx_CCV[14:0]

[Figure 12.5 RTCC Compare in calendar mode, COMPBASE = CNT on page 410](#) illustrates how the compare events are evaluated when in calendar mode with RTCC\_CCx\_CTRL\_COMPBASE = CNT. The SECU, SECT, MINU, MINT, HOURU, HOURT, MONTHU, and MONTHT bitfields in RTCC\_CCx\_TIME and RTCC\_CCx\_DATE are compared to the corresponding bitfields in RTCC\_DATE and RTCC\_TIME. The DAYU and DAYT bitfields in RTCC\_CCx\_DATE will be compared to {RTCC\_DATE\_DAYOMT, RTCC\_DATE\_DAYOMU} if DAYCC in RTCC\_CCx\_CTRL is set to MONTH. If DAYCC in RTCC\_CCx\_CTRL is set to WEEK, the DAYU and DAYT bitfields in RTCC\_CCx\_DATE will be compared to {0b000, RTCC\_DATE\_DAYOW}.

**Figure 12.5. RTCC Compare in calendar mode, COMPBASE = CNT**

To generate periodically recurring events, it is possible to mask out parts of the compare match values. By configuring COMPMASK in RTCC\_CCx\_CTRL, parts of the compare values will be masked out, limiting which part of the compare register being subject to comparison with the counter. [Figure 12.6 RTCC Compare mask illustration, COMPMASK=11](#) on page 410 illustrates the effect of COMPMASK when in normal mode and calendar mode.

**Figure 12.6. RTCC Compare mask illustration, COMPMASK=11**

Upon a compare match, the respective Capture/Compare interrupt flag CCx is set. Additionally, the event selected by the CMOA setting is generated on the corresponding PRS output. This is illustrated in [Figure 12.3 RTCC Compare match and PRS output illustration on page 408](#).

### 12.3.3 Interrupts and PRS Output

The RTCC has one interrupt for each of its 3 Capture/Compare channels, CC0, CC1, and CC2. Each Capture/Compare channel has a PRS output with configurable actions upon compare match.

The interrupt flag CNTTICK is set each time the main counter receives a tick (each second in calendar mode). In calendar mode, there are also interrupt flags being set each minute, hour, day, week, and month.

Upon oscillator failure detection, the OSCFAIL flag will be set.

### 12.3.3.1 Main Counter Tick PRS Output

To output the ticks for the main counter on PRS, it is possible to use a Capture/Compare channel and mask all the bits, i.e. RTCC\_CCx\_CTRL\_COMPBASE=CNT and RTCC\_CCx\_CTRL\_COMPMASK=31. PRS output of main counter ticks does not work if the main counter is not prescaled.

**Note:** To be able to mask all bits in the main counter, RTCC\_CTRL\_CNTMODE has to be set to CALENDAR. In NORMAL mode, the least significant bit can not be masked out.

### 12.3.4 Energy Mode Availability

The RTCC is available in all energy modes except EM4 Shutoff. To enable RTCC operation in EM4 Hibernate, the EMU\_EM4CTRL register in the EMU has to be configured. Any enabled RTCC interrupt will wake the system up from EM4 Hibernate; if EM4WU in RTCC\_EM4WUEN is set. Refer to [9. EMU - Energy Management Unit](#) for details on how to configure the EMU.

### 12.3.5 Register Lock

To prevent accidental writes to the RTCC registers, the RTCC\_LOCKKEY register can be written to any value other than the unlock value. To unlock the register, write the unlock value to RTCC\_LOCKKEY. Registers affected by this lock are:

- RTCC\_CTRL
- RTCC\_PRECNT
- RTCC\_CNT
- RTCC\_TIME
- RTCC\_DATE
- RTCC\_IEN
- RTCC\_POWERDOWN
- RTCC\_CCx\_CTRL
- RTCC\_CCx\_CCV
- RTCC\_CCx\_TIME
- RTCC\_CCx\_DATE

### 12.3.6 Oscillator Failure Detection

To be able to detect OSC failure, the RTCC includes a security mechanism ensuring that at least three OSC cycles are detected within one period of the ULFRCO. If no OSC cycles are detected, the OSCFAIL interrupt flag is set. OSC failure detection is enabled by setting the OSCFDETEN bit in RTCC\_CTRL.

### 12.3.7 Retention Registers

The RTCC includes 32 x 32 bit registers which can be retained in all energy modes except EM4 Shutoff. The registers are accessible through the RETx\_REG registers. Retention is by default enabled in EM0 Active through EM4 Hibernate/Shutoff. The registers can be shut off to save power by setting the RAM bit in RTCC\_POWERDOWN.

**Note:** The retention registers are mapped to a RAM instance and have undefined state out of reset.

### 12.3.8 Timestamp

The RTCC includes functionality for storing a timestamp when the system enters backup mode. The timestamp is stored in the RTCC\_CC2\_CCV (RTCC\_CC2\_TIME and RTCC\_CC2\_DATE in calendar mode) register. Timestamping is enabled by first writing a 1 to CLRSTATUS in RTCC\_CMD and then setting BUMODETSEN in RTCC\_CTRL. When a timestamp is stored, the BUMODETS bit in RTCC\_STATUS is set. To prevent uncontrolled time stamping when entering and exiting backup mode, this status bit has to be cleared before a new timestamp can be stored. Writing a 1 to CLRSTATUS in RTCC\_CMD clears BUMODETS.

### 12.3.9 Debug Session

By default, the RTCC is halted when code execution is halted from the debugger. By setting the DEBUGRUN bit in the RTCC\_CTRL register, the RTCC will continue to run even when the debugger has halted the system.

## 12.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	RTCC_CTRL	RW	Control Register
0x004	RTCC_PRECNT	RWH	Pre-Counter Value Register
0x008	RTCC_CNT	RWH	Counter Value Register
0x00C	RTCC_COMBCNT	R	Combined Pre-Counter and Counter Value Register
0x010	RTCC_TIME	RWH	Time of Day Register
0x014	RTCC_DATE	RWH	Date Register
0x018	RTCC_IF	R	RTCC Interrupt Flags
0x01C	RTCC_IFS	W1	Interrupt Flag Set Register
0x020	RTCC_IFC	(R)W1	Interrupt Flag Clear Register
0x024	RTCC_IEN	RW	Interrupt Enable Register
0x028	RTCC_STATUS	R	Status Register
0x02C	RTCC_CMD	W1	Command Register
0x030	RTCC_SYNCBUSY	R	Synchronization Busy Register
0x034	RTCC_POWERDOWN	RW	Retention RAM Power-down Register
0x038	RTCC_LOCK	RWH	Configuration Lock Register
0x03C	RTCC_EM4WUEN	RW	Wake Up Enable
0x040	RTCC_CC0_CTRL	RW	CC Channel Control Register
0x044	RTCC_CC0_CCV	RWH	Capture/Compare Value Register
0x048	RTCC_CC0_TIME	RWH	Capture/Compare Time Register
0x04C	RTCC_CC0_DATE	RWH	Capture/Compare Date Register
0x050	RTCC_CC1_CTRL	RW	CC Channel Control Register
0x054	RTCC_CC1_CCV	RWH	Capture/Compare Value Register
0x058	RTCC_CC1_TIME	RWH	Capture/Compare Time Register
0x05C	RTCC_CC1_DATE	RWH	Capture/Compare Date Register
0x060	RTCC_CC2_CTRL	RW	CC Channel Control Register
0x064	RTCC_CC2_CCV	RWH	Capture/Compare Value Register
0x068	RTCC_CC2_TIME	RWH	Capture/Compare Time Register
0x06C	RTCC_CC2_DATE	RWH	Capture/Compare Date Register
0x104	RTCC_RET0_REG	RW	Retention Register
...	RTCC_RET <sub>x</sub> _REG	RW	Retention Register
0x180	RTCC_RET31_REG	RW	Retention Register

## 12.5 Register Description

### 12.5.1 RTCC\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW		
Name	LYEARCORRDIS	CNTMODE	OSCFDETEN	BUMODETSEN	CNTTICK	CNTPRESC	CCV1TOP	PRECCV0TOP	DEBUGRUN	ENABLE	0	5	4	3	2	1	0	0	0	0	0	0	0	0	0	0	0	0	0			

Bit	Name	Reset	Access	Description
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	LYEARCORRDIS	0	RW	<b>Leap Year Correction Disabled</b>
				When cleared, February has 29 days in leap years. When set, February always has 28 days.
16	CNTMODE	0	RW	<b>Main Counter Mode</b>
				Configure count mode for the main counter.
	Value	Mode		Description
	0	NORMAL		The main counter is incremented with 1 for each tick.
	1	CALENDAR		The main counter is in calendar mode.
15	OSCFDETEN	0	RW	<b>Oscillator Failure Detection Enable</b>
				When set, the OSCFAIL interrupt flag will be set if no ticks are detected on LFCLK <sub>RTCC</sub> within one ULFRCO cycle.
14	BUMODETSEN	0	RW	<b>Backup Mode Timestamp Enable</b>
				When set, the RTCC will store its counter value in the RTCC_CC2_CCV register upon backup mode entry.
13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	CNTTICK	0	RW	<b>Counter Prescaler Mode</b>
				Select whether the main counter should tick on RTCC_CC0_CCV[14:0] compare match with the pre-counter or tick on a pre-counter tap selected in CNTPRESC bitfield in the RTCC_CTRL register.
	Value	Mode		Description
	0	PRESC		CNT register ticks according to configuration in CNTPRESC.
	1	CCV0MATCH		CNT register ticks when PRECNT matches RTCC_CC0_CCV[14:0]
11:8	CNTPRESC	0x0	RW	<b>Counter Prescaler Value</b>
				Configure counting frequency of the CNT register.
	Value	Mode		Description

Bit	Name	Reset	Access	Description
0	DIV1			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/1$
1	DIV2			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/2$
2	DIV4			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/4$
3	DIV8			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/8$
4	DIV16			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/16$
5	DIV32			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/32$
6	DIV64			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/64$
7	DIV128			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/128$
8	DIV256			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/256$
9	DIV512			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/512$
10	DIV1024			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/1024$
11	DIV2048			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/2048$
12	DIV4096			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/4096$
13	DIV8192			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/8192$
14	DIV16384			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/16384$
15	DIV32768			$\text{CLK}_{\text{CNT}} = \text{LFECLK}_{\text{RTCC}}/32768$
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	CCV1TOP	0	RW	<b>CCV1 Top Value Enable</b>
				When set, the counter wraps around on a CC1 event.
4	PRECCV0TOP	0	RW	<b>Pre-counter CCV0 Top Value Enable</b>
				When set, the pre-counter wraps around when PRECNT equals RTCC_CC0_CCV[14:0].
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>
				Set this bit to keep the RTCC running during a debug halt.
	Value			Description
	0			RTCC is frozen in debug mode
	1			RTCC is running in debug mode
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	ENABLE	0	RW	<b>RTCC Enable</b>
				Enable the RTCC.

**12.5.2 RTCC\_PRECNT - Pre-Counter Value Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0x0000																
Access																RWH																
Name																PRECNT																

Bit	Name	Reset	Access	Description
31:15	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
14:0	PRECNT	0x0000	RWH	<b>Pre-Counter Value</b>  Gives access to the Pre-counter value of the RTCC.

**12.5.3 RTCC\_CNT - Counter Value Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0x00000000																
Access																RWH																
Name																CNT																

Bit	Name	Reset	Access	Description
31:0	CNT	0x00000000	RWH	<b>Counter Value</b>  Gives access to the main counter value of the RTCC. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = CALENDAR.

## 12.5.4 RTCC\_COMBCNT - Combined Pre-Counter and Counter Value Register

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000																0x0000															
Access	R																R															
Name	CNTLSB																PRECNT															

Bit	Name	Reset	Access	Description
31:15	CNTLSB	0x00000	R	<b>Counter Value</b>
		Gives access to the 17 LSBs of the main counter, CNT. Register will be read as zero when RTCC_CTRL_CNTMODE = CALENDAR.		
14:0	PRECNT	0x0000	R	<b>Pre-Counter Value</b>
		Gives access to the pre-counter, PRECNT. Register will be read as zero when RTCC_CTRL_CNTMODE = CALENDAR.		

**12.5.5 RTCC\_TIME - Time of Day Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:22	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	HOURT	0x0	RWH	<b>Hours, Tens</b>  Shows the tens part of the hour counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
19:16	HOURU	0x0	RWH	<b>Hours, Units</b>  Shows the unit part of the hour counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
15	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:12	MINT	0x0	RWH	<b>Minutes, Tens</b>  Shows the tens part of the minute counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
11:8	MINU	0x0	RWH	<b>Minutes, Units</b>  Shows the unit part of the minute counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
7	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	SECT	0x0	RWH	<b>Seconds, Tens</b>  Shows the tens part of the second counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
3:0	SECU	0x0	RWH	<b>Seconds, Units</b>  Shows the unit part of the second counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.

**12.5.6 RTCC\_DATE - Date Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																											0x0				
Access	RWH																											RWH				
Name	DAYOW																											DAYOMU				

Bit	Name	Reset	Access	Description
31:27	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
26:24	DAYOW	0x0	RWH	<b>Day of Week</b>  Shows the day of week counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
23:20	YEART	0x0	RWH	<b>Year, Tens</b>  Shows the tens part of the year counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
19:16	YEARU	0x0	RWH	<b>Year, Units</b>  Shows the unit part of the year counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
15:13	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
12	MONTHT	0	RWH	<b>Month, Tens</b>  Shows the tens part of the month counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
11:8	MONTHU	0x0	RWH	<b>Month, Units</b>  Shows the unit part of the month counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
7:6	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
5:4	DAYOMT	0x0	RWH	<b>Day of Month, Tens</b>  Shows the tens part of the day of month counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
3:0	DAYOMU	0x0	RWH	<b>Day of Month, Units</b>  Shows the unit part of the day of month counter. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.

## 12.5.7 RTCC\_IF - RTCC Interrupt Flags

Offset	Bit Position																					
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	
Reset																						
Access																						
Name																						
MONTHTICK	R	0	10																			
DAYOWOF	R	0	9																			
DAYTICK	R	0	8																			
HOURTICK	R	0	7																			
MINTICK	R	0	6																			
CNTTICK	R	0	5																			
OSCFAIL	R	0	4																			
CC2	R	0	3																			
CC1	R	0	2																			
CC0	R	0	1																			
OF	R	0	0																			

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10	MONTHTICK	0	R	<b>Month Tick</b>  Set each time the month counter increments.
9	DAYOWOF	0	R	<b>Day of Week Overflow</b>  Set each time the day of week counter overflows.
8	DAYTICK	0	R	<b>Day Tick</b>  Set each time the day counter increments.
7	HOURTICK	0	R	<b>Hour Tick</b>  Set each time the hour counter increments.
6	MINTICK	0	R	<b>Minute Tick</b>  Set each time the minute counter increments.
5	CNTTICK	0	R	<b>Main Counter Tick</b>  Set each time the main counter is updated.
4	OSCFAIL	0	R	<b>Oscillator Failure Interrupt Flag</b>  Set when an oscillator failure has been detected.
3	CC2	0	R	<b>Channel 2 Interrupt Flag</b>  Set when a channel 2 event has occurred.
2	CC1	0	R	<b>Channel 1 Interrupt Flag</b>  Set when a channel 1 event has occurred.
1	CC0	0	R	<b>Channel 0 Interrupt Flag</b>  Set when a channel 0 event has occurred.
0	OF	0	R	<b>Overflow Interrupt Flag</b>  Set when a RTCC overflow has occurred.

## 12.5.8 RTCC\_IFS - Interrupt Flag Set Register

Offset	Bit Position																					
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	
Reset																	W1	0	10	W1	0	
Access																	DAYOWOF	W1	0	9	W1	0
Name																	DAYTICK	W1	0	8	W1	0
																	HOURTICK	W1	0	7	W1	0
																	MINTICK	W1	0	6	W1	0
																	CNTTICK	W1	0	5	W1	0
																	OSCFAIL	W1	0	4	CC2	
																	CC1			CC1		
																	CC0			W1	0	
																	OF			W1	0	

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10	MONTHTICK	0	W1	<b>Set MONTHTICK Interrupt Flag</b>  Write 1 to set the MONTHTICK interrupt flag
9	DAYOWOF	0	W1	<b>Set DAYOWOF Interrupt Flag</b>  Write 1 to set the DAYOWOF interrupt flag
8	DAYTICK	0	W1	<b>Set DAYTICK Interrupt Flag</b>  Write 1 to set the DAYTICK interrupt flag
7	HOURTICK	0	W1	<b>Set HOURTICK Interrupt Flag</b>  Write 1 to set the HOURTICK interrupt flag
6	MINTICK	0	W1	<b>Set MINTICK Interrupt Flag</b>  Write 1 to set the MINTICK interrupt flag
5	CNTTICK	0	W1	<b>Set CNTTICK Interrupt Flag</b>  Write 1 to set the CNTTICK interrupt flag
4	OSCFAIL	0	W1	<b>Set OSCFAIL Interrupt Flag</b>  Write 1 to set the OSCFAIL interrupt flag
3	CC2	0	W1	<b>Set CC2 Interrupt Flag</b>  Write 1 to set the CC2 interrupt flag
2	CC1	0	W1	<b>Set CC1 Interrupt Flag</b>  Write 1 to set the CC1 interrupt flag
1	CC0	0	W1	<b>Set CC0 Interrupt Flag</b>  Write 1 to set the CC0 interrupt flag
0	OF	0	W1	<b>Set OF Interrupt Flag</b>  Write 1 to set the OF interrupt flag

## 12.5.9 RTCC\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									(R)W1	0						
Access																									(R)W1	0						
Name																										OF	(R)W1	0				

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10	MONTHTICK	0	(R)W1	<b>Clear MONTHTICK Interrupt Flag</b>
				Write 1 to clear the MONTHTICK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	DAYOWOF	0	(R)W1	<b>Clear DAYOWOF Interrupt Flag</b>
				Write 1 to clear the DAYOWOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	DAYTICK	0	(R)W1	<b>Clear DAYTICK Interrupt Flag</b>
				Write 1 to clear the DAYTICK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	HOURTICK	0	(R)W1	<b>Clear HOURTICK Interrupt Flag</b>
				Write 1 to clear the HOURTICK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
6	MINTICK	0	(R)W1	<b>Clear MINTICK Interrupt Flag</b>
				Write 1 to clear the MINTICK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	CNTTICK	0	(R)W1	<b>Clear CNTTICK Interrupt Flag</b>
				Write 1 to clear the CNTTICK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	OSCFAIL	0	(R)W1	<b>Clear OSCFAIL Interrupt Flag</b>
				Write 1 to clear the OSCFAIL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	CC2	0	(R)W1	<b>Clear CC2 Interrupt Flag</b>
				Write 1 to clear the CC2 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	CC1	0	(R)W1	<b>Clear CC1 Interrupt Flag</b>
				Write 1 to clear the CC1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	CC0	0	(R)W1	<b>Clear CC0 Interrupt Flag</b>
				Write 1 to clear the CC0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
0	OF	0	(R)W1	<b>Clear OF Interrupt Flag</b>
Write 1 to clear the OF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).				

### 12.5.10 RTCC\_IEN - Interrupt Enable Register

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																						0	0	0	0	0	0	0	0	0	0	0
<b>Access</b>																						RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW
<b>Name</b>																						MONTHTICK	DAYOWOF	DAYTICK	HOURTICK	MINTICK	CNTTICK	OSCFAIL	CC2	CC1	CC0	OF

Bit	Name	Reset	Access	Description
31:11	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	MONTHTICK	0	RW	<b>MONTHTICK Interrupt Enable</b>  Enable/disable the MONTHTICK interrupt
9	DAYOWOF	0	RW	<b>DAYOWOF Interrupt Enable</b>  Enable/disable the DAYOWOF interrupt
8	DAYTICK	0	RW	<b>DAYTICK Interrupt Enable</b>  Enable/disable the DAYTICK interrupt
7	HOURTICK	0	RW	<b>HOURTICK Interrupt Enable</b>  Enable/disable the HOURTICK interrupt
6	MINTICK	0	RW	<b>MINTICK Interrupt Enable</b>  Enable/disable the MINTICK interrupt
5	CNTTICK	0	RW	<b>CNTTICK Interrupt Enable</b>  Enable/disable the CNTTICK interrupt
4	OSCFAIL	0	RW	<b>OSCFAIL Interrupt Enable</b>  Enable/disable the OSCFAIL interrupt
3	CC2	0	RW	<b>CC2 Interrupt Enable</b>  Enable/disable the CC2 interrupt
2	CC1	0	RW	<b>CC1 Interrupt Enable</b>  Enable/disable the CC1 interrupt
1	CC0	0	RW	<b>CC0 Interrupt Enable</b>  Enable/disable the CC0 interrupt
0	OF	0	RW	<b>OF Interrupt Enable</b>  Enable/disable the OF interrupt

**12.5.11 RTCC\_STATUS - Status Register**

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																											R	0				
Access																																
Name																											BUODETS	R	0			

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>.</i>
0	BUODETS	0	R	<b>Timestamp for Backup Mode Entry Stored</b>

Set when a timestamp has been stored in RTCC\_CC2\_CCV.

**12.5.12 RTCC\_CMD - Command Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																											W1	0				
Access																																
Name																											CLRSTATUS	W1	0			

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>.</i>
0	CLRSTATUS	0	W1	<b>Clear RTCC_STATUS Register</b>

Write a 1 to clear the RTCC\_STATUS register.

## 12.5.13 RTCC\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access																																
Name																																
CMD	0																															

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
5	CMD	0	R	<b>CMD Register Busy</b>
				Set when the value written to CMD is being synchronized.
4:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 12.5.14 RTCC\_POWERDOWN - Retention RAM Power-down Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																												RAM	RW	0	0
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access																																
Name																																
RAM	0																															

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	RAM	0	RW	<b>Retention RAM Power-down</b>
				Shut off power to the Retention RAM. Once it is powered down, it cannot be powered up again

**12.5.15 RTCC\_LOCK - Configuration Lock Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RWH															
Name																	LOCKKEY															

Bit	Name	Reset	Access	Description																									
31:16	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																											
15:0	LOCKKEY	0x0000	RWH	<b>Configuration Lock Key</b>																									
Write any other value than the unlock code to lock RTCC_CTRL, RTCC_PRECNT, RTCC_CNT, RTCC_TIME, RTCC_DATE, RTCC_IEN, RTCC_POWERDOWN, and RTCC_CCx_XXX registers from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.																													
<table border="1"> <thead> <tr> <th>Mode</th> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td colspan="5">Read Operation</td></tr> <tr> <td>UNLOCKED</td> <td>0</td> <td>All registers are unlocked</td></tr> <tr> <td>LOCKED</td> <td>1</td> <td>Registers are locked</td></tr> <tr> <td colspan="5">Write Operation</td></tr> <tr> <td>LOCK</td> <td>0</td> <td>Lock registers</td></tr> <tr> <td>UNLOCK</td> <td>0xAEE8</td> <td>Unlock all RTCC registers</td></tr> </tbody> </table>					Mode	Value	Description	Read Operation					UNLOCKED	0	All registers are unlocked	LOCKED	1	Registers are locked	Write Operation					LOCK	0	Lock registers	UNLOCK	0xAEE8	Unlock all RTCC registers
Mode	Value	Description																											
Read Operation																													
UNLOCKED	0	All registers are unlocked																											
LOCKED	1	Registers are locked																											
Write Operation																													
LOCK	0	Lock registers																											
UNLOCK	0xAEE8	Unlock all RTCC registers																											

**12.5.16 RTCC\_EM4WUEN - Wake Up Enable**

Offset	Bit Position																															
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0															
Access																	RW															
Name																	EM4WU															

Bit	Name	Reset	Access	Description
31:1	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
0	EM4WU	0	RW	<b>EM4 Wake-up Enable</b>
Write 1 to enable wake-up request, write 0 to disable wake-up request.				

**12.5.17 RTCC\_CCx\_CTRL - CC Channel Control Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	0	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Access	RW	0															RW	0x00								RW	0x0								
Name	DAYCC																COMPBASE	0								RW									

Bit	Name	Reset	Access	Description
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

17	DAYCC	0	RW	<b>Day Capture/Compare Selection</b>
Select whether day of week, or day of month is subject for Capture/Compare.				
Value		Mode	Description	
0		MONTH	Day of month is selected for Capture/Compare.	
1		WEEK	Day of week is selected for Capture/Compare.	

16:12	COMPBASE	0x00	RW	<b>Capture Compare Channel Comparison Mask</b>
The COMPBASE most significant bits of the compare value will not be subject to comparison.				

11	COMPBASE	0	RW	<b>Capture Compare Channel Comparison Base</b>
Configure comparison base for compare channel				
Value		Mode	Description	
0		CNT	RTCC_CCx_CCV is compared with RTCC_CNT register. RTCC_CCx_TIME/DATE compare with RTCC_TIME/DATE in calendar mode.	
1		PRECNT	Least significant bits of RTCC_CCx_CCV are compared with PRECNT.	

10:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
------	----------	--	--	---

8:6	PRSSEL	0x0	RW	<b>Compare/Capture Channel PRS Input Channel Selection</b>
Select PRS input channel for Compare/Capture channel.				
Value		Mode	Description	
0		PRSCH0	PRS Channel 0 selected as input	
1		PRSCH1	PRS Channel 1 selected as input	
2		PRSCH2	PRS Channel 2 selected as input	
3		PRSCH3	PRS Channel 3 selected as input	
4		PRSCH4	PRS Channel 4 selected as input	
5		PRSCH5	PRS Channel 5 selected as input	

Bit	Name	Reset	Access	Description
6	PRSCH6			PRS Channel 6 selected as input
7	PRSCH7			PRS Channel 7 selected as input
5:4	ICEDGE	0x0	RW	<b>Input Capture Edge Select</b>
				These bits control which edges the PRS edge detector triggers on.
	Value	Mode		Description
	0	RISING		Rising edges detected
	1	FALLING		Falling edges detected
	2	BOTH		Both edges detected
	3	NONE		No edge detection, signal is left as it is
3:2	CMOA	0x0	RW	<b>Compare Match Output Action</b>
				Select output action on compare match.
	Value	Mode		Description
	0	PULSE		A single clock cycle pulse is generated on output
	1	TOGGLE		Toggle output on compare match
	2	CLEAR		Clear output on compare match
	3	SET		Set output on compare match
1:0	MODE	0x0	RW	<b>CC Channel Mode</b>
				These bits select the mode for Compare/Capture channel.
	Value	Mode		Description
	0	OFF		Compare/Capture channel turned off
	1	INPUTCAPTURE		Input capture
	2	OUTPUTCOMPARE		Output compare

**12.5.18 RTCC\_CCx\_CCV - Capture/Compare Value Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RWH																																
Name	CCV																																

Bit	Name	Reset	Access	Description
-----	------	-------	--------	-------------

31:0	CCV	0x00000000	RWH	<b>Capture/Compare Value</b>
------	-----	------------	-----	------------------------------

Shows the Capture/Compare Value for the channel. Register can not be written and will be read as zero when RTCC\_CTRL\_CNTMODE = CALENDAR.

**12.5.19 RTCC\_CCx\_TIME - Capture/Compare Time Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																									0x0						
Access	RWH																									RWH						
Name	HOURT																									HOURU						
	RWH																									MINT						
	RWH																									MINU						
	RWH																									SECT						
	RWH																									SECU						

Bit	Name	Reset	Access	Description
31:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	HOURT	0x0	RWH	<b>Hours, Tens</b>  Shows the tens part of the Capture/Compare value for hours. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
19:16	HOURU	0x0	RWH	<b>Hours, Units</b>  Shows the unit part of the Capture/Compare value for hours. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:12	MINT	0x0	RWH	<b>Minutes, Tens</b>  Shows the tens part of the Capture/Compare value for minutes. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
11:8	MINU	0x0	RWH	<b>Minutes, Units</b>  Shows the unit part of the Capture/Compare value for minutes. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	SECT	0x0	RWH	<b>Seconds, Tens</b>  Shows the tens part of the Capture/Compare value for seconds. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
3:0	SECU	0x0	RWH	<b>Seconds, Units</b>  Shows the unit part of the Capture/Compare value for seconds. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.

**12.5.20 RTCC\_CCx\_DATE - Capture/Compare Date Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																												0	0x0	0x0		
Access																												RWH	0x0			
Name																												MONTHT	MONTHU	DAYT	DAYU	



Bit	Name	Reset	Access	Description
31:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	MONTHT	0	RWH	<b>Month, Tens</b>
				Shows the tens part of the Capture/Compare value for months. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
11:8	MONTHU	0x0	RWH	<b>Month, Units</b>
				Shows the unit part of the Capture/Compare value for months. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:4	DAYT	0x0	RWH	<b>Day of Month/week, Tens</b>
				Shows the tens part of the Capture/Compare value for days. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.
3:0	DAYU	0x0	RWH	<b>Day of Month/week, Units</b>
				Shows the unit part of the Capture/Compare value for days. Register can not be written and will be read as zero when RTCC_CTRL_CNTMODE = NORMAL.

**12.5.21 RTCC\_RETx\_REG - Retention Register**

Offset	Bit Position																															
0x104	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																												0xFFFFFFFF				
Access																												RW				
Name																												REG				

Bit	Name	Reset	Access	Description
31:0	REG	0xFFFFFFFFX	RW	<b>General Purpose Retention Register</b>

## 13. WDOG - Watchdog Timer



### Quick Facts

#### What?

The Watchdog Timer (WDOG) resets the system in case of a fault condition, and can be enabled in all energy modes as long as the low frequency clock source is available.

#### Why?

If a software failure or external event renders the MCU unresponsive, a Watchdog timeout will reset the system to a known, safe state.

#### How?

An enabled Watchdog Timer implements a configurable timeout period. If the CPU fails to re-start the Watchdog Timer before it times out, a full system reset will be triggered. The Watchdog consumes insignificant power, and allows the device to remain safely in low energy modes for up to 256 seconds at a time.

### 13.1 Introduction

The purpose of the watchdog timer is to generate a reset in case of a system failure to increase application reliability. The failure can be caused by a variety of events, such as an ESD pulse or a software failure.

### 13.2 Features

- Clock input from selectable oscillators
  - Internal 32 kHz LFRCO oscillator
  - Internal 1 kHz ULFRCO oscillator
  - External 32.768 kHz LFXO XTAL oscillator
  - HFCORECLK
- Configurable timeout period from 9 to 256k watchdog clock cycles
- Individual selection to keep running or freeze when entering EM2 DeepSleep or EM3 Stop
- Selection to keep running or freeze when entering debug mode
- Selection to block the CPU from entering Energy Mode 4
- Selection to block the CMU from disabling the selected watchdog clock
- Configurable warning interrupt at 25%, 50%, or 75% of the timeout period
- Configurable window interrupt at 12.5%, 25%, 37.5%, 50%, 62.5%, 75%, 87.5% of the timeout period
- Timeout interrupt
- PRS as a watchdog clear
- Interrupt for the event where a PRS rising edge is absent before a software reset

### 13.3 Functional Description

The watchdog is enabled by setting the EN bit in WDOGn\_CTRL. When enabled, the watchdog counts up to the period value configured through the PERSEL field in WDOGn\_CTRL. If the watchdog timer is not cleared to 0 (by writing a 1 to the CLEAR bit in WDOGn\_CMD) before the period is reached, the chip is reset. If a timely clear command is issued, the timer starts counting up from 0 again. The watchdog can optionally be locked by writing the LOCK bit in WDOGn\_CTRL. Once locked, it cannot be disabled or reconfigured by software.

When the EN bit in WDOGn\_CTRL is cleared to 0, the watchdog counter is reset.

### 13.3.1 Clock Source

Three clock sources are available for use with the watchdog, through the CLKSEL field in WDOGn\_CTRL. The corresponding clocks must be enabled in the CMU. The SWOSCBLOCK bit in WDOGn\_CTRL can be written to prevent accidental disabling of the selected clocks. Also, setting this bit will automatically start the selected oscillator source when the watchdog is enabled. The PERSEL field in WDOGn\_CTRL is used to divide the selected watchdog clock, and the timeout for the watchdog timer can be calculated with the formula:

$$T_{TIMEOUT} = (2^{3+PERSEL} + 1) / f$$

where f is the frequency of the selected clock.

When the watchdog is enabled, it is recommended to clear the watchdog before changing PERSEL.

To use this module, the LE interface clock must be enabled in CMU\_HFBUSCLKEN0.

### 13.3.2 Debug Functionality

The watchdog timer can either keep running or be frozen when the device is halted by a debugger. This configuration is done through the DEBUGRUN bit in WDOGn\_CTRL. When code execution is resumed, the watchdog will continue counting where it left off.

### 13.3.3 Energy Mode Handling

The watchdog timer can be configured to either keep on running or freeze when entering EM2 DeepSleep or EM3 Stop. The configuration is done individually for each energy mode in the EM2RUN and EM3RUN bits in WDOGn\_CTRL. When the watchdog has been frozen and is re-entering an energy mode where it is running, the watchdog timer will continue counting where it left off. For the watchdog there is no difference between EM0 Active and EM1 Sleep. The watchdog does not run in EM4 Hibernate/Shutoff. If EM4BLOCK in WDOGn\_CTRL is set, the CPU will be prevented from entering EM4 Hibernate/Shutoff by software request.

**Note:**

If the WDOG is clocked by the LFXO or LFRCO, writing the SWOSCBLOCK bit will prevent the CPU from entering EM3 Stop. When running from the ULFRCO, writing the SWOSCBLOCK bit will prevent the CPU from entering EM4 Hibernate/Shutoff.

### 13.3.4 Register Access

Since this module is a Low Energy Peripheral, and runs off a clock which is asynchronous to the HFCORECLK, special considerations must be taken when accessing registers. Refer to [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#) for a description on how to perform register accesses to Low Energy Peripherals. Note that clearing the EN bit in WDOGn\_CTRL will reset the WDOG module, which will halt any ongoing register synchronization.

**Note:**

Never write to the WDOG registers when it is disabled, except to enable the watchdog by setting the EN bitfield in WDOGn\_CTRL.

### 13.3.5 Warning Interrupt

The watchdog implements a warning interrupt which can be configured to occur at approximately 25%, 50%, or 75% of the timeout period through the WARNSEL field of the WDOGn\_CTRL register. This interrupt can be used to wake up the cpu for clearing the watchdog. The warning point for the watchdog timer can be calculated with the formula:

$$T_{WARNING} = (2^{3+PERSEL}) * (WARNSEL / 4) + 1 / f,$$

where f is the frequency of the selected clock.

When the watchdog is enabled, it is recommended to clear the watchdog before changing WARNSEL.


### 13.3.6 Window Interrupt

This interrupt occurs when the watchdog is cleared below a certain threshold. This threshold is given by the formula:

$$T_{\text{WARNING}} = (2^{3+\text{PERSEL}}) * (\text{WINSEL}/8) + 1/f,$$

where  $f$  is the frequency of the selected clock.

This value will be approximately 12.5%, 25%, 37.5%, 50%, 62.5%, 75%, or 87.5% of the timeout value based on the WINSEL field of the WDOGn\_CTRL. [Figure 13.2 WDOG Warning, Window, and Timeout on page 433](#) illustrates the warning, the window, and the timeout interrupts. Also, it shows where the prs rising edge needs to happen. The prs edge detection feature is discussed later.




**Figure 13.2. WDOG Warning, Window, and Timeout**

When the watchdog is enabled, it is recommended to clear the watchdog before changing WINSEL.

### 13.3.7 PRS as Watchdog Clear


The first PRS channel (selected by register WDOGn\_PCH0\_PRSCTRL) can be used to clear the watchdog counter. To enable this feature, CLRSRC must be set to 1. [Figure 13.2 PRS Clearing WDOG on page 434](#) shows how the PRS channel takes over the WDOG clear function. Clearing the WDOG with the PRS is mutually exclusive of clearing the WDT by software.



**Figure 13.2. PRS Clearing WDOG**

### 13.3.8 PRS Rising Edge Monitoring

PRS channels can be used to monitor multiple processes. If enabled, every time the watch dog timer is cleared the PRS channels are checked and any channel which has not seen an event can trigger an interrupt.



**Figure 13.3. PRS Edge Monitoring in WDOG**

### 13.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	WDOG_CTRL	RW	Control Register
0x004	WDOG_CMD	W1	Command Register
0x008	WDOG_SYNCBUSY	R	Synchronization Busy Register
0x00C	WDOGn_PCH0_PRSCTRL	RW	PRS Control Register
0x010	WDOGn_PCH1_PRSCTRL	RW	PRS Control Register
0x01C	WDOG_IF	R	Watchdog Interrupt Flags
0x020	WDOG_IFS	W1	Interrupt Flag Set Register
0x024	WDOG_IFC	(R)W1	Interrupt Flag Clear Register
0x028	WDOG_IEN	RW	Interrupt Enable Register

## 13.5 Register Description

### 13.5.1 WDOG\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																			
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset	0	0	0	0											0x0																					
Access	RW	RW			RW	0x0									RW					RW	0x0				RW	0xF										
Name	WDOGRSTDIS	CLRSRC			WINSEL										WARNSEL					CLKSEL					PERSEL					SWOSCBLOCK	EM4BLOCK	LOCK	EM3RUN	EM2RUN	DEBUGRUN	EN

Bit	Name	Reset	Access	Description
31	WDOGRSTDIS	0	RW	<b>Watchdog Reset Disable</b>  Disable watchdog reset output.
	Value	Mode		Description
	0	EN		A timeout will cause a watchdog reset
	1	DIS		A timeout will not cause a watchdog reset
30	CLRSRC	0	RW	<b>Watchdog Clear Source</b>  Select watchdog clear source.
	Value	Mode		Description
	0	SW		A write to the clear bit will clear the watchdog counter
	1	PCH0		A rising edge on the PRS Channel0 will clear the watchdog counter
29:27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
26:24	WINSEL	0x0	RW	<b>Watchdog Illegal Window Select</b>  Select watchdog illegal limit.
	Value			Description
	0			Disabled.
	1			Window limit is 12.5% of the Timeout.
	2			Window limit is 25.0% of the Timeout.
	3			Window limit is 37.5% of the Timeout.
	4			Window limit is 50.0% of the Timeout.
	5			Window limit is 62.5% of the Timeout.
	6			Window limit is 75.0% of the Timeout.
	7			Window limit is 87.5% of the Timeout.

Bit	Name	Reset	Access	Description																																
23:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																																
17:16	WARNSEL	0x0	RW	<b>Watchdog Timeout Period Select</b>  Select watchdog warning timeout period.																																
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Disabled.</td></tr> <tr> <td>1</td><td>Warning timeout is 25% of the Timeout.</td></tr> <tr> <td>2</td><td>Warning timeout is 50% of the Timeout.</td></tr> <tr> <td>3</td><td>Warning timeout is 75% of the Timeout.</td></tr> </tbody> </table>	Value	Description	0	Disabled.	1	Warning timeout is 25% of the Timeout.	2	Warning timeout is 50% of the Timeout.	3	Warning timeout is 75% of the Timeout.																						
Value	Description																																			
0	Disabled.																																			
1	Warning timeout is 25% of the Timeout.																																			
2	Warning timeout is 50% of the Timeout.																																			
3	Warning timeout is 75% of the Timeout.																																			
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																																
13:12	CLKSEL	0x0	RW	<b>Watchdog Clock Select</b>  Selects the WDOG oscillator, i.e. the clock on which the watchdog will run.																																
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>ULFRCO</td><td>ULFRCO</td></tr> <tr> <td>1</td><td>LFRCO</td><td>LFRCO</td></tr> <tr> <td>2</td><td>LFXO</td><td>LFXO</td></tr> <tr> <td>3</td><td>HFCORECLK</td><td>HFCORECLK</td></tr> </tbody> </table>	Value	Mode	Description	0	ULFRCO	ULFRCO	1	LFRCO	LFRCO	2	LFXO	LFXO	3	HFCORECLK	HFCORECLK																	
Value	Mode	Description																																		
0	ULFRCO	ULFRCO																																		
1	LFRCO	LFRCO																																		
2	LFXO	LFXO																																		
3	HFCORECLK	HFCORECLK																																		
11:8	PERSEL	0xF	RW	<b>Watchdog Timeout Period Select</b>  Select watchdog timeout period.																																
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Timeout period of 9 watchdog clock cycles.</td></tr> <tr> <td>1</td><td>Timeout period of 17 watchdog clock cycles.</td></tr> <tr> <td>2</td><td>Timeout period of 33 watchdog clock cycles.</td></tr> <tr> <td>3</td><td>Timeout period of 65 watchdog clock cycles.</td></tr> <tr> <td>4</td><td>Timeout period of 129 watchdog clock cycles.</td></tr> <tr> <td>5</td><td>Timeout period of 257 watchdog clock cycles.</td></tr> <tr> <td>6</td><td>Timeout period of 513 watchdog clock cycles.</td></tr> <tr> <td>7</td><td>Timeout period of 1k watchdog clock cycles.</td></tr> <tr> <td>8</td><td>Timeout period of 2k watchdog clock cycles.</td></tr> <tr> <td>9</td><td>Timeout period of 4k watchdog clock cycles.</td></tr> <tr> <td>10</td><td>Timeout period of 8k watchdog clock cycles.</td></tr> <tr> <td>11</td><td>Timeout period of 16k watchdog clock cycles.</td></tr> <tr> <td>12</td><td>Timeout period of 32k watchdog clock cycles.</td></tr> <tr> <td>13</td><td>Timeout period of 64k watchdog clock cycles.</td></tr> <tr> <td>14</td><td>Timeout period of 128k watchdog clock cycles.</td></tr> </tbody> </table>	Value	Description	0	Timeout period of 9 watchdog clock cycles.	1	Timeout period of 17 watchdog clock cycles.	2	Timeout period of 33 watchdog clock cycles.	3	Timeout period of 65 watchdog clock cycles.	4	Timeout period of 129 watchdog clock cycles.	5	Timeout period of 257 watchdog clock cycles.	6	Timeout period of 513 watchdog clock cycles.	7	Timeout period of 1k watchdog clock cycles.	8	Timeout period of 2k watchdog clock cycles.	9	Timeout period of 4k watchdog clock cycles.	10	Timeout period of 8k watchdog clock cycles.	11	Timeout period of 16k watchdog clock cycles.	12	Timeout period of 32k watchdog clock cycles.	13	Timeout period of 64k watchdog clock cycles.	14	Timeout period of 128k watchdog clock cycles.
Value	Description																																			
0	Timeout period of 9 watchdog clock cycles.																																			
1	Timeout period of 17 watchdog clock cycles.																																			
2	Timeout period of 33 watchdog clock cycles.																																			
3	Timeout period of 65 watchdog clock cycles.																																			
4	Timeout period of 129 watchdog clock cycles.																																			
5	Timeout period of 257 watchdog clock cycles.																																			
6	Timeout period of 513 watchdog clock cycles.																																			
7	Timeout period of 1k watchdog clock cycles.																																			
8	Timeout period of 2k watchdog clock cycles.																																			
9	Timeout period of 4k watchdog clock cycles.																																			
10	Timeout period of 8k watchdog clock cycles.																																			
11	Timeout period of 16k watchdog clock cycles.																																			
12	Timeout period of 32k watchdog clock cycles.																																			
13	Timeout period of 64k watchdog clock cycles.																																			
14	Timeout period of 128k watchdog clock cycles.																																			

Bit	Name	Reset	Access	Description
	15			Timeout period of 256k watchdog clock cycles.
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	SWOSCBLOCK	0	RW	<b>Software Oscillator Disable Block</b>
	Set to disallow disabling of the selected WDOG oscillator. Writing this bit to 1 will turn on the selected WDOG oscillator if it is not already running.			
	Value			Description
	0			Software is allowed to disable the selected WDOG oscillator. See CMU for detailed description. Note that also CMU registers are lockable.
	1			Software is not allowed to disable the selected WDOG oscillator.
5	EM4BLOCK	0	RW	<b>Energy Mode 4 Block</b>
	Set to disallow EM4 entry by software.			
	Value			Description
	0			EM4 can be entered by software. See EMU for detailed description.
	1			EM4 cannot be entered by software.
4	LOCK	0	RW	<b>Configuration Lock</b>
	Set to lock the watchdog configuration. This bit can only be cleared by reset.			
	Value			Description
	0			Watchdog configuration can be changed.
	1			Watchdog configuration cannot be changed.
3	EM3RUN	0	RW	<b>Energy Mode 3 Run Enable</b>
	Set to keep watchdog running in EM3.			
	Value			Description
	0			Watchdog timer is frozen in EM3.
	1			Watchdog timer is running in EM3.
2	EM2RUN	0	RW	<b>Energy Mode 2 Run Enable</b>
	Set to keep watchdog running in EM2.			
	Value			Description
	0			Watchdog timer is frozen in EM2.
	1			Watchdog timer is running in EM2.
1	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>
	Set to keep watchdog running in debug mode.			
	Value			Description
	0			Watchdog timer is frozen in debug mode.
	1			Watchdog timer is running in debug mode.

Bit	Name	Reset	Access	Description
0	EN	0	RW	<b>Watchdog Timer Enable</b>  Set to enabled watchdog timer.

### 13.5.2 WDOG\_CMD - Command Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	CLEAR	0	W1	<b>Watchdog Timer Clear</b>

Value	Mode	Description
0	UNCHANGED	Watchdog timer is unchanged.
1	CLEARED	Watchdog timer is cleared to 0.

## 13.5.3 WDOG\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	PCH1_PRSCTRL	0	R	<b>PCH1_PRSCTRL Register Busy</b>  Set when the value written to PCH1_PRSCTRL is being synchronized.
2	PCH0_PRSCTRL	0	R	<b>PCH0_PRSCTRL Register Busy</b>  Set when the value written to PCH0_PRSCTRL is being synchronized.
1	CMD	0	R	<b>CMD Register Busy</b>  Set when the value written to CMD is being synchronized.
0	CTRL	0	R	<b>CTRL Register Busy</b>  Set when the value written to CTRL is being synchronized.

**13.5.4 WDOGn\_PCHx\_PRSCTRL - PRS Control Register (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x0			
Access																													RW			
Name																													PRSEL			

Bit	Name	Reset	Access	Description
31:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8	PRSMISSRSTEN	0	RW	<b>PRS Missing Event Will Trigger a Watchdog Reset</b>
				When set, a PRS missing event will trigger a watchdog reset.
7:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	PRSEL	0x0	RW	<b>PRS Channel PRS Select</b>
				These bits select the PRS input for the PRS channel.
Value	Mode			Description
0	PRSCH0			PRS Channel 0 selected as input
1	PRSCH1			PRS Channel 1 selected as input
2	PRSCH2			PRS Channel 2 selected as input
3	PRSCH3			PRS Channel 3 selected as input
4	PRSCH4			PRS Channel 4 selected as input
5	PRSCH5			PRS Channel 5 selected as input
6	PRSCH6			PRS Channel 6 selected as input
7	PRSCH7			PRS Channel 7 selected as input

## 13.5.5 WDOG\_IF - Watchdog Interrupt Flags

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0		
Access																										R	R	R	R	R		
Name																										PEM1	PEM0	WIN	WARN	TOUT		

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	PEM1	0	R	<b>PRS Channel One Event Missing Interrupt Flag</b>  Set when a WDOG clear happens before a prs event has been detected on PRS channel one.
3	PEM0	0	R	<b>PRS Channel Zero Event Missing Interrupt Flag</b>  Set when a WDOG clear happens before a prs event has been detected on PRS channel zero.
2	WIN	0	R	<b>WDOG Window Interrupt Flag</b>  Set when a WDOG clear happens below the window limit value.
1	WARN	0	R	<b>WDOG Warning Timeout Interrupt Flag</b>  Set when a WDOG warning timeout has occurred.
0	TOUT	0	R	<b>WDOG Timeout Interrupt Flag</b>  Set when a WDOG timeout has occurred.

## 13.5.6 WDOG\_IFS - Interrupt Flag Set Register

Offset	Bit Position																										
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5
<b>Reset</b>																									4	0	
<b>Access</b>																									W1	0	
<b>Name</b>																									PEM1	W1	
																										PEM0	W1
																										WIN	W1
																										WARN	W1
																										TOUT	W1
																										0	0

Bit	Name	Reset	Access	Description
31:5	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	PEM1	0	W1	<b>Set PEM1 Interrupt Flag</b>  Write 1 to set the PEM1 interrupt flag
3	PEM0	0	W1	<b>Set PEM0 Interrupt Flag</b>  Write 1 to set the PEM0 interrupt flag
2	WIN	0	W1	<b>Set WIN Interrupt Flag</b>  Write 1 to set the WIN interrupt flag
1	WARN	0	W1	<b>Set WARN Interrupt Flag</b>  Write 1 to set the WARN interrupt flag
0	TOUT	0	W1	<b>Set TOUT Interrupt Flag</b>  Write 1 to set the TOUT interrupt flag

## 13.5.7 WDOG\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0		
Access																										(R)W1	(R)W1	(R)W1	(R)W1	(R)W1		
Name																										PEM1	PEM0	WIN	WARN	TOUT		



Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	PEM1	0	(R)W1	<b>Clear PEM1 Interrupt Flag</b>
				Write 1 to clear the PEM1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	PEM0	0	(R)W1	<b>Clear PEM0 Interrupt Flag</b>
				Write 1 to clear the PEM0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	WIN	0	(R)W1	<b>Clear WIN Interrupt Flag</b>
				Write 1 to clear the WIN interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	WARN	0	(R)W1	<b>Clear WARN Interrupt Flag</b>
				Write 1 to clear the WARN interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	TOUT	0	(R)W1	<b>Clear TOUT Interrupt Flag</b>
				Write 1 to clear the TOUT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 13.5.8 WDOG\_IEN - Interrupt Enable Register

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0		
Access																										RW	RW	RW	RW	RW		
Name																										PEM1	PEM0	WIN	WARN	TOUT		

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	PEM1	0	RW	<b>PEM1 Interrupt Enable</b>
	Enable/disable the PEM1 interrupt			
3	PEM0	0	RW	<b>PEM0 Interrupt Enable</b>
	Enable/disable the PEM0 interrupt			
2	WIN	0	RW	<b>WIN Interrupt Enable</b>
	Enable/disable the WIN interrupt			
1	WARN	0	RW	<b>WARN Interrupt Enable</b>
	Enable/disable the WARN interrupt			
0	TOUT	0	RW	<b>TOUT Interrupt Enable</b>
	Enable/disable the TOUT interrupt			

## 14. PRS - Peripheral Reflex System



### Quick Facts

#### What?

The Peripheral Reflex System (PRS) allows configurable, fast, and autonomous communication between peripherals.

#### Why?

Events and signals from one peripheral can be used as input signals or triggered by other peripherals. Besides, PRS reduces latency and ensures predictable timing by reducing software overhead and thus current consumption.

#### How?

Without CPU intervention the peripherals can send Reflex signals (both pulses and level) to each other in single or chained steps. The peripherals can be set up to perform actions based on the incoming Reflex signals. This results in improved system performance and reduced energy consumption.

### 14.1 Introduction


The Peripheral Reflex System (PRS) is a network allowing direct communication between different peripheral modules without involving the CPU. Peripheral modules which send out Reflex signals are called producers. The PRS routes these Reflex signals through Reflex channels to consumer peripherals which perform actions depending on the Reflex signals received. The format for the Reflex signals is not given, but edge triggers and other functionality can be applied by the PRS.

### 14.2 Features

- 8 Configurable Reflex Channels
  - Each channel can be connected to any producing peripheral, including the PRS channels
  - Consumers can choose which channel to listen to
  - Selectable edge detector (Rising, falling and both edges)
  - Configurable AND and OR between channels
  - Optional channel invert
  - PRS can generate event to CPU
  - Two independent DMA requests based on PRS channels
- Software controlled channel output
  - Configurable level
  - Triggered pulses

## 14.3 Functional Description

An overview of the PRS module is shown in [Figure 14.1 PRS Overview on page 447](#). The PRS contains 8 Reflex channels. All channels can select any Reflex signal offered by the producers. The consumers can choose which PRS channel to listen to and perform actions based on the Reflex signals routed through that channel. The Reflex signals can be both edge signals and level signals.



**Figure 14.1. PRS Overview**

### 14.3.1 Channel Functions

Different functions can be applied to a Reflex signal within the PRS. Each channel includes an edge detector to enable generation of pulse signals from level signals. The PRS channels can also be manually triggered by writing to PRS\_SWPULSE or PRS\_SWLEVEL. SWLEVEL[n] is a programmable level for each channel and holds the value it is programmed to. Setting SWPULSE[n] will cause the PRS channel to output a high pulse that is one HFCLK cycle wide. The SWLEVEL[n] and SWPULSE[n] signals are then XOR'ed with the selected input from the producers to form the output signal sent to the consumers listening to the channel. For example, when SWLEVEL[n] is set, if a producer produces a signal of 1, this will cause a channel output of 0.

#### 14.3.1.1 Operational Mode

Reflex channels can operate in two modes, synchronous or asynchronous. In synchronous mode Reflex signals are clocked on the HFCLK, and can be used by any Reflex consumer. However, this will not work in EM2/EM3, since the HFCLK will be turned off.

Asynchronous Reflex channels are not clocked on HFCLK, and can be used even in EM2/EM3. However, the asynchronous mode can only be used by a subset of the Reflex consumers.

The asynchronous Reflex signals generated by the producers are indicated in the SIGSEL field of PRS\_CHx\_CTRL register. The consumers capable of utilizing asynchronous Reflex signals include the LEUART and the PCNT. The USART can also utilize some particular asynchronous signals. Refer to the respective modules for details on how to configure them to use the PRS.

**Note:** If a Reflex channel with ASYNC field of PRS\_CHx\_CTRL register set to '1' is used in a consumer not supporting asynchronous reflexes, the behaviour is undefined


#### 14.3.1.2 Edge Detection and Clock Domains

Using EDSEL in PRS\_CHx\_CTRL, edge detection can be applied to a PRS signal. When edge detection is enabled, changes in the PRS input will result in a pulse on the PRS channel. This requires that the ASYNC bit in PRS\_CHx\_CTRL is cleared. Signals on the PRS input must be at least one HFCLK period wide in order to be detected properly. This applies to all cases when ASYNC is not used in the PRS.

For communication between peripherals on different prescaled clocks (e.g. between peripherals on HFCLK and HFFPERCLK), there are two options. One option is to use level signals. No additional action is needed for level signals, but software must make sure that the level signals are held long enough for the destination domain to detect them. The other option is to use pulse signals. For pulse signals, edge detection should be enabled (by configuring EDSEL in PRS\_CHx\_CTRL to positive edge, negative edge, or both) and STRETCH in PRS\_CHx\_CTRL should be set. When edge detection and stretch are enabled on a PRS source, the output on the PRS channel is held long enough for the destination domain to detect the pulse. This also works if there are multiple destination domains running at different frequencies.

#### 14.3.1.3 Configurable PRS Logic

Each PRS channel has three logic functions that can be used by themselves or in combination. The selected PRS source can be AND'ed with the next PRS channel output, OR'ed with the previous PRS channel output and inverted. This is shown in [Figure 14.1 PRS Overview on page 447](#). The order of the functions is important. If OR and AND are enabled at the same time, AND is applied first, and then OR. Note that the previous and next channel options wrap around. Using the ORPREV option on the first PRS channel OR's with the output of the last PRS channel. Likewise, using the ANDNEXT option on the last PRS channel AND's with the output of the first PRS channel.



**Figure 14.2. Configurable PRS Logic**

In addition to the logic functions that can combine a PRS channel with one of its neighbors, a PRS channel can also select any other PRS channel as input. This can allow relatively complex logic functions to be created.

#### 14.3.2 Producers

Through SOURCESEL in PRS\_CHx\_CTRL, each PRS channel selects signal producers. Each producer outputs one or more signals which can be selected by setting the SIGSEL field in PRS\_CHx\_CTRL. Setting the SOURCESEL bits to 0 (Off) leads to a constant 0 output from the input mux. An overview of the available producers can be found in the SOURCESEL and SIGSEL fields in PRS\_CHx\_CTRL. Note that GPIO producers are selected in the GPIO module using the edge interrupt configuration settings described in [32.3.5.1 Edge Interrupt Generation](#). GPIOPIN0 uses the selection for the EXTI0 interrupt, GPIOPIN1 uses the selection for the EXTI1 interrupt, and so on.

### 14.3.3 Consumers

Consumer peripherals (Listed in [Table 14.1 Reflex Consumers on page 449](#)) can be set to listen to a PRS channel and perform an action based on the signal received on that channel. While most consumers can handle either only pulse input or only level input, some can handle both pulse and level inputs.

**Table 14.1. Reflex Consumers**

Module	Reflex Input	Input Format
TIMER	Compare/Capture Channel	Pulse / Level
	Alternate Input for DTI (Available only in specific TIMERS See data sheet for details)	Level
	Alternate Input for DTI Fault 0 (Available only in specific TIMERS See data sheet for details)	Level
	Alternate Input for DTI Fault 1 (Available only in specific TIMERS See data sheet for details)	Level
WTIMER	Compare/Capture Channel	Pulse / Level
	Alternate Input for DTI (Available only in specific WTIMERS See data sheet for details)	Level
	Alternate Input for DTI Fault 0 (Available only in specific WTIMERS See data sheet for details)	Level
	Alternate Input for DTI Fault 1 (Available only in specific WTIMERS See data sheet for details)	Level
USART	RX/TX Trigger	Pulse
	Alternate Input for IrDA	Level
	Alternate Input for RX	Level
	Alternate Input for CLK	Level
VDAC	Channel 0 Trigger	Pulse
	Channel 1 Trigger	Pulse
ADC	Single Sample Trigger	Pulse
	Scan Sequence Trigger	Pulse
CMU	Alternate Input for Calibration Up-Counter	Level
	Alternate Input for Calibration Down-Counter	Level
LEUART	Alternate Input for RX	Level
PCNT	Compare/Clear Trigger	Pulse/Level
	Alternate Input for S0IN	Level
	Alternate Input for S1IN	Level

Module	Reflex Input	Input Format
LESENSE	Scan Start	Pulse
	LESENSE Decoder Bit 0	Level
	LESENSE Decoder Bit 1	Level
	LESENSE Decoder Bit 2	Level
	LESENSE Decoder Bit 3	Level
WDOG	Peripheral Watchdog	Pulse
LETIMER	Start LETIMER	Pulse
	Stop LETIMER	Pulse
	Clear LETIMER	Pulse
RTCC	Compare/Capture Channel	Pulse/Level
PRS	Set Event	Pulse
	DMA Request 0	Pulse
	DMA Request 1	Pulse
CAPSENSE	Start Conversion	Pulse

#### 14.3.4 Event on PRS

The PRS can be used to send events to the MCU. This is very useful in combination with the Wait For Event (WFE) instruction. A single PRS channel can be selected for this using SEVONPRSSEL in PRS\_CTRL, and the feature is enabled by setting SEVONPRS in the same register.

Using SEVONPRS, one can e.g. set up a timer to trigger an event to the MCU periodically, every time letting the MCU pass through a WFE instruction in its program. This can help in performance-critical sections where timing is known, and the goal is to wait for an event, then execute some code, then wait for an event, then execute some code and so on.

#### 14.3.5 DMA Request on PRS

Up to two independent DMA requests can be generated by the PRS. The PRS signals triggering the DMA requests are selected using the LDMA\_CHx\_REQSEL register, by setting SOURCESEL to PRS and SIGSEL to either PRSREQ0 or PRSREQ1. The DMA requests are cleared when the DMA services the requests. The requests are set whenever the selected PRS signals are high.


The selected PRS signals must have ASYNC cleared when they are used as inputs to the DMA. Edge detection in the PRS can be enabled to only trigger transfers on edges.

#### 14.3.6 Example

The example below (illustrated in [Figure 14.3 TIMER0 Overflow Starting ADC0 Single Conversions Through PRS Channel 5.](#) on page 451) shows how to set up ADC0 to start single conversions every time TIMER0 overflows (one HPERCLK cycle high pulse), using PRS channel 5:

- Set SOURCESEL in PRS\_CH5\_CTRL to TIMER0 as input to PRS channel 5.
- Set SIGSEL in PRS\_CH5\_CTRL to select the overflow signal (TIMER0OF from TIMER0).
- Configure ADC0 with the desired conversion set-up.
- Set SINGLEPRSEN in ADC0\_SINGLECTRL to 1 to enable single conversions to be started by a high PRS input signal.
- Set SINGLEPRSSEL in ADC0\_SINGLECTRL to 0x5 to select PRS channel 5 as input to start the single conversion.
- Start TIMER0 with the desired TOP value, an overflow PRS signal is output automatically on overflow.

Note that the ADC results needs to be fetched either by the CPU or DMA.



**Figure 14.3. TIMER0 Overflow Starting ADC0 Single Conversions Through PRS Channel 5.**

#### 14.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	PRS_SWPULSE	W1	Software Pulse Register
0x004	PRS_SWLEVEL	RW	Software Level Register
0x008	PRS_ROUTEPEN	RW	I/O Routing Pin Enable Register
0x010	PRS_ROUTELOC0	RW	I/O Routing Location Register
0x014	PRS_ROUTELOC1	RW	I/O Routing Location Register
0x030	PRS_CTRL	RW	Control Register
0x034	PRS_DMAREQ0	RW	DMA Request 0 Register
0x038	PRS_DMAREQ1	RW	DMA Request 1 Register
0x040	PRS_PEEK	R	PRS Channel Values
0x050	PRS_CH0_CTRL	RW	Channel Control Register
...	PRS_CHx_CTRL	RW	Channel Control Register
0x06C	PRS_CH7_CTRL	RW	Channel Control Register
0x100	PRS_TRACECTRL	RW	MTB Trace Control Register

## 14.5 Register Description

### 14.5.1 PRS\_SWPULSE - Software Pulse Register

Offset	Bit Position																															
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																
CH7PULSE	W1	0	7	CH6PULSE	W1	0	6	CH5PULSE	W1	0	5	CH4PULSE	W1	0	4	CH3PULSE	W1	0	3	CH2PULSE	W1	0	2	CH1PULSE	W1	0	1	CH0PULSE	W1	0		

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	CH7PULSE	0	W1	<b>Channel 7 Pulse Generation</b>  See bit 0.
6	CH6PULSE	0	W1	<b>Channel 6 Pulse Generation</b>  See bit 0.
5	CH5PULSE	0	W1	<b>Channel 5 Pulse Generation</b>  See bit 0.
4	CH4PULSE	0	W1	<b>Channel 4 Pulse Generation</b>  See bit 0.
3	CH3PULSE	0	W1	<b>Channel 3 Pulse Generation</b>  See bit 0.
2	CH2PULSE	0	W1	<b>Channel 2 Pulse Generation</b>  See bit 0.
1	CH1PULSE	0	W1	<b>Channel 1 Pulse Generation</b>  See bit 0.
0	CH0PULSE	0	W1	<b>Channel 0 Pulse Generation</b>  Write to 1 to generate one HFCLK cycle high pulse. This pulse is XOR'ed with the corresponding bit in the SWLEVEL register and the selected PRS input signal to generate the channel output.

## 14.5.2 PRS\_SWLEVEL - Software Level Register

Offset	Bit Position																									
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8		
Reset																									0	
Access																									1	
Name																									0	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	CH7LEVEL	0	RW	<b>Channel 7 Software Level</b>
	See bit 0.			
6	CH6LEVEL	0	RW	<b>Channel 6 Software Level</b>
	See bit 0.			
5	CH5LEVEL	0	RW	<b>Channel 5 Software Level</b>
	See bit 0.			
4	CH4LEVEL	0	RW	<b>Channel 4 Software Level</b>
	See bit 0.			
3	CH3LEVEL	0	RW	<b>Channel 3 Software Level</b>
	See bit 0.			
2	CH2LEVEL	0	RW	<b>Channel 2 Software Level</b>
	See bit 0.			
1	CH1LEVEL	0	RW	<b>Channel 1 Software Level</b>
	See bit 0.			
0	CH0LEVEL	0	RW	<b>Channel 0 Software Level</b>
	The value in this register is XOR'ed with the corresponding bit in the SWPULSE register and the selected PRS input signal to generate the channel output.			

### 14.5.3 PRS\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																																	
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																										0	0	0	0	0	0	0	0	
Access																										RW	RW							
Name																										CH7PEN	CH6PEN	CH5PEN	CH4PEN	CH3PEN	CH2PEN	CH1PEN	CH0PEN	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	CH7PEN	0	RW	<b>CH7 Pin Enable</b> When set, GPIO output from PRS channel 7 is enabled
6	CH6PEN	0	RW	<b>CH6 Pin Enable</b> When set, GPIO output from PRS channel 6 is enabled
5	CH5PEN	0	RW	<b>CH5 Pin Enable</b> When set, GPIO output from PRS channel 5 is enabled
4	CH4PEN	0	RW	<b>CH4 Pin Enable</b> When set, GPIO output from PRS channel 4 is enabled
3	CH3PEN	0	RW	<b>CH3 Pin Enable</b> When set, GPIO output from PRS channel 3 is enabled
2	CH2PEN	0	RW	<b>CH2 Pin Enable</b> When set, GPIO output from PRS channel 2 is enabled
1	CH1PEN	0	RW	<b>CH1 Pin Enable</b> When set, GPIO output from PRS channel 1 is enabled
0	CH0PEN	0	RW	<b>CH0 Pin Enable</b> When set, GPIO output from PRS channel 0 is enabled

#### 14.5.4 PRS ROUTELOC0 - I/O Routing Location Register

Bit	Name	Reset	Access	Description															
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
29:24	CH3LOC	0x00	RW	<b>I/O Location</b> Decides the location of the channel I/O pin															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr> <td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr> <td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr> <td>3</td><td>LOC3</td><td>Location 3</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3
Value	Mode	Description																	
0	LOC0	Location 0																	
1	LOC1	Location 1																	
2	LOC2	Location 2																	
3	LOC3	Location 3																	
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
21:16	CH2LOC	0x00	RW	<b>I/O Location</b> Decides the location of the channel I/O pin															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr> <td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr> <td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr> <td>3</td><td>LOC3</td><td>Location 3</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3
Value	Mode	Description																	
0	LOC0	Location 0																	
1	LOC1	Location 1																	
2	LOC2	Location 2																	
3	LOC3	Location 3																	
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
13:8	CH1LOC	0x00	RW	<b>I/O Location</b> Decides the location of the channel I/O pin															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr> <td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr> <td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr> <td>3</td><td>LOC3</td><td>Location 3</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3
Value	Mode	Description																	
0	LOC0	Location 0																	
1	LOC1	Location 1																	
2	LOC2	Location 2																	
3	LOC3	Location 3																	

Bit	Name	Reset	Access	Description
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:0	CH0LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the channel I/O pin

---

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3

## 14.5.5 PRS\_ROUTELOC1 - I/O Routing Location Register

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset					0x00								0x00																			0x00
Access				RW									RW										RW								RW	
Name			CH7LOC										CH6LOC										CH5LOC								CH4LOC	

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:24	CH7LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the channel I/O pin
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:16	CH6LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the channel I/O pin
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13:8	CH5LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the channel I/O pin
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:0	CH4LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the channel I/O pin

Bit	Name	Reset	Access	Description
	Value	Mode		Description
0	LOC0			Location 0
1	LOC1			Location 1
2	LOC2			Location 2

#### 14.5.6 PRS\_CTRL - Control Register

Offset	Bit Position																																
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
<b>Reset</b>																																	
<b>Access</b>																																	
<b>Name</b>																																	

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3:1	SEVONPRSEL	0x0	RW	<b>SEVONPRS PRS Channel Select</b>
	Selects PRS channel for SEVONPRS			
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected
	1	PRSCH1		PRS Channel 1 selected
	2	PRSCH2		PRS Channel 2 selected
	3	PRSCH3		PRS Channel 3 selected
	4	PRSCH4		PRS Channel 4 selected
	5	PRSCH5		PRS Channel 5 selected
	6	PRSCH6		PRS Channel 6 selected
	7	PRSCH7		PRS Channel 7 selected
0	SEVONPRS	0	RW	<b>Set Event on PRS</b>
	When set, an event is generated to the CPU when the PRS channel selected by SEVONPRSEL is high			

## 14.5.7 PRS\_DMAREQ0 - DMA Request 0 Register

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																												0x0				
<b>Access</b>																												RW				
<b>Name</b>																													PRSEL			

Bit	Name	Reset	Access	Description
31:9	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
8:6	PRSEL	0x0	RW	<b>DMA Request 0 PRS Channel Select</b>
	Selects PRS channel for DMA request 0 from the PRS (PRSREQ0).			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	
	4	PRSCH4	PRS Channel 4 selected	
	5	PRSCH5	PRS Channel 5 selected	
	6	PRSCH6	PRS Channel 6 selected	
	7	PRSCH7	PRS Channel 7 selected	
5:0	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		

## 14.5.8 PRS\_DMAREQ1 - DMA Request 1 Register

Offset	Bit Position																															
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																												0x0				
<b>Access</b>																												RW				
<b>Name</b>																													PRSEL			

Bit	Name	Reset	Access	Description
31:9	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
8:6	PRSEL	0x0	RW	<b>DMA Request 1 PRS Channel Select</b>
	Selects PRS channel for DMA request 1 from the PRS (PRSREQ1).			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	
	4	PRSCH4	PRS Channel 4 selected	
	5	PRSCH5	PRS Channel 5 selected	
	6	PRSCH6	PRS Channel 6 selected	
	7	PRSCH7	PRS Channel 7 selected	
5:0	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		

#### **14.5.9 PRS PEEK - PRS Channel Values**

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	CH7VAL	0	R	<b>Channel 7 Current Value</b>
	See bit 0.			
6	CH6VAL	0	R	<b>Channel 6 Current Value</b>
	See bit 0.			
5	CH5VAL	0	R	<b>Channel 5 Current Value</b>
	See bit 0.			
4	CH4VAL	0	R	<b>Channel 4 Current Value</b>
	See bit 0.			
3	CH3VAL	0	R	<b>Channel 3 Current Value</b>
	See bit 0.			
2	CH2VAL	0	R	<b>Channel 2 Current Value</b>
	See bit 0.			
1	CH1VAL	0	R	<b>Channel 1 Current Value</b>
	See bit 0.			
0	CH0VAL	0	R	<b>Channel 0 Current Value</b>
	When ASYNC = 0, sample the current output value of channel 0. Any enabled edge detection will not be visible. This value may be one or two clock delayed. When ASYNC = 1, no value is returned			

#### 14.5.10 PRS CHx CTRL - Channel Control Register

Bit	Name	Reset	Access	Description
31	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
30	ASYNC	0	RW	<b>Asynchronous Reflex</b>  Set to enable asynchronous mode of this reflex signal
29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28	ANDNEXT	0	RW	<b>And Next</b>  If set, channel output is AND'ed with the next channel output
27	ORPREV	0	RW	<b>Or Previous</b>  If set, channel output is OR'ed with the previous channel output
26	INV	0	RW	<b>Invert Channel</b>  If set, channel output is inverted
25	STRETCH	0	RW	<b>Stretch Channel Output</b>  If set, stretches channel output to ensure that the target clock domain sees it.
24:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	EDSEL	0x0	RW	<b>Edge Detect Select</b>  Select edge detection.
<hr/>				
Value	Mode	Description		
0	OFF	Signal is left as it is		
1	POSEDGE	A one HFCLK cycle pulse is generated for every positive edge of the incoming signal		
2	NEGEDGE	A one HFCLK clock cycle pulse is generated for every negative edge of the incoming signal		
3	BOTHEDGES	A one HFCLK clock cycle pulse is generated for every edge of the incoming signal		
<hr/>				
19:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
14:8	SOURCESEL	0x00	RW	<b>Source Select</b>
Select input source to PRS channel.				
	Value	Mode		Description
	0b00000000	NONE		No source selected
	0b00000001	PRSL		Peripheral Reflex System
	0b00000010	ACMP0		Analog Comparator 0
	0b00000011	ACMP1		Analog Comparator 1
	0b00000100	ADC0		Analog to Digital Converter 0
	0b00000101	RTCC		Real-Time Counter and Calendar
	0b00000110	GPIOL		General purpose Input/Output
	0b00000111	GPIOH		General purpose Input/Output
	0b0001000	LETIMERO		Low Energy Timer 0
	0b0001001	PCNT0		Pulse Counter 0
	0b0001010	CRYOTIMER		CRYOTIMER
	0b0001011	CMU		Clock Management Unit
	0b0010001	VDAC0		Digital to Analog Converter 0
	0b0010010	LESENSEL		Low Energy Sensor Interface
	0b0010011	LESENSEH		Low Energy Sensor Interface
	0b0010100	LESENSED		Low Energy Sensor Interface
	0b0010101	LESENSE		Low Energy Sensor Interface
	0b0100000	USART0		Universal Synchronous/Asynchronous Receiver/Transmitter 0
	0b0100001	USART1		Universal Synchronous/Asynchronous Receiver/Transmitter 1
	0b0100010	USART2		Universal Synchronous/Asynchronous Receiver/Transmitter 2
	0b0100011	USART3		Universal Synchronous/Asynchronous Receiver/Transmitter 3
	0b0100100	UART0		Universal Asynchronous Receiver/Transmitter 0
	0b0100101	TIMER0		Timer 0
	0b0100110	TIMER1		Timer 1
	0b0100111	WTIMERO		Wide Timer 0
	0b0101000	WTIMER1		Wide Timer 1
	0b0101001	CM0P		
7:3	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
2:0	SIGSEL	0x0	RW	<b>Signal Select</b>
Select signal input to PRS channel. Selected signal depends on SOURCESEL as indicated.				
	Value	Mode		Description
	SOURCESEL = 0b0000000			(NONE)

Bit	Name	Reset	Access	Description
0bxxx		OFF		Channel input selection is turned off
SOURCESEL =	<i>0b0000001</i>			(PRSL)
0b000	PRSCH0			PRS channel 0 PRSCH0 (Asynchronous)
0b001	PRSCH1			PRS channel 1 PRSCH1 (Asynchronous)
0b010	PRSCH2			PRS channel 2 PRSCH2 (Asynchronous)
0b011	PRSCH3			PRS channel 3 PRSCH3 (Asynchronous)
0b100	PRSCH4			PRS channel 4 PRSCH4 (Asynchronous)
0b101	PRSCH5			PRS channel 5 PRSCH5 (Asynchronous)
0b110	PRSCH6			PRS channel 6 PRSCH6 (Asynchronous)
0b111	PRSCH7			PRS channel 7 PRSCH7 (Asynchronous)
SOURCESEL =	<i>0b0000010</i>			(ACMP0)
0b000	ACMP0OUT			Analog comparator output ACMP0OUT (Asynchronous)
SOURCESEL =	<i>0b0000011</i>			(ACMP1)
0b000	ACMP1OUT			Analog comparator output ACMP1OUT (Asynchronous)
SOURCESEL =	<i>0b0000100</i>			(ADC0)
0b000	ADC0SINGLE			ADC single conversion done ADC0SINGLE (Asynchronous)
0b001	ADC0SCAN			ADC scan conversion done ADC0SCAN (Asynchronous)
SOURCESEL =	<i>0b0000101</i>			(RTCC)
0b001	RTCCCCV0			RTCC Compare 0 RTCCCCV0 (Asynchronous)
0b010	RTCCCCV1			RTCC Compare 1 RTCCCCV1 (Asynchronous)
0b011	RTCCCCV2			RTCC Compare 2 RTCCCCV2 (Asynchronous)
SOURCESEL =	<i>0b0000110</i>			(GPIOL)
0b000	GPIOPIN0			GPIO pin 0 GPIOPIN0 (Asynchronous)
0b001	GPIOPIN1			GPIO pin 1 GPIOPIN1 (Asynchronous)
0b010	GPIOPIN2			GPIO pin 2 GPIOPIN2 (Asynchronous)
0b011	GPIOPIN3			GPIO pin 3 GPIOPIN3 (Asynchronous)
0b100	GPIOPIN4			GPIO pin 4 GPIOPIN4 (Asynchronous)
0b101	GPIOPIN5			GPIO pin 5 GPIOPIN5 (Asynchronous)
0b110	GPIOPIN6			GPIO pin 6 GPIOPIN6 (Asynchronous)
0b111	GPIOPIN7			GPIO pin 7 GPIOPIN7 (Asynchronous)
SOURCESEL =	<i>0b0000111</i>			(GPIOH)
0b000	GPIOIN8			GPIO pin 8 GPIOIN8 (Asynchronous)
0b001	GPIOIN9			GPIO pin 9 GPIOIN9 (Asynchronous)
0b010	GPIOIN10			GPIO pin 10 GPIOIN10 (Asynchronous)
0b011	GPIOIN11			GPIO pin 11 GPIOIN11 (Asynchronous)
0b100	GPIOIN12			GPIO pin 12 GPIOIN12 (Asynchronous)
0b101	GPIOIN13			GPIO pin 13 GPIOIN13 (Asynchronous)

Bit	Name	Reset	Access	Description
0b110	GPIOPIN14			GPIO pin 14 GPIOPIN14 (Asynchronous)
0b111	GPIOPIN15			GPIO pin 15 GPIOPIN15 (Asynchronous)
SOURCESEL =	0b0001000			(LETIMER0)
0b000	LETIMER0CH0			LETIMER CH0 Out LETIMER0CH0 (Asynchronous)
0b001	LETIMER0CH1			LETIMER CH1 Out LETIMER0CH1 (Asynchronous)
SOURCESEL =	0b0001001			(PCNT0)
0b000	PCNT0TCC			Triggered compare match PCNT0TCC (Asynchronous)
0b001	PCNT0UFOF			Counter overflow or underflow PCNT0UFOF (Asynchronous)
0b010	PCNT0DIR			Counter direction PCNT0DIR (Asynchronous)
SOURCESEL =	0b0001010			(CRYOTIMER)
0b000	CRYOTIMERPERIOD			CRYOTIMER Output CRYOTIMERPERIOD (Asynchronous)
SOURCESEL =	0b0001011			(CMU)
0b000	CMUCLKOUT0			Clock Output 0 CMUCLKOUT0 (Asynchronous)
0b001	CMUCLKOUT1			Clock Output 1 CMUCLKOUT1 (Asynchronous)
0b111	CMUCLKOUT2			Clock Output 2 CMUCLKOUT2 (Asynchronous)
SOURCESEL =	0b0010001			(VDAC0)
0b000	VDAC0CH0			DAC ch0 conversion done VDAC0CH0
0b001	VDAC0CH1			DAC ch1 conversion done VDAC0CH1
0b010	VDAC0OPA0			OPA0 warmed up. output is valid. VDAC0OPA0 (Asynchronous)
0b011	VDAC0OPA1			OPA1 warmed up. output is valid. VDAC0OPA1 (Asynchronous)
0b100	VDAC0OPA2			OPA2 warmed up. output is valid. VDAC0OPA2 (Asynchronous)
0b101	VDAC0OPA3			OPA3 warmed up. output is valid. VDAC0OPA3 (Asynchronous)
SOURCESEL =	0b0010010			(LESENSEL)
0b000	LESENSESCANRES0			LESENSE SCANRES register, bit 0 LESENSESCANRES0 (Asynchronous)
0b001	LESENSESCANRES1			LESENSE SCANRES register, bit 1 LESENSESCANRES1 (Asynchronous)
0b010	LESENSESCANRES2			LESENSE SCANRES register, bit 2 LESENSESCANRES2 (Asynchronous)
0b011	LESENSESCANRES3			LESENSE SCANRES register, bit 3 LESENSESCANRES3 (Asynchronous)
0b100	LESENSESCANRES4			LESENSE SCANRES register, bit 4 LESENSESCANRES4 (Asynchronous)
0b101	LESENSESCANRES5			LESENSE SCANRES register, bit 5 LESENSESCANRES5 (Asynchronous)
0b110	LESENSESCANRES6			LESENSE SCANRES register, bit 6 LESENSESCANRES6 (Asynchronous)
0b111	LESENSESCANRES7			LESENSE SCANRES register, bit 7 LESENSESCANRES7 (Asynchronous)
SOURCESEL =	0b0010011			(LESENSEH)

Bit	Name	Reset	Access	Description
0b000	LESENSESCANRES8			LESENSE SCANRES register, bit 8 LESENSESCANRES8 (Asynchronous)
0b001	LESENSESCANRES9			LESENSE SCANRES register, bit 9 LESENSESCANRES9 (Asynchronous)
0b010	LESENSESCANRES10			LESENSE SCANRES register, bit 10 LESENSESCANRES10 (Asynchronous)
0b011	LESENSESCANRES11			LESENSE SCANRES register, bit 11 LESENSESCANRES11 (Asynchronous)
0b100	LESENSESCANRES12			LESENSE SCANRES register, bit 12 LESENSESCANRES12 (Asynchronous)
0b101	LESENSESCANRES13			LESENSE SCANRES register, bit 13 LESENSESCANRES13 (Asynchronous)
0b110	LESENSESCANRES14			LESENSE SCANRES register, bit 14 LESENSESCANRES14 (Asynchronous)
0b111	LESENSESCANRES15			LESENSE SCANRES register, bit 15 LESENSESCANRES15 (Asynchronous)
SOURCESEL =	<i>0b0010100</i>			(LESENSED)
0b000	LESENSEDEC0			LESENSE Decoder PRS out 0 LESENSEDEC0 (Asynchronous)
0b001	LESENSEDEC1			LESENSE Decoder PRS out 1 LESENSEDEC1 (Asynchronous)
0b010	LESENSEDEC2			LESENSE Decoder PRS out 2 LESENSEDEC2 (Asynchronous)
0b011	LESENSEDECCMP			LESENSE Decoder PRS compare value match channel LESENSE-DECCMP (Asynchronous)
SOURCESEL =	<i>0b0010101</i>			(LESENSE)
0b000	LESENSEMEASACT			LESENSE Measurement active LESENSEMEASACT (Asynchronous)
SOURCESEL =	<i>0b0100000</i>			(USART0)
0b000	USART0IRTX			USART0IRTX
0b001	USART0TXC			USART0TXC
0b010	USART0RXDATAV			USART0RXDATAV
0b011	USART0RTS			USART0RTS
0b101	USART0TX			USART0TX
0b110	USART0CS			USART0CS
SOURCESEL =	<i>0b0100001</i>			(USART1)
0b001	USART1TXC			USART1TXC
0b010	USART1RXDATAV			USART1RXDATAV
0b011	USART1RTS			USART1RTS
0b101	USART1TX			USART1TX
0b110	USART1CS			USART1CS
SOURCESEL =	<i>0b0100010</i>			(USART2)
0b000	USART2IRTX			USART 2 IRDA out USART2IRTX (Asynchronous)
0b001	USART2TXC			USART2TXC
0b010	USART2RXDATAV			USART2RXDATAV

Bit	Name	Reset	Access	Description
0b011	USART2RTS	USART2RTS		
0b101	USART2TX	USART2TX		
0b110	USART2CS	USART2CS		
SOURCESEL =	<i>0b0100011</i>	(USART3)		
0b001	USART3TXC	USART3TXC		
0b010	USART3RXDATAV	USART3RXDATAV		
0b011	USART3RTS	USART3RTS		
0b101	USART3TX	USART3TX		
0b110	USART3CS	USART3CS		
SOURCESEL =	<i>0b0100100</i>	(UART0)		
0b001	UART0TXC	UART0TXC		
0b010	UART0RXDATAV	UART0RXDATAV		
0b011	UART0RTS	UART0RTS		
0b101	UART0TX	UART0TX		
0b110	UART0CS	UART0CS		
SOURCESEL =	<i>0b0100101</i>	(TIMER0)		
0b000	TIMER0UF	TIMER0UF		
0b001	TIMER0OF	TIMER0OF		
0b010	TIMER0CC0	TIMER0CC0		
0b011	TIMER0CC1	TIMER0CC1		
0b100	TIMER0CC2	TIMER0CC2		
SOURCESEL =	<i>0b0100110</i>	(TIMER1)		
0b000	TIMER1UF	TIMER1UF		
0b001	TIMER1OF	TIMER1OF		
0b010	TIMER1CC0	TIMER1CC0		
0b011	TIMER1CC1	TIMER1CC1		
0b100	TIMER1CC2	TIMER1CC2		
0b101	TIMER1CC3	TIMER1CC3		
SOURCESEL =	<i>0b0100111</i>	(WTIMER0)		
0b000	WTIMER0UF	WTIMER0UF		
0b001	WTIMER0OF	WTIMER0OF		
0b010	WTIMER0CC0	WTIMER0CC0		
0b011	WTIMER0CC1	WTIMER0CC1		
0b100	WTIMER0CC2	WTIMER0CC2		
SOURCESEL =	<i>0b0101000</i>	(WTIMER1)		
0b000	WTIMER1UF	WTIMER1UF		
0b001	WTIMER1OF	WTIMER1OF		

Bit	Name	Reset	Access	Description
0b010	WTIMER1CC0	WTIMER1CC0		
0b011	WTIMER1CC1	WTIMER1CC1		
0b100	WTIMER1CC2	WTIMER1CC2		
0b101	WTIMER1CC3	WTIMER1CC3		
SOURCESEL =	0b0101001	(CM0P)		
0b000	CM0PTXEV	CM0PTXEV		
0b001	CM0PICACHEPCHIT-SOF	CM0PICACHEPCHITSOF		
0b010	CM0PICACHEPCMISSESOF	CM0PICACHEPCMISSESOF		



## 14.5.11 PRS\_TRACECTRL - MTB Trace Control Register

Offset	Bit Position																
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15
<b>Reset</b>																	11
<b>Access</b>																	10
<b>Name</b>																	9
																	8
																	7
																	6
																	5
																	4
																	3
																	2
																	1
																	0

Bit	Name	Reset	Access	Description
31:12	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
11:9	TSTOP	0x0	RW	<b>MTB TSTOP PRS Select</b>
	Select PRS channel controlling the TSTOP signal to the MTB.			
	Value	Mode	Description	
	0	PRSCH0	PRS ch 0 is controlling TSTOP.	
	1	PRSCH1	PRS ch 1 is controlling TSTOP.	
	2	PRSCH2	PRS ch 2 is controlling TSTOP.	
	3	PRSCH3	PRS ch 3 is controlling TSTOP.	
	4	PRSCH4	PRS ch 4 is controlling TSTOP.	
	5	PRSCH5	PRS ch 5 is controlling TSTOP.	
	6	PRSCH6	PRS ch 6 is controlling TSTOP.	
	7	PRSCH7	PRS ch 7 is controlling TSTOP.	
8	TSTOPEN	0	RW	<b>PRS TSTOP Enable</b>
	Set PRS control of the TSTOP-signal going to the MTB.			
	Value	Description		
	0	TSTOP is not controlled by PRS.		
	1	TSTOP is controlled by PRS.		
7:4	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
3:1	TSTART	0x0	RW	<b>MTB TSTART PRS Select</b>
	Select PRS channel controlling the TSTART signal to the MTB.			
	Value	Mode	Description	
	0	PRSCH0	PRS ch 0 is controlling TSTART.	
	1	PRSCH1	PRS ch 1 is controlling TSTART.	
	2	PRSCH2	PRS ch 2 is controlling TSTART.	
	3	PRSCH3	PRS ch 3 is controlling TSTART.	

Bit	Name	Reset	Access	Description						
4	PRSCH4			PRS ch 4 is controlling TSTART.						
5	PRSCH5			PRS ch 5 is controlling TSTART.						
6	PRSCH6			PRS ch 6 is controlling TSTART.						
7	PRSCH7			PRS ch 7 is controlling TSTART.						
0	TSTARTEN	0	RW	<b>PRS TSTART Enable</b>						
				Set PRS control of the TSTART-signal going to the MTB.						
				<table border="1"><thead><tr><th>Value</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>TSTART is not controlled by PRS.</td></tr><tr><td>1</td><td>TSTART is controlled by PRS.</td></tr></tbody></table>	Value	Description	0	TSTART is not controlled by PRS.	1	TSTART is controlled by PRS.
Value	Description									
0	TSTART is not controlled by PRS.									
1	TSTART is controlled by PRS.									

## 15. LCD - Liquid Crystal Display Driver



### Quick Facts

#### What?

The LCD driver can drive LCD displays of up to 8x32 segments. The animation feature makes it possible to have active animations without CPU intervention.

#### Why?

Segmented LCD displays are a common way to display information. The extreme low-power LCD driver enables a lot of applications to utilize an LCD display even in energy critical systems.

#### How?

The low frequency clock signal, low-power waveform, animation and blink capabilities enable the LCD driver to run autonomously in EM2 DeepSleep for long periods. Adding the flexible frame rate setting, contrast control, and different multiplexing modes make the EFM32 Tiny Gecko 11 the optimal choice for battery-driven systems with LCD panels.

### 15.1 Introduction

The LCD driver is capable of driving a segmented LCD display combination of: 1x36, 2x36, 3x36, 4x36, 6x34 or 8x32 segments. A charge pump enables it to provide the LCD display with higher voltage than the supply voltage for the device. In addition, an animation feature can run custom animations on the LCD display without any CPU intervention. The LCD driver can also remain active in Energy Mode 2 and provides a Frame Counter interrupt that can wake-up the device on a regular basis for updating data.


### 15.2 Features

- Up to 4x36 or 8x32 segments.
- Configurable multiplexing (1, 2, 3, 4, 6, 8)
- LCD supports the following COM/SEG combinations
  - 1x36, 2x36, 3x36, 4x36, 6x34 or 8x32
- Configurable bias/voltage levels settings
- Configurable clock source prescaler
- Configurable Frame rate
- Segment lines can be enabled or disabled individually
- Blink capabilities
- Integrated animation functionality
  - Available on SEG0-SEG7 or SEG8-SEG15
- Charge redistribution feature reduces LCD module current consumption by up to 40%
- Charge pump
- Programmable contrast
- Frame Counter
- LCD frame interrupt
- Direct segment control

### 15.3 Functional Description

An overview of the LCD module is shown in [Figure 15.1 LCD Block Diagram on page 472](#). The module provides the necessary waveforms for turning each segment of an LCD display on or off.

The waveforms are multiplexed between eight (1-8) different common lines and segment lines to support up to 256 different LCD segments. The common lines and segment lines can be enabled or disabled individually to prevent the LCD driver from occupying more I/O resources than required.



**Figure 15.1. LCD Block Diagram**

#### 15.3.1 Power Supply

The LCD block power ( $V_{LCDIN}$ ) is derived from the VDDX\_ANA supply rail. VDDX\_ANA can be selected from the AVDD or DVDD supply pins using the EMU\_PWRCTRL\_ANASW bit field. The LCD block generates its own stable supply ( $V_{LCD}$ ), which is used to derive all output voltages.

#### 15.3.2 LCD Driver Enable

Setting the EN bit in LCD\_CTRL enables the LCD driver. The MUX bit-field in LCD\_DISPCTRL determines which COM lines are driven by the LCD driver. By default, LCD\_COM0 is driven whenever the LCD driver is enabled. The LCD\_SEGEN and SEGGEN2 registers determine which segment lines are enabled or disabled. Individual segment lines can be enabled or disabled.

Each pin being used by the LCD block should be set to the DISABLED state in the GPIO block. Any other GPIO setting will prevent the LCD controller from accessing the pin. See the device data sheet for a mapping of LCD signals to GPIO pins.

### 15.3.3 LCD Frame Rate and Power Reduction

LCD Frame rates are usually set between 30 to 100 frames per second (FPS). The LFCLK<sub>LCD</sub> can be prescaled in the CMU. FRDIV in LCD\_FRAMERATE is used to further divide the LCD clock rate and provides the final frame rate. The power consumption of the LCD panel itself can be lowered through the use of charge redistribution. When charge redistribution is in use, all segments are briefly shorted together, allowing low segments to be partially charged by the energy in high segments instead of using additional energy from the power supply. A Static MUX selection will have two phase periods per frame, while an Octaplex MUX selection will have 16 phase periods per frame.

CHGRDST in LCD\_DISPCTRL is used to select the number of prescaled LFCLK<sub>LCD</sub> cycles used for charge redistribution. Refer to [Figure 15.2 Charge Redistribution Cycle Percentage on page 473](#) to calculate the charge redistribution cycle percentage (CHGRDST PERCENT).

$$\text{CHGRDST PERCENT} = \text{CHGRDST} / \text{FR Divider}$$

**Figure 15.2. Charge Redistribution Cycle Percentage**

The charge redistribution cycle percentage should be 5% or less to prevent reduction in LCD pad RMS voltage. If charge redistribution is not used, a larger CMU prescaling value is recommended to minimize power consumed by the LCD block itself. Note that disabling charge redistribution will always result in higher system power consumption. Charge redistribution is on by default, but it can be disabled by setting CHGRDST to disable in LCD\_DISPCTRL. Refer to table [Table 15.1 LCD Frame Rate on page 473](#) for examples of the percentage of time that charge redistribution is on in various scenarios using a 32 kHz clock.

**Table 15.1. LCD Frame Rate**

MUX	CHGRDST	CMU Prescaler	FR Divider	FPS	CHGRDST PERCENT
Static	4	DIV1	512	32.0	0.8%
Static	4	DIV1	163	100.5	2.5%
Static	1	DIV16	32	32.0	3.1%
Static	1	DIV8	20	102.4	5.0%
Static	0	DIV128	4	32.0	0.0%
Static	0	DIV32	5	102.4	0.0
Quadruplex	4	DIV1	136	30.1	2.9%
Quadruplex	2	DIV1	40	102.4	5.0%
Quadruplex	1	DIV4	34	30.1	2.9%
Quadruplex	1	DIV2	20	102.4	5.0%
Quadruplex	0	DIV16	8	32.0	0.0%
Quadruplex	0	DIV4	10	102.4	0.0%
Octaplex	2	DIV1	68	30.1	2.9%
Octaplex	1	DIV1	20	102.4	5.0%
Octaplex	1	DIV2	34	30.1	2.9%
Octaplex	0	DIV64	1	32.0	0.0%

#### 15.3.4 Multiplexing, Bias, and Wave Settings

The LCD driver supports different multiplexing and bias settings, and these can be set individually in the MUX and BIAS bits in LCD\_DISPCTRL respectively, see [Table 15.2 LCD Mux Settings on page 474](#) and [Table 15.3 LCD BIAS Settings on page 474](#).

**Note:** If the MUX and BIAS settings in LCD\_DISPCTRL are changed while the LCD driver is enabled, the output waveform is unpredictable and may lead to a DC-component for one LCD frame.

The MUX setting determines the number of LCD COM lines that are enabled. When using octaplex or sextaplex multiplexing, the additional COM lines used (COM4-COM7) are actually located on the (SEG20-SEG23) lines. When static multiplexing is selected, LCD output is enabled on LCD\_COM0, when duplex multiplexing is used, LCD\_COM0-LCD\_COM1 are used, when triplex multiplexing is selected, LCD\_COM0-LCD\_COM2 are used, when quadruplex multiplexing is selected, LCD\_COM0-LCD\_COM3 are used, when sextaplex multiplexing is selected, LCD\_COM0-LCD\_COM3 and SEG20-SEG21 act as common pins, reducing the number of available segment pins to 34 . Finally when octaplex multiplexing is selected, LCD\_COM0-LCD\_COM3 and SEG20-SEG23 act as common pins, reducing the number of available segment pins to 32 .

See [15.3.15 Waveform Examples](#) for waveforms for the different bias and multiplexing settings.

The waveforms generated by the LCD controller can be generated in two different versions, regular and low-power. The low power mode waveforms have a lower switching frequency than the regular waveforms, and thus consume less power. The WAVE bit in LCD\_DISPCTRL decides which waveforms to generate. An example of a low-power waveform is shown in [Figure 15.3 LCD Low-power Waveform for LCD\\_COM0 in Quadruples Multiplex Mode, 1/3 Bias on page 475](#), and an example of a regular waveform is shown in [Figure 15.4 LCD Normal Waveform for LCD\\_COM0 in Quadruples Multiplex Mode, 1/3 Bias on page 475](#). For COM waveforms, a green dotted lines indicates where the SEG waveform would be for an 'on' level while the red dotted lines indicate where the SEG waveform would be for an 'off' level.

**Table 15.2. LCD Mux Settings**



MUX	Mode	Multiplexing
000	Static	Static (segments can be multiplexed with LCD_COM[0])
001	Duplex	Duplex (segments can be multiplexed with LCD_COM[1:0])
010	Triplex	Triplex (segments can be multiplexed with LCD_COM[2:0])
011	Quadruplex	Quadruplex (segments can be multiplexed with LCD_COM[3:0])
101	Sextaplex	Sextaplex (segments can be multiplexed with LCD_COM[3:0] and SEG[21:20])
111	Octaplex	Octaplex (segments can be multiplexed with LCD_COM[3:0] and SEG[23:20])

**Table 15.3. LCD BIAS Settings**

BIAS	Mode	Bias setting
00	Static	Static (2 levels)
01	Half Bias	1/2 Bias (3 levels)
10	Third Bias	1/3 Bias (4 levels)
11	Fourth Bias	1/4 Bias (5 levels)

**Table 15.4. LCD Wave Settings**

WAVE	Mode	Wave mode
0	LowPower	Low power optimized waveform output
1	Normal	Regular waveform output

**Figure 15.3. LCD Low-power Waveform for LCD\_COM0 in Quadruples Multiplex Mode, 1/3 Bias****Figure 15.4. LCD Normal Waveform for LCD\_COM0 in Quadruples Multiplex Mode, 1/3 Bias**

### 15.3.5 LCD Contrast

To compensate for variations in LCD panels, the LCD driver has a programmable contrast that adjusts  $V_{LCD}$ . The contrast is set by CONTRAST in LCD\_DISPCTRL.

**Table 15.5. LCD Contrast**

Mode	Equation for $V_{LCD}$
current source	(CONTRAST[4:0] + 25) * 68.6mV
step down and charge pump	(CONTRAST[5:0] + 24) * 43.3mV

### 15.3.6 Voltage Levels and Mode Selection

By default,  $V_{LCD}$  is powered from the AVDD pin. If the ANASW bitfield in EMU->PWRCTRL is set,  $V_{LCD}$  will be powered from the DVDD pin instead. However, if using the DC-DC Converter the DVDD pin will typically be at 1.8 V, and thus not suitable for driving an LCD display directly.

The number of LCD bias levels is controlled by BIAS field in LCD\_DISPCTRL. When BIAS is set to ONEFOURTH, voltages of  $V_{LCD}$ ,  $\frac{3}{4}V_{LCD}$ ,  $\frac{1}{2}V_{LCD}$ ,  $\frac{1}{4}V_{LCD}$ , and VSS are generated. For a BIAS setting of ONETHIRD, the generated voltages are  $V_{LCD}$ ,  $\frac{2}{3}V_{LCD}$ ,  $\frac{1}{3}V_{LCD}$ , and VSS. For a BIAS setting of ONEHALF, the generated voltages are  $V_{LCD}$ ,  $\frac{1}{2}V_{LCD}$ , and VSS. For a BIAS setting of STATIC, the voltage are only  $V_{LCD}$  and VSS.

Three modes are available for setting the  $V_{LCD}$  level: current source mode, step down mode, or charge pump mode. For the current source mode no external capacitor is used. An internal current source is adjusted using CONTRAST[4:0] in LCD\_DISPCTRL to set the  $V_{LCD}$  voltage level.

For the step down mode an external capacitor is regulated using an LCD comparator to maintain a  $V_{LCD}$  voltage that is not greater than the supply voltage.

For the charge pump mode, a voltage of up to twice the supply voltage is generated internally and maintained on an external capacitor, which maintains the  $V_{LCD}$  voltage.

In both the step down and charge pump modes, the LCD\_BEXT signal is used. The LCD\_BEXT pin should be connected through a capacitor to VSS. For most applications, a 1  $\mu$ F capacitor is sufficient to prevent any visible artifacts from supply ripple. However, larger capacitors may be used to reduce the supply ripple if needed. The recommended value is approximately 1000 times the total LCD segment capacitance.

**Note:** All LCD pins should have the OVT protection enabled using GPIO\_Px\_OVTDIS registers before the LCD is enabled. The segment/com enables should not be changed while the LCD is enabled.

### 15.3.7 Frame Rate

It is important to choose the correct frame rate for the LCD display. Normally, the frame rate should be between 30 and 100 Hz. A frame rate below 30 Hz may lead to flickering, while a frame rate above 100 Hz may lead to ghosting and unnecessarily high power consumption.

#### 15.3.7.1 Clock Selection and Prescaler

The LFACLK is prescaled to LFACLK<sub>LCDpre</sub> in the CMU. In addition to selecting the correct prescaling, the clock source can be selected in the CMU. To use this module, the LE interface clock must be enabled in CMU\_HFBUSCLKEN0, in addition to the module clock.

### 15.3.7.2 Frame Rate Division Register

The frame rate is set with FRDIV in LCD\_FRAMERATE. FRDIV sets the frame rate phase frequency and the number of phases per frame is determined by the multiplex setting. Each COM line requires two phases. This setting should not be changed while the LCD driver is running. The equation for calculating the resulting frame rate is given from [Figure 15.5 LCD Frame rate Calculation on page 477](#)

$$\text{LFACLK}_{\text{LCD}} = \text{LFACLK}_{\text{LCDpre}} / (1 + \text{FRDIV})$$

**Figure 15.5. LCD Frame rate Calculation**

### 15.3.8 Data Update

The LCD driver logic that controls the output waveforms is clocked on LFACLK<sub>LCDpre</sub>. The LCD data and Control Registers are clocked on the HFCORECLK. Segment data should not be changed in the middle of a frame. The LCD driver has functionality to synchronize data transfer to the LCD frames. The synchronization logic is applied to all data that need to be updated at the beginning of the LCD frames:

- LCD\_SEGDn
- LCD\_AREGA
- LCD\_AREGB
- LCD\_BACTRL

The different methods to update data are controlled by the UDCTRL bits in LCD\_CTRL.

**Table 15.6. LCD Update Data Control (UDCTRL) Bits**

UDCTRL	Mode	Description
00	REGULAR	The data transfer is controlled by SW and data synchronization is initiated by writing data to the buffers. Data is transferred as soon as possible, possibly creating a frame with a DC component on the LCD.
01	FCEVENT	The data transfer is done at the next event triggered by the Frame Counter (FC). See <a href="#">15.3.10 Frame Counter (FC)</a> for details on how to configure the Frame Counter. Optionally, the Frame Counter can also generate an interrupt at every event.
10	FRAMESTART	The data transfer is done at frame-start.

### 15.3.9 Direct Segment Control (DSC)

It is possible to gain direct control over the bias levels for each SEG/COM line by setting DSC in LCD\_CTRL, overwriting the BIAS settings in LCD\_DISPCTRL. The SEG lines bias levels can be set in SEGD0-SEGD3, while the COM line bias levels can be set in SEGD4. To represent the different bias levels, 4-bits per SEG lines are needed. For example, SEG0's bias levels can be set using SEGD0[3:0], and SEG1 can be controlled through SEGD1[3:0] etc. Bias level encoding is shown in [Table 15.7 DSC BIAS Encoding on page 478](#), and segment/common locations are shown in [Table 15.8 DSC Segment and Common Mapping on page 478](#).

**Table 15.7. DSC BIAS Encoding**

SEGD	Bias setting
0000	tristate
0001	VSS
0010	1/3 or 1/4 $V_{LCD}$
0011	1/2 $V_{LCD}$
0100	2/3 or 3/4 $V_{LCD}$
0101	$V_{LCD}$

**Table 15.8. DSC Segment and Common Mapping**

Register	H[3:0]	L[31:28]	L[27:24]	L[23:20]	L[19:16]	L[15:12]	L[11:8]	L[7:4]	L[3:0]
SEGD0	seg32	seg28	seg24	seg20	seg16	seg12	seg8	seg4	seg0
SEGD1	seg33	seg29	seg25	seg21	seg17	seg13	seg9	seg5	seg1
SEGD2	seg34	seg30	seg26	seg22	seg18	seg14	seg10	seg6	seg2
SEGD3	seg35	seg31	seg27	seg23	seg19	seg15	seg11	seg7	seg3
SEGD4						com3	com2	com1	com0

### 15.3.10 Frame Counter (FC)

The Frame Counter is synchronized to the LCD frame start and will generate an event after a programmable number of frames. An FC event can trigger:

- LCD ready interrupt
- Blink (controlling the blink frequency)
- Next state in the Animation State Machine
- Data update if UDCTRL = 01

The Frame Counter is a down counter. It is enabled by writing FCEN in LCD\_BACTRL. Optionally, the Frame Counter can be prescaled so that the Frame Counter is decremented at:

- Every frame
- Every second frame
- Every fourth frame
- Every eight frame

This is controlled by the FCPRESC in LCD\_BACTRL, see [Table 15.9 FCPRESC on page 479](#)

**Table 15.9. FCPRESC**

FCPRES	Mode	Description	General equation
00	Div1	CLK <sub>FRAME</sub> /1	$CLK_{FC} = CLK_{FRAME}/2^{FCPRES}$
01	Div2	CLK <sub>FRAME</sub> /2	
10	Div4	CLK <sub>FRAME</sub> /4	
11	Div8	CLK <sub>FRAME</sub> /8	

The top value for the Frame Counter is set by FCTOP in LCD\_BACTRL. Every time the frame counter reaches zero, it is reloaded with the top value, and an event is triggered.

$$CLK_{EVENT} = CLK_{FC}/(1 + FCTOP[5:0]) \text{ Hz}$$

**Figure 15.6. LCD Event Frequency Equation**

The above equation shows how to set up the LCD event frequency. As an example, if the frame rate is 64Hz, in order to have a LCD event frequency of 0.5Hz, the following parameters should be set accordingly:

- Write FCPRESC to 3 => CLK<sub>FC</sub> = 8Hz (0.125 seconds)
- Write FCTOP to 15 => CLK<sub>EVENT</sub> = 0.5Hz (2 seconds)

If higher resolution is required, configure a lower prescaler value and increase the FCTOP value accordingly (e.g. FCPRESC = 2, FCTOP = 31).

### 15.3.11 LCD Interrupt

The LCD interrupt can be used to synchronize data update. The FC interrupt flag is set at every LCD Frame Counter Event. The interrupt is enabled by setting FC bit in LCD\_IEN.

### 15.3.12 Blink, Blank, and Animation Features

#### 15.3.12.1 Blink

The LCD driver can be configured to blink, alternating all enabled segments between on and off. The blink frequency is given by the CLK<sub>EVENT</sub> frequency, see [15.3.10 Frame Counter \(FC\)](#). See [15.3.8 Data Update](#) for details regarding synchronization of the blink feature. The FC must be on for blink to work.

### 15.3.12.2 Blank

Setting BLANK in LCD\_BACTRL will output the “OFF” waveform on all enabled segments, effectively blanking the entire display. Writing the BLANK bit to zero disables the blanking and segment data will be output as normal. See [15.3.8 Data Update](#) for details regarding synchronization of blank.

### 15.3.12.3 Animation State Machine

The Animation State Machine makes it possible to enable different animations without updating the data registers, allowing specialized patterns running on the LCD panel while the microcontroller remains in Low Energy Mode saving power. The animation feature is available on 8 segments multiplexed with LCD\_COM0. The 8 segments can be either segments 0 to 7 or 8 to 15, depending on ALOC in LCD\_BACTRL. The animation is implemented as two programmable 8 bit registers that are shifted left or right every other Animation state for a total of 16 states.

The shift operations applied to the shift registers are controlled by AREGASC and AREGBSC in LCD\_BACTRL. Note also that the FC must be on for animation to work, as it is the FC event that drives the animation state machine.

The two registers are either OR'ed or AND'ed to achieve the displayed animation pattern. This is controlled by ALOGSEL in LCD\_BACTRL. In addition, the regular segment data SEGDO[7:0] / SEGDO[15:8] is OR'ed with the animation pattern to generate the resulting output.


Each state is displayed for one CLK<sub>EVENT</sub> period, see [15.3.10 Frame Counter \(FC\)](#). By reading ASTATE in LCD\_STATUS, software can identify which state that is currently active in the state sequence. Note that the shifting operation is performed on internal registers that are not accessible in SW (when reading LCD\_AREGA and LCD\_AREGB, the data that was original written will also be read back). The SW must utilize the knowledge about the current state (ASTATE) to calculate what is currently output. ASTATE is cleared when LCD\_AREGA or LCD\_AREGB are updated with new values. See [Table 15.10 LCD Animation Example on page 481](#) for an example.

**Table 15.10. LCD Animation Example**

ASTATE	LCD_AREGA	LCD_AREGB	Resulting Data
0	11000000	11000000	11000000
1	01100000	11000000	11100000
2	01100000	01100000	01100000
3	00110000	01100000	01110000
4	00110000	00110000	00110000
5	00011000	00110000	00111000
6	00011000	00011000	00011000
7	00001100	00011000	00011100
8	00001100	00001100	00001100
9	00000110	00001100	00001110
10	00000110	00000110	00000110
11	00000011	00000110	00000111
12	00000011	00000011	00000011
13	10000001	00000011	10000011
14	10000001	10000001	10000001
15	11000000	10000001	11000001

In the table, AREGASC = SHIFTRIGHT, AREGBSC = SHIFTRIGHT, ALOGSEL = OR and the resulting data is to be displayed on segment lines 7-0 or 15-8 multiplexed with LCD\_COM0.

The block diagram of the animation circuit for the LCD is shown in the following figure.



**Figure 15.7. LCD Block Diagram of the Animation Circuit**

To set up an animation sequence for the LCD, the following sequence is recommended.

1. Write data into the animation registers LCD\_AREGA, LCD\_AREGB
2. Enable the correct shift direction (if any)
3. Decide which logical function to perform on the registers:
  - ALOGSEL = 0: Data\_out = LCD\_AREGA & LCD\_AREGB
  - ALOGSEL = 1: Data\_out = LCD\_AREGA | LCD\_AREGB
4. Configure the right animation period (CLK\_EVENT)
5. Enable the animation pattern and frame counter (AEN = 1, FCEN = 1)

For updating data in the LCD while it is running an animation, and the new animation data depends on the pattern visible on the LCD, see the following example.

1. Enable the LCD interrupt (the interrupt will be triggered simultaneously as the Animation State machine changes state)
2. In the interrupt handler, read back the current state (ASTATE)
3. Knowing the current state of the Animation State Machine makes it possible to calculate what data that is currently output
4. Modify data as required (Data will be updated at the next Frame Counter Event). It is important that new data is written before the next Frame Counter Event.

### 15.3.13 LCD in Low Energy Modes

As long as the LFACLK is running (EM0 Active-EM2 DeepSleep), the LCD controller continues to output LCD waveforms according to the data that is currently synchronized to the LCD Driver logic. In addition, the following features are still active if enabled:

- Animation State Machine
- Blink
- LCD Event Interrupt

### 15.3.14 Register Access

Since this module is a Low Energy Peripheral, and runs off a clock which is asynchronous to the HFCORECLK, special considerations must be taken when accessing registers. Refer to [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#) for a description on how to perform register accesses to Low Energy Peripherals.

### 15.3.15 Waveform Examples

The numbers on the illustration's y-axes in the following sections only indicate different voltage levels. All examples are shown with low-power waveforms.

### 15.3.15.1 Waveforms With Static Bias and Multiplexing

- With static bias and multiplexing, each segment line can be connected to LCD\_COM0. When the segment line has the same waveform as LCD\_COM0, the LCD panel pixel is turned off, while when the segment line has the opposite waveform, the LCD panel pixel is turned on.
- DC voltage = 0 (over one frame)
- $V_{RMS}(\text{on}) = V_{LCD}$
- $V_{RMS}(\text{off}) = 0 (V_{SS})$




Figure 15.8. LCD Static Bias and Multiplexing - LCD\_COM0

### 15.3.15.2 Waveforms With 1/2 Bias and Duplex Multiplexing

In this mode, each frame is divided into 4 periods. LCD\_COM[1:0] lines can be multiplexed with all segment lines. Figures below show 1/2 bias and duplex multiplexing (waveforms show two frames).




Figure 15.9. LCD 1/2 Bias and Duplex Multiplexing - LCD\_COM0







Figure 15.10. LCD 1/2 Bias and Duplex Multiplexing - LCD\_COM1

The LCD\_SEG0 waveform below is illustrates how different segment waveforms can be multiplexed with the LCD\_COM lines in order to turn on and off LCD pixels. As illustrated in the figures below, this waveform will turn ON pixels connected to LCD\_COM0, while pixels connected to LCD\_COM1 will be turned OFF.

**Figure 15.11. LCD 1/2 Bias and Duplex Multiplexing - LCD\_SEG0****Figure 15.12. LCD 1/2 Bias and Duplex Multiplexing - LCD\_SEG0 Connection**

The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.13 LCD 1/2 Bias and Duplex Multiplexing - LCD\\_SEG0-LCD\\_COM0 on page 485](#). In this case,  $V_{RMS}$  is  $0.79 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.14 LCD 1/2 Bias and Duplex Multiplexing - LCD\\_SEG0-LCD\\_COM1 on page 486](#). In this case,  $V_{RMS}$  is  $0.35 \times V_{LCD}$ , and the segment is OFF.

**Figure 15.13. LCD 1/2 Bias and Duplex Multiplexing - LCD\_SEG0-LCD\_COM0**




Figure 15.14. LCD 1/2 Bias and Duplex Multiplexing - LCD\_SEG0-LCD\_COM1

### 15.3.15.3 Waveforms With 1/3 Bias and Duplex Multiplexing

In this mode, each frame is divided into 4 periods. LCD\_COM[1:0] lines can be multiplexed with all segment lines. Figures below show 1/3 bias and duplex multiplexing (waveforms show two frames).




Figure 15.15. LCD 1/3 Bias and Duplex Multiplexing - LCD\_COM0




Figure 15.16. LCD 1/3 Bias and Duplex Multiplexing - LCD\_COM1

The LCD\_SEG0 waveform below illustrates how different segment waveforms can be multiplexed with the COM lines in order to turn on and off LCD pixels. As illustrated in the figures below, this waveform will turn ON pixels connected to LCD\_COM0, while pixels connected to LCD\_COM1 will be turned OFF.




Figure 15.17. LCD 1/3 Bias and Duplex Multiplexing - LCD\_SEG0




Figure 15.18. LCD 1/3 Bias and Duplex Multiplexing - LCD\_SEG0 Connection

The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.19 LCD 1/3 Bias and Duplex Multiplexing - LCD\\_SEG0-LCD\\_COM0 on page 488](#). In this case,  $V_{RMS}$  is  $0.75 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.20 LCD 1/3 Bias and Duplex Multiplexing - LCD\\_SEG0-LCD\\_COM1 on page 489](#). In this case,  $V_{RMS}$  is  $0.33 \times V_{LCD}$ , and the segment is OFF.




Figure 15.19. LCD 1/3 Bias and Duplex Multiplexing - LCD\_SEG0-LCD\_COM0




Figure 15.20. LCD 1/3 Bias and Duplex Multiplexing - LCD\_SEG0-LCD\_COM1

#### 15.3.15.4 Waveforms With 1/2 Bias and Triplex Multiplexing

In this mode, each frame is divided into 6 periods. LCD\_COM[2:0] lines can be multiplexed with all segment lines. Figures below show 1/2 bias and triplex multiplexing (waveforms show two frames).




Figure 15.21. LCD 1/2 Bias and Triplex Multiplexing - LCD\_COM0




Figure 15.22. LCD 1/2 Bias and Triplex Multiplexing - LCD\_COM1






Figure 15.23. LCD 1/2 Bias and Triplex Multiplexing - LCD\_COM2


The LCD\_SEG0 waveform below illustrates how different segment waveforms can be multiplexed with the COM lines in order to turn on and off LCD pixels. As illustrated in the figures below, this waveform will turn ON pixels connected to LCD\_COM1, while pixels connected to LCD\_COM0 and LCD\_COM2 will be turned OFF.

**Figure 15.24. LCD 1/2 Bias and Triplex Multiplexing - LCD\_SEG0****Figure 15.25. LCD 1/2 Bias and Triplex Multiplexing - LCD\_SEG0 Connection**

The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.26 LCD 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM0](#) on page 491. In this case,  $V_{RMS}$  is  $0.4 \times V_{LCD}$ , and the segment is OFF.

The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.27 LCD 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM1](#) on page 492. In this case,  $V_{RMS}$  is  $0.7 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM2 will see the waveform shown in [Figure 15.28 LCD 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM2](#) on page 492. In this case,  $V_{RMS}$  is  $0.4 \times V_{LCD}$ , and the segment is OFF.

**Figure 15.26. LCD 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM0**




Figure 15.27. LCD 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM1




Figure 15.28. LCD 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM2

### 15.3.15.5 Waveforms With 1/3 Bias and Triplex Multiplexing

In this mode, each frame is divided into 6 periods. LCD\_COM[2:0] lines can be multiplexed with all segment lines. Figures below show 1/3 bias and triplex multiplexing (waveforms show two frames).




Figure 15.29. LCD 1/3 Bias and Triplex Multiplexing - LCD\_COM0




Figure 15.30. LCD 1/3 Bias and Triplex Multiplexing - LCD\_COM1






Figure 15.31. LCD 1/3 Bias and Triplex Multiplexing - LCD\_COM2


The LCD\_SEG0 waveform illustrates how different segment waveforms can be multiplexed with the COM lines in order to turn on and off LCD pixels. As illustrated in the figures below, this waveform will turn ON pixels connected to LCD\_COM1, while pixels connected to LCD\_COM0 and LCD\_COM2 will be turned OFF.

**Figure 15.32. LCD 1/3 Bias and Triplex Multiplexing - LCD\_SEG0****Figure 15.33. LCD 1/3 Bias and Triplex Multiplexing - LCD\_SEG0 Connection**

The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.34 LCD 1/3 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM0 on page 494](#). In this case,  $V_{RMS}$  is  $0.33 \times V_{LCD}$ , and the segment is OFF.

The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.35 LCD 1/3 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM1 on page 495](#). In this case,  $V_{RMS}$  is  $0.64 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM2 will see the waveform shown in [Figure 15.36 LCD 1/3 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM2 on page 495](#). In this case,  $V_{RMS}$  is  $0.33 \times V_{LCD}$ , and the segment is OFF.

**Figure 15.34. LCD 1/3 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM0**




Figure 15.35. LCD 1/3 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM1




Figure 15.36. LCD 1/3 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM2

### 15.3.15.6 Waveforms With 1/3 Bias and Quadruplex Multiplexing

In this mode, each frame is divided into 8 periods. All COM lines can be multiplexed with all segment lines. Figures below show 1/3 bias and quadruplex multiplexing (waveforms show two frames).




Figure 15.37. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_COM0




Figure 15.38. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_COM1






Figure 15.39. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_COM2




**Figure 15.40. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_COM3**

The LCD\_SEG0 waveform below illustrates how different segment waveforms can be multiplexed with the COM lines in order to turn on and off LCD pixels. As illustrated in the figures below, this waveform will turn ON pixels connected to LCD\_COM0 and LCD\_COM2, while pixels connected to LCD\_COM1 and LCD\_COM3 will be turned OFF.



**Figure 15.41. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_SEG0**




**Figure 15.42. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_SEG0 Connection**

The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.43 LCD 1/3 Bias and Quadruplex Multiplexing - LCD\\_SEG0-LCD\\_COM0 on page 498](#). In this case,  $V_{RMS}$  is  $0.58 \times V_{LCD}$ , and the segment is ON.


The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.44 LCD 1/3 Bias and Quadruplex Multiplexing - LCD\\_SEG0-LCD\\_COM1 on page 498](#). In this case,  $V_{RMS}$  is  $0.33 \times V_{LCD}$ , and the segment is OFF.

The LCD segment between LCD\_SEG0 and LCD\_COM2 will see the waveform shown in [Figure 15.45 LCD 1/3 Bias and Quadruplex Multiplexing - LCD\\_SEG0-LCD\\_COM2 on page 499](#). In this case,  $V_{RMS}$  is  $0.58 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM3 will see the waveform shown in [Figure 15.46 LCD 1/3 Bias and Quadruplex Multiplexing- LCD\\_SEG0-LCD\\_COM3 on page 499](#). In this case,  $V_{RMS}$  is  $0.33 \times V_{LCD}$ , and the segment is OFF.



**Figure 15.43. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_SEG0-LCD\_COM0**



**Figure 15.44. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_SEG0-LCD\_COM1**




Figure 15.45. LCD 1/3 Bias and Quadruplex Multiplexing - LCD\_SEG0-LCD\_COM2




Figure 15.46. LCD 1/3 Bias and Quadruplex Multiplexing- LCD\_SEG0-LCD\_COM3

### 15.3.15.7 Waveforms With Charge Redistribution

This example assumes a 32.768 kHz clock prescaled in the CMU by 2, triplex multiplexing, and an FRDIV of 90 which gives 30 frames per second. The charge redistribution is 1% of each phase. The normal power waveform is shown with segment 0 data of {1,1,0}.




Figure 15.47. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_COM0




Figure 15.48. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_COM1




Figure 15.49. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_COM2





Figure 15.50. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_SEG0


The LCD segment between LCD\_SEG0 and LCD\_COM0 will see the waveform shown in [Figure 15.51 LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM0 on page 501](#). In this case,  $V_{RMS}$  is  $0.7 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM1 will see the waveform shown in [Figure 15.52 LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM1 on page 501](#). In this case,  $V_{RMS}$  is  $0.7 \times V_{LCD}$ , and the segment is ON.

The LCD segment between LCD\_SEG0 and LCD\_COM2 will see the waveform shown in [Figure 15.53 LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\\_SEG0-LCD\\_COM2 on page 502](#). In this case,  $V_{RMS}$  is  $0.4 \times V_{LCD}$ , and the segment is OFF.



**Figure 15.51. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM0**



**Figure 15.52. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM1**




Figure 15.53. LCD Charge Redist - 1/2 Bias and Triplex Multiplexing - LCD\_SEG0-LCD\_COM2

## 15.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	LCD_CTRL	RW	Control Register
0x004	LCD_DISPCTRL	RW	Display Control Register
0x008	LCD_SEGEN	RW	Segment Enable Register
0x00C	LCD_BACTRL	RW	Blink and Animation Control Register
0x010	LCD_STATUS	R	Status Register
0x014	LCD_AREGA	RW	Animation Register a
0x018	LCD_AREGB	RW	Animation Register B
0x01C	LCD_IF	R	Interrupt Flag Register
0x020	LCD_IFS	W1	Interrupt Flag Set Register
0x024	LCD_IFC	(R)W1	Interrupt Flag Clear Register
0x028	LCD_IEN	RW	Interrupt Enable Register
0x030	LCD_BIASCTRL	RW	Analog BIAS Control
0x040	LCD_SEGD0L	RW	Segment Data Low Register 0
0x044	LCD_SEGD1L	RW	Segment Data Low Register 1
0x048	LCD_SEGD2L	RW	Segment Data Low Register 2
0x04C	LCD_SEGD3L	RW	Segment Data Low Register 3
0x050	LCD_SEGD0H	RW	Segment Data High Register 0
0x054	LCD_SEGD1H	RW	Segment Data High Register 1
0x058	LCD_SEGD2H	RW	Segment Data High Register 2
0x05C	LCD_SEGD3H	RW	Segment Data High Register 3
0x060	LCD_SEGD4L	RW	Segment Data Low Register 4
0x064	LCD_SEGD5L	RW	Segment Data Low Register 5
0x068	LCD_SEGD6L	RW	Segment Data Low Register 6
0x06C	LCD_SEGD7L	RW	Segment Data Low Register 7
0x070	LCD_SEGD4H	RW	Segment Data High Register 4
0x074	LCD_SEGD5H	RW	Segment Data High Register 5
0x078	LCD_SEGD6H	RW	Segment Data High Register 6
0x07C	LCD_SEGD7H	RW	Segment Data High Register 7
0x0C0	LCD_FREEZE	RW	Freeze Register
0x0C4	LCD_SYNCBUSY	R	Synchronization Busy Register
0x0F0	LCD_FRAMERATE	RW	Frame Rate
0x0F4	LCD_SEGEN2	RW	Segment Enable (32 to 39)

## 15.5 Register Description

### 15.5.1 LCD\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																												0x0	0			
Access																												RW	0			
Name																												UDCTRL	RW	EN		

Bit	Name	Reset	Access	Description
31:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	DSC	0	RW	<b>Direct Segment Control</b>
		This bit enables direct control over bias levels for each SEG/COM line.		
	Value	Description		
	0	DSC disable		
	1	DSC enable		
22:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:1	UDCTRL	0x0	RW	<b>Update Data Control</b>
	These bits control how data from the SEGDN registers are transferred to the LCD driver.			
	Value	Mode	Description	
	0	REGULAR	The data transfer is controlled by SW. Transfer is performed as soon as possible	
	1	FCEVENT	The data transfer is done at the next event triggered by the Frame Counter	
	2	FRAMESTART	The data transfer is done continuously at every LCD frame start	
0	EN	0	RW	<b>LCD Enable</b>
	When this bit is set, the LCD driver is enabled and the driver will start outputting waveforms on the com/segment lines.			

## 15.5.2 LCD\_DISPCTRL - Display Control Register

Offset	Bit Position																																
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access		RW	0x0				RW	0x0				RW	0x1							RW	0x3F						RW	0				RW	0x0
Name		MODE					BIAS					CHGRDST							CONTRAST	RW												MUX	

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:28	MODE	0x0	RW	<b>Mode Setting</b>
		This field determines the LCD mode of operation.		
	Value	Mode		Description
	0	NOEXTCAP		No External Cap. Uses an internal current source to generate VLCD. Use CONTRAST[4:0] to control VLCD.
	1	STEPDOWN		Use step down control with VLCD less than VDD. Use CONTRAST[5:0] to control VLCD level, and use SPEED to adjust VLCD drive strength.
	2	CPINTOSC		Charge pump used with internal oscillator. Use CONTRAST[5:0] to control VLCD level, and use SPEED to adjust oscillator frequency.
27:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25:24	BIAS	0x0	RW	<b>Bias Configuration</b>
		These bits set the bias mode for the LCD Driver.		
	Value	Mode		Description
	0	STATIC		Static
	1	ONEHALF		1/2 Bias
	2	ONETHIRD		1/3 Bias
	3	ONEFOURTH		1/4 Bias
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	CHGRDST	0x1	RW	<b>Charge Redistribution Cycles</b>
		Selects number of prescaled low frequency clock cycles for charge redistribution.		
	Value	Mode		Description
	0	DISABLE		Disable charge redistribution.
	1	ONE		Use 1 prescaled low frequency clock cycle for charge redistribution.
	2	TWO		Use 2 prescaled low frequency clock cycles for charge redistribution.

Bit	Name	Reset	Access	Description
3	THREE			Use 3 prescaled low frequency clock cycles for charge redistribution.
4	FOUR			Use 4 prescaled low frequency clock cycles for charge redistribution.
19:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13:8	CONTRAST	0x3F	RW	<b>Contrast Control</b>  This controls the VLCD supply voltage.
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	WAVE	0	RW	<b>Waveform Selection</b>  This bit configures the output waveform.
	Value	Mode		Description
	0	LOWPOWER		Low power waveform
	1	NORMAL		Normal waveform
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	MUX	0x0	RW	<b>Mux Configuration</b>  These bits set the multiplexing mode for the LCD Driver.
	Value	Mode		Description
	0	STATIC		Static
	1	DUPLEX		Duplex
	2	TRIPLEX		Triplex
	3	QUADRUPLEX		Quadruplex
	5	SEXTAPLEX		Sextaplex
	7	OCTAPLEX		Octaplex

## 15.5.3 LCD\_SEGEN - Segment Enable Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	SEGEN																															

Bit	Name	Reset	Access	Description
31:0	SEGEN	0x00000000	RW	<b>Segment Enable</b>
Determines which segment lines are enabled from (0 to 31). The GPIO pin also needs to be configured as DISABLED in the GPIO pin configuration.				

**15.5.4 LCD\_BACTRL - Blink and Animation Control Register (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9									
Access																																
Name																																
	ALOC								FCTOP																							

Bit	Name	Reset	Access	Description															
31:29	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
28	ALOC	0	RW	<b>Animation Location</b>  Set the LCD segments which animation applies to															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>SEG0TO7</td> <td>Animation appears on segments 0 to 7</td> </tr> <tr> <td>1</td> <td>SEG8TO15</td> <td>Animation appears on segments 8 to 15</td> </tr> </tbody> </table>	Value	Mode	Description	0	SEG0TO7	Animation appears on segments 0 to 7	1	SEG8TO15	Animation appears on segments 8 to 15						
Value	Mode	Description																	
0	SEG0TO7	Animation appears on segments 0 to 7																	
1	SEG8TO15	Animation appears on segments 8 to 15																	
27:24	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
23:18	FCTOP	0x00	RW	<b>Frame Counter Top Value</b>  These bits contain the Top Value for the Frame Counter: $CLK_{EVENT} = CLK_{FC} / (1 + FCTOP[5:0])$ .															
17:16	FCPRES	0x0	RW	<b>Frame Counter Prescaler</b>  These bits controls the prescaling value for the Frame Counter input clock.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DIV1</td> <td><math>CLK_{FC} = CLK_{FRAME} / 1</math></td> </tr> <tr> <td>1</td> <td>DIV2</td> <td><math>CLK_{FC} = CLK_{FRAME} / 2</math></td> </tr> <tr> <td>2</td> <td>DIV4</td> <td><math>CLK_{FC} = CLK_{FRAME} / 4</math></td> </tr> <tr> <td>3</td> <td>DIV8</td> <td><math>CLK_{FC} = CLK_{FRAME} / 8</math></td> </tr> </tbody> </table>	Value	Mode	Description	0	DIV1	$CLK_{FC} = CLK_{FRAME} / 1$	1	DIV2	$CLK_{FC} = CLK_{FRAME} / 2$	2	DIV4	$CLK_{FC} = CLK_{FRAME} / 4$	3	DIV8	$CLK_{FC} = CLK_{FRAME} / 8$
Value	Mode	Description																	
0	DIV1	$CLK_{FC} = CLK_{FRAME} / 1$																	
1	DIV2	$CLK_{FC} = CLK_{FRAME} / 2$																	
2	DIV4	$CLK_{FC} = CLK_{FRAME} / 4$																	
3	DIV8	$CLK_{FC} = CLK_{FRAME} / 8$																	
15:9	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
8	FCEN	0	RW	<b>Frame Counter Enable</b>  When this bit is set, the frame counter is enabled.															
7	ALOGSEL	0	RW	<b>Animate Logic Function Select</b>  When this bit is set, the animation registers are AND'ed together. When this bit is cleared, the animation registers are OR'ed together.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AND</td> <td>AREGA and AREGB AND'ed</td> </tr> </tbody> </table>	Value	Mode	Description	0	AND	AREGA and AREGB AND'ed									
Value	Mode	Description																	
0	AND	AREGA and AREGB AND'ed																	

Bit	Name	Reset	Access	Description
	1	OR		AREGA and AREGB OR'ed
6:5	AREGBSC	0x0	RW	<b>Animate Register B Shift Control</b>
				These bits controls the shift operation that is performed on Animation register B.
	Value	Mode		Description
	0	NOSHIFT		No Shift operation on Animation Register B
	1	SHIFTLEFT		Animation Register B is shifted left
	2	SHIFTRIGHT		Animation Register B is shifted right
4:3	AREGASC	0x0	RW	<b>Animate Register a Shift Control</b>
				These bits controls the shift operation that is performed on Animation register A.
	Value	Mode		Description
	0	NOSHIFT		No Shift operation on Animation Register A
	1	SHIFTLEFT		Animation Register A is shifted left
	2	SHIFTRIGHT		Animation Register A is shifted right
2	AEN	0	RW	<b>Animation Enable</b>
				When this bit is set, the animate function is enabled.
1	BLANK	0	RW	<b>Blank Display</b>
				When this bit is set, all segment output waveforms are configured to blank the LCD display. The Segment Data Registers are not affected when writing this bit.
	Value			Description
	0			Display is not "blanked"
	1			Display is "blanked"
0	BLINKEN	0	RW	<b>Blink Enable</b>
				When this bit is set, the Blink function is enabled. Every "ON" segment will alternate between on and off at every Frame Counter Event.

**15.5.5 LCD\_STATUS - Status Register**

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																														0x0		
<b>Access</b>																													R	R		
<b>Name</b>																														ASTATE	R	

Bit	Name	Reset	Access	Description
31:9	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
8	BLINK	0	R	<b>Blink State</b>
	This bit indicates the blink status. If this bit is 1, all segments are off. If this bit is 0, the segments(LCD_SEGDxn) which are set to 1 are on.			
7:4	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
3:0	ASTATE	0x0	R	<b>Current Animation State</b>
	Contains the current animation state (0-15).			

**15.5.6 LCD\_AREGA - Animation Register a (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																														0x00		
<b>Access</b>																													RW			
<b>Name</b>																														AREGA		

Bit	Name	Reset	Access	Description
31:8	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	AREGA	0x00	RW	<b>Animation Register a Data</b>
	This register contains the A data for generating animation pattern.			

**15.5.7 LCD\_AREGB - Animation Register B (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x00						
Access																										RW						
Name																										AREGB						

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	AREGB	0x00	RW	<b>Animation Register B Data</b>  This register contains the B data for generating animation pattern.

**15.5.8 LCD\_IF - Interrupt Flag Register**

Offset	Bit Position																									FC <td data-kind="ghost"></td> <td data-cs="2" data-kind="parent">R</td> <td data-kind="ghost"></td> <td data-cs="2" data-kind="parent">0</td> <td data-kind="ghost"></td>		R		0			
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																										FC		R		0			
Access																										FC		R		0			
Name																										FC		R		0			

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	FC	0	R	<b>Frame Counter Interrupt Flag</b>  Set when Frame Counter is zero.

**15.5.9 LCD\_IFS - Interrupt Flag Set Register**

Offset	Bit Position																									FC <td data-kind="ghost"></td> <td data-cs="2" data-kind="parent">W1</td> <td data-kind="ghost"></td> <td data-cs="2" data-kind="parent">0</td> <td data-kind="ghost"></td>		W1		0			
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																										FC		W1		0			
Access																										FC		W1		0			
Name																										FC		W1		0			

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	FC	0	W1	<b>Frame Counter Interrupt Flag Set</b>  Write to 1 to set FC interrupt flag.

### 15.5.10 LCD\_IFC - Interrupt Flag Clear Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	FC	0	(R)W1	<b>Frame Counter Interrupt Flag Clear</b>

Write to 1 to clear FC interrupt flag.

### 15.5.11 LCD\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	FC	0	RW	<b>Frame Counter Interrupt Enable</b>  Set to enable interrupt on frame counter interrupt flag.

## 15.5.12 LCD\_BIASCTRL - Analog BIAS Control

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:13	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12:10	BUFBIAS	0x0	RW	<b>Buffer Bias Setting</b>
	This field sets the operating bias current for the buffers.			
9:8	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:4	BUFDRV	0x0	RW	<b>Buffer Drive Strength</b>
	This field is used to set the buffer driver strength.			
3	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	SPEED	0x0	RW	<b>SPEED Adjustment</b>
	This field is used in mode 1 to adjust the drive strength to the resistor string. For mode 3 this field is used to adjust the speed of the internal oscillator.			

## 15.5.13 LCD\_SEGD0L - Segment Data Low Register 0 (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:0	SEGDL0	0x00000000	RW	<b>COM0 Segment Data Low</b>
	This register contains segment data for segment lines 0-31 for COM0.			

**15.5.14 LCD\_SEGD1L - Segment Data Low Register 1 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEGD1L																																
Bit	Name	Reset	Access	Description																													
31:0	SEGD1L	0x00000000	RW	<b>COM1 Segment Data Low</b>																													
This register contains segment data for segment lines 0-31 for COM1.																																	

**15.5.15 LCD\_SEGD2L - Segment Data Low Register 2 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEGD2L																																
Bit	Name	Reset	Access	Description																													
31:0	SEGD2L	0x00000000	RW	<b>COM2 Segment Data Low</b>																													
This register contains segment data for segment lines 0-31 for COM2.																																	

**15.5.16 LCD\_SEGD3L - Segment Data Low Register 3 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEG3L																																
Bit	Name	Reset	Access	Description																													
31:0	SEG3L	0x00000000	RW	<b>COM3 Segment Data Low</b>																													
This register contains segment data for segment lines 0-31 for COM3.																																	

**15.5.17 LCD\_SEGD0H - Segment Data High Register 0 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00																																
Access	RW																																
Name	SEG0H																																
Bit	Name	Reset	Access	Description																													
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																															
7:0	SEG0H	0x00	RW	<b>COM0 Segment Data High</b>																													
This register contains segment data for segment lines 32-39 for COM0.																																	

**15.5.18 LCD\_SEGD1H - Segment Data High Register 1 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																										SEGD1H						

Bit	Name	Reset	Access	Description
31:8	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEGD1H	0x00	RW	<b>COM1 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM1.

**15.5.19 LCD\_SEGD2H - Segment Data High Register 2 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																									SEGD2H							

Bit	Name	Reset	Access	Description
31:8	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEGD2H	0x00	RW	<b>COM2 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM2.

**15.5.20 LCD\_SEGD3H - Segment Data High Register 3 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																									SEGD3H							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEGD3H	0x00	RW	<b>COM3 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM3.

**15.5.21 LCD\_SEGD4L - Segment Data Low Register 4 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x060	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00000000							
<b>Access</b>																									RW							
<b>Name</b>																									SEGD4L							

Bit	Name	Reset	Access	Description
31:0	SEGD4L	0x00000000	RW	<b>COM4 Segment Data</b>

This register contains segment data for segment lines 0-31 for COM4.

**15.5.22 LCD\_SEGD5L - Segment Data Low Register 5 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEG5L																																
Bit	Name	Reset	Access	Description																													
31:0	SEG5L	0x00000000	RW	<b>COM5 Segment Data</b>																													
This register contains segment data for segment lines 0-31 for COM5.																																	

**15.5.23 LCD\_SEGD6L - Segment Data Low Register 6 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x068	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEG6L																																
Bit	Name	Reset	Access	Description																													
31:0	SEG6L	0x00000000	RW	<b>COM6 Segment Data</b>																													
This register contains segment data for segment lines 0-31 for COM6.																																	

**15.5.24 LCD\_SEGD7L - Segment Data Low Register 7 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	SEG7L																																
Bit	Name	Reset	Access	Description																													
31:0	SEG7L	0x00000000	RW	<b>COM7 Segment Data</b>																													
This register contains segment data for segment lines 0-31 for COM7.																																	

**15.5.25 LCD\_SEGD4H - Segment Data High Register 4 (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x070	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00																																
Access	RW																																
Name	SEGD4H																																
Bit	Name	Reset	Access	Description																													
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																															
7:0	SEGD4H	0x00	RW	<b>COM0 Segment Data High</b>																													
This register contains segment data for segment lines 32-39 for COM4.																																	

**15.5.26 LCD\_SEGD5H - Segment Data High Register 5 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x074	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x00							
Access																										RW						
Name																										SEG D5H						

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEG D5H	0x00	RW	<b>COM1 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM5.

**15.5.27 LCD\_SEGD6H - Segment Data High Register 6 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x078	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x00							
Access																										RW						
Name																										SEG D6H						

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEG D6H	0x00	RW	<b>COM2 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM6.

**15.5.28 LCD\_SEGD7H - Segment Data High Register 7 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x07C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																									SEGD7H							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	SEGD7H	0x00	RW	<b>COM3 Segment Data High</b>

This register contains segment data for segment lines 32-39 for COM7.

## 15.5.29 LCD\_FREEZE - Freeze Register

Offset	Bit Position																															
0x0C0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0	0		
Access																													RW	0		
Name																													LCDGATE	RW	0	
																													REGFREEZE	RW	0	

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	LCDGATE	0	RW	<b>LCD Gate</b>  Tristate the LCD pins. The gating or un-gating occurs on Frame boundaries.
	Value	Mode		Description
	0	UNGATE		LCD BIAS voltages driven onto pins.
	1	GATE		LCD BIAS MUX tristated at the pins.
0	REGFREEZE	0	RW	<b>Register Update Freeze</b>  When set, the update of the LCD is postponed until this bit is cleared. Use this bit to update several registers simultaneously.
	Value	Mode		Description
	0	UPDATE		Each write access to an LCD register is updated into the Low Frequency domain as soon as possible.
	1	FREEZE		The LCD is not updated with the new written value.

### 15.5.30 LCD\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position											
0x0C4	31	30	29	28	27	26	25	24	23	22	21	20
Reset												
Access												
Name	SEG D7H	R	0	19	SEG D6H	R	0	18	SEG D5H	R	0	17
	SEG D4H	R	0	16	SEG D7L	R	0	15	SEG D6L	R	0	14
	SEG D5L	R	0	13	SEG D4L	R	0	12	SEG D3H	R	0	11
	SEG D2H	R	0	10	SEG D1H	R	0	9	SEG D0H	R	0	8
	SEG D3L	R	0	7	SEG D2L	R	0	6	SEG D1L	R	0	5
	SEG D0L	R	0	4	AREGB	R	0	3	AREGA	R	0	2
	BACTRL	R	0	1	CTRL	R	0	0				

Bit	Name	Reset	Access	Description
31:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
19	SEGD7H	0	R	<b>SEGD7H Register Busy</b> Set when the value written to SEGD7H is being synchronized.
18	SEGD6H	0	R	<b>SEGD6H Register Busy</b> Set when the value written to SEGD6H is being synchronized.
17	SEGD5H	0	R	<b>SEGD5H Register Busy</b> Set when the value written to SEGD5H is being synchronized.
16	SEGD4H	0	R	<b>SEGD4H Register Busy</b> Set when the value written to SEGD4H is being synchronized.
15	SEGD7L	0	R	<b>SEGD7L Register Busy</b> Set when the value written to SEGD7L is being synchronized.
14	SEGD6L	0	R	<b>SEGD6L Register Busy</b> Set when the value written to SEGD6L is being synchronized.
13	SEGD5L	0	R	<b>SEGD5L Register Busy</b> Set when the value written to SEGD5L is being synchronized.
12	SEGD4L	0	R	<b>SEGD4L Register Busy</b> Set when the value written to SEGD4L is being synchronized.
11	SEGD3H	0	R	<b>SEGD3H Register Busy</b> Set when the value written to SEGD3H is being synchronized.
10	SEGD2H	0	R	<b>SEGD2H Register Busy</b> Set when the value written to SEGD2H is being synchronized.
9	SEGD1H	0	R	<b>SEGD1H Register Busy</b> Set when the value written to SEGD1H is being synchronized.
8	SEGD0H	0	R	<b>SEGD0H Register Busy</b> Set when the value written to SEGD0H is being synchronized.
7	SEGD3L	0	R	<b>SEGD3L Register Busy</b> Set when the value written to SEGD3L is being synchronized.
6	SEGD2L	0	R	<b>SEGD2L Register Busy</b> Set when the value written to SEGD2L is being synchronized.

Bit	Name	Reset	Access	Description
5	SEGD1L	0	R	<b>SEGD1L Register Busy</b>  Set when the value written to SEGD1L is being synchronized.
4	SEGD0L	0	R	<b>SEGD0L Register Busy</b>  Set when the value written to SEGD0L is being synchronized.
3	AREGB	0	R	<b>AREGB Register Busy</b>  Set when the value written to AREGB is being synchronized.
2	AREGA	0	R	<b>AREGA Register Busy</b>  Set when the value written to AREGA is being synchronized.
1	BACTRL	0	R	<b>BACTRL Register Busy</b>  Set when the value written to BACTRL is being synchronized.
0	CTRL	0	R	<b>CTRL Register Busy</b>  Set when the value written to CTRL is being synchronized.

### 15.5.31 LCD\_FRAMERATE - Frame Rate

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Reset																											0x000				
Access																											RW				
Name																											FRDIV				




Bit	Name	Reset	Access	Description
31:9	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
8:0	FRDIV	0x000	RW	<b>Frame Rate Divider</b>  Determines number of prescaled clocks per phase. Static has 2 phases, and octaplex has sixteen phases per frame.

## 15.5.32 LCD\_SEGEN2 - Segment Enable (32 to 39)

Offset	Bit Position																															
0x0F4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x0						
Access																										RW						
Name																										SEGEN2						

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	SEGEN2	0x0	RW	<b>Segment Enable (second Group)</b>  Determines which segment lines are enabled from (32 to 39). The GPIO pin also needs to be configured as DISABLED in the GPIO pin configuration.

## 16. PCNT - Pulse Counter



### Quick Facts

#### What?

The Pulse Counter (PCNT) decodes incoming pulses. The module has a quadrature mode which may be used to decode the speed and direction of a mechanical shaft. PCNT can operate in EM0 Active down to EM3 Stop.

#### Why?

The PCNT generates an interrupt after a specific number of pulses (or rotations), eliminating the need for timing or I/O interrupts and CPU processing to measure pulse widths, etc.

#### How?

PCNT uses the LFACLK or may be externally clocked from a pin. The module incorporates a 16-bit up/down-counter to keep track of incoming pulses or rotations.

### 16.1 Introduction


The Pulse Counter (PCNT) can be used for counting incoming pulses on a single input or to decode quadrature encoded inputs in EM0 Active down to EM3 Stop. It can run from the internal LFACLK while counting pulses on the PCNTn\_S0IN pin. Or, alternately, the PCNTn\_S0IN pin may be used as an external clock source that runs both the PCNT counter and register access.

### 16.2 Features

- 16-bit counter with reload register
- Auxiliary counter for counting a single direction
- Single input oversampling up/down counter mode
- Externally clocked single input pulse up/down counter mode
- Quadrature decoder modes
  - Externally clocked quadrature decoder 1X mode
  - Oversampling quadrature decoder 1X, 2X and 4X modes
- Interrupt on counter underflow and overflow
- Interrupt when a direction change is detected (quadrature decoder mode only)
- Optional pulse width filter
- Optional input inversion/edge detect select
- Optional inputs from PRS
- Asynchronously triggered compare and clear

## 16.3 Functional Description

An overview of the PCNT module is shown in [Figure 16.1 PCNT Overview on page 527](#).



**Figure 16.1. PCNT Overview**

### 16.3.1 Pulse Counter Modes

The pulse counter can operate in single input oversampling mode (OVSSINGLE), externally clocked single input counter mode (EXTCLKSINGLE), externally clocked quadrature decoder mode (EXTCLKQUAD) and oversampling quadrature decoder modes(OVSQUAD1X, OVSQUAD2X and OVSQUAD4X). The following sections describe operation of each of these modes and how they are enabled. Input timing constraints are described in [16.3.6 Clock Sources](#) and [16.3.7 Input Filter](#).

#### 16.3.1.1 Single Input Oversampling Mode

This mode is enabled by writing OVSSINGLE to the MODE field in the PCNTn\_CTRL register and disabled by writing DISABLE to the same field. The LFACLK clock source to the pulse counter is configured by clearing PCNT0CLKSEL in the CMU\_PCNTCTRL in the Clock Management Unit (CMU).

The optional pulse width filter is enabled by setting the FILT bit in the PCNTn\_CTRL register. Additionally, the PCNTn\_S0IN input may be inverted, so that falling edges are counted, by setting the EDGE bit in the PCNTn\_CTRL register.

If S1CDIR in the PCNTn\_CTRL register is cleared, PCNTn\_S0IN is the only observed input in this mode. The PCNTn\_S0IN input is sampled by the LFACLK and the number of detected positive or negative edges on PCNTn\_S0IN appears in PCNTn\_CNT. The counter may be configured to count down by setting the CNTDIR bit in PCNTn\_CTRL. Default is to count up.

The counting direction can also be controlled externally in this mode by setting S1CDIR. This will make the input value on PCNTn\_S1IN decide the direction counted on a PCNTn\_S0IN edge. If PCNTn\_S1IN is high, the count is done according to CNTDIR in PCNTn\_CTRL. If low, the count direction is opposite.

#### 16.3.1.2 Externally Clocked Single Input Counter Mode

This mode is enabled by writing EXTCLKSINGLE to the MODE field in the PCNTn\_CTRL register and disabled by writing DISABLE to the same field. The external pin clock source is configured by setting PCNT0CLKSEL in the CMU\_PCNTCTRL register ([10. CMU - Clock Management Unit](#) ).

Positive edges on PCNTn\_S0IN are used to clock the counter. Similar to the oversampled mode, PCNTn\_S1IN is used to determine the count direction if S1CDIR is set. If not, CNTDIR in PCNTn\_CTRL solely defines count direction.

The digital pulse width filter is not available in this mode. The analog de-glitch filter in the GPIO pads is capable of removing some unwanted noise. However, this mode may be susceptible to spikes and unintended pulses from devices such as mechanical switches, and is therefore most suited to take input from electronic sensors etc. that generate single wire pulses.


### 16.3.1.3 Quadrature Decoder Modes

Two different types of quadrature decoding is supported in the pulse counter: the externally clocked (Asynchronous) quadrature decoding and the oversampling (Synchronous) quadrature decoding. The externally clocked mode supports 1X quadrature decoding whereas the oversampling mode supports 1X, 2X and 4X quadrature decoding. These modes are described in detail in [16.3.1.4 Externally Clocked Quadrature Decoder Mode](#) and [16.3.1.5 Oversampling Quadrature Decoder Mode](#).

#### 16.3.1.4 Externally Clocked Quadrature Decoder Mode

This mode is enabled by writing EXTCLKQUAD to the MODE field in PCNTn\_CTRL and disabled by writing DISABLE to the same field. The external pin clock source is configured by setting PCNT0CLKSEL in the CMU\_PCNTCTRL register ([10. CMU - Clock Management Unit](#)).

In this mode, both edges on PCNTn\_S0IN pin are used to sample PCNTn\_S1IN pin, in order to decode the quadrature code. A quadrature coded signal contains information about the relative speed and direction of a rotating shaft as illustrated by [Figure 16.2 PCNT Quadrature Coding on page 529](#), hence the direction of the counter register PCNTn\_CNT is controlled automatically.



**Figure 16.2. PCNT Quadrature Coding**

If PCNTn\_S0IN leads PCNTn\_S1IN in phase, the direction is clockwise, and if it lags in phase the direction is counter-clockwise. Default behavior is illustrated by [Figure 16.2 PCNT Quadrature Coding on page 529](#).

The counter direction may be read from the DIR bit in the PCNTn\_STATUS register. Additionally, the DIRCNG interrupt in the PCNTn\_IF register is generated when a direction change is detected. When a change is detected, the DIR bit in the PCNTn\_STATUS register must be read to determine the current new direction.

**Note:** The sector disc illustrated in the figure may be finer grained in some systems. Typically, they may generate 2-4 PCNTn\_S0IN wave periods per 360° rotation.

The direction of the quadrature code and control of the counter is generated by the simple binary function outlined by [Table 16.1 PCNT QUAD Mode Counter Control Function on page 529](#). Note that this function also filters some invalid inputs that may occur when the shaft changes direction or temporarily toggles direction.

**Table 16.1. PCNT QUAD Mode Counter Control Function**

Inputs		Control/Status	
S1IN posedge	S1IN negedge	Count Enable	CNTDIR status bit
0	0	0	0

Inputs		Control/Status	
S1IN posedge	S1IN negedge	Count Enable	CNTDIR status bit
0	1	1	0
1	0	1	1
1	1	0	0

**Note:** PCNTn\_S1IN is sampled on both edges of PCNTn\_S0IN.

### 16.3.1.5 Oversampling Quadrature Decoder Mode

There are three Oversampling Quadrature Decoder Modes supported: 1X , 2X and 4X. These modes are enabled by writing OVSQUAD1X, OVSQUAD2X and OVSQUAD4X, respectively, to the MODE field in PCNTn\_CTRL and disabled by writing DISABLE to the same field. The LFACLK clock source to the pulse counter must be configured by clearing PCNT0CLKSEL in the CMU\_PCNTCTRL in the Clock Management Unit (CMU), [10. CMU - Clock Management Unit](#) .

The optional pulse width filter is enabled by setting the FILT bit in the PCNTn\_CTRL register. The filter applies to both inputs PCNTn\_S0IN and PCNTn\_S1IN. The filter length is configured by FILTLEN in PCNTn\_OVSCFG register.


Based on the modes selected, the decoder updates the counter on different events. In the OVSQUAD1X mode, the counter is updated on the rising edge of the PCNTn\_S0IN input when counting up, and on the negedge of the PCNTn\_S0IN input when counting down. In the OVSQUAD2X mode, the counter is updated on both edges of PCNTn\_S0IN input. In the OVSQUAD4X mode the counter is updated on both edges of both inputs PCNTn\_S0IN and PCNTn\_S1IN. [Table 16.2 PCNT OVSQUAD 1X, 2X and 4X Mode Counter Control Function on page 531](#) outlines the increment or decrement of the counter based on the Quadrature Mode selected.

**Note:** The decoding behavior of OVSQUAD1X mode is slightly different compared to EXTCLKQUAD mode(also 1X mode). In the EXTCLKQUAD mode, the counter is updated only on the posedge of S0IN input. However, in the OVSQUAD1X mode, the counter is updated on the posedge of S0IN when counting up and on the negedge of S0IN when counting down.

**Table 16.2. PCNT OVSQUAD 1X, 2X and 4X Mode Counter Control Function**


Direction	Previous State		Next State		OVSQUAD MODE		
	S1IN	S0IN	S1IN	S0IN	1X	2X	4X
Clockwise	0	0	0	1	+1	+1	+1
	0	1	1	1			+1
	1	1	1	0		+1	+1
	1	0	0	0			+1
Counter Clock-wise	1	0	1	1		-1	-1
	1	1	0	1			-1
	0	1	0	0	-1	-1	-1
	0	0	1	0			-1

[Figure 16.3 PCNT State Transitions for Different Oversampling Quadrature Decoder Modes on page 532](#) illustrates the different states of the quadrature input and the state transitions that updates the counter for the different modes. Each cycle of the input states results in 1 update, 2 updates and 4 updates of the counter for OVSQUAD1X, OVSQUAD2X and OVSQUAD4X modes respectively.

**Figure 16.3. PCNT State Transitions for Different Oversampling Quadrature Decoder Modes**

The counter direction can be read from the DIR bit in PCNTn\_STATUS register. Additionally, the DIRCNG interrupt in the PCNTn\_IF is generated when the direction change is detected. When a change is detected, the DIR bit in the PCNTn\_STATUS register must be read to determine the new direction.

In the oversampling quadrature decoder modes, the maximum input toggle frequency supported is 8KHz. For frequencies of 8KHz and higher, incorrect decoding occurs. The different decoding modes and the counter updates are further illustrated by [Figure 16.4 PCNT Oversampling Quadrature Decoder 1X Mode on page 532](#), [Figure 16.5 PCNT Oversampling Quadrature Decoder 2X Mode on page 533](#) and [Figure 16.6 PCNT Oversampling Quadrature Decoder 4X Mode on page 533](#).

**Figure 16.4. PCNT Oversampling Quadrature Decoder 1X Mode**




Figure 16.5. PCNT Oversampling Quadrature Decoder 2X Mode




Figure 16.6. PCNT Oversampling Quadrature Decoder 4X Mode

The above modes, by default are prone to flutter effects in the inputs PCNTn\_S0IN and PCNTn\_S1IN. When this occurs, the counter changes directions rapidly causing DIRCNG interrupts and unnecessarily waking the core. To prevent this, set FLUTTERRM in PCNTn\_OVSCFG register. When enabled, flutter is removed, thus preventing unnecessary wakeup of the core. The flutter removal logic works by preventing update of the counter value if the wheel keeps changing direction as a result of flutter. The counter is only updated if the current and previous state transition of the rotation are in the same direction. These state transitions are quadrature decoder mode specific. The highlighted state transitions in [Figure 16.3 PCNT State Transitions for Different Oversampling Quadrature Decoder Modes on page 532](#) are the ones considered for the different quadrature decoder modes. [Figure 16.7 PCNT Oversampling Quadrature Decoder with Flutter Removal on page 533](#) shows how the counter is updated for the different quadrature decoder modes with flutter removal FLUTTERRM enabled in PCNTn\_OVSCFG.





Figure 16.7. PCNT Oversampling Quadrature Decoder with Flutter Removal

### 16.3.2 Hysteresis

By default the pulse counter wraps to 0 when passing the configured top value, and wraps to the top value when counting down from 0. On these events, a system will likely want to wake up to store and track the overflow count. This is fine if the pulse counter is tracking a monotonic value or a value that does not change directions frequently. In the latter scenario, if the counter changes directions around the overflow/underflow point, the system will have to wake up frequently to keep track of the rotations, resulting in higher current consumption.

To solve this, the pulse counter has a way of introducing hysteresis to the counter. When HYST in PCNTn\_CTRL is set, the pulse counter will always wrap to TOP/2 on underflows and overflows. This takes the counter away from the area where it might overflow or underflow, removing the problem. [Figure 16.8 PCNT Hysteresis behavior of Counter on page 534](#) illustrates the hysteresis behavior.



**Figure 16.8. PCNT Hysteresis behavior of Counter**

Given a starting value of 0 for the counter, the absolute count value when hysteresis is enabled can be calculated with the equations [Figure 16.9 Absolute Position With Hysteresis and Even TOP Value on page 534](#) or [Figure 16.10 Absolute Position With Hysteresis and Odd TOP Value on page 534](#), depending on whether the TOP value is even or odd.

$$CNT_{abs} = CNT - UF_{CNT} \times (TOP/2+1) + OF_{CNT} \times (TOP/2+1)$$

**Figure 16.9. Absolute Position With Hysteresis and Even TOP Value**

$$CNT_{abs} = CNT - UF_{CNT} \times (TOP/2+1) + OF_{CNT} \times (TOP/2+2)$$

**Figure 16.10. Absolute Position With Hysteresis and Odd TOP Value**

### 16.3.3 Auxiliary Counter

To be able to keep explicit track of counting in one direction in addition to the regular counter which counts both up and down, the auxiliary counter can be used. The pulse counter can, for instance, be configured to keep track of the absolute rotation of the wheel, while at the same time the auxiliary counter can keep track of how much the wheel has reversed.

The auxiliary counter is enabled by configuring AUXCNTEV in PCNTn\_CTRL. It will always count up, but it can be configured whether it should count up on up-events, down-events or both, keeping track of rotation either way or general movement. The value of the auxiliary counter can be read from the PCNTn\_AUXCNT register.

Overflows on the auxiliary counter happen when the auxiliary counter passes the top value of the pulse counter, configured in PCNTn\_TOP. In that event, the AUXOF interrupt flag is set, and the auxiliary counter wraps to 0.

As the auxiliary counter, the main counter can be configured to count only on certain events. This is done through CNTEV in PCNTn\_CTRL, and it is possible like for the auxiliary counter, to make the main counter count on only up and down events. The difference between the counters is that where the auxiliary counter will only count up, the main counter will count up or down depending on the direction of the count event.

#### 16.3.4 Triggered Compare and Clear

The pulse counter features triggered compare and clear. When enabled, a configurable trigger will induce a comparison between the main counter, PCNT<sub>n</sub>\_CNT, and the top value, PCNT<sub>n</sub>\_TOP. After the comparison, the counter is cleared. The trigger for a compare and clear event is configured in the TCCMODE bit-field in PCNT<sub>n</sub>\_CTRL. There are two options, LFA and PRS. If LFA is selected, the pulse counter will be compared with the top value, and cleared every  $2^N$  LFA clock cycle (where N is the value of TCCPRES in PCNT<sub>n</sub>\_CTRL). If a PRS trigger is selected, the active PRS channel is configured in TCCPRSSEL in PCNT<sub>n</sub>\_CTRL. The PRS input can be inverted by setting TCCPRSPOL, triggering the compare and clear on the negative edge of the PRS input. The PRS input can also be used as a gate for the pulse counter clock. This is enabled by setting PRSGATEEN in PCNT<sub>n</sub>\_CTRL.

**Note:** When PRSGATEEN is set, the clock to the entire pulse counter will be gated by the PRS input, meaning that register writes will not take effect while the gated clock is inactive.

Comparison with PCNT<sub>n</sub>\_TOP can be performed in three ways: range, greater than or equal, and less than or equal. TCCCOMP in PCNT<sub>n</sub>\_CTRL configures comparison mode. Upon a compare match, the TCC interrupt is set, and the PRS output from the pulse counter is set. The PRS output will remain set until the next compare and clear event. Triggered compare and clear is intended for use when the pulse counter is configured to count up. In this mode, PCNT<sub>n</sub>\_CNT will not wrap to 0 when hitting PCNT<sub>n</sub>\_TOP, it will keep counting. In addition, the counter will not overflow, it will rather stop counting, just setting the overflow interrupt flag.

[Figure 16.11 PCNT Triggered Compare and Clear on page 536](#) shows an overview of the control circuitry for triggered compare and clear. The control circuitry includes two positive edge detectors (PED) and glitch filters, used to generate clocks for the pulse counter. The two clock outputs are mutually exclusive: If both edge detectors receive a pulse at the same time, the output pulse from one of them will be postponed until the other edge detectors output pulse has completed.




Figure 16.11. PCNT Triggered Compare and Clear

**Note:** TCCMODE, TCCPRES, PRSGATEEN, TCCPRSPOL, and TCCPRSSEL in PCNT<sub>n</sub>\_CTRL should only be altered when RSTEN in PCNT<sub>n</sub>\_CTRL is set.

### 16.3.5 Register Access

The counter-clock domain may be clocked externally. To update the counter-clock domain registers from software in this mode, 2-3 clock pulses on the external clock are needed to synchronize accesses to the externally clocked domain. Clock source switching is controlled from the registers in the CMU ([10. CMU - Clock Management Unit](#) ).

When the RSTEN bit in the PCNTn\_CTRL register is set, the PCNT clock domain is asynchronously held in reset. The reset is synchronously released two PCNT clock edges after the RSTEN bit in the PCNTn\_CTRL register is cleared by software. This asynchronous reset restores the reset values in PCNTn\_TOP, PCNTn\_CNT and other control registers in the PCNT clock domain.

CNTRSTEN works in a similar manner as RSTEN, but only resetting the counter, CNT. Note that the counter is also reset by RSTEN.

AUXCNTRSTEN works in a similar manner as RSTEN, but only resetting the auxiliary counter, PCNTn\_AUXCNT. Note that the auxiliary counter is also reset by RSTEN.

Since this module is a Low Energy Peripheral, and runs off a clock which is asynchronous to the HFCORECLK, special considerations must be taken when accessing registers. Refer to [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#) for a description on how to perform register accesses to Low Energy Peripherals.

**Note:** PCNTn\_TOP and PCNTn\_CNT are read-only registers. When writing to PCNTn\_TOPB, make sure that the counter value, PCNTn\_CNT, can not exceed the value written to PCNTn\_TOPB within two clock cycles.

### 16.3.6 Clock Sources

The pulse counter may be clocked from two possible clock sources: LFACLK or an external clock. The clock selection is configured by the PCNT0CLKSEL bit in the CMU\_PCNTCTRL in the Clock Management Unit (CMU), [10. CMU - Clock Management Unit](#). The default clock source is the LFACLK.

This PCNT module may also use PCNTn\_S0IN as an external clock to clock the counter (EXTCLKSINGLE mode) and to sample PCNTn\_S1IN (EXTCLKQUAD mode). Setup, hold and max frequency constraints for PCNTn\_S0IN and PCNTn\_S1IN for these modes are specified in the device data sheet.

To use this module, the LE interface clock must be enabled in CMU\_HFBUSCLKEN0, in addition to the module clock in CMU\_PCNTCTRL.

**Note:** PCNT Clock Domain Reset, RSTEN, should be set when changing clock source for PCNT. If changing to an external clock source, the clock pin has to be enabled as input prior to de-asserting RSTEN. Changing clock source without asserting RSTEN results in undefined behaviour.

### 16.3.7 Input Filter

An optional pulse width filter is available in OVSSINGLE and OVSQUAD modes, when LFACLK is selected as a clock source for the Pulse Counter in CMU [10. CMU - Clock Management Unit](#). The filter is enabled by writing 1 to the FILT bit in the PCNTn\_CTRL register. When enabled, the high and low periods of PCNTn\_S0IN and PCNTn\_S1IN must be stable for a programmable number of consecutive clock cycles before the edge is passed to the edge detector. The filter length should be programmed in FILTLEN field of the PCNTn\_OVSCFG register.

The filter length is given by [Figure 16.12 PCNT Input Filter Length Equation on page 537](#):

$$\text{Filter length} = (\text{FILTLEN} + 5) \text{ LFACLK cycles}$$

**Figure 16.12. PCNT Input Filter Length Equation**

The maximum filter length configured is 260 LFACLK cycles.

In EXTCLKSINGLE and EXTCLKQUAD mode, there is no digital pulse width filter available.

### 16.3.8 Edge Polarity

The edge polarity can be set by configuring the EDGE bit in the PCNTn\_CTRL register. When this bit is cleared, the pulse counter counts positive edges of PCNTn\_S0IN input. When this bit is set, the pulse counter counts negative edges in OVSSINGLE mode. Also, when the EDGE bit is set in the OVSSINGLE and EXTCLKSINGLE modes, the PCNTn\_S1IN input is inverted. In OVSQUAD 1X-4X modes the EDGE bit inverts both inputs.

**Note:** The EDGE bit in PCNTn\_CTRL has no effect in EXTCLKQUAD mode.

### 16.3.9 PRS and PCNTn\_S0IN,PCNTn\_S1IN Inputs

It is possible to receive input from PRS on both PCNTn\_S0IN (or PCNTn\_S1IN) by setting S0PRSEN (or S1PRSEN) in PCNTn\_IN-PUT. The PRS channel used can be selected using S0PRSSEL (or S1PRSSEL) in PCNTn\_INPUT.

In the Oversampling quadrature decoder modes, the input frequency should be less than 8KHz to ensure correct functionality.

PCNT module generates three PRS outputs the TCC PRS output, the CNT OF/UF PRS output and the CNT DIR PRS output. The TCC PRS is generated on compare match of TCC event. The CNT OF/UF combined PRS is generated when the counter overflow or underflows. The CNT DIR PRS is a level PRS and indicates the current direction of count of counter CNT

**Note:** S0PRSEN,S1PRSEN,S0PRSSEL,S1PRSSEL should only be altered when RSTEN in PCNTn\_CTRL is set.

### 16.3.10 Interrupts

The interrupt generated by PCNT uses the PCNTn\_INT interrupt vector. Software must read the PCNTn\_IF register to determine which module interrupt that generated the vector invocation.


#### 16.3.10.1 Underflow and Overflow Interrupts

The underflow interrupt flag (UF) is set when the counter counts down from 0. I.e. when the value of the counter is 0 and a new pulse is received. The PCNTn\_CNT register is loaded with the PCNTn\_TOP value after this event.

The overflow interrupt flag (OF) is set when the counter counts up from the PCNTn\_TOP (reload) value. I.e. if PCNTn\_CNT = PCNTn\_TOP and a new pulse is received. The PCNTn\_CNT register is loaded with the value 0 after this event.

### 16.3.10.2 Direction Change Interrupt


The PCNTn\_PCNT module sets the DIRCNG interrupt flag (PCNTn\_IF register) for EXTCLKQUAD and OVSQUAD1X-4X modes when the direction of the quadrature code changes. The behavior of this interrupt in the EXTCLKQUAD mode is illustrated by [Figure 16.13 PCNT Direction Change Interrupt \(DIRCNG\) Generation on page 539](#).



**Figure 16.13. PCNT Direction Change Interrupt (DIRCNG) Generation**

### 16.3.11 Cascading Pulse Counters

When two or more Pulse Counters are available, it is possible to cascade them. For example two 16-bit Pulse Counters can be cascaded to form a 32-bit pulse counter. This can be done with the help of the CNT UF/OF PRS and CNT DIR PRS outputs. The figure [Figure 16.14 PCNT Cascading to two 16-bit PCNT to form a 32-bit PCNT on page 540](#) illustrates this structure.



**Figure 16.14. PCNT Cascading to two 16-bit PCNT to form a 32-bit PCNT**

For cascading of Pulse Counters to work, the PCNT1 according to the figure [Figure 16.14 PCNT Cascading to two 16-bit PCNT to form a 32-bit PCNT on page 540](#) should be programmed in EXTCLKSINGLE mode and its S0IN and S1IN inputs should be configured to prs\_ufof and prs\_dir of PCNT0 respectively. In addition to this, a strict programming sequence needs to be followed to ensure both PCNTs are in sync with each other.

- Configure PCNT0 registers. eg. PCNT0\_INPUT, PCNT0\_CTRL, PCNT0\_OVSCFG etc.
- Wait for PCNT0\_SYNBNBUSY to be cleared to ensure the registers are synchronized to the asynchronous clock domain.
- Hold PCNT0 in sw reset by setting PCNT0\_CTRL\_RSTEN.
- Configure PCNT1\_CTRL to EXTCLKSINLE mode with S1CDIR and CNTDIR bit set. Configure INPUT to accept "prs\_ufof" and "prs\_dir" of PCNT0 on S0IN and S1IN respectively.
- Wait for PCNTn\_SYNBNBUSY to be cleared to ensure the registers are synchronized to the asynchronous clock domain. Use three PRS\_SWPULSE on the S0IN prs channel to ensure this synchronization.
- Hold PCNT1 in sw reset by setting PCNT1\_CTRL\_RSTEN.
- Clear PCNT1\_CTRL\_RSTEN and synchronize it by asserting two PRS\_SWPULSE on the S0IN input.
- Finally clear PCNT0\_CTRL\_RSTEN and start counting.

**Note:** When RSTEN in PCNTn\_CTRL is set, the TOP value in the Pulse Counter gets cleared. Therefore, in order to update the TOP value while RSTEN is set, assert TOPBFHEN bit in PCNTn\_CTRL. This will update the TOP value with the TOPB value even without having to synchronize the TOPB value. This only works if TOPBFHEN and TOPB are configured while RSTEN in PCNTn\_CTRL is set.

## 16.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	PCNTn_CTRL	RW	Control Register
0x004	PCNTn_CMD	W1	Command Register
0x008	PCNTn_STATUS	R	Status Register
0x00C	PCNTn_CNT	R	Counter Value Register
0x010	PCNTn_TOP	R	Top Value Register
0x014	PCNTn_TOPB	RW	Top Value Buffer Register
0x018	PCNTn_IF	R	Interrupt Flag Register
0x01C	PCNTnIFS	W1	Interrupt Flag Set Register
0x020	PCNTnIFC	(R)W1	Interrupt Flag Clear Register
0x024	PCNTnIEN	RW	Interrupt Enable Register
0x02C	PCNTnROUTELOC0	RW	I/O Routing Location Register
0x040	PCNTnFREEZE	RW	Freeze Register
0x044	PCNTnSYNCBUSY	R	Synchronization Busy Register
0x064	PCNTnAUXCNT	R	Auxiliary Counter Value Register
0x068	PCNTnINPUT	RW	PCNT Input Register
0x06C	PCNTnOVSCFG	RW	Oversampling Config Register

## 16.5 Register Description

### 16.5.1 PCNTn\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																							
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0								
Reset	0						0								0																									
Access	RW	0					RW	0x0							RW	0x0																								
Name	TOPBHFSEL				TCCPRSSEL		TCCPRSPOL		PRSGATEEN		TCCCOMP		TCCPRESC		TCCMODE		EDGE		CNTDIR		AUXCNTEV		CNTEV		S1CDIR		HYST		DEBUGHALT		AUXCNRSTEN		CNRSTEN		RSTEN		FILT		MODE	

Bit	Name	Reset	Access	Description
31	TOPBHFSEL	0	RW	<b>TOPB High Frequency Value Select</b>  Apply High frequency value of TOPB to TOP register. Should be used only when RSTEN in PCNTn_CTRL is set
30:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28:26	TCCPRSSEL	0x0	RW	<b>TCC PRS Channel Select</b>  Select PRS channel used as compare and clear trigger.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected.
	1	PRSCH1		PRS Channel 1 selected.
	2	PRSCH2		PRS Channel 2 selected.
	3	PRSCH3		PRS Channel 3 selected.
	4	PRSCH4		PRS Channel 4 selected.
	5	PRSCH5		PRS Channel 5 selected.
	6	PRSCH6		PRS Channel 6 selected.
	7	PRSCH7		PRS Channel 7 selected.
25	TCCPRSPOL	0	RW	<b>TCC PRS Polarity Select</b>  Configure which edge on the PRS input is used to trigger a compare and clear event
	Value	Mode		Description
	0	RISING		Rising edge on PRS trigger compare and clear event.
	1	FALLING		Falling edge on PRS trigger compare and clear event.
24	PRSGATEEN	0	RW	<b>PRS Gate Enable</b>  When set, the clock input to the pulse counter will be gated when the selected PRS input is the inverse of TCCPRSPOL.

Bit	Name	Reset	Access	Description
23:22	TCCCOMP	0x0	RW	<b>Triggered Compare and Clear Compare Mode</b>  Selects the mode for comparison upon a compare and clear event.
<hr/>				
	Value	Mode		Description
	0	LTOE		Compare match if PCNT_CNT is less than, or equal to PCNT_TOP.
	1	GTOE		Compare match if PCNT_CNT is greater than or equal to PCNT_TOP.
	2	RANGE		Compare match if PCNT_CNT is less than, or equal to PCNT_TOP[15:8], and greater than, or equal to PCNT_TOP[7:0].
<hr/>				
21	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
20:19	TCCPRES	0x0	RW	<b>Set the LFA Prescaler for Triggered Compare and Clear</b>  Selects the prescaler value for LFA compare and clear events
<hr/>				
	Value	Mode		Description
	0	DIV1		Compare and clear event each LFA cycle.
	1	DIV2		Compare and clear performed on every other LFA cycle.
	2	DIV4		Compare and clear performed on every 4th LFA cycle.
	3	DIV8		Compare and clear performed on every 8th LFA cycle.
<hr/>				
18	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
17:16	TCCMODE	0x0	RW	<b>Sets the Mode for Triggered Compare and Clear</b>  Selects whether compare and clear should be triggered on each LFA clock, or from PRS
<hr/>				
	Value	Mode		Description
	0	DISABLED		Triggered compare and clear not enabled.
	1	LFA		Compare and clear performed on each (optionally prescaled) LFA clock cycle.
	2	PRS		Compare and clear performed on positive PRS edges.
<hr/>				
15	EDGE	0	RW	<b>Edge Select</b>  Determines the polarity of the incoming edges. This bit should be written when PCNT is in DISABLE mode, otherwise the behavior is unpredictable. This bit used only in OVSSINGLE, EXTCLKSINGLE and OVSQUAD1X-4X modes.
<hr/>				
	Value	Mode		Description
	0	POS		Positive edges on the PCNTn_S0IN inputs are counted in OVSSINGLE mode. Does not invert PCNTn_S1IN input in OVSSINGLE and EXTCLKSINGLE modes
	1	NEG		Negative edges on the PCNTn_S0IN inputs are counted in OVSSINGLE mode. Inverts the PCNTn_S1IN input in OVSSINGLE and EXTCLKSINGLE modes
<hr/>				
14	CNTDIR	0	RW	<b>Non-Quadrature Mode Counter Direction Control</b>  The direction of the counter must be set in the OVSSINGLE and EXTCLKSINGLE modes. This bit is ignored in EXTCLKQUAD mode as the direction is automatically detected.
<hr/>				

Bit	Name	Reset	Access	Description
	Value	Mode		Description
0	UP			Up counter mode.
1	DOWN			Down counter mode.
13:12	AUXCNTEV	0x0	RW	<b>Controls When the Auxiliary Counter Counts</b>
	Selects whether the auxiliary counter responds to up-count events, down-count events or both			
	Value	Mode		Description
0	NONE			Never counts.
1	UP			Counts up on up-count events.
2	DOWN			Counts up on down-count events.
3	BOTH			Counts up on both up-count and down-count events.
11:10	CNTEV	0x0	RW	<b>Controls When the Counter Counts</b>
	Selects whether the regular counter responds to up-count events, down-count events or both			
	Value	Mode		Description
0	BOTH			Counts up on up-count and down on down-count events.
1	UP			Only counts up on up-count events.
2	DOWN			Only counts down on down-count events.
3	NONE			Never counts.
9	S1CDIR	0	RW	<b>Count Direction Determined By S1</b>
	S1 gives the direction of counting when in the OVSSINGLE or EXTCLKSINGLE modes. When S1 is high, the count direction is given by CNTDIR, and when S1 is low, the count direction is the opposite			
8	HYST	0	RW	<b>Enable Hysteresis</b>
	When hysteresis is enabled, the PCNT will always overflow and underflow to TOP/2.			
7	DEBUGHALT	0	RW	<b>Debug Mode Halt Enable</b>
	Set to halt the PCNT in debug mode only in OVSSINGLE and OVSQUAD modes. When in EXTCLKSINGLE or EX-TCLKQUAD modes, DEBUGHALT does not halt the Pulse Counter.			
	Value			Description
0				PCNT is running in debug mode.
1				PCNT is frozen in debug mode.
6	AUXCNTRSTEN	0	RW	<b>Enable AUXCNT Reset</b>
	The auxiliary counter, AUXCNT, is asynchronously held in reset when this bit is set. The reset is synchronously released two PCNT clock edges after this bit is cleared. If an external clock is used, the reset should be performed by setting and clearing the bit without pending for SYNCBUSY bit.			
5	CNTRSTEN	0	RW	<b>Enable CNT Reset</b>
	The counter, CNT, is asynchronously held in reset when this bit is set. The reset is synchronously released two PCNT clock edges after this bit is cleared. If an external clock is used, the reset should be performed by setting and clearing the bit without pending for SYNCBUSY bit. This action clears the counter to its reset value			

Bit	Name	Reset	Access	Description
4	RSTEN	0	RW	<b>Enable PCNT Clock Domain Reset</b>  The PCNT clock domain is asynchronously held in reset when this bit is set. The reset is synchronously released two PCNT clock edges after this bit is cleared. If an external clock is used, the reset should be performed by setting and clearing the bit without pending for SYNCBUSY bit.
3	FILT	0	RW	<b>Enable Digital Pulse Width Filter</b>  The filter passes all high and low periods that are at least (FILTLEN+5) clock cycles wide. This filter is only available in OVSSINGLE,OVSQUAD1X-4X modes.
2:0	MODE	0x0	RW	<b>Mode Select</b>  Selects the mode of operation. The corresponding clock source must be selected from the CMU.
	Value	Mode		Description
	0	DISABLE		The module is disabled.
	1	OVSSINGLE		Single input LFACLK oversampling mode (available in EM0-EM3).
	2	EXTCLKSINGLE		Externally clocked single input counter mode (available in EM0-EM3).
	3	EXTCLKQUAD		Externally clocked quadrature decoder mode (available in EM0-EM3).
	4	OVSQUAD1X		LFACLK oversampling quadrature decoder 1X mode (available in EM0-EM3).
	5	OVSQUAD2X		LFACLK oversampling quadrature decoder 2X mode (available in EM0-EM3).
	6	OVSQUAD4X		LFACLK oversampling quadrature decoder 4X mode (available in EM0-EM3).

### 16.5.2 PCNTn\_CMD - Command Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0 0																															
Access	W1 W1																															
Name	LTOPBIM LCNTIM																															

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	LTOPBIM	0	W1	<b>Load TOPB Immediately</b>  This bit has no effect since TOPB is not buffered and it is loaded directly into TOP.
0	LCNTIM	0	W1	<b>Load CNT Immediately</b>  Load PCNTn_TOP into PCNTn_CNT on the next counter clock cycle.

### 16.5.3 PCNTn\_STATUS - Status Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	DIR	0	R	<b>Current Counter Direction</b>
				Current direction status of the counter. This bit is valid in EXTCLKQUAD mode only.

Value	Mode	Description
0	UP	Up counter mode (clockwise in EXTCLKQUAD mode with the EDGE bit in PCNTn_CTRL set to 0).
1	DOWN	Down counter mode.

#### **16.5.4 PCNTn\_CNT - Counter Value Register**

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	CNT	0x0000	R	<b>Counter Value</b>  Gives read access to the counter.

### 16.5.5 PCNTn\_TOP - Top Value Register

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	TOP	0x00FF	R	<b>Counter Top Value</b>  When counting down, this value is reloaded into PCNTn_CNT when counting past 0. When counting up, 0 is written to the PCNTn_CNT register when counting past this value.

#### 16.5.6 PCNTn\_TOPB - Top Value Buffer Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	TOPB	0x00FF	RW	<b>Counter Top Buffer</b>  Loaded automatically to TOP when written.

## 16.5.7 PCNTn\_IF - Interrupt Flag Register

Offset	Bit Position																									
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
Reset																										
Access																										
Name																										

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	OQSTERR	0	R	<b>Oversampling Quadrature State Error Interrupt</b>  Set in the Oversampling Quadrature Mode when incorrect state transition occurs
4	TCC	0	R	<b>Triggered Compare Interrupt Read Flag</b>  Set upon triggered compare match
3	AUXOF	0	R	<b>Auxiliary Overflow Interrupt Read Flag</b>  Set when an Auxiliary CNT overflow occurs
2	DIRCNG	0	R	<b>Direction Change Detect Interrupt Flag</b>  Set when the count direction changes. Set in EXTCLKQUAD mode only.
1	OF	0	R	<b>Overflow Interrupt Read Flag</b>  Set when a CNT overflow occurs
0	UF	0	R	<b>Underflow Interrupt Read Flag</b>  Set when a CNT underflow occurs

### 16.5.8 PCNTn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																									
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
Access																										
Name																										
OQSTERR	W1	0	5	TCC	W1	0	4	AUXOF	W1	0	3	DIRCNG	W1	0	2	OF	W1	0	1	UF	W1	0	0			

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	OQSTERR	0	W1	<b>Set OQSTERR Interrupt Flag</b>
				Write 1 to set the OQSTERR interrupt flag
4	TCC	0	W1	<b>Set TCC Interrupt Flag</b>
				Write 1 to set the TCC interrupt flag
3	AUXOF	0	W1	<b>Set AUXOF Interrupt Flag</b>
				Write 1 to set the AUXOF interrupt flag
2	DIRCNG	0	W1	<b>Set DIRCNG Interrupt Flag</b>
				Write 1 to set the DIRCNG interrupt flag
1	OF	0	W1	<b>Set OF Interrupt Flag</b>
				Write 1 to set the OF interrupt flag
0	UF	0	W1	<b>Set UF Interrupt Flag</b>
				Write 1 to set the UF interrupt flag

## 16.5.9 PCNTn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									OQSTERR	(R)W1	0					
Access																									TCC	(R)W1	0					
Name																									AUXOF	(R)W1	0					

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
5	OQSTERR	0	(R)W1	<b>Clear OQSTERR Interrupt Flag</b>
				Write 1 to clear the OQSTERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	TCC	0	(R)W1	<b>Clear TCC Interrupt Flag</b>
				Write 1 to clear the TCC interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	AUXOF	0	(R)W1	<b>Clear AUXOF Interrupt Flag</b>
				Write 1 to clear the AUXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	DIRCNG	0	(R)W1	<b>Clear DIRCNG Interrupt Flag</b>
				Write 1 to clear the DIRCNG interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	OF	0	(R)W1	<b>Clear OF Interrupt Flag</b>
				Write 1 to clear the OF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	UF	0	(R)W1	<b>Clear UF Interrupt Flag</b>
				Write 1 to clear the UF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 16.5.10 PCNTn\_IEN - Interrupt Enable Register

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0	0	0	0	0	0		
Access																									RW	RW	RW	RW	RW	RW		
Name																									OQSTERR	TCC	AUXOF	DIRCNG	OF	UF		

Bit	Name	Reset	Access	Description
31:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
5	OQSTERR	0	RW	<b>OQSTERR Interrupt Enable</b>  Enable/disable the OQSTERR interrupt
4	TCC	0	RW	<b>TCC Interrupt Enable</b>  Enable/disable the TCC interrupt
3	AUXOF	0	RW	<b>AUXOF Interrupt Enable</b>  Enable/disable the AUXOF interrupt
2	DIRCNG	0	RW	<b>DIRCNG Interrupt Enable</b>  Enable/disable the DIRCNG interrupt
1	OF	0	RW	<b>OF Interrupt Enable</b>  Enable/disable the OF interrupt
0	UF	0	RW	<b>UF Interrupt Enable</b>  Enable/disable the UF interrupt

## 16.5.11 PCNTn\_ROUTELOC0 - I/O Routing Location Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00									0x00						
Access																	RW									RW						
Name																	S1INLOC									S0INLOC						

Bit	Name	Reset	Access	Description
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

13:8	S1INLOC	0x00	RW	<b>I/O Location</b>
------	---------	------	----	---------------------

Defines the location of the PCNT S1IN input pin.

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3
4	LOC4	Location 4
5	LOC5	Location 5
6	LOC6	Location 6
7	LOC7	Location 7

7:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
-----	----------	---

5:0	S0INLOC	0x00	RW	<b>I/O Location</b>
-----	---------	------	----	---------------------

Defines the location of the PCNT S0IN input pin.

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3
4	LOC4	Location 4
5	LOC5	Location 5
6	LOC6	Location 6
7	LOC7	Location 7

### 16.5.12 PCNTn\_FREEZE - Freeze Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																																
Name																										REGFREEZE	RW	0				

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	REGFREEZE	0	RW	<b>Register Update Freeze</b>
When set, the update of the PCNT clock domain is postponed until this bit is cleared. Use this bit to update several registers simultaneously.				
Value	Mode	Description		
0	UPDATE	Each write access to a PCNT register is updated into the Low Frequency domain as soon as possible.		
1	FREEZE	The PCNT clock domain is not updated with the new written value.		

### 16.5.13 PCNTn\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																																		
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	OVSCFG	R	0	3			
Access																																TOPB	R	0	2
Name																																CMD	R	0	1
																																CTRL	R	0	0

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	OVSCFG	0	R	<b>OVSCFG Register Busy</b> Set when the value written to OVSCFG is being synchronized.
2	TOPB	0	R	<b>TOPB Register Busy</b> Set when the value written to TOPB is being synchronized.
1	CMD	0	R	<b>CMD Register Busy</b> Set when the value written to CMD is being synchronized.
0	CTRL	0	R	<b>CTRL Register Busy</b> Set when the value written to CTRL is being synchronized.

## 16.5.14 PCNTn\_AUXCNT - Auxiliary Counter Value Register

Offset	Bit Position																															
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x0000			
Access																													R			
Name																													AUXCNT			

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	AUXCNT	0x0000	R	<b>Auxiliary Counter Value</b>  Gives read access to the auxiliary counter.

### 16.5.15 PCNTn\_INPUT - PCNT Input Register

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	S1PRSEN	0	RW	<b>S1IN PRS Enable</b>
				When set, the PRS channel is selected as input to S1IN.
10:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:6	S1PRSSEL	0x0	RW	<b>S1IN PRS Channel Select</b>
				Select PRS channel as input to S1IN.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected.
	1	PRSCH1		PRS Channel 1 selected.
	2	PRSCH2		PRS Channel 2 selected.
	3	PRSCH3		PRS Channel 3 selected.
	4	PRSCH4		PRS Channel 4 selected.
	5	PRSCH5		PRS Channel 5 selected.
	6	PRSCH6		PRS Channel 6 selected.
	7	PRSCH7		PRS Channel 7 selected.
5	S0PRSEN	0	RW	<b>S0IN PRS Enable</b>
				When set, the PRS channel is selected as input to S0IN.
4:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	S0PRSSEL	0x0	RW	<b>S0IN PRS Channel Select</b>
				Select PRS channel as input to S0IN.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected.
	1	PRSCH1		PRS Channel 1 selected.
	2	PRSCH2		PRS Channel 2 selected.
	3	PRSCH3		PRS Channel 3 selected.

Bit	Name	Reset	Access	Description
4	PRSCH4			PRS Channel 4 selected.
5	PRSCH5			PRS Channel 5 selected.
6	PRSCH6			PRS Channel 6 selected.
7	PRSCH7			PRS Channel 7 selected.



### 16.5.16 PCNTn\_OVSCFG - Oversampling Config Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																													0	0x00		
<b>Access</b>																												RW				
<b>Name</b>																												FLUTTERRM	FILTLEN			

Bit	Name	Reset	Access	Description
31:13	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	FLUTTERRM	0	RW	<b>Flutter Remove</b>
	When set, removes flutter from Quaddecoder inputs S0IN and S1IN. Available only in OVSQUAD1X-4X modes			
11:8	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	FILTLEN	0x00	RW	<b>Configure Filter Length for Inputs S0IN and S1IN</b>
	Used only in OVSINGLE,OVSQUAD1X-4X modes. To use this first enable FILT in PCNTn_CTRL register. Filter length = (FILTLEN + 5) LFACLK cycles			

## 17. I2C - Inter-Integrated Circuit Interface



### Quick Facts

#### What?

The I<sup>2</sup>C interface allows communication on I<sup>2</sup>C-buses with the lowest energy consumption possible.

#### Why?

I<sup>2</sup>C is a popular serial bus that enables communication with a number of external devices using only two I/O pins.

#### How?

With the help of DMA, the I<sup>2</sup>C interface allows I<sup>2</sup>C communication with minimal CPU intervention. Address recognition is available in all energy modes (except EM4), allowing the MCU to wait for data on the I<sup>2</sup>C-bus with sub- $\mu$ A current consumption.

### 17.1 Introduction


The I<sup>2</sup>C module provides an interface between the MCU and a serial I<sup>2</sup>C-bus. It is capable of acting as both a master and a slave and supports multi-master buses. Standard-mode, fast-mode and fast-mode plus speeds are supported, allowing transmission rates all the way from 10 kbit/s up to 1 Mbit/s. Slave arbitration and timeouts are also provided to allow implementation of an SMBus compliant system. The interface provided to software by the I<sup>2</sup>C module allows precise control of the transmission process and highly automated transfers. Automatic recognition of slave addresses is provided in all energy modes (except EM4).

### 17.2 Features

- True multi-master capability
- Support for different bus speeds
  - Standard-mode (Sm) bit rate up to 100 kbit/s
  - Fast-mode (Fm) bit rate up to 400 kbit/s
  - Fast-mode Plus (Fm+) bit rate up to 1 Mbit/s
- Arbitration for both master and slave (allows SMBus ARP)
- Clock synchronization and clock stretching
- Hardware address recognition
  - 7-bit masked address
  - General call address
  - Active in all energy modes (except EM4)
- 10-bit address support
- Error handling
  - Clock low timeout
  - Clock high timeout
  - Arbitration lost
  - Bus error detection
- Separate receive/ transmit 2-level buffers, with additional separate shift registers
- Full DMA support

### 17.3 Functional Description


An overview of the I2C module is shown in [Figure 17.1 I2C Overview on page 558](#).



**Figure 17.1. I<sup>2</sup>C Overview**

### 17.3.1 I2C-Bus Overview

The I<sup>2</sup>C-bus uses two wires for communication; a serial data line (SDA) and a serial clock line (SCL) as shown in [Figure 17.2 I2C-Bus Example on page 559](#). As a true multi-master bus it includes collision detection and arbitration to resolve situations where multiple masters transmit data at the same time without data loss.



**Figure 17.2. I2C-Bus Example**

Each device on the bus is addressable by a unique address, and an I<sup>2</sup>C master can address all the devices on the bus, including other masters.

Both the bus lines are open-drain. The maximum value of the pull-up resistor can be calculated as a function of the maximal rise-time  $t_r$  for the given bus speed, and the estimated bus capacitance  $C_b$  as shown in [Figure 17.3 I2C Pull-up Resistor Equation on page 559](#).

$$R_p(\max) = t_r / (0.8473 \times C_b)$$

**Figure 17.3. I2C Pull-up Resistor Equation**


The maximal rise times for 100 kHz, 400 kHz and 1 MHz I<sup>2</sup>C are 1  $\mu$ s, 300 ns and 120 ns respectively.

**Note:**

- The GPIO drive strength can be used to control slew rate.
- If  $V_{dd}$  drops below the voltage on SCL and SDA lines, the MCU could become back powered and pull the SCL and SDA lines low.


### 17.3.1.1 START and STOP Conditions

START and STOP conditions are used to initiate and stop transactions on the I<sup>2</sup>C-bus. All transactions on the bus begin with a START condition (S) and end with a STOP condition (P). As shown in [Figure 17.4 I2C START and STOP Conditions on page 560](#), a START condition is generated by pulling the SDA line low while SCL is high, and a STOP condition is generated by pulling the SDA line high while SCL is high.



**Figure 17.4. I2C START and STOP Conditions**

The START and STOP conditions are easily identifiable bus events as they are the only conditions on the bus where a transition is allowed on SDA while SCL is high. During the actual data transmission, SDA is only allowed to change while SCL is low, and must be stable while SCL is high. One bit is transferred per clock pulse on the I<sup>2</sup>C-bus as shown in [Figure 17.5 I2C Bit Transfer on I<sup>2</sup>C-Bus on page 560](#).



**Figure 17.5. I2C Bit Transfer on I<sup>2</sup>C-Bus**

### 17.3.1.2 Bus Transfer

When a master wants to initiate a transfer on the bus, it waits until the bus is idle and transmits a START condition on the bus. The master then transmits the address of the slave it wishes to interact with and a single R/W bit telling whether it wishes to read from the slave (R/W bit set to 1) or write to the slave (R/W bit set to 0).

After the 7-bit address and the R/W bit, the master releases the bus, allowing the slave to acknowledge the request. During the next bit-period, the slave pulls SDA low (ACK) if it acknowledges the request, or keeps it high if it does not acknowledge it (NACK).

Following the address acknowledge, either the slave or master transmits data, depending on the value of the R/W bit. After every 8 bits (one byte) transmitted on the SDA line, the transmitter releases the line to allow the receiver to transmit an ACK or a NACK. Both the data and the address are transmitted with the most significant bit first.

The number of bytes in a bus transfer is unrestricted. The master ends the transmission after a (N)ACK by sending a STOP condition on the bus. After a STOP condition, any master wishing to initiate a transfer on the bus can try to gain control of it. If the current master wishes to make another transfer immediately after the current, it can start a new transfer directly by transmitting a repeated START condition (Sr) instead of a STOP followed by a START.

Examples of I<sup>2</sup>C transfers are shown in [Figure 17.6 I2C Single Byte Write to Slave on page 561](#), [Figure 17.7 I2C Double Byte Read from Slave on page 561](#), and [Figure 17.8 I2C Single Byte Write, then Repeated Start and Single Byte Read on page 561](#). The identifiers used are:

- ADDR - Address
- DATA - Data
- S - Start bit
- Sr - Repeated start bit
- P - Stop bit
- W/R - Read(1)/Write(0)
- A - ACK
- N - NACK



Figure 17.6. I<sup>2</sup>C Single Byte Write to Slave



Figure 17.7. I<sup>2</sup>C Double Byte Read from Slave



Figure 17.8. I<sup>2</sup>C Single Byte Write, then Repeated Start and Single Byte Read

### 17.3.1.3 Addresses

I<sup>2</sup>C supports both 7-bit and 10-bit addresses. When using 7-bit addresses, the first byte transmitted after the START-condition contains the address of the slave that the master wants to contact. In the 7-bit address space, several addresses are reserved. These addresses are summarized in [Table 17.1 I<sup>2</sup>C Reserved I<sup>2</sup>C Addresses on page 562](#), and include a General Call address which can be used to broadcast a message to all slaves on the I<sup>2</sup>C-bus.

**Table 17.1. I<sup>2</sup>C Reserved I<sup>2</sup>C Addresses**


I <sup>2</sup> C Address	R/W	Description
0000-000	0	General Call address
0000-000	1	START byte
0000-001	X	Reserved for the C-Bus format
0000-010	X	Reserved for a different bus format
0000-011	X	Reserved for future purposes
0000-1XX	X	Reserved for future purposes
1111-1XX	X	Reserved for future purposes
1111-0XX	X	10 Bit slave addressing mode

### 17.3.1.4 10-bit Addressing


To address a slave using a 10-bit address, two bytes are required to specify the address instead of one. The seven first bits of the first byte must then be 1111 0XX, where XX are the two most significant bits of the 10-bit address. As with 7-bit addresses, the eighth bit of the first byte determines whether the master wishes to read from or write to the slave. The second byte contains the eight least significant bits of the slave address.

When a slave receives a 10-bit address, it must acknowledge both the address bytes if they match the address of the slave.

When performing a master transmitter operation, the master transmits the two address bytes and then the remaining data, as shown in [Figure 17.9 I<sup>2</sup>C Master Transmitter/Slave Receiver with 10-bit Address on page 562](#).

**Figure 17.9. I<sup>2</sup>C Master Transmitter/Slave Receiver with 10-bit Address**

When performing a master receiver operation however, the master first transmits the two address bytes in a master transmitter operation, then sends a repeated START followed by the first address byte and then receives data from the addressed slave. The slave addressed by the 10-bit address in the first two address bytes must remember that it was addressed, and respond with data if the address transmitted after the repeated start matches its own address. An example of this (with one byte transmitted) is shown in [Figure 17.10 I<sup>2</sup>C Master Receiver/Slave Transmitter with 10-bit Address on page 562](#).

**Figure 17.10. I<sup>2</sup>C Master Receiver/Slave Transmitter with 10-bit Address**

### 17.3.1.5 Arbitration, Clock Synchronization, Clock Stretching

Arbitration and clock synchronization are features aimed at allowing multi-master buses. Arbitration occurs when two devices try to drive the bus at the same time. If one device drives it low, while the other drives it high, the one attempting to drive it high will not be able to do so due to the open-drain bus configuration. Both devices sample the bus, and the one that was unable to drive the bus in the desired direction detects the collision and backs off, letting the other device continue communication on the bus undisturbed.

Clock synchronization is a means of synchronizing the clock outputs from several masters driving the bus at once, and is a requirement for effective arbitration.

Slaves on the bus are allowed to force the clock output on the bus low in order to pause the communication on the bus and give themselves time to process data or perform any real-time tasks they might have. This is called clock stretching.

Arbitration is supported by the I<sup>2</sup>C module for both masters and slaves. Clock synchronization and clock stretching is also supported.

### 17.3.2 Enable and Reset

The I<sup>2</sup>C is enabled by setting the EN bit in the I2Cn\_CTRL register. Whenever this bit is cleared, the internal state of the I<sup>2</sup>C is reset, terminating any ongoing transfers.

**Note:** When enabling the I<sup>2</sup>C, the ABORT command or the Bus Idle Timeout feature must be applied prior to use even if the BUSY flag is not set.

### 17.3.3 Safely Disabling and Changing Slave Configuration

The I<sup>2</sup>C slave is partially asynchronous, and some precautions are necessary to always ensure a safe slave disable or slave configuration change. These measures should be taken, if (while the slave is enabled) the user cannot guarantee that an address match will not occur at the exact time of slave disable or slave configuration change.

Worst case consequences for an address match while disabling slave or changing configuration is that the slave may end up in an undefined state. To reset the slave back to a known state, the EN bit in I2Cn\_CTRL must be reset. This should be done regardless of whether the slave is going to be re-enabled or not.

### 17.3.4 Clock Generation

The SCL signal generated by the I<sup>2</sup>C master determines the maximum transmission rate on the bus. The clock is generated as a division of the peripheral clock, and is given by the following equation:

$$f_{SCL} = f_{HFPERCCLK}/(((N_{low} + N_{high}) \times (DIV + 1)) + 8),$$

**Figure 17.11. I2C Maximum Transmission Rate**

$N_{low}$  and  $N_{high}$  in combination with the synchronization cycles (discussed below) specify the number of prescaled clock cycles in the low and high periods of the clock signal respectively. The worst case low and high periods of the signal are:

$$T_{high} \geq ((N_{high}) \times (DIV + 1) + 4)/f_{HFPERCCLK},$$

$$T_{low} \geq (N_{low} \times (DIV + 1) + 4)/f_{HFPERCCLK}.$$

**Figure 17.12. I2C High and Low Cycles Equations**

In worst case,  $T_{high}$  and  $T_{low}$  can be 1  $f_{HFPERCCLK}$  cycle longer than the number found by above equations due to synchronization uncertainty (i.e., if the synchronization takes 3  $f_{HFPERCCLK}$  cycles instead of 2). Similarly, in the worst case the number 8 in the denominator in  $f_{SCL}$  equation can be 9 (if the synchronization cycles were 3 instead of 2 in  $T_{high}$  or  $T_{low}$ ) or 10 (if synchronization cycles were 3 in both  $T_{high}$  and  $T_{low}$ ). The values of  $N_{low}$  and  $N_{high}$  and thus the ratio between the high and low parts of the clock signal is controlled by CLHR in the I2Cn\_CTRL register.

**Note:** DIV must be set to 1 during slave mode operation.

### 17.3.5 Arbitration

Arbitration is enabled by default, but can be disabled by setting the ARBDIS bit in I2Cn\_CTRL. When arbitration is enabled, the value on SDA is sensed every time the I<sup>2</sup>C module attempts to change its value. If the sensed value is different than the value the I<sup>2</sup>C module tried to output, it is interpreted as a simultaneous transmission by another device, and that the I<sup>2</sup>C module has lost arbitration.

Whenever arbitration is lost, the ARBLOST interrupt flag in I2Cn\_IF is set, any lines held are released, and the I<sup>2</sup>C device goes idle. If an I<sup>2</sup>C master loses arbitration during the transmission of an address, another master may be trying to address it. The master therefore receives the rest of the address, and if the address matches the slave address of the master, the master goes into either slave transmitter or slave receiver mode.


**Note:** Arbitration can be lost both when operating as a master and when operating as a slave.

### 17.3.6 Buffers

The I<sup>2</sup>C peripheral includes separate receive and transmit buffers and shift registers.

#### 17.3.6.1 Transmit Buffer and Shift Register

The I<sup>2</sup>C transmitter has a 2-level FIFO transmit buffer and a transmit shift register as shown in [Figure 17.1 I2C Overview on page 558](#). A byte is loaded into the transmit buffer by writing to I2Cn\_TXDATA or 2 bytes can be loaded simultaneously in the transmit buffer by writing to I2Cn\_TXDOUBLE. [Figure 17.13 I2C Transmit Buffer Operation on page 564](#) shows the basics of the transmit buffer. When the transmit shift register is empty and ready for new data, the byte from the transmit buffer is then loaded into the shift register. The byte is then kept in the shift register until it is transmitted. When a byte has been transmitted, a new byte is loaded into the shift register (if available in the transmit buffer). If the transmit buffer is empty, then the shift register also remains empty. The TXC flag in I2Cn\_STATUS and the TXC interrupt flags in I2Cn\_IF are then set, signaling that the transmit shift register is out of data. TXC is cleared when new data becomes available, but the TXC interrupt flag must be cleared by software.



**Figure 17.13. I2C Transmit Buffer Operation**


The TXBL flags in the I2Cn\_STATUS and I2Cn\_IF are used to indicate the level of the transmit buffer. TXBIL in I2Cn\_CTRL controls the level at which these flag bits are set. If TXBIL is cleared, the flags are set whenever the transmit buffer becomes empty (used when transmitting using I2Cn\_TXDOUBLE). If TXBIL is set, the flags are set whenever the transmit buffer goes from full to half-empty or empty (used when transmitting with I2Cn\_TXDATA). Both the TXBL status flag and the TXBL interrupt flag are cleared automatically when the condition becomes false.

If an attempt is made to write more bytes to the transmit buffer than the space available, the TXOF interrupt flag in I2Cn\_IF is set, indicating the overflow. The data already in the buffer remains preserved, and no new data is written.

The transmit buffer and the transmit shift register can be cleared by setting command bit CLEARTX in I2Cn\_CMD. This will prevent the I<sup>2</sup>C module from transmitting the data in the buffer and the shift register, and will make them available for new data. Any byte currently being transmitted will not be aborted. Transmission of this byte will be completed.

### 17.3.6.2 Receive Buffer and Shift Register

The I<sup>2</sup>C receiver uses a 2-level FIFO receive buffer and a receive shift register as shown in [Figure 17.14 I2C Receive Buffer Operation on page 565](#). When a byte has been fully received by the receive shift register, it is loaded into the receive buffer if there is room for it, making the shift register empty to receive another byte. Otherwise, the byte waits in the shift register until space becomes available in the buffer.



**Figure 17.14. I2C Receive Buffer Operation**

When a byte becomes available in the receive buffer, the RXDATAV in I2Cn\_STATUS and RXDATAV interrupt flag in I2Cn\_IF are set. When the buffer becomes full, RXFULL in the I2Cn\_STATUS and I2Cn\_IF are set. The status flags RXDATAV and RXFULL are automatically cleared by hardware when their condition is no longer true. This also goes for the RXDATAV interrupt flag, but the RXFULL interrupt flag must be cleared by software. When the RXFULL flag is set, notifying that the buffer is full, space is still available in the receive shift register for one more byte.

The data can be fetched from the buffer in two ways. I2Cn\_RXDATA gives access to the received byte (if two bytes are received then the one received first is fetched first). I2Cn\_RXDOUBLE makes it possible to read the two received bytes simultaneously. If an attempt is made to read more bytes from the buffer than available, the RXUF interrupt flag in I2Cn\_IF is set to signal the underflow, and the data read from the buffer is undefined.

When using I2Cn\_RXDOUBLE to pick data, AUTOACK in I2Cn\_CTRL should be set to 1. This ensures that an ACK is automatically sent out after the first byte is received so that the reception of the next byte can begin. In order to stop receiving data bytes, a NACK must be sent out through the I2Cn\_CMD register.

I2Cn\_RXDATAP and I2Cn\_RXDOUBLEP can be used to read data from the receive buffer without removing it from the buffer. The RXUF interrupt flag in I2Cn\_IF will never be set as a result of reading from I2Cn\_RXDATAP and I2Cn\_RXDOUBLEP, but the data read through I2Cn\_RXDATAP when the receive buffer is empty is still undefined.

Once a transaction is complete (STOP sent or received), the receive buffer needs to be flushed (all received data must be read) before starting a new transaction.

### 17.3.7 Master Operation

A bus transaction is initiated by transmitting a START condition (S) on the bus. This is done by setting the START bit in I2Cn\_CMD. The command schedules a START condition, and makes the I<sup>2</sup>C module generate a start condition whenever the bus becomes free.

The I<sup>2</sup>C-bus is considered busy whenever another device on the bus transmits a START condition. Until a STOP condition is detected, the bus is owned by the master issuing the START condition. The bus is considered free when a STOP condition is transmitted on the bus. After a STOP is detected, all masters that have data to transmit send a START condition and begin transmitting data. Arbitration ensures that collisions are avoided.

When the START condition has been transmitted, the master must transmit a slave address (ADDR) with an R/W bit on the bus. If this address is available in the transmit buffer, the master transmits it immediately, but if the buffer is empty, the master holds the I<sup>2</sup>C-bus while waiting for software to write the address to the transmit buffer.

After the address has been transmitted, a sequence of bytes can be read from or written to the slave, depending on the value of the R/W bit (bit 0 in the address byte). If the bit was cleared, the master has entered a master transmitter role, where it now transmits data to the slave. If the bit was set, it has entered a master receiver role, where it now should receive data from the slave. In either case, an unlimited number of bytes can be transferred in one direction during the transmission.

At the end of the transmission, the master either transmits a repeated START condition (Sr) if it wishes to continue with another transfer, or transmits a STOP condition (P) if it wishes to release the bus. When operating in the master mode, HPERCCLK frequency must be higher than 2 MHz for Standard-mode, 9 MHz for Fast-mode, and 20 MHz for Fast-mode Plus.

### 17.3.7.1 Master State Machine

The master state machine is shown in [Figure 17.15 I2C Master State Machine on page 567](#). A master operation starts in the far left of the state machine, and follows the solid lines through the state machine, ending the operation or continuing with a new operation when arriving at the right side of the state machine.

Branches in the path through the state machine are the results of bus events and choices made by software, either directly or indirectly. The dotted lines show where I<sup>2</sup>C-specific interrupt flags are set along the path and the full-drawn circles show places where interaction may be required by software to let the transmission proceed.




Figure 17.15. I2C Master State Machine

### 17.3.7.2 Interactions

Whenever the I<sup>2</sup>C module is waiting for interaction from software, it holds the bus clock SCL low, freezing all bus activities, and the BUSHOLD interrupt flag in I2Cn\_IF is set. The action(s) required by software depends on the current state of the I<sup>2</sup>C module. This state can be read from the I2Cn\_STATE register.

As an example, [Table 17.3 I2C Master Transmitter on page 570](#) shows the different states the I<sup>2</sup>C goes through when operating as a Master Transmitter, i.e., a master that transmits data to a slave. As seen in the table, when a start condition has been transmitted, a requirement is that there is an address and an R/W bit in the transmit buffer. If the transmit buffer is empty, then the BUSHOLD interrupt flag is set, and the bus is held until data becomes available in the buffer. While waiting for the address, I2Cn\_STATE has a value 0x57, which can be used to identify exactly what the I<sup>2</sup>C module is waiting for.

**Note:** The bus would never stop at state 0x57 if the address was available in the transmit buffer.

The different interactions used by the I<sup>2</sup>C module are listed in [Table 17.2 I2C Interactions in Prioritized Order on page 568](#) in a prioritized order. If the I<sup>2</sup>C module is in such a state that multiple courses of action are possible, then the action chosen is the one that has the highest priority. For example, after sending out a START, if an address is present in the buffer and a STOP is also pending, then the I<sup>2</sup>C will send out the STOP since it has the higher priority.

**Table 17.2. I2C Interactions in Prioritized Order**

Interaction	Priority	Software action	Automatically continues if
STOP*	1	Set the STOP command bit in I2Cn_CMD	PSTOP is set (STOP pending) in I2Cn_STATUS
ABORT	2	Set the ABORT command bit in I2Cn_CMD	Never, the transmission is aborted
CONT*	3	Set the CONT command bit in I2Cn_CMD	PCONT is set in I2Cn_STATUS (CONT pending)
NACK*	4	Set the NACK command bit in I2Cn_CMD	PNACK is set in I2Cn_STATUS (NACK pending)
ACK*	5	Set the ACK command bit in I2Cn_CMD	AUTOACK is set in I2Cn_CTRL or PACK is set in I2Cn_STATUS (ACK pending)
ADDR+W -> TXDATA	6	Write an address to the transmit buffer with the R/W bit set	Address is available in transmit buffer with R/W bit set
ADDR+R -> TXDATA	7	Write an address to the transmit buffer with the R/W bit cleared	Address is available in transmit buffer with R/W bit cleared
START*	8	Set the START command bit in I2Cn_CMD	PSTART is set in I2Cn_STATUS (START pending)
TXDATA/ TXDOUBLE	9	Write data to the transmit buffer	Data is available in transmit buffer
RXDATA/ RXDOUBLE	10	Read data from receive buffer	Space is available in receive buffer
None	11	No interaction is required	

The commands marked with a \* in [Table 17.2 I2C Interactions in Prioritized Order on page 568](#) can be issued before an interaction is required. When such a command is issued before it can be used/consumed by the I<sup>2</sup>C module, the command is set in a pending state, which can be read from the STATUS register. A pending START command can for instance be identified by PSTART having a high value.

Whenever the I<sup>2</sup>C module requires an interaction, it checks the pending commands. If one or a combination of these can fulfill an interaction, they are consumed by the module and the transmission continues without setting the BUSHOLD interrupt flag in I2Cn\_IF to get an interaction from software. The pending status of a command goes low when it is consumed.

When several interactions are possible from a set of pending commands, the interaction with the highest priority, i.e., the interaction closest to the top of [Table 17.2 I2C Interactions in Prioritized Order on page 568](#) is applied to the bus.

Pending commands can be cleared by setting the CLEARPC command bit in I2Cn\_CMD.

#### 17.3.7.3 Automatic ACK Interaction

When receiving addresses and data, an ACK command in I2Cn\_CMD is normally required after each received byte. When AUTOACK is set in I2Cn\_CTRL, an ACK is always pending, and the ACK-pending bit PACK in I2Cn\_STATUS is thus always set, even after an ACK has been consumed. This is used when data is picked using I2Cn\_RXDOUBLE and can also be used with I2Cn\_RXDATA in order to reduce the amount of software interaction required during a transfer.

#### 17.3.7.4 Reset State

After a reset, the state of the I<sup>2</sup>C-bus is unknown. To avoid interrupting transfers on the I<sup>2</sup>C-bus after a reset of the I<sup>2</sup>C module or the entire MCU, the I<sup>2</sup>C-bus is assumed to be busy when coming out of a reset, and the BUSY flag in I2Cn\_STATUS is thus set. To be able to carry through master operations on the I<sup>2</sup>C-bus, the bus must be idle.

The bus goes idle when a STOP condition is detected on the bus, but on buses with little activity, the time before the I<sup>2</sup>C module detects that the bus is idle can be significant. There are two ways of assuring that the I<sup>2</sup>C module gets out of the busy state.

- Use the ABORT command in I2Cn\_CMD. When the ABORT command is issued, the I<sup>2</sup>C module is instructed that the bus is idle. The I<sup>2</sup>C module can then initiate master operations.
- Use the Bus Idle Timeout. When SCL has been high for a long period of time, it is very likely that the bus is idle. Set BITO in I2Cn\_CTRL to an appropriate timeout period and set GIBITO in I2Cn\_CTRL. If activity has not been detected on the bus within the timeout period, the bus is then automatically assumed idle, and master operations can be initiated.

**Note:** If operating in slave mode, the above approach is not necessary.

### 17.3.7.5 Master Transmitter

To transmit data to a slave, the master must operate as a master transmitter. [Table 17.3 I2C Master Transmitter on page 570](#) shows the states the I<sup>2</sup>C module goes through while acting as a master transmitter. Every state where an interaction is required has the possible interactions listed, along with the result of the interactions. The table also shows which interrupt flags are set in the different states. The interrupt flags enclosed in parenthesis may be set. If the BUSHOLD interrupt in I2Cn\_IF is set, the module is waiting for an interaction, and the bus is frozen. The value of I2Cn\_STATE will be equal to the values given in the table when the BUSHOLD interrupt flag is set, and can be used to determine which interaction is required to make the transmission continue.

The interrupt flag START in I2Cn\_IF is set when the I<sup>2</sup>C module transmits the START.

A master operation is started by issuing a START command by setting START in I2Cn\_CMD. ADDR+W, i.e., the address of the slave + the R/W bit is then required by the I<sup>2</sup>C module. If this is not available in the transmit buffer, then the bus is held and the BUSHOLD interrupt flag is set. The value of I2Cn\_STATE will then be 0x57. As seen in the table, the I<sup>2</sup>C module also stops in this state if the address is not available after a repeated start condition.

To continue, write a byte to I2Cn\_TXDATA with the address of the slave in the 7 most significant bits and the least significant bit cleared (ADDR+W). This address will then be transmitted, and the slave will reply with an ACK or a NACK. If no slave replies to the address, the response will also be NACK. If the address was acknowledged, the master now has four choices. It can send data by placing it in I2Cn\_TXDATA/ I2Cn\_TXDOUBLE (the master should check the TXBL interrupt flag before writing to the transmit buffer), this data is then transmitted. The master can also stop the transmission by sending a STOP, it can send a repeated start by sending START, or it can send a STOP and then a START as soon as possible. If the master wishes to make another transfer immediately after the current, the preferred way is to start a new transfer directly by transmitting a repeated START instead of a STOP followed by a START. This is so because if a STOP is sent out, then any master wishing to initiate a transfer on the bus can try to gain control of it.

If a NACK was received, the master has to issue a CONT command in addition to providing data in order to continue transmission. This is not standard I<sup>2</sup>C, but is provided for flexibility. The rest of the options are similar to when an ACK was received.

If a new byte was transmitted, an ACK or NACK is received after the transmission of the byte, and the master has the same options as for when the address was sent.

The master may lose arbitration at any time during transmission. In this case, the ARBLOST interrupt flag in I2Cn\_IF is set. If the arbitration was lost during the transfer of an address, and SLAVE in I2Cn\_CTRL is set, the master then checks which address was transmitted. If it was the address of the master, then the master goes to slave mode.

After a master has transmitted a START and won any arbitration, it owns the bus until it transmits a STOP. After a STOP, the bus is released, and arbitration decides which bus master gains the bus next. The MSTOP interrupt flag in I2Cn\_IF is set when a STOP condition is transmitted by the master.

**Table 17.3. I2C Master Transmitter**

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
0x57	Start transmitted	START interrupt flag (BUSHOLD interrupt flag)	ADDR+W -> TXDATA	ADDR+W will be sent
			STOP	STOP will be sent and bus released.
			STOP + START	STOP will be sent and bus released. Then a START will be sent when bus becomes idle.
0x57	Repeated start transmitted	START interrupt flag (BUSHOLD interrupt flag)	ADDR+W -> TXDATA	ADDR+W will be sent
			STOP	STOP will be sent and bus released.
			STOP + START	STOP will be sent and bus released. Then a START will be sent when bus becomes idle.
-	ADDR+W transmitted	TXBL interrupt flag (TXC interrupt flag)	None	

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
0x97	ADDR+W transmitted, ACK received	ACK interrupt flag (BUSHOLD interrupt flag)	TXDATA	DATA will be sent
			STOP	STOP will be sent. Bus will be released
			START	Repeated start condition will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle
0x9F	ADDR+W transmitted, NACK received	NACK (BUSHOLD interrupt flag)	CONT + TXDATA	DATA will be sent
			STOP	STOP will be sent. Bus will be released
			START	Repeated start condition will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle
-	Data transmitted	TXBL interrupt flag (TXC interrupt flag)	None	
0xD7	Data transmitted, ACK received	ACK interrupt flag (BUSHOLD interrupt flag)	TXDATA	DATA will be sent
			STOP	STOP will be sent. Bus will be released
			START	Repeated start condition will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle
0xDF	Data transmitted, NACK received	NACK(BUSHOLD interrupt flag)	CONT + TXDATA	DATA will be sent
			STOP	STOP will be sent. Bus will be released
			START	Repeated start condition will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle
-	Stop transmitted	MSTOP interrupt flag	None	
-	Arbitration lost	ARBLOST interrupt flag	START	START will be sent when bus becomes idle

### 17.3.7.6 Master Receiver

To receive data from a slave, the master must operate as a master receiver, see [Table 17.4 I2C Master Receiver on page 572](#). This is done by transmitting ADDR+R as the address byte instead of ADDR+W, which is transmitted to become a master transmitter. The address byte loaded into the data register thus has to contain the 7-bit slave address in the 7 most significant bits of the byte, and have the least significant bit set.

When the address has been transmitted, the master receives an ACK or a NACK. If an ACK is received, the ACK interrupt flag in I2Cn\_IF is set, and if space is available in the receive shift register, reception of a byte from the slave begins. If the receive buffer and shift register is full however, the bus is held until data is read from the receive buffer or another interaction is made. Note that the STOP and START interactions have a higher priority than the data-available interaction, so if a STOP or START command is pending, the highest priority interaction will be performed, and data will not be received from the slave.

If a NACK was received, the CONT command in I2Cn\_CMD has to be issued in order to continue receiving data, even if there is space available in the receive buffer and/or shift register.

After a data byte has been received the master must ACK or NACK the received byte. If an ACK is pending or AUTOACK in I2Cn\_CTRL is set, an ACK is sent automatically and reception continues if space is available in the receive buffer.

If a NACK is sent, the CONT command must be used in order to continue transmission. If an ACK or NACK is issued along with a START or STOP or both, then the ACK/NACK is transmitted and the reception is ended. If START in I2Cn\_CMD is set alone, a repeated start condition is transmitted after the ACK/NACK. If STOP in I2Cn\_CMD is set, a stop condition is sent regardless of whether START is set. If START is set in this case, it is set as pending.

As when operating as a master transmitter, arbitration can be lost as a master receiver. When this happens the ARBLOST interrupt flag in I2Cn\_IF is set, and the master has a possibility of being selected as a slave given the correct conditions.

**Table 17.4. I2C Master Receiver**

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
0x57	START transmitted	START interrupt flag (BUSHOLD interrupt flag)	ADDR+R -> TXDATA	ADDR+R will be sent
			STOP	STOP will be sent and bus released.
			STOP + START	STOP will be sent and bus released. Then a START will be sent when bus becomes idle.
0x57	Repeated START transmitted	START interrupt flag(BUSHOLD interrupt flag)	ADDR+R -> TXDATA	ADDR+R will be sent
			STOP	STOP will be sent and bus released.
			STOP + START	STOP will be sent and bus released. Then a START will be sent when bus becomes idle.
-	ADDR+R transmitted	TXBL interrupt flag (TXC interrupt flag)	None	
0x93	ADDR+R transmitted, ACK received	ACK interrupt flag(BUS-HOLD)	RXDATA	Start receiving
			STOP	STOP will be sent and the bus released
			START	Repeated START will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle
0x9B	ADDR+R transmitted,NACK received	NACK(BUSHOLD)	CONT + RXDATA	Continue, start receiving
			STOP	STOP will be sent and the bus released
			START	Repeated START will be sent
			STOP + START	STOP will be sent and the bus released. Then a START will be sent when the bus becomes idle

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
0xB3	Data received	RXDATA interrupt flag(BUSHOLD interrupt flag)	ACK + RXDATA	ACK will be transmitted, reception continues
			NACK + CONT + RXDATA	NACK will be transmitted, reception continues
			ACK/NACK + STOP	ACK/NACK will be sent and the bus will be released.
			ACK/NACK + START	ACK/NACK will be sent, and then a repeated start condition.
			ACK/NACK + STOP + START	ACK/NACK will be sent and the bus will be released. Then a START will be sent when the bus becomes idle
-	Stop received	MSTOP interrupt flag	None	
-	Arbitration lost	ARBLOST interrupt flag	START	START will be sent when bus becomes idle
-			None	
-			START	START will be sent when bus becomes idle

### 17.3.8 Bus States

The I2Cn\_STATE register can be used to determine which state the I<sup>2</sup>C module and the I<sup>2</sup>C bus are in at a given time. The register consists of the STATE bit-field, which shows which state the I<sup>2</sup>C module is at in any ongoing transmission, and a set of single-bits, which reveal the transmission mode, whether the bus is busy or idle, and whether the bus is held by this I<sup>2</sup>C module waiting for a software response.

The possible values of the STATE field are summarized in [Table 17.5 I2C STATE Values on page 574](#). When this field is cleared, the I<sup>2</sup>C module is not a part of any ongoing transmission. The remaining status bits in the I2Cn\_STATUS register are listed in [Table 17.6 I2C Transmission Status on page 574](#).

**Table 17.5. I2C STATE Values**

Mode	Value	Description
IDLE	0	No transmission is being performed by this module.
WAIT	1	Waiting for idle. Will send a start condition as soon as the bus is idle.
START	2	Start being transmitted
ADDR	3	Address being transmitted or has been received
ADDRACK	4	Address ACK/NACK being transmitted or received
DATA	5	Data being transmitted or received
DATAACK	6	Data ACK/NACK being transmitted or received

**Table 17.6. I2C Transmission Status**

Bit	Description
BUSY	Set whenever there is activity on the bus. Whether or not this module is responsible for the activity cannot be determined by this byte.
MASTER	Set when operating as a master. Cleared at all other times.
TRANSMITTER	Set when operating as a transmitter; either a master transmitter or a slave transmitter. Cleared at all other times
BUSHOLD	Set when the bus is held by this I <sup>2</sup> C module because an action is required by software.
NACK	Only valid when bus is held and STATE is ADDRACK or DATAACK. In that case it is set if a NACK was received. In all other cases, the bit is cleared.


**Note:** I2Cn\_STATE reflects the internal state of the I<sup>2</sup>C module, and therefore only held constant as long as the bus is held, i.e., as long as BUSHOLD in I2Cn\_STATUS is set.

### 17.3.9 Slave Operation

The I<sup>2</sup>C module operates in master mode by default. To enable slave operation, i.e., to allow the device to be addressed as an I<sup>2</sup>C slave, the SLAVE bit in I2Cn\_CTRL must be set. In this case the I<sup>2</sup>C module operates in a mixed mode, both capable of starting transmissions as a master, and being addressed as a slave. When operating in the slave mode, HFPERCCLK frequency must be higher than 2 MHz for Standard-mode, 5 MHz for Fast-mode, and 14 MHz for Fast-mode Plus.

### 17.3.9.1 Slave State Machine

The slave state machine is shown in [Figure 17.16 I2C Slave State Machine on page 575](#). The dotted lines show where I<sup>2</sup>C-specific interrupt flags are set. The full-drawn circles show places where interaction may be required by software to let the transmission proceed.



**Figure 17.16. I2C Slave State Machine**

### 17.3.9.2 Address Recognition

The I<sup>2</sup>C module provides automatic address recognition for 7-bit addresses. 10-bit address recognition is not fully automatic, but can be assisted by the 7-bit address comparator as shown in [17.3.11 Using 10-bit Addresses](#). Address recognition is supported in all energy modes (except EM4).

The slave address, i.e., the address which the I<sup>2</sup>C module should be addressed with, is defined in the I2Cn\_SADDR register. In addition to the address, a mask must be specified, telling the address comparator which bits of an incoming address to compare with the address defined in I2Cn\_SADDR. The mask is defined in I2Cn\_SADDRMASK, and for every zero in the mask, the corresponding bit in the slave address is treated as a don't-care, i.e., the 0-masked bits are ignored.

An incoming address that fails address recognition is automatically replied to with a NACK. Since only the bits defined by the mask are checked, a mask with a value 0x00 will result in all addresses being accepted. A mask with a value 0x7F will only match the exact address defined in I2Cn\_SADDR, while a mask 0x70 will match all addresses where the three most significant bits in I2Cn\_SADDR and the incoming address are equal.

If GCAMEN in I2Cn\_CTRL is not set, the start-byte, i.e., the general call address with the R/W bit set is ignored unless it is included in the defined slave address and the address mask.

When an address is accepted by the address comparator, the decision of whether to ACK or NACK the address is passed to software.

### 17.3.9.3 Slave Transmitter

When SLAVE in I2Cn\_CTRL is set, the RSTART interrupt flag in I2Cn\_IF will be set when repeated START conditions are detected. After a START or repeated START condition, the bus master will transmit an address along with an R/W bit. If there is no room in the receive shift register for the address, the bus will be held by the slave until room is available in the shift register. Transmission then continues and the address is loaded into the shift register. If this address does not pass address recognition, it is automatically NACK'ed by the slave, and the slave goes to an idle state. The address byte is in this case discarded, making the shift register ready for a new address. It is not loaded into the receive buffer.

If the address was accepted and the R/W bit was set (R), indicating that the master wishes to read from the slave, the slave now goes into the slave transmitter mode. Software interaction is now required to decide whether the slave wants to acknowledge the request or not. The accepted address byte is loaded into the receive buffer like a regular data byte. If no valid interaction is pending, the bus is held until the slave responds with a command. The slave can reject the request with a single NACK command.

The slave will in that case go to an idle state, and wait for the next start condition. To continue the transmission, the slave must make sure data is loaded into the transmit buffer and send an ACK. The loaded data will then be transmitted to the master, and an ACK or NACK will be received from the master.

Data transmission can also continue after a NACK if a CONT command is issued along with the NACK. This is not standard I<sup>2</sup>C however.

If the master responds with an ACK, it may expect another byte of data, and data should be made available in the transmit buffer. If data is not available, the bus is held until data is available.

If the response is a NACK however, this is an indication of that the master has received enough bytes and wishes to end the transmission. The slave now automatically goes idle, unless CONT in I2Cn\_CMD is set and data is available for transmission. The latter is not standard I<sup>2</sup>C.

The master ends the transmission by sending a STOP or a repeated START. The SSTOP interrupt flag in I2Cn\_IF is set when the master transmits a STOP condition. If the transmission is ended with a repeated START, then the SSTOP interrupt flag is not set.

**Note:** The SSTOP interrupt flag in I2Cn\_IF will be set regardless of whether the slave is participating in the transmission or not, as long as SLAVE in I2Cn\_CTRL is set and a STOP condition is detected.

If arbitration is lost at any time during transmission, the ARBLOST interrupt flag in I2Cn\_IF is set, the bus is released and the slave goes idle.

See [Table 17.7 I2C Slave Transmitter](#) on page 576 for more information.

**Table 17.7. I2C Slave Transmitter**

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
0x41	Repeated START received	RSTART interrupt flag (BUSHOLD interrupt flag)	RXDATA	Receive and compare address
0x75	ADDR + R received	ADDR interrupt flag	ACK + TXDATA	ACK will be sent, then DATA
		RXDATA interrupt flag	NACK	NACK will be sent, slave goes idle
		(BUSHOLD interrupt flag)	NACK + CONT + TXDATA	NACK will be sent, then DATA.
-	Data transmitted	TXBL interrupt flag (TXC interrupt flag)	None	
0xD5	Data transmitted, ACK received	ACK interrupt flag (BUSHOLD interrupt flag)	TXDATA	DATA will be transmitted
0xDD	Data transmitted, NACK received	NACK interrupt flag	None	The slave goes idle
		(BUSHOLD interrupt flag)	CONT + TXDATA	DATA will be transmitted

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
-	Stop received	SSTOP interrupt flag	None	The slave goes idle
			START	START will be sent when bus becomes idle
-	Arbitration lost	ARBLOST interrupt flag	None	The slave goes idle
			START	START will be sent when the bus becomes idle

#### 17.3.9.4 Slave Receiver

A slave receiver operation is started in the same way as a slave transmitter operation, with the exception that the address transmitted by the master has the R/W bit cleared (W), indicating that the master wishes to write to the slave. The slave then goes into slave receiver mode.

To receive data from the master, the slave should respond to the address with an ACK and make sure space is available in the receive buffer. Transmission will then continue, and the slave will receive a byte from the master.

If a NACK is sent without a CONT, the transmission is ended for the slave, and it goes idle. If the slave issues both the NACK and CONT commands and has space available in the receive buffer, it will be open for continuing reception from the master.

When a byte has been received from the master, the slave must ACK or NACK the byte. The responses here are the same as for the reception of the address byte.

The master ends the transmission by sending a STOP or a repeated START. The SSTOP interrupt flag is set when the master transmits a STOP condition. If the transmission is ended with a repeated START, then the SSTOP interrupt flag in I2Cn\_IF is not set.

**Note:** The SSTOP interrupt flag in I2Cn\_IF will be set regardless of whether the slave is participating in the transmission or not, as long as SLAVE in I2Cn\_CTRL is set and a STOP condition is detected

If arbitration is lost at any time during transmission, the ARBLOST interrupt flag in I2Cn\_IF is set, the bus is released and the slave goes idle.

See [Table 17.8 I2C - Slave Receiver](#) on page 578 for more information.

**Table 17.8. I2C - Slave Receiver**

I2Cn_STATE	Description	I2Cn_IF	Required interaction	Response
-	Repeated START received	RSTART interrupt flag (BUSHOLD interrupt flag)	RXDATA	Receive and compare address
0x71	ADDR + W received	ADDR interrupt flag RXDATA interrupt flag (BUSHOLD interrupt flag)	ACK + RXDATA	ACK will be sent and data will be received
			NACK	NACK will be sent, slave goes idle
			NACK + CONT + RXDATA	NACK will be sent and DATA will be received.
0xB1	Data received	RXDATA interrupt flag (BUSHOLD interrupt flag)	ACK + RXDATA	ACK will be sent and data will be received
			NACK	NACK will be sent and slave will go idle
			NACK + CONT + RXDATA	NACK will be sent and data will be received
-	Stop received	SSTOP interrupt flag	None	The slave goes idle
			START	START will be sent when bus becomes idle
-	Arbitration lost	ARBLOST interrupt flag	None	The slave goes idle
			START	START will be sent when the bus becomes idle

#### 17.3.10 Transfer Automation

The I<sup>2</sup>C can be set up to complete transfers with a minimal amount of interaction.

### 17.3.10.1 DMA

DMA can be used to automatically load data into the transmit buffer and load data out from the receive buffer. When using DMA, software is thus relieved of moving data to and from memory after each transferred byte.

### 17.3.10.2 Automatic ACK

When AUTOACK in I2Cn\_CTRL is set, an ACK is sent automatically whenever an ACK interaction is possible and no higher priority interactions are pending.

### 17.3.10.3 Automatic STOP

A STOP can be generated automatically on two conditions. These apply only to the master transmitter.

If AUTOSN in I2Cn\_CTRL is set, the I<sup>2</sup>C module ends a transmission by transmitting a STOP condition when operating as a master transmitter and a NACK is received.

If AUTOSE in I2Cn\_CTRL is set, the I<sup>2</sup>C module always ends a transmission when there is no more data in the transmit buffer. If data has been transmitted on the bus, the transmission is ended after the (N)ACK has been received by the slave. If a START is sent when no data is available in the transmit buffer and AUTOSE is set, then the STOP condition is sent immediately following the START. Software must thus make sure data is available in the transmit buffer before the START condition has been fully transmitted if data is to be transferred.

### 17.3.11 Using 10-bit Addresses

When using 10-bit addresses in slave mode, set the I2Cn\_SADDR register to 1111 0XX where XX are the two most significant bits of the 10-bit address, and set I2Cn\_SADDRMASK to 0xFF. Address matches will now be given on all 10-bit addresses where the two most significant bits are correct.

When receiving an address match, the slave must acknowledge the address and receive the first data byte. This byte contains the second part of the 10-bit address. If it matches the address of the slave, the slave should ACK the byte to continue the transmission, and if it does not match, the slave should NACK it.

When the master is operating as a master transmitter, the data bytes will follow after the second address byte. When the master is operating as a master receiver however, a repeated START condition is sent after the second address byte. The address sent after this repeated START is equal to the first of the address bytes transmitted previously, but now with the R/W byte set, and only the slave that found a match on the entire 10-bit address in the previous message should ACK this address. The repeated start should take the master into a master receiver mode, and after the single address byte sent this time around, the slave begins transmission to the master.

### 17.3.12 Error Handling

**Note:** The setting of GCAMEN and SLAVE fields in the I2Cn\_CTRL register and the registers I2Cn\_SADDR and I2Cn\_ROUTELOC0 are considered static. This means that these need to be set before an I<sup>2</sup>C transaction starts and need to stay stable during the entire transaction.

#### 17.3.12.1 ABORT Command

Some bus errors may require software intervention to be resolved. The I<sup>2</sup>C module provides an ABORT command, which can be set in I2Cn\_CMD, to help resolve bus errors.

When the bus for some reason is locked up and the I<sup>2</sup>C module is in the middle of a transmission it cannot get out of, or for some other reason the I<sup>2</sup>C wants to abort a transmission, the ABORT command can be used.

Setting the ABORT command will make the I<sup>2</sup>C module discard any data currently being transmitted or received, release the SDA and SCL lines and go to an idle mode. ABORT effectively makes the I<sup>2</sup>C module forget about any ongoing transfers.

#### 17.3.12.2 Bus Reset

A bus reset can be performed by setting the START and STOP commands in I2Cn\_CMD while the transmit buffer is empty. A START condition will then be transmitted, immediately followed by a STOP condition. A bus reset can also be performed by transmitting a START command with the transmit buffer empty and AUTOSE set.

### 17.3.12.3 I<sup>2</sup>C-Bus Errors

An I<sup>2</sup>C-bus error occurs when a START or STOP condition is misplaced, which happens when the value on SDA changes while SCL is high during bit-transmission on the I<sup>2</sup>C-bus. If the I<sup>2</sup>C module is part of the current transmission when a bus error occurs, any data currently being transmitted or received is discarded, SDA and SCL are released, the BUSERR interrupt flag in I2Cn\_IF is set to indicate the error, and the module automatically takes a course of action as defined in [Table 17.9 I<sup>2</sup>C Bus Error Response on page 580](#).

**Table 17.9. I<sup>2</sup>C Bus Error Response**

	<b>Misplaced START</b>	<b>Misplaced STOP</b>
In a master/slave operation	Treated as START. Receive address.	Go idle. Perform any pending actions.

### 17.3.12.4 Bus Lockup

A lockup occurs when a master or slave on the I<sup>2</sup>C-bus has locked the SDA or SCL at a low value, preventing other devices from putting high values on the bus, and thus making communication on the bus impossible.

Many slave-only devices operating on an I<sup>2</sup>C-bus are not capable of driving SCL low, but in the rare case that SCL is stuck LOW, the advice is to apply a hardware reset signal to the slaves on the bus. If this does not work, cycle the power to the devices in order to make them release SCL.

When SDA is stuck low and SCL is free, a master should send 9 clock pulses on SCL while tristating the SDA. This procedure is performed in the GPIO module after clearing the I2C\_ROUTE register and disabling the I<sup>2</sup>C module. The device that held the bus low should release it sometime within those 9 clocks. If not, use the same approach as for when SCL is stuck, resetting and possibly cycling power to the slaves.

Lockup of SDA can be detected by keeping count of the number of continuous arbitration losses during address transmission. If arbitration is also lost during the transmission of a general call address, i.e., during the transmission of the STOP condition, which should never happen during normal operation, this is a good indication of SDA lockup.

Detection of SCL lockups can be done using the timeout functionality defined in [17.3.12.6 Clock Low Timeout](#)

### 17.3.12.5 Bus Idle Timeout

When SCL has been high for a significant amount of time, this is a good indication of that the bus is idle. On an SMBus system, the bus is only allowed to be in this state for a maximum of 50 µs before the bus is considered idle.

The bus idle timeout BITO in I2Cn\_CTRL can be used to detect situations where the bus goes idle in the middle of a transmission. The timeout can be configured in BITO, and when the bus has been idle for the given amount of time, the BITO interrupt flag in I2Cn\_IF is set. The bus can also be set idle automatically on a bus idle timeout. This is enabled by setting GIBITO in I2Cn\_CTRL.

When the bus idle timer times out, it wraps around and continues counting as long as its condition is true. If the bus is not set idle using GIBITO or the ABORT command in I2Cn\_CMD, this will result in periodic timeouts.

**Note:** This timeout will be generated even if SDA is held low.

The bus idle timeout is active as long as the bus is busy, i.e., BUSY in I2Cn\_STATUS is set. The timeout can be used to get the I<sup>2</sup>C module out of the busy-state it enters when reset, see [17.3.7.4 Reset State](#).

### 17.3.12.6 Clock Low Timeout

The clock timeout, which can be configured in CLTO in I2Cn\_CTRL, starts counting whenever SCL goes low, and times out if SCL does not go high within the configured timeout. A clock low timeout results in CLTOIF in I2Cn\_IF being set, allowing software to take action.

When the timer times out, it wraps around and continues counting as long as SCL is low. An SCL lockup will thus result in periodic clock low timeouts as long as SCL is low.

### 17.3.12.7 Clock Low Error

The I<sup>2</sup>C module can continue transmission in parallel with another device for the entire transaction, as long as the two communications are identical. A case may arise when (before an arbitration has been decided upon) the I<sup>2</sup>C module decides to send out a repeated START or a STOP condition while the other device is still sending data. In the I<sup>2</sup>C protocol specifications, such a combination results in an undefined condition. The I<sup>2</sup>C deals with this by generating a clock low error. This means that if the I<sup>2</sup>C is transmitting a repeated START or a STOP condition and another device (another master or a misbehaving slave) pulls SCL low before the I<sup>2</sup>C sends out the START/STOP condition on SDA, a clock low error is generated. The CLERR interrupt flag is then set in the I2Cn\_IF register, any held lines are released and the I<sup>2</sup>C device goes to idle.

### 17.3.13 DMA Support

The I<sup>2</sup>C module has full DMA support. A request for the DMA controller to write to the I<sup>2</sup>C transmit buffer can come from TXBL (transmit buffer has room for more data). The DMA controller can write to the transmit buffer using the I2Cn\_TXDATA or the I2Cn\_TXDOUBLE register. In order to write to the I2Cn\_TXDOUBLE register (i.e., transferring 2 bytes simultaneously to the transmit buffer using the DMA), DMA\_USEBURSTS needs to be set to 1 for the selected DMA channel. This ensures that the transfer is made to the transmit buffer only when both buffer elements are empty. For performing a DMA write to the I2Cn\_TXDATA register, DMA\_USEBURSTC needs to be set to 1 for the selected DMA channel. This ensures that a DMA transfer is made even when the transmit buffer is half-empty.

A request for the DMA controller to read from the I<sup>2</sup>C receive buffer can come from RXDATAV (data available in the receive buffer). To receive from I2Cn\_RXDOUBLE (i.e., receive only when both buffer elements are full), DMA\_USEBURSTS needs to be set to 1 for the selected DMA channel. In order to receive from I2Cn\_RXDATA through the DMA, DMA\_USEBURSTC needs to be set to 1. This ensures that the data gets picked up even when the receive buffer is half-full.

### 17.3.14 Interrupts

The interrupts generated by the I<sup>2</sup>C module are combined into one interrupt vector, I2C\_INT. If I<sup>2</sup>C interrupts are enabled, an interrupt will be made if one or more of the interrupt flags in I2Cn\_IF and their corresponding bits in I2Cn\_IEN are set.

### 17.3.15 Wake-up

The I<sup>2</sup>C receive section can be active all the way down to energy mode EM3 Stop, and can wake up the CPU on address interrupt. All address match modes are supported.

## 17.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	I2Cn_CTRL	RW	Control Register
0x004	I2Cn_CMD	W1	Command Register
0x008	I2Cn_STATE	R	State Register
0x00C	I2Cn_STATUS	R	Status Register
0x010	I2Cn_CLKDIV	RW	Clock Division Register
0x014	I2Cn_SADDR	RW	Slave Address Register
0x018	I2Cn_SADDRMASK	RW	Slave Address Mask Register
0x01C	I2Cn_RXDATA	R(a)	Receive Buffer Data Register
0x020	I2Cn_RXDOUBLE	R(a)	Receive Buffer Double Data Register
0x024	I2Cn_RXDATAP	R	Receive Buffer Data Peek Register
0x028	I2Cn_RXDOUBLEP	R	Receive Buffer Double Data Peek Register
0x02C	I2Cn_TXDATA	W	Transmit Buffer Data Register
0x030	I2Cn_TXDOUBLE	W	Transmit Buffer Double Data Register
0x034	I2Cn_IF	R	Interrupt Flag Register
0x038	I2Cn_IFS	W1	Interrupt Flag Set Register
0x03C	I2Cn_IFC	(R)W1	Interrupt Flag Clear Register
0x040	I2Cn_IEN	RW	Interrupt Enable Register
0x044	I2Cn_ROUTEPEN	RW	I/O Routing Pin Enable Register
0x048	I2Cn_ROUTELOC0	RW	I/O Routing Location Register

## 17.5 Register Description

### 17.5.1 I2Cn\_CTRL - Control Register

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

18:16 CLTO 0x0 RW **Clock Low Timeout**

$$\text{timeout} = \text{PCC}/(\text{f}_{\text{SCL}} \times (\text{N}_{\text{low}} + \text{N}_{\text{high}}))$$

Value	Mode	Description
0	OFF	Timeout disabled
1	40PCC	Timeout after 40 prescaled clock cycles. In standard mode at 100 kHz, this results in a 50us timeout.
2	80PCC	Timeout after 80 prescaled clock cycles. In standard mode at 100 kHz, this results in a 100us timeout.
3	160PCC	Timeout after 160 prescaled clock cycles. In standard mode at 100 kHz, this results in a 200us timeout.
4	320PCC	Timeout after 320 prescaled clock cycles. In standard mode at 100 kHz, this results in a 400us timeout.
5	1024PCC	Timeout after 1024 prescaled clock cycles. In standard mode at 100 kHz, this results in a 1280us timeout.

15 GIBITO 0 RW Go Idle on Bus Idle Timeout

When set, the bus automatically goes idle on a bus idle timeout, allowing new transfers to be initiated.

Value	Description
0	A bus idle timeout has no effect on the bus state.
1	A bus idle timeout tells the I <sup>2</sup> C module that the bus is idle, allowing new

**14 Reserved** To ensure compatibility with future devices, always write bits to 0. More information in [1.2 Conventions](#).

Bit	Name	Reset	Access	Description															
13:12	BITO	0x0	RW	<b>Bus Idle Timeout</b>															
Use to generate a timeout when SCL has been high for a given amount time between a START and STOP condition. When in a bus transaction, i.e. the BUSY flag is set, a timer is started whenever SCL goes high. When the timer reaches the value defined by BITO, it sets the BITO interrupt flag. The BITO interrupt flag will then be set periodically as long as SCL remains high. The bus idle timeout is active as long as BUSY is set. It is thus stopped automatically on a timeout if GIBITO is set. It is also stopped a STOP condition is detected and when the ABORT command is issued. The timeout is activated whenever the bus goes BUSY, i.e. a START condition is detected. The timeout value can be calculated by																			
timeout = PCC/(f <sub>SCL</sub> × (N <sub>low</sub> + N <sub>high</sub> ))																			
<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>OFF</td><td>Timeout disabled</td></tr> <tr> <td>1</td><td>40PCC</td><td>Timeout after 40 prescaled clock cycles. In standard mode at 100 kHz, this results in a 50us timeout.</td></tr> <tr> <td>2</td><td>80PCC</td><td>Timeout after 80 prescaled clock cycles. In standard mode at 100 kHz, this results in a 100us timeout.</td></tr> <tr> <td>3</td><td>160PCC</td><td>Timeout after 160 prescaled clock cycles. In standard mode at 100 kHz, this results in a 200us timeout.</td></tr> </tbody> </table>					Value	Mode	Description	0	OFF	Timeout disabled	1	40PCC	Timeout after 40 prescaled clock cycles. In standard mode at 100 kHz, this results in a 50us timeout.	2	80PCC	Timeout after 80 prescaled clock cycles. In standard mode at 100 kHz, this results in a 100us timeout.	3	160PCC	Timeout after 160 prescaled clock cycles. In standard mode at 100 kHz, this results in a 200us timeout.
Value	Mode	Description																	
0	OFF	Timeout disabled																	
1	40PCC	Timeout after 40 prescaled clock cycles. In standard mode at 100 kHz, this results in a 50us timeout.																	
2	80PCC	Timeout after 80 prescaled clock cycles. In standard mode at 100 kHz, this results in a 100us timeout.																	
3	160PCC	Timeout after 160 prescaled clock cycles. In standard mode at 100 kHz, this results in a 200us timeout.																	
11:10	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																	
9:8	CLHR	0x0	RW	<b>Clock Low High Ratio</b>															
Determines the ratio between the low and high parts of the clock signal generated on SCL as master.																			
<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>STANDARD</td><td>The ratio between low period and high period counters (N<sub>low</sub>:N<sub>high</sub>) is 4:4</td></tr> <tr> <td>1</td><td>ASYMMETRIC</td><td>The ratio between low period and high period counters (N<sub>low</sub>:N<sub>high</sub>) is 6:3</td></tr> <tr> <td>2</td><td>FAST</td><td>The ratio between low period and high period counters (N<sub>low</sub>:N<sub>high</sub>) is 11:6</td></tr> </tbody> </table>					Value	Mode	Description	0	STANDARD	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 4:4	1	ASYMMETRIC	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 6:3	2	FAST	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 11:6			
Value	Mode	Description																	
0	STANDARD	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 4:4																	
1	ASYMMETRIC	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 6:3																	
2	FAST	The ratio between low period and high period counters (N <sub>low</sub> :N <sub>high</sub> ) is 11:6																	
7	TXBIL	0	RW	<b>TX Buffer Interrupt Level</b>															
Determines the interrupt and status level of the transmit buffer.																			
<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>EMPTY</td><td>TXBL status and the TXBL interrupt flag are set when the transmit buffer becomes empty. TXBL is cleared when the buffer becomes non-empty.</td></tr> <tr> <td>1</td><td>HALFFULL</td><td>TXBL status and the TXBL interrupt flag are set when the transmit buffer goes from full to half-full or empty. TXBL is cleared when the buffer becomes full.</td></tr> </tbody> </table>					Value	Mode	Description	0	EMPTY	TXBL status and the TXBL interrupt flag are set when the transmit buffer becomes empty. TXBL is cleared when the buffer becomes non-empty.	1	HALFFULL	TXBL status and the TXBL interrupt flag are set when the transmit buffer goes from full to half-full or empty. TXBL is cleared when the buffer becomes full.						
Value	Mode	Description																	
0	EMPTY	TXBL status and the TXBL interrupt flag are set when the transmit buffer becomes empty. TXBL is cleared when the buffer becomes non-empty.																	
1	HALFFULL	TXBL status and the TXBL interrupt flag are set when the transmit buffer goes from full to half-full or empty. TXBL is cleared when the buffer becomes full.																	
6	GCAMEN	0	RW	<b>General Call Address Match Enable</b>															
Set to enable address match on general call in addition to the programmed slave address.																			
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>General call address will be NACK'ed if it is not included by the slave address and address mask.</td></tr> </tbody> </table>					Value	Description	0	General call address will be NACK'ed if it is not included by the slave address and address mask.											
Value	Description																		
0	General call address will be NACK'ed if it is not included by the slave address and address mask.																		

Bit	Name	Reset	Access	Description						
1				When a general call address is received, a software response is required.						
5	ARBDIS	0	RW	<b>Arbitration Disable</b>						
				A master or slave will not release the bus upon losing arbitration.						
				<table> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>When a device loses arbitration, the ARB interrupt flag is set and the bus is released.</td></tr> <tr> <td>1</td><td>When a device loses arbitration, the ARB interrupt flag is set, but communication proceeds.</td></tr> </tbody> </table>	Value	Description	0	When a device loses arbitration, the ARB interrupt flag is set and the bus is released.	1	When a device loses arbitration, the ARB interrupt flag is set, but communication proceeds.
Value	Description									
0	When a device loses arbitration, the ARB interrupt flag is set and the bus is released.									
1	When a device loses arbitration, the ARB interrupt flag is set, but communication proceeds.									
4	AUTOSN	0	RW	<b>Automatic STOP on NACK</b>						
				Write to 1 to make a master transmitter send a STOP when a NACK is received from a slave.						
				<table> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Stop is not automatically sent if a NACK is received from a slave.</td></tr> <tr> <td>1</td><td>The master automatically sends a STOP if a NACK is received from a slave.</td></tr> </tbody> </table>	Value	Description	0	Stop is not automatically sent if a NACK is received from a slave.	1	The master automatically sends a STOP if a NACK is received from a slave.
Value	Description									
0	Stop is not automatically sent if a NACK is received from a slave.									
1	The master automatically sends a STOP if a NACK is received from a slave.									
3	AUTOSE	0	RW	<b>Automatic STOP When Empty</b>						
				Write to 1 to make a master transmitter send a STOP when no more data is available for transmission.						
				<table> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>A stop must be sent manually when no more data is to be transmitted.</td></tr> <tr> <td>1</td><td>The master automatically sends a STOP when no more data is available for transmission.</td></tr> </tbody> </table>	Value	Description	0	A stop must be sent manually when no more data is to be transmitted.	1	The master automatically sends a STOP when no more data is available for transmission.
Value	Description									
0	A stop must be sent manually when no more data is to be transmitted.									
1	The master automatically sends a STOP when no more data is available for transmission.									
2	AUTOACK	0	RW	<b>Automatic Acknowledge</b>						
				Set to enable automatic acknowledges.						
				<table> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Software must give one ACK command for each ACK transmitted on the I<sup>2</sup>C bus.</td></tr> <tr> <td>1</td><td>Addresses that are not automatically NACK'ed, and all data is automatically acknowledged.</td></tr> </tbody> </table>	Value	Description	0	Software must give one ACK command for each ACK transmitted on the I <sup>2</sup> C bus.	1	Addresses that are not automatically NACK'ed, and all data is automatically acknowledged.
Value	Description									
0	Software must give one ACK command for each ACK transmitted on the I <sup>2</sup> C bus.									
1	Addresses that are not automatically NACK'ed, and all data is automatically acknowledged.									
1	SLAVE	0	RW	<b>Addressable as Slave</b>						
				Set this bit to allow the device to be selected as an I <sup>2</sup> C slave.						
				<table> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>All addresses will be responded to with a NACK</td></tr> <tr> <td>1</td><td>Addresses matching the programmed slave address or the general call address (if enabled) require a response from software. Other addresses are automatically responded to with a NACK.</td></tr> </tbody> </table>	Value	Description	0	All addresses will be responded to with a NACK	1	Addresses matching the programmed slave address or the general call address (if enabled) require a response from software. Other addresses are automatically responded to with a NACK.
Value	Description									
0	All addresses will be responded to with a NACK									
1	Addresses matching the programmed slave address or the general call address (if enabled) require a response from software. Other addresses are automatically responded to with a NACK.									
0	EN	0	RW	<b>I<sup>2</sup>C Enable</b>						
				Use this bit to enable or disable the I <sup>2</sup> C module.						

Bit	Name	Reset	Access	Description
	Value			Description
0				The I <sup>2</sup> C module is disabled. And its internal state is cleared
1				The I <sup>2</sup> C module is enabled.

### 17.5.2 I2Cn\_CMD - Command Register

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8								
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																
	CLEARPC	W1	0	7	CLEARTX	W1	0	6	ABORT	W1	0	5	CONT	W1	0	4	NACK	W1	0	3	ACK	W1	0	2	STOP	W1	0	1	START	W1	0	0

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	CLEARPC	0	W1	<b>Clear Pending Commands</b>
	Set to clear pending commands.			
6	CLEARTX	0	W1	<b>Clear TX</b>
	Set to clear transmit buffer and shift register. Will not abort ongoing transfer.			
5	ABORT	0	W1	<b>Abort Transmission</b>
	Abort the current transmission making the bus go idle. When used in combination with STOP, a STOP condition is sent as soon as possible before aborting the transmission. The stop condition is subject to clock synchronization.			
4	CONT	0	W1	<b>Continue Transmission</b>
	Set to continue transmission after a NACK has been received.			
3	NACK	0	W1	<b>Send NACK</b>
	Set to transmit a NACK the next time an acknowledge is required.			
2	ACK	0	W1	<b>Send ACK</b>
	Set to transmit an ACK the next time an acknowledge is required.			
1	STOP	0	W1	<b>Send Stop Condition</b>
	Set to send stop condition as soon as possible.			
0	START	0	W1	<b>Send Start Condition</b>
	Set to send start condition as soon as possible. If a transmission is ongoing and not owned, the start condition will be sent as soon as the bus is idle. If the current transmission is owned by this module, a repeated start condition will be sent. Use in combination with a STOP command to automatically send a STOP, then a START when the bus becomes idle.			

## 17.5.3 I2Cn\_STATE - State Register

Offset	Bit Position																																		
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset	0x0																											R	0	0	0	0	0	0	0
Access																												R	0	0	0	0	0	0	0
Name																													STATE	BUSHOLD	NACKED	TRANSMITTER	MASTER	BUSY	

Bit	Name	Reset	Access	Description
31:8	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
7:5	STATE	0x0	R	<b>Transmission State</b>
				The state of any current transmission. Cleared if the I <sup>2</sup> C module is idle.
	Value	Mode		Description
	0	IDLE		No transmission is being performed.
	1	WAIT		Waiting for idle. Will send a start condition as soon as the bus is idle.
	2	START		Start transmitted or received
	3	ADDR		Address transmitted or received
	4	ADDRACK		Address ack/nack transmitted or received
	5	DATA		Data transmitted or received
	6	DATAACK		Data ack/nack transmitted or received
4	BUSHOLD	0	R	<b>Bus Held</b>
				Set if the bus is currently being held by this I <sup>2</sup> C module.
3	NACKED	0	R	<b>Nack Received</b>
				Set if a NACK was received and STATE is ADDRACK or DATAACK.
2	TRANSMITTER	0	R	<b>Transmitter</b>
				Set when operating as a master transmitter or a slave transmitter. When cleared, the system may be operating as a master receiver, a slave receiver or the current mode is not known.
1	MASTER	0	R	<b>Master</b>
				Set when operating as an I <sup>2</sup> C master. When cleared, the system may be operating as an I <sup>2</sup> C slave.
0	BUSY	1	R	<b>Bus Busy</b>
				Set when the bus is busy. Whether the I <sup>2</sup> C module is in control of the bus or not has no effect on the value of this bit. When the MCU comes out of reset, the state of the bus is not known, and thus BUSY is set. Use the ABORT command or a bus idle timeout to force the I <sup>2</sup> C module out of the BUSY state.

## 17.5.4 I2Cn\_STATUS - Status Register

Offset	Bit Position																						
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	
Reset																							
Access																							
Name																							

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	RXFULL	0	R	<b>RX FIFO Full</b>
				Set when the receive buffer is full. Cleared when the receive buffer is no longer full. When this bit is set, there is still room for one more frame in the receive shift register.
8	RXDATAV	0	R	<b>RX Data Valid</b>
				Set when data is available in the receive buffer. Cleared when the receive buffer is empty.
7	TXBL	1	R	<b>TX Buffer Level</b>
				Indicates the level of the transmit buffer. Set when the transmit buffer is empty, and cleared when it is full.
6	TXC	0	R	<b>TX Complete</b>
				Set when a transmission has completed and no more data is available in the transmit buffer. Cleared when a new transmission starts.
5	PABORT	0	R	<b>Pending Abort</b>
				An abort is pending and will be transmitted as soon as possible.
4	PCONT	0	R	<b>Pending Continue</b>
				A continue is pending and will be transmitted as soon as possible.
3	PNACK	0	R	<b>Pending NACK</b>
				A not-acknowledge is pending and will be transmitted as soon as possible.
2	PACK	0	R	<b>Pending ACK</b>
				An acknowledge is pending and will be transmitted as soon as possible.
1	PSTOP	0	R	<b>Pending STOP</b>
				A stop condition is pending and will be transmitted as soon as possible.
0	PSTART	0	R	<b>Pending START</b>
				A start condition is pending and will be transmitted as soon as possible.

**17.5.5 I2Cn\_CLKDIV - Clock Division Register**

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x000							
<b>Access</b>																									RW							
<b>Name</b>																									DIV							

Bit	Name	Reset	Access	Description
31:9	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
8:0	DIV	0x000	RW	<b>Clock Divider</b>

Specifies the clock divider for the I<sup>2</sup>C. Note that DIV must be 1 or higher when slave is enabled.

**17.5.6 I2Cn\_SADDR - Slave Address Register**

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x00							
<b>Access</b>																									RW							
<b>Name</b>																									ADDR							

Bit	Name	Reset	Access	Description
31:8	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:1	ADDR	0x00	RW	<b>Slave Address</b>
0	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

Specifies the slave address of the device.

## 17.5.7 I2Cn\_SADDRMASK - Slave Address Mask Register

Offset	Bit Position																																
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:1	MASK	0x00	RW	<b>Slave Address Mask</b>
				Specifies the significant bits of the slave address. Setting the mask to 0x00 will match all addresses, while setting it to 0x7F will only match the exact address specified by ADDR.
0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 17.5.8 I2Cn\_RXDATA - Receive Buffer Data Register (Actionable Reads)

Offset	Bit Position																																
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	RXDATA	0x00	R	<b>RX Data</b>

Use this register to read from the receive buffer. Buffer is emptied on read access.

**17.5.9 I2Cn\_RXDOUBLE - Receive Buffer Double Data Register (Actionable Reads)**

Offset	Bit Position																								
0x020	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																								
<b>Reset</b>																									0x00
<b>Access</b>																									R
<b>Name</b>																									RXDATA0

Bit	Name	Reset	Access	Description
31:16	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:8	RXDATA1	0x00	R	<b>RX Data 1</b>  Second byte read from buffer. Buffer is emptied on read access.
7:0	RXDATA0	0x00	R	<b>RX Data 0</b>  First byte read from buffer. Buffer is emptied on read access.

**17.5.10 I2Cn\_RXDATAP - Receive Buffer Data Peek Register**

Offset	Bit Position																								
0x024	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																								
<b>Reset</b>																									0x00
<b>Access</b>																									R
<b>Name</b>																									RXDATAP

Bit	Name	Reset	Access	Description
31:8	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	RXDATAP	0x00	R	<b>RX Data Peek</b>  Use this register to read from the receive buffer. Buffer is not emptied on read access.

## 17.5.11 I2Cn\_RXDOUBLEP - Receive Buffer Double Data Peek Register

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00								0x00							
Access																	R								R							
Name																	RXDATAP1								RXDATAP0							

Bit	Name	Reset	Access	Description
31:16	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
15:8	RXDATAP1	0x00	R	<b>RX Data 1 Peek</b>  Second byte read from buffer. Buffer is not emptied on read access.
7:0	RXDATAP0	0x00	R	<b>RX Data 0 Peek</b>  First byte read from buffer. Buffer is not emptied on read access.

## 17.5.12 I2Cn\_TXDATA - Transmit Buffer Data Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00								0x00							
Access																	W								W							
Name																	TXDATA								TXDATA							

Bit	Name	Reset	Access	Description
31:8	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
7:0	TXDATA	0x00	W	<b>TX Data</b>  Use this register to write a byte to the transmit buffer.

## 17.5.13 I2Cn\_TXDOUBLE - Transmit Buffer Double Data Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00	0x00														
Access																	W	W														
Name																	TXDATA1	TXDATA0														

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15:8	TXDATA1	0x00	W	<b>TX Data</b>  Second byte to write to buffer.
7:0	TXDATA0	0x00	W	<b>TX Data</b>  First byte to write to buffer.

## 17.5.14 I2Cn\_IF - Interrupt Flag Register

Offset	Bit Position															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	0	17
Reset															R	0
Access															R	0
Name															R	0

Bit	Name	Reset	Access	Description
31:19	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
18	CLERR	0	R	<b>Clock Low Error Interrupt Flag</b>  Set when the clock is pulled low before a START or a STOP condition could be transmitted.
17	RXFULL	0	R	<b>Receive Buffer Full Interrupt Flag</b>  Set when the receive buffer becomes full.
16	SSTOP	0	R	<b>Slave STOP Condition Interrupt Flag</b>  Set when a STOP condition has been received. Will be set regardless of the slave being involved in the transaction or not.
15	CLTO	0	R	<b>Clock Low Timeout Interrupt Flag</b>  Set on each clock low timeout. The timeout value can be set in CLTO bit field in the I2Cn_CTRL register.
14	BITO	0	R	<b>Bus Idle Timeout Interrupt Flag</b>  Set on each bus idle timeout. The timeout value can be set in the BITO bit field in the I2Cn_CTRL register.
13	RXUF	0	R	<b>Receive Buffer Underflow Interrupt Flag</b>  Set when data is read from the receive buffer through the I2Cn_RXDATA register while the receive buffer is empty. It is also set when data is read through the I2Cn_RXDOUBLE while the buffer is not full.
12	TXOF	0	R	<b>Transmit Buffer Overflow Interrupt Flag</b>  Set when data is written to the transmit buffer while the transmit buffer is full.
11	BUSHOLD	0	R	<b>Bus Held Interrupt Flag</b>  Set when the bus becomes held by the I <sup>2</sup> C module.
10	BUSERR	0	R	<b>Bus Error Interrupt Flag</b>  Set when a bus error is detected. The bus error is resolved automatically, but the current transfer is aborted.
9	ARBLOST	0	R	<b>Arbitration Lost Interrupt Flag</b>  Set when arbitration is lost.
8	MSTOP	0	R	<b>Master STOP Condition Interrupt Flag</b>  Set when a STOP condition has been successfully transmitted. If arbitration is lost during the transmission of the STOP condition, then the MSTOP interrupt flag is not set.
7	NACK	0	R	<b>Not Acknowledge Received Interrupt Flag</b>  Set when a NACK has been received.
6	ACK	0	R	<b>Acknowledge Received Interrupt Flag</b>  Set when an ACK has been received.

Bit	Name	Reset	Access	Description
5	RXDATAV	0	R	<b>Receive Data Valid Interrupt Flag</b>  Set when data is available in the receive buffer. Cleared automatically when the receive buffer is read.
4	TXBL	1	R	<b>Transmit Buffer Level Interrupt Flag</b>  Set when the transmit buffer becomes empty. Cleared automatically when new data is written to the transmit buffer.
3	TXC	0	R	<b>Transfer Completed Interrupt Flag</b>  Set when the transmit shift register becomes empty and there is no more data in the transmit buffer.
2	ADDR	0	R	<b>Address Interrupt Flag</b>  Set when incoming address is accepted, i.e. own address or general call address is received.
1	RSTART	0	R	<b>Repeated START Condition Interrupt Flag</b>  Set when a repeated start condition is detected.
0	START	0	R	<b>START Condition Interrupt Flag</b>  Set when a start condition is successfully transmitted.

## 17.5.15 I2Cn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	0	1	8
<b>Reset</b>																	
<b>Access</b>																	
<b>Name</b>																	

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18	CLERR	0	W1	<b>Set CLERR Interrupt Flag</b>  Write 1 to set the CLERR interrupt flag
17	RXFULL	0	W1	<b>Set RXFULL Interrupt Flag</b>  Write 1 to set the RXFULL interrupt flag
16	SSTOP	0	W1	<b>Set SSTOP Interrupt Flag</b>  Write 1 to set the SSTOP interrupt flag
15	CLTO	0	W1	<b>Set CLTO Interrupt Flag</b>  Write 1 to set the CLTO interrupt flag
14	BITO	0	W1	<b>Set BITO Interrupt Flag</b>  Write 1 to set the BITO interrupt flag
13	RXUF	0	W1	<b>Set RXUF Interrupt Flag</b>  Write 1 to set the RXUF interrupt flag
12	TXOF	0	W1	<b>Set TXOF Interrupt Flag</b>  Write 1 to set the TXOF interrupt flag
11	BUSHOLD	0	W1	<b>Set BUSHOLD Interrupt Flag</b>  Write 1 to set the BUSHOLD interrupt flag
10	BUSERR	0	W1	<b>Set BUSERR Interrupt Flag</b>  Write 1 to set the BUSERR interrupt flag
9	ARBLOST	0	W1	<b>Set ARBLOST Interrupt Flag</b>  Write 1 to set the ARBLOST interrupt flag
8	MSTOP	0	W1	<b>Set MSTOP Interrupt Flag</b>  Write 1 to set the MSTOP interrupt flag
7	NACK	0	W1	<b>Set NACK Interrupt Flag</b>  Write 1 to set the NACK interrupt flag
6	ACK	0	W1	<b>Set ACK Interrupt Flag</b>  Write 1 to set the ACK interrupt flag
5:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
3	TXC	0	W1	<b>Set TXC Interrupt Flag</b> Write 1 to set the TXC interrupt flag
2	ADDR	0	W1	<b>Set ADDR Interrupt Flag</b> Write 1 to set the ADDR interrupt flag
1	RSTART	0	W1	<b>Set RSTART Interrupt Flag</b> Write 1 to set the RSTART interrupt flag
0	START	0	W1	<b>Set START Interrupt Flag</b> Write 1 to set the START interrupt flag

### 17.5.16 I2Cn IFC - Interrupt Flag Clear Register

Offset	Bit Position																
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	
Access	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	(R)W1	
Name	CLERR	RXFULL	SSTOP	CLTO	BITO	RXUF	TXOF	BUSHOLD	BUSERR	ARBLOST	MSTOP	NACK	ACK	TXC	ADDR	RSTART	START

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18	CLERR	0	(R)W1	<b>Clear CLERR Interrupt Flag</b>
				Write 1 to clear the CLERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
17	RXFULL	0	(R)W1	<b>Clear RXFULL Interrupt Flag</b>
				Write 1 to clear the RXFULL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
16	SSTOP	0	(R)W1	<b>Clear SSTOP Interrupt Flag</b>
				Write 1 to clear the SSTOP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15	CLTO	0	(R)W1	<b>Clear CLTO Interrupt Flag</b>
				Write 1 to clear the CLTO interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
14	BITO	0	(R)W1	<b>Clear BITO Interrupt Flag</b>
				Write 1 to clear the BITO interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
13	RXUF	0	(R)W1	<b>Clear RXUF Interrupt Flag</b>
				Write 1 to clear the RXUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
12	TXOF	0	(R)W1	<b>Clear TXOF Interrupt Flag</b>
				Write 1 to clear the TXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
11	BUSHOLD	0	(R)W1	<b>Clear BUSHOLD Interrupt Flag</b>
				Write 1 to clear the BUSHOLD interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
10	BUSERR	0	(R)W1	<b>Clear BUSERR Interrupt Flag</b>
				Write 1 to clear the BUSERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	ARBLOST	0	(R)W1	<b>Clear ARBLOST Interrupt Flag</b>
				Write 1 to clear the ARBLOST interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
8	MSTOP	0	(R)W1	<b>Clear MSTOP Interrupt Flag</b>  Write 1 to clear the MSTOP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	NACK	0	(R)W1	<b>Clear NACK Interrupt Flag</b>  Write 1 to clear the NACK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
6	ACK	0	(R)W1	<b>Clear ACK Interrupt Flag</b>  Write 1 to clear the ACK interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	TXC	0	(R)W1	<b>Clear TXC Interrupt Flag</b>  Write 1 to clear the TXC interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	ADDR	0	(R)W1	<b>Clear ADDR Interrupt Flag</b>  Write 1 to clear the ADDR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	RSTART	0	(R)W1	<b>Clear RSTART Interrupt Flag</b>  Write 1 to clear the RSTART interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	START	0	(R)W1	<b>Clear START Interrupt Flag</b>  Write 1 to clear the START interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 17.5.17 I2Cn\_IEN - Interrupt Enable Register

Offset	Bit Position															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	0	1
<b>Reset</b>															RW	0
<b>Access</b>															RW	0
<b>Name</b>															RW	0

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18	CLERR	0	RW	<b>CLERR Interrupt Enable</b> Enable/disable the CLERR interrupt
17	RXFULL	0	RW	<b>RXFULL Interrupt Enable</b> Enable/disable the RXFULL interrupt
16	SSTOP	0	RW	<b>SSTOP Interrupt Enable</b> Enable/disable the SSTOP interrupt
15	CLTO	0	RW	<b>CLTO Interrupt Enable</b> Enable/disable the CLTO interrupt
14	BITO	0	RW	<b>BITO Interrupt Enable</b> Enable/disable the BITO interrupt
13	RXUF	0	RW	<b>RXUF Interrupt Enable</b> Enable/disable the RXUF interrupt
12	TXOF	0	RW	<b>TXOF Interrupt Enable</b> Enable/disable the TXOF interrupt
11	BUSHOLD	0	RW	<b>BUSHOLD Interrupt Enable</b> Enable/disable the BUSHOLD interrupt
10	BUSERR	0	RW	<b>BUSERR Interrupt Enable</b> Enable/disable the BUSERR interrupt
9	ARBLOST	0	RW	<b>ARBLOST Interrupt Enable</b> Enable/disable the ARBLOST interrupt
8	MSTOP	0	RW	<b>MSTOP Interrupt Enable</b> Enable/disable the MSTOP interrupt
7	NACK	0	RW	<b>NACK Interrupt Enable</b> Enable/disable the NACK interrupt
6	ACK	0	RW	<b>ACK Interrupt Enable</b> Enable/disable the ACK interrupt

Bit	Name	Reset	Access	Description
5	RXDATAV	0	RW	<b>RXDATAV Interrupt Enable</b>  Enable/disable the RXDATAV interrupt
4	TXBL	0	RW	<b>TXBL Interrupt Enable</b>  Enable/disable the TXBL interrupt
3	TXC	0	RW	<b>TXC Interrupt Enable</b>  Enable/disable the TXC interrupt
2	ADDR	0	RW	<b>ADDR Interrupt Enable</b>  Enable/disable the ADDR interrupt
1	RSTART	0	RW	<b>RSTART Interrupt Enable</b>  Enable/disable the RSTART interrupt
0	START	0	RW	<b>START Interrupt Enable</b>  Enable/disable the START interrupt

#### 17.5.18 I2Ch\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																																		
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																													0	0					
Access																																			
Name																																SCLPEN	RW	SDAPEN	RW



Bit	Name	Reset	Access	Description
31:2	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
1	SCLPEN	0	RW	<b>SCL Pin Enable</b>  When set, the SCL pin of the I <sup>2</sup> C is enabled.
0	SDAPEN	0	RW	<b>SDA Pin Enable</b>  When set, the SDA pin of the I <sup>2</sup> C is enabled.

## 17.5.19 I2Cn\_ROUTELOC0 - I/O Routing Location Register

Offset	Bit Position																																		
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																										0x00									
Access																										RW									
Name																										SCLLOC									
																										SDALOC									

Bit	Name	Reset	Access	Description																											
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																											
13:8	SCLLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the I <sup>2</sup> C SCL pin.																											
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> <tr><td>7</td><td>LOC7</td><td>Location 7</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6	7	LOC7	Location 7
Value	Mode	Description																													
0	LOC0	Location 0																													
1	LOC1	Location 1																													
2	LOC2	Location 2																													
3	LOC3	Location 3																													
4	LOC4	Location 4																													
5	LOC5	Location 5																													
6	LOC6	Location 6																													
7	LOC7	Location 7																													
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																											
5:0	SDALOC	0x00	RW	<b>I/O Location</b>  Decides the location of the I <sup>2</sup> C SDA pin.																											
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> <tr><td>7</td><td>LOC7</td><td>Location 7</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6	7	LOC7	Location 7
Value	Mode	Description																													
0	LOC0	Location 0																													
1	LOC1	Location 1																													
2	LOC2	Location 2																													
3	LOC3	Location 3																													
4	LOC4	Location 4																													
5	LOC5	Location 5																													
6	LOC6	Location 6																													
7	LOC7	Location 7																													

## 18. USART - Universal Synchronous Asynchronous Receiver/Transmitter



### Quick Facts

#### What?

The USART handles high-speed UART, SPI-bus, SmartCards, and IrDA communication.

#### Why?

Serial communication is frequently used in embedded systems and the USART allows efficient communication with a wide range of external devices.

#### How?

The USART has a wide selection of operating modes, frame formats and baud rates. The multi-processor mode allows the USART to remain idle when not addressed. Triple buffering and DMA support makes high data rates possible with minimal CPU intervention and it is possible to transmit and receive large frames while the MCU remains in EM1 Sleep.

### 18.1 Introduction

The Universal Synchronous Asynchronous serial Receiver and Transmitter (USART) is a very flexible serial I/O module. It supports full duplex asynchronous UART communication as well as RS-485, SPI, MicroWire and 3-wire. It can also interface with ISO7816 Smart Cards, and IrDA devices.

## 18.2 Features

- Asynchronous and synchronous (SPI) communication
- Full duplex and half duplex
- Separate TX/RX enable
- Separate receive / transmit multiple entry buffers, with additional separate shift registers
- Programmable baud rate, generated as an fractional division from the peripheral clock ( $\text{HFPERCLK}_{\text{USARTn}}$ )
- Max bit-rate
  - SPI master mode, peripheral clock rate/2
  - SPI slave mode, peripheral clock rate/8
  - UART mode, peripheral clock rate/16, 8, 6, or 4
- Asynchronous mode supports
  - Majority vote baud-reception
  - False start-bit detection
  - Break generation/detection
  - Multi-processor mode
- Synchronous mode supports
  - All 4 SPI clock polarity/phase configurations
  - Master and slave mode
- Data can be transmitted LSB first or MSB first
- Configurable number of data bits, 4-16 (plus the parity bit, if enabled)
  - HW parity bit generation and check
- Configurable number of stop bits in asynchronous mode: 0.5, 1, 1.5, 2
- HW collision detection
- Multi-processor mode
- IrDA modulator
- SmartCard (ISO7816) mode
- I<sup>2</sup>S mode
- Separate interrupt vectors for receive and transmit interrupts
- Loopback mode
  - Half duplex communication
  - Communication debugging
- PRS RX input
- 8 bit Timer
- Hardware Flow Control
- Automatic Baud Rate Detection

### 18.3 Functional Description

An overview of the USART module is shown in [Figure 18.1 USART Overview on page 605](#).

This section describes all possible USART features. Refer to the device data sheet to see what features a specific USART instance supports.




Figure 18.1. USART Overview

### 18.3.1 Modes of Operation

The USART operates in either asynchronous or synchronous mode.

In synchronous mode, a separate clock signal is transmitted with the data. This clock signal is generated by the bus master, and both the master and slave sample and transmit data according to this clock. Both master and slave modes are supported by the USART. The synchronous communication mode is compatible with the Serial Peripheral Interface Bus (SPI) standard.

In asynchronous mode, no separate clock signal is transmitted with the data on the bus. The USART receiver thus has to determine where to sample the data on the bus from the actual data. To make this possible, additional synchronization bits are added to the data when operating in asynchronous mode, resulting in a slight overhead.

Asynchronous or synchronous mode can be selected by configuring SYNC in USARTn\_CTRL. The options are listed with supported protocols in [Table 18.1 USART Asynchronous Vs. Synchronous Mode on page 606](#). Full duplex and half duplex communication is supported in both asynchronous and synchronous mode.

**Table 18.1. USART Asynchronous Vs. Synchronous Mode**

SYNC	Communication Mode	Supported Protocols
0	Asynchronous	RS-232, RS-485 (w/external driver), IrDA, ISO 7816
1	Synchronous	SPI, MicroWire, 3-wire

[Table 18.2 USART Pin Usage on page 606](#) explains the functionality of the different USART pins when the USART operates in different modes. Pin functionality enclosed in square brackets is optional, and depends on additional configuration parameters. LOOPBK and MASTER are discussed in [18.3.2.14 Local Loopback](#) and [18.3.3.3 Master Mode](#) respectively.

**Table 18.2. USART Pin Usage**


SYNC	LOOPBK	MASTER	Pin functionality			
			U(S)n_TX (MOSI)	U(S)n_RX (MISO)	USn_CLK	USn_CS
0	0	x	Data out	Data in	-	[Driver enable]
0	1	x	Data out/in	-	-	[Driver enable]
1	0	0	Data in	Data out	Clock in	Slave select
1	0	1	Data out	Data in	Clock out	[Auto slave select]
1	1	0	Data out/in	-	Clock in	Slave select
1	1	1	Data out/in	-	Clock out	[Auto slave select]

### 18.3.2 Asynchronous Operation

The USART operates in asynchronous mode when SYNC in USARTn\_CTRL is cleared to 0.

### 18.3.2.1 Frame Format

The frame format used in asynchronous mode consists of a set of data bits in addition to bits for synchronization and optionally a parity bit for error checking. A frame starts with one start-bit (S), where the line is driven low for one bit-period. This signals the start of a frame, and is used for synchronization. Following the start bit are 4 to 16 data bits and an optional parity bit. Finally, a number of stop-bits, where the line is driven high, end the frame. An example frame is shown in [Figure 18.2 USART Asynchronous Frame Format on page 607](#).



**Figure 18.2. USART Asynchronous Frame Format**

The number of data bits in a frame is set by DATABITS in USARTn\_FRAME, see [Table 18.3 USART Data Bits on page 607](#), and the number of stop-bits is set by STOPBITS in USARTn\_FRAME, see [Table 18.4 USART Stop Bits on page 607](#). Whether or not a parity bit should be included, and whether it should be even or odd is defined by PARITY, also in USARTn\_FRAME. For communication to be possible, all parties of an asynchronous transfer must agree on the frame format being used.

**Table 18.3. USART Data Bits**

DATA BITS [3:0]	Number of Data Bits
0001	4
0010	5
0011	6
0100	7
0101	8 (Default)
0110	9
0111	10
1000	11
1001	12
1010	13
1011	14
1100	15
1101	16

**Table 18.4. USART Stop Bits**

STOP BITS [1:0]	Number of Stop Bits
00	0.5
01	1 (Default)
10	1.5
11	2

The order in which the data bits are transmitted and received is defined by MSBF in USARTn\_CTRL. When MSBF is cleared, data in a frame is sent and received with the least significant bit first. When it is set, the most significant bit comes first.

The frame format used by the transmitter can be inverted by setting TXINV in USARTn\_CTRL, and the format expected by the receiver can be inverted by setting RXINV in USARTn\_CTRL. These bits affect the entire frame, not only the data bits. An inverted frame has a low idle state, a high start-bit, inverted data and parity bits, and low stop-bits.

### 18.3.2.2 Parity Bit Calculation and Handling

When parity bits are enabled, hardware automatically calculates and inserts any parity bits into outgoing frames, and verifies the received parity bits in incoming frames. This is true for both asynchronous and synchronous modes, even though it is mostly used in asynchronous communication. The possible parity modes are defined in [Table 18.5 USART Parity Bits on page 608](#). When even parity is chosen, a parity bit is inserted to make the number of high bits (data + parity) even. If odd parity is chosen, the parity bit makes the total number of high bits odd.

**Table 18.5. USART Parity Bits**

PARITY BITS [1:0]	Description
00	No parity bit (Default)
01	Reserved
10	Even parity
11	Odd parity

### 18.3.2.3 Clock Generation

**Note:** Not all USART instances are using the same peripheral clock. Normally the USART uses  $f_{HPPERCLK_{USARTn}}$ , however USART2 supports higher frequencies and therefore uses  $f_{HPPERBCLK_{USART2}}$ . This chapter describes the general case and therefore uses  $f_{HPPERCLK_{USARTn}}$  and  $f_{HPPERCLK}$ , which should be interpreted as  $f_{HPPERBCLK_{USARTn}}$  and  $f_{HPPERBCLK}$  for USART2. **10.3.1.4 HPPERCLK, HPPERBCLK, HPERCCLK - High Frequency Peripheral Clocks** shows which peripheral uses what peripheral clock.

The USART clock defines the transmission and reception data rate. When operating in asynchronous mode, the baud rate (bit-rate) is given by [Figure 18.3 USART Baud Rate on page 609](#).

$$br = f_{HPPERCLK} / (\text{oversample} \times (1 + \text{USARTn\_CLKDIV}/256))$$

**Figure 18.3. USART Baud Rate**

where  $f_{HPPERCLK}$  is the peripheral clock ( $f_{HPPERCLK_{USARTn}}$ ) frequency and oversample is the oversampling rate as defined by OVS in `USARTn_CTRL`, see [Table 18.6 USART Oversampling on page 609](#).

**Table 18.6. USART Oversampling**

OVS [1:0]	Oversample
00	16
01	8
10	6
11	4

The USART has a fractional clock divider to allow the USART clock to be controlled more accurately than what is possible with a standard integral divider.

The clock divider used in the USART is a 20-bit value, with a 15-bit integral part and an 5-bit fractional part. The fractional part is configured in the lower 5 bits of DIV in `USART_CLKDIV`.

Fractional clock division is implemented by distributing the selected fraction over thirty two baud periods. The fractional part of the divider tells how many of these periods should be extended by one peripheral clock cycle.

Given a desired baud rate  $br_{desired}$ , the clock divider `USARTn_CLKDIV` can be calculated by using [Figure 18.4 USART Desired Baud Rate on page 609](#):

$$\text{USARTn\_CLKDIV} = 256 \times (f_{HPPERCLK} / (\text{oversample} \times br_{desired})) - 1$$

**Figure 18.4. USART Desired Baud Rate**

[Table 18.7 USART Baud Rates @ 4MHz Peripheral Clock With 20 Bit CLKDIV on page 609](#) shows a set of desired baud rates and how accurately the USART is able to generate these baud rates when running at a 4 MHz peripheral clock, using 16x or 8x oversampling.

**Table 18.7. USART Baud Rates @ 4MHz Peripheral Clock With 20 Bit CLKDIV**

Desired baud rate [baud/s]	USARTn_OVS =00			USARTn_OVS =01		
	USARTn_CLKDIV/256 (to 32nd position)	Actual baud rate [baud/s]	Error %	USARTn_CLKDIV/256 (to 32nd position)	Actual baud rate [baud/s]	Error %
600	415.6563	600.015	0.003	832.3438	599.9925	-0.001
1200	207.3438	1199.94	-0.005	415.6563	1200.03	0.003
2400	103.1563	2400.24	0.010	207.3438	2399.88	-0.005
4800	51.09375	4799.04	-0.020	103.1563	4800.48	0.010

Desired baud rate [baud/s]	USARTn_OVS =00			USARTn_OVS =01		
	USARTn_CLKDIV/256 (to 32nd position)	Actual baud rate [baud/s]	Error %	USARTn_CLKDIV/256 (to 32nd position)	Actual baud rate [baud/s]	Error %
9600	25.03125	9603.842	0.040	51.09375	9598.08	-0.020
14400	16.375	14388.49	-0.080	33.71875	14401.44	0.010
19200	12.03125	19184.65	-0.080	25.03125	19207.68	0.040
28800	7.6875	28776.98	-0.080	16.375	28776.98	-0.080
38400	5.5	38461.54	0.160	12.03125	38369.3	-0.080
57600	3.34375	57553.96	-0.080	7.6875	57553.96	-0.080
76800	2.25	76923.08	0.160	5.5	76923.08	0.160
115200	1.15625	115942	0.644	3.34375	115107.9	-0.080
230400	0.09375	228571.4	-0.794	1.15625	231884.1	0.644

#### 18.3.2.4 Auto Baud Detection

Setting AUTOBAUDEN in USARTn\_CLKDIV uses the first frame received to automatically set the baud rate provided that it contains 0x55 (IrDA uses 0x00). AUTOBAUDEN can be used in a simple LIN configuration to auto detect the SYNC byte. The receiver will measure the number of local clock cycles between the beginning of the START bit and the beginning of the 8th data bit. The DIV field in USARTn\_CLKDIV will be overwritten with the new value. The OVS in USARTn\_CTRL and the +1 count of the Baud Rate equation are already factored into the result that gets written into the DIV field. To restart autobaud detection, clear AUTOBAUDEN and set it high again. Since the auto baud detection is done over 8 baud times, only the upper 3 bits of the fractional part of the clock divider are populated.

#### 18.3.2.5 Data Transmission

Asynchronous data transmission is initiated by writing data to the transmit buffer using one of the methods described in [18.3.2.6 Transmit Buffer Operation](#). When the transmission shift register is empty and ready for new data, a frame from the transmit buffer is loaded into the shift register, and if the transmitter is enabled, transmission begins. When the frame has been transmitted, a new frame is loaded into the shift register if available, and transmission continues. If the transmit buffer is empty, the transmitter goes to an idle state, waiting for a new frame to become available.


Transmission is enabled through the command register USARTn\_CMD by setting TXEN, and disabled by setting TXDIS in the same command register. When the transmitter is disabled using TXDIS, any ongoing transmission is aborted, and any frame currently being transmitted is discarded. When disabled, the TX output goes to an idle state, which by default is a high value. Whether or not the transmitter is enabled at a given time can be read from TXENS in USARTn\_STATUS.

When the USART transmitter is enabled and there is no data in the transmit shift register or transmit buffer, the TXC flag in USARTn\_STATUS and the TXC interrupt flag in USARTn\_IF are set, signaling that the transmission is complete. The TXC status flag is cleared when a new frame becomes available for transmission, but the TXC interrupt flag must be cleared by software.

### 18.3.2.6 Transmit Buffer Operation

The transmit-buffer is a multiple entry FIFO buffer. A frame can be loaded into the buffer by writing to USARTn\_TXDATA, USARTn\_TXDATAx, USARTn\_TXDOUBLE or USARTn\_TXDOUBLEx. Using USARTn\_TXDATA allows 8 bits to be written to the buffer, while using USARTn\_TXDOUBLE will write 2 frames of 8 bits to the buffer. If 9-bit frames are used, the 9th bit of the frames will in these cases be set to the value of BIT8DV in USARTn\_CTRL.

To set the 9th bit directly and/or use transmission control, USARTn\_TXDATAx and USARTn\_TXDOUBLEx must be used. USARTn\_TXDATAx allows 9 data bits to be written, as well as a set of control bits regarding the transmission of the written frame. Every frame in the buffer is stored with 9 data bits and additional transmission control bits. USARTn\_TXDOUBLEx allows two frames, complete with control bits to be written at once. When data is written to the transmit buffer using USARTn\_TXDATAx and USARTn\_TXDOUBLEx, the 9th bit(s) written to these registers override the value in BIT8DV in USARTn\_CTRL, and alone define the 9th bits that are transmitted if 9-bit frames are used. [Figure 18.5 USART Transmit Buffer Operation on page 611](#) shows the basics of the transmit buffer when DATABITS in USARTn\_FRAME is configured to less than 10 bits.



**Figure 18.5. USART Transmit Buffer Operation**

When writing more frames to the transmit buffer than there is free space for, the TXOF interrupt flag in USARTn\_IF will be set, indicating the overflow. The data already in the transmit buffer is preserved in this case, and no data is written.

In addition to the interrupt flag TXC in USARTn\_IF and status flag TXC in USARTn\_STATUS which are set when the transmission is complete, TXBL in USARTn\_STATUS and the TXBL interrupt flag in USARTn\_IF are used to indicate the level of the transmit buffer. TXBIL in USARTn\_CTRL controls the level at which these bits are set. If TXBIL is cleared, they are set whenever the transmit buffer becomes empty, and if TXBIL is set, they are set whenever the transmit buffer goes from full to half-full or empty. Both the TXBL status flag and the TXBL interrupt flag are cleared automatically when their condition becomes false.

There is a TXIDLE status bit in USARTn\_STATUS to provide an indication of when the transmitter is idle. The combined count of TX buffer element 0, TX buffer element 1, and TX shift register is called TXBUFCNT in USARTn\_STATUS. For large frames, the count is only of TX buffer entry 0 and the TX shifter register.

The transmit buffer, including the transmit shift register can be cleared by setting CLEARTX in USARTn\_CMD. This will prevent the USART from transmitting the data in the buffer and shift register, and will make them available for new data. Any frame currently being transmitted will not be aborted. Transmission of this frame will be completed.

### 18.3.2.7 Frame Transmission Control

The transmission control bits, which can be written using USARTn\_TXDATAx and USARTn\_TXDOUBLEx, affect the transmission of the written frame. The following options are available:

- Generate break: By setting TXBREAK, the output will be held low during the stop-bit period to generate a framing error. A receiver that supports break detection detects this state, allowing it to be used e.g. for framing of larger data packets. The line is driven high before the next frame is transmitted so the next start condition can be identified correctly by the recipient. Continuous breaks lasting longer than a USART frame are thus not supported by the USART. GPIO can be used for this.
- Disable transmitter after transmission: If TXDISAT is set, the transmitter is disabled after the frame has been fully transmitted.
- Enable receiver after transmission: If RXENAT is set, the receiver is enabled after the frame has been fully transmitted. It is enabled in time to detect a start-bit directly after the last stop-bit has been transmitted.
- Unblock receiver after transmission: If UBRXAT is set, the receiver is unblocked and RXBLOCK is cleared after the frame has been fully transmitted.
- Tristate transmitter after transmission: If TXTRIAT is set, TXTRI is set after the frame has been fully transmitted, tristating the transmitter output. Tristating of the output can also be performed automatically by setting AUTOTRI. If AUTOTRI is set TXTRI is always read as 0.

**Note:** When in SmartCard mode with repeat enabled, none of the actions, except generate break, will be performed until the frame is transmitted without failure. Generation of a break in SmartCard mode with repeat enabled will cause the USART to detect a NACK on every frame.

### 18.3.2.8 Data Reception

Data reception is enabled by setting RXEN in USARTn\_CMD. When the receiver is enabled, it actively samples the input looking for a transition from high to low indicating the start baud of a new frame. When a start baud is found, reception of the new frame begins if the receive shift register is empty and ready for new data. When the frame has been received, it is pushed into the receive buffer, making the shift register ready for another frame of data, and the receiver starts looking for another start baud. If the receive buffer is full, the received frame remains in the shift register until more space in the receive buffer is available. If an incoming frame is detected while both the receive buffer and the receive shift register are full, the data in the shift register is overwritten, and the RXOF interrupt flag in USARTn\_IF is set to indicate the buffer overflow.

The receiver can be disabled by setting the command bit RXDIS in USARTn\_CMD. Any frame currently being received when the receiver is disabled is discarded. Whether or not the receiver is enabled at a given time can be read out from RXENS in USARTn\_STATUS.

### 18.3.2.9 Receive Buffer Operation


When data becomes available in the receive buffer, the RXDATAV flag in USARTn\_STATUS, and the RXDATAV interrupt flag in USARTn\_IF are set, and when the buffer becomes full, RXFULL in USARTn\_STATUS and the RXFULL interrupt flag in USARTn\_IF are set. The status flags RXDATAV and RXFULL are automatically cleared by hardware when their condition is no longer true. This also goes for the RXDATAV interrupt flag, but the RXFULL interrupt flag must be cleared by software. When the RXFULL flag is set, notifying that the buffer is full, space is still available in the receive shift register for one more frame.

Data can be read from the receive buffer in a number of ways. USARTn\_RXDATA gives access to the 8 least significant bits of the received frame, and USARTn\_RXDOUBLE makes it possible to read the 8 least significant bits of two frames at once, pulling two frames from the buffer. To get access to the 9th, most significant bit, USARTn\_RXDATAX must be used. This register also contains status information regarding the frame. USARTn\_RXDOUBLEXP can be used to get two frames complete with the 9th bits and status bits.

When a frame is read from the receive buffer using USARTn\_RXDATA or USARTn\_RXDATAX, the frame is pulled out of the buffer, making room for a new frame. USARTn\_RXDOUBLE and USARTn\_RXDOUBLEXP pull two frames out of the buffer. If an attempt is done to read more frames from the buffer than what is available, the RXUF interrupt flag in USARTn\_IF is set to signal the underflow, and the data read from the buffer is undefined.

Frames can be read from the receive buffer without removing the data by using USARTn\_RXDATAXP and USARTn\_RXDOUBLEXP. USARTn\_RXDATAXP gives access the first frame in the buffer with status bits, while USARTn\_RXDOUBLEXP gives access to both frames with status bits. The data read from these registers when the receive buffer is empty is undefined. If the receive buffer contains one valid frame, the first frame in USARTn\_RXDOUBLEXP will be valid. No underflow interrupt is generated by a read using these registers, i.e. RXUF in USARTn\_IF is never set as a result of reading from USARTn\_RXDATAXP or USARTn\_RXDOUBLEXP.

The basic operation of the receive buffer when DATABITS in USARTn\_FRAME is configured to less than 10 bits is shown in [Figure 18.6 USART Receive Buffer Operation on page 613](#).



**Figure 18.6. USART Receive Buffer Operation**

The receive buffer, including the receive shift register can be cleared by setting CLEARRX in USARTn\_CMD. Any frame currently being received will not be discarded.

### 18.3.2.10 Blocking Incoming Data

When using hardware frame recognition, as detailed in [18.3.2.20 Multi-Processor Mode](#) and [18.3.2.21 Collision Detection](#), it is necessary to be able to let the receiver sample incoming frames without passing the frames to software by loading them into the receive buffer. This is accomplished by blocking incoming data.

Incoming data is blocked as long as RXBLOCK in USARTn\_STATUS is set. When blocked, frames received by the receiver will not be loaded into the receive buffer, and software is not notified by the RXDATAV flag in USARTn\_STATUS or the RXDATAV interrupt flag in USARTn\_IF at their arrival. For data to be loaded into the receive buffer, RXBLOCK must be cleared in the instant a frame is fully received by the receiver. RXBLOCK is set by setting RXBLOCKEN in USARTn\_CMD and disabled by setting RXBLOCKDIS also in USARTn\_CMD. There is one exception where data is loaded into the receive buffer even when RXBLOCK is set. This is when an address frame is received when operating in multi-processor mode. See [18.3.2.20 Multi-Processor Mode](#) for more information.

Frames received containing framing or parity errors will not result in the FERR and PERR interrupt flags in USARTn\_IF being set while RXBLOCK in USARTn\_STATUS is set. Hardware recognition is not applied to these erroneous frames, and they are silently discarded.

**Note:**

- If a frame is received while RXBLOCK in USARTn\_STATUS is cleared, but stays in the receive shift register because the receive buffer is full, the received frame will be loaded into the receive buffer when space becomes available even if RXBLOCK is set at that time.
- The overflow interrupt flag RXOF in USARTn\_IF will be set if a frame in the receive shift register, waiting to be loaded into the receive buffer is overwritten by an incoming frame even though RXBLOCK in USARTn\_STATUS is set.

### 18.3.2.11 Clock Recovery and Filtering

The receiver samples the incoming signal at a rate 16, 8, 6 or 4 times higher than the given baud rate, depending on the oversampling mode given by OVS in USARTn\_CTRL. Lower oversampling rates make higher baud rates possible, but give less room for errors.


When a high-to-low transition is registered on the input while the receiver is idle, this is recognized as a start-bit, and the baud rate generator is synchronized with the incoming frame.

For oversampling modes 16, 8 and 6, every bit in the incoming frame is sampled three times to gain a level of noise immunity. These samples are aimed at the middle of the bit-periods, as visualized in [Figure 18.7 USART Sampling of Start and Data Bits on page 615](#). With OVS=0 in USARTn\_CTRL, the start and data bits are thus sampled at locations 8, 9 and 10 in the figure, locations 4, 5 and 6 for OVS=1 and locations 3, 4, and 5 for OVS=2. The value of a sampled bit is determined by majority vote. If two or more of the three bit-samples are high, the resulting bit value is high. If the majority is low, the resulting bit value is low.

Majority vote is used for all oversampling modes except 4x oversampling. In this mode, a single sample is taken at position 3 as shown in [Figure 18.7 USART Sampling of Start and Data Bits on page 615](#).

Majority vote can be disabled by setting MVDIS in USARTn\_CTRL.


If the value of the start bit is found to be high, the reception of the frame is aborted, filtering out false start bits possibly generated by noise on the input.



**Figure 18.7. USART Sampling of Start and Data Bits**

If the baud rate of the transmitter and receiver differ, the location each bit is sampled will be shifted towards the previous or next bit in the frame. This is acceptable for small errors in the baud rate, but for larger errors, it will result in transmission errors.

When the number of stop bits is 1 or more, stop bits are sampled like the start and data bits as seen in [Figure 18.8 USART Sampling of Stop Bits when Number of Stop Bits are 1 or More on page 616](#). When a stop bit has been detected by sampling at positions 8, 9 and 10 for normal mode, or 4, 5 and 6 for smart mode, the USART is ready for a new start bit. As seen in [Figure 18.8 USART Sampling of Stop Bits when Number of Stop Bits are 1 or More on page 616](#), a stop-bit of length 1 normally ends at c, but the next frame will be received correctly as long as the start-bit comes after position a for OVS=0 and OVS=3, and b for OVS=1 and OVS=2.



**Figure 18.8. USART Sampling of Stop Bits when Number of Stop Bits are 1 or More**

When working with stop bit lengths of half a baud period, the above sampling scheme no longer suffices. In this case, the stop-bit is not sampled, and no framing error is generated in the receiver if the stop-bit is not generated. The line must still be driven high before the next start bit however for the USART to successfully identify the start bit.

#### 18.3.2.12 Parity Error

When parity bits are enabled, a parity check is automatically performed on incoming frames. When a parity error is detected in an incoming frame, the data parity error bit PERR in the frame is set, as well as the interrupt flag PERR in USARTn\_IF. Frames with parity errors are loaded into the receive buffer like regular frames.

PERR can be accessed by reading the frame from the receive buffer using the USARTn\_RXDATAx, USARTn\_RXDATAxP, USARTn\_RXDOUBLEx or USARTn\_RXDOUBLExP registers.

If ERRSTX in USARTn\_CTRL is set, the transmitter is disabled on received parity and framing errors. If ERRSRX in USARTn\_CTRL is set, the receiver is disabled on parity and framing errors.

#### 18.3.2.13 Framing Error and Break Detection

A framing error is the result of an asynchronous frame where the stop bit was sampled to a value of 0. This can be the result of noise and baud rate errors, but can also be the result of a break generated by the transmitter on purpose.


When a framing error is detected in an incoming frame, the framing error bit FERR in the frame is set. The interrupt flag FERR in USARTn\_IF is also set. Frames with framing errors are loaded into the receive buffer like regular frames.

FERR can be accessed by reading the frame from the receive buffer using the USARTn\_RXDATAx, USARTn\_RXDATAxP, USARTn\_RXDOUBLEx or USARTn\_RXDOUBLExP registers.

If ERRSTX in USARTn\_CTRL is set, the transmitter is disabled on parity and framing errors. If ERRSRX in USARTn\_CTRL is set, the receiver is disabled on parity and framing errors.

### 18.3.2.14 Local Loopback

The USART receiver samples U(S)n\_RX by default, and the transmitter drives U(S)n\_TX by default. This is not the only option however. When LOOPBK in USARTn\_CTRL is set, the receiver is connected to the U(S)n\_TX pin as shown in [Figure 18.9 USART Local Loopback on page 617](#). This is useful for debugging, as the USART can receive the data it transmits, but it is also used to allow the USART to read and write to the same pin, which is required for some half duplex communication modes. In this mode, the U(S)n\_TX pin must be enabled as an output in the GPIO.



**Figure 18.9. USART Local Loopback**

### 18.3.2.15 Asynchronous Half Duplex Communication

When doing full duplex communication, two data links are provided, making it possible for data to be sent and received at the same time. In half duplex mode, data is only sent in one direction at a time. There are several possible half duplex setups, as described in the following sections.

### 18.3.2.16 Single Data-link

In this setup, the USART both receives and transmits data on the same pin. This is enabled by setting LOOPBK in USARTn\_CTRL, which connects the receiver to the transmitter output. Because they are both connected to the same line, it is important that the USART transmitter does not drive the line when receiving data, as this would corrupt the data on the line.

When communicating over a single data-link, the transmitter must thus be tristated whenever not transmitting data. This is done by setting the command bit TXTRIEN in USARTn\_CMD, which tristates the transmitter. Before transmitting data, the command bit TXTRI-DIS, also in USARTn\_CMD, must be set to enable transmitter output again. Whether or not the output is tristated at a given time can be read from TXTRI in USARTn\_STATUS. If TXTRI is set when transmitting data, the data is shifted out of the shift register, but is not put out on U(S)n\_TX.

When operating a half duplex data bus, it is common to have a bus master, which first transmits a request to one of the bus slaves, then receives a reply. In this case, the frame transmission control bits, which can be set by writing to USARTn\_TXDATAX, can be used to make the USART automatically disable transmission, tristate the transmitter and enable reception when the request has been transmitted, making it ready to receive a response from the slave.

The timer, [18.3.10 Timer](#), can also be used to add delay between the RX and TX frames so that the interrupt service routine has time to process data that was just received before transmitting more data. Also hardware flow control is another method to insert time for processing the frame. RTS and CTS can be used to halt either the link partner's transmitter or the local transmitter. See the section on hardware flow control, [18.3.4 Hardware Flow Control](#), for more details.

Tristating the transmitter can also be performed automatically by the USART by using AUTOTRI in USARTn\_CTRL. When AUTOTRI is set, the USART automatically tristates U(S)n\_TX whenever the transmitter is idle, and enables transmitter output when the transmitter goes active. If AUTOTRI is set TXTRI is always read as 0.

**Note:** Another way to tristate the transmitter is to enable wired-and or wired-or mode in GPIO. For wired-and mode, outputting a 1 will be the same as tristating the output, and for wired-or mode, outputting a 0 will be the same as tristating the output. This can only be done on buses with a pull-up or pull-down resistor respectively.

### 18.3.2.17 Single Data-link With External Driver


Some communication schemes, such as RS-485 rely on an external driver. Here, the driver has an extra input which enables it, and instead of tristating the transmitter when receiving data, the external driver must be disabled.

This can be done manually by assigning a GPIO to turn the driver on or off, or it can be handled automatically by the USART. If AUTOCS in USARTn\_CTRL is set, the USn\_CS output is automatically activated a configurable number of baud periods before the transmitter starts transmitting data, and deactivated a configurable number of baud periods after the last bit has been transmitted and there is no more data in the transmit buffer to transmit. The number of baud periods are controlled by CSSETUP and CSHOLD in USARTn\_TIMING. This feature can be used to turn the external driver on when transmitting data, and turn it off when the data has been transmitted.

The timer, [18.3.10 Timer](#), can also be used to configure CSSETUP and CSHOLD values between 1 to 256 baud-times by using TCMPVAL0, TCMPVAL1, or TCMPVAL2 for the TX sequencer.

USn\_CS is immediately deasserted when the transmitter becomes disabled.

[Figure 18.10 USART Half Duplex Communication with External Driver on page 618](#) shows an example configuration where USn\_CS is used to automatically enable and disable an external driver.



**Figure 18.10. USART Half Duplex Communication with External Driver**

The USn\_CS output is active low by default, but its polarity can be changed with CSINV in USARTn\_CTRL. AUTOCS works regardless of which mode the USART is in, so this functionality can also be used for automatic chip/slave select when in synchronous mode (e.g. SPI).

### 18.3.2.18 Two Data-links

Some limited devices only support half duplex communication even though two data links are available. In this case software is responsible for making sure data is not transmitted when incoming data is expected.


TXARXnEN in USARTn\_TRIGCTRL may be used to automatically start transmission after the end of the RX frame plus any TXSTDELAY and CSSETUP delay in USARTn\_TIMING. For enabling the receiver either use RXENAT in USARTn\_TXDATAx or RXATXnEN in USARTn\_TRIGCTRL.

### 18.3.2.19 Large Frames

As each frame in the transmit and receive buffers holds a maximum of 9 bits, both the elements in the buffers are combined when working with USART-frames of 10 or more data bits.

To transmit such a frame, at least two elements must be available in the transmit buffer. If only one element is available, the USART will wait for the second element before transmitting the combined frame. Both the elements making up the frame are consumed when transmitting such a frame.


When using large frames, the 9th bits in the buffers are unused. For an 11 bit frame, the 8 least significant bits are thus taken from the first element in the buffer, and the 3 remaining bits are taken from the second element as shown in [Figure 18.11 USART Transmission of Large Frames on page 619](#). The first element in the transmit buffer, i.e. element 0 in [Figure 18.11 USART Transmission of Large Frames on page 619](#) is the first element written to the FIFO, or the least significant byte when writing two bytes at a time using USARTn\_TXDOUBLE.



**Figure 18.11. USART Transmission of Large Frames**

As shown in [Figure 18.11 USART Transmission of Large Frames on page 619](#), frame transmission control bits are taken from the second element in FIFO.

The two buffer elements can be written at the same time using the USARTn\_TXDOUBLE or USARTn\_TXDOUBLEX register. The TXDATAx0 bitfield then refers to buffer element 0, and TXDATAx1 refers to buffer element 1.




**Figure 18.12. USART Transmission of Large Frames, MSBF**

[Figure 18.12 USART Transmission of Large Frames, MSBF on page 619](#) illustrates the order of the transmitted bits when an 11 bit frame is transmitted with MSBF set. If MSBF is set and the frame is smaller than 10 bits, only the contents of transmit buffer 0 will be transmitted.

When receiving a large frame, BYTESWAP in USARTn\_CTRL determines the order the way the large frame is split into the two buffer elements. If BYTESWAP is cleared, the least significant 8 bits of the received frame are loaded into the first element of the receive buffer, and the remaining bits are loaded into the second element, as shown in [Figure 18.13 USART Reception of Large Frames on page 620](#). The first byte read from the buffer thus contains the 8 least significant bits. Set BYTESWAP to reverse the order.

The status bits are loaded into both elements of the receive buffer. The frame is not moved from the receive shift register before there are two free spaces in the receive buffer.



**Figure 18.13. USART Reception of Large Frames**

The two buffer elements can be read at the same time using the USARTn\_RXDOUBLE or USARTn\_RXDOUBLEX register. RXDATA0 then refers to buffer element 0 and RXDATA1 refers to buffer element 1.

Large frames can be used in both asynchronous and synchronous modes.

#### 18.3.2.20 Multi-Processor Mode

To simplify communication between multiple processors, the USART supports a special multi-processor mode. In this mode the 9th data bit in each frame is used to indicate whether the content of the remaining 8 bits is data or an address.

When multi-processor mode is enabled, an incoming 9-bit frame with the 9th bit equal to the value of MPAB in USARTn\_CTRL is identified as an address frame. When an address frame is detected, the MPAF interrupt flag in USARTn\_IF is set, and the address frame is loaded into the receive register. This happens regardless of the value of RXBLOCK in USARTn\_STATUS.

Multi-processor mode is enabled by setting MPM in USARTn\_CTRL, and the value of the 9th bit in address frames can be set in MPAB. Note that the receiver must be enabled for address frames to be detected. The receiver can be blocked however, preventing data from being loaded into the receive buffer while looking for address frames.

Basic usage of the multi-processor mode is as follows:

1. All slaves enable multi-processor mode and, enable and block the receiver. They will now not receive data unless it is an address frame. MPAB in USARTn\_CTRL is set to identify frames with the 9th bit high as address frames.
2. The master sends a frame containing the address of a slave and with the 9th bit set
3. All slaves receive the address frame and get an interrupt. They can read the address from the receive buffer. The selected slave unblocks the receiver to start receiving data from the master.
4. The master sends data with the 9th bit cleared
5. Only the slave with RX enabled receives the data. When transmission is complete, the slave blocks the receiver and waits for a new address frame.

When a slave has received an address frame and wants to receive the following data, it must make sure the receiver is unblocked before the next frame has been completely received in order to prevent data loss.

BIT8DV in USARTn\_CTRL can be used to specify the value of the 9th bit without writing to the transmit buffer with USARTn\_TXDATAx or USARTn\_RXDOUBLEX, giving higher efficiency in multi-processor mode, as the 9th bit is only set when writing address frames, and 8-bit writes to the USART can be used when writing the data frames.

### 18.3.2.21 Collision Detection

The USART supports a basic form of collision detection. When the receiver is connected to the output of the transmitter, either by using the LOOPBK bit in USARTn\_CTRL or through an external connection, this feature can be used to detect whether data transmitted on the bus by the USART did get corrupted by a simultaneous transmission by another device on the bus.

For collision detection to be enabled, CCEN in USARTn\_CTRL must be set, and the receiver enabled. The data sampled by the receiver is then continuously compared with the data output by the transmitter. If they differ, the CCF interrupt flag in USARTn\_IF is set. The collision check includes all bits of the transmitted frames. The CCF interrupt flag is set once for each bit sampled by the receiver that differs from the bit output by the transmitter. When the transmitter output is disabled, i.e. the transmitter is tristated, collisions are not registered.


### 18.3.2.22 SmartCard Mode

In SmartCard mode, the USART supports the ISO 7816 I/O line T0 mode. With exception of the stop-bits (guard time), the 7816 data frame is equal to the regular asynchronous frame. In this mode, the receiver pulls the line low for one baud, half a baud into the guard time to indicate a parity error. This NAK can for instance be used by the transmitter to re-transmit the frame. SmartCard mode is a half duplex asynchronous mode, so the transmitter must be tristated whenever not transmitting data.

To enable SmartCard mode, set SCMODE in USARTn\_CTRL, set the number of databits in a frame to 8, and configure the number of stopbits to 1.5 by writing to STOPBITS in USARTn\_FRAME.


The SmartCard mode relies on half duplex communication on a single line, so for it to work, both the receiver and transmitter must work on the same line. This can be achieved by setting LOOPBK in USARTn\_CTRL or through an external connection. The TX output should be configured as open-drain in the GPIO module.

When no parity error is identified by the receiver, the data frame is as shown in [Figure 18.14 USART ISO 7816 Data Frame Without Error on page 622](#). The frame consists of 8 data bits, a parity bit, and 2 stop bits. The transmitter does not drive the output line during the guard time.



**Figure 18.14. USART ISO 7816 Data Frame Without Error**

If a parity error is detected by the receiver, it pulls the line I/O line low after half a stop bit, see [Figure 18.15 USART ISO 7816 Data Frame With Error on page 622](#). It holds the line low for one bit-period before it releases the line. In this case, the guard time is extended by one bit period before a new transmission can start, resulting in a total of 3 stop bits.




**Figure 18.15. USART ISO 7816 Data Frame With Error**

On a parity error, the NAK is generated by hardware. The NAK generated by the receiver is sampled as the stop-bit of the frame. Because of this, parity errors when in SmartCard mode are reported with both a parity error and a framing error.

When transmitting a T0 frame, the USART receiver on the transmitting side samples position 16, 17 and 18 in the stop-bit to detect the error signal when in 16x oversampling mode as shown in [Figure 18.16 USART SmartCard Stop Bit Sampling on page 623](#). Sampling at this location places the stop-bit sample in the middle of the bit-period used for the error signal (NAK).

If a NAK is transmitted by the receiver, it will thus appear as a framing error at the transmitter, and the FERR interrupt flag in USARTn\_IF will be set. If SCRETRANS USARTn\_CTRL is set, the transmitter will automatically retransmit a NACK'ed frame. The transmitter will retransmit the frame until it is ACK'ed by the receiver. This only works when the number of databits in a frame is configured to 8.

Set SKIPPERRF in USARTn\_CTRL to make the receiver discard frames with parity errors. The PERR interrupt flag in USARTn\_IF is set when a frame is discarded because of a parity error.



**Figure 18.16. USART SmartCard Stop Bit Sampling**

For communication with a SmartCard, a clock signal needs to be generated for the card. This clock output can be generated using one of the timers. See the ISO 7816 specification for more info on this clock signal.

SmartCard T1 mode is also supported. The T1 frame format used is the same as the asynchronous frame format with parity bit enabled and one stop bit. The USART must then be configured to operate in asynchronous half duplex mode.

### 18.3.3 Synchronous Operation

Most of the features in asynchronous mode are available in synchronous mode. Multi-processor mode can be enabled for 9-bit frames, loopback is available and collision detection can be performed.

#### 18.3.3.1 Frame Format

The frames used in synchronous mode need no start and stop bits since a single clock is available to all parts participating in the communication. Parity bits cannot be used in synchronous mode.

The USART supports frame lengths of 4 to 16 bits per frame. Larger frames can be simulated by transmitting multiple smaller frames, i.e. a 22 bit frame can be sent using two 11-bit frames, and a 21 bit frame can be generated by transmitting three 7-bit frames. The number of bits in a frame is set using DATABITS in USARTn\_FRAME.

The frames in synchronous mode are by default transmitted with the least significant bit first like in asynchronous mode. The bit-order can be reversed by setting MSBF in USARTn\_CTRL.

The frame format used by the transmitter can be inverted by setting TXINV in USARTn\_CTRL, and the format expected by the receiver can be inverted by setting RXINV, also in USARTn\_CTRL.

### 18.3.3.2 Clock Generation

**Note:** Not all USART instances are using the same peripheral clock. Normally the USART uses HFFPERCLK<sub>USARTn</sub>, however USART2 supports higher frequencies and therefore uses HFFPERBCLK<sub>USART2</sub>. This chapter describes the general case and therefore uses HFFPERCLK<sub>USARTn</sub> and f<sub>HFFPERCLK</sub>, which should be interpreted as HFFPERBCLK<sub>USARTn</sub> and f<sub>HFFPERBCLK</sub> for USART2. [10.3.1.4 HFFPERCLK, HFFPERBCLK, HFFPERCCLK - High Frequency Peripheral Clocks](#) shows which peripheral uses what peripheral clock.

The bit-rate in synchronous mode is given by [Figure 18.17 USART Synchronous Mode Bit Rate on page 624](#). As in the case of asynchronous operation, the clock division factor have a 15-bit integral part and a 5-bit fractional part.

$$br = f_{HFFPERCLK} / (2 \times (1 + USARTn\_CLKDIV/256))$$

**Figure 18.17. USART Synchronous Mode Bit Rate**

Given a desired baud rate brdesired, the clock divider USARTn\_CLKDIV can be calculated using [Figure 18.18 USART Synchronous Mode Clock Division Factor on page 624](#)

$$USARTn\_CLKDIV = 256 \times (f_{HFFPERCLK} / (2 \times brdesired) - 1)$$

**Figure 18.18. USART Synchronous Mode Clock Division Factor**


When the USART operates in master mode, the highest possible bit rate is half the peripheral clock rate. When operating in slave mode however, the highest bit rate is an eighth of the peripheral clock:

- Master mode: br<sub>max</sub> = f<sub>HFFPERCLK</sub>/2
- Slave mode: br<sub>max</sub> = f<sub>HFFPERCLK</sub>/8

On every clock edge data on the data lines, MOSI and MISO, is either set up or sampled. When CLKPHA in USARTn\_CTRL is cleared, data is sampled on the leading clock edge and set-up is done on the trailing edge. If CLKPHA is set however, data is set-up on the leading clock edge, and sampled on the trailing edge. In addition to this, the polarity of the clock signal can be changed by setting CLKPOL in USARTn\_CTRL, which also defines the idle state of the clock. This results in four different modes which are summarized in [Table 18.8 USART SPI Modes on page 624](#). [Figure 18.19 USART SPI Timing on page 625](#) shows the resulting timing of data set-up and sampling relative to the bus clock.

**Table 18.8. USART SPI Modes**

SPI mode	CLKPOL	CLKPHA	Leading Edge	Trailing Edge
0	0	0	Rising, sample	Falling, set-up
1	0	1	Rising, set-up	Falling, sample
2	1	0	Falling, sample	Rising, set-up
3	1	1	Falling, set-up	Rising, sample



**Figure 18.19. USART SPI Timing**

If CPHA=1, the TX underflow flag, TXUF, will be set on the first setup clock edge of a frame in slave mode if TX data is not available. If CPHA=0, TXUF is set if data is not available in the transmit buffer three HPERCLK cycles prior to the first sample clock edge. The RXDATAV flag is updated on the last sample clock edge of a transfer, while the RX overflow interrupt flag, RXOF, is set on the first sample clock edge if the receive buffer overflows. When a transfer has been performed, interrupt flags TXBL and TXC are updated on the first setup clock edge of the succeeding frame, or when CS is deasserted.

#### 18.3.3.3 Master Mode

When in master mode, the USART is in full control of the data flow on the synchronous bus. When operating in full duplex mode, the slave cannot transmit data to the master without the master transmitting to the slave. The master outputs the bus clock on **USn\_CLK**.

Communication starts whenever there is data in the transmit buffer and the transmitter is enabled. The USART clock then starts, and the master shifts bits out from the transmit shift register using the internal clock.

When there are no more frames in the transmit buffer and the transmit shift register is empty, the clock stops, and communication ends. When the receiver is enabled, it samples data using the internal clock when the transmitter transmits data. Operation of the RX and TX buffers is as in asynchronous mode.

#### 18.3.3.4 Operation of **USn\_CS** Pin

When operating in master mode, the **USn\_CS** pin can have one of two functions, or it can be disabled.

If **USn\_CS** is configured as an output, it can be used to automatically generate a chip select for a slave by setting **AUTOCS** in **USARTn\_CTRL**. If **AUTOCS** is set, **USn\_CS** is activated before a transmission begins, and deactivated after the last bit has been transmitted and there is no more data in the transmit buffer.

The time between when CS is asserted and the first bit is transmitted can be controlled using the USART Timer and with **CSSETUP** in **USARTn\_TIMING**. Any of the three comparators can be used to set this delay. If new data is ready for transmission before CS is deasserted, the data is sent without deasserting CS in between. **CSHOLD** in **USARTn\_TIMING** keeps CS asserted after the end of frame for the number of baud-times specified.

By default, **USn\_CS** is active low, but its polarity can be inverted by setting **CSINV** in **USARTn\_CTRL**.

When **USn\_CS** is configured as an input, it can be used by another master that wants control of the bus to make the USART release it. When **USn\_CS** is driven low, or high if **CSINV** is set, the interrupt flag **SSM** in **USARTn\_IF** is set, and if **CSMA** in **USARTn\_CTRL** is set, the USART goes to slave mode.

### 18.3.3.5 AUTOTX

A synchronous master is required to transmit data to a slave in order to receive data from the slave. In some cases, only a few words are transmitted and a lot of data is then received from the slave. In that case, one solution is to keep feeding the TX with data to transmit, but that consumes system bandwidth. Instead AUTOTX can be used.

When AUTOTX in USARTn\_CTRL is set, the USART transmits data as long as there is available space in the RX shift register for the chosen frame size. This happens even though there is no data in the TX buffer. The TX underflow interrupt flag TXUF in USARTn\_IF is set on the first word that is transmitted which does not contain valid data.

During AUTOTX the USART will always send the previous sent bit, thus reducing the number of transitions on the TX output. So if the last bit sent was a 0, 0's will be sent during AUTOTX and if the last bit sent was a 1, 1's will be sent during AUTOTX.

### 18.3.3.6 Slave Mode

When the USART is in slave mode, data transmission is not controlled by the USART, but by an external master. The USART is therefore not able to initiate a transmission, and has no control over the number of bytes written to the master.

The output and input to the USART are also swapped when in slave mode, making the receiver take its input from USn\_TX (MOSI) and the transmitter drive USn\_RX (MISO).

To transmit data when in slave mode, the slave must load data into the transmit buffer and enable the transmitter. The data will remain in the USART until the master starts a transmission by pulling the USn\_CS input of the slave low and transmitting data. For every frame the master transmits to the slave, a frame is transferred from the slave to the master. After a transmission, MISO remains in the same state as the last bit transmitted. This also applies if the master transmits to the slave and the slave TX buffer is empty.

If the transmitter is enabled in synchronous slave mode and the master starts transmission of a frame, the underflow interrupt flag TXUF in USARTn\_IF will be set if no data is available for transmission to the master.

If the slave needs to control its own chip select signal, this can be achieved by clearing CSPEN in the ROUTE register. The internal chip select signal can then be controlled through CSINV in the CTRL register. The chip select signal will be CSINV inverted, i.e. if CSINV is cleared, the chip select is active and vice versa.

### 18.3.3.7 Synchronous Half Duplex Communication

Half duplex communication in synchronous mode is very similar to half duplex communication in asynchronous mode as detailed in [18.3.2.15 Asynchronous Half Duplex Communication](#). The main difference is that in this mode, the master must generate the bus clock even when it is not transmitting data, i.e. it must provide the slave with a clock to receive data. To generate the bus clock, the master should transmit data with the transmitter tristated, i.e. TXTRI in USARTn\_STATUS set, when receiving data. If 2 bytes are expected from the slave, then transmit 2 bytes with the transmitter tristated, and the slave uses the generated bus clock to transmit data to the master. TXTRI can be set by setting the TXTRIEN command bit in USARTn\_CMD.

**Note:** When operating as SPI slave in half duplex mode, TX has to be tristated (not disabled) during data reception if the slave is to transmit data in the current transfer.

### 18.3.3.8 I2S

I2S is a synchronous format for transmission of audio data. The frame format is 32-bit, but since data is always transmitted with MSB first, an I2S device operating with 16-bit audio may choose to only process the 16 msb of the frame, and only transmit data in the 16 msb of the frame.

In addition to the bit clock used for regular synchronous transfers, I2S mode uses a separate word clock. When operating in mono mode, with only one channel of data, the word clock pulses once at the start of each new word. In stereo mode, the word clock toggles at the start of new words, and also gives away whether the transmitted word is for the left or right audio channel; A word transmitted while the word clock is low is for the left channel, and a word transmitted while the word clock is high is for the right.

When operating in I2S mode, the CS pin is used as the word clock. In master mode, this is automatically driven by the USART, and in slave mode, the word clock is expected from an external master.

### 18.3.3.9 Word Format

The general I<sup>2</sup>S word format is 32 bits wide, but the USART also supports 16-bit and 8-bit words. In addition to this, it can be specified how many bits of the word should actually be used by the USART. These parameters are given by FORMAT in USARTn\_I2SCTRL.

As an example, configuring FORMAT to using a 32-bit word with 16-bit data will make each word on the I<sup>2</sup>S bus 32-bits wide, but when receiving data through the USART, only the 16 most significant bits of each word can be read out of the USART. Similarly, only the 16 most significant bits have to be written to the USART when transmitting. The rest of the bits will be transmitted as zeroes.

### 18.3.3.10 Major Modes


The USART supports a set of different I2S formats as shown in [Table 18.9 USART I2S Modes on page 628](#), but it is not limited to these modes. MONO, JUSTIFY and DELAY in USARTn\_I2SCTRL can be mixed and matched to create an appropriate format. MONO enables mono mode, i.e. one data stream instead of two which is the default. JUSTIFY aligns data within a word on the I2S bus, either left or right which can be seen in figures [Figure 18.22 USART Left-Justified I2S Waveform on page 629](#) and [Figure 18.23 USART Right-Justified I2S Waveform on page 629](#). Finally, DELAY specifies whether a new I2S word should be started directly on the edge of the word-select signal, or one bit-period after the edge.

**Table 18.9. USART I2S Modes**


Mode	MONO	JUSTIFY	DELAY	CLKPOL
Regular I2S	0	0	1	0
Left-Justified	0	0	0	1
Right-Justified	0	1	0	1
Mono	1	0	0	0

The regular I2S waveform is shown in [Figure 18.20 USART Standard I2S Waveform on page 628](#) and [Figure 18.21 USART Standard I2S Waveform \(Reduced Accuracy\) on page 628](#). The first figure shows a waveform transmitted with full accuracy. The wordlength can be configured to 32-bit, 16-bit or 8-bit using FORMAT in USARTn\_I2SCTRL. In the second figure, I2S data is transmitted with reduced accuracy, i.e. the data transmitted has less bits than what is possible in the bus format.

Note that the msb of a word transmitted in regular I2S mode is delayed by one cycle with respect to word select




**Figure 18.20. USART Standard I2S Waveform**




**Figure 18.21. USART Standard I2S Waveform (Reduced Accuracy)**

A left-justified stream is shown in [Figure 18.22 USART Left-Justified I2S Waveform on page 629](#). Note that the MSB comes directly after the edge on the word-select signal in contradiction to the regular I2S waveform where it comes one bit-period after.




**Figure 18.22. USART Left-Justified I2S Waveform**

A right-justified stream is shown in [Figure 18.23 USART Right-Justified I2S Waveform on page 629](#). The left and right justified streams are equal when the data-size is equal to the word-width.



**Figure 18.23. USART Right-Justified I2S Waveform**

In mono-mode, the word-select signal pulses at the beginning of each word instead of toggling for each word. Mono I2S waveform is shown in [Figure 18.24 USART Mono I2S Waveform on page 629](#).



**Figure 18.24. USART Mono I2S Waveform**

### 18.3.3.11 Using I2S Mode

When using the USART in I2S mode, DATABITS in USARTn\_FRAME must be set to 8 or 16 data-bits. 8 databits can be used in all modes, and 16 can be used in the modes where the number of bytes in the I2S word is even. In addition to this, MSBF in USARTn\_CTRL should be set, and CLKPOL and CLKPHA in USARTn\_CTRL should be cleared.

The USART does not have separate TX and RX buffers for left and right data, so when using I2S in stereo mode, the application must keep track of whether the buffers contain left or right data. This can be done by observing TXBLRIGHT, RXDATAVRIGHT and RXFULLRIGHT in USARTn\_STATUS. TXBLRIGHT tells whether TX is expecting data for the left or right channel. It will be set with TXBL if right data is expected. The receiver will set RXDATAVRIGHT if there is at least one right element in the buffer, and RXFULLRIGHT if the buffer is full of right elements.

When using I2S with DMA, separate DMA requests can be used for left and right data by setting DMASPLIT in USARTn\_I2SCTRL.

In both master and slave mode the USART always starts transmitting on the LEFT channel after being enabled. In master mode, the transmission will stop if TX becomes empty. In that case, TXC is set. Continuing the transmission in this case will make the data-stream continue where it left off. To make the USART start on the LEFT channel after going empty, disable and re-enable TX.

### 18.3.4 Hardware Flow Control

Hardware flow control can be used to hold off the link partner's transmission until RX buffer space is available. Use RTSPEN and CTSLEN in USARTn\_ROUTEPEN to allocate the hardware flow control to GPIOs. RTS is an out going signal which indicates that RX buffer space is available to receive a frame. The link partner is being requested to send its data when RTS is asserted. CTS is an incoming signal to stop the next TX data from going out. When CTS is negated, the frame currently being transmitted is completed before stopping. CTS indicates that the link partner has RX buffer space available, and the local transmitter is clear to send. Also use CTSEN in USARTn\_CTRLX to enable the CTS input into the TX sequencer. For debug use set DBGHALT in USARTn\_CTRLX which will force the RTS to request one frame from the link partner when the CPU core single steps.

### 18.3.5 Debug Halt

When DBGHALT in USART\_CTRLX is clear, RTS is only dependent on the RX buffer having space available to receive data. Incoming data is always received until both the RX buffer is full and the RX shift register is full regardless of the state of DBGHALT or chip halt. Additional incoming data is discarded. When DBGHALT is set, RTS deasserts on RX buffer full or when chip halt is high. However, a low pulse detected on chip halt will keep RTS asserted when no frame is being received. At the start of frame reception, RTS will deassert if chip halt is high and DBGHALT is set. This behavior allows single stepping to pulse the chip halt low for a cycle, and receive the next frame. The link partner must stop transmitting when RTS is deasserted, or the RX buffer could overflow. All data in the transmit buffer is sent out even when chip halt is asserted; therefore, the DMA will need to be set to stop sending the USART TX data during chip halt.

### 18.3.6 PRS-triggered Transmissions

If a transmission must be started on an event with very little delay, the PRS system can be used to trigger the transmission. The PRS channel to use as a trigger can be selected using TSEL in USARTn\_TRIGCTRL. When a positive edge is detected on this signal, the receiver is enabled if RXTEN in USARTn\_TRIGCTRL is set, and the transmitter is enabled if TXTEN in USARTn\_TRIGCTRL is set. Only one signal input is supported by the USART.

The AUTOTX feature can also be enabled via PRS. If an external SPI device sets a pin high when there is data to be read from the device, this signal can be routed to the USART through the PRS system and be used to make the USART clock data out of the external device. If AUTOTXTEN in USARTn\_TRIGCTRL is set, the USART will transmit data whenever the PRS signal selected by TSEL is high given that there is enough room in the RX buffer for the chosen frame size. Note that if there is no data in the TX buffer when using AUTOTX, the TX underflow interrupt will be set.

AUTOTXTEN can also be combined with TXTEN to make the USART transmit a command to the external device prior to clocking out data. To do this, disable TX using the TXDIS command, load the TX buffer with the command and enable AUTOTXTEN and TXTEN. When the selected PRS input goes high, the USART will now transmit the loaded command, and then continue clocking out while both the PRS input is high and there is room in the RX buffer.

### 18.3.7 PRS RX Input

The USART can be configured to receive data directly from a PRS channel by setting RXPRS in USARTn\_INPUT. The PRS channel used is selected using RXPRSEL in USARTn\_INPUT. This way, for example, a differential RX signal can be input to the ACMP and the output routed via PRS to the USART.

### 18.3.8 PRS CLK Input

The USART can be configured to receive clock directly from a PRS channel by setting CLKPRS in USARTn\_INPUT. The PRS channel used is selected using CLKPRSSEL in USARTn\_INPUT. This is useful in synchronous slave mode and can together with RX PRS input be used to input data from PRS.

### 18.3.9 DMA Support

The USART has full DMA support. The DMA controller can write to the transmit buffer using the registers USARTn\_TXDATA, USARTn\_TXDATAX, USARTn\_TXDOUBLE and USARTn\_RXDOUBLE, and it can read from the receive buffer using the registers USARTn\_RXDATA, USARTn\_RXDATAX, USARTn\_RXDOUBLE and USARTn\_RXDOUBLEX. This enables single byte transfers, 9 bit data + control/status bits, double byte and double byte + control/status transfers both to and from the USART.

A request for the DMA controller to read from the USART receive buffer can come from the following source:

- Data available in the receive buffer
- Data available in the receive buffer and data is for the RIGHT I2S channel. Only used in I2S mode.

A write request can come from one of the following sources:

- Transmit buffer and shift register empty. No data to send.
- Transmit buffer has room for more data. This does not check the TXBIL for half full. For DMA use, it is either full or empty.
- Transmit buffer has room for RIGHT I2S data. Only used in I2S mode

Even though there are two sources for write requests to the DMA, only one should be used at a time, since the requests from both sources are cleared even though only one of the requests are used.

In some cases, it may be sensible to temporarily stop DMA access to the USART when an error such as a framing error has occurred. This is enabled by setting ERRSDMA in USARTn\_CTRL.

For Synchronous mode full duplex operation, if both receive buffer and transmit buffer are served by DMA, to make sure receive buffer is not overflowed the settings below should be followed.


- The DMA channel that serves receive buffer should have higher priority than the DMA channel that serves transmit buffer.
- TXBL should be used as write request for transmit buffer DMA channel.
- IGNORESREQ should be set for both DMA channel.

### 18.3.10 Timer

In addition to the TX sequence timer, there is a versatile 8 bit timer that can generate up to three event pulses. These pulses can be used to create timing for a variety of uses such as RX timeout, break detection, response timeout, and RX enable delay. Transmission delay, CS setup, inter-character spacing, and CS hold use the TX sequence counter. The TX sequencer counter can use the three 8 bit compare values or preset values for delays. There is one general counter with three comparators. Each comparator has a start source, a stop source, a restart enable, and a timer compare value. The start source enables the comparator, resets the counter, and starts the counter. If the counter is already running, the start source will reset the counter and restart it.

Any comparator could start the counter using the same start source but have different timing events programmed into TCMPVALn in USARTn\_TIMECMPn. The TCMP0, TCMP1, or TCMP2 events can be preempted by using the comparator stop source to disable the comparator before the counter reaches TCMPVAL0, TCMPVAL1, or TCMPVAL2. If one comparator gets disabled while the other comparator is still enabled, the counter continues counting. By default the counter will count up to 256 and stop unless a RESTARTEN is set in one of the USARTn\_TIMECMPn registers. By using RESTARTEN and an interval programmed into TCMPVAL, an interval timer can be set up. The TSTART field needs to be changed to DISABLE to stop the interval timer. The timer stops running once all of the comparators are disabled. If a comparator's start and stop sources both trigger the same cycle, the TCMPn event triggers, the comparator stays enabled, and the counter begins counting from zero.

The TXDELAY, CSSETUP, ICS, and CSHOLD in USARTn\_TIMING are used to program start of transmission delay, chip select setup delay, inter-character space, and chip select hold delay. Either a preset value of 0, 1, 2, 3, or 7 can be used for any of these delays; or the value in TCMPVALn may be used to set the delay. Using the preset values leaves the TCMPVALn free for other uses. The same TCMPVALn may be used for multiple events that require the same timing. The transmit sequencer's counter can run in parallel with the timer's counter. The counters and controls are shown in [Figure 18.25 USART Timer Block Diagram on page 633](#).

**Figure 18.25. USART Timer Block Diagram**

The following sections will go into more details on programming the various usage cases.

**Table 18.10. USART Application Settings for USARTn\_TIMING and USARTn\_TIMECMPn**

Application	TSTARTn	TSTOPn	TCMPVALn	Other
Response Timeout	TSTART0 = TXEOF	TSTOP0 = RXACT	TCMPVAL0 = 0x08	TCMP0 in USARTn_IEN
Receiver Timeout	TSTART1 = RXEOF	TSTOP1 = RXACT	TCMPVAL1 = 0x08	TCMP1 in USARTn_IEN
Large Receiver Timeout	TSTART1 = RXEOF, TCMP1	TSTOP1 = RXACT	TCMPVAL1 = 0xFF	TCMP1 in USARTn_IEN; TIME-RRESTARTED in USARTn_STATUS; RESTART1EN in USARTn_TIMECMP1

Application	TSTARTn	TSTOPn	TCMPVALn	Other
Break Detect	TSTART1 = RXACT	TSTOP1 = RXACTN	TCMPVAL1 = 0x0C	TCMP1 in USARTn_IEN
TX delayed start of transmission and CS setup	TSTART0 = DISABLE, TSTART1 = DISABLE	TSTOP0 = TCMP0, TSTOP1 = TCMP1	TCMPVAL0 = 0x04, TCMPVAL1 = 0x02	TXDELAY = TCMP0, CSSETUP = TCMP1 in USARTn_TIMING; AUTOCS in USARTn_CTRL
TX inter-character spacing	TSTART2 = DISABLE	TSTOP2 = TCMP2	TCMPVAL2 = 0x03	ICS = TCMP2 in USARTn_TIMING; AUTOCS in USARTn_CTRL
TX Chip Select End Delay	TSTART1 = DISABLE	TSTOP1 = TCMP1	TCMPVAL1 = 0x04	CSHOLD = TCMP1 in USARTn_TIMING; AUTOCS in USARTn_CTRL
Response Delay	TSTART1 = RXEOF	TSTOP1 = TCMP1	TCMPVAL1 = 0x08	TXARX1EN in USARTn_TRIGCTRL
Combined TX and RX Example	TSTART1 = RXEOF, TSTART0 = TXEOF	TSTOP1 = TCMP1, TSTOP0 = TCMP0	TCMPVAL1 = 0x1C, TCMPVAL0 = 0x10	TXARX1EN, RXATX0EN in USARTn_TRIGCTRL; CSSETUP = 0x7, CSHOLD = 0x3 in USARTn_TIMING
Combined Delayed TX and Receiver Timeout Example	TSTART0 = TCMPVAL0, TSTART1 = RXEOF	TSTOP0 = RXACTN, TSTOP1 = RXACT	TCMPVAL0 = 0x20, TCMPVAL1 = 0x0C	TXARX0EN in USARTn_TRIGCTRL; TCMP0 in USARTn_IEN

Table 18.10 USART Application Settings for USARTn\_TIMING and USARTn\_TIMECMPn on page 633 shows some examples of how the USART timer can be programmed for various applications. The following sections will describe more details for each applications shown in the table.

#### 18.3.10.1 Response Timeout

Response Timeout is when a UART master sends a frame and expects the slave to respond within a certain number of baud-times. Refer to Table 18.10 USART Application Settings for USARTn\_TIMING and USARTn\_TIMECMPn on page 633 for specific register settings. Comparator 0 will be looking for TX end of frame to use as the timer start source. For this example, a receiver start of frame RXACT has not been detected for 8 baud-times, and the TCMP0 interrupt in USARTn\_IF is set. If an RX start bit is detected before the 8 baud-times, comparator 0 is disabled before the TCMP0 event can trigger.





Figure 18.26. USART Response Timeout

### 18.3.10.2 RX Timeout


A receiver timeout function can be implemented by using the RX end of frame to start comparator 1 and look for the RX start bit RXACT to disable the comparator. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example. As long as the next RX start bit occurs before the counter reaches the comparator 1 value TCMPVAL1, the interrupt will not get set. In this example the RX Timeout was set to 8 baud-times. To get an RX timeout larger than 256 baud-times, RESTART1EN in USARTn\_TIMER can be used to restart the counter when it reaches TCMPVAL1. By setting TCMPVAL1 in USARTn\_TIMING to 0xFF, an interrupt will be generated after 256 baud-times. An interrupt service routine can then increment a memory location until the desired timeout is reached. Once the RX start bit is detected, comparator 1 will be disabled. If TIMERRESTARTED in USARTn\_STATUS is clear, the TCMP1 interrupt is the first interrupt after RXEOF.



**Figure 18.27. USART RX Timeout**

### 18.3.10.3 Break Detect


LIN bus and half-duplex UARTs can take advantage of the timer configured for break detection where RX is held low for a number of baud-times to indicate a break condition. [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) shows the settings for this mode. Each time RX is active (default of low) such as for a start bit, the timer begins counting. If the counter reaches 12 baud-times before RX goes to inactive RXACTN (default of high), an interrupt is asserted.



**Figure 18.28. USART Break Detection**

#### 18.3.10.4 TX Start Delay

Some applications may require a delay before the start of transmission. This example in [Figure 18.29 USART TXSEQ Timing on page 636](#) shows the TXSEQ timer used to delay the start of transmission by 4 baud times before the start of CS, and by 2 baud times with CS asserted. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on how to configure this mode. The TX sequencer could be enabled on PRS and start the TXSEQ counter running for 4 baud times as programmed in TCMPVAL0. Then CS is asserted for 2 baud times before the transmitter begins sending TX data. TXDELAY in USARTn\_TIMING is the initial delay before any CS assertion, and CSSETUP is the delay during CS assertion. There are several small preset timing values such as 1, 2, 3, or 7 that can be used for some of the TX sequencer timing which leaves TCMPVAL0, TCMPVAL1, and TCMPVAL2 free for other uses.



**Figure 18.29. USART TXSEQ Timing**

#### 18.3.10.5 Inter-Character Space


In addition to delaying the start of frame transmission, it is sometimes necessary to also delay the time between each transmit character (inter-character space). After the first transmission, the inter-character space will delay the start of all subsequent transmissions until the transmit buffer is empty. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example. For this example in [Figure 18.29 USART TXSEQ Timing on page 636](#) ICS is set to TCMP2 in USARTn\_TIMING. To keep CS asserted during the inter-character space, set AUTOCS in USARTn\_CTRL. There are a few small preset timing values provided for TX sequence timing. Using these preset timing values can free up the TCMPVALn for other uses. For this example, the inter-character space is set to 0x03 and a preset value could be used.

#### 18.3.10.6 TX Chip Select End Delay

The assertion of CS can be extended after the final character of the frame by using CSHOLD in USARTn\_TIMING. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example. AUTOCS in USARTn\_CTRL needs to be set to extend the CS assertion after the last TX character is transmitted as shown in [Figure 18.29 USART TXSEQ Timing on page 636](#).

#### 18.3.10.7 Response Delay

A response delay can be used to hold off the transmitter until a certain number of baud-times after the RX frame. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example. TXARX1EN in USARTn\_TRIGCTRL tells the TX sequencer to trigger after RX EOF plus tcmp1val baud times.



**Figure 18.30. USART Response Delay**

### 18.3.10.8 Combined TX and RX Example

This example describes how to alternate between TX and RX frames. This has a 28 baud-time space after RX and a 16 baud-time space after TX. The TSTART1 in USARTn\_TIMECMP1 is set to RXEOF which uses the receiver end of frame to start the timer. The TSTOP1 is set to TCMP1 to generate an event after 28 baud times. Set TXARX1EN in USARTn\_TRIGCTRL, and the transmitter is held off until 28 baud times. TCMPVAL in USARTn\_TIMECMP1 is set to 0x1C for 28 baud times. By setting TSTART0 in USARTn\_TIMECMP0 to TXEOF, the timer will be started after the transmission has completed. RXATX0EN in USARTn\_TRIGCTRL is used to delay enabling of the receiver until 16 baud times after the transmitter has completed. Write 0x10 into TCMPVAL of USARTn\_TIMECMP0 for a 16 baud time delay. CS is also asserted 7 baud-times before start of transmission by setting CSSETUP to 0x7 in USARTn\_TIMING. To keep CS asserted for 3 baud-times after transmission completes, CSHOLD is set to 0x3 in USARTn\_TIMING. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example.

### 18.3.10.9 Combined TX Delay and RX Break Detect

This example describes how to delay TX transmission after an RX frame and how to have a break condition signal an interrupt. See [Table 18.10 USART Application Settings for USARTn\\_TIMING and USARTn\\_TIMECMPn on page 633](#) for details on setting up this example. The TX delay is set up by using transmit after RX, TXARX0EN in USARTn\_TRIGCTRL to start the timer. TSTART0 in USARTn\_TIMECMP0 is set to RXEOF which enables the transmitter of the timer delay. For this example TCMPVAL in USARTn\_TIMECMP0 is set to 0x20 to create a 32 baud-time delay between the end of the RX frame and the start of the TX frame. The break detect is configured by setting TSTART1 to RXACT to detect the start bit, and setting TSTOP1 to RXACTN to detect RX going high. In this case the interrupt asserts after RX stays low for 12 baud-times, so TCMPVAL1 is set to 0x0C.

### 18.3.10.10 Other Stop Conditions

There is also a timer stop on TX start using the TXST setting in TSTOP of USARTn\_TIMECMPn. This can be used to see that the DMA has not written to the TXBUFFER for a given time.

## 18.3.11 Interrupts

The interrupts generated by the USART are combined into two interrupt vectors. Interrupts related to reception are assigned to one interrupt vector, and interrupts related to transmission are assigned to the other. Separating the interrupts in this way allows different priorities to be set for transmission and reception interrupts.

The transmission interrupt vector groups the transmission-related interrupts generated by the following interrupt flags:

- TXC
- TXBL
- TXOF
- CCF
- TXIDLE

The reception interrupt on the other hand groups the reception-related interrupts, triggered by the following interrupt flags:


- RXDATAV
- RXFULL
- RXOF
- RXUF
- PERR
- FERR
- MPAF
- SSM
- TCMPn

If USART interrupts are enabled, an interrupt will be made if one or more of the interrupt flags in USART\_IF and their corresponding bits in USART\_IEN are set.

### 18.3.12 IrDA Modulator/ Demodulator

The IrDA modulator implements the physical layer of the IrDA specification, which is necessary for communication over IrDA. The modulator takes the signal output from the USART module, and modulates it before it leaves the USART. In the same way, the input signal is demodulated before it enters the actual USART module. The modulator implements the original Rev. 1.0 physical layer and one high speed extension which supports speeds from 2.4 kbps to 1.152 Mbps.

The data from and to the USART is represented in a NRZ (Non Return to Zero) format, where the signal value is at the same level through the entire bit period. For IrDA, the required format is RZI (Return to Zero Inverted), a format where a “1” is signalled by holding the line low, and a “0” is signalled by a short high pulse. An example is given in [Figure 18.31 USART Example RZI Signal for a given Asynchronous USART Frame on page 638](#).



**Figure 18.31. USART Example RZI Signal for a given Asynchronous USART Frame**

The IrDA module is enabled by setting IREN. The USART transmitter output and receiver input is then routed through the IrDA modulator.

The width of the pulses generated by the IrDA modulator is set by configuring IRPW in USARTn\_IRCTRL. Four pulse widths are available, each defined relative to the configured bit period as listed in [Table 18.11 USART IrDA Pulse Widths on page 638](#).

**Table 18.11. USART IrDA Pulse Widths**

IRPW	Pulse width OVS=0	Pulse width OVS=1	Pulse width OVS=2	Pulse width OVS=3
00	1/16	1/8	1/6	1/4
01	2/16	2/8	2/6	N/A
10	3/16	3/8	N/A	N/A
11	4/16	N/A	N/A	N/A

By default, no filter is enabled in the IrDA demodulator. A filter can be enabled by setting IRFILT in USARTn\_IRCTRL. When the filter is enabled, an incoming pulse has to last for 4 consecutive clock cycles to be detected by the IrDA demodulator.

Note that by default, the idle value of the USART data signal is high. This means that the IrDA modulator generates negative pulses, and the IrDA demodulator expects negative pulses. To make the IrDA module use RZI signalling, both TXINV and RXINV in USARTn\_CTRL must be set.

The IrDA module can also modulate a signal from the PRS system, and transmit a modulated signal to the PRS system. To use a PRS channel as transmitter source instead of the USART, set IRPRSEN in USARTn\_IRCTRL high. The channel is selected by configuring IRPRSSEL in USARTn\_IRCTRL.

## 18.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	USARTn_CTRL	RW	Control Register
0x004	USARTn_FRAME	RW	USART Frame Format Register
0x008	USARTn_TRIGCTRL	RW	USART Trigger Control Register
0x00C	USARTn_CMD	W1	Command Register
0x010	USARTn_STATUS	R	USART Status Register
0x014	USARTn_CLKDIV	RWH	Clock Control Register
0x018	USARTn_RXDATAX	R(a)	RX Buffer Data Extended Register
0x01C	USARTn_RXDATA	R(a)	RX Buffer Data Register
0x020	USARTn_RXDOUBLEX	R(a)	RX Buffer Double Data Extended Register
0x024	USARTn_RXDOUBLE	R(a)	RX FIFO Double Data Register
0x028	USARTn_RXDATAXP	R	RX Buffer Data Extended Peek Register
0x02C	USARTn_RXDOUBLEXP	R	RX Buffer Double Data Extended Peek Register
0x030	USARTn_TXDATAX	W	TX Buffer Data Extended Register
0x034	USARTn_TXDATA	W	TX Buffer Data Register
0x038	USARTn_TXDOUBLEX	W	TX Buffer Double Data Extended Register
0x03C	USARTn_TXDOUBLE	W	TX Buffer Double Data Register
0x040	USARTn_IF	R	Interrupt Flag Register
0x044	USARTn_IFS	W1	Interrupt Flag Set Register
0x048	USARTn_IFC	(R)W1	Interrupt Flag Clear Register
0x04C	USARTn_IEN	RW	Interrupt Enable Register
0x050	USARTn_IRCTRL	RW	IrDA Control Register
0x058	USARTn_INPUT	RW	USART Input Register
0x05C	USARTn_I2SCTRL	RW	I2S Control Register
0x060	USARTn_TIMING	RW	Timing Register
0x064	USARTn_CTRLX	RW	Control Register Extended
0x068	USARTn_TIMECMP0	RW	Used to Generate Interrupts and Various Delays
0x06C	USARTn_TIMECMP1	RW	Used to Generate Interrupts and Various Delays
0x070	USARTn_TIMECMP2	RW	Used to Generate Interrupts and Various Delays
0x074	USARTn_ROUTEOPEN	RW	I/O Routing Pin Enable Register
0x078	USARTn_ROUTELOC0	RW	I/O Routing Location Register
0x07C	USARTn_ROUTELOC1	RW	I/O Routing Location Register

## 18.5 Register Description

### 18.5.1 USARTn\_CTRL - Control Register

Offset	Bit Position							
0x000	31	SSSEARLY	RW	0	25			
Reset	0	30	ERIRSTX	RW	0	24		
Access	RW	0	ERRSRX	RW	0	23		
Name	SMSDELAY	RW	0	28	BIT8DV	RW	0	21
	MVDIS	RW	0	27	SKIPPERF	RW	0	20
	AUTOTX	RW	0	26	SCRETRANS	RW	0	19
	BYTESWAP	RW	0	25	SCMODE	RW	0	18
Bit	Name	Reset	Access	Description				
31	SMSDELAY	0	RW	<b>Synchronous Master Sample Delay</b>	Delay Synchronous Master sample point to the next setup edge to improve timing and allow communication at higher speeds			
30	MVDIS	0	RW	<b>Majority Vote Disable</b>	Disable majority vote for 16x, 8x and 6x oversampling modes.			
29	AUTOTX	0	RW	<b>Always Transmit When RX Not Full</b>	Transmits as long as RX is not full. If TX is empty, underflows are generated.			
28	BYTESWAP	0	RW	<b>Byteswap in Double Accesses</b>	Set to switch the order of the bytes in double accesses.			
	Value			Description				
	0			Normal byte order				
	1			Byte order swapped				
27:26	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>				
25	SSSEARLY	0	RW	<b>Synchronous Slave Setup Early</b>	Setup data on sample edge in synchronous slave mode to improve MOSI setup time			
24	ERRSTX	0	RW	<b>Disable TX on Error</b>	When set, the transmitter is disabled on framing and parity errors (asynchronous mode only) in the receiver.			
	Value			Description				
	0			Received framing and parity errors have no effect on transmitter				
	1			Received framing and parity errors disable the transmitter				
23	ERRSRX	0	RW	<b>Disable RX on Error</b>	When set, the receiver is disabled on framing and parity errors (asynchronous mode only).			
	Value			Description				
	0			Framing and parity errors have no effect on receiver				
	OVS		RW	0x0	6			
	MPAB		RW	0	5			
	MPM		RW	0	4			
	CCEN		RW	0	3			
	LOOPBK		RW	0	2			
	SYNC		RW	0	1			

Bit	Name	Reset	Access	Description
	1			Framing and parity errors disable the receiver
22	ERRSDMA	0	RW	<b>Halt DMA on Error</b>
				When set, DMA requests will be cleared on framing and parity errors (asynchronous mode only).
	Value			Description
	0			Framing and parity errors have no effect on DMA requests from the USART
	1			DMA requests from the USART are blocked while the PERR or FERR interrupt flags are set
21	BIT8DV	0	RW	<b>Bit 8 Default Value</b>
				The default value of the 9th bit. If 9-bit frames are used, and an 8-bit write operation is done, leaving the 9th bit unspecified, the 9th bit is set to the value of BIT8DV.
20	SKIPERRF	0	RW	<b>Skip Parity Error Frames</b>
				When set, the receiver discards frames with parity errors (asynchronous mode only). The PERR interrupt flag is still set.
19	SCRETRANS	0	RW	<b>SmartCard Retransmit</b>
				When in SmartCard mode, a NACK'ed frame will be kept in the shift register and retransmitted if the transmitter is still enabled.
18	SCMODE	0	RW	<b>SmartCard Mode</b>
				Use this bit to enable or disable SmartCard mode.
17	AUTOTRI	0	RW	<b>Automatic TX Tristate</b>
				When enabled, TXTRI is set by hardware whenever the transmitter is idle, and TXTRI is cleared by hardware when transmission starts.
	Value			Description
	0			The output on U(S)n_TX when the transmitter is idle is defined by TXINV
	1			U(S)n_TX is tristated whenever the transmitter is idle
16	AUTOCS	0	RW	<b>Automatic Chip Select</b>
				When enabled, the output on USn_CS will be activated one baud-period before transmission starts, and deactivated when transmission ends.
15	CSINV	0	RW	<b>Chip Select Invert</b>
				Default value is active low. This affects both the selection of external slaves, as well as the selection of the microcontroller as a slave.
	Value			Description
	0			Chip select is active low
	1			Chip select is active high
14	TXINV	0	RW	<b>Transmitter Output Invert</b>
				The output from the USART transmitter can optionally be inverted by setting this bit.
	Value			Description
	0			Output from the transmitter is passed unchanged to U(S)n_TX

Bit	Name	Reset	Access	Description
	1			Output from the transmitter is inverted before it is passed to U(S)n_TX
13	RXINV	0	RW	<b>Receiver Input Invert</b>
				Setting this bit will invert the input to the USART receiver.
	Value			Description
	0			Input is passed directly to the receiver
	1			Input is inverted before it is passed to the receiver
12	TXBIL	0	RW	<b>TX Buffer Interrupt Level</b>
				Determines the interrupt and status level of the transmit buffer.
	Value	Mode		Description
	0	EMPTY		TXBL and the TXBL interrupt flag are set when the transmit buffer becomes empty. TXBL is cleared when the buffer becomes nonempty.
	1	HALFFULL		TXBL and TXBLIF are set when the transmit buffer goes from full to half-full or empty. TXBL is cleared when the buffer becomes full.
11	CSMA	0	RW	<b>Action on Slave-Select in Master Mode</b>
				This register determines the action to be performed when slave-select is configured as an input and driven low while in master mode.
	Value	Mode		Description
	0	NOACTION		No action taken
	1	GOTOSLAVEMODE		Go to slave mode
10	MSBF	0	RW	<b>Most Significant Bit First</b>
				Decides whether data is sent with the least significant bit first, or the most significant bit first.
	Value			Description
	0			Data is sent with the least significant bit first
	1			Data is sent with the most significant bit first
9	CLKPHA	0	RW	<b>Clock Edge for Setup/Sample</b>
				Determines where data is set-up and sampled according to the bus clock when in synchronous mode.
	Value	Mode		Description
	0	SAMPLELEADING		Data is sampled on the leading edge and set-up on the trailing edge of the bus clock in synchronous mode
	1	SAMPLETRAILING		Data is set-up on the leading edge and sampled on the trailing edge of the bus clock in synchronous mode
8	CLKPOL	0	RW	<b>Clock Polarity</b>
				Determines the clock polarity of the bus clock used in synchronous mode.
	Value	Mode		Description
	0	IDLELOW		The bus clock used in synchronous mode has a low base value

Bit	Name	Reset	Access	Description
1	IDLEHIGH			The bus clock used in synchronous mode has a high base value
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6:5	OVS	0x0	RW	<b>Oversampling</b>
				Sets the number of clock periods in a USART bit-period. More clock cycles gives better robustness, while less clock cycles gives better performance.
	Value	Mode		Description
	0	X16		Regular UART mode with 16X oversampling in asynchronous mode
	1	X8		Double speed with 8X oversampling in asynchronous mode
	2	X6		6X oversampling in asynchronous mode
	3	X4		Quadruple speed with 4X oversampling in asynchronous mode
4	MPAB	0	RW	<b>Multi-Processor Address-Bit</b>
				Defines the value of the multi-processor address bit. An incoming frame with its 9th bit equal to the value of this bit marks the frame as a multi-processor address frame.
3	MPM	0	RW	<b>Multi-Processor Mode</b>
				Multi-processor mode uses the 9th bit of the USART frames to tell whether the frame is an address frame or a data frame.
	Value			Description
	0			The 9th bit of incoming frames has no special function
	1			An incoming frame with the 9th bit equal to MPAB will be loaded into the receive buffer regardless of RXBLOCK and will result in the MPAB interrupt flag being set
2	CCEN	0	RW	<b>Collision Check Enable</b>
				Enables collision checking on data when operating in half duplex modus.
	Value			Description
	0			Collision check is disabled
	1			Collision check is enabled. The receiver must be enabled for the check to be performed
1	LOOPBK	0	RW	<b>Loopback Enable</b>
				Allows the receiver to be connected directly to the USART transmitter for loopback and half duplex communication.
	Value			Description
	0			The receiver is connected to and receives data from U(S)n_RX
	1			The receiver is connected to and receives data from U(S)n_TX
0	SYNC	0	RW	<b>USART Synchronous Mode</b>
				Determines whether the USART is operating in asynchronous or synchronous mode.
	Value			Description
	0			The USART operates in asynchronous mode

Bit	Name	Reset	Access	Description
1				The USART operates in synchronous mode

### 18.5.2 USARTn\_FRAME - USART Frame Format Register

Bit	Name	Reset	Access	Description
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13:12	STOPBITS	0x1	RW	<b>Stop-Bit Mode</b>  Determines the number of stop-bits used.
	Value	Mode		Description
	0	HALF		The transmitter generates a half stop bit. Stop-bits are not verified by receiver
	1	ONE		One stop bit is generated and verified
	2	ONEANDAHALF		The transmitter generates one and a half stop bit. The receiver verifies the first stop bit
	3	TWO		The transmitter generates two stop bits. The receiver checks the first stop-bit only
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9:8	PARITY	0x0	RW	<b>Parity-Bit Mode</b>  Determines whether parity bits are enabled, and whether even or odd parity should be used. Only available in asynchronous mode.
	Value	Mode		Description
	0	NONE		Parity bits are not used
	2	EVEN		Even parity are used. Parity bits are automatically generated and checked by hardware.
	3	ODD		Odd parity is used. Parity bits are automatically generated and checked by hardware.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	DATABITS	0x5	RW	<b>Data-Bit Mode</b>  This register sets the number of data bits in a USART frame.
	Value	Mode		Description
	1	FOUR		Each frame contains 4 data bits
	2	FIVE		Each frame contains 5 data bits

Bit	Name	Reset	Access	Description
3	SIX			Each frame contains 6 data bits
4	SEVEN			Each frame contains 7 data bits
5	EIGHT			Each frame contains 8 data bits
6	NINE			Each frame contains 9 data bits
7	TEN			Each frame contains 10 data bits
8	ELEVEN			Each frame contains 11 data bits
9	TWELVE			Each frame contains 12 data bits
10	THIRTEEN			Each frame contains 13 data bits
11	FOURTEEN			Each frame contains 14 data bits
12	FIFTEEN			Each frame contains 15 data bits
13	SIXTEEN			Each frame contains 16 data bits

## 18.5.3 USARTn\_TRIGCTRL - USART Trigger Control Register

Offset	Bit Position																				
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	0
<b>Reset</b>											0x0										
<b>Access</b>											RW										
<b>Name</b>											TSEL										
												RXATX2EN	RXATX1EN	RXATX0EN	TXARX2EN	TXARX1EN	TXARX0EN	AUTOTXTEN	TXTEN	RXTEN	

Bit	Name	Reset	Access	Description
31:19	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
18:16	TSEL	0x0	RW	<b>Trigger PRS Channel Select</b>
	Select USART PRS trigger channel. The PRS signal can enable RX and/or TX, depending on the setting of RXTEN and TXTEN.			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	
	4	PRSCH4	PRS Channel 4 selected	
	5	PRSCH5	PRS Channel 5 selected	
	6	PRSCH6	PRS Channel 6 selected	
	7	PRSCH7	PRS Channel 7 selected	
15:13	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
12	RXATX2EN	0	RW	<b>Enable Receive Trigger After TX End of Frame Plus TCMPVAL2 Baud-times</b>
	When set, a TX end of frame will trigger the receiver after a TCMPVAL2 baud-time delay			
11	RXATX1EN	0	RW	<b>Enable Receive Trigger After TX End of Frame Plus TCMPVAL1 Baud-times</b>
	When set, a TX end of frame will trigger the receiver after a TCMPVAL1 baud-time delay			
10	RXATX0EN	0	RW	<b>Enable Receive Trigger After TX End of Frame Plus TCMPVAL0 Baud-times</b>
	When set, a TX end of frame will trigger the receiver after a TCMPVAL0 baud-time delay			
9	TXARX2EN	0	RW	<b>Enable Transmit Trigger After RX End of Frame Plus TCMP2VAL</b>
	When set, an RX end of frame will trigger the transmitter after TCMP2VAL bit times to force a minimum response delay			
8	TXARX1EN	0	RW	<b>Enable Transmit Trigger After RX End of Frame Plus TCMP1VAL</b>
	When set, an RX end of frame will trigger the transmitter after TCMP1VAL bit times to force a minimum response delay			

Bit	Name	Reset	Access	Description
7	TXARX0EN	0	RW	<b>Enable Transmit Trigger After RX End of Frame Plus TCMP0VAL</b> When set, an RX end of frame will trigger the transmitter after TCMP0VAL bit times to force a minimum response delay
6	AUTOTXTEN	0	RW	<b>AUTOTX Trigger Enable</b> When set, AUTOTX is enabled as long as the PRS channel selected by TSEL has a high value
5	TXTEN	0	RW	<b>Transmit Trigger Enable</b> When set, the PRS channel selected by TSEL sets TXEN, enabling the transmitter on positive trigger edges.
4	RXTEN	0	RW	<b>Receive Trigger Enable</b> When set, the PRS channel selected by TSEL sets RXEN, enabling the receiver on positive trigger edges.
3:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 18.5.4 USARTn\_CMD - Command Register

Offset	Bit Position																			
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12
<b>Reset</b>																W1	0	11		
<b>Access</b>																W1	0	10		
<b>Name</b>																CLEARRX	W1	0	9	
																CLEARTX	W1	0	8	
																TXTRIDIS	W1	0	7	
																TXTRIEN	W1	0	6	
																RXBLOCKDIS	W1	0	5	
																RXBLOCKEN	W1	0	4	
																MASTERDIS	W1	0	3	
																MASTEREN	W1	0	2	
																TXDIS	W1	0	1	
																TXEN	W1	0	0	
																RXDIS	W1	0	0	
																RXEN	W1	0	0	

Bit	Name	Reset	Access	Description
31:12	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
11	CLEARRX	0	W1	<b>Clear RX</b>
				Set to clear receive buffer and the RX shift register.
10	CLEARTX	0	W1	<b>Clear TX</b>
				Set to clear transmit buffer and the TX shift register.
9	TXTRIDIS	0	W1	<b>Transmitter Tristate Disable</b>
				Disables tristating of the transmitter output.
8	TXTRIEN	0	W1	<b>Transmitter Tristate Enable</b>
				Tristates the transmitter output.
7	RXBLOCKDIS	0	W1	<b>Receiver Block Disable</b>
				Set to clear RXBLOCK, resulting in all incoming frames being loaded into the receive buffer.
6	RXBLOCKEN	0	W1	<b>Receiver Block Enable</b>
				Set to set RXBLOCK, resulting in all incoming frames being discarded.
5	MASTERDIS	0	W1	<b>Master Disable</b>
				Set to disable master mode, clearing the MASTER status bit and putting the USART in slave mode.
4	MASTEREN	0	W1	<b>Master Enable</b>
				Set to enable master mode, setting the MASTER status bit. Master mode should not be enabled while TXENS is set to 1. To enable both master and TX mode, write MASTEREN before TXEN, or enable them both in the same write operation.
3	TXDIS	0	W1	<b>Transmitter Disable</b>
				Set to disable transmission.
2	TXEN	0	W1	<b>Transmitter Enable</b>
				Set to enable data transmission.
1	RXDIS	0	W1	<b>Receiver Disable</b>
				Set to disable data reception. If a frame is under reception when the receiver is disabled, the incoming frame is discarded.
0	RXEN	0	W1	<b>Receiver Enable</b>
				Set to activate data reception on U(S)n_RX.

## 18.5.5 USARTn\_STATUS - USART Status Register

Offset	Bit Position																																		
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																	0x0																		
Access																	R																		
Name																	TXBUFCNT																		

Bit	Name	Reset	Access	Description
31:18	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
17:16	TXBUFCNT	0x0	R	<b>TX Buffer Count</b>  Count of TX buffer entry 0, entry 1, and TX shift register. For large frames, the count is only of TX buffer entry 0 and the TX shifter register.
15	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
14	TIMERRESTARTED	0	R	<b>The USART Timer Restarted Itself</b>  When the timer is restarting itself on each TCMP event, a TIMERRESTARTED value of 0x0 indicates the first TCMP event in the sequence of multiple TCMP events. Any non TCMP timer start events will clear TIMERRESTARTED. When there is a TCMP interrupt and TIMERRESTARTED is 0x0, an interrupt service routine can set a TCMP event counter variable in memory to 0x1 to indicate the first TCMP interrupt of the sequence.
13	TXIDLE	1	R	<b>TX Idle</b>  Set when TX idle
12	RXFULLRIGHT	0	R	<b>RX Full of Right Data</b>  When set, the entire RX buffer contains right data. Only used in I2S mode
11	RXDATAVRIGHT	0	R	<b>RX Data Right</b>  When set, reading RXDATA or RXDATAX gives right data. Else left data is read. Only used in I2S mode
10	TXBSRIGHT	0	R	<b>TX Buffer Expects Single Right Data</b>  When set, the TX buffer expects at least a single right data. Else it expects left data. Only used in I2S mode
9	TXBDRIGHT	0	R	<b>TX Buffer Expects Double Right Data</b>  When set, the TX buffer expects double right data. Else it may expect a single right data or left data. Only used in I2S mode
8	RXFULL	0	R	<b>RX FIFO Full</b>  Set when the RXFIFO is full. Cleared when the receive buffer is no longer full. When this bit is set, there is still room for one more frame in the receive shift register.
7	RXDATAV	0	R	<b>RX Data Valid</b>  Set when data is available in the receive buffer. Cleared when the receive buffer is empty.
6	TXBL	1	R	<b>TX Buffer Level</b>  Indicates the level of the transmit buffer. If TXBIL is 0x0, TXBL is set whenever the transmit buffer is completely empty. Otherwise TXBL is set whenever the TX Buffer becomes half full.

Bit	Name	Reset	Access	Description
5	TXC	0	R	<b>TX Complete</b>  Set when a transmission has completed and no more data is available in the transmit buffer and shift register. Cleared when data is written to the transmit buffer.
4	TXTRI	0	R	<b>Transmitter Tristated</b>  Set when the transmitter is tristated, and cleared when transmitter output is enabled. If AUTOTRI in USARTn_CTRL is set this bit is always read as 0.
3	RXBLOCK	0	R	<b>Block Incoming Data</b>  When set, the receiver discards incoming frames. An incoming frame will not be loaded into the receive buffer if this bit is set at the instant the frame has been completely received.
2	MASTER	0	R	<b>SPI Master Mode</b>  Set when the USART operates as a master. Set using the MASTEREN command and clear using the MASTERDIS command.
1	TXENS	0	R	<b>Transmitter Enable Status</b>  Set when the transmitter is enabled.
0	RXENS	0	R	<b>Receiver Enable Status</b>  Set when the receiver is enabled.

#### 18.5.6 USARTn\_CLKDIV - Clock Control Register

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Reset	0	0x000000																													
Access	RW	RWH																													
Name	AUTOBAUDEN	DIV																													

Bit	Name	Reset	Access	Description
31	AUTOBAUDEN	0	RW	<b>AUTOBAUD Detection Enable</b>  Detects the baud rate based on receiving a 0x55 frame (0x00 for IrDA). This is used in Asynchronous mode.
30:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
22:3	DIV	0x000000	RWH	<b>Fractional Clock Divider</b>  Specifies the fractional clock divider for the USART. Setting AUTOBAUDEN in USARTn_CLKDIV will overwrite the DIV field.
2:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

### 18.5.7 USARTn\_RXDATAx - RX Buffer Data Extended Register (Actionable Reads)

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0	0	0x000														
Access																R	R															
Name																FERR	PERR											RXDATA	R			

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15	FERR	0	R	<b>Data Framing Error</b>
				Set if data in buffer has a framing error. Can be the result of a break condition.
14	PERR	0	R	<b>Data Parity Error</b>
				Set if data in buffer has a parity error (asynchronous mode only).
13:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:0	RXDATA	0x000	R	<b>RX Data</b>
				Use this register to access data read from the USART. Buffer is cleared on read access.

### 18.5.8 USARTn\_RXDATA - RX Buffer Data Register (Actionable Reads)

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0	0	0x00														
Access																R																
Name																RXDATA											RXDATA	R				

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	RXDATA	0x00	R	<b>RX Data</b>
				Use this register to access data read from USART. Buffer is cleared on read access. Only the 8 LSB can be read using this register.

## 18.5.9 USARTn\_RXDOUBLEX - RX Buffer Double Data Extended Register (Actionable Reads)

Offset	Bit Position																																	
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset	0	0	0										0x0000																					
Access	R	R										R					R	R																
Name	FERR1	PERR1										RXDATA1					FERR0	R	0	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
																	PERR0	R																

Bit	Name	Reset	Access	Description
31	FERR1	0	R	<b>Data Framing Error 1</b>
				Set if data in buffer has a framing error. Can be the result of a break condition.
30	PERR1	0	R	<b>Data Parity Error 1</b>
				Set if data in buffer has a parity error (asynchronous mode only).
29:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
24:16	RXDATA1	0x000	R	<b>RX Data 1</b>
				Second frame read from buffer.
15	FERR0	0	R	<b>Data Framing Error 0</b>
				Set if data in buffer has a framing error. Can be the result of a break condition.
14	PERR0	0	R	<b>Data Parity Error 0</b>
				Set if data in buffer has a parity error (asynchronous mode only).
13:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8:0	RXDATA0	0x000	R	<b>RX Data 0</b>
				First frame read from buffer.

### 18.5.10 USARTn\_RXDOUBLE - RX FIFO Double Data Register (Actionable Reads)

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00								0x00							
Access																	R								R							
Name																	RXDATA1								RXDATA0							

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15:8	RXDATA1	0x00	R	<b>RX Data 1</b>  Second frame read from buffer.
7:0	RXDATA0	0x00	R	<b>RX Data 0</b>  First frame read from buffer.

### 18.5.11 USARTn\_RXDATAP - RX Buffer Data Extended Peek Register

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00															
Access																	R								R							
Name																	FERRP								PERRP							

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15	FERRP	0	R	<b>Data Framing Error Peek</b>  Set if data in buffer has a framing error. Can be the result of a break condition.
14	PERRP	0	R	<b>Data Parity Error Peek</b>  Set if data in buffer has a parity error (asynchronous mode only).
13:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
8:0	RXDATAP	0x000	R	<b>RX Data Peek</b>  Use this register to access data read from the USART.

## 18.5.12 USARTn\_RXDOUBLEXP - RX Buffer Double Data Extended Peek Register

Offset	Bit Position																																
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0	0											0x0000																				
Access	R	R											R																				
Name	FERRP1	PERRP1											RXDATAP1																			RXDATAP0	R

Bit	Name	Reset	Access	Description
31	FERRP1	0	R	<b>Data Framing Error 1 Peek</b>
				Set if data in buffer has a framing error. Can be the result of a break condition.
30	PERRP1	0	R	<b>Data Parity Error 1 Peek</b>
				Set if data in buffer has a parity error (asynchronous mode only).
29:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24:16	RXDATAP1	0x0000	R	<b>RX Data 1 Peek</b>
				Second frame read from FIFO.
15	FERRP0	0	R	<b>Data Framing Error 0 Peek</b>
				Set if data in buffer has a framing error. Can be the result of a break condition.
14	PERRP0	0	R	<b>Data Parity Error 0 Peek</b>
				Set if data in buffer has a parity error (asynchronous mode only).
13:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:0	RXDATAP0	0x0000	R	<b>RX Data 0 Peek</b>
				First frame read from FIFO.

### 18.5.13 USARTn TXDATAx - TX Buffer Data Extended Register

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15	RXENAT	0	W	<b>Enable RX After Transmission</b> Set to enable reception after transmission.
14	TXDISAT	0	W	<b>Clear TXEN After Transmission</b> Set to disable transmitter and release data bus directly after transmission.
13	TXBREAK	0	W	<b>Transmit Data as Break</b> Set to send data as a break. Recipient will see a framing error or a break condition depending on its configuration and the value of TXDATA.
12	TXTRIAT	0	W	<b>Set TXTRI After Transmission</b> Set to tristate transmitter by setting TXTRI after transmission.
11	UBRXAT	0	W	<b>Unblock RX After Transmission</b> Set to clear RXBLOCK after transmission, unblocking the receiver.
10:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:0	TXDATAx	0x000	W	<b>TX Data</b> Use this register to write data to the USART. If TXEN is set, a transfer will be initiated at the first opportunity.

## 18.5.14 USARTn\_TXDATA - TX Buffer Data Register

Offset	Bit Position																																
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
<b>Reset</b>																																0x00	
<b>Access</b>																																W	
<b>Name</b>																																	TXDATA

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	TXDATA	0x00	W	<b>TX Data</b>

This frame will be added to TX buffer. Only 8 LSB can be written using this register. 9th bit and control bits will be cleared.

#### 18.5.15 USARTn\_TXDOUBLEX - TX Buffer Double Data Extended Register

Offset	Bit Position							
0x038	RXENAT1	W	0	31				
Reset	TXDISAT1	W	0	30				
Access	TXBREAK1	W	0	29				
Name	TXTRIAT1	W	0	28				
	UBRXAT1	W	0	27				
				26				
				25				
				24				
				23				
				22				
				21				
	TXDATA1	W	0x000	20				
				19				
				18				
				17				
				16				
				15				
	RXENATO	W	0	15				
	TXDISATO	W	0	14				
	TXBREAKO	W	0	13				
	TXTRIATO	W	0	12				
	UBRXATO	W	0	11				
				10				
				9				
				8				
				7				
				6				
				5				
	TXDATA0	W	0x000	4				
				3				
				2				
				1				
				0				

Bit	Name	Reset	Access	Description
31	RXENAT1	0	W	<b>Enable RX After Transmission</b> Set to enable reception after transmission.
30	TXDISAT1	0	W	<b>Clear TXEN After Transmission</b> Set to disable transmitter and release data bus directly after transmission.
29	TXBREAK1	0	W	<b>Transmit Data as Break</b> Set to send data as a break. Recipient will see a framing error or a break condition depending on its configuration and the value of USARTn_TXDATA.
28	TXTRIAT1	0	W	<b>Set TXTRI After Transmission</b> Set to tristate transmitter by setting TXTRI after transmission.
27	UBRXAT1	0	W	<b>Unblock RX After Transmission</b> Set clear RXBLOCK after transmission, unblocking the receiver.
26:25	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
24:16	TXDATA1	0x000	W	<b>TX Data</b> Second frame to write to FIFO.
15	RXENAT0	0	W	<b>Enable RX After Transmission</b> Set to enable reception after transmission.
14	TXDISATO	0	W	<b>Clear TXEN After Transmission</b> Set to disable transmitter and release data bus directly after transmission.
13	TXBREAK0	0	W	<b>Transmit Data as Break</b> Set to send data as a break. Recipient will see a framing error or a break condition depending on its configuration and the value of TXDATA.
12	TXTRIATO	0	W	<b>Set TXTRI After Transmission</b> Set to tristate transmitter by setting TXTRI after transmission.
11	UBRXATO	0	W	<b>Unblock RX After Transmission</b> Set clear RXBLOCK after transmission, unblocking the receiver.
10:9	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
8:0	TXDATA0	0x000	W	<b>TX Data</b> First frame to write to buffer.

## 18.5.16 USARTn\_TXDOUBLE - TX Buffer Double Data Register

Offset	Bit Position																															
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00								0x00							
Access																	W								W							
Name																	TXDATA1								TXDATA0							

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
15:8	TXDATA1	0x00	W	<b>TX Data</b> Second frame to write to buffer.
7:0	TXDATA0	0x00	W	<b>TX Data</b> First frame to write to buffer.

## 18.5.17 USARTn\_IF - Interrupt Flag Register

Offset	Bit Position															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Reset															0	0
Access															R	0
Name															TCMP2	R
															TCMP1	R
															TCMP0	R
															TXIDLE	R
															CCF	R
															SSM	R
															MPAF	R
															FERR	R
															PERR	R
															TXUF	R
															TXOF	R
															RXUF	R
															RXOF	R
															RXFULL	R
															RXDATAV	R
															TXBL	R
															TXC	R

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
16	TCMP2	0	R	<b>Timer Comparator 2 Interrupt Flag</b> Set when the timer reaches the comparator 2 value, TCMP2.
15	TCMP1	0	R	<b>Timer Comparator 1 Interrupt Flag</b> Set when the timer reaches the comparator 1 value, TCMP1.
14	TCMP0	0	R	<b>Timer Comparator 0 Interrupt Flag</b> Set when the Timer reaches the comparator 0 value, TCMP0.
13	TXIDLE	0	R	<b>TX Idle Interrupt Flag</b> Set when TX goes idle. At this point, transmission has ended
12	CCF	0	R	<b>Collision Check Fail Interrupt Flag</b> Set when a collision check notices an error in the transmitted data.
11	SSM	0	R	<b>Slave-Select in Master Mode Interrupt Flag</b> Set when the device is selected as a slave when in master mode.
10	MPAF	0	R	<b>Multi-Processor Address Frame Interrupt Flag</b> Set when a multi-processor address frame is detected.
9	FERR	0	R	<b>Framing Error Interrupt Flag</b> Set when a frame with a framing error is received while RXBLOCK is cleared.
8	PERR	0	R	<b>Parity Error Interrupt Flag</b> Set when a frame with a parity error (asynchronous mode only) is received while RXBLOCK is cleared.
7	TXUF	0	R	<b>TX Underflow Interrupt Flag</b> Set when operating as a synchronous slave, no data is available in the transmit buffer when the master starts transmission of a new frame.
6	TXOF	0	R	<b>TX Overflow Interrupt Flag</b> Set when a write is done to the transmit buffer while it is full. The data already in the transmit buffer is preserved.
5	RXUF	0	R	<b>RX Underflow Interrupt Flag</b> Set when trying to read from the receive buffer when it is empty.
4	RXOF	0	R	<b>RX Overflow Interrupt Flag</b> Set when data is incoming while the receive shift register is full. The data previously in the shift register is lost.

Bit	Name	Reset	Access	Description
3	RXFULL	0	R	<b>RX Buffer Full Interrupt Flag</b> Set when the receive buffer becomes full.
2	RXDATAV	0	R	<b>RX Data Valid Interrupt Flag</b> Set when data becomes available in the receive buffer.
1	TXBL	1	R	<b>TX Buffer Level Interrupt Flag</b> Set when buffer becomes empty if buffer level is set to 0x0, or when the number of empty TX buffer elements equals specified buffer level.
0	TXC	0	R	<b>TX Complete Interrupt Flag</b> This interrupt is set after a transmission when both the TX buffer and shift register are empty.

#### 18.5.18 USARTn\_IFS - Interrupt Flag Set Register

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	TCMP2	0	W1	<b>Set TCMP2 Interrupt Flag</b> Write 1 to set the TCMP2 interrupt flag
15	TCMP1	0	W1	<b>Set TCMP1 Interrupt Flag</b> Write 1 to set the TCMP1 interrupt flag
14	TCMP0	0	W1	<b>Set TCMP0 Interrupt Flag</b> Write 1 to set the TCMP0 interrupt flag
13	TXIDLE	0	W1	<b>Set TXIDLE Interrupt Flag</b> Write 1 to set the TXIDLE interrupt flag
12	CCF	0	W1	<b>Set CCF Interrupt Flag</b> Write 1 to set the CCF interrupt flag
11	SSM	0	W1	<b>Set SSM Interrupt Flag</b> Write 1 to set the SSM interrupt flag
10	MPAF	0	W1	<b>Set MPAF Interrupt Flag</b> Write 1 to set the MPAF interrupt flag
9	FERR	0	W1	<b>Set FERR Interrupt Flag</b> Write 1 to set the FERR interrupt flag
8	PERR	0	W1	<b>Set PERR Interrupt Flag</b> Write 1 to set the PERR interrupt flag
7	TXUF	0	W1	<b>Set TXUF Interrupt Flag</b> Write 1 to set the TXUF interrupt flag
6	TXOF	0	W1	<b>Set TXOF Interrupt Flag</b> Write 1 to set the TXOF interrupt flag
5	RXUF	0	W1	<b>Set RXUF Interrupt Flag</b> Write 1 to set the RXUF interrupt flag
4	RXOF	0	W1	<b>Set RXOF Interrupt Flag</b> Write 1 to set the RXOF interrupt flag
3	RXFULL	0	W1	<b>Set RXFULL Interrupt Flag</b> Write 1 to set the RXFULL interrupt flag

Bit	Name	Reset	Access	Description
2:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	TXC	0	W1	<b>Set TXC Interrupt Flag</b> Write 1 to set the TXC interrupt flag

## 18.5.19 USARTn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
Reset																(R)W1
Access																(R)W1
Name																(R)W1

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	TCMP2	0	(R)W1	<b>Clear TCMP2 Interrupt Flag</b>
				Write 1 to clear the TCMP2 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15	TCMP1	0	(R)W1	<b>Clear TCMP1 Interrupt Flag</b>
				Write 1 to clear the TCMP1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
14	TCMP0	0	(R)W1	<b>Clear TCMP0 Interrupt Flag</b>
				Write 1 to clear the TCMP0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
13	TXIDLE	0	(R)W1	<b>Clear TXIDLE Interrupt Flag</b>
				Write 1 to clear the TXIDLE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
12	CCF	0	(R)W1	<b>Clear CCF Interrupt Flag</b>
				Write 1 to clear the CCF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
11	SSM	0	(R)W1	<b>Clear SSM Interrupt Flag</b>
				Write 1 to clear the SSM interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
10	MPAF	0	(R)W1	<b>Clear MPAF Interrupt Flag</b>
				Write 1 to clear the MPAF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	FERR	0	(R)W1	<b>Clear FERR Interrupt Flag</b>
				Write 1 to clear the FERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	PERR	0	(R)W1	<b>Clear PERR Interrupt Flag</b>
				Write 1 to clear the PERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	TXUF	0	(R)W1	<b>Clear TXUF Interrupt Flag</b>
				Write 1 to clear the TXUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
6	TXOF	0	(R)W1	<b>Clear TXOF Interrupt Flag</b>  Write 1 to clear the TXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	RXUF	0	(R)W1	<b>Clear RXUF Interrupt Flag</b>  Write 1 to clear the RXUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	RXOF	0	(R)W1	<b>Clear RXOF Interrupt Flag</b>  Write 1 to clear the RXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	RXFULL	0	(R)W1	<b>Clear RXFULL Interrupt Flag</b>  Write 1 to clear the RXFULL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	TXC	0	(R)W1	<b>Clear TXC Interrupt Flag</b>  Write 1 to clear the TXC interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 18.5.20 USARTn\_IEN - Interrupt Enable Register

Offset	Bit Position																	
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
Reset																RW	0	
Access																RW	0	
Name																T CMP2	RW	0
																T CMP1	RW	0
																T CMP0	RW	0
																TXIDLE	RW	0
																CCF	RW	0
																SSM	RW	0
																MPAF	RW	0
																FERR	RW	0
																PERR	RW	0
																TXUF	RW	0
																TXOF	RW	0
																RXUF	RW	0
																RXOF	RW	0
																RXFULL	RW	0
																RXDATAV	RW	0
																TXBL	RW	0
																TXC	RW	0

Bit	Name	Reset	Access	Description
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
16	TCMP2	0	RW	<b>TCMP2 Interrupt Enable</b> Enable/disable the TCMP2 interrupt
15	TCMP1	0	RW	<b>TCMP1 Interrupt Enable</b> Enable/disable the TCMP1 interrupt
14	TCMP0	0	RW	<b>TCMP0 Interrupt Enable</b> Enable/disable the TCMP0 interrupt
13	TXIDLE	0	RW	<b>TXIDLE Interrupt Enable</b> Enable/disable the TXIDLE interrupt
12	CCF	0	RW	<b>CCF Interrupt Enable</b> Enable/disable the CCF interrupt
11	SSM	0	RW	<b>SSM Interrupt Enable</b> Enable/disable the SSM interrupt
10	MPAF	0	RW	<b>MPAF Interrupt Enable</b> Enable/disable the MPAF interrupt
9	FERR	0	RW	<b>FERR Interrupt Enable</b> Enable/disable the FERR interrupt
8	PERR	0	RW	<b>PERR Interrupt Enable</b> Enable/disable the PERR interrupt
7	TXUF	0	RW	<b>TXUF Interrupt Enable</b> Enable/disable the TXUF interrupt
6	TXOF	0	RW	<b>TXOF Interrupt Enable</b> Enable/disable the TXOF interrupt
5	RXUF	0	RW	<b>RXUF Interrupt Enable</b> Enable/disable the RXUF interrupt
4	RXOF	0	RW	<b>RXOF Interrupt Enable</b> Enable/disable the RXOF interrupt

Bit	Name	Reset	Access	Description
3	RXFULL	0	RW	<b>RXFULL Interrupt Enable</b> Enable/disable the RXFULL interrupt
2	RXDATAV	0	RW	<b>RXDATAV Interrupt Enable</b> Enable/disable the RXDATAV interrupt
1	TXBL	0	RW	<b>TXBL Interrupt Enable</b> Enable/disable the TXBL interrupt
0	TXC	0	RW	<b>TXC Interrupt Enable</b> Enable/disable the TXC interrupt

## 18.5.21 USARTn\_IRCTRL - IrDA Control Register

Offset	Bit Position																																
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
<b>Reset</b>																									0x0	0	0x0	0	0				
<b>Access</b>																									RW	0	RW	0x0	2				
<b>Name</b>																									IRPRSEL	RW	RW	IRFILT	IRPW	IREN			

Bit	Name	Reset	Access	Description
31:11	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
10:8	<b>IRPRSSEL</b>	0x0	RW	<b>IrDA PRS Channel Select</b>
	A PRS can be used as input to the pulse modulator instead of TX. This value selects the channel to use.			
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	
	4	PRSCH4	PRS Channel 4 selected	
	5	PRSCH5	PRS Channel 5 selected	
	6	PRSCH6	PRS Channel 6 selected	
	7	PRSCH7	PRS Channel 7 selected	
7	<b>IRPRSEN</b>	0	RW	<b>IrDA PRS Channel Enable</b>
	Enable the PRS channel selected by IRPRSSEL as input to IrDA module instead of TX.			
6:4	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
3	<b>IRFILT</b>	0	RW	<b>IrDA RX Filter</b>
	Set to enable filter on IrDA demodulator.			
	Value	Mode	Description	
	0		No filter enabled	
	1		Filter enabled. IrDA pulse must be high for at least 4 consecutive clock cycles to be detected	
2:1	<b>IRPW</b>	0x0	RW	<b>IrDA TX Pulse Width</b>
	Configure the pulse width generated by the IrDA modulator as a fraction of the configured USART bit period.			
	Value	Mode	Description	
	0	ONE	IrDA pulse width is 1/16 for OVS=0 and 1/8 for OVS=1	
	1	TWO	IrDA pulse width is 2/16 for OVS=0 and 2/8 for OVS=1	

Bit	Name	Reset	Access	Description
	2	THREE		IrDA pulse width is 3/16 for OVS=0 and 3/8 for OVS=1
	3	FOUR		IrDA pulse width is 4/16 for OVS=0 and 4/8 for OVS=1
0	IREN	0	RW	<b>Enable IrDA Module</b>  Enable IrDA module and route USART signals through it.

## 18.5.22 USARTn\_INPUT - USART Input Register

Offset	Bit Position																																	
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																0	0x0	0	0x0															
Access																RW	RW	RW	RW															
Name																CLKPRS	CLKPRSSEL	RXPRS	RXPRSSEL															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15	CLKPRS	0	RW	<b>PRS CLK Enable</b>
		When set, the PRS channel selected as input to CLK.		
14:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10:8	CLKPRSSEL	0x0	RW	<b>CLK PRS Channel Select</b>
		Select PRS channel as input to CLK.		
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	
	4	PRSCH4	PRS Channel 4 selected	
	5	PRSCH5	PRS Channel 5 selected	
	6	PRSCH6	PRS Channel 6 selected	
	7	PRSCH7	PRS Channel 7 selected	
7	RXPRS	0	RW	<b>PRS RX Enable</b>
		When set, the PRS channel selected as input to RX.		
6:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2:0	RXPRSSEL	0x0	RW	<b>RX PRS Channel Select</b>
		Select PRS channel as input to RX.		
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected	
	1	PRSCH1	PRS Channel 1 selected	
	2	PRSCH2	PRS Channel 2 selected	
	3	PRSCH3	PRS Channel 3 selected	

Bit	Name	Reset	Access	Description
4	PRSCH4			PRS Channel 4 selected
5	PRSCH5			PRS Channel 5 selected
6	PRSCH6			PRS Channel 6 selected
7	PRSCH7			PRS Channel 7 selected

## 18.5.23 USARTn\_I2SCTRL - I2S Control Register

Offset	Bit Position																										
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5
<b>Reset</b>																									4	0	
<b>Access</b>																									RW	0	
<b>Name</b>																									FORMAT	0x0	

Bit	Name	Reset	Access	Description
31:11	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
10:8	FORMAT	0x0	RW	<b>I2S Word Format</b>
	Configure the data-width used internally for I2S data			
	Value	Mode	Description	
	0	W32D32	32-bit word, 32-bit data	
	1	W32D24M	32-bit word, 32-bit data with 8 lsb masked	
	2	W32D24	32-bit word, 24-bit data	
	3	W32D16	32-bit word, 16-bit data	
	4	W32D8	32-bit word, 8-bit data	
	5	W16D16	16-bit word, 16-bit data	
	6	W16D8	16-bit word, 8-bit data	
	7	W8D8	8-bit word, 8-bit data	
7:5	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
4	DELAY	0	RW	<b>Delay on I2S Data</b>
	Set to add a one-cycle delay between a transition on the word-clock and the start of the I2S word. Should be set for standard I2S format			
3	DMASPLIT	0	RW	<b>Separate DMA Request for Left/Right Data</b>
	When set DMA requests for right-channel data are put on the TXBLRIGHT and RXDATAVRIGHT DMA requests.			
2	JUSTIFY	0	RW	<b>Justification of I2S Data</b>
	Determines whether the I2S data is left or right justified			
	Value	Mode	Description	
	0	LEFT	Data is left-justified	
	1	RIGHT	Data is right-justified	
1	MONO	0	RW	<b>Stereo or Mono</b>
	Switch between stereo and mono mode. Set for mono			

Bit	Name	Reset	Access	Description
0	EN	0	RW	<b>Enable I2S Mode</b> Set the U(S)ART in I2S mode.

## 18.5.24 USARTn\_TIMING - Timing Register

Offset	Bit Position																															
0x060	31	30	29	28	27	26	25	24	23	22	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset			0x0			0x0				0x0			0x0																			
Access		RW			RW			RW			RW			RW																		
Name		CSHOLD			ICS			CSSETUP			TXDELAY																					

Bit	Name	Reset	Access	Description
31	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

30:28 CSHOLD 0x0 RW **Chip Select Hold**

Chip Select will be asserted after the end of frame transmission. When using TCMPn, normally set TIMECMPn\_TSTART to DISABLE to stop general timer and to prevent unwanted interrupts.

Value	Mode	Description
0	ZERO	Disable CS being asserted after the end of transmission
1	ONE	CS is asserted for 1 baud-times after the end of transmission
2	TWO	CS is asserted for 2 baud-times after the end of transmission
3	THREE	CS is asserted for 3 baud-times after the end of transmission
4	SEVEN	CS is asserted for 7 baud-times after the end of transmission
5	TCMP0	CS is asserted after the end of transmission for TCMPVAL0 baud-times
6	TCMP1	CS is asserted after the end of transmission for TCMPVAL1 baud-times
7	TCMP2	CS is asserted after the end of transmission for TCMPVAL2 baud-times

27	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
----	----------	--	--	---

26:24 ICS 0x0 RW **Inter-character Spacing**

Inter-character spacing after each TX frame while the TX buffer is not empty. When using USART\_TIMECMPn, normally set TSTART to DISABLE to stop general timer and to prevent unwanted interrupts.

Value	Mode	Description
0	ZERO	There is no space between characters
1	ONE	Create a space of 1 baud-times before start of transmission
2	TWO	Create a space of 2 baud-times before start of transmission
3	THREE	Create a space of 3 baud-times before start of transmission
4	SEVEN	Create a space of 7 baud-times before start of transmission
5	TCMP0	Create a space of before the start of transmission for TCMPVAL0 baud-times

Bit	Name	Reset	Access	Description																											
6	TCMP1			Create a space of before the start of transmission for TCMPVAL1 baud-times																											
7	TCMP2			Create a space of before the start of transmission for TCMPVAL2 baud-times																											
23	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
22:20	CSSETUP	0x0	RW	<b>Chip Select Setup</b>																											
		Chip Select will be asserted before the start of frame transmission. When using USART_TIMECMPn, normally set TSTART to DISABLE to stop general timer and to prevent unwanted interrupts.																													
		<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>ZERO</td><td>CS is not asserted before start of transmission</td></tr> <tr> <td>1</td><td>ONE</td><td>CS is asserted for 1 baud-times before start of transmission</td></tr> <tr> <td>2</td><td>TWO</td><td>CS is asserted for 2 baud-times before start of transmission</td></tr> <tr> <td>3</td><td>THREE</td><td>CS is asserted for 3 baud-times before start of transmission</td></tr> <tr> <td>4</td><td>SEVEN</td><td>CS is asserted for 7 baud-times before start of transmission</td></tr> <tr> <td>5</td><td>TCMP0</td><td>CS is asserted before the start of transmission for TCMPVAL0 baud-times</td></tr> <tr> <td>6</td><td>TCMP1</td><td>CS is asserted before the start of transmission for TCMPVAL1 baud-times</td></tr> <tr> <td>7</td><td>TCMP2</td><td>CS is asserted before the start of transmission for TCMPVAL2 baud-times</td></tr> </tbody> </table>			Value	Mode	Description	0	ZERO	CS is not asserted before start of transmission	1	ONE	CS is asserted for 1 baud-times before start of transmission	2	TWO	CS is asserted for 2 baud-times before start of transmission	3	THREE	CS is asserted for 3 baud-times before start of transmission	4	SEVEN	CS is asserted for 7 baud-times before start of transmission	5	TCMP0	CS is asserted before the start of transmission for TCMPVAL0 baud-times	6	TCMP1	CS is asserted before the start of transmission for TCMPVAL1 baud-times	7	TCMP2	CS is asserted before the start of transmission for TCMPVAL2 baud-times
Value	Mode	Description																													
0	ZERO	CS is not asserted before start of transmission																													
1	ONE	CS is asserted for 1 baud-times before start of transmission																													
2	TWO	CS is asserted for 2 baud-times before start of transmission																													
3	THREE	CS is asserted for 3 baud-times before start of transmission																													
4	SEVEN	CS is asserted for 7 baud-times before start of transmission																													
5	TCMP0	CS is asserted before the start of transmission for TCMPVAL0 baud-times																													
6	TCMP1	CS is asserted before the start of transmission for TCMPVAL1 baud-times																													
7	TCMP2	CS is asserted before the start of transmission for TCMPVAL2 baud-times																													
19	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
18:16	TXDELAY	0x0	RW	<b>TX Frame Start Delay</b>																											
		Number of baud-times to delay the start of frame transmission. When using USART_TIMECMPn, normally set TSTART to DISABLE to stop general timer and to prevent unwanted interrupts.																													
		<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>Disable - TXDELAY in USARTn_CTRL can be used for legacy</td></tr> <tr> <td>1</td><td>ONE</td><td>Start of transmission is delayed for 1 baud-times</td></tr> <tr> <td>2</td><td>TWO</td><td>Start of transmission is delayed for 2 baud-times</td></tr> <tr> <td>3</td><td>THREE</td><td>Start of transmission is delayed for 3 baud-times</td></tr> <tr> <td>4</td><td>SEVEN</td><td>Start of transmission is delayed for 7 baud-times</td></tr> <tr> <td>5</td><td>TCMP0</td><td>Start of transmission is delayed for TCMPVAL0 baud-times</td></tr> <tr> <td>6</td><td>TCMP1</td><td>Start of transmission is delayed for TCMPVAL1 baud-times</td></tr> <tr> <td>7</td><td>TCMP2</td><td>Start of transmission is delayed for TCMPVAL2 baud-times</td></tr> </tbody> </table>			Value	Mode	Description	0	DISABLE	Disable - TXDELAY in USARTn_CTRL can be used for legacy	1	ONE	Start of transmission is delayed for 1 baud-times	2	TWO	Start of transmission is delayed for 2 baud-times	3	THREE	Start of transmission is delayed for 3 baud-times	4	SEVEN	Start of transmission is delayed for 7 baud-times	5	TCMP0	Start of transmission is delayed for TCMPVAL0 baud-times	6	TCMP1	Start of transmission is delayed for TCMPVAL1 baud-times	7	TCMP2	Start of transmission is delayed for TCMPVAL2 baud-times
Value	Mode	Description																													
0	DISABLE	Disable - TXDELAY in USARTn_CTRL can be used for legacy																													
1	ONE	Start of transmission is delayed for 1 baud-times																													
2	TWO	Start of transmission is delayed for 2 baud-times																													
3	THREE	Start of transmission is delayed for 3 baud-times																													
4	SEVEN	Start of transmission is delayed for 7 baud-times																													
5	TCMP0	Start of transmission is delayed for TCMPVAL0 baud-times																													
6	TCMP1	Start of transmission is delayed for TCMPVAL1 baud-times																													
7	TCMP2	Start of transmission is delayed for TCMPVAL2 baud-times																													
15:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													

## 18.5.25 USARTn\_CTRLX - Control Register Extended

Offset	Bit Position																																					
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Reset																																						
Access																																						
Name																																						

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	RTSINV	0	RW	<b>RTS Pin Inversion</b>
	When set, the RTS pin polarity is inverted.			
	Value			Description
	0			The USn_RTS pin is low true
	1			The USn_RTS pin is high true
2	CTSEN	0	RW	<b>CTS Function Enabled</b>
	When set, frames in the TXBUFn will not be sent until link partner asserts CTS. Any data in the TX shift register will continue transmitting, the next TXBUFn data will not load into the TX shift register			
	Value			Description
	0			Ignore CTS
	1			Stop transmitting when CTS is negated
1	CTSINV	0	RW	<b>CTS Pin Inversion</b>
	When set, the CTS pin polarity is inverted.			
	Value			Description
	0			The USn_CTS pin is low true
	1			The USn_CTS pin is high true
0	DBGHALT	0	RW	<b>Debug Halt</b>
	.			
	Value			Description
	0			Continue to transmit until TX buffer is empty
	1			Complete the transmission in the shift register and then halt transmission; also negate RTS to stop link partner's transmission during debug HALT. NOTE** The core clock should be equal to or faster than the peripheral clock; otherwise, each single step could transmit multiple frames instead of just transmitting one frame.

### 18.5.26 USARTn\_TIMECMP0 - Used to Generate Interrupts and Various Delays

Offset	Bit Position																															
0x068	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00															
Access																	RW															
Name																	TCMPVAL															

Bit	Name	Reset	Access	Description
31:25	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
24	RESTARTEN	0	RW	<b>Restart Timer on TCMP0</b>  Each TCMP0 event will reset and restart the timer
		Value Description		
	0	Disable the timer restarting on TCMP0		
	1	Enable the timer restarting on TCMP0		
23	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
22:20	TSTOP	0x0	RW	<b>Source Used to Disable Comparator 0</b>  Select the source which disables comparator 0
		Value Mode Description		
	0	TCMP0 Comparator 0 is disabled when the counter equals TCMPVAL and triggers a TCMP0 event		
	1	TXST Comparator 0 is disabled at the start of transmission		
	2	RXACT Comparator 0 is disabled on RX going Active (default: low)		
	3	RXACTN Comparator 0 is disabled on RX going Inactive		
19	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
18:16	TSTART	0x0	RW	<b>Timer Start Source</b>  Source used to start comparator 0 and timer
		Value Mode Description		
	0	DISABLE Comparator 0 is disabled		
	1	TXEOF Comparator 0 and timer are started at TX end of frame		
	2	TXC Comparator 0 and timer are started at TX Complete		
	3	RXACT Comparator 0 and timer are started at RX going Active (default: low)		
	4	RXEOF Comparator 0 and timer are started at RX end of frame		

Bit	Name	Reset	Access	Description
15:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	TCMPVAL	0x00	RW	<b>Timer Comparator 0</b>  When the timer equals TCMPVAL, this signals a TCMP0 event and sets the TCMP0 flag. This event can also be used to enable various USART functionality. A value of 0x00 represents 256 baud times.

### 18.5.27 USARTn\_TIMECMP1 - Used to Generate Interrupts and Various Delays

Offset	Bit Position																															
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x00						
Access																										RW						
Name																										TCMPVAL						

Bit	Name	Reset	Access	Description
31:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24	RESTARTEN	0	RW	<b>Restart Timer on TCMP1</b>
	Each TCMP1 event will reset and restart the timer			
	Value	Description		
	0	Disable the timer restarting on TCMP1		
	1	Enable the timer restarting on TCMP1		
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	TSTOP	0x0	RW	<b>Source Used to Disable Comparator 1</b>
	Select the source which disables comparator 1			
	Value	Mode	Description	
	0	TCMP1	Comparator 1 is disabled when the counter equals TCMPVAL and triggers a TCMP1 event	
	1	TXST	Comparator 1 is disabled at TX start TX Engine	
	2	RXACT	Comparator 1 is disabled on RX going Active (default: low)	
	3	RXACTN	Comparator 1 is disabled on RX going Inactive	
19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18:16	TSTART	0x0	RW	<b>Timer Start Source</b>
	Source used to start comparator 1 and timer			
	Value	Mode	Description	
	0	DISABLE	Comparator 1 is disabled	
	1	TXEOF	Comparator 1 and timer are started at TX end of frame	
	2	TXC	Comparator 1 and timer are started at TX Complete	
	3	RXACT	Comparator 1 and timer are started at RX going Active (default: low)	
	4	RXEOF	Comparator 1 and timer are started at RX end of frame	

Bit	Name	Reset	Access	Description
15:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	TCMPVAL	0x00	RW	<b>Timer Comparator 1</b>  When the timer equals TCMPVAL, this signals a TCMP1 event and sets the TCMP1 flag. This event can also be used to enable various USART functionality. A value of 0x00 represents 256 baud times.

## 18.5.28 USARTn\_TIMECMP2 - Used to Generate Interrupts and Various Delays

Offset	Bit Position																															
0x070	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x00			
Access																												RW				
Name																												TCMPVAL				

Bit	Name	Reset	Access	Description
31:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24	RESTARTEN	0	RW	<b>Restart Timer on TCMP2</b>
	Each TCMP2 event will reset and restart the timer			
	Value	Description		
	0	Disable the timer restarting on TCMP2		
	1	Enable the timer restarting on TCMP2		
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	TSTOP	0x0	RW	<b>Source Used to Disable Comparator 2</b>
	Select the source which disables comparator 2			
	Value	Mode	Description	
	0	TCMP2	Comparator 2 is disabled when the counter equals TCMPVAL and triggers a TCMP2 event	
	1	TXST	Comparator 2 is disabled at TX start TX Engine	
	2	RXACT	Comparator 2 is disabled on RX going Active (default: low)	
	3	RXACTN	Comparator 2 is disabled on RX going Inactive	
19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18:16	TSTART	0x0	RW	<b>Timer Start Source</b>
	Source used to start comparator 2 and timer			
	Value	Mode	Description	
	0	DISABLE	Comparator 2 is disabled	
	1	TXEOF	Comparator 2 and timer are started at TX end of frame	
	2	TXC	Comparator 2 and timer are started at TX Complete	
	3	RXACT	Comparator 2 and timer are started at RX going Active (default: low)	
	4	RXEOF	Comparator 2 and timer are started at RX end of frame	

Bit	Name	Reset	Access	Description
15:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	TCMPVAL	0x00	RW	<b>Timer Comparator 2</b>  When the timer equals TCMPVAL, this signals a TCMP2 event and sets the TCMP2 flag. This event can also be used to enable various USART functionality. A value of 0x00 represents 256 baud times.

## 18.5.29 USARTn\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																															
0x074	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0	0	
Access																										RW	RW	RW	RW	RW	RW	
Name																										RTSPEN	CTSPEN	CLKPEN	CSPEN	TXPEN	RXPEN	

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
5	<b>RTSPEN</b>	0	RW	<b>RTS Pin Enable</b>
	When set, the RTS pin of the USART is enabled.			
	Value	Description		
	0	The USn_RTS pin is disabled		
	1	The USn_RTS pin is enabled		
4	<b>CTSPEN</b>	0	RW	<b>CTS Pin Enable</b>
	When set, the CTS pin of the USART is enabled.			
	Value	Description		
	0	The USn_CTS pin is disabled		
	1	The USn_CTS pin is enabled		
3	<b>CLKPEN</b>	0	RW	<b>CLK Pin Enable</b>
	When set, the CLK pin of the USART is enabled.			
	Value	Description		
	0	The USn_CLK pin is disabled		
	1	The USn_CLK pin is enabled		
2	<b>CSPEN</b>	0	RW	<b>CS Pin Enable</b>
	When set, the CS pin of the USART is enabled.			
	Value	Description		
	0	The USn_CS pin is disabled		
	1	The USn_CS pin is enabled		
1	<b>TXPEN</b>	0	RW	<b>TX Pin Enable</b>
	When set, the TX/MOSI pin of the USART is enabled			
	Value	Description		
	0	The U(S)n_TX (MOSI) pin is disabled		
	1	The U(S)n_TX (MOSI) pin is enabled		

Bit	Name	Reset	Access	Description
0	RXPEN	0	RW	<b>RX Pin Enable</b>
When set, the RX/MISO pin of the USART is enabled.				
Value		Description		
0		The U(S)n_RX (MISO) pin is disabled		
1		The U(S)n_RX (MISO) pin is enabled		

### 18.5.30 USARTn\_ROUTELOC0 - I/O Routing Location Register

Bit	Name	Reset	Access	Description																								
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																								
29:24	CLKLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the USART CLK pin.																								
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																								
21:16	CSLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the USART CS pin.																								
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																								
13:8	TXLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the USART TX pin.																								



Bit	Name	Reset	Access	Description
	Value	Mode		Description
0	LOC0			Location 0
1	LOC1			Location 1
2	LOC2			Location 2
3	LOC3			Location 3
4	LOC4			Location 4
5	LOC5			Location 5
6	LOC6			Location 6
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:0	RXLOC	0x00	RW	<b>I/O Location</b>
				Decides the location of the USART RX pin.
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
	3	LOC3		Location 3
	4	LOC4		Location 4
	5	LOC5		Location 5
	6	LOC6		Location 6

## 18.5.31 USARTn\_ROUTELOC1 - I/O Routing Location Register

Offset	Bit Position																																	
0x07C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
<b>Reset</b>																																		
<b>Access</b>																																		
<b>Name</b>																																		

Bit	Name	Reset	Access	Description																								
31:14	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																										
13:8	RTSLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the USART RTS pin.  <table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										
7:6	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																										
5:0	CTSLOC	0x00	RW	<b>I/O Location</b>  Decides the location of the USART CTS pin.  <table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										

## 19. UART - Universal Asynchronous Receiver/ Transmitter



### Quick Facts

#### What?

The UART is capable of high-speed asynchronous serial communication

#### Why?

Serial communication is frequently used in embedded systems and the UART allows efficient communication with a wide range of external devices.

#### How?

The UART has a wide selection of operating modes, frame formats and baud rates. The multi-processor mode allows the UART to remain idle when not addressed. Triple buffering and DMA support makes high data rates possible with minimal CPU intervention and it is possible to transmit and receive large frames while the MCU remains in EM1.

### 19.1 Introduction

The Universal Asynchronous serial Receiver and Transmitter (UART) is a very flexible serial I/O module. It supports full- and half-duplex asynchronous UART communication.

## 19.2 Features

- Full duplex and half duplex
- Separate TX/RX enable
- Separate receive / transmit multiple entry buffers, with additional separate shift registers
- Programmable baud rate, generated as an fractional division from the peripheral clock ( $HFFPERCLK_{UARTn}$ )
- Max bit-rate
  - UART mode, peripheral clock rate/16, 8, 6, or 4
- Asynchronous mode supports
  - Majority vote baud-reception
  - False start-bit detection
  - Break generation/detection
  - Multi-processor mode
- Configurable number of data bits, 4-16 (plus the parity bit, if enabled)
  - HW parity bit generation and check
- Configurable number of stop bits in asynchronous mode: 0.5, 1, 1.5, 2
- HW collision detection
- Multi-processor mode
- Separate interrupt vectors for receive and transmit interrupts
- Loopback mode
  - Half duplex communication
  - Communication debugging
- PRS RX input
- Hardware Flow Control
- Automatic Baud Rate Detection

## 19.3 Functional Description

The UART is functionally equivalent to the USART with the exceptions defined in the following table. The register map and register descriptions are equal to those of the USART. See the USART chapter for detailed information on the operation of the UART.

**Table 19.1. UART Limitations**

Feature	Limitation
Synchronous operation	Not available. SYNC, CSMA, SMSDELAY, SSSEARLY, CSINV, CPOL and CPHA in USARTn_CTRL, and MASTEREN in USARTn_STATUS are always 0.
Transmission direction	Always LSB first. MSBF in USARTn_CTRL is always 0.
Chip-select	Not available. AUTOCS in USARTn_CTRL is always 0.
SmartCard mode	Not available. SCMODE in USARTn_CTRL is always 0.
IrDA	Not available. IREN in USARTn_IRCTRL is always 0.



## 19.4 Register Map

The register map of the UART is equivalent to the register map of the USART. See the USART chapter for complete information.

## 19.5 Register Description

The register description of the UART is equivalent to the register description of the USART except the limitations mentioned in [Table 19.1 UART Limitations on page 689](#). See the USART chapter for complete information.

## 20. LEUART - Low Energy Universal Asynchronous Receiver/Transmitter



### Quick Facts

#### What?

The LEUART provides full UART communication using a low frequency 32.768 kHz clock, and has special features for communication without CPU intervention.

#### Why?

It allows UART communication to be performed in low energy modes, using only a few  $\mu\text{A}$  during active communication and only 150 nA when waiting for incoming data.

#### How?

A low frequency clock signal allows communication with less energy. Using DMA, the LEUART can transmit and receive data with minimal CPU intervention. Special UART-frames can be configured to help control the data flow, further automating data transmission.

### 20.1 Introduction

The unique Low Energy UART (LEUART) is a UART that allows two-way UART communication on a strict power budget. Only a 32.768 kHz clock is needed to allow UART communication up to 9600 baud.

Even when the system is in low energy mode EM2 DeepSleep (with most core functionality turned off), the LEUART can wait for an incoming UART frame while having an extremely low energy consumption. When a UART frame is completely received, the CPU can quickly be woken up. Alternatively, multiple frames can be transferred via the Direct Memory Access (DMA) module into RAM memory before waking up the CPU.

Received data can optionally be blocked until a configurable start frame is detected. A signal frame can be configured to generate an interrupt indicating the end of a data transmission. The start frame and signal frame can be used in combination to handle higher level communication protocols.

Similarly, data can be transmitted in EM2 DeepSleep either on a frame-by-frame basis with data from the CPU or through use of the DMA.


The LEUART includes all necessary hardware support to make asynchronous serial communication possible with minimal software overhead and low energy consumption.

## 20.2 Features

- Low energy asynchronous serial communications
- Full/half duplex communication
- Separate TX / RX enable
- Separate double buffered transmit buffer and receive buffer
- Programmable baud rate, generated as a fractional division of the LFBCLK
  - Supports baud rates from 300 baud to 9600 baud
- Can use a high frequency clock source for even higher baud rates
- Configurable number of data bits: 8 or 9 (plus parity bit, if enabled)
- Configurable parity: off, even or odd
  - HW parity bit generation and check
- Configurable number of stop bits, 1 or 2
- Capable of sleep-mode wake-up on received frame
  - Either wake-up on any received byte or
  - Wake up only on specified start and signal frames
- Supports transmission and reception in EM0 Active, EM1 Sleep and EM2 DeepSleep with
  - Full DMA support
  - Specified start-frame can start reception automatically
- IrDA modulator (pulse generator, pulse extender)
- Multi-processor mode
- Loopback mode
  - Half duplex communication
  - Communication debugging
- PRS RX input

### 20.3 Functional Description


An overview of the LEUART module is shown in [Figure 20.1 LEUART Overview on page 692](#).



**Figure 20.1. LEUART Overview**

### 20.3.1 Frame Format

The frame format used by the LEUART consists of a set of data bits in addition to bits for synchronization and optionally a parity bit for error checking. A frame starts with one start-bit (S), where the line is driven low for one bit-period. This signals the start of a frame, and is used for synchronization. Following the start bit are 8 or 9 data bits and an optional parity bit. The data is transmitted with the least significant bit first. Finally, a number of stop-bits, where the line is driven high, end the frame. The frame format is shown in [Figure 20.2 LEUART Asynchronous Frame Format on page 693](#).



**Figure 20.2. LEUART Asynchronous Frame Format**

The number of data bits in a frame is set by DATABITS in LEUARTn\_CTRL, and the number of stop-bits is set by STOPBITS in LEUARTn\_CTRL. Whether or not a parity bit should be included, and whether it should be even or odd is defined by PARITY in LEUARTn\_CTRL. For communication to be possible, all parties of an asynchronous transfer must agree on the frame format being used.

The frame format used by the LEUART can be inverted by setting INV in LEUARTn\_CTRL. This affects the entire frame, resulting in a low idle state, a high start-bit, inverted data and parity bits, and low stop-bits. INV should only be changed while the receiver is disabled.

#### 20.3.1.1 Parity Bit Calculation and Handling

Hardware automatically inserts parity bits into outgoing frames and checks the parity bits of incoming frames. The possible parity modes are defined in [Table 20.1 LEUART Parity Bit on page 693](#). When even parity is chosen, a parity bit is inserted to make the number of high bits (data + parity) even. If odd parity is chosen, the parity bit makes the total number of high bits odd. When parity bits are disabled, which is the default configuration, the parity bit is omitted.

**Table 20.1. LEUART Parity Bit**

PARITY [1:0]	Description
00	No parity (default)
01	Reserved
10	Even parity
11	Odd parity

See [20.3.5.4 Parity Error](#) for more information on parity bit handling.

#### 20.3.2 Clock Source

The LEUART clock source is selected by the LFB bit field the CMU\_LFBCLKSEL register. The clock is prescaled by the LEUARTn bitfield in the CMU\_LFBPRESC0 register and enabled by the LEUARTn bit in the CMU\_LFBCLKEN0. See [Figure 10.2 CMU Overview - Low Frequency Portion on page 298](#) for a diagram of the clocking structure.

To use this module, the LE interface clock must be enabled in CMU\_HFBUSCLKEN0, in addition to the module clock.

### 20.3.3 Clock Generation

The LEUART clock defines the transmission and reception data rate. The clock generator employs a fractional clock divider to allow baud rates that are not attainable by integral division of the 32.768 kHz clock that drives the LEUART.

The clock divider used in the LEUART is a 14-bit value, with a 9-bit integral part and a 5-bit fractional part. The baud rate of the LEUART is given by :

$$br = f_{LEUARTn} / (1 + LEUARTn\_CLKDIV / 256)$$

**Figure 20.3. LEUART Baud Rate Equation**

where  $f_{LEUARTn}$  is the clock frequency supplied to the LEUART. The value of  $LEUARTn\_CLKDIV$  thus defines the baud rate of the LEUART. The integral part of the divider is right-aligned in the upper 24 bits of  $LEUARTn\_CLKDIV$  and the fractional part is left-aligned in the lower 8 bits. The divider is thus a 256th of  $LEUARTn\_CLKDIV$  as seen in the equation.

As an example let us assume  $f_{LEUART} = 22.5$  kHz and the value of DIV in  $LEUARTn\_CLKDIV$  is 0x0028 ( $LEUARTn\_CLKDIV = 0x00000140$ ). The baud rate =  $22.5$  kHz /  $(1 + 0x140 / 256)$  =  $22.5$  kHz /  $2.25$  =  $10$  kHz.

For a desired baud rate  $br_{DESIRED}$ ,  $LEUARTn\_CLKDIV$  can be calculated by using:

$$LEUARTn\_CLKDIV = 256 \times (f_{LEUARTn}/br_{DESIRED} - 1)$$

**Figure 20.4. LEUART CLKDIV Equation**

It's important to note that this equation results in a 32bit value for the  $LEUARTn\_CLKDIV$  register but only bits [16:3] are valid and all others must be 0. For example if we have a 32 kHz clock and whish to achieve a baud rate of 10 kHz the equation above results in a  $LEUARTn\_CLKDIV$  value of 0x233. However, the actual value of the register will be 0x230 since bits [2:0] cannot be set. This limits the best achievable accuracy. In this example the actual baud rate will be  $32$  kHz /  $(1 + 0x230 / 255)$  =  $10.039$  kHz instead of  $32$  kHz /  $(1 + 0x233 / 255)$  =  $10.002$  kHz.

[Table 20.2 LEUART Baud Rates on page 694](#) lists a set of desired baud rates and the closest baud rates reachable by the LEUART with a 32.768 kHz clock source. It also shows the average baud rate error.

**Table 20.2. LEUART Baud Rates**

Desired baud rate	LEUARTn_CLKDIV	LEUARTn_CLKDIV/256	Actual Baud Rate	Error [%]
300	27704	108.21875	300.0217	0.01
600	13728	53.625	599.8719	-0.02
1200	6736	26.3125	1199.744	-0.02
2400	3240	12.65625	2399.487	-0.02
4800	1488	5.8125	4809.982	0.21
9600	616	2.40625	9619.963	0.21

### 20.3.4 Data Transmission

Data transmission is initiated by writing data to the transmit buffer using one of the methods described in [20.3.4.1 Transmit Buffer Operation](#). When the transmit shift register is empty and ready for new data, a frame from the transmit buffer is loaded into the shift register, and if the transmitter is enabled, transmission begins. When the frame has been transmitted, a new frame is loaded into the shift register if available, and transmission continues. If the transmit buffer is empty, the transmitter goes to an idle state, waiting for a new frame to become available. Transmission is enabled through the command register  $LEUARTn\_CMD$  by setting  $TXEN$ , and disabled by setting  $TXDIS$ . When the transmitter is disabled using  $TXDIS$ , any ongoing transmission is aborted, and any frame currently being transmitted is discarded. When disabled, the TX output goes to an idle state, which by default is a high value. Whether or not the transmitter is enabled at a given time can be read from  $TXENS$  in  $LEUARTn\_STATUS$ . After a transmission, when there is no more data in the shift register or transmit buffer, the  $TXC$  flag in  $LEUARTn\_STATUS$  and the  $TXC$  interrupt flag in  $LEUARTn\_IF$  are set, signaling that the transmitter is idle. The  $TXC$  status flag is cleared when a new byte becomes available for transmission, but the  $TXC$  interrupt flag must be cleared by software.

#### 20.3.4.1 Transmit Buffer Operation


A frame can be loaded into the transmit buffer by writing to LEUARTn\_TXDATA or LEUARTn\_TXDATAX. Using LEUARTn\_TXDATA allows 8 bits to be written to the buffer. If 9 bit frames are used, the 9th bit will in that case be set to the value of BIT8DV in LEUARTn\_CTRL. To set the 9th bit directly and/or use transmission control, LEUARTn\_TXDATAX must be used. When writing data to the transmit buffer using LEUARTn\_TXDATAX, the 9th bit written to LEUARTn\_TXDATAX overrides the value in BIT8DV, and alone defines the 9th bit that is transmitted if 9-bit frames are used.

If a write is attempted to the transmit buffer when it is not empty, the TXOF interrupt flag in LEUARTn\_IF is set, indicating the overflow. The data already in the buffer is in that case preserved, and no data is written.

In addition to the interrupt flag TXC in LEUARTn\_IF and the status flag TXC in LEUARTn\_STATUS which are set when the transmitter becomes idle, TXBL in LEUARTn\_STATUS and the TXBL interrupt flag in LEUARTn\_IF are used to indicate the level of the transmit buffer. Whenever the transmit buffer becomes empty, these flags are set high. Both the TXBL status flag and the TXBL interrupt flag are cleared automatically when data is written to the transmit buffer.

There is also TXIDLE status in LEUART\_STATUS which can be used to detect when the transmit state machine is in the idle state.

The transmit buffer, including the TX shift register can be cleared by setting command bit CLEARTX in LEUARTn\_CMD. This will prevent the LEUART from transmitting the data in the buffer and shift register, and will make them available for new data. Any frame currently being transmitted will not be aborted. Transmission of this frame will be completed. An overview of the operation of the transmitter is shown in [Figure 20.5 LEUART Transmitter Overview on page 695](#).



**Figure 20.5. LEUART Transmitter Overview**

#### 20.3.4.2 Frame Transmission Control

The transmission control bits, which can be written using LEUARTn\_TXDATAX, affect the transmission of the written frame. The following options are available:

- Generate break: By setting TXBREAK, the output will be held low during the first stop-bit period to generate a framing error. A receiver that supports break detection detects this state, allowing it to be used e.g. for framing of larger data packets. The line is driven high for one bit period before the next frame is transmitted so the next start condition can be identified correctly by the recipient. Continuous breaks lasting longer than an UART frame are thus not supported by the LEUART. GPIO can be used for this. Note that when AUTOTRI in LEUARTn\_CTRL is used, the transmitter is not tristated before the high-bit after the break has been transmitted.
- Disable transmitter after transmission: If TXDISAT is set, the transmitter is disabled after the frame has been fully transmitted.
- Enable receiver after transmission: If RXENAT is set, the receiver is enabled after the frame has been fully transmitted. It is enabled in time to detect a start-bit directly after the last stop-bit has been transmitted.

The transmission control bits in the LEUART cannot tristate the transmitter. This is performed automatically by hardware if AUTOTRI in LEUARTn\_CTRL is set. See [20.3.7 Half Duplex Communication](#) for more information on half duplex operation.

### 20.3.5 Data Reception

Data reception is enabled by setting RXEN in LEUARTn\_CMD. When the receiver is enabled, it actively samples the input looking for a transition from high to low indicating the start bit of a new frame. When a start bit is found, reception of the new frame begins if the receive shift register is empty and ready for new data. When the frame has been received, it is pushed into the receive buffer, making the shift register ready for another frame of data, and the receiver starts looking for another start bit. If the receive buffer is full, the received frame remains in the shift register until more space in the receive buffer is available.

If an incoming frame is detected while both the receive buffer and the receive shift register are full, the data in the receive shift register is overwritten, and the RXOF interrupt flag in LEUARTn\_IF is set to indicate the buffer overflow.

The receiver can be disabled by setting the command bit RXDIS in LEUARTn\_CMD. Any frame currently being received when the receiver is disabled is discarded. Whether or not the receiver is enabled at a given time can be read out from RXENS in LEUARTn\_STATUS.

The receive buffer can be cleared by setting command bit CLEARRX in LEUARTn\_CMD. This will make it available for new data. Any frame currently being received will not be aborted and will become the first received frame when complete.

#### 20.3.5.1 Receive Buffer Operation


When data becomes available in the receive buffer, the RXDATAV flag in LEUARTn\_STATUS and the RXDATAV interrupt flag in LEUARTn\_IF are set. Both the RXDATAV status flag and the RXDATAV interrupt flag are cleared by hardware when data is no longer available, i.e. when data has been read out of the buffer.

Data can be read from receive buffer using either LEUARTn\_RXDATA or LEUARTn\_RXDATAX. LEUARTn\_RXDATA gives access to the 8 least significant bits of the received frame, while LEUARTn\_RXDATAX must be used to get access to the 9th, most significant bit. The LEUARTn\_RXDATAX register also contains status information regarding the frame.

When a frame is read from the receive buffer using LEUARTn\_RXDATA or LEUARTn\_RXDATAX, the frame is removed from the buffer, making room for a new one. If an attempt is done to read more frames from the buffer than what is available, the RXUF interrupt flag in LEUARTn\_IF is set to signal the underflow, and the data read from the buffer is undefined.

Frames can also be read from the receive buffer without removing the data by using LEUARTn\_RXDATAXP, which gives access to the frame in the buffer including control bits. Data read from this register when the receive buffer is empty is undefined. No underflow interrupt is generated by a read using LEUARTn\_RXDATAXP, i.e. the RXUF interrupt flag is never set as a result of reading from LEUARTn\_RXDATAXP.

An overview of the operation of the receiver is shown in [Figure 20.6 LEUART Receiver Overview on page 696](#).



**Figure 20.6. LEUART Receiver Overview**

### 20.3.5.2 Blocking Incoming Data

When using hardware frame recognition, as detailed in [20.3.5.6 Programmable Start Frame](#), [20.3.5.7 Programmable Signal Frame](#), and [20.3.5.8 Multi-Processor Mode](#), it is necessary to be able to let the receiver sample incoming frames without passing the frames to software by loading them into the receive buffer. This is accomplished by blocking incoming data.

Incoming data is blocked as long as RXBLOCK in LEUARTn\_STATUS is set. When blocked, frames received by the receiver will not be loaded into the receive buffer, and software is not notified by the RXDATAV bit in LEUARTn\_STATUS or the RXDATAV interrupt flag in LEUARTn\_IF at their arrival. For data to be loaded into the receive buffer, RXBLOCK must be cleared in the instant a frame is fully received by the receiver. RXBLOCK is set by setting RXBLOCKEN in LEUARTn\_CMD and disabled by setting RXBLOCKDIS also in LEUARTn\_CMD. There are two exceptions where data is loaded into the receive buffer even when RXBLOCK is set. The first is when an address frame is received when in operating in multi-processor mode as shown in [20.3.5.8 Multi-Processor Mode](#). The other case is when receiving a start-frame when SFUBRX in LEUARTn\_CTRL is set; see [20.3.5.6 Programmable Start Frame](#)

Frames received containing framing or parity errors will not result in the FERR and PERR interrupt flags in LEUARTn\_IF being set while RXBLOCK is set. Hardware recognition is not applied to these erroneous frames, and they are silently discarded.

**Note:**

- If a frame is received while RXBLOCK in LEUARTn\_STATUS is cleared, but stays in the receive shift register because the receive buffer is full, the received frame will be loaded into the receive buffer when space becomes available even if RXBLOCK is set at that time.
- The overflow interrupt flag RXOF in LEUARTn\_IF will be set if a frame in the receive shift register, waiting to be loaded into the receive buffer is overwritten by an incoming frame even though RXBLOCK is set.

### 20.3.5.3 Data Sampling

The receiver samples each incoming bit as close as possible to the middle of the bit-period. Except for the start-bit, only a single sample is taken of each of the incoming bits.

The length of a bit-period is given by  $1 + \text{LEUARTn\_CLKDIV}/256$ , as a number of 32.768 kHz clock periods. Let the clock cycle where a start-bit is first detected be given the index 0. The optimal sampling point for each bit in the UART frame is then given by the following equation:

$$S_{\text{opt}}(n) = n (1 + \text{LEUARTn\_CLKDIV}/256) + \text{LEUARTn\_CLKDIV}/512$$

**Figure 20.7. LEUART Optimal Sampling Point**

where n is the bit-index.

Since samples are only done on the positive edges of the 32.768 kHz clock, the actual samples are performed on the closest positive edge, i.e. the edge given by the following equation:

$$S(n) = \text{floor}(n x (1 + \text{LEUARTn\_CLKDIV}/256) + \text{LEUARTn\_CLKDIV}/512)$$

**Figure 20.8. LEUART Actual Sampling Point**

The sampling location will thus have jitter according to difference between  $S_{\text{opt}}$  and S. The start-bit is found at n=0, then follows the data bits, any parity bit, and the stop bits.

If the value of the start-bit is found to be high, then the start-bit is discarded, and the receiver waits for a new start-bit.

### 20.3.5.4 Parity Error

When the parity bit is enabled, a parity check is automatically performed on incoming frames. When a parity error is detected in a frame, the data parity error bit PERR in the frame is set, as well as the interrupt flag PERR. Frames with parity errors are loaded into the receive buffer like regular frames.

PERR can be accessed by reading the frame from the receive buffer using the LEUARTn\_RXDATAX register.

### 20.3.5.5 Framing Error and Break Detection

A framing error is the result of a received frame where the stop bit was sampled to a value of 0. This can be the result of noise and baud rate errors, but can also be the result of a break generated by the transmitter on purpose.

When a framing error is detected, the framing error bit FERR in the received frame is set. The interrupt flag FERR in LEUARTn\_IF is also set. Frames with framing errors are loaded into the receive buffer like regular frames.

FERR can be accessed by reading the frame from the receive buffer using the LEUARTn\_RXDATA or LEUARTn\_RXDATAXP registers.

### 20.3.5.6 Programmable Start Frame

The LEUART can be configured to start receiving data when a special start frame is detected on the input. This can be useful when operating in low energy modes, allowing other devices to gain the attention of the LEUART by transmitting a given frame.

When SFUBRX in LEUARTn\_CTRL is set, an incoming frame matching the frame defined in LEUARTn\_STARTFRAME will result in RXBLOCK in LEUARTn\_STATUS being cleared. This can be used to enable reception when a specified start frame is detected. If the receiver is enabled and blocked, i.e. RXENS and RXBLOCK in LEUARTn\_STATUS are set, the receiver will receive all incoming frames, but unless an incoming frame is a start frame it will be discarded and not loaded into the receive buffer. When a start frame is detected, the block is cleared, and frames received from that point, including the start frame, are loaded into the receive buffer.

An incoming start frame results in the STARTF interrupt flag in LEUARTn\_IF being set, regardless of the value of SFUBRX in LEUARTn\_CTRL. This allows an interrupt to be made when the start frame is detected.

When 8 data-bit frame formats are used, only the 8 least significant bits of LEUARTn\_STARTFRAME are compared to incoming frames. The full length of LEUARTn\_STARTFRAME is used when operating with frames consisting of 9 data bits.

**Note:** The receiver must be enabled for start frames to be detected. In addition, a start frame with a parity error or framing error is not detected as a start frame.

### 20.3.5.7 Programmable Signal Frame

As well as the configurable start frame, a special signal frame can be specified. When a frame matching the frame defined in LEUARTn\_SIGFRAME is detected by the receiver, the SIGF interrupt flag in LEUARTn\_IF is set. As for start frame detection, the receiver must be enabled for signal frames to be detected.

One use of the programmable signal frame is to signal the end of a multi-frame message transmitted to the LEUART. An interrupt will then be triggered when the packet has been completely received, allowing software to process it. Used in conjunction with the programmable start frame and DMA, this makes it possible for the LEUART to automatically begin the reception of a packet on a specified start frame, load the entire packet into memory, and give an interrupt when reception of a packet has completed. The device can thus wait for data packets in EM2 DeepSleep, and only be woken up when a packet has been completely received.

A signal frame with a parity error or framing error is not detected as a signal frame.

### 20.3.5.8 Multi-Processor Mode

To simplify communication between multiple processors and maintain compatibility with the USART, the LEUART supports a multi-processor mode. In this mode the 9th data bit in each frame is used to indicate whether the content of the remaining 8 bits is data or an address.

When multi-processor mode is enabled, an incoming 9-bit frame with the 9th bit equal to the value of MPAB in LEUARTn\_CTRL is identified as an address frame. When an address frame is detected, the MPAF interrupt flag in LEUARTn\_IF is set, and the address frame is loaded into the receive register. This happens regardless of the value of RXBLOCK in LEUARTn\_STATUS.


Multi-processor mode is enabled by setting MPM in LEUARTn\_CTRL. The mode can be used in buses with multiple slaves, allowing the slaves to be addressed using the special address frames. An addressed slave, which was previously blocking reception using RXBLOCK, would then unblock reception, receive a message from the bus master, and then block reception again, waiting for the next message. See the USART for a more detailed example.

**Note:** The programmable start frame functionality can be used for automatic address matching, enabling reception on a correctly configured incoming frame.

An address frame with a parity error or a framing error is not detected as an address frame. The Start, Signal, and address frames should not be set to match the same frame since each of these uses separate synchronization to the peripheral clock domain.

### 20.3.6 Loopback

The LEUART receiver samples LEUn\_RX by default, and the transmitter drives LEUn\_TX by default. This is not the only configuration however. When LOOPBK in LEUARTn\_CTRL is set, the receiver is connected to the LEUn\_TX pin as shown in [Figure 20.9 LEUART Local Loopback on page 699](#). This is useful for debugging, as the LEUART can receive the data it transmits, but it is also used to allow the LEUART to read and write to the same pin, which is required for some half duplex communication modes. In this mode, the LEUn\_TX pin must be enabled as an output in the GPIO.



**Figure 20.9. LEUART Local Loopback**

### 20.3.7 Half Duplex Communication

When doing full duplex communication, two data links are provided, making it possible for data to be sent and received at the same time. In half duplex mode, data is only sent in one direction at a time. There are several possible half duplex setups, as described in the following sections.

#### 20.3.7.1 Single Data-link

In this setup, the LEUART both receives and transmits data on the same pin. This is enabled by setting LOOPBK in LEUARTn\_CTRL, which connects the receiver to the transmitter output. Because they are both connected to the same line, it is important that the LEUART transmitter does not drive the line when receiving data, as this would corrupt the data on the line.


When communicating over a single data-link, the transmitter must thus be tristated whenever not transmitting data. If AUTOTRI in LEUARTn\_CTRL is set, the LEUART automatically tristates LEUn\_TX whenever the transmitter is inactive. It is then the responsibility of the software protocol to make sure the transmitter is not transmitting data whenever incoming data is expected.

The transmitter can also be tristated from software by configuring the GPIO pin as an input and disabling the LEUART output on LEUn\_TX.

**Note:** Another way to tristate the transmitter is to enable wired-and or wired-or mode in GPIO. For wired-and mode, outputting a 1 will be the same as tristating the output, and for wired-or mode, outputting a 0 will be the same as tristating the output. This can only be done on buses with a pull-up or pull-down resistor respectively.

### 20.3.7.2 Single Data-link With External Driver

Some communication schemes, such as RS-485 rely on an external driver. Here, the driver has an extra input which enables it, and instead of Tristating the transmitter when receiving data, the external driver must be disabled. The USART has hardware support for automatically turning the driver on and off. When using the LEUART in such a setup, the driver must be controlled by a GPIO. [Figure 20.10 LEUART Half Duplex Communication with External Driver on page 700](#) shows an example configuration using an external driver.



**Figure 20.10. LEUART Half Duplex Communication with External Driver**

### 20.3.7.3 Two Data-links

Some limited devices only support half duplex communication even though two data links are available. In this case software is responsible for making sure data is not transmitted when incoming data is expected.

### 20.3.8 Transmission Delay

By configuring TXDELAY in LEUARTn\_CTRL, the transmitter can be forced to wait a number of bit-periods from when it is ready to transmit data, to when it actually transmits the data. This delay is only applied to the first frame transmitted after the transmitter has been idle. When transmitting frames back-to-back the delay is not introduced between the transmitted frames.

This is useful on half duplex buses, because the receiver always returns received frames to software during the first stop-bit. The bus may still be driven for up to 3 bit periods, depending on the current frame format. Using the transmission delay, a transmission can be started when a frame is received, and it is possible to make sure that the transmitter does not begin driving the output before the frame on the bus is completely transmitted.

To route the UART TX and RX signals to a pin first select the desired pins using the RXLOC and TXLOC fields in the LEUARTn\_ROUTTELOC0 register. Then enable the connection using TXPEN and RXPEN in the LEUARTn\_ROUTPEN register. See the device data sheet for mappings between UART locations (LOC0, LOC1, etc.) and device pins (PA0, PA1, etc.).

### 20.3.9 PRS RX Input

In addition to receiving data on an external pin the LEUART can be configured to receive data directly from a PRS channel by setting RX\_PRS in LEUARTn\_INPUT. The PRS channel used can be selected using RX\_PRS\_SEL in LEUARTn\_INPUT. See the PRS chapter for more details on the PRS block.

For example the output of a comparator could be routed to the LEUART through the PRS to allow for receiving a signal with low peak-to-peak voltage or a significant DC offset.

### 20.3.10 DMA Support

The LEUART has full DMA support in energy modes EM0 Active – EM2 DeepSleep. The DMA controller can write to the transmit buffer using the registers LEUARTn\_TXDATA and LEUARTn\_RXDATA, and it can read from receive buffer using the registers LEUARTn\_RXDATA and LEUARTn\_RXDATA. This enables single byte transfers and 9 bit data + control/status bits transfers both to and from the LEUART. The DMA will start up the HFRCO and run from this when it is waken by the LEUART in EM2. The HFRCO is disabled once the transaction is done.

A request for the DMA controller to read from the receive buffer can come from one of the following sources:

- Receive buffer full

A write request can come from one of the following sources:

- Transmit buffer and shift register empty. No data to send.
- Transmit buffer empty


In some cases, it may be sensible to temporarily stop DMA access to the LEUART when a parity or framing error has occurred. This is enabled by setting ERRSDMA in LEUARTn\_CTRL. When this bit is set, the DMA controller will not get requests from the receive buffer if a framing error or parity error is detected in the received byte. The ERRSDMA bit applies only to the RX DMA.

When operating in EM2 DeepSleep, the DMA controller must be powered up in order to perform the transfer. This is automatically performed for read operations if RXDMAWU in LEUARTn\_CTRL is set and for write operations if TXDMAWU in LEUARTn\_CTRL is set. To make sure the DMA controller still transfers bits to and from the LEUART in low energy modes, these bits must thus be configured accordingly.

**Note:** When RXDMAWU or TXDMAWU is set, the system will not be able to go to EM2 DeepSleep/EM3 Stop before all related LEUART DMA requests have been processed. This means that if RXDMAWU is set and the LEUART receives a frame, the system will not be able to go to EM2 DeepSleep/EM3 Stop before the frame has been read from the LEUART. In order for the system to go to EM2 during the last byte transmission, LEUART\_CTRL\_TXDMAWU must be cleared in the DMA interrupt service routine. This is because TXBL will be high during that last byte transfer.

### 20.3.11 Pulse Generator/ Pulse Extender

The LEUART has an optional pulse generator for the transmitter output, and a pulse extender on the receiver input. These are enabled by setting PULSEEN in LEUARTn\_PULSECTRL, and with INV in LEUARTn\_CTRL set, they will change the output/input format of the LEUART from NRZ to RZI as shown in [Figure 20.11 LEUART - NRZ vs. RZI on page 701](#).



**Figure 20.11. LEUART - NRZ vs. RZI**

If PULSEEN in LEUARTn\_PULSECTRL is set while INV in LEUARTn\_CTRL is cleared, the output waveform will look like RZI shown in [Figure 20.11 LEUART - NRZ vs. RZI on page 701](#), only inverted.

The width of the pulses from the pulse generator can be configured using PULSEW in LEUARTn\_PULSECTRL. The generated pulse width is PULSEW + 1 cycles of the 32.768 kHz clock, which makes pulse width from 31.25µs to 500µs possible.

Since the incoming signal is only sampled on positive clock edges, the width of the incoming pulses must be at least two 32.768 kHz clock periods wide for reliable detection by the LEUART receiver. They must also be shorter than half a UART bit period.

At 2400 baud or lower, the pulse generator is able to generate RZI pulses compatible with the IrDA physical layer specification. The external IrDA device must generate pulses of sufficient length for successful two-way communication.

PULSEFILT in the LEUARTn\_PULSECTRL register can be used to extend the minimum receive pulse width from 2 clock periods to 3 clock periods.

### 20.3.11.1 Interrupts

The interrupts generated by the LEUART are combined into one interrupt vector. If LEUART interrupts are enabled, an interrupt will be made if one or more of the interrupt flags in LEUARTn\_IF and their corresponding bits in LEUART\_IEN are set.

### 20.3.12 Register Access

Since this module is a Low Energy Peripheral, and runs off a clock which is asynchronous to the HFCORECLK, special considerations must be taken when accessing registers. Refer to [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#) for a description on how to perform register accesses to Low Energy Peripherals.

The registers LEUARTn\_FREEZE and LEUARTn\_SYNCBUSY are used for synchronization of this peripheral.

## 20.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	LEUARTn_CTRL	RW	Control Register
0x004	LEUARTn_CMD	W1	Command Register
0x008	LEUARTn_STATUS	R	Status Register
0x00C	LEUARTn_CLKDIV	RW	Clock Control Register
0x010	LEUARTn_STARTFRAME	RW	Start Frame Register
0x014	LEUARTn_SIGFRAME	RW	Signal Frame Register
0x018	LEUARTn_RXDATA	R(a)	Receive Buffer Data Extended Register
0x01C	LEUARTn_RXDATA	R(a)	Receive Buffer Data Register
0x020	LEUARTn_RXDATAXP	R	Receive Buffer Data Extended Peek Register
0x024	LEUARTn_TXDATA	W	Transmit Buffer Data Extended Register
0x028	LEUARTn_TXDATA	W	Transmit Buffer Data Register
0x02C	LEUARTn_IF	R	Interrupt Flag Register
0x030	LEUARTn_IFS	W1	Interrupt Flag Set Register
0x034	LEUARTn_IFC	(R)W1	Interrupt Flag Clear Register
0x038	LEUARTn_IEN	RW	Interrupt Enable Register
0x03C	LEUARTn_PULSECTRL	RW	Pulse Control Register
0x040	LEUARTn_FREEZE	RW	Freeze Register
0x044	LEUARTn_SYNCBUSY	R	Synchronization Busy Register
0x054	LEUARTn_ROUTEPEN	RW	I/O Routing Pin Enable Register
0x058	LEUARTn_ROUTELOC0	RW	I/O Routing Location Register
0x064	LEUARTn_INPUT	RW	LEUART Input Register

## 20.5 Register Description

### 20.5.1 LEUARTn\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																	0x0																		
Access																	RW																		
Name																	TXDELAY																		

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:14	<b>TXDELAY</b>	0x0	RW	<b>TX Delay Transmission</b>  Configurable delay before new transfers. Frames sent back-to-back are not delayed.
	Value	Mode		Description
	0	NONE		Frames are transmitted immediately
	1	SINGLE		Transmission of new frames are delayed by a single bit period
	2	DOUBLE		Transmission of new frames are delayed by two bit periods
	3	TRIPLE		Transmission of new frames are delayed by three bit periods
13	<b>TXDMAWU</b>	0	RW	<b>TX DMA Wakeup</b>  Set to wake the DMA controller up when in EM2 and space is available in the transmit buffer.
	Value			Description
	0			While in EM2, the DMA controller will not get requests about space being available in the transmit buffer
	1			DMA is available in EM2 for the request about space available in the transmit buffer
12	<b>RXDMAWU</b>	0	RW	<b>RX DMA Wakeup</b>  Set to wake the DMA controller up when in EM2 and data is available in the receive buffer.
	Value			Description
	0			While in EM2, the DMA controller will not get requests about data being available in the receive buffer
	1			DMA is available in EM2 for the request about data in the receive buffer
11	<b>BIT8DV</b>	0	RW	<b>Bit 8 Default Value</b>  When 9-bit frames are transmitted, the default value of the 9th bit is given by BIT8DV. If TXDATA is used to write a frame, then the value of BIT8DV is assigned to the 9th bit of the outgoing frame. If a frame is written with TXDATAX however, the default value is overridden by the written value.

Bit	Name	Reset	Access	Description						
10	MPAB	0	RW	<b>Multi-Processor Address-Bit</b>  Defines the value of the multi-processor address bit. An incoming frame with its 9th bit equal to the value of this bit marks the frame as a multi-processor address frame.						
9	MPM	0	RW	<b>Multi-Processor Mode</b>  Set to enable multi-processor mode.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>The 9th bit of incoming frames have no special function</td></tr> <tr> <td>1</td><td>An incoming frame with the 9th bit equal to MPAB will be loaded into the receive buffer regardless of RXBLOCK and will result in the MPAB interrupt flag being set</td></tr> </tbody> </table>	Value	Description	0	The 9th bit of incoming frames have no special function	1	An incoming frame with the 9th bit equal to MPAB will be loaded into the receive buffer regardless of RXBLOCK and will result in the MPAB interrupt flag being set
Value	Description									
0	The 9th bit of incoming frames have no special function									
1	An incoming frame with the 9th bit equal to MPAB will be loaded into the receive buffer regardless of RXBLOCK and will result in the MPAB interrupt flag being set									
8	SFUBRX	0	RW	<b>Start-Frame UnBlock RX</b>  Clears RXBLOCK when the start-frame is found in the incoming data. The start-frame is loaded into the receive buffer.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Detected start-frames have no effect on RXBLOCK</td></tr> <tr> <td>1</td><td>When a start-frame is detected, RXBLOCK is cleared and the start-frame is loaded into the receive buffer</td></tr> </tbody> </table>	Value	Description	0	Detected start-frames have no effect on RXBLOCK	1	When a start-frame is detected, RXBLOCK is cleared and the start-frame is loaded into the receive buffer
Value	Description									
0	Detected start-frames have no effect on RXBLOCK									
1	When a start-frame is detected, RXBLOCK is cleared and the start-frame is loaded into the receive buffer									
7	LOOPBK	0	RW	<b>Loopback Enable</b>  Set to connect receiver to LEUn_TX instead of LEUn_RX.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>The receiver is connected to and receives data from LEUn_RX</td></tr> <tr> <td>1</td><td>The receiver is connected to and receives data from LEUn_TX</td></tr> </tbody> </table>	Value	Description	0	The receiver is connected to and receives data from LEUn_RX	1	The receiver is connected to and receives data from LEUn_TX
Value	Description									
0	The receiver is connected to and receives data from LEUn_RX									
1	The receiver is connected to and receives data from LEUn_TX									
6	ERRSDMA	0	RW	<b>Clear RX DMA on Error</b>  When set, RX DMA requests will be cleared on framing and parity errors.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Framing and parity errors have no effect on DMA requests from the LEUART</td></tr> <tr> <td>1</td><td>RX DMA requests from the LEUART are disabled if a framing error or parity error occurs.</td></tr> </tbody> </table>	Value	Description	0	Framing and parity errors have no effect on DMA requests from the LEUART	1	RX DMA requests from the LEUART are disabled if a framing error or parity error occurs.
Value	Description									
0	Framing and parity errors have no effect on DMA requests from the LEUART									
1	RX DMA requests from the LEUART are disabled if a framing error or parity error occurs.									
5	INV	0	RW	<b>Invert Input and Output</b>  Set to invert the output on LEUn_TX and input on LEUn_RX.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>A high value on the input/output is 1, and a low value is 0.</td></tr> <tr> <td>1</td><td>A low value on the input/output is 1, and a high value is 0.</td></tr> </tbody> </table>	Value	Description	0	A high value on the input/output is 1, and a low value is 0.	1	A low value on the input/output is 1, and a high value is 0.
Value	Description									
0	A high value on the input/output is 1, and a low value is 0.									
1	A low value on the input/output is 1, and a high value is 0.									
4	STOPBITS	0	RW	<b>Stop-Bit Mode</b>  Determines the number of stop-bits used. Only used when transmitting data. The receiver only verifies that one stop bit is present.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> </table>	Value	Mode	Description			
Value	Mode	Description								

Bit	Name	Reset	Access	Description
	0	ONE		One stop-bit is transmitted with every frame
	1	TWO		Two stop-bits are transmitted with every frame
3:2	PARITY	0x0	RW	<b>Parity-Bit Mode</b>
				Determines whether parity bits are enabled, and whether even or odd parity should be used.
	Value	Mode		Description
	0	NONE		Parity bits are not used
	2	EVEN		Even parity are used. Parity bits are automatically generated and checked by hardware.
	3	ODD		Odd parity is used. Parity bits are automatically generated and checked by hardware.
1	DATABITS	0	RW	<b>Data-Bit Mode</b>
				This register sets the number of data bits.
	Value	Mode		Description
	0	EIGHT		Each frame contains 8 data bits
	1	NINE		Each frame contains 9 data bits
0	AUTOTRI	0	RW	<b>Automatic Transmitter Tristate</b>
				When set, LEUn_TX is tristated whenever the transmitter is inactive.
	Value			Description
	0			LEUn_TX is held high when the transmitter is inactive. INV inverts the inactive state.
	1			LEUn_TX is tristated when the transmitter is inactive

### 20.5.2 LEUARTn\_CMD - Command Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																									
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8		
Access	W1	0	7	6	5	4	3	2	1	0	W1															
Name	CLEARRX	CLEARTX	RXBLOCKDIS	RXBLOCKEN	TXDIS	TXEN	RXDIS	RXEN																		

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	CLEARRX	0	W1	<b>Clear RX</b>  Set to clear receive buffer and the RX shift register.
6	CLEARTX	0	W1	<b>Clear TX</b>  Set to clear transmit buffer and the TX shift register.
5	RXBLOCKDIS	0	W1	<b>Receiver Block Disable</b>  Set to clear RXBLOCK, resulting in all incoming frames being loaded into the receive buffer.
4	RXBLOCKEN	0	W1	<b>Receiver Block Enable</b>  Set to set RXBLOCK, resulting in all incoming frames being discarded.
3	TXDIS	0	W1	<b>Transmitter Disable</b>  Set to disable transmission.
2	TXEN	0	W1	<b>Transmitter Enable</b>  Set to enable data transmission.
1	RXDIS	0	W1	<b>Receiver Disable</b>  Set to disable data reception. If a frame is under reception when the receiver is disabled, the incoming frame is discarded.
0	RXEN	0	W1	<b>Receiver Enable</b>  Set to activate data reception on LEUn_RX.

### 20.5.3 LEUARTn\_STATUS - Status Register

Offset	Bit Position																																
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6	TXIDLE	1	R	<b>TX Idle</b>  Set when TX is idle
5	RXDATAV	0	R	<b>RX Data Valid</b>  Set when data is available in the receive buffer. Cleared when the receive buffer is empty.
4	TXBL	1	R	<b>TX Buffer Level</b>  Indicates the level of the transmit buffer. Set when the transmit buffer is empty, and cleared when it is full.
3	TXC	0	R	<b>TX Complete</b>  Set when a transmission has completed and no more data is available in the transmit buffer. Cleared when a new transmission starts.
2	RXBLOCK	0	R	<b>Block Incoming Data</b>  When set, the receiver discards incoming frames. An incoming frame will not be loaded into the receive buffer if this bit is set at the instant the frame has been completely received.
1	TXENS	0	R	<b>Transmitter Enable Status</b>  Set when the transmitter is enabled.
0	RXENS	0	R	<b>Receiver Enable Status</b>  Set when the receiver is enabled. The receiver must be enabled for start frames, signal frames, and multi-processor address bit detection.

#### 20.5.4 LEUARTn\_CLKDIV - Clock Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																															
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:17	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
16:3	DIV	0x0000	RW	<b>Fractional Clock Divider</b>
		Specifies the fractional clock divider for the LEUART. Bits [7:3] are the fractional part and bits [16:8] are the integer part. The total divider is $([16:8] + [7:3]/32)$ . To make the math easier the total divider can also be calculated as $'([16:8] + [7:0])/256'$ where bits [0:2] will always be 0.		
2:0	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		

#### 20.5.5 LEUARTn\_STARTFRAME - Start Frame Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																															
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:9	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
8:0	STARTFRAME	0x000	RW	<b>Start Frame</b>
		When a frame matching STARTFRAME is detected by the receiver, STARTF interrupt flag is set, and if SFUBRX is set, RXBLOCK is cleared. The start-frame is be loaded into the RX buffer.		

### 20.5.6 LEUARTn\_SIGFRAME - Signal Frame Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x000																															
Access	RW																															
Name	SIGFRAME																															

Bit	Name	Reset	Access	Description
31:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
8:0	SIGFRAME	0x000	RW	<b>Signal Frame</b>

When a frame matching SIGFRAME is detected by the receiver, SIGF interrupt flag is set.

### 20.5.7 LEUARTn\_RXDATAX - Receive Buffer Data Extended Register (Actionable Reads)

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x000																															
Access	R																															
Name	RXDATA																															

Bit	Name	Reset	Access	Description	
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>			
15	FERR	0	R	<b>Receive Data Framing Error</b>	
	Set if data in buffer has a framing error. Can be the result of a break condition.				
14	PERR	0	R	<b>Receive Data Parity Error</b>	
	Set if data in buffer has a parity error.				
13:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>			
8:0	RXDATA	0x000	R	<b>RX Data</b>	
	Use this register to access data read from the LEUART. Buffer is cleared on read access.				

### 20.5.8 LEUARTn\_RXDATA - Receive Buffer Data Register (Actionable Reads)

Offset	Bit Position																								
0x01C	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																								
Reset																									0x00
Access																									R
Name																									RXDATA

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	RXDATA	0x00	R	<b>RX Data</b>  Use this register to access data read from LEUART. Buffer is cleared on read access. Only the 8 LSB can be read using this register.

### 20.5.9 LEUARTn\_RXDATAXP - Receive Buffer Data Extended Peek Register

Offset	Bit Position																								
0x020	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																								
Reset																									0x000
Access																									R
Name																									RXDATAP

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15	FERRP	0	R	<b>Receive Data Framing Error Peek</b>  Set if data in buffer has a framing error. Can be the result of a break condition.
14	PERRP	0	R	<b>Receive Data Parity Error Peek</b>  Set if data in buffer has a parity error.
13:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8:0	RXDATAP	0x000	R	<b>RX Data Peek</b>  Use this register to access data read from the LEUART.

### 20.5.10 LEUARTn\_TXDATAx - Transmit Buffer Data Extended Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x000																															
Access	W																															
Name	TXDATA																															

Bit	Name	Reset	Access	Description
31:16	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
15	RXENAT	0	W	<b>Enable RX After Transmission</b>
	Set to enable reception after transmission.			
	Value Description			
	0 The receiver is not enabled after the frame has been transmitted			
	1 The receiver is enabled (setting RXENS) after the frame has been transmitted			
14	TXDISAT	0	W	<b>Disable TX After Transmission</b>
	Set to disable transmitter directly after transmission has competed.			
	Value Description			
	0 The transmitter is not disabled after the frame has been transmitted			
	1 The transmitter is disabled (clearing TXENS) after the frame has been transmitted			
13	TXBREAK	0	W	<b>Transmit Data as Break</b>
	Set to send data as a break. Recipient will see a framing error or a break condition depending on its configuration and the value of TXDATA.			
	Value Description			
	0 The specified number of stop-bits are transmitted			
	1 Instead of the ordinary stop-bits, 0 is transmitted to generate a break. A single stop-bit is generated after the break to allow the receiver to detect the start of the next frame			
12:9	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
8:0	TXDATA	0x000	W	<b>TX Data</b>
	Use this register to write data to the LEUART. If the transmitter is enabled, a transfer will be initiated at the first opportunity.			

### 20.5.11 LEUARTn\_TXDATA - Transmit Buffer Data Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0x00		
Access																																W	
Name																																	TXDATA

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	TXDATA	0x00	W	<b>TX Data</b>  This frame will be added to the transmit buffer. Only 8 LSB can be written using this register. 9th bit and control bits will be cleared.

### 20.5.12 LEUARTn\_IF - Interrupt Flag Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																						0	0	0	0	0	0	0	0	0	0	
Access																						R	R	R	R	R	R	R	R	R	R	R
Name																						SIGF	STARTF	MPAF	FERR	PERR	TXOF	RXUF	RXOF	RXDATAV	TXBL	TXC

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10	SIGF	0	R	<b>Signal Frame Interrupt Flag</b>  Set when a signal frame is detected. MPA, START, and SIGNAL should not be set to match the same frame since they use different synchronizers.
9	STARTF	0	R	<b>Start Frame Interrupt Flag</b>  Set when a start frame is detected. MPA, START, and SIGNAL should not be set to match the same frame since they use different synchronizers.
8	MPAF	0	R	<b>Multi-Processor Address Frame Interrupt Flag</b>  Set when a multi-processor address frame is detected. MPA, START, and SIGNAL should not be set to match the same frame since they use different synchronizers.
7	FERR	0	R	<b>Framing Error Interrupt Flag</b>  Set when a frame with a framing error is received while RXBLOCK is cleared.
6	PERR	0	R	<b>Parity Error Interrupt Flag</b>  Set when a frame with a parity error is received while RXBLOCK is cleared.
5	TXOF	0	R	<b>TX Overflow Interrupt Flag</b>  Set when a write is done to the transmit buffer while it is full. The data already in the transmit buffer is preserved.
4	RXUF	0	R	<b>RX Underflow Interrupt Flag</b>  Set when trying to read from the receive buffer when it is empty.
3	RXOF	0	R	<b>RX Overflow Interrupt Flag</b>  Set when data is incoming while the receive shift register is full. The data previously in shift register is overwritten by the new data.
2	RXDATAV	0	R	<b>RX Data Valid Interrupt Flag</b>  Set when data becomes available in the receive buffer.
1	TXBL	1	R	<b>TX Buffer Level Interrupt Flag</b>  Set when space becomes available in the transmit buffer for a new frame.
0	TXC	0	R	<b>TX Complete Interrupt Flag</b>  Set after a transmission when both the TX buffer and shift register are empty.

## 20.5.13 LEUARTn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																																																		
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																			
Reset																									W1	0	W1	0																							
Access																									W1	0	W1	0																							
Name																									SIGF	0	STARTF	W1	0	9	MPAF	W1	0	FERR	W1	0	PERR	W1	0	TXOF	W1	0	RXUF	W1	0	RXOF	W1	0	TXC	W1	0

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	SIGF	0	W1	<b>Set SIGF Interrupt Flag</b> Write 1 to set the SIGF interrupt flag
9	STARTF	0	W1	<b>Set STARTF Interrupt Flag</b> Write 1 to set the STARTF interrupt flag
8	MPAF	0	W1	<b>Set MPAF Interrupt Flag</b> Write 1 to set the MPAF interrupt flag
7	FERR	0	W1	<b>Set FERR Interrupt Flag</b> Write 1 to set the FERR interrupt flag
6	PERR	0	W1	<b>Set PERR Interrupt Flag</b> Write 1 to set the PERR interrupt flag
5	TXOF	0	W1	<b>Set TXOF Interrupt Flag</b> Write 1 to set the TXOF interrupt flag
4	RXUF	0	W1	<b>Set RXUF Interrupt Flag</b> Write 1 to set the RXUF interrupt flag
3	RXOF	0	W1	<b>Set RXOF Interrupt Flag</b> Write 1 to set the RXOF interrupt flag
2:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	TXC	0	W1	<b>Set TXC Interrupt Flag</b> Write 1 to set the TXC interrupt flag

## 20.5.14 LEUARTn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																				
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11
Reset																					
Access																			(R)\W1		
Name																			TXC		

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	SIGF	0	(R)\W1	<b>Clear SIGF Interrupt Flag</b>
				Write 1 to clear the SIGF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	STARTF	0	(R)\W1	<b>Clear STARTF Interrupt Flag</b>
				Write 1 to clear the STARTF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	MPAF	0	(R)\W1	<b>Clear MPAF Interrupt Flag</b>
				Write 1 to clear the MPAF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	FERR	0	(R)\W1	<b>Clear FERR Interrupt Flag</b>
				Write 1 to clear the FERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
6	PERR	0	(R)\W1	<b>Clear PERR Interrupt Flag</b>
				Write 1 to clear the PERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	TXOF	0	(R)\W1	<b>Clear TXOF Interrupt Flag</b>
				Write 1 to clear the TXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	RXUF	0	(R)\W1	<b>Clear RXUF Interrupt Flag</b>
				Write 1 to clear the RXUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	RXOF	0	(R)\W1	<b>Clear RXOF Interrupt Flag</b>
				Write 1 to clear the RXOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	TXC	0	(R)\W1	<b>Clear TXC Interrupt Flag</b>
				Write 1 to clear the TXC interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

### 20.5.15 LEUARTn\_IEN - Interrupt Enable Register

Offset	Bit Position																				
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11
<b>Reset</b>																					
<b>Access</b>																					
<b>Name</b>																					

Bit	Name	Reset	Access	Description
31:11	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	<b>SIGF</b>	0	RW	<b>SIGF Interrupt Enable</b>
	Enable/disable the SIGF interrupt			
9	<b>STARTF</b>	0	RW	<b>STARTF Interrupt Enable</b>
	Enable/disable the STARTF interrupt			
8	<b>MPAF</b>	0	RW	<b>MPAF Interrupt Enable</b>
	Enable/disable the MPAF interrupt			
7	<b>FERR</b>	0	RW	<b>FERR Interrupt Enable</b>
	Enable/disable the FERR interrupt			
6	<b>PERR</b>	0	RW	<b>PERR Interrupt Enable</b>
	Enable/disable the PERR interrupt			
5	<b>TXOF</b>	0	RW	<b>TXOF Interrupt Enable</b>
	Enable/disable the TXOF interrupt			
4	<b>RXUF</b>	0	RW	<b>RXUF Interrupt Enable</b>
	Enable/disable the RXUF interrupt			
3	<b>RXOF</b>	0	RW	<b>RXOF Interrupt Enable</b>
	Enable/disable the RXOF interrupt			
2	<b>RXDATAV</b>	0	RW	<b>RXDATAV Interrupt Enable</b>
	Enable/disable the RXDATAV interrupt			
1	<b>TXBL</b>	0	RW	<b>TXBL Interrupt Enable</b>
	Enable/disable the TXBL interrupt			
0	<b>TXC</b>	0	RW	<b>TXC Interrupt Enable</b>
	Enable/disable the TXC interrupt			

### 20.5.16 LEUARTn\_PULSECTRL - Pulse Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0x0		
Access																																RW	
Name																																	PULSEW

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	PULSEFILT	0	RW	<b>Pulse Filter</b>
	Enable a one-cycle pulse filter for pulse extender			
	Value	Description		
	0	Filter is disabled. Pulses must be at least 2 cycles long for reliable detection.		
	1	Filter is enabled. Pulses must be at least 3 cycles long for reliable detection.		
4	PULSEEN	0	RW	<b>Pulse Generator/Extender Enable</b>
	Filter LEUART output through pulse generator and the LEUART input through the pulse extender.			
3:0	PULSEW	0x0	RW	<b>Pulse Width</b>
	Configure the pulse width of the pulse generator as a number of 32.768 kHz clock cycles.			

#### 20.5.17 LEUARTn\_FREEZE - Freeze Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	REGREFREEZE	0	RW	Register Update Freeze

When set, the update of the LEUART logic from registers is postponed until this bit is cleared. Use this bit to update several registers simultaneously.

Value	Mode	Description
0	UPDATE	Each write access to a LEUART register is updated into the Low Frequency domain as soon as possible.
1	FREEZE	The LEUART is not updated with the new written value.

## 20.5.18 LEUARTn\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																								
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	
Reset																									
Access																									
Name																									
Bit	Name	Reset	Access	Description																					
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																							

Bit	Name	Reset	Access	Description
7	PULSECTRL	0	R	<b>PULSECTRL Register Busy</b>  Set when the value written to PULSECTRL is being synchronized.
6	TXDATA	0	R	<b>TXDATA Register Busy</b>  Set when the value written to TXDATA is being synchronized.
5	TXDATAX	0	R	<b>TXDATAX Register Busy</b>  Set when the value written to TXDATAX is being synchronized.
4	SIGFRAME	0	R	<b>SIGFRAME Register Busy</b>  Set when the value written to SIGFRAME is being synchronized.
3	STARTFRAME	0	R	<b>STARTFRAME Register Busy</b>  Set when the value written to STARTFRAME is being synchronized.
2	CLKDIV	0	R	<b>CLKDIV Register Busy</b>  Set when the value written to CLKDIV is being synchronized.
1	CMD	0	R	<b>CMD Register Busy</b>  Set when the value written to CMD is being synchronized.
0	CTRL	0	R	<b>CTRL Register Busy</b>  Set when the value written to CTRL is being synchronized.

### 20.5.19 LEUARTn\_ROUTEOPEN - I/O Routing Pin Enable Register

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

1	TXPEN	0	RW	TX Pin Enable
---	-------	---	----	---------------

When set, the TX pin of the LEUART is enabled.

Value	Description
0	The LEUn_TX pin is disabled
1	The LEUn_TX pin is enabled

0 RXPEN 0 RW RX Pin Enable

When set, the RX pin of the LEUART is enabled.

Value	Description
0	The LEUn_RX pin is disabled
1	The LEUn_RX pin is enabled

### 20.5.20 LEUARTn\_ROUTELOC0 - I/O Routing Location Register

Offset	Bit Position																																		
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																	0x00																		
Access																	RW																		
Name																	TXLOC																		
Bit	Name	Reset	Access	Description																															

31:14	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
-------	----------	---	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--

13:8	TXLOC	0x00	RW	I/O Location
Decides the location of the LEUART TX pin. See the device data sheet for the mapping between location and physical pins.				

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3
4	LOC4	Location 4
5	LOC5	Location 5

7:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																												
-----	----------	---	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--	--



5:0	RXLOC	0x00	RW	I/O Location
Decides the location of the LEUART RX pin. See the device data sheet for the mapping between location and physical pins.				

Value	Mode	Description
0	LOC0	Location 0
1	LOC1	Location 1
2	LOC2	Location 2
3	LOC3	Location 3
4	LOC4	Location 4
5	LOC5	Location 5

### 20.5.21 LEUARTn\_INPUT - LEUART Input Register

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	RXPRS	0	RW	<b>PRS RX Enable</b>
				When set, the PRS channel selected as input to RX.
4:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	RXPRSEL	0x0	RW	<b>RX PRS Channel Select</b>
				Select PRS channel as input to RX.
<hr/>				
Value	Mode	Description		
0	PRSCH0	PRS Channel 0 selected		
1	PRSCH1	PRS Channel 1 selected		
2	PRSCH2	PRS Channel 2 selected		
3	PRSCH3	PRS Channel 3 selected		
4	PRSCH4	PRS Channel 4 selected		
5	PRSCH5	PRS Channel 5 selected		
6	PRSCH6	PRS Channel 6 selected		
7	PRSCH7	PRS Channel 7 selected		

## 21. TIMER/WTIMER - Timer/Counter



### Quick Facts

#### What?

The TIMER (Timer/Counter) keeps track of timing and counts events, generates output waveforms, and triggers timed actions in other peripherals.

#### Why?

Most applications have activities that need to be timed accurately with as little CPU intervention and energy consumption as possible.

#### How?

The flexible 16/32-bit timer can be configured to provide PWM waveforms with optional dead-time insertion (e.g. motor control) or work as a frequency generator. The timer can also count events and control other peripherals through the PRS, which offloads the CPU and reduces energy consumption.

### 21.1 Introduction

The general purpose timer has 3 or 4 compare/capture channels for input capture and compare/Pulse-Width Modulation (PWM) output.

The TIMER and WTIMER peripherals are identical except for the timer width. A TIMER is 16-bits wide and a WTIMER is 32-bits wide. Some timers also include a Dead-Time Insertion module suitable for motor control applications.

Refer to the device data sheet to determine the capabilities (capture/compare channel count and DTI) of each timer instance.

## 21.2 Features


- 16/32-bit auto reload up/down counter
  - Dedicated 16/32-bit reload register which serves as counter maximum
- 3 or 4 Compare/Capture channels
  - Individually configurable as either input capture or output compare/PWM
- Multiple Counter modes
  - Count up
  - Count down
  - Count up/down
  - Quadrature Decoder
    - Direction and count from external pins
- 2x Count Mode
- Counter control from PRS or external pin
  - Start
  - Stop
  - Reload and start
- Inter-Timer connection
  - Allows 32-bit counter mode
  - Start/stop synchronization between several timers
- Input Capture
  - Period measurement
  - Pulse width measurement
  - Two capture registers for each capture channel
    - Capture on either positive or negative edge
    - Capture on both edges
    - Optional digital noise filtering on capture inputs
- Output Compare
  - Compare output toggle/pulse on compare match
  - Immediate update of compare registers
- PWM
  - Up-count PWM
  - Up/down-count PWM
  - Predictable initial PWM output state (configured by SW)
  - Buffered compare register to ensure glitch-free update of compare values
- Clock sources
  - HPERCLK<sub>TIMERn</sub>
    - 10-bit Prescaler
  - External pin
  - Peripheral Reflex System
- Debug mode
  - Configurable to either run or stop when processor is stopped (halt/breakpoint)
- Interrupts, PRS output and/or DMA request on:
  - Underflow
  - Overflow
  - Compare/Capture event

- Dead-Time Insertion Unit

- Complementary PWM outputs with programmable dead-time
  - Dead-time is specified independently for rising and falling edge
    - 10-bit prescaler
    - 6-bit time value
  - Outputs have configurable polarity
  - Outputs can be set inactive individually by software.
- Configurable action on fault
  - Set outputs inactive
  - Clear output
  - Tristate output
- Individual fault sources
  - One or two PRS signals
  - Debugger
    - Support for automatic restart
  - Core lockup
  - Configuration lock

### 21.3 Functional Description

An overview of the TIMER/WTIMER module is shown in [Figure 21.1 TIMER/WTIMER Block Overview on page 725](#) and it consists of a 16/32 bit up/down counter with 3 Compare/Capture channels connected to pins TIMn\_CC0, TIMn\_CC1, and TIMn\_CC2.



**Figure 21.1. TIMER/WTIMER Block Overview**

WTIMERS (Wide TIMERS) are 32-bit variants of the TIMER/WTIMER module.

### 21.3.1 Counter Modes

The timer consists of a counter that can be configured to the following modes:

1. Up-count: Counter counts up until it reaches the value in TIMERn\_TOP, where it is reset to 0 before counting up again.
2. Down-count: The counter starts at the value in TIMERn\_TOP and counts down. When it reaches 0, it is reloaded with the value in TIMERn\_TOP.
3. Up/Down-count: The counter starts at 0 and counts up. When it reaches the value in TIMERn\_TOP, it counts down until it reaches 0 and starts counting up again.
4. Quadrature Decoder: Two input channels where one determines the count direction, while the other pin triggers a clock event.

In addition, to the TIMER/WTIMER modes listed above, the TIMER/WTIMER also supports a 2x Count Mode. In this mode the counter increments/decrements by 2. The 2x Count Mode intended use is to generate 2x PWM frequency when the Compare/Capture channel is put in PWM mode. The 2x Count Mode can be enabled by setting the X2CNT bitfield in the TIMERn\_CTRL register.

The counter value can be read or written by software at any time by accessing the CNT field in TIMERn\_CNT.

#### 21.3.1.1 Events

Overflow is set when the counter value shifts from TIMERn\_TOP to the next value when counting up. In up-count mode and Quadrature Decoder mode the next value is 0. In up/down-count mode, the next value is TIMERn\_TOP-1.

Underflow is set when the counter value shifts from 0 to the next value when counting down. In down-count mode and Quadrature Decoder mode, the next value is TIMERn\_TOP. In up/down-count mode the next value is 1.

An update event occurs on overflow in up-count mode and on underflow in down-count or up/down count mode. Additionally, an update event also occurs on overflow and underflow in Quadrature Decoder Mode. This event is used to time updates of buffered values.

### 21.3.1.2 Operation

Figure 21.2 TIMER/WTIMER Hardware Timer/Counter Control on page 727 shows the hardware Timer/Counter control. Software can start or stop the counter by setting the START or STOP bits in TIMERn\_CMD. The counter value (CNT in TIMERn\_CNT) can always be written by software to any 16/32-bit value.

It is also possible to control the counter through either an external pin or PRS input. This is done through the input logic for the Compare/Capture Channel 0. The Timer/Counter allows individual actions (start, stop, reload) to be taken for rising and falling input edges. This is configured in the RISEA and FALLA fields in TIMERn\_CTRL. The reload value is 0 in up-count and up/down-count mode and TOP in down-count mode.

The RUNNING bit in TIMERn\_STATUS indicates if the timer is running or not. If the SYNC bit in TIMERn\_CTRL is set, the timer is started/stopped/reloaded (external pin or PRS) when any of the other timers are started/stopped/reloaded.

**Note:** TIMER0 uses a different peripheral clock compared to the other timers. Therefore it can normally not be used to start/stop/reload other timers. When using SYNC in TIMERn\_CTRL for other timers make sure DYSSYNCOUT in TIMER0\_CTRL is set to prevent it from triggering start/stop/reload in other timers and resulting in undesired behavior. This restriction does not apply when both HFPERCLK and HFPERBCLK are non-prescaled versions of HFCLK.

The DIR bit in TIMERn\_STATUS indicates the counting direction of the timer at any given time. The counter value can be read or written by software through the CNT field in TIMERn\_CNT. In Up/Down-Count mode the count direction will be set to up if the CNT value is written by software.





Figure 21.2. TIMER/WTIMER Hardware Timer/Counter Control

### 21.3.1.3 Clock Source

The counter can be clocked from several sources, which are all synchronized with the peripheral clock (HFPERCLK). See Figure 21.3 [TIMER/WTIMER Clock Selection](#) on page 728.



**Figure 21.3. TIMER/WTIMER Clock Selection**

**Note:** Not all TIMER instances are using the same peripheral clock. Normally the TIMER uses  $HFPERCLK_{TIMERn}$ , however TIMER0 supports higher frequencies and therefore uses  $HFPERBCLK_{TIMER0}$ . This chapter describes the general case and therefore uses  $HFPERCLK_{TIMERn}$  and  $f_{HFPERCLK}$ , which should be interpreted as  $HFPERBCLK_{TIMERn}$  and  $f_{HFPERBCLK}$  for TIMER0. [10.3.1.4 HFPERCLK, HFPERBCLK, HFPERCCCLK - High Frequency Peripheral Clocks](#) shows which peripheral uses what peripheral clock.

### 21.3.1.4 Peripheral Clock (HFPERCLK)

The peripheral clock (HFPERCLK) can be used as a source with a configurable prescale factor of  $2^{PRESC}$ , where PRESC is an integer between 0 and 10, which is set in PRESC in `TIMERn_CTRL`. However, if 2x Count Mode is enabled and the Compare/Capture channels are put in PWM mode, the CC output is updated on both clock edges so prescaling the peripheral clock will produce an incorrect result. The prescaler is stopped and reset when the timer is stopped.


### 21.3.1.5 Compare/ Capture Channel 1 Input

The timer can also be clocked by positive and/or negative edges on the Compare/Capture channel 1 input. This input can either come from the  $TIMn\_CC1$  pin or one of the PRS channels. The input signal must not have a higher frequency than  $f_{HFPERCLK}/3$  when running from a pin input or a PRS input with FILT enabled in `TIMERn_CCx_CTRL`. When running from PRS without FILT, the frequency can be as high as  $f_{HFPERCLK}$ . Note that when clocking the timer from the same pulse that triggers a start (through RISEA/FALLA in `TIMERn_CTRL`), the starting pulse will not update the Counter Value.

### 21.3.1.6 Underflow/Overflow From Neighboring Timer

All timers are linked together (see [Figure 21.4 TIMER/WTIMER Connections on page 729](#)), allowing timers to count on overflow/underflow from the lower numbered neighbouring timers to form a 32-bit or 48-bit timer. Note that all timers must be set to same count direction and less significant timer(s) can only be set to count up or down.

**Note:** TIMER0 uses a different peripheral clock compared to the other timers. Therefore it can normally not be used to start/stop/reload other timers. When using SYNC in TIMERn\_CTRL for other timers make sure DYSSYNCOUT in TIMER0\_CTRL is set to prevent it from triggering start/stop/reload in other timers and resulting in undesired behavior. This restriction does not apply when both HFPERCLK and HFPERBCLK are non-prescaled versions of HFCLK.



**Figure 21.4. TIMER/WTIMER Connections**


### 21.3.1.7 One-Shot Mode

By default, the counter counts continuously until it is stopped. If the OSMEN bit is set in the TIMERn\_CTRL register, however, the counter is disabled by hardware on the first *update event* (see [21.3.1.1 Events](#)). Note that when the counter is running with CC1 as clock source (0b01 in CLKSEL in TIMERn\_CTRL) and OSMEN is set, a CC1 capture event will not take place on the *update event* (CC1 rising edge) that stops the timer.

### 21.3.1.8 Top Value Buffer

The TIMERn\_TOP register can be altered either by writing it directly or by writing to the TIMER\_TOPB (buffer) register. When writing to the buffer register the TIMERn\_TOPB register will be written to TIMERn\_TOP on the next *update event*. Buffering ensures that the TOP value is not set below the actual count value. The TOPBV flag in TIMERn\_STATUS indicates whether the TIMERn\_TOPB register contains data that has not yet been written to the TIMERn\_TOP register (see [Figure 21.5 TIMER/WTIMER TOP Value Update Functionality on page 729](#)).


**Note:** When writing to TIMERn\_TOP register directly, the TIMERn\_TOPB register value will be invalidated and the TOPBV flag will be cleared. This prevents TIMERn\_TOP register from being immediately updated by an existing valid TIMERn\_TOPB value during the next *update event*.



**Figure 21.5. TIMER/WTIMER TOP Value Update Functionality**

### 21.3.1.9 Quadrature Decoder


Quadrature Decoding mode is used to track motion and determine both rotation direction and position. The Quadrature Decoder uses two input channels that are 90 degrees out of phase (see [Figure 21.6 TIMER/WTIMER Quadrature Encoded Inputs on page 730](#)).



**Figure 21.6. TIMER/WTIMER Quadrature Encoded Inputs**

In the timer these inputs are tapped from the Compare/Capture channel 0 (Channel A) and 1 (Channel B) inputs before edge detection. The Timer/Counter then increments or decrements the counter, based on the phase relation between the two inputs. The Quadrature Decoder Mode supports two channels, but if a third channel (Z-terminal) is available, this can be connected to an external interrupt and trigger a counter reset from the interrupt service routine. By connecting a periodic signal from another timer as input capture on Compare/Capture Channel 2, it is also possible to calculate speed and acceleration.

**Note:** In Quadrature Decoder mode, overflow and underflow triggers an *update event*.



**Figure 21.7. TIMER/WTIMER Quadrature Decoder Configuration**


The Quadrature Decoder can be set in either X2 or X4 mode, which is configured in the QDM bit in TIMERn\_CTRL. See [Figure 21.7 TIMER/WTIMER Quadrature Decoder Configuration on page 730](#)

**21.3.1.10 X2 Decoding Mode**

In X2 Decoding mode, the counter increments or decrements on every edge of Channel A, see [Table 21.1 TIMER/WTIMER Counter Response in X2 Decoding Mode on page 731](#) and [Figure 21.8 TIMER/WTIMER X2 Decoding Mode on page 731](#).

**Table 21.1. TIMER/WTIMER Counter Response in X2 Decoding Mode**


Channel B	Channel A	
	Rising	Falling
0	Increment	Decrement
1	Decrement	Increment

**Figure 21.8. TIMER/WTIMER X2 Decoding Mode****21.3.1.11 X4 Decoding Mode**

In X4 Decoding mode, the counter increments or decrements on every edge of Channel A and Channel B, see [Figure 21.9 TIMER/WTIMER X4 Decoding Mode on page 731](#) and [Table 21.2 TIMER/WTIMER Counter Response in X4 Decoding Mode on page 731](#).

**Table 21.2. TIMER/WTIMER Counter Response in X4 Decoding Mode**

Opposite Channel	Channel A		Channel B	
	Rising	Falling	Rising	Falling
Channel A = 0			Decrement	Increment
Channel A = 1			Increment	Decrement
Channel B = 0	Increment	Decrement		
Channel B = 1	Decrement	Increment		

**Figure 21.9. TIMER/WTIMER X4 Decoding Mode**

### 21.3.1.12 TIMER/WTIMER Rotational Position

To calculate a position Figure 21.10 TIMER/WTIMER Rotational Position Equation on page 732 can be used.

$$\text{pos}^\circ = (\text{CNT}/\text{X} \times \text{N}) \times 360^\circ$$

**Figure 21.10. TIMER/WTIMER Rotational Position Equation**

where X = Encoding type and N = Number of pulses per revolution.


### 21.3.2 Compare/Capture Channels

The timer contains 3 Compare/Capture channels, which can be configured in the following modes:

1. Input Capture
2. Output Compare
3. PWM

#### 21.3.2.1 Input Pin Logic

Each Compare/Capture channel can be configured as an input source for the Capture Unit or as external clock source for the timer (see Figure 21.11 TIMER/WTIMER Input Pin Logic on page 732). Compare/Capture channels 0 and 1 are the inputs for the Quadrature Decoder Mode. The input channel can be filtered before it is used, which requires the input to remain stable for 5 cycles in a row before the input is propagated to the output.




**Figure 21.11. TIMER/WTIMER Input Pin Logic**

#### 21.3.2.2 Compare/Capture Registers

The Compare/Capture channel registers are prefixed with TIMERn\_CCx\_, where the x stands for the channel number. Since the Compare/Capture channels serve three functions (input capture, compare, PWM), the behavior of the Compare/Capture registers (TIMERn\_CCx\_CCV) and buffer registers (TIMERn\_CCx\_CCVB) change depending on the mode the channel is set in.

### 21.3.2.3 Input Capture

In Input Capture Mode, the counter value (TIMERn\_CNT) can be captured in the Compare/Capture Register (TIMERn\_CCx\_CCV) (see [Figure 21.12 TIMER/WTIMER Input Capture on page 733](#)). The CCPOL bits in TIMERn\_STATUS indicate the polarity of the edge that triggered the capture in TIMERn\_CCx\_CCV.



**Figure 21.12. TIMER/WTIMER Input Capture**


The Compare/Capture Buffer Register (TIMERn\_CCx\_CCVB) and the TIMERn\_CCx\_CCV register form double-buffered capture registers allowing two subsequent capture events to take place before a read-out is required. The first capture can always be read from TIMERn\_CCx\_CCV, and reading this address will load the next capture value into TIMERn\_CCx\_CCV from TIMERn\_CCx\_CCVB if it contains valid data. The CC value can be read without altering the FIFO contents by reading TIMERn\_CCx\_CCVP. TIMERn\_CCx\_CCVB can also be read without altering the FIFO contents. The ICV flag in TIMERn\_STATUS indicates if there is a valid unread capture in TIMERn\_CCx\_CCV. In this mode, TIMERn\_CCx\_CCV is read-only.

In the case where a capture is triggered while both TIMERn\_CCx\_CCV and TIMERn\_CCx\_CCVB contain unread capture values, the buffer overflow interrupt flag (ICBOF in TIMERn\_IF) will be set. On overflow new capture values will overwrite the value in TIMERn\_CCx\_CCVB and the value of TIMERn\_CCx\_CCV will remain unchanged. TIMERn\_CCx\_CCV will always contain the oldest unread value and TIMERn\_CCx\_CCVB will always contain the newest value.

**Note:** In input capture mode, the timer will only trigger interrupts when it is running.

#### 21.3.2.4 Period/Pulse-Width Capture


Period and/or pulse-width capture can only be possible with Channel 0 (CC0), because this is the only channel that can start and stop the timer. This can be done by setting the RISEA field in TIMERn\_CTRL to Clear&Start, and select the wanted input from either external pin or PRS, see [Figure 21.13 TIMER/WTIMER Period and/or Pulse width Capture on page 734](#). For period capture, the Compare/Capture Channel should then be set to input capture on a rising edge of the same input signal. To capture the width of a high pulse, the Compare/Capture Channel should be set to capture on a falling edge of the input signal. To measure the low pulse-width of a signal, opposite polarities should be chosen.



**Figure 21.13. TIMER/WTIMER Period and/or Pulse width Capture**

### 21.3.2.5 Compare

Each Compare/Capture channel contains a comparator which outputs a compare match if the contents of TIMERn\_CC<sub>x</sub>\_CCV matches the counter value, see [Figure 21.14 TIMER/WTIMER Block Diagram Showing Comparison Functionality on page 735](#). In compare mode, each compare channel can be configured to either set, clear or toggle the output on an event (compare match, overflow or underflow). The output from each channel is represented as an alternative function on the port it is connected to, which needs to be enabled for the CC outputs to propagate to the pins.




**Figure 21.14. TIMER/WTIMER Block Diagram Showing Comparison Functionality**

The compare output is delayed by one cycle to allow for full 0% to 100% PWM generation. If occurring in the same cycle, match action will have priority over overflow or underflow action.

The input selected (through PRSSEL, INSEL and FILTSEL in TIMERn\_CC<sub>x</sub>\_CTRL) for the CC channel will also be sampled on compare match and the result is found in the CCPOL bits in TIMERn\_STATUS. It is also possible to configure the CCPOL to always track the inputs by setting ATI in TIMERn\_CTRL.


The COIST bit in TIMERn\_CC<sub>x</sub>\_CTRL is the initial state of the compare/PWM output. The COIST bit can also be used as an initial value to the compare outputs on a reload-start when RSSCOIST is set in TIMERn\_CTRL. Also the resulting output can be inverted by setting OUTINV in TIMERn\_CC<sub>x</sub>\_CTRL. It is recommended to turn off the CC channel before configuring the output state to avoid any pulses on the output. The CC channel can be turned off by setting MODE to OFF in TIMER\_CC<sub>x</sub>\_CTRL. The following figure shows the output logic for the TIMER/WTIMER module.



**Figure 21.15. TIMER/WTIMER Output Logic**

### 21.3.2.6 Compare Mode Registers

When running in Output Compare or PWM mode, the value in TIMERn\_CCx\_CCV will be compared against the count value. In Compare mode the output can be configured to toggle, clear or set on compare match, overflow, and underflow through the CMOA, COFOA and CUFOA fields in TIMERn\_CCx\_CTRL. TIMERn\_CCx\_CCV can be accessed directly or through the buffer register TIMERn\_CCx\_CCVB, see [Figure 21.16 TIMER/WTIMER Output Compare/PWM Buffer Functionality Detail on page 736](#). When writing to the buffer register, the value in TIMERn\_CCx\_CCVB will be written to TIMERn\_CCx\_CCV on the next *update event*. This functionality ensures glitch free PWM outputs. The CCVB flag in TIMERn\_STATUS indicates whether the TIMERn\_CCx\_CCVB register contains data that has not yet been written to the TIMERn\_CCx\_CCV register. Note that when writing 0 to TIMERn\_CCx\_CCVB in up-down count mode the CCV value is updated when the timer counts from 0 to 1. Thus, the compare match for the next period will not happen until the timer reaches 0 again on the way down.




**Figure 21.16. TIMER/WTIMER Output Compare/PWM Buffer Functionality Detail**

### 21.3.2.7 Frequency Generation (FRG)

Frequency generation (see [Figure 21.17 TIMER/WTIMER Up-count Frequency Generation on page 737](#)) can be achieved in compare mode by:

- Setting the counter in up-count mode
- Enabling buffering of the TOP value.
- Setting the CC channels overflow action to toggle




**Figure 21.17. TIMER/WTIMER Up-count Frequency Generation**

The output frequency is given by [Figure 21.18 TIMER/WTIMER Up-count Frequency Generation Equation on page 737](#)

$$f_{FRG} = f_{HFPERCLK} / (2^{(PRESC + 1)} \times (TOP + 1) \times 2)$$

**Figure 21.18. TIMER/WTIMER Up-count Frequency Generation Equation**

The figure below provides cycle accurate timing and event generation information for frequency generation.




**Figure 21.19. TIMER/WTIMER Up-count Frequency Generation Detail**

### 21.3.2.8 Pulse-Width Modulation (PWM)

In PWM mode, `TIMERn_CCx_CCV` is buffered to avoid glitches in the output. The settings in the Compare Output Action configuration bits are ignored in PWM mode and PWM generation is only supported for up-count and up/down-count mode.

### 21.3.2.9 Up-count (Single-slope) PWM

If the counter is set to up-count and the Compare/Capture channel is put in PWM mode, single slope PWM output will be generated (see [Figure 21.20 TIMER/WTIMER Up-count PWM Generation on page 738](#)). In up-count mode the PWM period is TOP+1 cycles and the PWM output will be high for a number of cycles equal to `TIMERn_CCx_CCV`. This means that a constant high output is achieved by setting `TIMERn_CCx_CCV` to TOP+1 or higher. The PWM resolution (in bits) is then given by [Figure 21.21 TIMER/WTIMER Up-count PWM Resolution Equation on page 738](#).



**Figure 21.20. TIMER/WTIMER Up-count PWM Generation**

$$R_{\text{PWM}_{\text{up}}} = \log(\text{TOP}+1)/\log(2)$$

**Figure 21.21. TIMER/WTIMER Up-count PWM Resolution Equation**

The PWM frequency is given by [Figure 21.22 TIMER/WTIMER Up-count PWM Frequency Equation on page 738](#):

$$f_{\text{PWM}_{\text{up/down}}} = f_{\text{HFPERCLK}} / (2^{\text{PRESC}} \times (\text{TOP} + 1))$$


**Figure 21.22. TIMER/WTIMER Up-count PWM Frequency Equation**

The high duty cycle is given by [Figure 21.23 TIMER/WTIMER Up-count Duty Cycle Equation on page 738](#)

$$DS_{\text{up}} = CCVx / (\text{TOP} + 1)$$

**Figure 21.23. TIMER/WTIMER Up-count Duty Cycle Equation**


The figure below provides cycle accurate timing and event generation information for up-count mode.



**Figure 21.24. TIMER/WTIMER Up-count PWM Generation Detail**

**21.3.2.10 2x Count Mode (Up-count)**

When the timer is set in 2x mode, the TIMER/WTIMER will count up by two. This will in effect make any odd Top value be rounded down to the closest even number. Similarly, any odd CC value will generate a match on the closest lower even value as shown in [Figure 21.25 TIMER/WTIMER CC out in 2x mode on page 739](#)

**Figure 21.25. TIMER/WTIMER CC out in 2x mode**

The PWM resolution is given by [Figure 21.26 TIMER/WTIMER 2x PWM Resolution Equation on page 739](#).

$$R_{\text{PWM}_{2\text{xmode}}} = \log(\text{TOP}/2+1)/\log(2)$$

**Figure 21.26. TIMER/WTIMER 2x PWM Resolution Equation**

The PWM frequency is given by [Figure 21.27 TIMER/WTIMER 2x Mode PWM Frequency Equation\( Up-count\) on page 739](#):

$$f_{\text{PWM}_{2\text{xmode}}} = f_{\text{HFPERCLK}} / \text{floor}(\text{TOP}/2)+1$$

**Figure 21.27. TIMER/WTIMER 2x Mode PWM Frequency Equation( Up-count)**


The high duty cycle is given by [Figure 21.28 TIMER/WTIMER 2x Mode Duty Cycle Equation on page 739](#)

$$DS_{2\text{xmode}} = CCVx / ((\text{floor}(\text{TOP}/2)+1)*2)$$

**Figure 21.28. TIMER/WTIMER 2x Mode Duty Cycle Equation**

### 21.3.2.11 Up/Down-count (Dual-slope) PWM

If the counter is set to up-down count and the Compare/Capture channel is put in PWM mode, dual slope PWM output will be generated by [Figure 21.29 TIMER/WTIMER Up/Down-count PWM Generation on page 740](#). The resolution (in bits) is given by [Figure 21.30 TIMER/WTIMER Up/Down-count PWM Resolution Equation on page 740](#).



**Figure 21.29. TIMER/WTIMER Up/Down-count PWM Generation**

$$R_{PWM_{up/down}} = \log(TOP+1)/\log(2)$$

**Figure 21.30. TIMER/WTIMER Up/Down-count PWM Resolution Equation**

The PWM frequency is given by [Figure 21.31 TIMER/WTIMER Up/Down-count PWM Frequency Equation on page 740](#):

$$f_{PWM_{up/down}} = f_{HFPERCLK} / (2^{(PRESC+1)} \times TOP)$$


**Figure 21.31. TIMER/WTIMER Up/Down-count PWM Frequency Equation**

The high duty cycle is given by [Figure 21.32 TIMER/WTIMER Up/Down-count Duty Cycle Equation on page 740](#)

$$DS_{up/down} = CCVx/TOP$$

**Figure 21.32. TIMER/WTIMER Up/Down-count Duty Cycle Equation**


The figure below provides cycle accurate timing and event generation information for up-count mode.



**Figure 21.33. TIMER/WTIMER Up/Down-count PWM Generation**

**21.3.2.12 2x Count Mode (Up/Down-count)**

When the timer is set in 2x mode, the TIMER/WTIMER will count up/down by two. This will in effect make any odd Top value be rounded down to the closest even number. Similarly, any odd CC value will generate a match on the closest lower even value as shown in [Figure 21.34 TIMER/WTIMER CC out in 2x mode on page 741](#)

**Figure 21.34. TIMER/WTIMER CC out in 2x mode**

[Figure 21.35 TIMER/WTIMER 2x PWM Resolution Equation on page 741](#).

$$R_{\text{PWM}_{2\text{xmode}}} = \log(\text{TOP}/2+1)/\log(2)$$

**Figure 21.35. TIMER/WTIMER 2x PWM Resolution Equation**

The PWM frequency is given by [Figure 21.36 TIMER/WTIMER 2x Mode PWM Frequency Equation\( Up/Down-count\) on page 741](#):

$$f_{\text{PWM}_{2\text{xmode}}} = f_{\text{HFPERCLK}} / (\text{floor}(\text{TOP}/2)^*2)$$

**Figure 21.36. TIMER/WTIMER 2x Mode PWM Frequency Equation( Up/Down-count)**

The high duty cycle is given by two equations based on the CCVx values. [Figure 21.37 TIMER/WTIMER 2x Mode Duty Cycle Equation for CCVx = 1 or CCVx = even on page 741](#) and [Figure 21.38 TIMER/WTIMER 2x Mode Duty Cycle Equation for all other CCVx = odd values on page 741](#)

$$DS_{2\text{xmode}} = (CCVx^*2)/(\text{floor}(\text{TOP}/2)^*4)$$

**Figure 21.37. TIMER/WTIMER 2x Mode Duty Cycle Equation for CCVx = 1 or CCVx = even**


$$DS_{2\text{xmode}} = (CCVx^*2 - CCVx)/(\text{floor}(\text{TOP}/2)^*4)$$

**Figure 21.38. TIMER/WTIMER 2x Mode Duty Cycle Equation for all other CCVx = odd values****21.3.2.13 Timer Configuration Lock**

To prevent software errors from making changes to the timer configuration, a configuration lock is available similar to DTI configuration Lock. Writing any value but 0xCE80 to LOCKKEY in TIMERn\_LOCK results in TIMERn\_CTRL, TIMERn\_CMD, TIMERn\_TOP, TIMERn\_CNT, TIMERn\_CCx\_CTRL and TIMERn\_CCx\_CCV being locked from writing. To unlock the registers, write 0xCE80 to LOCKKEY in TIMERn\_LOCK. The value of TIMERn\_LOCK is 1 when the lock is active, and 0 when the registers are unlocked.


### 21.3.3 Dead-Time Insertion Unit

Some of the timers include a Dead-Time Insertion module suitable for motor control applications. Refer to the device data sheet to check if a timer has this feature. The example settings in this section are for TIMER0, but identical settings can be used for other timers with DTI as well. The Dead-Time Insertion Unit aims to make control of brushless DC (BLDC) motors safer and more efficient by introducing complementary PWM outputs with dead-time insertion and fault handling, see [Figure 21.39 TIMER/WTIMER Dead-Time Insertion Unit Overview on page 742](#).




**Figure 21.39. TIMER/WTIMER Dead-Time Insertion Unit Overview**

When used for motor control, the PWM outputs TIM0\_CC0, TIM0\_CC1 and TIM0\_CC2 are often connected to the high-side transistors of a triple half-bridge setup (UH, VH and WH), and the complementary outputs connected to the respective low-side transistors (UL, VL, WL shown in [Figure 21.40 TIMER/WTIMER Triple Half-Bridge on page 742](#)). Transistors used in such a bridge often do not open/close instantaneously, and using the exact complementary inputs for the high and low side of a half-bridge may result in situations where both gates are open. This can give unnecessary current-draw and short circuit the power supply. The DTI unit provides dead-time insertion to deal with this problem.



**Figure 21.40. TIMER/WTIMER Triple Half-Bridge**


For each of the 3 compare-match outputs of TIMER0, an additional complementary output is provided by the DTI unit. These outputs, named TIM0\_CDTI0, TIM0\_CDTI1 and TIM0\_CDTI2 are provided to make control of e.g. 3-channel BLDC or permanent magnet AC (PMAC) motors possible using only a single timer, see [Figure 21.41 TIMER/WTIMER Overview of Dead-Time Insertion Block for a Single PWM channel on page 743](#).



**Figure 21.41. TIMER/WTIMER Overview of Dead-Time Insertion Block for a Single PWM channel**

The DTI unit is enabled by setting DTEN in TIMER0\_DTCR. In addition to providing the complementary outputs, the DTI unit then also overrides the compare match outputs from the timer.

The DTI unit gives the rising edges of the PWM outputs and the rising edges of the complementary PWM outputs a configurable time delay. By doing this, the DTI unit introduces a dead-time where both the primary and complementary outputs in a pair are inactive as seen in [Figure 21.42 TIMER/WTIMER Polarity of Both Signals are Set as Active-High on page 743](#).



**Figure 21.42. TIMER/WTIMER Polarity of Both Signals are Set as Active-High**

Dead-time is specified individually for the rising and falling edge of the original PWM. These values are shared across all the three PWM channels of the DTI unit. A single prescaler value is provided for the DTI unit, meaning that both the rising and falling edge dead-times share prescaler value. The prescaler divides the HFPERCLK<sub>TIMERn</sub> by a configurable factor between 1 and 1024, which is set in the DTPRESC field in TIMER0\_DTTIME. The rising and falling edge dead-times are configured in DTRISET and DTFALLT in TIMER0\_DTTIME to any number between 1-64 HFPERCLK<sub>TIMER0</sub> cycles.

The DTAR and DTFATS bits in TIMER0\_DTCR control the DTI output behavior when the timer stops. By default the DTI block stops when the timer is stopped. Setting the DTAR bit will cause the DTI to output on channel 0 to continue when the timer is stopped. DTAR effects only channel 0. See [21.3.3.2 PRS Channel as a Source](#) for an example of when this can be used. While in this mode the undivided HFPERCLK\_TIMER0 (DTPRESC=0) is always used regardless of programmed DTPRESC value in TIMER0\_DTTIME. This means that rise and fall dead times are calculated assuming DTPRESC = 0.

When the timer stops DTI outputs are frozen by default, preserving their last state. To allow the outputs to go to a safe state as programmed in the DTFA field of TIMER0\_DTCR register and set the DTFATS bitfield in the TIMER0\_DTCR reg. Note that when DTAR is also set, DTAR has priority over DTFATS for DTI channel 0 output.

The following table shows the DTI output when the timer is halted.


**Table 21.3. DTI Output When Timer Halted**

DTAR	DTFATS	State
0	0	frozen
0	1	safe
1	0	running
1	1	running

**21.3.3.1 Output Polarity**

The value of the primary and complementary outputs in a pair will never be set active at the same time by the DTI unit. The polarity of the outputs can be changed if this is required by the application. The active values of the primary and complementary outputs are set by the DTIPOL and DTCINV bits in the TIMER0\_DTCTRL register. The DTIPOL bit of this register specifies the base polarity. If DTIPOL = 0, then the outputs are active-high, and if DTIPOL = 1 they are active-low. The relative phase of the primary and complementary outputs is not changed by DTIPOL, as the polarity of both outputs is changed, see [Figure 21.43 TIMER/WTIMER Output Polarities on page 744](#).

In some applications, it may be required that the primary outputs are active-high, while the complementary outputs are active-low. This can be accomplished by manipulating the DTCINV bit of the TIMER0\_DTCTRL register, which inverts the polarity of the complementary outputs relative to the primary outputs. As an example, DTIPOL = 0 and DTCINV = 0 results in outputs with opposite phase and active-high states. Similarly, DTIPOL = 1 and DTCINV = 1 results in outputs with equal phase and the primary output will be active-high while the complementary will be active-low.

**Figure 21.43. TIMER/WTIMER Output Polarities**

Output generation on the individual DTI outputs can be disabled by configuring TIMER0.DTOGEN. When output generation on an output is disabled that output will go to and stay in its inactive state.

### 21.3.3.2 PRS Channel as a Source

A PRS channel can be used as input to the DTI module instead of the PWM output from the timer for DTI channel 0. Setting DTPRSEN in TIMER0\_DTCTRL will override the source of the first DTI channel, driving TIM0\_CC0 and TIM0\_CDTI0, with the value on the PRS channel. The rest of the DTI channels will continue to be driven by the PWM output from the timer. The input PRS channel is chosen by configuring DTPRSSEL in TIMER0\_DTCTRL. Note that the timer must be running even when PRS is used as DTI source. However, if it is required to keep the DTI channel 0 running even when the timer is stopped, set DTAR in TIMER0\_DTCTRL. When this bit is set, it uses DTPRESC=0 regardless of the value programmed in DTPRESC in TIMER0\_DTTIME.

The DTI prescaler, set by DTPRESC in TIMER0\_DTTIME determines the accuracy with which the DTI can insert dead-time into a PRS signal. The maximum dead-time error equals  $2^{\text{DTPRESC}}$  clock cycles. With zero prescaling, the inserted dead-times are therefore accurate, but they may be inaccurate for larger prescaler settings.

### 21.3.3.3 Fault Handling

The fault handling system of the DTI unit allows the outputs of the DTI unit to be put in a well-defined state in case of a fault. This hardware fault handling system enables a fast reaction to faults, reducing the possibility of damage to the system.

The fault sources which trigger a fault in the DTI module are determined by the bitfields of TIMER0\_DTFc register. Any combination of the available error sources can be selected:

- PRS source 0, determined by DTPRS0FSEL in TIMER0\_DTFc
- PRS source 1, determined by DTPRS1FSEL in TIMER0\_DTFc
- Debugger
- Core Lockup

One or two PRS channels can be used as an error source. When PRS source 0 is selected as an error source, DTPRS0FSEL determines which PRS channel is used for this source. DTPRS1FSEL determines which PRS channel is selected as PRS source 1. Note that for Core Lockup, the LOCKUPRDIS in RMU\_CTRL must be set. Otherwise this will generate a full reset of the chip.

### 21.3.3.4 Action on Fault

When a fault occurs, the bit representing the fault source is set in TIMER0\_DTFault register, and the outputs from the DTI unit are set to a well-defined state. The following options are available, and can be enabled by configuring DTFact in TIMER0\_DTFc:

- Set outputs to inactive level
- Clear outputs
- Tristate outputs

With the first option enabled, the output state in case of a fault depends on the polarity settings for the individual outputs. An output set to be active high will be set low if a fault is detected, while an output set to be active low will be driven high.

When a fault occurs, the fault source(s) can be read out from TIMER0\_DTFault register.

Additionally a fault action can also be triggered when the timer stops if DTFATS in TIMER0\_DTCTRL is set. This allows the DTI output to go to safe state programmed in DTFact in TIMER0\_DTFc when timer stops. When DTAR and DTFATS in TIMER0\_DTCTRL are both set, DTI channel 0 keeps running even when the timer stops. This is useful when DTI channel 0 has an input coming from PRS.

### 21.3.3.5 Exiting Fault State

When a fault is triggered by the PRS system, software intervention is required to re-enable the outputs of the DTI unit. This is done by manually clearing bits in TIMER0\_DTFault register. If the fault source as determined by checking TIMER0\_DEFAULT is the debugger alone, the outputs can be automatically restarted when the debugger exits. To enable automatic restart set DTDAS in TIMER0\_DCTRL. When an automatic restart occurs the DTDBGF bit in TIMER0\_DTFault will be automatically cleared by hardware. If any other bits in the TIMER0\_DTFault register are set when the hardware clears DTDBGF the DTI module will not exit the fault state.

### 21.3.3.6 DTI Configuration Lock

To prevent software errors from making changes to the DTI configuration, a configuration lock is available. Writing any value but 0xCE80 to LOCKKEY in TIMER0\_DTLOCK results in TIMER0\_DTCFC, TIMER0\_DTCCTRL, TIMER0\_DTTIME and TIMER0\_ROUTE being locked from writing. To unlock the registers, write 0xCE80 to LOCKKEY in TIMER0\_DTLOCK. The value of TIMER0\_DTLOCK is 1 when the lock is active, and 0 when the registers are unlocked.

**Note:** Some of the ROUTE locations have non-interference priority. These locations prevent the use of the selected pin for other alternate functions. Thus these can be used to secure TIMER PWM outputs from software errors (i.e. another alternate function enabled to the same pin inadvertently). Therefore, it is recommended to use these locations to fully make use of the DTI Configuration Lock feature. An overview of these locations is provided in the pin map section of the device data sheet.

### 21.3.4 Debug Mode

When the CPU is halted in debug mode, the timer can be configured to either continue to run or to be frozen. This is configured in DEBUGRUN in TIMERn\_CTRL.

### 21.3.5 Interrupts, DMA and PRS Output

The timer has 3 different types of output events:

- Counter Underflow
- Counter Overflow
- Compare match or input capture (one per Compare/Capture channel)

Each of the events has its own interrupt flag. Also, there is one interrupt flag for each Compare/Capture channel which is set on buffer overflow in capture mode. Buffer overflow happens when a new capture pushes an old unread capture out of the TIMERn\_CCx\_CCV/TIMERn\_CCx\_CCVB register pair.

If the interrupt flags are set and the corresponding interrupt enable bits in TIMERn\_IEN are set high, the timer will send out an interrupt request. Each of the events will also lead to a one HFFPERCLK<sub>TIMERn</sub> cycle high pulse on individual PRS outputs. Setting PRSOCNF to LEVEL in TIMERn\_CCx\_CTRL will make the compare match PRS output follow the compare match output, instead of outputting one HFFPERCLK<sub>TIMERn</sub> cycle high pulse. Interrupts are cleared by setting the corresponding bit in the TIMERn\_IFC register.

Each of the events will also set a DMA request when they occur. The different DMA requests are cleared when certain acknowledge conditions are met, see [Table 21.4 TIMER/WTIMER DMA Events on page 746](#). Events which clear the DMA requests do not clear interrupt flags. Software must still manually clear the interrupt flag if interrupts are in use.

If DMACLRACT is set in TIMERn\_CTRL, the DMA request is cleared when the triggered DMA channel is active, without having to access any timer registers. This is useful in cases where a timer event is used to trigger a DMA transfer that does not target the CCV or CCVB register.

**Table 21.4. TIMER/WTIMER DMA Events**

Event	Acknowledge/Clear
Underflow/Overflow	Read or write to TIMERn_CNT or TIMERn_TOPB
CC 0	Read or write to TIMERn_CC0_CCV or TIMERn_CC0_CCVB
CC 1	Read or write to TIMERn_CC1_CCV or TIMERn_CC1_CCVB
CC 2	Read or write to TIMERn_CC2_CCV or TIMERn_CC2_CCVB

### 21.3.6 GPIO Input/Output

The TIMn\_CCx inputs/outputs and TIM0\_CDTIx outputs are accessible as alternate functions through GPIO. Each pin connection can be enabled/disabled separately by setting the corresponding CCxPEN or CDTIxPEN bits in TIMERn\_ROUTE. The LOCATION bits in the same register can be used to move all enabled pins to alternate pins. See the device data sheet for the mapping between block locations (LOC0, LOC1, etc.) and actual device pins (PA0, PA1, etc.).

## 21.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	TIMERn_CTRL	RW	Control Register
0x004	TIMERn_CMD	W1	Command Register
0x008	TIMERn_STATUS	R	Status Register
0x00C	TIMERn_IF	R	Interrupt Flag Register
0x010	TIMERn_IFS	W1	Interrupt Flag Set Register
0x014	TIMERn_IFC	(R)W1	Interrupt Flag Clear Register
0x018	TIMERn_IEN	RW	Interrupt Enable Register
0x01C	TIMERn_TOP	RWH	Counter Top Value Register
0x020	TIMERn_TOPB	RW	Counter Top Value Buffer Register
0x024	TIMERn_CNT	RWH	Counter Value Register
0x02C	TIMERn_LOCK	RWH	TIMER Configuration Lock Register
0x030	TIMERn_ROUTEPEN	RW	I/O Routing Pin Enable Register
0x034	TIMERn_ROUTELOC0	RW	I/O Routing Location Register
0x03C	TIMERn_ROUTELOC2	RW	I/O Routing Location Register
0x060	TIMERn_CC0_CTRL	RW	CC Channel Control Register
0x064	TIMERn_CC0_CCV	RWH(a)	CC Channel Value Register
0x068	TIMERn_CC0_CCVP	R	CC Channel Value Peek Register
0x06C	TIMERn_CC0_CCVB	RWH	CC Channel Buffer Register
...	TIMERn_CCx_CTRL	RW	CC Channel Control Register
...	TIMERn_CCx_CCV	RWH(a)	CC Channel Value Register
...	TIMERn_CCx_CCVP	R	CC Channel Value Peek Register
...	TIMERn_CCx_CCVB	RWH	CC Channel Buffer Register
0x090	TIMERn_CC3_CTRL	RW	CC Channel Control Register
0x094	TIMERn_CC3_CCV	RWH(a)	CC Channel Value Register
0x098	TIMERn_CC3_CCVP	R	CC Channel Value Peek Register
0x09C	TIMERn_CC3_CCVB	RWH	CC Channel Buffer Register
0x0A0	TIMERn_DCTRL	RW	DTI Control Register
0x0A4	TIMERn_DTTIME	RW	DTI Time Control Register
0x0A8	TIMERn_DTC	RW	DTI Fault Configuration Register
0x0AC	TIMERn_DTOGEN	RW	DTI Output Generation Enable Register
0x0B0	TIMERn_DTFault	R	DTI Fault Register
0x0B4	TIMERn_DTFaultTC	W1	DTI Fault Clear Register
0x0B8	TIMERn_DTLock	RWH	DTI Configuration Lock Register

## 21.5 Register Description

### 21.5.1 TIMERn\_CTRL - Control Register

Offset	Bit Position																															
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0x0	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0	RSSCOIST	RW	0		
Access	ATI	RW	0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0	PRES	RW	0x0		
Name	RSSCOIST	ATI	PRES	CLKSEL	DISYNCOUT	X2CNT	FALLA	RISEA	DMACLRACT	DEBUGRUN	QDM	OSMEN	SYNC	MODE																		

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	RSSCOIST	0	RW	<b>Reload-Start Sets Compare Output Initial State</b>  When set, compare output is set to COIST value at Reload-Start event
28	ATI	0	RW	<b>Always Track Inputs</b>  when set, makes CCPOL always track the polarity of the inputs
27:24	PRES	0x0	RW	<b>Prescaler Setting</b>  These bits select the prescaling factor.
	Value	Mode		Description
	0	DIV1		The HFPERCLK is undivided
	1	DIV2		The HFPERCLK is divided by 2
	2	DIV4		The HFPERCLK is divided by 4
	3	DIV8		The HFPERCLK is divided by 8
	4	DIV16		The HFPERCLK is divided by 16
	5	DIV32		The HFPERCLK is divided by 32
	6	DIV64		The HFPERCLK is divided by 64
	7	DIV128		The HFPERCLK is divided by 128
	8	DIV256		The HFPERCLK is divided by 256
	9	DIV512		The HFPERCLK is divided by 512
	10	DIV1024		The HFPERCLK is divided by 1024
23:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17:16	CLKSEL	0x0	RW	<b>Clock Source Select</b>  These bits select the clock source for the timer.
	Value	Mode		Description
	0	PRESCHFPERCLK		Prescaled HFPERCLK

Bit	Name	Reset	Access	Description															
1	CC1			Compare/Capture Channel 1 Input															
2	TIMEROUF			Timer is clocked by underflow(down-count) or overflow(up-count) in the lower numbered neighbor Timer															
15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
14	DISSYNCOUT	0	RW	<b>Disable Timer From Start/Stop/Reload Other Synchronized Timers</b>  When this bit is set, the Timer does not start/stop/reload other timer with SYNC bit set															
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Timer can start/stop/reload other timers with SYNC bit set</td></tr> <tr> <td>1</td><td>Timer cannot start/stop/reload other timers with SYNC bit set</td></tr> </tbody> </table>	Value	Description	0	Timer can start/stop/reload other timers with SYNC bit set	1	Timer cannot start/stop/reload other timers with SYNC bit set									
Value	Description																		
0	Timer can start/stop/reload other timers with SYNC bit set																		
1	Timer cannot start/stop/reload other timers with SYNC bit set																		
13	X2CNT	0	RW	<b>2x Count Mode</b>  Enable 2x count mode															
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
11:10	FALLA	0x0	RW	<b>Timer Falling Input Edge Action</b>  These bits select the action taken in the counter when a falling edge occurs on the input.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NONE</td><td>No action</td></tr> <tr> <td>1</td><td>START</td><td>Start counter without reload</td></tr> <tr> <td>2</td><td>STOP</td><td>Stop counter without reload</td></tr> <tr> <td>3</td><td>RELOADSTART</td><td>Reload and start counter</td></tr> </tbody> </table>	Value	Mode	Description	0	NONE	No action	1	START	Start counter without reload	2	STOP	Stop counter without reload	3	RELOADSTART	Reload and start counter
Value	Mode	Description																	
0	NONE	No action																	
1	START	Start counter without reload																	
2	STOP	Stop counter without reload																	
3	RELOADSTART	Reload and start counter																	
9:8	RISEA	0x0	RW	<b>Timer Rising Input Edge Action</b>  These bits select the action taken in the counter when a rising edge occurs on the input.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NONE</td><td>No action</td></tr> <tr> <td>1</td><td>START</td><td>Start counter without reload</td></tr> <tr> <td>2</td><td>STOP</td><td>Stop counter without reload</td></tr> <tr> <td>3</td><td>RELOADSTART</td><td>Reload and start counter</td></tr> </tbody> </table>	Value	Mode	Description	0	NONE	No action	1	START	Start counter without reload	2	STOP	Stop counter without reload	3	RELOADSTART	Reload and start counter
Value	Mode	Description																	
0	NONE	No action																	
1	START	Start counter without reload																	
2	STOP	Stop counter without reload																	
3	RELOADSTART	Reload and start counter																	
7	DMACLRAC	0	RW	<b>DMA Request Clear on Active</b>  When this bit is set, the DMA requests are cleared when the corresponding DMA channel is active. This enables the timer DMA requests to be cleared without accessing the timer.															
6	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>  Set this bit to enable timer to run in debug mode.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Timer is frozen in debug mode</td></tr> <tr> <td>1</td><td>Timer is running in debug mode</td></tr> </tbody> </table>	Value	Description	0	Timer is frozen in debug mode	1	Timer is running in debug mode									
Value	Description																		
0	Timer is frozen in debug mode																		
1	Timer is running in debug mode																		

Bit	Name	Reset	Access	Description
5	QDM	0	RW	<b>Quadrature Decoder Mode Selection</b>
This bit sets the mode for the quadrature decoder.				
	Value	Mode		Description
	0	X2		X2 mode selected
	1	X4		X4 mode selected
4	OSMEN	0	RW	<b>One-shot Mode Enable</b>
Enable/disable one shot mode.				
3	SYNC	0	RW	<b>Timer Start/Stop/Reload Synchronization</b>
When this bit is set, the Timer is started/stopped/reloaded by start/stop/reload commands in the other timers				
	Value			Description
	0			Timer is not started/stopped/reloaded by other timers
	1			Timer is started/stopped/reloaded by other timers
2	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
1:0	MODE	0x0	RW	<b>Timer Mode</b>
These bits set the counting mode for the Timer. Note, when Quadrature Decoder Mode is selected (MODE = 'b11), the CLKSEL is don't care. The Timer is clocked by the Decoder Mode clock output.				
	Value	Mode		Description
	0	UP		Up-count mode
	1	DOWN		Down-count mode
	2	UPDOWN		Up/down-count mode
	3	QDEC		Quadrature decoder mode

## 21.5.2 TIMERn\_CMD - Command Register

Offset	Bit Position																																	
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
<b>Reset</b>																															0	0		
<b>Access</b>																															W1	W1		
<b>Name</b>																																	STOP	START

Bit	Name	Reset	Access	Description
31:2	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	STOP	0	W1	<b>Stop Timer</b>
	Set this bit to stop timer			
0	START	0	W1	<b>Start Timer</b>
	Set this bit to start timer			

### 21.5.3 TIMERn\_STATUS - Status Register

Offset	Bit Position																
Reset	31	30	29	28	27	26	25	24									
Access	CCPOL3	R	0	27	CCPOL2	R	0	26	CCPOL1	R	0	25	CCPOL0	R	0	24	
Name																	
	ICV3	R	0	19	ICV2	R	0	18	ICV1	R	0	17	ICV0	R	0	16	
	CCVBV3	R	0	11	CCVBV2	R	0	10	CCVBV1	R	0	9	CCVBV0	R	0	8	
	TOPBV	R	0	2	DIR	R	0	1	RUNNING	R	0	0					

Bit	Name	Reset	Access	Description
31:28	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

27 CCPOL3 0 R CC3 Polarity

In Input Capture mode, this bit indicates the polarity of the edge that triggered capture in TIMERn\_CC3\_CCV. In Compare/PWM mode, this bit indicates the polarity of the selected input to CC channel 3. These bits are cleared when CCMODE is written to 0b00 (Off).

Value	Mode	Description
0	LOWRISE	CC3 polarity low level/rising edge
1	HIGHFALL	CC3 polarity high level/falling edge

26 CCPOL2 0 R CC2 Polarity

In Input Capture mode, this bit indicates the polarity of the edge that triggered capture in TIMERn\_CC2\_CCV. In Compare/PWM mode, this bit indicates the polarity of the selected input to CC channel 2. These bits are cleared when CCMODE is written to 0b00 (Off).

Value	Mode	Description
0	LOWRISE	CC2 polarity low level/rising edge
1	HIGHFALL	CC2 polarity high level/falling edge

25 CCPOL1 0 R CC1 Polarity

In Input Capture mode, this bit indicates the polarity of the edge that triggered capture in TIMERn\_CC1\_CCV. In Compare/PWM mode, this bit indicates the polarity of the selected input to CC channel 1. These bits are cleared when CCMODE is written to 0b00 (Off).

Value	Mode	Description
0	LOWRISE	CC1 polarity low level/rising edge
1	HIGHFALL	CC1 polarity high level/falling edge

24 CCPOL0 0 R CC0 Polarity

In Input Capture mode, this bit indicates the polarity of the edge that triggered capture in TIMERn\_CC0\_CCV. In Compare/PWM mode, this bit indicates the polarity of the selected input to CC channel 0. These bits are cleared when CCMODE is written to 0b00 (Off).

Value	Mode	Description
0	LOWRISE	CC0 polarity low level/rising edge
1	HIGHFALL	CC0 polarity high level/falling edge

Bit	Name	Reset	Access	Description						
23:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>						
19	ICV3	0	R	<b>CC3 Input Capture Valid</b>						
				This bit indicates that TIMERn_CC3_CCV contains a valid capture value. These bits are only used in input capture mode and are cleared when CCMODE is written to 0b00 (Off).						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>TIMERn_CC3_CCV does not contain a valid capture value(FIFO empty)</td></tr> <tr> <td>1</td><td>TIMERn_CC3_CCV contains a valid capture value(FIFO not empty)</td></tr> </tbody> </table>	Value	Description	0	TIMERn_CC3_CCV does not contain a valid capture value(FIFO empty)	1	TIMERn_CC3_CCV contains a valid capture value(FIFO not empty)
Value	Description									
0	TIMERn_CC3_CCV does not contain a valid capture value(FIFO empty)									
1	TIMERn_CC3_CCV contains a valid capture value(FIFO not empty)									
18	ICV2	0	R	<b>CC2 Input Capture Valid</b>						
				This bit indicates that TIMERn_CC2_CCV contains a valid capture value. These bits are only used in input capture mode and are cleared when CCMODE is written to 0b00 (Off).						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>TIMERn_CC2_CCV does not contain a valid capture value(FIFO empty)</td></tr> <tr> <td>1</td><td>TIMERn_CC2_CCV contains a valid capture value(FIFO not empty)</td></tr> </tbody> </table>	Value	Description	0	TIMERn_CC2_CCV does not contain a valid capture value(FIFO empty)	1	TIMERn_CC2_CCV contains a valid capture value(FIFO not empty)
Value	Description									
0	TIMERn_CC2_CCV does not contain a valid capture value(FIFO empty)									
1	TIMERn_CC2_CCV contains a valid capture value(FIFO not empty)									
17	ICV1	0	R	<b>CC1 Input Capture Valid</b>						
				This bit indicates that TIMERn_CC1_CCV contains a valid capture value. These bits are only used in input capture mode and are cleared when CCMODE is written to 0b00 (Off).						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>TIMERn_CC1_CCV does not contain a valid capture value(FIFO empty)</td></tr> <tr> <td>1</td><td>TIMERn_CC1_CCV contains a valid capture value(FIFO not empty)</td></tr> </tbody> </table>	Value	Description	0	TIMERn_CC1_CCV does not contain a valid capture value(FIFO empty)	1	TIMERn_CC1_CCV contains a valid capture value(FIFO not empty)
Value	Description									
0	TIMERn_CC1_CCV does not contain a valid capture value(FIFO empty)									
1	TIMERn_CC1_CCV contains a valid capture value(FIFO not empty)									
16	ICV0	0	R	<b>CC0 Input Capture Valid</b>						
				This bit indicates that TIMERn_CC0_CCV contains a valid capture value. These bits are only used in input capture mode and are cleared when CCMODE is written to 0b00 (Off).						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>TIMERn_CC0_CCV does not contain a valid capture value(FIFO empty)</td></tr> <tr> <td>1</td><td>TIMERn_CC0_CCV contains a valid capture value(FIFO not empty)</td></tr> </tbody> </table>	Value	Description	0	TIMERn_CC0_CCV does not contain a valid capture value(FIFO empty)	1	TIMERn_CC0_CCV contains a valid capture value(FIFO not empty)
Value	Description									
0	TIMERn_CC0_CCV does not contain a valid capture value(FIFO empty)									
1	TIMERn_CC0_CCV contains a valid capture value(FIFO not empty)									
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>						
11	CCVBV3	0	R	<b>CC3 CCVB Valid</b>						
				This field indicates that the TIMERn_CC3_CCVB registers contain data which have not been written to TIMERn_CC3_CCV. These bits are only used in output compare/PWM mode and are cleared when CCMODE is written to 0b00 (Off).						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>TIMERn_CC3_CCVB does not contain valid data</td></tr> <tr> <td>1</td><td>TIMERn_CC3_CCVB contains valid data which will be written to TIMERn_CC3_CCV on the next update event</td></tr> </tbody> </table>	Value	Description	0	TIMERn_CC3_CCVB does not contain valid data	1	TIMERn_CC3_CCVB contains valid data which will be written to TIMERn_CC3_CCV on the next update event
Value	Description									
0	TIMERn_CC3_CCVB does not contain valid data									
1	TIMERn_CC3_CCVB contains valid data which will be written to TIMERn_CC3_CCV on the next update event									

Bit	Name	Reset	Access	Description
10	CCVBV2	0	R	<b>CC2 CCVB Valid</b>
This field indicates that the TIMERn_CC2_CCVB registers contain data which have not been written to TIMERn_CC2_CCV. These bits are only used in output compare/PWM mode and are cleared when CCMODE is written to 0b00 (Off).				
Value		Description		
0		TIMERn_CC2_CCVB does not contain valid data		
1		TIMERn_CC2_CCVB contains valid data which will be written to TIMERn_CC2_CCV on the next update event		
9	CCVBV1	0	R	<b>CC1 CCVB Valid</b>
This field indicates that the TIMERn_CC1_CCVB registers contain data which have not been written to TIMERn_CC1_CCV. These bits are only used in output compare/PWM mode and are cleared when CCMODE is written to 0b00 (Off).				
Value		Description		
0		TIMERn_CC1_CCVB does not contain valid data		
1		TIMERn_CC1_CCVB contains valid data which will be written to TIMERn_CC1_CCV on the next update event		
8	CCVBV0	0	R	<b>CC0 CCVB Valid</b>
This field indicates that the TIMERn_CC0_CCVB registers contain data which have not been written to TIMERn_CC0_CCV. These bits are only used in output compare/PWM mode and are cleared when CCMODE is written to 0b00 (Off).				
Value		Description		
0		TIMERn_CC0_CCVB does not contain valid data		
1		TIMERn_CC0_CCVB contains valid data which will be written to TIMERn_CC0_CCV on the next update event		
7:3	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
2	TOPBV	0	R	<b>TOPB Valid</b>
This indicates that TIMERn_TOPB contains valid data that has not been written to TIMERn_TOP. This bit is also cleared when TIMERn_TOP is written.				
Value		Description		
0		TIMERn_TOPB does not contain valid data		
1		TIMERn_TOPB contains valid data which will be written to TIMERn_TOP on the next update event		
1	DIR	0	R	<b>Direction</b>
Indicates count direction.				
Value		Mode	Description	
0		UP	Counting up	
1		DOWN	Counting down	

Bit	Name	Reset	Access	Description
0	RUNNING	0	R	<b>Running</b>  Indicates if timer is running or not.
<hr/>				

#### 21.5.4 TIMERn\_IF - Interrupt Flag Register

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:12	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
<hr/>				
11	ICBOF3	0	R	<b>CC Channel 3 Input Capture Buffer Overflow Interrupt Flag</b>  This bit indicates that a new capture value has pushed an unread value out of TIMERn_CC3_CCVB.
<hr/>				
10	ICBOF2	0	R	<b>CC Channel 2 Input Capture Buffer Overflow Interrupt Flag</b>  This bit indicates that a new capture value has pushed an unread value out of TIMERn_CC2_CCVB.
<hr/>				
9	ICBOF1	0	R	<b>CC Channel 1 Input Capture Buffer Overflow Interrupt Flag</b>  This bit indicates that a new capture value has pushed an unread value out of TIMERn_CC1_CCVB.
<hr/>				
8	ICBOF0	0	R	<b>CC Channel 0 Input Capture Buffer Overflow Interrupt Flag</b>  This bit indicates that a new capture value has pushed an unread value out of TIMERn_CC0_CCVB.
<hr/>				
7	CC3	0	R	<b>CC Channel 3 Interrupt Flag</b>  This bit indicates that there has been an interrupt event on Compare/Capture channel 3.
<hr/>				
6	CC2	0	R	<b>CC Channel 2 Interrupt Flag</b>  This bit indicates that there has been an interrupt event on Compare/Capture channel 2.
<hr/>				
5	CC1	0	R	<b>CC Channel 1 Interrupt Flag</b>  This bit indicates that there has been an interrupt event on Compare/Capture channel 1.
<hr/>				
4	CC0	0	R	<b>CC Channel 0 Interrupt Flag</b>  This bit indicates that there has been an interrupt event on Compare/Capture channel 0.
<hr/>				
3	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
<hr/>				
2	DIRCHG	0	R	<b>Direction Change Detect Interrupt Flag</b>  This bit is set when count direction changes. Set only in Quadrature Decoder mode
<hr/>				
1	UF	0	R	<b>Underflow Interrupt Flag</b>  This bit indicates that there has been an underflow.
<hr/>				
0	OF	0	R	<b>Overflow Interrupt Flag</b>  This bit indicates that there has been an overflow.
<hr/>				

## 21.5.5 TIMERn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																			
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12
Reset																				
Access																				
Name																				
ICBOF3	W1	0	11	ICBOF2	W1	0	10	ICBOF1	W1	0	9	ICBOF0	W1	0	8	CC3	W1	0	7	CC2
ICBOF3	W1	0	11	ICBOF2	W1	0	10	ICBOF1	W1	0	9	ICBOF0	W1	0	8	CC3	W1	0	6	CC2
ICBOF2	W1	0	10	ICBOF1	W1	0	9	ICBOF0	W1	0	8	CC3	W1	0	7	CC2	W1	0	5	CC1
ICBOF1	W1	0	9	ICBOF0	W1	0	8	CC3	W1	0	7	CC2	W1	0	6	CC1	W1	0	5	CC0
ICBOF0	W1	0	8	CC3	W1	0	7	CC2	W1	0	6	CC1	W1	0	5	CC0	W1	0	4	CC0
CC3	W1	0	7	CC2	W1	0	6	CC1	W1	0	5	CC0	W1	0	4	DIRCHG	W1	0	3	DIRCHG
CC2	W1	0	6	CC1	W1	0	5	CC0	W1	0	4	DIRCHG	W1	0	3	UF	W1	0	2	UF
CC1	W1	0	5	CC0	W1	0	4	DIRCHG	W1	0	3	UF	W1	0	2	OF	W1	0	1	OF
CC0	W1	0	4	DIRCHG	W1	0	3	UF	W1	0	2	OF	W1	0	1	OF	W1	0	0	OF

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	ICBOF3	0	W1	<b>Set ICBOF3 Interrupt Flag</b>  Write 1 to set the ICBOF3 interrupt flag
10	ICBOF2	0	W1	<b>Set ICBOF2 Interrupt Flag</b>  Write 1 to set the ICBOF2 interrupt flag
9	ICBOF1	0	W1	<b>Set ICBOF1 Interrupt Flag</b>  Write 1 to set the ICBOF1 interrupt flag
8	ICBOF0	0	W1	<b>Set ICBOF0 Interrupt Flag</b>  Write 1 to set the ICBOF0 interrupt flag
7	CC3	0	W1	<b>Set CC3 Interrupt Flag</b>  Write 1 to set the CC3 interrupt flag
6	CC2	0	W1	<b>Set CC2 Interrupt Flag</b>  Write 1 to set the CC2 interrupt flag
5	CC1	0	W1	<b>Set CC1 Interrupt Flag</b>  Write 1 to set the CC1 interrupt flag
4	CC0	0	W1	<b>Set CC0 Interrupt Flag</b>  Write 1 to set the CC0 interrupt flag
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	DIRCHG	0	W1	<b>Set DIRCHG Interrupt Flag</b>  Write 1 to set the DIRCHG interrupt flag
1	UF	0	W1	<b>Set UF Interrupt Flag</b>  Write 1 to set the UF interrupt flag
0	OF	0	W1	<b>Set OF Interrupt Flag</b>  Write 1 to set the OF interrupt flag

## 21.5.6 TIMERn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																			
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12
<b>Reset</b>																				
<b>Access</b>																				
<b>Name</b>																				

Bit	Name	Reset	Access	Description
31:12	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	ICBOF3	0	(R)W1	<b>Clear ICBOF3 Interrupt Flag</b>
	Write 1 to clear the ICBOF3 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
10	ICBOF2	0	(R)W1	<b>Clear ICBOF2 Interrupt Flag</b>
	Write 1 to clear the ICBOF2 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
9	ICBOF1	0	(R)W1	<b>Clear ICBOF1 Interrupt Flag</b>
	Write 1 to clear the ICBOF1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
8	ICBOF0	0	(R)W1	<b>Clear ICBOF0 Interrupt Flag</b>
	Write 1 to clear the ICBOF0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
7	CC3	0	(R)W1	<b>Clear CC3 Interrupt Flag</b>
	Write 1 to clear the CC3 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
6	CC2	0	(R)W1	<b>Clear CC2 Interrupt Flag</b>
	Write 1 to clear the CC2 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
5	CC1	0	(R)W1	<b>Clear CC1 Interrupt Flag</b>
	Write 1 to clear the CC1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
4	CC0	0	(R)W1	<b>Clear CC0 Interrupt Flag</b>
	Write 1 to clear the CC0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			
3	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	DIRCHG	0	(R)W1	<b>Clear DIRCHG Interrupt Flag</b>
	Write 1 to clear the DIRCHG interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).			

Bit	Name	Reset	Access	Description
1	UF	0	(R)W1	<b>Clear UF Interrupt Flag</b>  Write 1 to clear the UF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	OF	0	(R)W1	<b>Clear OF Interrupt Flag</b>  Write 1 to clear the OF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

### 21.5.7 TIMERn\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
11	ICBOF3	0	RW	<b>ICBOF3 Interrupt Enable</b> Enable/disable the ICBOF3 interrupt
10	ICBOF2	0	RW	<b>ICBOF2 Interrupt Enable</b> Enable/disable the ICBOF2 interrupt
9	ICBOF1	0	RW	<b>ICBOF1 Interrupt Enable</b> Enable/disable the ICBOF1 interrupt
8	ICBOF0	0	RW	<b>ICBOF0 Interrupt Enable</b> Enable/disable the ICBOF0 interrupt
7	CC3	0	RW	<b>CC3 Interrupt Enable</b> Enable/disable the CC3 interrupt
6	CC2	0	RW	<b>CC2 Interrupt Enable</b> Enable/disable the CC2 interrupt
5	CC1	0	RW	<b>CC1 Interrupt Enable</b> Enable/disable the CC1 interrupt
4	CC0	0	RW	<b>CC0 Interrupt Enable</b> Enable/disable the CC0 interrupt
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	DIRCHG	0	RW	<b>DIRCHG Interrupt Enable</b> Enable/disable the DIRCHG interrupt
1	UF	0	RW	<b>UF Interrupt Enable</b> Enable/disable the UF interrupt
0	OF	0	RW	<b>OF Interrupt Enable</b> Enable/disable the OF interrupt

**21.5.8 TIMERn\_TOP - Counter Top Value Register**

Offset	Bit Position																																
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x0000FFFF																																
Access	RWH																																
Name	TOP																																

Bit	Name	Reset	Access	Description
31:0	TOP	0x0000FFFF	RWH	<b>Counter Top Value</b>
These bits hold the TOP value for the counter.				

**21.5.9 TIMERn\_TOPB - Counter Top Value Buffer Register**

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	TOPB																															

Bit	Name	Reset	Access	Description
31:0	TOPB	0x00000000	RW	<b>Counter Top Value Buffer</b>
These bits hold the TOP buffer value.				

## 21.5.10 TIMERn\_CNT - Counter Value Register

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RWH																															
Name	CNT																															

Bit	Name	Reset	Access	Description
31:0	CNT	0x00000000	RWH	<b>Counter Value</b>
These bits hold the counter value.				

## 21.5.11 TIMERn\_LOCK - TIMER Configuration Lock Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																															
Access	RWH																															
Name	TIMERLOCKKEY																															

Bit	Name	Reset	Access	Description
31:16	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
15:0	TIMERLOCKKEY	0x0000	RWH	<b>Timer Lock Key</b>
Write any other value than the unlock code to lock TIMERn_CTRL, TIMERn_CMD, TIMERn_TOP, TIMERn_CNT, TIMERn_CCx_CTRL and TIMERn_CCx_CCV from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.				
Mode	Value	Description		
Read Operation				
UNLOCKED	0	TIMER registers are unlocked		
LOCKED	1	TIMER registers are locked		
Write Operation				
LOCK	0	Lock TIMER registers		
UNLOCK	0xCE80	Unlock TIMER registers		

## 21.5.12 TIMERn\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0	0	0	0	0			
Access																									RW	RW	RW	RW	RW			
Name																									CDT12PEN	CDT11PEN	CDT10PEN	CC3PEN	CC2PEN	CC1PEN	CC0PEN	

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
10	CDT12PEN	0	RW	<b>CC Channel 2 Complementary Dead-Time Insertion Pin Enable</b> Enable/disable CC channel 2 complementary dead-time insertion output connection to pin.
9	CDT11PEN	0	RW	<b>CC Channel 1 Complementary Dead-Time Insertion Pin Enable</b> Enable/disable CC channel 1 complementary dead-time insertion output connection to pin.
8	CDT10PEN	0	RW	<b>CC Channel 0 Complementary Dead-Time Insertion Pin Enable</b> Enable/disable CC channel 0 complementary dead-time insertion output connection to pin.
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	CC3PEN	0	RW	<b>CC Channel 3 Pin Enable</b> Enable/disable CC channel 3 output/input connection to pin.
2	CC2PEN	0	RW	<b>CC Channel 2 Pin Enable</b> Enable/disable CC channel 2 output/input connection to pin.
1	CC1PEN	0	RW	<b>CC Channel 1 Pin Enable</b> Enable/disable CC channel 1 output/input connection to pin.
0	CC0PEN	0	RW	<b>CC Channel 0 Pin Enable</b> Enable/disable CC Channel 0 output/input connection to pin.

### 21.5.13 TIMERn\_ROUTELOC0 - I/O Routing Location Register

Bit	Name	Reset	Access	Description		
31:30	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>				
29:24	CC3LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CC3 pin.		
	Value	Mode	Description			
	0	LOC0	Location 0			
	1	LOC1	Location 1			
	2	LOC2	Location 2			
	3	LOC3	Location 3			
	4	LOC4	Location 4			
	5	LOC5	Location 5			
	6	LOC6	Location 6			
	7	LOC7	Location 7			
23:22	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>				
21:16	CC2LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CC2 pin.		
	Value	Mode	Description			
	0	LOC0	Location 0			
	1	LOC1	Location 1			
	2	LOC2	Location 2			
	3	LOC3	Location 3			
	4	LOC4	Location 4			
	5	LOC5	Location 5			
	6	LOC6	Location 6			
	7	LOC7	Location 7			
15:14	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>				

Bit	Name	Reset	Access	Description
13:8	CC1LOC	0x00	RW	<b>I/O Location</b>
Decides the location of the CC1 pin.				
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
	3	LOC3		Location 3
	4	LOC4		Location 4
	5	LOC5		Location 5
	6	LOC6		Location 6
	7	LOC7		Location 7
7:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
5:0	CC0LOC	0x00	RW	<b>I/O Location</b>
Decides the location of the CC0 pin.				
	Value	Mode		Description
	0	LOC0		Location 0
	1	LOC1		Location 1
	2	LOC2		Location 2
	3	LOC3		Location 3
	4	LOC4		Location 4
	5	LOC5		Location 5
	6	LOC6		Location 6
	7	LOC7		Location 7

## 21.5.14 TIMERn\_ROUTELOC2 - I/O Routing Location Register

Offset	Bit Position																															
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset									0x00												0x00				0x00							
Access									RW								RW								RW							
Name									CDT12LOC								CDT11LOC								CDT10LOC							

Bit	Name	Reset	Access	Description																		
31:22	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																				
21:16	CDT12LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CDTI2 pin.  <table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>LOC0</td><td>Location 0</td></tr><tr><td>1</td><td>LOC1</td><td>Location 1</td></tr><tr><td>2</td><td>LOC2</td><td>Location 2</td></tr><tr><td>3</td><td>LOC3</td><td>Location 3</td></tr><tr><td>4</td><td>LOC4</td><td>Location 4</td></tr></tbody></table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4
Value	Mode	Description																				
0	LOC0	Location 0																				
1	LOC1	Location 1																				
2	LOC2	Location 2																				
3	LOC3	Location 3																				
4	LOC4	Location 4																				
15:14	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																				
13:8	CDT11LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CDTI1 pin.  <table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>LOC0</td><td>Location 0</td></tr><tr><td>1</td><td>LOC1</td><td>Location 1</td></tr><tr><td>2</td><td>LOC2</td><td>Location 2</td></tr><tr><td>3</td><td>LOC3</td><td>Location 3</td></tr><tr><td>4</td><td>LOC4</td><td>Location 4</td></tr></tbody></table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4
Value	Mode	Description																				
0	LOC0	Location 0																				
1	LOC1	Location 1																				
2	LOC2	Location 2																				
3	LOC3	Location 3																				
4	LOC4	Location 4																				
7:6	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																				
5:0	CDT10LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the CDTI0 pin.  <table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>LOC0</td><td>Location 0</td></tr><tr><td>1</td><td>LOC1</td><td>Location 1</td></tr><tr><td>2</td><td>LOC2</td><td>Location 2</td></tr></tbody></table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2						
Value	Mode	Description																				
0	LOC0	Location 0																				
1	LOC1	Location 1																				
2	LOC2	Location 2																				

Bit	Name	Reset	Access	Description
3		LOC3		Location 3
4		LOC4		Location 4

## 21.5.15 TIMERn\_CCx\_CTRL - CC Channel Control Register

Offset	Bit Position																	
0x060	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16		
<b>Reset</b>		RW	0	RW	0	RW	0x0	RW										
<b>Access</b>		RW	0x0	RW	0x0	RW		RW	0x0	RW								
<b>Name</b>	FILT	INSEL	PRSCONF	ICEVCTRL	ICEDGE			PRSSEL								COIST	OUTINV	MODE

Bit	Name	Reset	Access	Description
31	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
30	FILT	0	RW	<b>Digital Filter</b>  Enable digital filter.
	Value	Mode		Description
	0	DISABLE		Digital filter disabled
	1	ENABLE		Digital filter enabled
29	INSEL	0	RW	<b>Input Selection</b>  Select Compare/Capture channel input.
	Value	Mode		Description
	0	PIN		TIMERnCCx pin is selected
	1	PRS		PRS input (selected by PRSSEL) is selected
28	PRSCONF	0	RW	<b>PRS Configuration</b>  Select PRS pulse or level.
	Value	Mode		Description
	0	PULSE		Each CC event will generate a one HPERCLK cycle high pulse
	1	LEVEL		The PRS channel will follow CC out
27:26	ICEVCTRL	0x0	RW	<b>Input Capture Event Control</b>  These bits control when a Compare/Capture PRS output pulse and interrupt flag is set. DMA request however is set on every capture.
	Value	Mode		Description
	0	EVERYEDGE		PRS output pulse and interrupt flag set on every capture
	1	EVERYSECONDEDGE		PRS output pulse and interrupt flag set on every second capture
	2	RISING		PRS output pulse and interrupt flag set on rising edge only (if ICEDGE = BOTH)
	3	FALLING		PRS output pulse and interrupt flag set on falling edge only (if ICEDGE = BOTH)

Bit	Name	Reset	Access	Description
25:24	ICEDGE	0x0	RW	<b>Input Capture Edge Select</b>
These bits control which edges the edge detector triggers on. The output is used for input capture and external clock input.				
	Value	Mode		Description
	0	RISING		Rising edges detected
	1	FALLING		Falling edges detected
	2	BOTH		Both edges detected
	3	NONE		No edge detection, signal is left as it is
23:19	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
18:16	PRSSEL	0x0	RW	<b>Compare/Capture Channel PRS Input Channel Selection</b>
Select PRS input channel for Compare/Capture channel.				
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as input
	1	PRSCH1		PRS Channel 1 selected as input
	2	PRSCH2		PRS Channel 2 selected as input
	3	PRSCH3		PRS Channel 3 selected as input
	4	PRSCH4		PRS Channel 4 selected as input
	5	PRSCH5		PRS Channel 5 selected as input
	6	PRSCH6		PRS Channel 6 selected as input
	7	PRSCH7		PRS Channel 7 selected as input
15:14	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
13:12	CUFOA	0x0	RW	<b>Counter Underflow Output Action</b>
Select output action on counter underflow.				
	Value	Mode		Description
	0	NONE		No action on counter underflow
	1	TOGGLE		Toggle output on counter underflow
	2	CLEAR		Clear output on counter underflow
	3	SET		Set output on counter underflow
11:10	COFOA	0x0	RW	<b>Counter Overflow Output Action</b>
Select output action on counter overflow.				
	Value	Mode		Description
	0	NONE		No action on counter overflow
	1	TOGGLE		Toggle output on counter overflow
	2	CLEAR		Clear output on counter overflow
	3	SET		Set output on counter overflow

Bit	Name	Reset	Access	Description															
9:8	CMOA	0x0	RW	<b>Compare Match Output Action</b>  Select output action on compare match.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NONE</td><td>No action on compare match</td></tr> <tr> <td>1</td><td>TOGGLE</td><td>Toggle output on compare match</td></tr> <tr> <td>2</td><td>CLEAR</td><td>Clear output on compare match</td></tr> <tr> <td>3</td><td>SET</td><td>Set output on compare match</td></tr> </tbody> </table>	Value	Mode	Description	0	NONE	No action on compare match	1	TOGGLE	Toggle output on compare match	2	CLEAR	Clear output on compare match	3	SET	Set output on compare match
Value	Mode	Description																	
0	NONE	No action on compare match																	
1	TOGGLE	Toggle output on compare match																	
2	CLEAR	Clear output on compare match																	
3	SET	Set output on compare match																	
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
4	COIST	0	RW	<b>Compare Output Initial State</b>  This bit is only used in Output Compare and PWM mode. When this bit is set in Compare or PWM mode, the output is set high when the counter is disabled. When counting resumes, this value will represent the initial value for the output. If the bit is cleared, the output will be cleared when the counter is disabled.															
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
2	OUTINV	0	RW	<b>Output Invert</b>  Setting this bit inverts the output from the CC channel (Output compare,PWM).															
1:0	MODE	0x0	RW	<b>CC Channel Mode</b>  These bits select the mode for Compare/Capture channel.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>OFF</td><td>Compare/Capture channel turned off</td></tr> <tr> <td>1</td><td>INPUTCAPTURE</td><td>Input capture</td></tr> <tr> <td>2</td><td>OUTPUTCOMPARE</td><td>Output compare</td></tr> <tr> <td>3</td><td>PWM</td><td>Pulse-Width Modulation</td></tr> </tbody> </table>	Value	Mode	Description	0	OFF	Compare/Capture channel turned off	1	INPUTCAPTURE	Input capture	2	OUTPUTCOMPARE	Output compare	3	PWM	Pulse-Width Modulation
Value	Mode	Description																	
0	OFF	Compare/Capture channel turned off																	
1	INPUTCAPTURE	Input capture																	
2	OUTPUTCOMPARE	Output compare																	
3	PWM	Pulse-Width Modulation																	

**21.5.16 TIMERn\_CCx\_CCV - CC Channel Value Register (Actionable Reads)**

Offset	Bit Position																																
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RWH																																
Name	CCV																																

Bit	Name	Reset	Access	Description
31:0	CCV	0x00000000	RWH	<b>CC Channel Value</b>
In input capture mode, this field holds the first unread capture value. When reading this register in input capture mode, the contents of the TIMERn_CCx_CCVB register will be written to TIMERn_CCx_CCV in the next cycle. In compare mode, this field holds the compare value.				

**21.5.17 TIMERn\_CCx\_CCVP - CC Channel Value Peek Register**

Offset	Bit Position																																
0x068	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	R																																
Name	CCVP																																

Bit	Name	Reset	Access	Description
31:0	CCVP	0x00000000	R	<b>CC Channel Value Peek</b>
This field is used to read the CC value without pulling data through the FIFO in capture mode.				

## 21.5.18 TIMERn\_CCx\_CCVB - CC Channel Buffer Register

Offset	Bit Position																															
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RWH																															
Name	CCVB																															

Bit	Name	Reset	Access	Description
31:0	CCVB	0x00000000	RWH	<b>CC Channel Value Buffer</b>

In Input Capture mode, this field holds the last capture value if the TIMERn\_CCx\_CCV register already contains an earlier unread capture value. In Output Compare or PWM mode, this field holds the CC buffer value which will be written to TIMERn\_CCx\_CCV on an update event if TIMERn\_CCx\_CCVB contains valid data.

## 21.5.19 TIMERn\_DTCTRL - DTI Control Register

Offset	Bit Position																																
0x0A0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access								RW	0																								
Name					DTPRSEN																												

Bit	Name	Reset	Access	Description
31:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24	DTPRSEN	0	RW	<b>DTI PRS Source Enable</b>
				Enable/disable PRS as DTI input.
23:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	DTFATS	0	RW	<b>DTI Fault Action on Timer Stop</b>
				When Timer stops, DTI block outputs go to safe state as programmed in DTFA field of TIMERn_DTCFC register. However, when DTAR is also set, DTAR having higher priority allows channel 0 to output the incoming PRS input while the other channels go to safe state.
9	DTAR	0	RW	<b>DTI Always Run</b>
				This is used only for DTI channel 0. It Allows DTI channel 0 to keep running even when timer is stopped. This is useful when its input source is PRS. However, here the undivided HPERCLK is always used regardless of the programmed value in DTPRESC.
8:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	DTPRSSEL	0x0	RW	<b>DTI PRS Source Channel Select</b>
				Selects which PRS channel compare channel 0 will listen to.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as input
	1	PRSCH1		PRS Channel 1 selected as input
	2	PRSCH2		PRS Channel 2 selected as input
	3	PRSCH3		PRS Channel 3 selected as input
	4	PRSCH4		PRS Channel 4 selected as input
	5	PRSCH5		PRS Channel 5 selected as input
	6	PRSCH6		PRS Channel 6 selected as input
	7	PRSCH7		PRS Channel 7 selected as input
3	DTCINV	0	RW	<b>DTI Complementary Output Invert</b>
				Set to invert complementary outputs.

Bit	Name	Reset	Access	Description
2	DTIPOL	0	RW	<b>DTI Inactive Polarity</b>  Set inactive polarity for outputs.
1	DTDAS	0	RW	<b>DTI Automatic Start-up Functionality</b>  Configure DTI restart on debugger exit.
		Value	Mode	Description
		0	NORESTART	No DTI restart on debugger exit
		1	RESTART	DTI restart on debugger exit
0	DTEN	0	RW	<b>DTI Enable</b>  Enable/disable DTI.

## 21.5.20 TIMERn\_DTTIME - DTI Time Control Register

Offset	Bit Position																																
0x0A4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset									0x00												0x00												
Access									RW								RW																
Name									DTFALLT								DTRISET																DTPRESC RW

Bit	Name	Reset	Access	Description
31:22	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
21:16	DTFALLT	0x00	RW	<b>DTI Fall-time</b>  Set time span for the falling edge.
	Value			Description
	DTFALLT			Fall time of DTFALLT+1 prescaled HFPERCLK cycles
15:14	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
13:8	DTRISET	0x00	RW	<b>DTI Rise-time</b>  Set time span for the rising edge.
	Value			Description
	DTRISET			Rise time of DTRISET+1 prescaled HFPERCLK cycles
7:4	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
3:0	DTPRESC	0x0	RW	<b>DTI Prescaler Setting</b>  Select prescaler for DTI.
	Value	Mode		Description
	0	DIV1		The HFPERCLK is undivided
	1	DIV2		The HFPERCLK is divided by 2
	2	DIV4		The HFPERCLK is divided by 4
	3	DIV8		The HFPERCLK is divided by 8
	4	DIV16		The HFPERCLK is divided by 16
	5	DIV32		The HFPERCLK is divided by 32
	6	DIV64		The HFPERCLK is divided by 64
	7	DIV128		The HFPERCLK is divided by 128
	8	DIV256		The HFPERCLK is divided by 256
	9	DIV512		The HFPERCLK is divided by 512
	10	DIV1024		The HFPERCLK is divided by 1024

Bit	Name	Reset	Access	Description
-----	------	-------	--------	-------------

## 21.5.21 TIMERn\_DTCF - DTI Fault Configuration Register

Offset	Bit Position																																																										
0x0A8	31	30	29	28	27	0	26	0	25	0	24	0	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																							
Reset															0x0															0x0																													
Access															RW															RW																													
Name															DTFA															DTPRS1FSEL															DTPRS0FSEL														

Bit	Name	Reset	Access	Description
31:28	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
27	DTLOCKUPFEN	0	RW	<b>DTI Lockup Fault Enable</b>  Set this bit to 1 to enable core lockup as a fault source
26	DTDBGFEN	0	RW	<b>DTI Debugger Fault Enable</b>  Set this bit to 1 to enable debugger as a fault source
25	DTPRS1FEN	0	RW	<b>DTI PRS 1 Fault Enable</b>  Set this bit to 1 to enable PRS source 1(PRS channel determined by DTPRS1FSEL) as a fault source
24	DTPRS0FEN	0	RW	<b>DTI PRS 0 Fault Enable</b>  Set this bit to 1 to enable PRS source 0(PRS channel determined by DTPRS0FSEL) as a fault source
23:18	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
17:16	DTFA	0x0	RW	<b>DTI Fault Action</b>  Select fault action.
	Value	Mode	Description	
	0	NONE	No action on fault	
	1	INACTIVE	Set outputs inactive	
	2	CLEAR	Clear outputs	
	3	TRISTATE	Tristate outputs	
15:11	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
10:8	DTPRS1FSEL	0x0	RW	<b>DTI PRS Fault Source 1 Select</b>  Select PRS channel for fault source 1.
	Value	Mode	Description	
	0	PRSCH0	PRS Channel 0 selected as fault source 1	
	1	PRSCH1	PRS Channel 1 selected as fault source 1	
	2	PRSCH2	PRS Channel 2 selected as fault source 1	

Bit	Name	Reset	Access	Description
3	PRSCH3			PRS Channel 3 selected as fault source 1
4	PRSCH4			PRS Channel 4 selected as fault source 1
5	PRSCH5			PRS Channel 5 selected as fault source 1
6	PRSCH6			PRS Channel 6 selected as fault source 1
7	PRSCH7			PRS Channel 7 selected as fault source 1
7:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	DTPRS0FSEL	0x0	RW	<b>DTI PRS Fault Source 0 Select</b>  Select PRS channel for fault source 0.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as fault source 0
	1	PRSCH1		PRS Channel 1 selected as fault source 1
	2	PRSCH2		PRS Channel 2 selected as fault source 2
	3	PRSCH3		PRS Channel 3 selected as fault source 3
	4	PRSCH4		PRS Channel 4 selected as fault source 4
	5	PRSCH5		PRS Channel 5 selected as fault source 5
	6	PRSCH6		PRS Channel 6 selected as fault source 6
	7	PRSCH7		PRS Channel 7 selected as fault source 7

## 21.5.22 TIMERn.DTOGEN - DTI Output Generation Enable Register

Offset	Bit Position																									
0x0AC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
<b>Reset</b>																									5	
<b>Access</b>																									4	
<b>Name</b>																									3	
																									2	
																									1	
																									0	

Bit	Name	Reset	Access	Description
31:6	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	DTOGCDT2EN	0	RW	<b>DTI CDTI2 Output Generation Enable</b>
	This bit enables/disables output generation for the CDTI2 output from the DTI.			
4	DTOGCDT1EN	0	RW	<b>DTI CDTI1 Output Generation Enable</b>
	This bit enables/disables output generation for the CDTI1 output from the DTI.			
3	DTOGCDT0EN	0	RW	<b>DTI CDTI0 Output Generation Enable</b>
	This bit enables/disables output generation for the CDTI0 output from the DTI.			
2	DTOGCC2EN	0	RW	<b>DTI CC2 Output Generation Enable</b>
	This bit enables/disables output generation for the CC2 output from the DTI.			
1	DTOGCC1EN	0	RW	<b>DTI CC1 Output Generation Enable</b>
	This bit enables/disables output generation for the CC1 output from the DTI.			
0	DTOGCC0EN	0	RW	<b>DTI CC0 Output Generation Enable</b>
	This bit enables/disables output generation for the CC0 output from the DTI.			

## 21.5.23 TIMERn\_DTFAULT - DTI Fault Register

Offset	Bit Position																															
0x0B0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	DTLOCKUPF	0	R	<b>DTI Lockup Fault</b>
				This bit is set to 1 if a core lockup fault has occurred and DTLOCKUPFEN is set to 1. The TIMER0_DTFAULTTC register can be used to clear fault bits.
2	DTDBGF	0	R	<b>DTI Debugger Fault</b>
				This bit is set to 1 if a debugger fault has occurred and DTDBGFEN is set to 1. The TIMER0_DTFAULTTC register can be used to clear fault bits.
1	DTPRS1F	0	R	<b>DTI PRS 1 Fault</b>
				This bit is set to 1 if a PRS 1 fault has occurred and DTPRS1FEN is set to 1. The TIMER0_DTFAULTTC register can be used to clear fault bits.
0	DTPRS0F	0	R	<b>DTI PRS 0 Fault</b>
				This bit is set to 1 if a PRS 0 fault has occurred and DTPRS0FEN is set to 1. The TIMER0_DTFAULTTC register can be used to clear fault bits.

## 21.5.24 TIMERn\_DTFaultTC - DTI Fault Clear Register

Offset	Bit Position																															
0x0B4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	TLOCKUPFC	0	W1	<b>DTI Lockup Fault Clear</b>
				Write 1 to this bit to clear core lockup fault.
2	DTDBGFC	0	W1	<b>DTI Debugger Fault Clear</b>
				Write 1 to this bit to clear debugger fault.
1	DTPRS1FC	0	W1	<b>DTI PRS1 Fault Clear</b>
				Write 1 to this bit to clear PRS 1 fault.
0	DTPRS0FC	0	W1	<b>DTI PRS0 Fault Clear</b>
				Write 1 to this bit to clear PRS 0 fault.

## 21.5.25 TIMERn\_DTLOCK - DTI Configuration Lock Register



Offset	Bit Position																															
0x0B8	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RWH															
Name																	LOCKKEY															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15:0	LOCKKEY	0x0000	RWH	<b>DTI Lock Key</b>

Write any other value than the unlock code to lock TIMERn\_ROUTE, TIMERn\_DTCtrl, TIMERn\_DTTIME and TIMERn\_DTFC from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.

Mode	Value	Description
<b>Read Operation</b>		
UNLOCKED	0	TIMER DTI registers are unlocked
LOCKED	1	TIMER DTI registers are locked
<b>Write Operation</b>		
LOCK	0	Lock TIMER DTI registers
UNLOCK	0xCE80	Unlock TIMER DTI registers

## 22. LETIMER - Low Energy Timer



### Quick Facts

#### What?

The LETIMER is a down-counter that can keep track of time and output configurable waveforms. Running on a 32768 Hz clock, the LETIMER is available in EM0 Active, EM1 Sleep, EM2 DeepSleep, and EM3 Stop.

#### Why?

The LETIMER can be used to provide repeatable waveforms to external components while remaining in EM2 DeepSleep. It is well suited for applications such as metering systems or to provide more compare values than available in the RTC.

#### How?

With buffered repeat and top value registers, the LETIMER can provide glitch-free waveforms at frequencies up to 16 kHz. It can be coupled with RTC using PRS, allowing advanced time-keeping and wake-up functions in EM2 DeepSleep and EM3 Stop.

### 22.1 Introduction

The unique LETIMER™, the Low Energy Timer, is a 16-bit timer that is available in energy mode EM0 Active, EM1 Sleep, EM2 DeepSleep, and EM3 Stop. Because of this, it can be used for timing and output generation when most of the device is powered down, allowing simple tasks to be performed while the power consumption of the system is kept at an absolute minimum.


The LETIMER can be used to output a variety of waveforms with minimal software intervention. It can also be connected to the Real Time Counter (RTC) using PRS, and can be configured to start counting on compare matches from the RTC.

### 22.2 Features

- 16-bit down count timer
- 2 Compare match registers
- Compare register 0 can be top timer top value
- Compare registers can be double buffered
- Double buffered 8-bit Repeat Register
- Same clock source as the Real Time Counter
- LETIMER can be triggered (started) by an RTC event via PRS or by software
- LETIMER can be started, stopped, and/or cleared by PRS
- 2 output pins can optionally be configured to provide different waveforms on timer underflow:
  - Toggle output pin
  - Apply a positive pulse (pulse width of one LFACLK<sub>LETIMER</sub> period)
  - PWM
- Interrupt on:
  - Compare matches
  - Timer underflow
  - Repeat done
- Optionally runs during debug
- PRS Output

## 22.3 Functional Description

An overview of the LETIMER module is shown in [Figure 22.1 LETIMER Overview on page 783](#). The LETIMER is a 16-bit down-counter with two compare registers, LETIMERn\_COMP0 and LETIMERn\_COMP1. The LETIMERn\_COMP0 register can optionally act as a top value for the counter. The repeat counter LETIMERn\_REPO allows the timer to count a specified number of times before it stops. Both the LETIMERn\_COMP0 and LETIMERn\_REPO registers can be double buffered by the LETIMERn\_COMP1 and LETIMERn\_REPO registers to allow continuous operation. The timer can generate a single pin output, or two linked outputs.



**Figure 22.1. LETIMER Overview**

### 22.3.1 Timer

The timer is started by setting command bit START in LETIMERn\_CMD, and stopped by setting the STOP command bit in the same register. RUNNING in LETIMERn\_STATUS is set as long as the timer is running. The timer can also be started on external signals, such as a compare match from the Real Time Counter. If START and STOP are set at the same time, STOP has priority, and the timer will be stopped.

The timer value can be read using the LETIMERn\_CNT register. The value can be written, and it can also be cleared by setting the CLEAR command bit in LETIMERn\_CMD. If the CLEAR and START commands are issued at the same time, the timer will be cleared, then start counting at the top value.

### 22.3.2 Compare Registers

The LETIMER has two compare match registers, LETIMERn\_COMP0 and LETIMERn\_COMP1. Each of these compare registers are capable of generating an interrupt when the counter value LETIMERn\_CNT becomes equal to their value. When LETIMERn\_CNT becomes equal to the value of LETIMERn\_COMP0, the interrupt flag COMP0 in LETIMERn\_IF is set, and when LETIMERn\_CNT becomes equal to the value of LETIMERn\_COMP1, the interrupt flag COMP1 in LETIMERn\_IF is set.

### 22.3.3 Top Value

If COMP0TOP in LETIMERn\_CTRL is set, the value of LETIMERn\_COMP0 acts as the top value of the timer, and LETIMERn\_COMP0 is loaded into LETIMERn\_CNT on timer underflow. If COMP0TOP is cleared to 0, the timer wraps around to 0xFFFF. The underflow interrupt flag UF in LETIMERn\_IF is set when the timer reaches zero.

#### 22.3.3.1 Buffered Top Value

If BUFTOP in LETIMERn\_CTRL is set, the value of LETIMERn\_COMP0 is buffered by LETIMERn\_COMP1. In this mode, the value of LETIMERn\_COMP1 is loaded into LETIMERn\_COMP0 every time LETIMERn REP0 is about to decrement to 0. This can for instance be used in conjunction with the buffered repeat mode to generate continually changing output waveforms.

Write operations to LETIMERn\_COMP0 have priority over buffer loads.

#### 22.3.3.2 Repeat Modes

By default, the timer wraps around to the top value or 0xFFFF on each underflow, and continues counting. The repeat counters can be used to get more control of the operation of the timer, including defining the number of times the counter should wrap around. Four different repeat modes are available, see [Table 22.1 LETIMER Repeat Modes on page 784](#).


**Table 22.1. LETIMER Repeat Modes**

REPMODE	Mode	Description
0b00	Free-running	The timer runs until it is stopped.
0b01	One-shot	The timer runs as long as LETIMERn REP0 != 0. LETIMERn REP0 is decremented at each timer underflow.
0b10	Buffered	The timer runs as long as LETIMERn REP0 != 0. LETIMERn REP0 is decremented on each timer underflow. If LETIMERn REP1 has been written, it is loaded into LETIMERn REP0 when LETIMERn REP0 is about to be decremented to 0.
0b11	Double	The timer runs as long as LETIMERn REP0 != 0 or LETIMERn REP1 != 0. Both LETIMERn REP0 and LETIMERn REP1 are decremented at each timer underflow.

The interrupt flags REP0 and REP1 in LETIMERn\_IF are set whenever LETIMERn REP0 or LETIMERn REP1 are decremented to 0 respectively. REP0 is also set when the value of LETIMERn REP1 is loaded into LETIMERn REP0 in buffered mode.

### 22.3.3.3 Free-Running Mode

In free-running mode, the LETIMER acts as a regular timer and the repeat counter is disabled. When started, the timer runs until it is stopped using the STOP command bit in LETIMERn\_CMD. A state machine for this mode is shown in [Figure 22.2 LETIMER State Machine for Free-running Mode on page 785](#).



**Figure 22.2. LETIMER State Machine for Free-running Mode**

Note that the CLEAR command bit in LETIMERn\_CMD always has priority over other changes to LETIMERn\_CNT. When the clear command is used, LETIMERn\_CNT is set to 0 and an underflow event will not be generated when LETIMERn\_CNT wraps around to the top value or 0xFFFF. Since no underflow event is generated, no output action is performed. LETIMERn\_REP0, LETIMERn\_REP1, LETIMERn\_COMP0 and LETIMERn\_COMP1 are also left untouched.

#### 22.3.3.4 One-shot Mode

The one-shot repeat mode is the most basic repeat mode. In this mode, the repeat register LETIMERn\_REPEAT is decremented every time the timer underflows, and the timer stops when LETIMERn\_REPEAT goes from 1 to 0. In this mode, the timer counts down LETIMERn\_REPEAT times, i.e. the timer underflows LETIMERn\_REPEAT times.

**Note:** Write operations to LETIMERn\_REPEAT have priority over the timer decrement event. If LETIMERn\_REPEAT is assigned a new value in the same cycle as a timer decrement event occurs, the timer decrement will not occur and the new value is assigned.

LETIMERn\_REPEAT can be written while the timer is running to allow the timer to run for longer periods at a time without stopping. Figure 22.3 LETIMER One-shot Repeat State Machine on page 786 .




Figure 22.3. LETIMER One-shot Repeat State Machine

### 22.3.3.5 Buffered Mode

The Buffered repeat mode allows buffered timer operation. When started, the timer runs LETIMERn\_REP0 number of times. If LETIMERn\_REP1 has been written since the last time it was used and it is nonzero, LETIMERn\_REP1 is then loaded into LETIMERn\_REPO, and counting continues the new number of times. The timer keeps going as long as LETIMERn\_REP1 is updated with a nonzero value before LETIMERn\_REPO is finished counting down. The timer top value (LETIMERn\_COMP0) may also optionally be buffered by setting BUFTOP in LETIMERn\_CTRL.

If the timer is started when both LETIMERn\_CNT and LETIMERn\_REPO are zero but LETIMERn\_REP1 is non-zero, LETIMERn\_REP1 is loaded into LETIMERn\_REPO, and the counter counts the loaded number of times.

Used in conjunction with a buffered top value, both the top and repeat values of the timer may be buffered, and the timer can for instance be set to run 4 times with period 7 (top value 6), 6 times with period 200, then 3 times with period 50.

A state machine for the buffered repeat mode is shown in [Figure 22.4 LETIMER Buffered Repeat State Machine on page 787](#). REP1\_USED shown in the state machine is an internal variable that keeps track of whether the value in LETIMERn\_REP1 has been loaded into LETIMERn\_REPO or not. The purpose of this is that a value written to LETIMERn\_REP1 should only be counted once. REP1\_USED is cleared whenever LETIMERn\_REP1 is written.





Figure 22.4. LETIMER Buffered Repeat State Machine

### 22.3.3.6 Double Mode

The Double repeat mode works much like the one-shot repeat mode. The difference is that, where the one-shot mode counts as long as LETIMERn\_REPO is larger than 0, the double mode counts as long as either LETIMERn\_REPO or LETIMERn\_REP1 is larger than 0. As an example, say LETIMERn\_REPO is 3 and LETIMERn\_REP1 is 10 when the timer is started. If no further interaction is done with the timer, LETIMERn\_REPO will now be decremented 3 times, and LETIMERn\_REP1 will be decremented 10 times. The timer counts a total of 10 times, and LETIMERn\_REPO is 0 after the first three timer underflows and stays at 0. LETIMERn\_REPO and LETIMERn\_REP1 can be written at any time. After a write to either of these, the timer is guaranteed to underflow at least the written number of times if the timer is running. Use the Double repeat mode to generate output on both the LETIMER outputs at the same time. The state machine for this repeat mode can be seen in [Figure 22.5 LETIMER Double Repeat State Machine on page 788](#).



**Figure 22.5. LETIMER Double Repeat State Machine**

### 22.3.3.7 Clock Source

The LETIMER clock source and its prescaler value are defined in the Clock Management Unit (CMU). The LFACKL<sub>LETIMERn</sub> has a frequency given by [Figure 22.6 LETIMER Clock Frequency on page 788](#).

$$f_{LFACKL\_LETIMERn} = 32768/2^{LETIMERn}$$

**Figure 22.6. LETIMER Clock Frequency**


where the exponent LETIMERn is a 4 bit value in the CMU\_LFAPRESC0 register.

To use this module, the LE interface clock must be enabled in CMU\_HFBUSCLKEN0, in addition to the module clock.

### 22.3.3.8 PRS Input Triggers

The LETIMER can be configured to start, stop, and/or clear based on PRS inputs. The diagram showing the functions of the PRS input triggers is shown in [Figure 22.7 LETIMER PRS Input Triggers on page 789](#).

There are 12 PRS inputs to the LETIMER. PRSSTARTSEL, PRSSTOPSEL, and PRSCLEARSEL select which PRS inputs are used to start, stop, and/or clear the LETIMER. PRSSTARTMODE, PRSSTOPMODE, and PRSCLEARMODE select which edge or edge(s) can trigger the start, stop, and/or clear action. The PRSSTARTEN, PRSSTOPEN, and PRSCLEAREN signals shown in the diagram are derived from the PRSSTARTMODE, PRSSTOPMODE, and PRSCLEARMODE fields; if the corresponding bit field is set to NONE, the feature is disabled.



**Figure 22.7. LETIMER PRS Input Triggers**

### 22.3.3.9 Debug

If `DEBUGRUN` in `LETIMERn_CTRL` is cleared, the LETIMER automatically stops counting when the CPU is halted during a debug session, and resumes operation when the CPU continues. Because of synchronization, the LETIMER is halted two clock cycles after the CPU is halted, and continues running two clock cycles after the CPU continues. `RUNNING` in `LETIMERn_STATUS` is not cleared when the LETIMER stops because of a debug-session.

Set `DEBUGRUN` in `LETIMERn_CTRL` to allow the LETIMER to continue counting even when the CPU is halted in debug mode.

#### 22.3.4 Underflow Output Action

For each of the repeat registers, an underflow output action can be set. The configured output action is performed every time the counter underflows while the respective repeat register is nonzero. In PWM mode, the output is similarly only changed on COMP1 match if the repeat register is nonzero. As an example, the timer will perform 7 output actions if LETIMERn REP0 is set to 7 when starting the timer in one-shot mode and leaving it untouched.

The output actions can be set by configuring UFOA0 and UFOA1 in LETIMERn\_CTRL. UFOA0 defines the action on output 0, and is connected to LETIMERn REP0, while UFOA1 defines the action on output 1 and is connected to LETIMERn REP1. The possible actions are defined in [Table 22.2 LETIMER Underflow Output Actions on page 790](#).

**Table 22.2. LETIMER Underflow Output Actions**

UF0A0/UF0A1	Mode	Description
0b00	Idle	The output is held at its idle value
0b01	Toggle	The output is toggled on LETIMERn_CNT underflow if LETIMERn REPx is nonzero
0b10	Pulse	The output is held active for one clock cycle on LETIMERn_CNT underflow if LETIMERn REPx is nonzero. It then returns to its idle value
0b11	PWM	The output is set idle on LETIMERn_CNT underflow and active on compare match with LETIMERn COMP1 if LETIMERn REPx is nonzero.

**Note:**

- For the Pulse and PWM modes, the outputs will return to their idle states regardless of the state of the corresponding LETIMERn REPx registers. They will only be set active if the LETIMERn REPx registers are nonzero however.
- For free-running mode, LETIMERn REP0 != 0 for output generation to be enabled.

The polarity of the outputs can be set individually by configuring OPOL0 and OPOL1 in LETIMERn\_CTRL. When these are cleared, their respective outputs have a low idle value and a high active value. When they are set, the idle value is high, and the active value is low.

When using the toggle action, the outputs can be driven to their idle values by setting their respective CTO0/CTO1 command bits in LETIMERn\_CTRL. This can be used to put the output in a well-defined state before beginning to generate toggle output, which may be important in some applications. The command bit can also be used while the timer is running.

Some simple waveforms generated with the different output modes are shown in [Figure 22.8 LETIMER Simple Waveforms Output on page 791](#). For the example, REP MODE in LETIMERn\_CTRL has been cleared, COMP0TOP also in LETIMERn\_CTRL has been set and LETIMERn COMP0 has been written to 3. As seen in the figure, LETIMERn COMP0 now decides the length of the signal periods. For the toggle mode, the period of the output signal is  $2(\text{LETIMERn COMP0} + 1)$ , and for the pulse modes, the periods of the output signals are  $\text{LETIMERn COMP0} + 1$ . Note that the pulse outputs are delayed by one period relative to the toggle output. The pulses come at the end of their periods.




Figure 22.8. LETIMER Simple Waveforms Output

For the example in [Figure 22.9 LETIMER Repeated Counting on page 791](#), the One-shot repeat mode has been selected, and LETIMERn\_REPO has been written to 3. The resulting behavior is pretty similar to that shown in Figure 6, but in this case, the timer stops after counting to zero LETIMERn\_REPO times. By using LETIMERn\_REPO the user has full control of the number of pulses/toggles generated on the output.




Figure 22.9. LETIMER Repeated Counting

Using the Double repeat mode, output can be generated on both the LETIMER outputs. [Figure 22.10 LETIMER Dual Output on page 792](#) shows an example of this. UFOA0 and UFOA1 in LETIMERn\_CTRL are configured for pulse output and the outputs are configured for low idle polarity. As seen in the figure, the number written to the repeat registers determine the number of pulses generated on each of the outputs.




Figure 22.10. LETIMER Dual Output

### 22.3.5 PRS Output

The LETIMER outputs can be routed out onto the PRS system. Enabling the PRS connection can be done by setting SOURCESEL to LETIMERx and SIGSEL to LETIMERxChn in PRS\_CHx\_CTRL. The PRS register description can be found in [14.5 Register Description](#)

### 22.3.6 Examples


This section presents a couple of usage examples for the LETIMER.

### **22.3.6.1 Triggered Output Generation**

If both LETIMERn\_CNT and LETIMERn\_REPO are 0 in buffered mode, and COMP0TOP and BUFTOP in LETIMERn\_CTRL are set, the values of LETIMERn\_COMP1 and LETIMERn\_REPO1 are loaded into LETIMERn\_CNT and LETIMERn\_REPO respectively when the timer is started. If no additional writes to LETIMERn\_REPO1 are done before the timer stops, LETIMERn\_REPO1 determines the number of pulses/toggles generated on the output, and LETIMERn\_COMP1 determines the period lengths.

As the RTC can be used via PRS to start the LETIMER, the RTC and LETIMER can thus be combined to generate specific pulse-trains at given intervals. Software can update LETIMERn\_COMP1 and LETIMERn REP1 to change the number of pulses and pulse-period in each train, but if changes are not required, software does not have to update the registers between each pulse train.

For the example in [Figure 22.11 LETIMER Triggered Operation](#), the initial values cause the LETIMER to generate two pulses with 3 cycle periods, or a single pulse 3 cycles wide every time the LETIMER is started. After the output has been generated, the LETIMER stops, and is ready to be triggered again.




**Figure 22.11.** LETIMER Triggered Operation

### 22.3.6.2 Continuous Output Generation

In some scenarios, it might be desired to make LETIMER generate a continuous waveform. Very simple constant waveforms can be generated without the repeat counter as shown in [Figure 22.8 LETIMER Simple Waveforms Output on page 791](#), but to generate changing waveforms, using the repeat counter and buffer registers can prove advantageous.

For the example in [Figure 22.12 LETIMER Continuous Operation on page 794](#), the goal is to produce a pulse train consisting of 3 sequences with the following properties:

- 3 pulses with periods of 3 cycles
- 4 pulses with periods of 2 cycles
- 2 pulses with periods of 3 cycles



**Figure 22.12. LETIMER Continuous Operation**

The first two sequences are loaded into the LETIMER before the timer is started.

LETIMERn\_COMP0 is set to 2 (cycles – 1), and LETIMERn\_REP0 is set to 3 for the first sequence, and the second sequence is loaded into the buffer registers, i.e. COMP1 is set to 1 and LETIMERn\_REP1 is set to 4.


The LETIMER is set to trigger an interrupt when LETIMERn\_REP0 is done by setting REP0 in LETIMERn\_IEN. This interrupt is a good place to update the values of the buffers. Last but not least REP MODE in LETIMERn\_CTRL is set to buffered mode, and the timer is started.

In the interrupt routine the buffers are updated with the values for the third sequence. If this had not been done, the timer would have stopped after the second sequence.

The final result is shown in [Figure 22.12 LETIMER Continuous Operation on page 794](#). The pulse output is grouped to show which sequence generated which output. Toggle output is also shown in the figure. Note that the toggle output is not aligned with the pulse outputs.

**Note:** Multiple LETIMER cycles are required to write a value to the LETIMER registers. The example in [Figure 22.12 LETIMER Continuous Operation](#) on page 794 assumes that writes are done in advance so they arrive in the LETIMER as described in the figure.

Figure 22.13 LETIMER LETIMERn\_CNT Not Initialized to 0 on page 795 shows an example where the LETIMER is started while LETIMERn\_CNT is nonzero. In this case the length of the first repetition is given by the value in LETIMERn\_CNT.



**Figure 22.13.** LETIMER LETIMERn\_CNT Not Initialized to 0

### 22.3.6.3 PWM Output

There are several ways of generating PWM output with the LETIMER, but the most straight-forward way is using the PWM output mode. This mode is enabled by setting UFOA0 or UFOA1 in LETIMERn\_CTRL to 3. In PWM mode, the output is set idle on timer underflow, and active on LETIMERn\_COMP1 match, so if for instance COMP0TOP = 1 and OPOL0 = 0 in LETIMERn\_CTRL, LETIMERn COMP0 determines the PWM period, and LETIMERn COMP1 determines the active period.

The PWM period in PWM mode is LETIMERn\_COMP0 + 1. There is no special handling of the case where LETIMERn\_COMP1 > LETIMERn\_COMP0, so if LETIMERn\_COMP1 > LETIMERn\_COMP0, the PWM output is given by the idle output value. This means that for OPOLx = 0 in LETIMERn\_CTRL, the PWM output will always be 0 for at least one clock cycle, and for OPOLx = 1 LETIMERn\_CTRL, the PWM output will always be 1 for at least one clock cycle.

To generate a PWM signal using the full PWM range, invert OPOLx when LETIMERn\_COMP1 is set to a value larger than LETIMERn\_COMP0.

#### 22.3.6.4 Interrupts

The interrupts generated by the LETIMER are combined into one interrupt vector. If the interrupt for the LETIMER is enabled, an interrupt will be made if one or more of the interrupt flags in LETIMERn\_IF and their corresponding bits in LETIMER\_IEN are set.

### 22.3.7 Register Access

This module is a Low Energy Peripheral, and supports immediate synchronization. For description regarding immediate synchronization, the reader is referred to [4.3.1 Writing](#).

## 22.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	LETIMERn_CTRL	RW	Control Register
0x004	LETIMERn_CMD	W1	Command Register
0x008	LETIMERn_STATUS	R	Status Register
0x00C	LETIMERn_CNT	RWH	Counter Value Register
0x010	LETIMERn_COMP0	RWH	Compare Value Register 0
0x014	LETIMERn_COMP1	RW	Compare Value Register 1
0x018	LETIMERn_REPEAT0	RWH	Repeat Counter Register 0
0x01C	LETIMERn_REPEAT1	RWH	Repeat Counter Register 1
0x020	LETIMERn_IF	R	Interrupt Flag Register
0x024	LETIMERn_IFS	W1	Interrupt Flag Set Register
0x028	LETIMERn_IFC	(R)W1	Interrupt Flag Clear Register
0x02C	LETIMERn_IEN	RW	Interrupt Enable Register
0x034	LETIMERn_SYNCBUSY	R	Synchronization Busy Register
0x040	LETIMERn_ROUTEOPEN	RW	I/O Routing Pin Enable Register
0x044	LETIMERn_ROUTELOC0	RW	I/O Routing Location Register
0x050	LETIMERn_PRSSEL	RW	PRS Input Select Register

## 22.5 Register Description

### 22.5.1 LETIMERn\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description						
31:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>						
12	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>						
				Set to keep the LETIMER running in debug mode.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LETIMER is frozen in debug mode</td></tr> <tr> <td>1</td><td>LETIMER is running in debug mode</td></tr> </tbody> </table>	Value	Description	0	LETIMER is frozen in debug mode	1	LETIMER is running in debug mode
Value	Description									
0	LETIMER is frozen in debug mode									
1	LETIMER is running in debug mode									
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>						
9	COMP0TOP	0	RW	<b>Compare Value 0 is Top Value</b>						
				When set, the counter is cleared in the clock cycle after a compare match with compare channel 0.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>The top value of the LETIMER is 65535 (0xFFFF)</td></tr> <tr> <td>1</td><td>The top value of the LETIMER is given by COMP0</td></tr> </tbody> </table>	Value	Description	0	The top value of the LETIMER is 65535 (0xFFFF)	1	The top value of the LETIMER is given by COMP0
Value	Description									
0	The top value of the LETIMER is 65535 (0xFFFF)									
1	The top value of the LETIMER is given by COMP0									
8	BUFTOP	0	RW	<b>Buffered Top</b>						
				Set to load COMP1 into COMP0 when REP0 reaches 0, allowing a buffered top value.						
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>COMP0 is only written by software</td></tr> <tr> <td>1</td><td>COMP0 is set to COMP1 when REP0 reaches 0</td></tr> </tbody> </table>	Value	Description	0	COMP0 is only written by software	1	COMP0 is set to COMP1 when REP0 reaches 0
Value	Description									
0	COMP0 is only written by software									
1	COMP0 is set to COMP1 when REP0 reaches 0									
7	OPOL1	0	RW	<b>Output 1 Polarity</b>						
				Defines the idle value of output 1.						
6	OPOL0	0	RW	<b>Output 0 Polarity</b>						
				Defines the idle value of output 0.						

Bit	Name	Reset	Access	Description
5:4	UFOA1	0x0	RW	<b>Underflow Output Action 1</b>
Defines the action on LETn_O1 on a LETIMER underflow.				
	Value	Mode		Description
	0	NONE		LETn_O1 is held at its idle value as defined by OPOL1
	1	TOGGLE		LETn_O1 is toggled on CNT underflow
	2	PULSE		LETn_O1 is held active for one LFACLK <sub>LETIMER0</sub> clock cycle on CNT underflow. The output then returns to its idle value as defined by OPOL1
	3	PWM		LETn_O1 is set idle on CNT underflow, and active on compare match with COMP1
3:2	UFOA0	0x0	RW	<b>Underflow Output Action 0</b>
Defines the action on LETn_O0 on a LETIMER underflow.				
	Value	Mode		Description
	0	NONE		LETn_O0 is held at its idle value as defined by OPOL0
	1	TOGGLE		LETn_O0 is toggled on CNT underflow
	2	PULSE		LETn_O0 is held active for one LFACLK <sub>LETIMER0</sub> clock cycle on CNT underflow. The output then returns to its idle value as defined by OPOL0
	3	PWM		LETn_O0 is set idle on CNT underflow, and active on compare match with COMP1
1:0	REPMODE	0x0	RW	<b>Repeat Mode</b>
Allows the repeat counter to be enabled and disabled.				
	Value	Mode		Description
	0	FREE		When started, the LETIMER counts down until it is stopped by software
	1	ONESHOT		The counter counts REP0 times. When REP0 reaches zero, the counter stops
	2	BUFFERED		The counter counts REP0 times. If REP1 has been written, it is loaded into REP0 when REP0 reaches zero, otherwise the counter stops
	3	DOUBLE		Both REP0 and REP1 are decremented when the LETIMER wraps around. The LETIMER counts until both REP0 and REP1 are zero

**22.5.2 LETIMERn\_CMD - Command Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	CTO1	0	W1	<b>Clear Toggle Output 1</b>
				Set to drive toggle output 1 to its idle value
3	CTO0	0	W1	<b>Clear Toggle Output 0</b>
				Set to drive toggle output 0 to its idle value
2	CLEAR	0	W1	<b>Clear LETIMER</b>
				Set to clear LETIMER
1	STOP	0	W1	<b>Stop LETIMER</b>
				Set to stop LETIMER
0	START	0	W1	<b>Start LETIMER</b>
				Set to start LETIMER

**22.5.3 LETIMERn\_STATUS - Status Register**

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	RUNNING	0	R	<b>LETIMER Running</b>
				Set when LETIMER is running.

## 22.5.4 LETIMERn\_CNT - Counter Value Register

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RWH															
Name																	CNT															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	CNT	0x0000	RWH	<b>Counter Value</b>  Use to read the current value of the LETIMER.

## 22.5.5 LETIMERn\_COMP0 - Compare Value Register 0 (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RWH															
Name																	COMP0															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	COMP0	0x0000	RWH	<b>Compare Value 0</b>  Compare and optionally top value for LETIMER.

**22.5.6 LETIMERn\_COMP1 - Compare Value Register 1 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																																			
Access																																			
Name																																			COMP1

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	COMP1	0x0000	RW	<b>Compare Value 1</b>  Compare and optionally buffered top value for LETIMER.

**22.5.7 LETIMERn REP0 - Repeat Counter Register 0 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																																	0x00		
Access																																		RWH	
Name																																			REP0

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	REP0	0x00	RWH	<b>Repeat Counter 0</b>  Optional repeat counter.

**22.5.8 LETIMERn\_REPEAT1 - Repeat Counter Register 1 (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00																															
Access	RWH																															
Name	REP1																															

Bit	Name	Reset	Access	Description
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
7:0	REP1	0x00	RWH	<b>Repeat Counter 1</b>  Optional repeat counter or buffer for REP0.

**22.5.9 LETIMERn\_IF - Interrupt Flag Register**

Offset	Bit Position																												
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5		
Reset	0x00																												
Access	RWH																												
Name	REP1 REP0 UF COMP1 COMP0																												

Bit	Name	Reset	Access	Description
31:5	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
4	REP1	0	R	<b>Repeat Counter 1 Interrupt Flag</b>  Set when repeat counter 1 reaches zero.
3	REP0	0	R	<b>Repeat Counter 0 Interrupt Flag</b>  Set when repeat counter 0 reaches zero or when the REP1 interrupt flag is loaded into the REP0 interrupt flag.
2	UF	0	R	<b>Underflow Interrupt Flag</b>  Set on LETIMER underflow.
1	COMP1	0	R	<b>Compare Match 1 Interrupt Flag</b>  Set when LETIMER reaches the value of COMP1.
0	COMP0	0	R	<b>Compare Match 0 Interrupt Flag</b>  Set when LETIMER reaches the value of COMP0.

## 22.5.10 LETIMERn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																																					
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Reset																															W1	0	4	3	2	1	0	
Access																															W1	0	4	3	2	1	0	
Name																															REP1	W1	0	4	3	2	1	0

Bit	Name	Reset	Access	Description
31:5	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	REP1	0	W1	<b>Set REP1 Interrupt Flag</b>
	Write 1 to set the REP1 interrupt flag			
3	REP0	0	W1	<b>Set REP0 Interrupt Flag</b>
	Write 1 to set the REP0 interrupt flag			
2	UF	0	W1	<b>Set UF Interrupt Flag</b>
	Write 1 to set the UF interrupt flag			
1	COMP1	0	W1	<b>Set COMP1 Interrupt Flag</b>
	Write 1 to set the COMP1 interrupt flag			
0	COMP0	0	W1	<b>Set COMP0 Interrupt Flag</b>
	Write 1 to set the COMP0 interrupt flag			

## 22.5.11 LETIMERn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										(R)W1	0	0	0	0		
Access																										(R)W1	0	0	0	0		
Name																										REP1	(R)W1	0	0	0		

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	REP1	0	(R)W1	<b>Clear REP1 Interrupt Flag</b>
				Write 1 to clear the REP1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	REP0	0	(R)W1	<b>Clear REP0 Interrupt Flag</b>
				Write 1 to clear the REP0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	UF	0	(R)W1	<b>Clear UF Interrupt Flag</b>
				Write 1 to clear the UF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	COMP1	0	(R)W1	<b>Clear COMP1 Interrupt Flag</b>
				Write 1 to clear the COMP1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	COMP0	0	(R)W1	<b>Clear COMP0 Interrupt Flag</b>
				Write 1 to clear the COMP0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 22.5.12 LETIMERn\_IEN - Interrupt Enable Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																										RW	0	0	0	0		
<b>Access</b>																										RW	0	0	0	0		
<b>Name</b>																										REP1	RW	0	1	0		
																										REP0	RW	0	3	0		
																										UF	RW	0	2	0		
																										COMP1	RW	0	1	0		
																										COMP0	RW	0	0	0		

Bit	Name	Reset	Access	Description
31:5	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	REP1	0	RW	<b>REP1 Interrupt Enable</b>
	Enable/disable the REP1 interrupt			
3	REP0	0	RW	<b>REP0 Interrupt Enable</b>
	Enable/disable the REP0 interrupt			
2	UF	0	RW	<b>UF Interrupt Enable</b>
	Enable/disable the UF interrupt			
1	COMP1	0	RW	<b>COMP1 Interrupt Enable</b>
	Enable/disable the COMP1 interrupt			
0	COMP0	0	RW	<b>COMP0 Interrupt Enable</b>
	Enable/disable the COMP0 interrupt			

## 22.5.13 LETIMERn\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																										R	0					
<b>Access</b>																										CMD	R					
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:2	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	CMD	0	R	<b>CMD Register Busy</b>
	Set when the value written to CMD is being synchronized.			
0	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 22.5.14 LETIMERn\_ROUTEOPEN - I/O Routing Pin Enable Register

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0	0		
Access																													RW	0		
Name																													OUT1PEN	RW	0	
																													OUT0OPEN	RW	0	

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	OUT1PEN	0	RW	<b>Output 1 Pin Enable</b>
	When set, output 1 of the LETIMER is enabled.			
	Value			Description
	0			The LETn_O1 pin is disabled
	1			The LETn_O1 pin is enabled
0	OUT0OPEN	0	RW	<b>Output 0 Pin Enable</b>
	When set, output 0 of the LETIMER is enabled.			
	Value			Description
	0			The LETn_O0 pin is disabled
	1			The LETn_O0 pin is enabled

## 22.5.15 LETIMERn\_ROUTELOC0 - I/O Routing Location Register

Offset	Bit Position																															
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00								0x00							
Access																	RW								RW							
Name																	OUT1LOC								OUT0LOC							

Bit	Name	Reset	Access	Description																								
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																								
13:8	OUT1LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the LETIMER OUT1 pin.																								
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																								
5:0	OUT0LOC	0x00	RW	<b>I/O Location</b>  Decides the location of the LETIMER OUT0 pin.																								
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>LOC0</td><td>Location 0</td></tr> <tr><td>1</td><td>LOC1</td><td>Location 1</td></tr> <tr><td>2</td><td>LOC2</td><td>Location 2</td></tr> <tr><td>3</td><td>LOC3</td><td>Location 3</td></tr> <tr><td>4</td><td>LOC4</td><td>Location 4</td></tr> <tr><td>5</td><td>LOC5</td><td>Location 5</td></tr> <tr><td>6</td><td>LOC6</td><td>Location 6</td></tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6
Value	Mode	Description																										
0	LOC0	Location 0																										
1	LOC1	Location 1																										
2	LOC2	Location 2																										
3	LOC3	Location 3																										
4	LOC4	Location 4																										
5	LOC5	Location 5																										
6	LOC6	Location 6																										

## 22.5.16 LETIMERn\_PRSSEL - PRS Input Select Register



Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																												RW				
Access																												RW				
Name	PRSCLEARMODE	RW	0x0	PRSSTOPMODE	RW	0x0	PRSTARTMODE	RW	PRSCLEARSEL	RW	PRSSTOPSEL	RW	PRSSTOPSEL	RW	PRSTARTSEL	RW																

Bit	Name	Reset	Access	Description
31:28	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
27:26	PRSCLEARMODE	0x0	RW	<b>PRS Clear Mode</b>
	Determines mode for PRS input clear.			
	Value	Mode	Description	
	0	NONE	PRS cannot clear the LETIMER	
	1	RISING	Rising edge of selected PRS input can clear the LETIMER	
	2	FALLING	Falling edge of selected PRS input can clear the LETIMER	
	3	BOTH	Both the rising or falling edge of the selected PRS input can clear the LETIMER	
25:24	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
23:22	PRSSTOPMODE	0x0	RW	<b>PRS Stop Mode</b>
	Determines mode for PRS input stop.			
	Value	Mode	Description	
	0	NONE	PRS cannot stop the LETIMER	
	1	RISING	Rising edge of selected PRS input can stop the LETIMER	
	2	FALLING	Falling edge of selected PRS input can stop the LETIMER	
	3	BOTH	Both the rising or falling edge of the selected PRS input can stop the LETIMER	
21:20	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
19:18	PRSTARTMODE	0x0	RW	<b>PRS Start Mode</b>
	Determines mode for PRS input start.			
	Value	Mode	Description	
	0	NONE	PRS cannot start the LETIMER	
	1	RISING	Rising edge of selected PRS input can start the LETIMER	

Bit	Name	Reset	Access	Description																											
2		FALLING		Falling edge of selected PRS input can start the LETIMER																											
3		BOTH		Both the rising or falling edge of the selected PRS input can start the LETIMER																											
17:15	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
14:12	PRSCLEARSEL	0x0	RW	<b>PRS Clear Select</b>  Determines which PRS input can clear the LETIMER.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS Channel 3 selected as input</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS Channel 4 selected as input</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS Channel 5 selected as input</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS Channel 6 selected as input</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS Channel 7 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input	3	PRSCH3	PRS Channel 3 selected as input	4	PRSCH4	PRS Channel 4 selected as input	5	PRSCH5	PRS Channel 5 selected as input	6	PRSCH6	PRS Channel 6 selected as input	7	PRSCH7	PRS Channel 7 selected as input
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													
3	PRSCH3	PRS Channel 3 selected as input																													
4	PRSCH4	PRS Channel 4 selected as input																													
5	PRSCH5	PRS Channel 5 selected as input																													
6	PRSCH6	PRS Channel 6 selected as input																													
7	PRSCH7	PRS Channel 7 selected as input																													
11:9	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
8:6	PRSSTOPSEL	0x0	RW	<b>PRS Stop Select</b>  Determines which PRS input can stop the LETIMER.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS Channel 3 selected as input</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS Channel 4 selected as input</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS Channel 5 selected as input</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS Channel 6 selected as input</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS Channel 7 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input	3	PRSCH3	PRS Channel 3 selected as input	4	PRSCH4	PRS Channel 4 selected as input	5	PRSCH5	PRS Channel 5 selected as input	6	PRSCH6	PRS Channel 6 selected as input	7	PRSCH7	PRS Channel 7 selected as input
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													
3	PRSCH3	PRS Channel 3 selected as input																													
4	PRSCH4	PRS Channel 4 selected as input																													
5	PRSCH5	PRS Channel 5 selected as input																													
6	PRSCH6	PRS Channel 6 selected as input																													
7	PRSCH7	PRS Channel 7 selected as input																													
5:3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
2:0	PRSSTARTSEL	0x0	RW	<b>PRS Start Select</b>  Determines which PRS input can start the LETIMER.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input															
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													

Bit	Name	Reset	Access	Description
3	PRSCH3			PRS Channel 3 selected as input
4	PRSCH4			PRS Channel 4 selected as input
5	PRSCH5			PRS Channel 5 selected as input
6	PRSCH6			PRS Channel 6 selected as input
7	PRSCH7			PRS Channel 7 selected as input

## 23. CRYOTIMER - Ultra Low Energy Timer/Counter



### Quick Facts

#### What?

The CRYOTIMER is a timer capable of providing wakeup events/interrupts after deterministic intervals in all energy modes, including EM4.

#### Why?

The CRYOTIMER enables the chip to remain in the lowest energy modes for long durations, while keeping track of time and being able to wake up at regular intervals, all with an absolute minimum current consumption.

#### How?

Using a counter running on a prescaled Low Frequency Oscillator, the CRYOTIMER can provide periodic wakeup events with a very wide period range.

### 23.1 Introduction

The CRYOTIMER is a 32 bit counter which operates on a low frequency oscillator, and is capable of running in all energy modes. It can provide periodic wakeup events and PRS signals which can be used to wake up peripherals from any energy mode. The CRYOTIMER provides a very wide range of periods for the interrupts facilitating flexible ultra-low energy operation.

Because of its simplicity, the CRYOTIMER is a lower energy solution for periodically waking up the MCU compared to the RTCC.


### 23.2 Features

- 32 bit Counter
- Works in all the energy modes
- Only External and Power-On resets reset the CRYOTIMER
- Interrupt/wake up event after deterministic intervals
- PRS Output
- Debug mode
  - Configurable to either run or stop when processor is stopped (break)

### 23.3 Functional Description

### 23.3.1 Block Diagram

An overview of the CRYOTIMER is shown in [Figure 23.1 CRYOTIMER Block Overview on page 812](#).



**Figure 23.1. CRYOTIMER Block Overview**

### 23.3.2 Operation

The desired low frequency oscillator for the CRYOTIMER operation can be selected by using OSCSEL in CRYOTIMER\_CTRL. The selection must be made before enabling the CRYOTIMER, and it must be ensured that the selected oscillator is ready. This can be checked by observing LFXORDY or LFRCORDY (depending upon the oscillator selection) in CMU\_STATUS. Note that the ULFRCO is always ready.

By default the CRYOTIMER is held in reset. It can be started by setting EN in CRYOTIMER\_CTRL. The CRYOTIMER, when running, is reset by clearing EN.

The timer counts at a frequency determined by PRESC in CRYOTIMER\_CTRL. This value should be set before the CRYOTIMER is enabled. Setting PRESC to 0 gives the maximum resolution, while higher values allow longer periods, see [Table 23.1 CRYOTIMER Resolution vs Maximum Wakeup Event/Interrupt Period, F<sub>CRYOCLK</sub> = 32768 Hz on page 813](#).

The 32-bit Counter provides 32 different options for selecting the duration between the Wakeup events. The selected duration is specified by CRYOTIMER\_PERIODSEL. It should be configured before the CRYOTIMER is enabled.

$$T_{WU} = (2^{PRESC} \times 2^{PERIODSEL})/f_{CRYOCLK}$$

**Figure 23.2. Duration Between the CRYOTIMER Wakeup Events in Seconds**

**Table 23.1. CRYOTIMER Resolution vs Maximum Wakeup Event/Interrupt Period, F<sub>CRYOCLK</sub> = 32768 Hz**

CRYOTIMER_CTRL_PRESC	Resolution, 2 <sup>PRESC</sup> /f <sub>CRYOCLK</sub>	Maximum Wakeup event/Interrupt Period
DIV1	30.5 µs	36.4 hours
DIV2	61 µs	72.8 hours
DIV4	122 µs	145.6 hours
DIV8	244 µs	12 days
DIV16	488 µs	24 days
DIV32	977 µs	48 days
DIV64	1.95 ms	97 days
DIV128	3.91 ms	194 days

The 32-bit counter value of the CRYOTIMER can be read using the CRYOTIMER\_CNT register.

The PRS output pulses of the CRYOTIMER are 1 CRYOCLK clock cycle wide. However, if the PRESC and PERIODSEL are both set to 0, the width of these pulses will be half CRYOCLK time period.

The CRYOTIMER wakeup events set the flag in the CRYOTIMER\_IF. Interrupt on this event can be enabled by using the CRYOTIMER\_IEN register.

The CRYOTIMER is always reset by the External Pin and Power-On resets. Additionally, by using EMU\_CTRL, it can also be configured to reset by Watchdog, lockup, and system request resets.

**Note:** The CRYOTIMER configuration bits/registers should only be changed when EN in CRYOTIMER\_CTRL is cleared.

### 23.3.3 Debug Mode

When the CPU is halted in debug mode, the CRYOTIMER can be configured to either continue to run or to be frozen. This is configured using DEBUGRUN in CRYOTIMER\_CTRL.

### 23.3.4 Energy Mode Availability

The CRYOTIMER is available in all energy modes. Wakeup from EM2 DeepSleep and EM3 Stop to EM0 Active can be performed using the regular interrupt as discussed in [23.3.2 Operation](#). To generate wakeup events during EM4 Hibernate/Shutoff, EM4WU in CRYOTIMER\_EM4WUEN must be set to 1. Since the interrupt flag serves as the wakeup source, it must be cleared by software after exiting a low energy mode. Refer to [9. EMU - Energy Management Unit](#) for details on how to configure the EMU.

## 23.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	CRYOTIMER_CTRL	RW	Control Register
0x004	CRYOTIMER_PERIODSEL	RW	Interrupt Duration
0x008	CRYOTIMER_CNT	R	Counter Value
0x00C	CRYOTIMER_EM4WUEN	RW	Wake Up Enable
0x010	CRYOTIMER_IF	R	Interrupt Flag Register
0x014	CRYOTIMER_IFS	W1	Interrupt Flag Set Register
0x018	CRYOTIMER_IFC	(R)W1	Interrupt Flag Clear Register
0x01C	CRYOTIMER_IEN	RW	Interrupt Enable Register

## 23.5 Register Description

### 23.5.1 CRYOTIMER\_CTRL - Control Register

Offset	Bit Position																															
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x0	0x0	0x0	0x0	0x0		
Access																										RW	RW	RW	RW	RW		
Name																										PRESC	OSCSEL	DEBUGRUN	EN	EN		

Bit	Name	Reset	Access	Description
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
7:5	PRESC	0x0	RW	<b>Prescaler Setting</b>
	These bits select the prescaling factor.			
	Value	Mode	Description	
	0	DIV1	LF Oscillator frequency undivided	
	1	DIV2	LF Oscillator frequency divided by 2	
	2	DIV4	LF Oscillator frequency divided by 4	
	3	DIV8	LF Oscillator frequency divided by 8	
	4	DIV16	LF Oscillator frequency divided by 16	
	5	DIV32	LF Oscillator frequency divided by 32	
	6	DIV64	LF Oscillator frequency divided by 64	
	7	DIV128	LF Oscillator frequency divided by 128	
4	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
3:2	OSCSEL	0x0	RW	<b>Select Low Frequency Oscillator</b>
	These bits select the low frequency oscillator for the CRYOTIMER operation. This field should be set after the oscillator to be selected is ready.			
	Value	Mode	Description	
	0	DISABLED	Output is driven low	
	1	LFRCO	Select Low Frequency RC Oscillator	
	2	LFXO	Select Low Frequency Crystal Oscillator	
	3	ULFRCO	Select Ultra Low Frequency RC Oscillator	
1	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>
	Set this bit to enable CRYOTIMER to run in debug mode.			

Bit	Name	Reset	Access	Description
0	EN	0	RW	<b>Enable CRYOTIMER</b> Set this bit to start the CRYOTIMER. Clear this bit to reset the CRYOTIMER. This bit should be set after the oscillator to be selected is ready.

## 23.5.2 CRYOTIMER\_PERIODSEL - Interrupt Duration

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																										0x20						
<b>Access</b>																										RW						
<b>Name</b>																										PERIODSEL						

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
5:0	PERIODSEL	0x20	RW	<b>Interrupts/Wakeup Events Period Setting</b>
	Defines the duration between the Interrupts/Wakeup events based on the pre-scaled clock.			
0	Value			
0	Description			
0	Wakeup event after every Pre-scaled clock cycle.			
1				
1	Wakeup event after 2 Pre-scaled clock cycles.			
2				
2	Wakeup event after 4 Pre-scaled clock cycles.			
3				
3	Wakeup event after 8 Pre-scaled clock cycles.			
4				
4	Wakeup event after 16 Pre-scaled clock cycles.			
5				
5	Wakeup event after 32 Pre-scaled clock cycles.			
6				
6	Wakeup event after 64 Pre-scaled clock cycles.			
7				
7	Wakeup event after 128 Pre-scaled clock cycles.			
8				
8	Wakeup event after 256 Pre-scaled clock cycles.			
9				
9	Wakeup event after 512 Pre-scaled clock cycles.			
10				
10	Wakeup event after 1k Pre-scaled clock cycles.			
11				
11	Wakeup event after 2k Pre-scaled clock cycles.			
12				
12	Wakeup event after 4k Pre-scaled clock cycles.			
13				
13	Wakeup event after 8k Pre-scaled clock cycles.			
14				
14	Wakeup event after 16k Pre-scaled clock cycles.			
15				
15	Wakeup event after 32k Pre-scaled clock cycles.			
16				
16	Wakeup event after 64k Pre-scaled clock cycles.			
17				
17	Wakeup event after 128k Pre-scaled clock cycles.			
18				
18	Wakeup event after 256k Pre-scaled clock cycles.			
19				
19	Wakeup event after 512k Pre-scaled clock cycles.			
20				
20	Wakeup event after 1M Pre-scaled clock cycles.			
21				
21	Wakeup event after 2M Pre-scaled clock cycles.			
22				
22	Wakeup event after 4M Pre-scaled clock cycles.			

Bit	Name	Reset	Access	Description
23				Wakeup event after 8M Pre-scaled clock cycles.
24				Wakeup event after 16M Pre-scaled clock cycles.
25				Wakeup event after 32M Pre-scaled clock cycles.
26				Wakeup event after 64M Pre-scaled clock cycles.
27				Wakeup event after 128M Pre-scaled clock cycles.
28				Wakeup event after 256M Pre-scaled clock cycles.
29				Wakeup event after 512M Pre-scaled clock cycles.
30				Wakeup event after 1024M Pre-scaled clock cycles.
31				Wakeup event after 2048M Pre-scaled clock cycles.
32				Wakeup event after 4096M Pre-scaled clock cycles.

### 23.5.3 CRYOTIMER\_CNT - Counter Value

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	CNT																															

Bit	Name	Reset	Access	Description
31:0	CNT	0x00000000	R	Counter Value
These bits hold the Counter value.				

### 23.5.4 CRYOTIMER\_EM4WUEN - Wake Up Enable

Offset	Bit Position																																
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:1	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
0	EM4WU	0	RW	EM4 Wake-up Enable
Write 1 to enable wake-up request, write 0 to disable wake-up request.				

### 23.5.5 CRYOTIMER\_IF - Interrupt Flag Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PERIOD	0	R	<b>Wakeup Event/Interrupt</b>  Set when the Wakeup event/Interrupt occurs.

### 23.5.6 CRYOTIMER\_IFS - Interrupt Flag Set Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PERIOD	0	W1	<b>Set PERIOD Interrupt Flag</b>  Write 1 to set the PERIOD interrupt flag

### 23.5.7 CRYOTIMER\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																																
Name																																
PERIOD	(R)W1	0																														

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>



0 PERIOD 0 (R)W1 Clear PERIOD Interrupt Flag

Write 1 to clear the PERIOD interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

### 23.5.8 CRYOTIMER\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	PERIOD	0	RW	<b>PERIOD Interrupt Enable</b>  Enable/disable the PERIOD interrupt

## 24. VDAC - Digital to Analog Converter



### Quick Facts

#### What?

The VDAC is designed for low energy consumption, but can also provide very good performance. It can convert digital values to analog signals at up to 500 kilo samples/second with 12-bit accuracy.

#### Why?

The VDAC can be used to generate accurate analog signals for sound, sensors and other applications, using only a limited amount of energy.

#### How?

The VDAC can generate high-resolution analog signals while the MCU is operating at low frequencies and with low total power consumption. Using DMA and a timer, the VDAC can be used to generate waveforms without any CPU intervention. The VDAC is available down to Energy Mode 3.

### 24.1 Introduction

The Voltage Digital to Analog Converter (VDAC) can convert a digital value to an analog output voltage. The VDAC is fully differential rail-to-rail, with 12-bit resolution. It has two single ended output buffers which can be combined into one differential output. The VDAC may be used for a number of different applications such as sensor interfaces or sound output.

## 24.2 Features

- 500 ksamples/s operation
- Two single ended output channels
  - Can be combined into one differential output
- Integrated prescaler with division factor selectable between 1-128
- Selectable voltage reference
  - Internal low noise 2.5 V
  - Internal low noise 1.25 V
  - Internal low power 2.5 V
  - Internal low power 1.25 V
  - AVDD
  - External Pin Reference
- Conversion triggers
  - Data write
  - PRS input
  - Refresh timer
  - LESENSE
- Automatic refresh timer
  - Selection from 16-64 DAC\_CLK cycles
  - Individual refresh enable for each channel
- Interrupt generation on buffer empty or finished conversion
  - Separate interrupt flags for each channel
- PRS output pulse on finished conversion
  - Separate line for each channel
- DMA request on buffer empty
  - Separate request for each channel
- Support for offset and gain calibration
- Output to dedicated pins or APORt bus
- Internal connections to ADC and ACMP
- Sine generation mode
- Asynchronous clocking mode

## 24.3 Functional Description

An overview of the VDAC module is shown in the figure below.




Figure 24.1. VDAC Overview

### 24.3.1 Power Supply

The VDAC module power ( $V_{OPA}$ ) is derived from the AVDD supply pin.

### 24.3.2 I/O Pin Considerations

The maximum usable analog signal that can be seen on external VDAC outputs depends on several factors: whether the signal is routed through the APORTE, whether overvoltage is enabled, and on the IOVDD/AVDD supply voltages, as shown in the [Table 24.1 Maximum Usable IO Voltage on page 823](#) table.

Table 24.1. Maximum Usable IO Voltage

VDAC Pin	Maximum IO Voltage (APORT USED and OVT Enabled/Disabled)	Maximum IO Voltage (APORT UNUSED, OVT Enabled)	Maximum IO Voltage (APORT UNUSED, OVT Disabled)
VDAC External VREF Inputs	N/A	MIN(AVDD, IOVDD)	MIN(AVDD, IOVDD)
VDAC Outputs	MIN(AVDD, IOVDD)	MIN(AVDD, IOVDD + 2 V)	MIN(AVDD, IOVDD)

### 24.3.3 Enabling and Disabling a Channel

A VDAC channel is enabled by writing 1 to the CHxEN and disabled by writing 1 to CHxDIS in VDACn\_CMD. The channel enabled status can be read by polling the CHxENS bit in VDACn\_STATUS. This bit will go high immediately following a write to CHxEN. After disabling a channel the CHxENS bit will stay high until the VDAC channel is completely disabled.

Software should configure the VDAC before enabling a channel. Software *must not* write to any of the following registers while either CH0ENS or CH1ENS are set:

- VDACn\_CTRL
- VDACn\_CHxCtrl
- VDACn\_OPAxTIMER

A VDAC channel will not begin driving its output before it is enabled *and* has received a conversion trigger, see [24.3.4.3 Conversion Trigger](#). After a channel is enabled it will listen for trigger sources specified in TRIGMODE in VDACn\_CHxCCTRL. If TRIGMODE is set to SW, SWPRS or SWREFRESH and a value was written to CHxDATA or COMBDATA before enabling the channel a conversion will start immediately when the channel is enabled. When disabling a channel any pending triggers are flushed.

#### 24.3.4 Conversions

The VDAC consists of two channels (channel 0 and 1) with separate 12-bit data registers (VDACn\_CH0DATA and VDACn\_CH1DATA). These can be used to produce two independent single ended outputs or the channel 0 register can be used to drive both outputs in differential mode. The VDAC supports two conversion modes: continuous and sample/off.

##### 24.3.4.1 Continuous Mode

In continuous mode the VDAC channels will drive their outputs continuously with the data in the VDACn\_CHxDATA registers. A channel is configured in continuous mode by programming the CONVMODE bitfield in VDACn\_CHxCTRL to CONTINUOUS. This mode will maintain the output voltage and no manual refresh is needed.

In continuous mode the SETTLETIME field in VDACn\_OPAXTIMER should be programmed to zero to achieve the maximum update rate.

##### 24.3.4.2 Sample/Off Mode

In sample/off mode the VDAC will only drive the output for a limited time per conversion. A channel is configured in sample/off mode by programming the CONVMODE bitfield in VDACn\_CHxCTRL to SAMPLEOFF. How long the channel should drive the output can be controlled by programming the SETTLETIME field in the VDACn\_OPAXTIMER register. The VDAC will drive the output for SETTLETIME  $f_{DAC\_CLK}$  cycles before tristating the output again (and therefore if SETTLETIME is set to zero, the output will never be driven when using sample/off mode).

##### 24.3.4.3 Conversion Trigger

Conversions can only be done while a channel is enabled, see [24.3.3 Enabling and Disabling a Channel](#).

If TRIGMODE is programmed to SW, SWPRS or SWREFRESH a conversion can be started by writing to the VDACn\_CHxDATA register. The data registers are also mapped to a combined data register, VDACn\_COMBODATA, where the data values for both channels can be written simultaneously. Writing to this register will trigger all enabled channels.

If TRIGMODE is programmed to PRS or SWPRS, a conversion can be started by an incoming pulse on the PRS channel selected in PRSSEL in VDACn\_CHxCTRL. The PRSASYNC bit in VDACn\_CHxCTRL determines if the VDAC expects a PRS pulse coming from a synchronous or asynchronous PRS producer.

If TRIGMODE is programmed to REFRESH or SWREFRESH a conversion will start on an overflow of the internal refresh timer. See [24.3.10 Refresh Timer](#).

If TRIGMODE is programmed to LESENSE a conversion will start when the LESENSE block sends a request. This setting needs to be selected whenever the channel is under LESENSE control.

##### 24.3.4.4 PRS Triggers

PRS triggers can be used to set a constant sample frequency, for instance by using a TIMER. In order to get a jitter-free sample rate, set DACCLKMODE to SYNC, set the CH0PRECSRST bit and clear the PRSASYNC bit. Note that this is only possible for channel 0.

The PRSASYNC bit tells whether the VDAC expects a synchronous PRS producer or not. When this bit is cleared, the PRS pulse must come from a synchronous producer and HFPERCLK must be running (this clock is turned off in EM2 and below). When PRSASYNC is set, the corresponding PRS channels should also be configured as asynchronous (see the PRS chapter).

When either DACCLKMODE is set to ASYNC or the PRSASYNC bit is set, the sample frequency cannot be guaranteed to be jitter-free with respect to the PRS pulses.

The PRS frequency should never be higher than 0.5 MHz (the fastest possible sample rate). In addition the PRS frequency should not be higher than  $f_{HFPERCLK}/12$  (in synchronous mode). If the PRS frequency is set too high, some PRS pulses will be dropped and the output can jitter.

#### 24.3.5 Reference Selection

These voltage references are available and are selected by programming the REFSEL field in VDACn\_CTRL.

- Internal 1.25 V Low Noise Bandgap Reference
- Internal 2.5 V Low Noise Bandgap Reference
- Internal 1.25 V Low Power Bandgap Reference
- Internal 2.5 V Low Power Bandgap Reference
- AVDD

- External Pin

#### 24.3.6 Warmup Time and Initial Conversion

When a channel is first enabled it needs to warm up. This is performed automatically during the first conversion. The time required to warm up depends on the programmed DRIVESTRENGTH field in VDACn\_OPAX\_CTRL. In [Table 24.2 VDAC Warmup Time on page 825](#) the minimum WARMUPTIME field for each drive strength is specified. Software is responsible for programming the correct value to WARMUPTIME before enabling a channel. If the time is programmed too short, an undefined voltage may be output until the VDAC settles.

The CHxWARM bits in VDACn\_STATUS are set when the warmup period has completed.

A consequence of the warmup period is that in continuous mode, the first conversion might take longer than the following conversions. In order to make sure all samples have the same timing, perform a dummy conversion to make the VDAC settle to a known voltage first.

**Table 24.2. VDAC Warmup Time**

DRIVESTRENGTH	WARMUPTIME
0	100 µs
1	85 µs
2	8 µs
3	8 µs

#### 24.3.7 Analog Output

The output selection for each VDAC channel is configured in the VDACn\_OPAX\_OUT registers. Each VDAC channel has its own main output pin, VDACn\_OUTx, that can be enabled with MAINOUTEN. In addition, several alternate outputs can be selected. These are enabled by first setting ALTOUTEN and then setting the corresponding bit(s) in ALTOUTPADEN. The VDAC output can also be routed to APORTE by setting APORROUTEN and configuring the APORROUTSEL field to select the desired APORTE.

The VDAC outputs also have direct internal connections to ADCs and ACMPs. These outputs are always enabled and can be selected by configuring the input selection for the ADC/ACMP.

In sample/off mode the VDAC will only drive the output for the duration programmed in SETTLETIME (in VDACn\_OPAX\_TIMER register) for each incoming conversion trigger. In continuous mode the VDAC will continue to drive the output until the channel is disabled. However, note that also in this mode a conversion trigger is needed before the output is enabled. See [24.3.3 Enabling and Disabling a Channel](#) and [24.3.4.3 Conversion Trigger](#).

#### 24.3.8 Output Mode

The two VDAC channels can act as two separate single ended channels or be combined into one differential channel. This is selected through the DIFF bit in VDACn\_CTRL.

##### 24.3.8.1 Single Ended Output

When operating in single ended mode, the channel 0 output is on VDACn\_OUT0 and the channel 1 output is on VDACn\_OUT1. The output voltage can be calculated using [Figure 24.2 VDAC Single Ended Output Voltage on page 825](#)

$$V_{OUT} = V_{VDACn\_OUTx} - V_{SS} = V_{ref} \times CHxDATA/4095$$

**Figure 24.2. VDAC Single Ended Output Voltage**

where CHxDATA is a 12-bit unsigned integer.

##### 24.3.8.2 Differential Output

When operating in differential mode, both VDAC outputs are used. The differential conversion uses VDACn\_CH0DATA as source. The positive output is on VDACn\_OUT1 and the negative output is on VDACn\_OUT0. Since the output can be negative, it is expected that

the data is written in 2's complement form with the MSB of the 12-bit value being the signed bit. The output voltage can be calculated using [Figure 24.3 VDAC Differential Output Voltage on page 826](#):

$$V_{OUT} = V_{VDACn\_OUT1} - V_{VDACn\_OUT0} = V_{ref} \times CH0DATA/2047$$

**Figure 24.3. VDAC Differential Output Voltage**

where CH0DATA is a 12-bit signed integer. The common mode voltage is  $V_{ref}/2$ .

When using differential mode, the user must make sure that both channels are set up identically. I.e. VDACn\_CH0CTRL and VDACn\_CH1CTRL must be programmed to identical values (with the exception that the PRSSEL bitfield is allowed to be programmed differently for usage together with the OUTENPRS feature). Similarly the user must program VDACn\_OPA0TIMER and VDACn\_OPA1TIMER to identical values.

#### 24.3.9 Async Mode

The VDAC is default clocked from HFPERCCLK, which is automatically turned off in EM2/3. In order to allow VDAC operation in EM2/3 an internal oscillator can be selected for the VDAC by setting the DACCLKMODE bitfield in VDACn\_CTRL to ASYNC. Before entering EM2/3 software must make sure the channel is enabled first by polling CHxENS in VDACn\_STATUS. Entering EM2/3 with an enabled VDAC channel while DACCLKMODE is set to SYNC is a programming error and will lead to EM23ERRIF getting set to 1.

In asynchronous mode both VDAC channels are not necessarily triggered synchronous to each other and therefore the user should not assume that e.g. PRS, refresh or VDACn\_COMBODATA based conversion triggers are observed by both channels at the same time. In differential mode both channels will operate in lock step, even while using the asynchronous clocking mode.

#### 24.3.10 Refresh Timer

The VDAC includes an internal refresh timer. The refresh timer is automatically started if a channel selects either REFRESH or SWREFRESH for TRIGMODE and the channel is enabled. The refresh timer will count the number of  $f_{DAC\_CLK}$  cycles programmed in REFRESHPERIOD before wrapping and generating a conversion trigger.

#### 24.3.11 Clock Prescaling

The VDAC has an internal clock prescaler, which can divide the input clock by any factor between 1 and 128, by setting the PRESC field in VDACn\_CTRL. The resulting DAC\_CLK is used by the converter core and the frequency is given by [Figure 24.4 VDAC Clock Prescaling on page 826](#):

$$f_{DAC\_CLK} = f_{IN\_CLK} / (\text{PRESC} + 1)$$

**Figure 24.4. VDAC Clock Prescaling**

where  $f_{IN\_CLK}$  is the input clock frequency. The  $f_{DAC\_CLK}$  must be programmed to be at most 1 MHz. When the DACCLKMODE is set to SYNC, the input clock frequency is  $f_{HFPERCCLK}$ . When DACCLKMODE is set to ASYNC, an internal 12Mhz oscillator is used. In this mode it is required that the PRESC field be program to 11 or higher.

The prescaler runs continuously when either of the channels are enabled. When running with a prescaler setting higher than 0, there will be an unpredictable delay from the time the conversion was triggered to the time the actual conversion takes place. This is because the conversions are controlled by the prescaled clock and the conversion can arrive at any time during a prescaled clock (DAC\_CLK) period. A second reason for unpredictable delay between a trigger and the associated conversion is that the activity on one channel can impact whether the VDAC reference is warm or not and therefore it can impact whether warmup is required when using the other channel. The uncertainty related to the clock prescaler can be addressed by using CH0PRECSRST. If the CH0PRECSRST bit in VDACn\_CTRL is set, the prescaler will be reset every time a conversion is triggered on channel 0. This leads to a predictable latency between channel 0 trigger and conversion (assuming the warmup sequence is deterministic as well). If channel 0 is used in continuous mode, the warmup sequence will only apply to its first conversion and software can use the CH0WARM status bit to determine if the VDAC has warmed up.

#### 24.3.12 High Speed

The VDAC is able to do conversions up to 400 ksamples/s. In order to reach the maximum conversion rate it is recommended to configure the VDAC in the following way:

1. Make  $f_{DAC\_CLK}$  1 Mhz
2. Set TRIGMODE to SW
3. Program SETTLETIME in OPAx\_TIMER to 0

4. Set up a DMA transfer from a buffer in RAM to CHxDATA
5. Set CONVMODE to CONTINUOUS

#### 24.3.13 Sine Generation Mode


The VDAC contains an automatic sine-generation mode, which is enabled by setting the SINEMODE bit in VDACPn\_CTRL. In this mode, the VDAC data is overridden with a conversion data taken from a sine lookup table. The sine signal is controlled by the PRS line selected by CH0PRSSEL in VDACPn\_CH0CTRL. When the line is high, a sine wave will be produced. Each period, starting at 0 degrees, is made up of 16 samples and the frequency is given by [Figure 24.5 VDAC Sine Generation on page 827](#). In case OUTENPRS equals 1, lowering the PRS line selected by CH0PRSSEL will reset the sine output to 0 degrees resulting in a voltage of Vref/2 on the output channel. In case OUTENPRS equals 0, lowering the PRS line selected by CH0PRSSEL will stop progress of the sine wave at the sample currently being output (and the sine will therefore not be reset to 0 degrees when raising the PRS line again).

$$f_{\text{sine}} = f_{\text{HFPERCCLK}} / 32 \times (\text{PRESC} + 1)$$

**Figure 24.5. VDAC Sine Generation**

Sine mode is supported only for the fastest configuration of the VDAC in continuous mode. Therefore the CONVMODE bitfield needs to be set to CONTINUOUS and the SETTLETIME bitfield in VDACPn\_OPAXTIMER need to be programmed to zero for the used channel(s) in order to use sine generation mode. The TRIGMODE bitfield needs to be programmed to PRS for any channel used for sine generation mode. The other trigger modes are not supported.

The SINE wave will be output on channel 0 and therefore requires that this channel is enabled by writing 1 to CH0EN in the VDACPn\_CMD register. If DIFF is set in VDACPn\_CTRL, the sine wave will be output on both channels, but inverted. Note that when OUTENPRS in VDACPn\_CTRL is set, the sine output will be reset to 0 degrees when the PRS line selected by CH1PRSSEL is low.



**Figure 24.6. VDAC Sine Mode**

#### 24.3.14 Interrupt Flags

The VDAC has several interrupt flags, indicating state transitions and error conditions.

In addition to the VDAC interrupt flags the VDAC registers contain interrupt flags for the OPAMP modules. See The OPAMP chapter for more information on these flags.

##### 24.3.14.1 Conversion Done

The Conversion Done (CHxCD) interrupt flags are set when a conversion is complete. The flags are set after a channel has driven the output with the new code for the time programmed in SETTLETIME in VDACPn\_OPAXTIMER.

##### 24.3.14.2 Buffer Level

The Buffer Level (CHxBL) interrupt flags are set when there is space available in CHxDATA. These flags are initially set, get cleared when CHxDATA is written and set again when the value is used for a conversion.

#### 24.3.14.3 Overflow/Underflow

If CHxDATA is written to while CHxBL is cleared, the channel overflow flag (CHxOF) will be set. If a new conversion is triggered (e.g. via PRS) before data is written to CHxDATA (CHxDATA is empty) the channel underflow flag (CHxUF) will be set.

#### 24.3.14.4 EM2/3 Sleep Error

The VDAC can only operate in EM2/3 when DACCLKMODE is set to ASYNC. If EM2 or EM3 is entered while a channel is enabled and DACCLKMODE is set to SYNC the EM23ERRIF flag will be set.

#### 24.3.15 PRS Outputs

The VDAC has two PRS outputs which will carry a one cycle (HFFPERCCLK) high pulse when the corresponding channel has finished a conversion. Only available when DACCLKMODE is set to SYNC.

#### 24.3.16 DMA Request

Each channel sends a DMA request when there is space in the channel's data register (VDACn\_CHxDATA). These registers are initially empty and also become empty every time a conversion is triggered. The request is cleared when VDACn\_CHxDATA is written.

#### 24.3.17 LESENSE Trigger Mode

The VDAC can be controlled by LESENSE by programming the TRIGMODE field in VDACn\_CHxCTRL to LESENSE. In LESENSE mode the conversion data can come from either VDACn\_CHxDATA registers or LESENSE registers, depending on the LESENSE configuration. The trigger events are also controlled by the LESENSE state machine. See the LESENSE chapter for more information.

#### 24.3.18 Opamps

The VDAC includes a set of highly configurable opamps that can be accessed with the VDAC registers. OPA0 and OPA1 is used for the output stages of the two VDAC channels, but can be used as standalone opamps if the VDAC channels are not in use. Opamps with higher numbers are completely standalone. For a detailed description see the OPAMP chapter.

#### 24.3.19 Calibration

The VDAC contains a calibration register, VDACn\_CAL, where calibration values for both offset and gain correction can be written. The required (gain) calibration values depend on the chosen reference and on whether the main or alternative VDAC output is used. The Device Information page provides the required trim values depending on reference choice and output selection in the DEVINFO\_VDACnMAINCAL, DEVINFO\_VDACnALTCAL, and DEVINFO\_VDACnCH1CAL locations.

The OPAMPs contain a calibration register, VDACn\_OPAx\_CAL, where calibration values for both offset and gain correction can be written. The required calibration settings depend on the chosen DRIVESTRENGTH. The required calibration values can be found in the Device Information pages. For a given OPAMP x, the calibration settings for DRIVESTRENGTH n can be found in DEVINFO\_OPAx\_CALn.

##### 24.3.19.1 Channel 1 Calibration

For channel 1, the factory calibration values are only accurate for the main output. When using the alternative outputs or APORt, the error on the output may be larger than the data sheet values (even when loading values from DEVINFO\_VDACn\_ALTCAL). To get accurate output from channel 1, either use the main output or perform manual calibration.

##### 24.3.19.2 Manual Calibration

To manually calibrate the VDAC:

1. Enable CH0 and CH1 in their desired modes
2. Set both channel outputs to 80% of full-scale by setting VDACn\_CHxDATA = 0xCCC
3. Measure CH0 output and sweep VDACn\_CAL.GAINERRTRIM until the smallest calibration error is found
4. Measure CH1 output and sweep VDACn\_CAL.GAINERRTRIMCH1 until the smallest calibration error is found

The calibration error is given by

$$e = \text{abs}(V_{\text{out}}/(V_{\text{REF}} * 0.8) - 1)$$

**Figure 24.7. Calibration Error**

where  $V_{\text{out}}$  is the measured voltage at the pin and  $V_{\text{REF}}$  is the reference voltage.

Note that even if only CH1 is going to be used, the full calibration procedure should be followed. It is permissible to skip CH1 calibration if only CH0 is used. The following parameters influence the calibration. A change in any of these might require a re-calibration:

- VDACn\_CTRL.REFSEL
- VDACn\_OPAX\_OUT.MAINOUTEN
- VDACn\_OPAX\_OUT.ALTOUTEN
- VDACn\_OPAX\_CTRL.DRIVESTRENGTH

#### 24.3.20 Warmup Mode

If the WARMUPMODE field in VDACn\_CTRL is set to KEEPINSTANDBY, the VDAC keeps internal bias currents running between conversions. It does not reduce the startup time, but it can help reduce noise from the VDAC to other analog peripherals, like the ADC or ACMP.

## 24.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	VDACn_CTRL	RW	Control Register
0x004	VDACn_STATUS	R	Status Register
0x008	VDACn_CH0CTRL	RW	Channel 0 Control Register
0x00C	VDACn_CH1CTRL	RW	Channel 1 Control Register
0x010	VDACn_CMD	W1	Command Register
0x014	VDACn_IF	R	Interrupt Flag Register
0x018	VDACn_IFS	W1	Interrupt Flag Set Register
0x01C	VDACn_IFC	(R)W1	Interrupt Flag Clear Register
0x020	VDACn_IEN	RW	Interrupt Enable Register
0x024	VDACn_CH0DATA	RWH	Channel 0 Data Register
0x028	VDACn_CH1DATA	RWH	Channel 1 Data Register
0x02C	VDACn_COMBDATA	W	Combined Data Register
0x030	VDACn_CAL	RW	Calibration Register
0x0A0	VDACn_OPA0_APORTRQ	R	Operational Amplifier APORTRQ Status Register
0x0A4	VDACn_OPA0_APORTCNF	R	Operational Amplifier APORTCNF Status Register
0x0A8	VDACn_OPA0_CTRL	RW	Operational Amplifier Control Register
0x0AC	VDACn_OPA0_TIMER	RW	Operational Amplifier Timer Control Register
0x0B0	VDACn_OPA0_MUX	RW	Operational Amplifier Mux Configuration Register
0x0B4	VDACn_OPA0_OUT	RW	Operational Amplifier Output Configuration Register
0x0B8	VDACn_OPA0_CAL	RW	Operational Amplifier Calibration Register
...	VDACn_OPAx_APORTRQ	R	Operational Amplifier APORTRQ Status Register
...	VDACn_OPAx_APORTCNF	R	Operational Amplifier APORTCNF Status Register
...	VDACn_OPAx_CTRL	RW	Operational Amplifier Control Register
...	VDACn_OPAx_TIMER	RW	Operational Amplifier Timer Control Register
...	VDACn_OPAx_MUX	RW	Operational Amplifier Mux Configuration Register
...	VDACn_OPAx_OUT	RW	Operational Amplifier Output Configuration Register
...	VDACn_OPAx_CAL	RW	Operational Amplifier Calibration Register
0x100	VDACn_OPA3_APORTRQ	R	Operational Amplifier APORTRQ Status Register
0x104	VDACn_OPA3_APORTCNF	R	Operational Amplifier APORTCNF Status Register
0x108	VDACn_OPA3_CTRL	RW	Operational Amplifier Control Register
0x10C	VDACn_OPA3_TIMER	RW	Operational Amplifier Timer Control Register
0x110	VDACn_OPA3_MUX	RW	Operational Amplifier Mux Configuration Register
0x114	VDACn_OPA3_OUT	RW	Operational Amplifier Output Configuration Register

Offset	Name	Type	Description
0x118	VDACn_OPA3_CAL	RW	Operational Amplifier Calibration Register

## 24.5 Register Description

### 24.5.1 VDACn\_CTRL - Control Register

Offset	Bit Position																																				
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0				
Reset	0			0			0x0			0x0																											
Access	RW			RW			RW			RW			RW			RW		RW																			
Name	DACCLKMODE			WARMUPMODE			REFRESHPERIOD																														

Bit	Name	Reset	Access	Description												
31	DACCLKMODE	0	RW	<b>Clock Mode</b>  Selects DAC clock source from synchronous or asynchronous - with respect to Peripheral Clock - clock source												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>SYNC</td> <td>Uses HPERCCLK to generate DAC_CLK, DAC will run with static settings in EM2 in this mode</td> </tr> <tr> <td>1</td> <td>ASYNC</td> <td>Uses internal VDAC oscillator to generate DAC_CLK. DAC will be available in EM2</td> </tr> </tbody> </table>	Value	Mode	Description	0	SYNC	Uses HPERCCLK to generate DAC_CLK, DAC will run with static settings in EM2 in this mode	1	ASYNC	Uses internal VDAC oscillator to generate DAC_CLK. DAC will be available in EM2			
Value	Mode	Description														
0	SYNC	Uses HPERCCLK to generate DAC_CLK, DAC will run with static settings in EM2 in this mode														
1	ASYNC	Uses internal VDAC oscillator to generate DAC_CLK. DAC will be available in EM2														
30:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
28	WARMUPMODE	0	RW	<b>Warm-up Mode</b>  Select Warm-up Mode for DAC												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>NORMAL</td> <td>DAC is shut off after each sample off conversion</td> </tr> <tr> <td>1</td> <td>KEEPINSTANDBY</td> <td>DAC is kept in standby mode between sample off conversions</td> </tr> </tbody> </table>	Value	Mode	Description	0	NORMAL	DAC is shut off after each sample off conversion	1	KEEPINSTANDBY	DAC is kept in standby mode between sample off conversions			
Value	Mode	Description														
0	NORMAL	DAC is shut off after each sample off conversion														
1	KEEPINSTANDBY	DAC is kept in standby mode between sample off conversions														
27:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
25:24	REFRESHPERIOD	0x0	RW	<b>Refresh Period</b>  Select refresh counter period. A channel x will be refreshed with the period set in REFRESHPERIOD if the channel in VDACn_CHxCTRL has its TRIGMODE set to REFRESH or SWREFRESH.												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>8CYCLES</td> <td>All channels with enabled refresh are refreshed every 8 DAC_CLK cycles</td> </tr> <tr> <td>1</td> <td>16CYCLES</td> <td>All channels with enabled refresh are refreshed every 16 DAC_CLK cycles</td> </tr> <tr> <td>2</td> <td>32CYCLES</td> <td>All channels with enabled refresh are refreshed every 32 DAC_CLK cycles</td> </tr> </tbody> </table>	Value	Mode	Description	0	8CYCLES	All channels with enabled refresh are refreshed every 8 DAC_CLK cycles	1	16CYCLES	All channels with enabled refresh are refreshed every 16 DAC_CLK cycles	2	32CYCLES	All channels with enabled refresh are refreshed every 32 DAC_CLK cycles
Value	Mode	Description														
0	8CYCLES	All channels with enabled refresh are refreshed every 8 DAC_CLK cycles														
1	16CYCLES	All channels with enabled refresh are refreshed every 16 DAC_CLK cycles														
2	32CYCLES	All channels with enabled refresh are refreshed every 32 DAC_CLK cycles														

Bit	Name	Reset	Access	Description
3		64CYCLES		All channels with enabled refresh are refreshed every 64 DAC_CLK cycles
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:16	PRESC	0x00	RW	<b>Prescaler Setting for DAC Clock</b>
				Selected DAC clock source (as selected by DACCLKMODE) is prescaled by PRESC+1 to generated DAC clock (DAC_CLK)
	Value			Description
	PRESC			Clock division factor of PRESC+1.
15:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10:8	REFSEL	0x0	RW	<b>Reference Selection</b>
				Select reference
	Value	Mode		Description
	0	1V25LN		Internal low noise 1.25 V bandgap reference
	1	2V5LN		Internal low noise 2.5 V bandgap reference
	2	1V25		Internal 1.25 V bandgap reference
	3	2V5		Internal 2.5 V bandgap reference
	4	VDD		AVDD reference
	6	EXT		External pin reference
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6	CH0PRECSRST	0	RW	<b>Channel 0 Start Reset Prescaler</b>
				Select if prescaler (determining DAC_CLK rate) is reset on channel 0 start.
	Value			Description
	0			Prescaler not reset on channel 0 start
	1			Prescaler reset on channel 0 start
5	OUTENPRS	0	RW	<b>PRS Controlled Output Enable</b>
				Enable PRS Control of DAC output enable.
	Value			Description
	0			DAC output enable always on
	1			DAC output enable controlled by PRS signal selected for CH1
4	SINEMODE	0	RW	<b>Sine Mode</b>
				Enable/disable sine mode.
	Value			Description

Bit	Name	Reset	Access	Description
	0			Sine mode disabled. Sine reset to 0 degrees
	1			Sine mode enabled
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	DIFF	0	RW	<b>Differential Mode</b>  Select single ended or differential mode.
	Value			Description
	0			Single ended output
	1			Differential output

## 24.5.2 VDACn\_STATUS - Status Register

Offset	Bit Position																									
Reset	0	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6
Access	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	
Name	OPA3OUTVALID	OPA2OUTVALID	OPA1OUTVALID	OPA0OUTVALID	OPA3WARM	OPA2WARM	OPA1WARM	OPA0WARM	OPA3ENS	OPA2ENS	OPA1ENS	OPA0ENS	OPA3APORTCONFLICT	OPA2APORTCONFLICT	OPA1APORTCONFLICT	OPA0APORTCONFLICT	CH1WARM	CH0WARM	CH1BL	CH0BL	CH1ENS	CH0ENS	CH1WARM	CH0WARM	CH1BL	CH0BL
Bit	Name	Reset	Access	Description																						
31	OPA3OUTVALID	0	R	<b>OPA3 Output Valid Status</b>	OPA3 output is settled externally at the load. In PRS triggered mode this status flag is not used (and remains 0).																					
30	OPA2OUTVALID	0	R	<b>OPA2 Output Valid Status</b>	OPA2 output is settled externally at the load. In PRS triggered mode this status flag is not used (and remains 0).																					
29	OPA1OUTVALID	0	R	<b>OPA1 Output Valid Status</b>	OPA1 output is settled externally at the load. In PRS triggered mode this status flag is not used (and remains 0).																					
28	OPA0OUTVALID	0	R	<b>OPA0 Output Valid Status</b>	OPA0 output is settled externally at the load. In PRS triggered mode this status flag is not used (and remains 0).																					
27	OPA3WARM	0	R	<b>OPA3 Warm Status</b>	OPA3 is warm and output is enabled. In PRS triggered mode this status flag is not used (and remains 0).																					
26	OPA2WARM	0	R	<b>OPA2 Warm Status</b>	OPA2 is warm and output is enabled. In PRS triggered mode this status flag is not used (and remains 0).																					
25	OPA1WARM	0	R	<b>OPA1 Warm Status</b>	OPA1 is warm and output is enabled. In PRS triggered mode this status flag is not used (and remains 0).																					
24	OPA0WARM	0	R	<b>OPA0 Warm Status</b>	OPA0 is warm and output is enabled. In PRS triggered mode this status flag is not used (and remains 0).																					
23	OPA3ENS	0	R	<b>OPA3 Enabled Status</b>	This bit is set when OPA3 is enabled																					
22	OPA2ENS	0	R	<b>OPA2 Enabled Status</b>	This bit is set when OPA2 is enabled																					
21	OPA1ENS	0	R	<b>OPA1 Enabled Status</b>	This bit is set when OPA1 is enabled																					
20	OPA0ENS	0	R	<b>OPA0 Enabled Status</b>	This bit is set when OPA0 is enabled																					

Bit	Name	Reset	Access	Description
19	OPA3APORTCON-FLICT	0	R	<b>OPA3 Bus Conflict Output</b>  1 if any of the APORts being requested by the OPA3 are also being requested by another peripheral.
18	OPA2APORTCON-FLICT	0	R	<b>OPA2 Bus Conflict Output</b>  1 if any of the APORts being requested by the OPA2 are also being requested by another peripheral.
17	OPA1APORTCON-FLICT	0	R	<b>OPA1 Bus Conflict Output</b>  1 if any of the APORts being requested by the OPA1 are also being requested by another peripheral.
16	OPA0APORTCON-FLICT	0	R	<b>OPA0 Bus Conflict Output</b>  1 if any of the APORts being requested by the OPA0 are also being requested by another peripheral.
15:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	CH1WARM	0	R	<b>Channel 1 Warm</b>  This bit is set when channel 1 is warm.
4	CH0WARM	0	R	<b>Channel 0 Warm</b>  This bit is set when channel 0 is warm.
3	CH1BL	1	R	<b>Channel 1 Buffer Level</b>  This bit is set when there is space for new data in CH1DATA.
2	CH0BL	1	R	<b>Channel 0 Buffer Level</b>  This bit is set when there is space for new data in CH0DATA.
1	CH1ENS	0	R	<b>Channel 1 Enabled Status</b>  This bit is set when channel 1 is enabled.
0	CH0ENS	0	R	<b>Channel 0 Enabled Status</b>  This bit is set when channel 0 is enabled.

## 24.5.3 VDACn\_CH0CTRL - Channel 0 Control Register

Offset	Bit Position																																
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																	0x0																
Access																	RW																
Name																	PRSSEL																
																	PRSASYNC																
																	TRIGMODE																
																	CONVMODE																

Bit	Name	Reset	Access	Description
31:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
14:12	PRSSEL	0x0	RW	<b>Channel 0 PRS Trigger Select</b>
	Select Channel 0 PRS input channel.			
	Value	Mode	Description	
	0	PRSCH0	PRS ch 0 triggers a conversion.	
	1	PRSCH1	PRS ch 1 triggers a conversion.	
	2	PRSCH2	PRS ch 2 triggers a conversion.	
	3	PRSCH3	PRS ch 3 triggers a conversion.	
	4	PRSCH4	PRS ch 4 triggers a conversion.	
	5	PRSCH5	PRS ch 5 triggers a conversion.	
	6	PRSCH6	PRS ch 6 triggers a conversion.	
	7	PRSCH7	PRS ch 7 triggers a conversion.	
11:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8	PRSASYNC	0	RW	<b>Channel 0 PRS Asynchronous Enable</b>
	Set this bit to 1 to treat PRS channel as asynchronous			
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6:4	TRIGMODE	0x0	RW	<b>Channel 0 Trigger Mode</b>
	Select Channel 0 conversion trigger.			
	Value	Mode	Description	
	0	SW	Channel 0 is triggered by CH0DATA or COMBDDATA write	
	1	PRS	Channel 0 is triggered by PRS input	
	2	REFRESH	Channel 0 is triggered by Refresh timer	
	3	SWPRS	Channel 0 is triggered by CH0DATA/COMBDDATA write or PRS input	
	4	SWREFRESH	Channel 0 is triggered by CH0DATA/COMBDDATA write or Refresh timer	
	5	LESENSE	Channel 0 is triggered by LESENSE	

Bit	Name	Reset	Access	Description									
3:1	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>									
0	CONVMODE	0	RW	<b>Conversion Mode</b>									
Configure conversion mode.													
<table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>CONTINUOUS</td><td>DAC channel 0 is set in continuous mode</td></tr><tr><td>1</td><td>SAMPLEOFF</td><td>DAC channel 0 is set in sample/off mode</td></tr></tbody></table>					Value	Mode	Description	0	CONTINUOUS	DAC channel 0 is set in continuous mode	1	SAMPLEOFF	DAC channel 0 is set in sample/off mode
Value	Mode	Description											
0	CONTINUOUS	DAC channel 0 is set in continuous mode											
1	SAMPLEOFF	DAC channel 0 is set in sample/off mode											

## 24.5.4 VDACn\_CH1CTRL - Channel 1 Control Register

Offset	Bit Position																																
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset																	0x0																
Access																	RW																
Name																	PRSSEL																
																	PRSASYNC																
																	TRIGMODE																
																	CONVMODE																

Bit	Name	Reset	Access	Description
31:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
14:12	PRSSEL	0x0	RW	<b>Channel 1 PRS Trigger Select</b>
	Select Channel 1 PRS input channel.			
	Value	Mode	Description	
	0	PRSCH0	PRS ch 0 triggers a conversion.	
	1	PRSCH1	PRS ch 1 triggers a conversion.	
	2	PRSCH2	PRS ch 2 triggers a conversion.	
	3	PRSCH3	PRS ch 3 triggers a conversion.	
	4	PRSCH4	PRS ch 4 triggers a conversion.	
	5	PRSCH5	PRS ch 5 triggers a conversion.	
	6	PRSCH6	PRS ch 6 triggers a conversion.	
	7	PRSCH7	PRS ch 7 triggers a conversion.	
11:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
8	PRSASYNC	0	RW	<b>Channel 1 PRS Asynchronous Enable</b>
	Set this bit to 1 to treat PRS channel as asynchronous			
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
6:4	TRIGMODE	0x0	RW	<b>Channel 1 Trigger Mode</b>
	Select Channel 1 conversion trigger.			
	Value	Mode	Description	
	0	SW	Channel 1 is triggered by CH1DATA or COMBDDATA write	
	1	PRS	Channel 1 is triggered by PRS input	
	2	REFRESH	Channel 1 is triggered by Refresh timer	
	3	SWPRS	Channel 1 is triggered by CH1DATA/COMBDDATA write or PRS input	
	4	SWREFRESH	Channel 1 is triggered by CH1DATA/COMBDDATA write or Refresh timer	
	5	LESENSE	Channel 1 is triggered by LESENSE	

Bit	Name	Reset	Access	Description									
3:1	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>									
0	CONVMODE	0	RW	<b>Conversion Mode</b>									
Configure conversion mode.													
<table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>CONTINUOUS</td><td>DAC channel 1 is set in continuous mode</td></tr><tr><td>1</td><td>SAMPLEOFF</td><td>DAC channel 1 is set in sample/off mode</td></tr></tbody></table>					Value	Mode	Description	0	CONTINUOUS	DAC channel 1 is set in continuous mode	1	SAMPLEOFF	DAC channel 1 is set in sample/off mode
Value	Mode	Description											
0	CONTINUOUS	DAC channel 1 is set in continuous mode											
1	SAMPLEOFF	DAC channel 1 is set in sample/off mode											

## 24.5.5 VDACn\_CMD - Command Register

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									W1	0	W1	0	W1	0		
Access																									W1	0	W1	0	W1	0		
Name																									W1	0	W1	0	W1	0		

Bit	Name	Reset	Access	Description
31:24	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
23	OPA3DIS	0	W1	<b>OPA3 Disable</b>  Disables OPA3.
22	OPA3EN	0	W1	<b>OPA3 Enable</b>  Enables OPA3
21	OPA2DIS	0	W1	<b>OPA2 Disable</b>  Disables OPA2.
20	OPA2EN	0	W1	<b>OPA2 Enable</b>  Enables OPA2
19	OPA1DIS	0	W1	<b>OPA1 Disable</b>  Disables OPA1.
18	OPA1EN	0	W1	<b>OPA1 Enable</b>  Enables OPA1
17	OPA0DIS	0	W1	<b>OPA0 Disable</b>  Disables OPA0.
16	OPA0EN	0	W1	<b>OPA0 Enable</b>  Enables OPA0
15:4	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
3	CH1DIS	0	W1	<b>DAC Channel 1 Disable</b>  Disables DAC Channel 1
2	CH1EN	0	W1	<b>DAC Channel 1 Enable</b>  Enables DAC Channel 1.
1	CH0DIS	0	W1	<b>DAC Channel 0 Disable</b>  Disables DAC Channel 0.
0	CH0EN	0	W1	<b>DAC Channel 0 Enable</b>  Enables DAC Channel 0

## 24.5.6 VDACn\_IF - Interrupt Flag Register

Offset	Bit Position																	
Reset	31	0	30	0	29	0	28	0	27	0	26	0	25	0	24	0		
Access	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R		
Name	OPA3OUTVALID	OPA2OUTVALID	OPA1OUTVALID	OPA0OUTVALID	OPA3PRSTIMEDERR	OPA2PRSTIMEDERR	OPA1PRSTIMEDERR	OPAOPRSTIMEDERR	OPA3APORTCONFLICT	OPA2APORTCONFLICT	OPA1APORTCONFLICT	OPA0APORTCONFLICT	EM23ERR	CH1BL	CH0BL	CH1UF	CH0UF	
Bit	31	30	29	28	27:24	23	22	21	20	19	18	17	16	15	14	13	12	
Reset	0	0	0	0	Reserved	0	0	0	0	0	0	0	0	0	1	1	6	
Access	R	R	R	R	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>	R	R	R	R	R	R	R	R	R	R	R	R	
Description	<b>OPA3 Output Valid Interrupt Flag</b> OPA3 output is settled externally at the load	<b>OPA3 Output Valid Interrupt Flag</b> OPA2 output is settled externally at the load	<b>OPA1 Output Valid Interrupt Flag</b> OPA1 output is settled externally at the load	<b>OPA0 Output Valid Interrupt Flag</b> OPA0 output is settled externally at the load		<b>OPA3 PRS Trigger Mode Error Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.		<b>OPA2 PRS Trigger Mode Error Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.		<b>OPA1 PRS Trigger Mode Error Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.		<b>OPA0 PRS Trigger Mode Error Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.						
27:24	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																
23	OPA3PRSTIME-DERR	0	R	<b>OPA3 Bus Conflict Output Interrupt Flag</b> 1 if any of the APORts being requested by the OPA3 are also being requested by another peripheral.														
22	OPA2PRSTIME-DERR	0	R	<b>OPA2 Bus Conflict Output Interrupt Flag</b> 1 if any of the APORts being requested by the OPA0 are also being requested by another peripheral.														
21	OPA1PRSTIME-DERR	0	R	<b>OPA1 Bus Conflict Output Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.														
20	OPA0PRSTIME-DERR	0	R	<b>OPA0 Bus Conflict Output Interrupt Flag</b> Indicates that in TIMED PRS triggered mode, the negative edge of the PRS pulse came before the OPA output was valid.														
19	OPA3APORTCONFLICT	0	R	<b>OPA3 Bus Conflict Output Interrupt Flag</b> 1 if any of the APORts being requested by the OPA3 are also being requested by another peripheral.														
18	OPA2APORTCONFLICT	0	R	<b>OPA2 Bus Conflict Output Interrupt Flag</b> 1 if any of the APORts being requested by the OPA0 are also being requested by another peripheral.														

Bit	Name	Reset	Access	Description
17	OPA1APORTCON-FLICT	0	R	<b>OPA1 Bus Conflict Output Interrupt Flag</b>  1 if any of the APORts being requested by the OPA1 are also being requested by another peripheral.
16	OPA0APORTCON-FLICT	0	R	<b>OPA0 Bus Conflict Output Interrupt Flag</b>  1 if any of the APORts being requested by the OPA0 are also being requested by another peripheral.
15	EM23ERR	0	R	<b>EM2/3 Entry Error Flag</b>  Set when going to EM2/3 while DACCLKMODE equals SYNC and a channel is enabled
14:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	CH1BL	1	R	<b>Channel 1 Buffer Level Interrupt Flag</b>  Indicates space available in CH1DATA.
6	CH0BL	1	R	<b>Channel 0 Buffer Level Interrupt Flag</b>  Indicates space available in CH0DATA.
5	CH1UF	0	R	<b>Channel 1 Data Underflow Interrupt Flag</b>  Indicates channel 1 data underflow.
4	CH0UF	0	R	<b>Channel 0 Data Underflow Interrupt Flag</b>  Indicates channel 0 data underflow.
3	CH1OF	0	R	<b>Channel 1 Data Overflow Interrupt Flag</b>  Indicates channel 1 data overflow.
2	CH0OF	0	R	<b>Channel 0 Data Overflow Interrupt Flag</b>  Indicates channel 0 data overflow.
1	CH1CD	0	R	<b>Channel 1 Conversion Done Interrupt Flag</b>  Indicates channel 1 conversion complete.
0	CH0CD	0	R	<b>Channel 0 Conversion Done Interrupt Flag</b>  Indicates channel 0 conversion complete.

## 24.5.7 VDACn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																
Reset	31	0	W1	0	30	W1	0	30	W1	0	29	W1	0	29	W1	0	28
Access																	
Name	OPA3OUTVALID	OPA2OUTVALID	OPA1OUTVALID	OPA0OUTVALID	OPA3PRSTIMEDERR	OPA2PRSTIMEDERR	OPA1PRSTIMEDERR	OPA0PRSTIMEDERR	OPA3APORTCONFLICT	OPA2APORTCONFLICT	OPA1APORTCONFLICT	OPA0APORTCONFLICT	EM23ERR	CH1UF	CH0UF	CH1OF	CH0OF
Bit	31	30	29	28	27:24	23	22	21	20	19	18	17	16	15	14	13	12
Reset	0	0	0	0	Reserved	0	0	0	0	0	0	0	0	0	0	0	0
Access	W1	W1	W1	W1		W1	W1	W1	W1	W1	W1	W1	W1	W1	W1	W1	W1
Description	<b>Set OPA3OUTVALID Interrupt Flag</b> Write 1 to set the OPA3OUTVALID interrupt flag	<b>Set OPA2OUTVALID Interrupt Flag</b> Write 1 to set the OPA2OUTVALID interrupt flag	<b>Set OPA1OUTVALID Interrupt Flag</b> Write 1 to set the OPA1OUTVALID interrupt flag	<b>Set OPA0OUTVALID Interrupt Flag</b> Write 1 to set the OPA0OUTVALID interrupt flag	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>	<b>Set OPA3PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA3PRSTIMEDERR interrupt flag	<b>Set OPA2PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA2PRSTIMEDERR interrupt flag	<b>Set OPA1PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA1PRSTIMEDERR interrupt flag	<b>Set OPA0PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA0PRSTIMEDERR interrupt flag	<b>Set OPA3APORTCONFLICT Interrupt Flag</b> Write 1 to set the OPA3APORTCONFLICT interrupt flag	<b>Set OPA2APORTCONFLICT Interrupt Flag</b> Write 1 to set the OPA2APORTCONFLICT interrupt flag						

Bit	Name	Reset	Access	Description
31	OPA3OUTVALID	0	W1	<b>Set OPA3OUTVALID Interrupt Flag</b> Write 1 to set the OPA3OUTVALID interrupt flag
30	OPA2OUTVALID	0	W1	<b>Set OPA2OUTVALID Interrupt Flag</b> Write 1 to set the OPA2OUTVALID interrupt flag
29	OPA1OUTVALID	0	W1	<b>Set OPA1OUTVALID Interrupt Flag</b> Write 1 to set the OPA1OUTVALID interrupt flag
28	OPA0OUTVALID	0	W1	<b>Set OPA0OUTVALID Interrupt Flag</b> Write 1 to set the OPA0OUTVALID interrupt flag
27:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	OPA3PRSTIME-DERR	0	W1	<b>Set OPA3PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA3PRSTIMEDERR interrupt flag
22	OPA2PRSTIME-DERR	0	W1	<b>Set OPA2PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA2PRSTIMEDERR interrupt flag
21	OPA1PRSTIME-DERR	0	W1	<b>Set OPA1PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA1PRSTIMEDERR interrupt flag
20	OPA0PRSTIME-DERR	0	W1	<b>Set OPA0PRSTIMEDERR Interrupt Flag</b> Write 1 to set the OPA0PRSTIMEDERR interrupt flag
19	OPA3APORTCONFLICT	0	W1	<b>Set OPA3APORTCONFLICT Interrupt Flag</b> Write 1 to set the OPA3APORTCONFLICT interrupt flag
18	OPA2APORTCONFLICT	0	W1	<b>Set OPA2APORTCONFLICT Interrupt Flag</b> Write 1 to set the OPA2APORTCONFLICT interrupt flag

Bit	Name	Reset	Access	Description
17	OPA1APORTCONFLICT	0	W1	<b>Set OPA1APORTCONFLICT Interrupt Flag</b>  Write 1 to set the OPA1APORTCONFLICT interrupt flag
16	OPA0APORTCONFLICT	0	W1	<b>Set OPA0APORTCONFLICT Interrupt Flag</b>  Write 1 to set the OPA0APORTCONFLICT interrupt flag
15	EM23ERR	0	W1	<b>Set EM23ERR Interrupt Flag</b>  Write 1 to set the EM23ERR interrupt flag
14:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	CH1UF	0	W1	<b>Set CH1UF Interrupt Flag</b>  Write 1 to set the CH1UF interrupt flag
4	CH0UF	0	W1	<b>Set CH0UF Interrupt Flag</b>  Write 1 to set the CH0UF interrupt flag
3	CH1OF	0	W1	<b>Set CH1OF Interrupt Flag</b>  Write 1 to set the CH1OF interrupt flag
2	CH0OF	0	W1	<b>Set CH0OF Interrupt Flag</b>  Write 1 to set the CH0OF interrupt flag
1	CH1CD	0	W1	<b>Set CH1CD Interrupt Flag</b>  Write 1 to set the CH1CD interrupt flag
0	CH0CD	0	W1	<b>Set CH0CD Interrupt Flag</b>  Write 1 to set the CH0CD interrupt flag

#### 24.5.8 VDACn IFC - Interrupt Flag Clear Register

Bit	Name	Reset	Access	Description
31	OPA3OUTVALID	0	(R)W1	<b>Clear OPA3OUTVALID Interrupt Flag</b>  Write 1 to clear the OPA3OUTVALID interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
30	OPA2OUTVALID	0	(R)W1	<b>Clear OPA2OUTVALID Interrupt Flag</b>  Write 1 to clear the OPA2OUTVALID interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
29	OPA1OUTVALID	0	(R)W1	<b>Clear OPA1OUTVALID Interrupt Flag</b>  Write 1 to clear the OPA1OUTVALID interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
28	OPA0OUTVALID	0	(R)W1	<b>Clear OPA0OUTVALID Interrupt Flag</b>  Write 1 to clear the OPA0OUTVALID interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
27:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	OPA3PRSTIME-DERR	0	(R)W1	<b>Clear OPA3PRSTIMEDERR Interrupt Flag</b>  Write 1 to clear the OPA3PRSTIMEDERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
22	OPA2PRSTIME-DERR	0	(R)W1	<b>Clear OPA2PRSTIMEDERR Interrupt Flag</b>  Write 1 to clear the OPA2PRSTIMEDERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
21	OPA1PRSTIME-DERR	0	(R)W1	<b>Clear OPA1PRSTIMEDERR Interrupt Flag</b>  Write 1 to clear the OPA1PRSTIMEDERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
20	OPA0PRSTIME-DERR	0	(R)W1	<b>Clear OPA0PRSTIMEDERR Interrupt Flag</b>  Write 1 to clear the OPA0PRSTIMEDERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
19	OPA3APORTCONFLICT	0	(R)W1	<b>Clear OPA3APORTCONFLICT Interrupt Flag</b>  Write 1 to clear the OPA3APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
18	OPA2APORTCONFLICT	0	(R)W1	<b>Clear OPA2APORTCONFLICT Interrupt Flag</b>  Write 1 to clear the OPA2APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
17	OPA1APORTCONFLICT	0	(R)W1	<b>Clear OPA1APORTCONFLICT Interrupt Flag</b>  Write 1 to clear the OPA1APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
16	OPA0APORTCONFLICT	0	(R)W1	<b>Clear OPA0APORTCONFLICT Interrupt Flag</b>  Write 1 to clear the OPA0APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15	EM23ERR	0	(R)W1	<b>Clear EM23ERR Interrupt Flag</b>  Write 1 to clear the EM23ERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
14:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	CH1UF	0	(R)W1	<b>Clear CH1UF Interrupt Flag</b>  Write 1 to clear the CH1UF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	CH0UF	0	(R)W1	<b>Clear CH0UF Interrupt Flag</b>  Write 1 to clear the CH0UF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	CH1OF	0	(R)W1	<b>Clear CH1OF Interrupt Flag</b>  Write 1 to clear the CH1OF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	CH0OF	0	(R)W1	<b>Clear CH0OF Interrupt Flag</b>  Write 1 to clear the CH0OF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	CH1CD	0	(R)W1	<b>Clear CH1CD Interrupt Flag</b>  Write 1 to clear the CH1CD interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	CH0CD	0	(R)W1	<b>Clear CH0CD Interrupt Flag</b>  Write 1 to clear the CH0CD interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 24.5.9 VDACn\_IEN - Interrupt Enable Register

Offset	Bit Position															
0x020	31	0	30	0	29	0	28	0	27	0	26	0	25	0	24	
Reset	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0
Access	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0
Name	OPA3OUTVALID	OPA2OUTVALID	OPA1OUTVALID	OPA0OUTVALID	OPA3PRSTIMEDERR	OPA2PRSTIMEDERR	OPA1PRSTIMEDERR	OPA0PRSTIMEDERR	OPA3APORTCONFLICT	OPA2APORTCONFLICT	OPA1APORTCONFLICT	OPA0APORTCONFLICT	EM23ERR	CH1BL	CH0BL	CH1UF
																CH0UF
																CH1OF
																CH0OF
																CH1CD
																CH0CD

Bit	Name	Reset	Access	Description
31	OPA3OUTVALID	0	RW	<b>OPA3OUTVALID Interrupt Enable</b>  Enable/disable the OPA3OUTVALID interrupt
30	OPA2OUTVALID	0	RW	<b>OPA2OUTVALID Interrupt Enable</b>  Enable/disable the OPA2OUTVALID interrupt
29	OPA1OUTVALID	0	RW	<b>OPA1OUTVALID Interrupt Enable</b>  Enable/disable the OPA1OUTVALID interrupt
28	OPA0OUTVALID	0	RW	<b>OPA0OUTVALID Interrupt Enable</b>  Enable/disable the OPA0OUTVALID interrupt
27:24	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
23	OPA3PRSTIME-DERR	0	RW	<b>OPA3PRSTIMEDERR Interrupt Enable</b>  Enable/disable the OPA3PRSTIMEDERR interrupt
22	OPA2PRSTIME-DERR	0	RW	<b>OPA2PRSTIMEDERR Interrupt Enable</b>  Enable/disable the OPA2PRSTIMEDERR interrupt
21	OPA1PRSTIME-DERR	0	RW	<b>OPA1PRSTIMEDERR Interrupt Enable</b>  Enable/disable the OPA1PRSTIMEDERR interrupt
20	OPA0PRSTIME-DERR	0	RW	<b>OPA0PRSTIMEDERR Interrupt Enable</b>  Enable/disable the OPA0PRSTIMEDERR interrupt
19	OPA3APORTCONFLICT	0	RW	<b>OPA3APORTCONFLICT Interrupt Enable</b>  Enable/disable the OPA3APORTCONFLICT interrupt
18	OPA2APORTCONFLICT	0	RW	<b>OPA2APORTCONFLICT Interrupt Enable</b>  Enable/disable the OPA2APORTCONFLICT interrupt

Bit	Name	Reset	Access	Description
17	OPA1APORTCONFLICT	0	RW	<b>OPA1APORTCONFLICT Interrupt Enable</b>  Enable/disable the OPA1APORTCONFLICT interrupt
16	OPA0APORTCONFLICT	0	RW	<b>OPA0APORTCONFLICT Interrupt Enable</b>  Enable/disable the OPA0APORTCONFLICT interrupt
15	EM23ERR	0	RW	<b>EM23ERR Interrupt Enable</b>  Enable/disable the EM23ERR interrupt
14:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	CH1BL	0	RW	<b>CH1BL Interrupt Enable</b>  Enable/disable the CH1BL interrupt
6	CH0BL	0	RW	<b>CH0BL Interrupt Enable</b>  Enable/disable the CH0BL interrupt
5	CH1UF	0	RW	<b>CH1UF Interrupt Enable</b>  Enable/disable the CH1UF interrupt
4	CH0UF	0	RW	<b>CH0UF Interrupt Enable</b>  Enable/disable the CH0UF interrupt
3	CH1OF	0	RW	<b>CH1OF Interrupt Enable</b>  Enable/disable the CH1OF interrupt
2	CH0OF	0	RW	<b>CH0OF Interrupt Enable</b>  Enable/disable the CH0OF interrupt
1	CH1CD	0	RW	<b>CH1CD Interrupt Enable</b>  Enable/disable the CH1CD interrupt
0	CH0CD	0	RW	<b>CH0CD Interrupt Enable</b>  Enable/disable the CH0CD interrupt

**24.5.10 VDACn\_CH0DATA - Channel 0 Data Register**

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x800						
Access																										RWH						
Name																										DATA						

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:0	DATA	0x800	RWH	<b>Channel 0 Data</b>  This register contains the value which will be converted by DAC channel 0.

**24.5.11 VDACn\_CH1DATA - Channel 1 Data Register**

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0x800						
Access																										RWH						
Name																										DATA						

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:0	DATA	0x800	RWH	<b>Channel 1 Data</b>  This register contains the value which will be converted by DAC channel 1.

## 24.5.12 VDACn\_COMBDATA - Combined Data Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x800														0x800																	
Access	W														W																	
Name	CH1DATA														CH0DATA																	

Bit	Name	Reset	Access	Description
31:28	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
27:16	CH1DATA	0x800	W	<b>Channel 1 Data</b>
	Data written to this register will be written to DATA in VDACn_CH1DATA.			
15:12	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
11:0	CH0DATA	0x800	W	<b>Channel 0 Data</b>
	Data written to this register will be written to DATA in VDACn_CH0DATA.			

## 24.5.13 VDACn\_CAL - Calibration Register

Offset	Bit Position																																	
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset															0x8								0x20								0x4			
Access															RW				RW				RW				RW							
Name															GAINERRTRIMCH1				GAINERRTRIM				OFFSETTRIM				OFFSETTRIM							

Bit	Name	Reset	Access	Description
31:20	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
19:16	GAINERRTRIMCH1	0x8	RW	<b>Gain Error Trim Value for CH1</b>  This register contains the fine gain error trim for CH1. Program with Device Information value found in DEVINFO_VDACnCH1CAL depending on chosen reference.
15:14	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
13:8	GAINERRTRIM	0x20	RW	<b>Gain Error Trim Value</b>  This register contains the fine gain error trim for CH0 and coarse gain error trim for CH1. Program with Device Information value found in DEVINFO_VDACnMAINCAL or DEVINFO_VDACnALTCAL depending on chosen reference and choice of main versus alternative output usage.
7:3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
2:0	OFFSETTRIM	0x4	RW	<b>Input Buffer Offset Calibration Value</b>  This register contains the DAC input buffer offset calibration value. Program with Device Information value found in DDEVINFO_VDACnCH1CAL.

## 24.5.14 VDACn\_OPAX\_APORTRREQ - Operational Amplifier APORTR Request Status Register

Offset	Bit Position																
0x0A0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15
<b>Reset</b>															0	9	8
<b>Access</b>																7	6
<b>Name</b>																5	4
																3	2
																1	0

Bit	Name	Reset	Access	Description
31:10	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	APORT4YREQ	0	R	<b>1 If the Bus Connected to APORTR4Y is Requested</b>  Reports if the bus connected to APORTR4Y is being requested from the APORTR
8	APORT4XREQ	0	R	<b>1 If the Bus Connected to APORTR4X is Requested</b>  Reports if the bus connected to APORTR4X is being requested from the APORTR
7	APORT3YREQ	0	R	<b>1 If the Bus Connected to APORTR3Y is Requested</b>  Reports if the bus connected to APORTR3Y is being requested from the APORTR
6	APORT3XREQ	0	R	<b>1 If the Bus Connected to APORTR3X is Requested</b>  Reports if the bus connected to APORTR3X is being requested from the APORTR
5	APORT2YREQ	0	R	<b>1 If the Bus Connected to APORTR2Y is Requested</b>  Reports if the bus connected to APORTR2Y is being requested from the APORTR
4	APORT2XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
3	APORT1YREQ	0	R	<b>1 If the Bus Connected to APORTR1X is Requested</b>  Reports if the bus connected to APORTR1X is being requested from the APORTR
2	APORT1XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
1:0	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 24.5.15 VDACn\_OPAX\_APORCONFLICT - Operational Amplifier APORConflict Status Register

Offset	Bit Position																															
0x0A4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YCONFLICT	0	R	<b>1 If the Bus Connected to APOR4Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR4Y is also being requested by another peripheral
8	APORT4XCONFLICT	0	R	<b>1 If the Bus Connected to APOR4X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR4X is also being requested by another peripheral
7	APORT3YCONFLICT	0	R	<b>1 If the Bus Connected to APOR3Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR3Y is also being requested by another peripheral
6	APORT3XCONFLICT	0	R	<b>1 If the Bus Connected to APOR3X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR3X is also being requested by another peripheral
5	APORT2YCONFLICT	0	R	<b>1 If the Bus Connected to APOR2Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR2Y is also being requested by another peripheral
4	APORT2XCONFLICT	0	R	<b>1 If the Bus Connected to APOR2X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR2X is also being requested by another peripheral
3	APORT1YCONFLICT	0	R	<b>1 If the Bus Connected to APOR1X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR1X is also being requested by another peripheral
2	APORT1XCONFLICT	0	R	<b>1 If the Bus Connected to APOR1X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR1X is also being requested by another peripheral
1:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 24.5.16 VDACn\_OPAX\_CTRL - Operational Amplifier Control Register

Offset	Bit Position																																
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Access	RW	0	RW	0	RW	0	RW	0	RW		RW	0	RW		RW		RW		RW		RW		RW										
Name																																	

Bit	Name	Reset	Access	Description
31:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21	APORTYMASTER-DIS	0	RW	<b>APORT Bus Master Disable</b>
				Determines if the OPAX will request the APOR Tbus Y with POSSEL, NEGSEL or APORTOUTSEL. This bit allows multiple APOR Tconnected devices to monitor the same APOR Tbus simultaneously by allowing the OPAX to not master the selected bus. When 1, the determination is expected to be from another peripheral, and the OPAX only passively looks at the bus. When 1, the selection of channel for a selected bus is ignored (the bus is not), and is whatever selection the external device mastering the bus has configured for the APOR Tbus.
	Value			Description
	0			Bus mastering enabled
	1			Bus mastering disabled
20	APORTXMASTER-DIS	0	RW	<b>APORT Bus Master Disable</b>
				Determines if the OPAX will request the APOR Tbus X with POSSEL , NEGSEL or APORTOUTSEL. This bit allows multiple APOR Tconnected devices to monitor the same APOR Tbus simultaneously by allowing the OPAX to not master the selected bus. When 1, the determination is expected to be from another peripheral, and the OPAX only passively looks at the bus. When 1, the selection of channel for a selected bus is ignored (the bus is not), and is whatever selection the external device mastering the bus has configured for the APOR Tbus.
	Value			Description
	0			Bus mastering enabled
	1			Bus mastering disabled
19:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	PRSOUTMODE	0	RW	<b>OPAX PRS Output Select</b>
				Selects OPAX Output to PRS.
	Value	Mode		Description
	0	WARM		Warm status available on PRS. Warm status indicates that opamp is warm and output is enabled.

Bit	Name	Reset	Access	Description																											
1	OUTVALID			Outvalid status available on PRS. Outvalid status indicates that opamp output is settled externally at the load.																											
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
12:10	PRSSEL	0x0	RW	<b>OPAx PRS Trigger Select</b>  Select Channel 0 PRS input channel.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PRSCH0</td><td>PRS ch 0 triggers OPA.</td></tr> <tr> <td>1</td><td>PRSCH1</td><td>PRS ch 1 triggers OPA.</td></tr> <tr> <td>2</td><td>PRSCH2</td><td>PRS ch 2 triggers OPA.</td></tr> <tr> <td>3</td><td>PRSCH3</td><td>PRS ch 3 triggers OPA.</td></tr> <tr> <td>4</td><td>PRSCH4</td><td>PRS ch 4 triggers OPA.</td></tr> <tr> <td>5</td><td>PRSCH5</td><td>PRS ch 5 triggers OPA.</td></tr> <tr> <td>6</td><td>PRSCH6</td><td>PRS ch 6 triggers OPA.</td></tr> <tr> <td>7</td><td>PRSCH7</td><td>PRS ch 7 triggers OPA.</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS ch 0 triggers OPA.	1	PRSCH1	PRS ch 1 triggers OPA.	2	PRSCH2	PRS ch 2 triggers OPA.	3	PRSCH3	PRS ch 3 triggers OPA.	4	PRSCH4	PRS ch 4 triggers OPA.	5	PRSCH5	PRS ch 5 triggers OPA.	6	PRSCH6	PRS ch 6 triggers OPA.	7	PRSCH7	PRS ch 7 triggers OPA.
Value	Mode	Description																													
0	PRSCH0	PRS ch 0 triggers OPA.																													
1	PRSCH1	PRS ch 1 triggers OPA.																													
2	PRSCH2	PRS ch 2 triggers OPA.																													
3	PRSCH3	PRS ch 3 triggers OPA.																													
4	PRSCH4	PRS ch 4 triggers OPA.																													
5	PRSCH5	PRS ch 5 triggers OPA.																													
6	PRSCH6	PRS ch 6 triggers OPA.																													
7	PRSCH7	PRS ch 7 triggers OPA.																													
9	PRSMODE	0	RW	<b>OPAx PRS Trigger Mode</b>  PRS trigger mode of OPA.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PULSED</td><td>PULSED trigger is considered a regular asynchronous pulse that starts OPA warmup sequence. The end of warmup sequence is controlled by timeout settings in OPAxTIMER.</td></tr> <tr> <td>1</td><td>TIMED</td><td>TIMED trigger is considered a pulse long enough to provide OPA warmup sequence. The end of warmup sequence is controlled by negative edge of the pulse.</td></tr> </tbody> </table>	Value	Mode	Description	0	PULSED	PULSED trigger is considered a regular asynchronous pulse that starts OPA warmup sequence. The end of warmup sequence is controlled by timeout settings in OPAxTIMER.	1	TIMED	TIMED trigger is considered a pulse long enough to provide OPA warmup sequence. The end of warmup sequence is controlled by negative edge of the pulse.																		
Value	Mode	Description																													
0	PULSED	PULSED trigger is considered a regular asynchronous pulse that starts OPA warmup sequence. The end of warmup sequence is controlled by timeout settings in OPAxTIMER.																													
1	TIMED	TIMED trigger is considered a pulse long enough to provide OPA warmup sequence. The end of warmup sequence is controlled by negative edge of the pulse.																													
8	PRSEN	0	RW	<b>OPAx PRS Trigger Enable</b>  Select OPAx conversion trigger.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>OPAx is triggered by OPAxEN</td></tr> <tr> <td>1</td><td>OPAx is triggered by PRS input</td></tr> </tbody> </table>	Value	Description	0	OPAx is triggered by OPAxEN	1	OPAx is triggered by PRS input																					
Value	Description																														
0	OPAx is triggered by OPAxEN																														
1	OPAx is triggered by PRS input																														
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
4	OUTSCALE	0	RW	<b>Scale OPAx Output Driving Strength</b>  Use this to scale OPAx output driving strength.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>FULL</td><td>Select this for full output driving strength.</td></tr> <tr> <td>1</td><td>HALF</td><td>Select this for half output driving strength.</td></tr> </tbody> </table>	Value	Mode	Description	0	FULL	Select this for full output driving strength.	1	HALF	Select this for half output driving strength.																		
Value	Mode	Description																													
0	FULL	Select this for full output driving strength.																													
1	HALF	Select this for half output driving strength.																													

Bit	Name	Reset	Access	Description										
3	HCMDIS	1	RW	<b>High Common Mode Disable</b>  Set to disable high common mode. Disables rail-to-rail on input, while output still remains rail-to-rail. The input voltage to the opamp while HCM is disabled is restricted between VSS and VDD-1.2V. Setting this bit improves output linearity when input is low.										
2	INCBW	1	RW	<b>OPAx Unity Gain Bandwidth Scale</b>  Unity gain bandwidth scale.										
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>No scaling</td></tr> <tr> <td>1</td><td>When set the unity gain bandwidth will be scaled by factor of 2.5. useful to make OPA operate faster for closed-loop gain setting greater than 3x.</td></tr> </tbody> </table>	Value	Description	0	No scaling	1	When set the unity gain bandwidth will be scaled by factor of 2.5. useful to make OPA operate faster for closed-loop gain setting greater than 3x.				
Value	Description													
0	No scaling													
1	When set the unity gain bandwidth will be scaled by factor of 2.5. useful to make OPA operate faster for closed-loop gain setting greater than 3x.													
1:0	DRIVESTRENGTH	0x2	RW	<b>OPAx Operation Mode</b>  Selects OPAX operation mode.										
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Lower accuracy with Low drive strength.</td></tr> <tr> <td>1</td><td>Low accuracy with Low drive strength.</td></tr> <tr> <td>2</td><td>High accuracy with High drive strength.</td></tr> <tr> <td>3</td><td>Higher accuracy with High drive strength.</td></tr> </tbody> </table>	Value	Description	0	Lower accuracy with Low drive strength.	1	Low accuracy with Low drive strength.	2	High accuracy with High drive strength.	3	Higher accuracy with High drive strength.
Value	Description													
0	Lower accuracy with Low drive strength.													
1	Low accuracy with Low drive strength.													
2	High accuracy with High drive strength.													
3	Higher accuracy with High drive strength.													

## 24.5.17 VDACn\_OPAX\_TIMER - Operational Amplifier Timer Control Register

Offset	Bit Position																																					
0x0AC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Reset													0x001												0x00													
Access													RW												RW													
Name													SETTLETIME												STARTUPDLY													
Bit	Name	Reset	Access	Description																																		
31:26	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																				
25:16	SETTLETIME	0x001	RW	OPAx Output Settling Timeout Value	Number of clock cycles to drive the output																																	
15	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																				
14:8	WARMUPTIME	0x07	RW	OPAx Warmup Time Count Value	OPAx warmup timeout value																																	
7:6	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																				
5:0	STARTUPDLY	0x00	RW	OPAx Startup Delay Count Value	OPAx startup delay in us. Used only in PRS sample of mode of stand alone opamp.																																	

## 24.5.18 VDACn\_OPAX\_MUX - Operational Amplifier Mux Configuration Register

Offset	Bit Position																																															
0x0B0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																
Reset	0x0												0xF2												0xF1																							
Access	RW												RW												RW																							
Name	RESSEL												RESIN3X												NEGSEL												POSSEL											

Bit	Name	Reset	Access	Description																																							
31:27	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																									
26:24	RESSEL	0x0	RW	<b>OPAx Resistor Ladder Select</b>																																							
	Configures the resistor ladder tap for OPAx.																																										
	Value	Mode												Resistor Value																													
	0	RES0												R2 = 1/3 x R1																													
	1	RES1												R2 = R1																													
	2	RES2												R2 = 1 2/3 x R1																													
	3	RES3												R2 = 2 1/5 x R1																													
	4	RES4												R2 = 3 x R1																													
	5	RES5												R2 = 4 1/3 x R1																													
	6	RES6												R2 = 7 x R1																													
	7	RES7												R2 = 15 x R1																													
23:21	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																									
20	GAIN3X	1	RW	<b>OPAx Dedicated 3x Gain Resistor Ladder</b>																																							
	Selects gain of 3x.																																										
	Value	Description																																									
	0	Disables 3x gain ladder.																																									
	1	Enables and sets the gain to 3x. If this is set to 1, RESSEL will only be used externally by other opamps. By default this is set to 1 for dac to work properly. For stand alone opamp and to configure gain based on RESSEL value, users need to configure this to 0.																																									
19	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																									
18:16	RESINMUX	0x6	RW	<b>OPAx Resistor Ladder Input Mux</b>																																							
	These bits selects the source for the input mux to the resistor ladder																																										
	Value	Mode												Description																													
	0	DISABLE												Set for Unity Gain																													

Bit	Name	Reset	Access	Description
1	OPANEXT			Set for NEXTOUT(x-1) input
2	NEGPAD			NEG pad connected
3	POSPAD			POS pad connected
4	COMPAD			Neg pad of OPA0 connected. Direct input to support common reference.
5	CENTER			OPA0 and OPA1 Resmux connected to form fully differential instrumentation amplifier.
6	VSS			VSS connected
15:8	NEGSEL	0xF2	RW	<b>OPAx Inverting Input Mux</b>
				These bits selects the source for the inverting input on OPAx
	Mode	Value		Description
	APORT1YCH1	48		Select APOR1YCH1
	APORT1YCH3	49		Select APOR1YCH3
	APORT1YCH5	50		Select APOR1YCH5
	...	...		.....
	APORT1YCH31	63		Select APOR1YCH31
	APORT2YCH0	80		Select APOR2YCH0
	APORT2YCH2	81		Select APOR2YCH2
	APORT2YCH4	82		Select APOR2YCH3
	...	...		.....
	APORT2YCH30	95		Select APOR2YCH30
	APORT3YCH1	112		Select APOR3YCH1
	APORT3YCH3	113		Select APOR3YCH3
	APORT3YCH5	114		Select APOR3YCH5
	...	...		.....
	APORT3YCH31	127		Select APOR3YCH31
	APORT4YCH0	144		Select APOR4YCH0
	APORT4YCH2	145		Select APOR4YCH2
	APORT4YCH4	146		Select APOR4YCH4
	...	...		.....
	APORT4YCH30	159		Select APOR4YCH30
	DISABLE	240		Input disabled
	UG	241		Unity Gain feedback path
	OPATAP	242		OPAxTAP as input
	NEGPAD	243		Input from NEG PAD
7:0	POSSEL	0xF1	RW	<b>OPAx Non-inverting Input Mux</b>
				These bits selects the source for the non-inverting input on OPAx

Bit	Name	Reset	Access	Description
	Mode	Value		Description
	APORT1XCH0	32		Select APORT1XCH0
	APORT1XCH2	33		Select APORT1XCH2
	APORT1XCH4	34		Select APORT1XCH4
	...	...		.....
	APORT1XCH30	47		Select APORT1XCH30
	APORT2XCH1	64		Select APORT2XCH1
	APORT2XCH3	65		Select APORT2XCH3
	APORT2XCH5	66		Select APORT2XCH5
	...	...		.....
	APORT2XCH31	79		Select APORT2XCH31
	APORT3XCH0	96		Select APORT3XCH0
	APORT3XCH2	97		Select APORT3XCH2
	APORT3XCH4	98		Select APORT3XCH4
	...	...		.....
	APORT3XCH30	111		Select APORT3XCH30
	APORT4XCH1	128		Select APORT4XCH1
	APORT4XCH3	129		Select APORT4XCH3
	APORT4XCH5	130		Select APORT4XCH5
	...	...		.....
	APORT4XCH31	143		Select APORT4XCH31
	DISABLE	240		Input disabled
	DAC	241		DAC as input
	POSPAD	242		POS PAD as input
	OPANEXT	243		NEXTOUT(x-1) as input. For OPA0 not applicable.
	OPATAP	244		OPAxTAP as input. For OPA2 OPA0TAP.

## 24.5.19 VDACn\_OPAX\_OUT - Operational Amplifier Output Configuration Register

Offset	Bit Position																																																
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0																	
Reset									0x00												0x00								0																				
Access									RW												RW								RW																				
Name									APORTOUTSEL												ALTOUTPADEN								SHORT																				
																					APORTOUTEN								MAINOUTEN																				
Bit	Name	Reset	Access	Description																																													
31:24	Reserved					To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																											
23:16	APORTOUTSEL	0x00	RW	<b>OPAx APORt Output</b>																																													
	Select APORt output.																																																
Mode	Value	Description																																															
APORT1YCH1	48	Select APORT1YCH1																																															
APORT1YCH3	49	Select APORT1YCH3																																															
APORT1YCH5	50	Select APORT1YCH5																																															
...	...	.....																																															
APORT1YCH31	63	Select APORT1YCH31																																															
APORT2YCH0	80	Select APORT2YCH0																																															
APORT2YCH2	81	Select APORT2YCH2																																															
APORT2YCH4	82	Select APORT2YCH3																																															
...	...	.....																																															
APORT2YCH30	95	Select APORT2YCH30																																															
APORT3YCH1	112	Select APORT3YCH1																																															
APORT3YCH3	113	Select APORT3YCH3																																															
APORT3YCH5	114	Select APORT3YCH5																																															
...	...	.....																																															
APORT3YCH31	127	Select APORT3YCH31																																															
APORT4YCH0	144	Select APORT4YCH0																																															
APORT4YCH2	145	Select APORT4YCH2																																															
APORT4YCH4	146	Select APORT4YCH4																																															
...	...	.....																																															
APORT4YCH30	159	Select APORT4YCH30																																															
15:9	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																															

Bit	Name	Reset	Access	Description
8:4	ALTOUTPADEN	0x00	RW	<b>OPAx Output Enable Value</b>
Set to enable output, clear to disable output				
	OUT ENABLE	VALUE		Description
	OUT0	xxxx1		Alternate Output 0
	OUT1	xxx1x		Alternate Output 1
	OUT2	xx1xx		Alternate Output 2
	OUT3	x1xxx		Alternate Output 3
	OUT4	1xxxx		Alternate Output 4
3	SHORT	0	RW	<b>OPAx Main and Alternative Output Short</b>
Set this to short circuit main and alternative outputs. This will keep the outputs shorted even when the VDAC is disabled.				
2	APORTOUTEN	0	RW	<b>OPAx Aport Output Enable</b>
Set this to enable aport output of OPAx.				
1	ALTOUTEN	0	RW	<b>OPAx Alternative Output Enable</b>
Set this to enable alternative output of OPAx.				
0	MAINOUTEN	1	RW	<b>OPAx Main Output Enable</b>
Set this to enable main output of OPAx.				



## 24.5.20 VDACn\_OPAX\_CAL - Operational Amplifier Calibration Register

Offset	Bit Position																																		
0x0B8	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset				0x00						0x00				0x0																					
Access			RW					RW					RW			RW				RW					RW							RW			
Name		OFFSETN						OFFSETP					GM3			GM				CM3					CM2							CM1			

Bit	Name	Reset	Access	Description
31	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
30:26	OFFSETN	0x00	RW	<b>OPAx Inverting Input Offset Configuration Value</b>  This register contains the offset calibration value for inverting input. Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24:20	OFFSETP	0x00	RW	<b>OPAx Non-Inverting Input Offset Configuration Value</b>  This register contains the offset calibration value for Non-inverting input offset. Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18:17	GM3	0x0	RW	<b>Gm3 Trim Value</b>  Gm trim code of OPAMP stage 3. Additional trim for OPAMP stage 3. Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:13	GM	0x4	RW	<b>Gm Trim Value</b>  Gm trim value common to all OPAMP stages to keep the bandwidth insensitive to process variation. Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:10	CM3	0x0	RW	<b>Compensation Cap Cm3 Trim Value</b>  Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
8:5	CM2	0x7	RW	<b>Compensation Cap Cm2 Trim Value</b>  Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.
4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
3:0	CM1	0x7	RW	<b>Compensation Cap Cm1 Trim Value</b>  Program with value obtained from Device Information page (DEVINFO_OPAXCALn) depending on OPAMP number and chosen DRIVESTRENGTH.

## 25. OPAMP - Operational Amplifier



### Quick Facts

#### What?

The opamps are low power amplifiers with a high degree of flexibility targeting a wide variety of standard opamp application areas. With flexible gain and interconnection built-in, they can be configured to support multiple common opamp functions. All pins are available externally for filter configurations. Each opamp has a rail-to-rail input and a rail-to-rail output.

#### Why?

The opamps are included not only to save energy on a PCB compared to standalone opamps but also to reduce system cost by replacing external opamps.

#### How?

Two of the opamps are made available as part of the VDAC, while the other opamps are standalone. In addition to popular differential-to-single ended and differential-to-differential driver modes, an ADC unity gain buffer mode configuration makes it possible to isolate kickback noise. The opamps can also be configured as a multi-step cascaded PGA, and for all of the built-in modes no external components are necessary.

### 25.1 Introduction

The opamps are highly configurable general purpose opamps, suitable for simple filters and buffer applications. The 4 opamps can be configured to support various operational amplifier functions through a network of muxes with possibilities of selecting ranges of on-chip non-inverting and inverting gain configurations and selecting between outputs to various destinations. The opamps can also be configured with external feedback in addition to supporting cascade connections between two or three opamps. The opamps are rail-to-rail in and out. A user selectable mode has been added to optimize linearity, in which case the input voltage to the opamp is restricted to a range between VSS and AVDD-1.2V.

### 25.2 Features

- 4 individually configurable opamps
- Opamps support rail-to-rail inputs and outputs
- Supports the following functions
  - General opamp mode
  - Voltage follower unity gain
  - Inverting input PGA
  - Non-inverting PGA
  - Cascaded inverting PGA
  - Cascaded non-inverting PGA
  - Two opamp differential amplifier
  - Three opamp differential amplifier
  - Dual buffer ADC driver
- Programmable gain
- Programmable drive strength
- Programmable start delay, warmup and settle time
- Connection to APOR
- Enable / Disable via PRS

- Output status to PRS

### 25.3 Functional Description

The 4 opamps can be configured to perform various opamp functions through a network of muxes. An overview of the opamps are shown in [Figure 25.1 OPAMP System Overview on page 867](#). Two of the 4 opamps are part of the VDAC, while the others are stand-alone. The outputs of the opamps can be routed to the ADC and ACMP. All 4 opamps can also take input from pins. Since OPA0 and OPA1 are part of the VDAC, special considerations needs to be taken when both VDAC channel 0/channel 1 and OPA0/OPA1 are used. For detailed explanation, refer to [25.3.5 Opamp VDAC Combination](#).





Figure 25.1. OPAMP System Overview

There is a set of input muxes for each opamp, making it possible to select various input sources. A more detailed view of the 4 opamps, including the mux network is shown in [Figure 25.2 OPAMP Overview on page 868](#). The POSSEL mux connected to the positive input makes it possible to select a pin, another opamp output, or tap from the resistor network. Similarly, the NEGSEL mux on the negative input makes it possible to select a pin or a feedback path as its source. The feedback path can be unity gain, 3x gain, or selected from the resistor network for programmable gain. Each opamp has several outputs, a main output, an alternative output network, APOR output and a next output. These outputs make it possible to route the output to a pin, another opamp input, the ADC, the ACMP, or into the feedback path. For details regarding configuring the outputs, see [25.3.1.8 Output Configuration](#). In addition, there is also a mux to configure the resistor ladder for connection to VSS, a pin, or another opamp output.



**Figure 25.2. OPAMP Overview**

### 25.3.1 Opamp Configuration

Since two of the 4 OPAMPs (OPA0, OPA1) are part of the VDAC, the opamp configuration registers are located in the VDAC.

Each OPAMP can be enabled by setting OPAxEN in VDACn\_CMD and can be disabled by setting OPAxDIS in VDACn\_CMD. The enabled status of each OPAMP can be read by polling the OPAxENS bit in VDACn\_STATUS. OPAxENS goes high immediately after an OPAxEN is written and goes low when OPAxDIS is written and after OPAMP is completely disabled.

Software *must not* write to the following registers while OPAxENS set.

- VDACn\_OPAx\_CTRL
- VDACn\_OPAx\_TIMER
- VDACn\_OPAx\_MUX

#### 25.3.1.1 Enable Sources

Opamp can be enabled either with software or PRS. The default source is software. Setting PRSEN to 1 in VDACn\_OPAx\_CTRL enables PRS mode. In PRS mode, opamp has two options, which are selectable with PRSMODE in VDACn\_OPAx\_CTRL. If PRSMODE is configured to TIMED, opamp is turned on on the positive edge of PRS and stays on until PRS goes low. If PRSMODE is configured to PULSED, opamp is turned on on the positive edge of PRS and stays on based on the timer configurations in VDACn\_OPAxTIMER. The PRS channel is selected by PRSSEL in VDACn\_OPAx\_CTRL.

#### 25.3.1.2 Warmup Time

When an opamp is enabled some initialization time is required. The warm up period is programmable with WARMUPTIME in VDACn\_OPAx\_TIME. The OPAxWARM bit in VDACn\_STATUS are set when the warmup period has completed.

The warm up period depends on the selected DRIVESTRENGTH in VDACn\_OPAx\_CTRL.

**Table 25.1. OPAMP Warmup Time**

DRIVESTRENGTH	WARMUPTIME (μs)
0	100
1	85
2	8
3	6

**25.3.1.3 Settle Time**

After an opamp is enabled and the warmed-up time has elapsed the output settles externally. The settle period is programmable with SETTLETIME in VDACn\_OPAX\_TIME. The OPAXOUTVALID bit in VDACn\_STATUS is set when the settle period has completed. When in use by the VDAC the default settling time is used.

The settling period depends on the load at opamp output and DRIVESTRENGTH of the opamp. [Table 25.2 OPAMP Settling Time on page 869](#) specifies SETTLETIME settings for a load of 1KOhm and 75pF.

**Table 25.2. OPAMP Settling Time**

DRIVESTRENGTH	SETTLETIME (μs)
0	60
1	25
2	3
3	1

**25.3.1.4 Startup Delay**

Each opamp has an option to delay the warm up period. The startup delay is programmable with STARTDLY in VDACn\_OPAX\_TIME. If STARTDLY is programmed to a non-zero value, the opamp is warmed up after STARTDLY+WARMUPTIME, and the output settles after STARTDLY+WARMUPTIME+SETTLETIME.

**25.3.1.5 Power Supply**

The opamp module power ( $V_{OPA}$ ) is derived from the AVDD supply pin.

**25.3.1.6 I/O Pin Considerations**

The maximum usable analog signal that can be applied to external opamp inputs (or seen on external opamp outputs) depends on several factors: whether the signal is routed through the APOR, whether High Linearity mode is used, whether overvoltage is enabled, and on the IOVDD/AVDD supply voltages, as shown in the [Table 25.3 Maximum Usable IO Voltage on page 869](#) table.

**Table 25.3. Maximum Usable IO Voltage**


Opamp Pin	Maximum IO Voltage (APORT USED and OVT Enabled/Disabled)	Maximum IO Voltage (APORT UNUSED, OVT Enabled)	Maximum IO Voltage (APORT UNUSED, OVT Disabled)
Opamp Inputs - Normal Mode	MIN(AVDD, IOVDD)	MIN(AVDD, IOVDD)	MIN(AVDD, IOVDD)
Opamp Inputs - High Linearity Mode	MIN(AVDD - 1.2 V, IOVDD)	MIN(AVDD - 1.2 V, IOVDD)	MIN(AVDD - 1.2 V, IOVDD)
Opamp Outputs	MIN(AVDD, IOVDD)	MIN(AVDD, IOVDD + 2 V)	MIN(AVDD, IOVDD)

### 25.3.1.7 Input Configuration

The inputs to the opamps are controlled through a set of input muxes. The mux connected to the positive input is configured by the POSSEL bit-field in the VDACn\_OPAX\_MUX register. Similarly, the mux connected to the negative input is configured by setting the NEGSEL bit-field in VDACn\_OPAX\_MUX. The input into the resistor ladder can be configured by setting the RESINMUX bit-field in VDACn\_OPAX\_MUX.

### 25.3.1.8 Output Configuration

Each opamp has three outputs: the main output, an alternative output network with lower drive strength, and an APORTE output with low drive strength. These three outputs can be configured as shown in [Figure 25.3 Opamp Output Stage Overview on page 870](#). The main output can be used to drive the main output by setting MAINOUTEN in VDACn\_OPAX\_OUT. The alternative output can drive the alternative output network by setting ALTOUTEN in VDACn\_OPAX\_OUT. The APORTE output can drive the APORTE selection mux by setting APORTOUTEN in VDACn\_OPAX\_OUT.



**Figure 25.3. Opamp Output Stage Overview**

The alternative output network consists of connections to pins and a connection to the next opamp. The connections to pins can be individually enabled by configuring ALTOUTPADEN in the VDACn\_OPAX\_OUT register. For cascaded opamp configurations, each opamp has a NEXTOUT connection.

The opamp outputs can also be routed to APORTE1Y, APORTE2Y, APORTE3Y, and APORTE4Y. The APORTE channel can be selected by configuring APORTOUTSEL in VDACn\_OPAX\_OUT.

The opamps are also routed internally to the ADC. OPA0 and OPA1 are routed through the POSMUX of the ADC, and OPA2 and OPA3 are routed through the NEGMUX of the ADC. See [27.3.7 Input Selection](#) in the ADC chapter for information on how to configure the ADC input mux.

In addition, OPA0 and OPA1 are internally routed to both the POSMUX and NEGMUX of ACMP. See [26.3.6 Input Selection](#) in the ACMP chapter for information on how to configure the ACMP input mux.

The main and alternate outputs of each opamp can be shorted together by setting the SHORT bit-field in VDACn\_OPAX\_OUT.

### 25.3.1.9 Gain Programming

The feedback path of each mux includes a resistor ladder that can be used to select a set of gain values. Gain is configured by the RESSEL bit-field located in the VDACn\_OPAX\_MUX register. Gain values are determined by the resistor ladder based on ratio of R2/R1. It is also possible to bypass the resistor ladder in unity gain mode. In addition, there is also a preconfigured resistor ladder with 3X gain. The 3x gain resistor ladder is enabled by setting GAIN3X in VDACn\_OPAX\_MUX. By default all opamps are configured in 3x gain mode. When using RESSEL, GAIN3X should be set to zero.

### 25.3.1.10 Offset Calibration

Each opamp has a calibration register, `VDACn_OPAX_CAL`, where calibration values for both offset and gain correction can be written. The required calibration settings depend on the chosen `DRIVESTRENGTH`. The default calibration settings stored in `VDACn_OPAX_CAL` are for `DRIVESTRENGTH=2`. If an opamp is being reconfigured, the required calibration settings for `DRIVESTRENGTH=n` can be found in `DEVINFO_OPAXCALn`. Offsets can be programmed through the `OFFSETP` and `OFFSETN` bitfields of `VDACn_OPAX_CAL`.

### 25.3.1.11 Disabling of Rail-to-Rail Operation

Each opamp can have its input rail-to-rail stage disabled by setting the `HCMDIS` in `VDACn_OPAX_CTRL`. Disabling the rail-to-rail input stage improves linearity of the opamp, thus improving the total harmonic distortion (THD) at the cost of reduced input signal swing.

### 25.3.1.12 Unity Gain Bandwidth Scaling

Unity gain bandwidth of an opamp can be scaled setting the `INCBW` bit in `VDACn_OPAX_CTRL`. Note that this setting is used only when closed loop gain is greater than 3X. With this setting is enabled, the opamp is not unity gain stable.

### 25.3.1.13 Opamp Output Scaling

Opamp output drive strength is scaled by one half when the `OUTSCALE` bit in `VDACn_OPAX_CTRL` is set.

## 25.3.2 Interrupts and PRS Output

Each opamp has an interrupt flag `OPAxOUTVALID` in `VDACn_IF` that is set when the output is settled externally at the load. An interrupt will be requested if the `OPAxOUTVALID` interrupt flag in `VDACn_IF` is set and enabled by the `OPAxOUTVALID` bit in `VDACn_IEN`.

The `OPAxERRPRSMODE` interrupt flag in `VDACn_IF` indicates a protocol error when the opamp is triggered in PRS TIMED mode. This flag is set if the negative edge of the PRS pulse came before the output to opamp is valid. The interrupt flag is enabled by the `OPAxERRPRSMODE` bit in `VDACn_IEN`.

An interrupt can also be requested when an APORt bus conflict occurs if the `OPAxAPORTCONFLICT` interrupt flag in `VDACn_IF` is set and enabled through by the `OPAxAPORTCONFLICT` bit in `VDACn_IEN`.

One of two asynchronous PRS outputs can be enabled for each opamp by setting `PRSOUTMODE` in `VDACn_OPAX_CTRL`. If `PRSOUTMODE` is `WARM`, opamp warm-up status is available. If `PRSOUTMODE` is `OUTVALID`, opamp output valid status is available.

### 25.3.3 APORt Request and Conflict Status

The opamps are connected to pins through the APORt system. To help debug over-utilization of APORt resources, the opamps provide request and conflict status information. The request status of APORt buses is visible through the `DACn_OPAX_APORTREQ` register.

If an APORt bus conflict occurs, it is reported in the `DACn_OPAX_APORTCONFLICT` register. An APORt conflict occurs if an opamp requests the same bus at the same time as another analog peripheral. In addition an APORt conflict is reported if any two of `NEGSEL`, `POSSEL` or `APORTOUTSEL` are configured to request the same APORt bus.

It is possible for the opamps to passively monitor APORt buses without controlling the switches and creating bus conflicts. This can be done by setting `APORTXMASTERDIS` or `APORTYMASTERDIS` in the `DACn_OPAX_CTRL` register.

### 25.3.4 Opamp Modes

The opamps can perform several different functions by configuring the internal signal routing between the opamps. The modes available are described in the following sections.

#### 25.3.4.1 General Opamp Mode


In this mode, the resistor ladder is isolated from the feedback path, and the input signal routing is defined by `POSSEL` and `NEGSEL` in `VDACn_OPAX_MUX`. The output signal routing is defined by the setting of `VDACn_OPAX_OUT`.

**Table 25.4. General Opamp Mode Configuration**

OPA Bitfields	OPA Configuration
OPAx POSSEL	POSPADx, APOR[1-4]X
OPAx NEGSEL	OPATAP, UG, NEGPADx, APOR[1-4]Y
OPAx RESINMUX	NEXTOUT, POSPADx, NEGPADx, VSS

**25.3.4.2 Voltage Follower Unity Gain**


In this mode, the unity gain feedback path is selected for the negative input by setting the NEGSEL bit-field to UG in the VDACn\_OPAX\_MUX register as shown in [Figure 25.4 Voltage Follower Unity Gain Overview on page 872](#). The positive input is selected by the POSSEL bit-field in VDACn\_OPAX\_MUX, and the output is configured by VDACn\_OPAX\_OUT register.

**Figure 25.4. Voltage Follower Unity Gain Overview****Table 25.5. Voltage Follower Unity Gain Configuration**

OPA Bitfields	OPA Configuration
OPAx POSSEL	OPATAP, NEXTOUT, POSPADx, APOR[1-4]X
OPAx NEGSEL	UG
OPAx RESINMUX	DISABLE

**25.3.4.3 Inverting Input PGA**

[Figure 25.5 Inverting Input PGA Overview on page 872](#) shows the inverting input PGA configuration. In this mode, the negative input is connected to the resistor ladder by setting the NEGSEL bit-field to OPATAP in the VDACn\_OPAX\_MUX register. This setting provides a programmable gain on the negative input, which is set by the RESSEL bit-field in VDACn\_OPAX\_MUX. Signal ground for the positive input can come from off-chip by setting the POSSEL bit-field to PAD or APOR in VDACn\_OPAX\_MUX. In addition, the output is configured by VDACn\_OPAX\_OUT register.


**Figure 25.5. Inverting Input PGA Overview**

**Table 25.6. Inverting Input PGA Configuration**

OPA Bitfields	OPA Configuration
OPAx POSSEL	POSPADx, APOR[1-4]X
OPAx NEGSEL	OPATAP
OPAx RESINMUX	NEXTOUT, NEGPADx, POSPADx

**25.3.4.4 Non-inverting PGA**


[Figure 25.6 Non-inverting PGA Overview on page 873](#) shows the non-inverting input configuration. In this mode, the negative input is connected to the resistor ladder by setting the NEGSEL bit-field to OPATAP in VDACn\_OPAx\_MUX. This setting provides a programmable gain on the negative input, which is set by the RESSEL bit-field in VDACn\_OPAx\_MUX. In addition, the RESINMUX bit-field must be set to VSS or NEGPAD in VDACn\_OPAx\_MUX. The positive input is selected by the POSSEL bit-field, and the output is configured by VDACn\_OPAx\_OUT register.

**Figure 25.6. Non-inverting PGA Overview****Table 25.7. Non-inverting PGA Configuration**

OPA Bitfields	OPA Configuration
OPAx POSSEL	NEXTOUT, POSPADx, APOR[1-4]X
OPAx NEGSEL	OPATAP
OPAx RESINMUX	VSS, NEGPAD

**25.3.4.5 Cascaded Inverting PGA**

This mode enables the opamp signals to be internally configured to cascade two or more opamps in inverting mode as shown in [Figure 25.7 Cascaded Inverting PGA Overview on page 874](#). In both cases, the positive input is connected to signal ground by setting the POSSEL bit-field to PAD or APOR in VDACn\_OPAx\_MUX. When cascaded, the negative input is connected to the resistor ladder by setting the NEGSEL bit-field to OPATAP in VDACn\_OPAx\_MUX. The input to the resistor ladder is configured by the RESINMUX bit-field in VDACn\_OPAx\_MUX.

**Figure 25.7. Cascaded Inverting PGA Overview**


[Table 25.8 Cascaded Inverting PGA Configuration on page 874](#) shows cascaded non-inverting PGA with OPA0, OPA1 and OPA2. The output from OPA0 is connected to OPA1 to create the second stage by setting the RESINMUX field to OPANEXT in VDACn\_OPA1\_MUX. The last stage is created by setting the RESINMUX bit-field to OPANEXT in VDACn\_OPA2MUX.

**Table 25.8. Cascaded Inverting PGA Configuration**

OPA	OPA Bitfields	OPA Configuration
OPA0	POSSEL	POSPAD0, APOR[1-4]X
OPA0	NEGSEL	OPATAP
OPA0	RESINMUX	NEGPAD0
OPA1	POSSEL	POSPAD1, APOR[1-4]X
OPA1	NEGSEL	OPATAP
OPA1	RESINMUX	OPANEXT
OPA2	POSSEL	POSPAD2, APOR[1-4]X
OPA2	NEGSEL	OPATAP
OPA2	RESINMUX	OPANEXT

#### 25.3.4.6 Cascaded Non-inverting PGA

This mode enables the opamp signals to be internally configured to cascade two or more opamps in non-inverting mode as shown in [Figure 25.8 Cascaded Non-inverting PGA Overview on page 875](#). The negative input for all opamps will be connected to the resistor ladder by setting the NEGSEL bit-field to OPATAP. In addition the resistor ladder input must be set to VSS or NEGPADx by configuring the RESINMUX bit-field in VDACn\_OPAx\_MUX.

**Figure 25.8. Cascaded Non-inverting PGA Overview**

[Table 25.9 Cascaded Non-inverting PGA Configuration on page 875](#) shows cascaded non-inverting PGA with OPA0,OPA1 and OPA2. When cascaded, the positive input on OPA0 is configured by the OPA0 POSSEL bit-field in VDACn\_OPA0\_MUX. The output from OPA0 is connected to OPA1 to create the second stage by setting the POSSEL field to OPANEXT in VDACn\_OPA1\_MUX. The last stage is created by setting the POSSEL bit-field to OPANEXT in VDACn\_OPA2\_MUX.


**Table 25.9. Cascaded Non-inverting PGA Configuration**

OPA	OPA Bitfields	OPA Configuration
OPA0	POSSEL	POSPAD0,APORT[1-4]X
OPA0	NEGSEL	OPATAP
OPA0	RESINMUX	VSS, NEGPAD0
OPA1	POSSEL	OPANEXT
OPA1	NEGSEL	OPATAP
OPA1	RESINMUX	VSS, NEGPAD1
OPA2	POSSEL	OPANEXT
OPA2	NEGSEL	OPATAP
OPA2	RESINMUX	VSS, NEGPAD2

#### 25.3.4.7 Two Opamp Differential Amplifier

This mode allows OPA0 and OPA1 or OPA1 and OPA2 to be internally connected to form a two opamp differential amplifier as shown in [Figure 25.9 Two Op-amp Differential Amplifier Overview on page 876](#). When using OPA0 and OPA1, the positive input of OPA0 can be connected to any input by setting the POSSEL bit-field in VDACn\_OPA0\_MUX. The OPA0 feedback path must be configured for unity gain by setting the NEGSEL bit-field to UG in VDACn\_OPA0\_MUX. In addition, the OPA0 RESINMUX bit-field must be set to DISABLED. The OPA0 NEXTOUT output must be connected to OPA1 by setting the RESINMUX bit-field to OPANEXT in VDAC\_n\_OPA1\_MUX. The positive input on OPA1 is selected by the POSSELbit-field in VDACn\_OPA1\_MUX. The OPA1 output is configured by DACn\_OPA1\_OUT.

When using OPA1 and OPA2, the positive input of OPA1 can be connected to any input by setting the POSSEL bit-field in VDACn\_OPA1\_MUX. The OPA1 feedback path must be configured for unity gain by setting the NEGSEL bit-field to UG in VDACn\_OPA1\_MUX. In addition, the OPA1 RESINMUX bit-field must be set to DISABLED. The OPA1 NEXTOUT output must be connected to OPA2 by setting the RESINMUX bit-field to OPANEXT in VDACn\_OPA2\_MUX. The positive input of OPA2 is selected by the POSSEL bit-field in VDACn\_OPA2\_MUX. The OPA2 output is configured by DACn\_OPA2\_OUT.

**Figure 25.9. Two Op-amp Differential Amplifier Overview****Table 25.10. OPA0/OPA1 Differential Amplifier Configuration**


OPA	OPA Bitfields	OPA Configuration
OPA0	POSSEL	POSPAD0, APORT[1-4]X
OPA0	NEGSEL	UG
OPA0	RESINMUX	DISABLE
OPA1	POSSEL	POSPAD1, APORT[1-4]X
OPA1	NEGSEL	OPATAP
OPA1	RESINMUX	OPANEXT

**Table 25.11. OPA1/OPA2 Differential Amplifier Configuration**

OPA	OPA Bitfields	OPA Configuration
OPA1	POSSEL	POSPAD1, APORT[1-4]X
OPA1	NEGSEL	UG
OPA1	RESINMUX	DISABLE
OPA2	POSSEL	POSPAD2, APORT[1-4]X
OPA2	NEGSEL	OPATAP
OPA2	RESINMUX	OPANEXT

#### 25.3.4.8 Three Opamp Differential Amplifier

This mode allows the three opamps to be internally configured to form a three opamp differential amplifier as shown in [Figure 25.10 Three Op-amp Differential Amplifier Overview on page 877](#). For both OPA0 and OPA1, the positive input can be connected to any input by configuring the OPA0 POSSEL and OPA1 POSSEL bitfields in `VDACn_OPA0_MUX` and `VDACn_OPA1_MUX`, respectively. The OPA0 and OPA1 feedback paths must be configured for unity gain by setting the OPA0 NEGSEL and OPA1 NEGSEL bitfields to UG in `VDACn_OPA0_MUX` and `VDACn_OPA1_MUX` respectively. In addition the OPA0 RESINMUX and OPA1 RESINMUX bitfields must be set to DISABLED. The OPA1 output must be connected to OPA2 by setting RESINMUX to OPANEXT in `VDACn_OPA2_MUX` and the OPA2 POSSEL must be set to OPATAP. The OPA2 output is configured by the `DACn_OPA2_OUT` register.

**Figure 25.10. Three Op-amp Differential Amplifier Overview**

The gain for the Three Opamp Differential Amplifier is determined by the combination of the gain settings of OPA0 and OPA2. Gain values of 1/3, 1 and 3, are available and programmed as shown in the table below.

**Table 25.12. Three Opamp Differential Amplifier Gain Programming**

Gain	OPA0 RESSEL	OPA2 RESSEL
1/3	4	0
1	1	1
3	0	4

**Table 25.13. Three Opamp Differential Amplifier Configuration**

OPA	OPA Bitfields	OPA Configuration
OPA0	POSSEL	POSPAD0, APOR[1-4]X
OPA0	NEGSEL	UG
OPA0	RESINMUX	DISABLE
OPA1	POSSEL	POSPAD1, APOR[1-4]X
OPA1	NEGSEL	UG
OPA1	RESINMUX	DISABLE
OPA2	POSSEL	OPATAP
OPA2	NEGSEL	OPATAP
OPA2	RESINMUX	OPANEXT

#### 25.3.4.9 Instrumentation Amplifier

OPA0 and OPA1 can form a fully differential instrumentation amplifier by setting RESINMUX to CENTER for both opamps in VDACn\_OPA0\_MUX and VDACn\_OPA1\_MUX. Configuring RESINMUX to CENTER makes a connection between resistor ladder of the opamps as shown in [Figure 25.11 Instrumentation Amplifier Overview on page 878](#).




Figure 25.11. Instrumentation Amplifier Overview

#### 25.3.4.10 Common Reference

It is possible to configure all opamps to have a common reference by setting the RESINMUX to COMPAD in VDACn\_OPAx\_MUX. When RESINMUX of all opamps is set to COMPAD mode, the NEGPAD input of OPA0 is used.

#### 25.3.4.11 Dual Buffer ADC Driver

It is possible to use any two of the opamps to form a Dual Buffer ADC driver as shown in [Figure 25.12 Dual Buffer ADC Driver Overview on page 878](#). Both opamps used must be configured in the same way. The positive input is configured by setting the OPAX POS\_SEL to PAD, and the negative input is connected to the resistor ladder by setting NEGSEL to OPATAP in VDACn\_OPAX\_MUX. The output from the opamps can be configured to drive pins through the alternative output network or the APOR. The ADC can sample pins that the opamps are driving through the APOR.




Figure 25.12. Dual Buffer ADC Driver Overview

Table 25.14. Dual Buffer ADC Driver Configuration

OPA	OPA Bitfields	OPA Configuration
OPAx	POSSEL	POSPADx, APOR[1-4]X
OPAx	NEGSEL	OPATAP
OPAx	RESINMUX	VSS

#### 25.3.5 Opamp VDAC Combination

Since two of the OPAMPs are part of the VDAC, it is not possible to use both VDAC channels and all 4 OPAMPs at the same time. If both VDAC channels are used, OPA0 and OPA1 can not be used as stand-alone opamp. However, it is possible to use one of the VDAC channels in combination with OPA0 or OPA1. OPA1 is available when VDAC channel 0 is in use, and OPA0 is available when VDAC channel 1 is used.



## 25.4 Register Map

The register map of the opamp can be found in [24.4 Register Map](#) in the VDAC chapter.

## 25.5 Register Description

The register description of the opamp can be found in [24.5 Register Description](#) in the VDAC chapter.

## 26. ACMP - Analog Comparator



### Quick Facts

#### What?

The Analog Comparator (ACMP) compares two analog signals and returns a digital value telling which is greater.

#### Why?

Applications often do not need to know the exact value of an analog signal, only if it has passed a certain threshold. Often the voltage must be monitored continuously, which requires extremely low power consumption.

#### How?

Available down to Energy Mode 3 and using as little as 100 nA, the ACMP can wake up the system when input signals pass the threshold. The analog comparator can compare two analog signals or one analog signal and a highly configurable internal reference.

### 26.1 Introduction


The Analog Comparator compares the voltage of two analog inputs and outputs a digital signal indicating which input voltage is higher. Inputs can either be from internal references or from external pins. Response time, and thereby the current consumption, can be configured by altering the current supply to the comparator.

## 26.2 Features

- Up to 160 selectable external I/O inputs for both positive and negative inputs
  - Up to 48 I/O can be used as a dividable reference
- 5 selectable internal inputs
  - VDAC channel 0 voltage as a reference
  - VDAC channel 1 voltage as a reference
  - Dividable Internal 1.25 V bandgap reference voltage
  - Dividable Internal 2.5 V bandgap reference voltage
  - Dividable  $V_{ACMPVDD}$  reference voltage
- Voltage supply monitoring
- Low power mode for internal  $V_{DD}$  and bandgap references
- Selectable hysteresis
  - 8 values
  - Values can be positive or negative
  - Dividable references have scale for both output values, allowing for even larger hysteresis
- Selectable response time
- Asynchronous interrupt generation on selectable edges
  - Rising edge
  - Falling edge
  - Both edges
- Operational in EM0 Active down to EM3 Stop
- Dedicated capacitive sense mode with up to 8 inputs
  - Adjustable internal resistor
- Configurable output when inactive
- Comparator output direct on PRS
- Comparator output on GPIO through alternate functionality
  - Output inversion available

## 26.3 Functional Description

An overview of the ACMP is shown in [Figure 26.1 ACMP Overview on page 882](#).



**Figure 26.1. ACMP Overview**

The comparator has two analog inputs: one positive and one negative. When the comparator is active, the output indicates which of the two input voltages is higher. When the voltage on the positive input is higher than the voltage on the negative input, the digital output is high and vice versa.

The output of the comparator can be read in the ACMPOUT bit in ACMPn\_STATUS. It is possible to switch inputs while the comparator is enabled, but all other configuration should only be changed while the comparator is disabled.

### 26.3.1 Power Supply

The comparator power supply ( $V_{ACMPVDD}$ ) can be configured to be AVDD, DVDD, or IOVDD using the PWRSEL bitfield in ACMPn\_CTRL. By default,  $V_{ACMPVDD}$  is set to AVDD.

### 26.3.2 Warm-up Time

The analog comparator is enabled by setting the EN bit in ACMPn\_CTRL. The comparator requires some time to stabilize after it is enabled. This time period is called the warm-up time. The warm-up period is self-timed and will complete within 5 $\mu$ s after EN is set.

During warm-up and when the comparator is disabled, the output level of the comparator is set to the value of the INACTVAL bit in ACMPn\_CTRL. When the warm-up time is over, the ACMPACT bit in ACMPn\_STATUS is set to 1 to indicate that the comparator is active.

An edge interrupt will be generated if the edge interrupt is enabled and the value set in INACTVAL differs from ACMPOUT when the comparator transitions from warm-up to active.

Software should wait until the warm-up period is over before entering EM2 or EM3, otherwise no comparator interrupts will be detected. EM1 can still be entered during warm-up. After the warm-up period is completed, interrupts will be detected in EM2 and EM3.

### 26.3.3 Response Time

There is a delay from when the input voltage changes polarity to when the output toggles. This delay is called the response time and can be altered by increasing or decreasing the bias current to the comparator through the BIASPROG and FULLBIAS fields in the ACMPn\_CTRL register. The current and speed of the circuit increase as the values of FULLBIAS and BIASPROG are increased from their minimum setting of FULLBIAS=0 BIASPROG=0b00000 to the maximum setting FULLBIAS=1 BIASPROG=0b11111 (maximum). The setting of FULLBIAS has a greater affect on current and speed than the setting of BIASPROG. See the part data sheet for specific current and response times related to the setting of these fields.

If FULLBIAS is set, to avoid glitches the highest hysteresis level should be used.

#### 26.3.4 Hysteresis


When the hysteresis level is set to a non-zero value, the digital output will not toggle until the positive input voltage is at a voltage equal to the hysteresis level above or below the negative input voltage (see [Figure 26.3 Hysteresis on page 884](#) ). This feature can be used to avoid continual comparator output changes due to noise when the positive and negative inputs are nearly equal by requiring the input difference to exceed the hysteresis threshold.

In the analog comparator, hysteresis can be configured to 8 different levels. Level 0 is no hysteresis. Hysteresis is configured through the HYST field in ACMPn\_HYSTERESIS0 and ACMPn\_HYSTERESIS1 registers. The hysteresis value can be positive or negative. The comparator will output a 1 if:

$$\text{POSSEL} - \text{NEGSEL} > \text{HYST}$$

There are two hysteresis registers, ACMPn\_HYSTERESIS0 and ACMPn\_HYSTERESIS1, as the ACMP supports asymmetric hysteresis. ACMPn\_HYSTERESIS0 are the hysteresis values used when the comparator output is 0; ACMPn\_HYSTERESIS1 are the values used when the comparator output is 1. The user must set both registers to the same values if symmetric hysteresis is desired.

Along with the HYST field, the ACMPn\_HYSTERESIS0/1 registers include the DIVVA and DIVVB fields. This allows the user to implement even larger hysteresis when comparing against VADIV or VBDIV, as the reference voltage can vary with the comparator output, also.



**Figure 26.3. Hysteresis**

### 26.3.5 Input Pin Considerations

For external ACMP inputs routed through the APORT, the maximum supported analog input voltage will be limited to the  $\text{MIN}(\text{V}_{\text{ACMPVDD}}, \text{IOVDD})$  (where  $\text{V}_{\text{ACMPVDD}}$  is selected by the PWRSEL bitfield in ACMPn\_CTRL). Note that pins configured as ACMP inputs should disable OVT (by setting the corresponding GPIO\_Px\_OVTDIS bit) to reduce any potential distortion introduced by the OVT circuitry.

### 26.3.6 Input Selection

The POSSEL and NEGSEL fields in ACMPn\_INPUTSEL control the input connections to the positive and negative inputs of the comparator. The user can select external GPIO pins on the chip, or select a number of internal chip voltages. Pins are selected by configuring channels on APORT buses. Not all selectable channels are available on a given device, as different devices within a family may not implement or bring out all of the I/O defined for that family. Refer to the data sheet for channel availability and pin mapping.

There are limitations on the POSSEL and NEGSEL connections that can be made. The user cannot select an X-bus for both POSSEL and NEGSEL simultaneously, nor a Y-bus for both POSSEL and NEGSEL simultaneously. The second limitation is that when using the feedback resistor only X-bus selections can be made for POSSEL. (The resistor only physically exists on the positive input of the comparator).

The user may also select from a number of internal voltages. VADIV and VBDIV are two dividable voltages. VADIV can be  $\text{V}_{\text{ACMPVDD}}$  divided, or the user can choose to select inputs from a number of APORT buses. VBDIV consists of two dividable band-gap references of either 1.25V or 2.5V. Each of these voltages have dividers in the ACMPn\_HYSTERESIS0/1 registers. The formula for the division of these voltages is:

$$\text{VADIV} = \text{VA} \times ( (\text{DIVVA}+1) / 64 )$$

Figure 26.3. VA Voltage Division

$$\text{VBDIV} = \text{VB} \times ( (\text{DIVVB}+1) / 64 )$$

Figure 26.4. VB Voltage Division

Either VADIV and VBDIV can also be used as an input to a lower power reference: VLP. Which of the two is used is configured via the VLPSEL field in ACMPn\_INPUTSEL. If the user selects VLP as an input source, then VADIV or VBDIV cannot be used as the source for the other input.

**Note:** The VLP should not be selected as an input source when the external override interface is enabled.



The POSSEL and NEGSEL fields also allow input from the on-chip VDAC channel 0 or VDAC channel 1.

ACMP can be configured to operate with a selected level of accuracy depending on the setting of ACCURACY in ACMPn\_CTRL. The default is low-accuracy mode where ACMP operates with lower accuracy but consumes less current. When higher accuracy is needed the user can set ACCURACY=1 at the cost of higher current consumption.

### 26.3.7 Capacitive Sense Mode

The analog comparator includes specialized hardware for capacitive sensing of passive push buttons. Such buttons are traces on the PCB laid out in a way that creates a parasitic capacitor between the button and the ground node. Because a human finger will have a small intrinsic capacitance to ground, the capacitance of the button will increase when the button is touched. The capacitance is measured by including the capacitor in a free-running RC oscillator (see [Figure 26.5 Capacitive Sensing Setup on page 887](#) ). The frequency produced will decrease when the button is touched compared to when it is not touched. By measuring the output frequency with a timer (via the PRS), the change in capacitance can be detected.

The analog comparator contains a feedback loop including an optional internal resistor. This resistor is enabled by setting the CSREN bit in ACMPn\_INPUTSEL. The resistance can be set to any of 8 values by configuring the CSRESSEL bits in ACMPn\_INPUTSEL. The source for VADIV is set to VACMPVDD by setting field VASEL=0 in ACMPn\_INPUTSEL. The oscillation rails are defined by the VADIV fields in registers ACMPn\_HYSTERESIS0/1. The user should select VADIV as the source for NEGSEL, and APORTEXCHc for POSSEL in ACMPn\_INPUTSEL. When enabled, the comparator output will oscillate between the rails defined by VADIV in ACMPn\_HYSTERESIS0/1.



**Figure 26.5. Capacitive Sensing Setup**

### 26.3.8 Interrupts and PRS Output

The analog comparator includes an edge triggered interrupt flag (EDGE in ACMPn\_IF). If either IRISE and/or IFALL in ACMPn\_CTRL is set, the EDGE interrupt flag will be set on rising and/or falling edge of the comparator output respectively. An interrupt request will be sent if the EDGE interrupt flag in ACMPn\_IF is set and enabled through the EDGE bit in ACMPn\_IEN. The edge interrupt can also be used to wake up the device from EM3 Stop-EM1 Sleep.

The analog comparator includes the interrupt flag WARMUP in ACMPn\_IF which is set when a warm-up sequence has finished. An interrupt request will be sent if the WARMUP interrupt flag in ACMPn\_IF is set and enabled through the WARMUP bit in ACMPn\_IEN.

The analog comparator can also generate an interrupt if a bus conflict occurs. An interrupt request will be sent if the APORTCOMFLICT interrupt flag in ACMPn\_IF is set and enabled through the APORTCOMFLICT bit in ACMPn\_IEN.

The synchronized comparator output is also available as a PRS output signal.

### 26.3.9 Output to GPIO

The output from the comparator and the capacitive sense output are available as alternate functions to the GPIO pins. Set the ACMP\_PEN bit in ACMPn\_ROUTE to enable the output to a pin and the LOCATION bits to select the output location. The GPIO-pin must also be set as output. The output to the GPIO can be inverted by setting the GPIOINV bit in ACMPn\_CTRL.

### 26.3.10 APORTCOMFLICT

The analog comparator connects to chip pins through APORTCOMFLICT buses. It is possible that another APORTCOMFLICT client is using a given APORTCOMFLICT bus. To help debugging over-utilization of APORTCOMFLICT resources the ACMP provides a number of status registers. The ACMPn\_APORTCOMFLICT gives the user visibility into what APORTCOMFLICT buses the ACMP is requesting given the setting of registers ACMPn\_INPUTSEL and ACMPn\_CTRL. ACMPn\_APORTCOMFLICT indicates if any of the selections are in conflict, internally or externally.

For example, if the user selects APORTCOMFLICT1XCH0 for POSSEL and APORTCOMFLICT3XCH1 for NEGSEL, then bits APORTCOMFLICT1XCOMFLICT and APORTCOMFLICT3XCOMFLICT would be 1 in register ACMPn\_APORTCOMFLICT, as it is illegal for POSSEL and NEGSEL to both select an X-bus simultaneously.

If the user wishes the ACMP to monitor the same pin as another APORTCOMFLICT client within the system, the ACMP can be configured to not attempt to control the switches on an APORTCOMFLICT bus via the fields APORTCOMFLICTMASTERDIS, APORTCOMFLICTYMASTERDIS, and APORTCOMFLICTVMASTERDIS in ACMPn\_CTRL. APORTCOMFLICTMASTERDIS and APORTCOMFLICTYMASTERDIS control if the X or Y bus selected via POSSEL or NEGSEL is mastered or not. APORTCOMFLICTVMASTERDIS controls if either the X or Y bus selection of VASEL is mastered or not. When bus mastering is disabled, it is the other APORTCOMFLICT client that determines which pin is connected to the APORTCOMFLICT bus.

### 26.3.11 Supply Voltage Monitoring

The ACMP can be used to monitor supply voltages. The ACMP can select which voltage it uses via PWRSEL in ACMPn\_CTRL. This voltage can be selected for VADIV using VASEL=0 in ACMPn\_INPUTSEL and divided to a voltage with the band-gap reference range using DIVVA in registers ACMPn\_HYSTERESIS0/1. The band-gap reference voltage can also be scaled via DIVVB in registers ACMPn\_HYSTERESIS0/1 to provide a voltage higher or lower than the scaled VA voltage for comparison.

### 26.3.12 External Override Interface

The ACMP can be controlled by an external module, for instance LESENSE. In this mode, the external module will take control of the positive input mux control signal, which is normally controlled by ACMP\_INPUTSEL\_POSSEL. Only the APORts are selectable for the positive input mux in this mode. Which APORt(s) used is configured in ACMP\_EXTIFCTRL\_APORtSEL. Additionally, the VLP should not be selected for the negative input mux in this mode.

**Note:** When the ACMP is controlled by the external interface, the ACMP warmup time may take up to 30 µs.

ACMP\_EXTIFCTRL\_APORtSEL also controls the base value for the positive input mux control signal. The external module will be able to add an offset to this base. The resulting mux configuration can be calculated using [Figure 26.6 POSSEL in External Override Mode on page 889](#). The external module controls EXT\_OFFSET, while EXT\_BASE is controlled by ACMP. See register description of ACMP\_EXTIFCTRL\_APORtSEL to see values of EXT\_BASE.

$$\text{POSSel} = \text{EXT\_BASE} + \text{EXT\_OFFSET}$$

**Figure 26.6. POSSel in External Override Mode**

**Note:** If only one APORt in a pair is used, the external module needs to be programmed to only use the channels that the ACMP has control of.

The external module is also able to override DIVVA and DIVVB in ACMP\_HYSTERESIS0/HYSTERESIS1. This needs to be enabled in the external module. If the external module does not override DIVVA/DIVVB, the configuration in ACMP\_HYSTERESIS0/HYSTERESIS1 will be used.

To enable the external override interface these steps must be performed:

- Configure the parts of the ACMP that will not be overridden, i.e. everything except ACMP\_INPUTSEL\_POSSEL and possibly ACMP\_HYSTERESIS0/HYSTERESIS1. Make sure ACMP\_CTRL\_EN is set.
- Configure and enable the external override interface in ACMP\_EXTIFCTRL.
- Check for APORt conflicts in ACMP\_APORtCONFLICT.
- Wait for ACMP\_STATUS\_EXTIFACT to go high, indicating that the interface is ready to use.

## 26.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	ACMPn_CTRL	RW	Control Register
0x004	ACMPn_INPUTSEL	RW	Input Selection Register
0x008	ACMPn_STATUS	R	Status Register
0x00C	ACMPn_IF	R	Interrupt Flag Register
0x010	ACMPn_IFS	W1	Interrupt Flag Set Register
0x014	ACMPn_IFC	(R)W1	Interrupt Flag Clear Register
0x018	ACMPn_IEN	RW	Interrupt Enable Register
0x020	ACMPn_APORtREQ	R	APORt Request Status Register
0x024	ACMPn_APORtCONFLICT	R	APORt Conflict Status Register
0x028	ACMPn_HYSTERESIS0	RW	Hysteresis 0 Register
0x02C	ACMPn_HYSTERESIS1	RW	Hysteresis 1 Register
0x040	ACMPn_ROUTEOPEN	RW	I/O Routing Pipe Enable Register
0x044	ACMPn_ROUTELOC0	RW	I/O Routing Location Register
0x048	ACMPn_EXTIFCTRL	RW	External Override Interface Control

## 26.5 Register Description

### 26.5.1 ACMPn\_CTRL - Control Register

Offset	Bit Position							
Reset	0x000	FULLBIAS	RW	0	31			
Access			RW	0x07	26	30		
Name	BIASPROG				25			
					24			
					23			
					22			
					IFALL	RW	0	21
					IRISE	RW	0	20
					INPUTRANGE	RW	0x0	19
					ACCURACY	RW	0	15
					PWRSEL	RW	0x0	13
					APORTVMASTERDIS	RW	0	10
					APORTYMASTERDIS	RW	0	9
					APORTXMASTERDIS	RW	0	8
					GPIOINV	RW	0	3
					INACTVAL	RW	0	2
					EN	RW	0	0

Bit	Name	Reset	Access	Description
31	FULLBIAS	0	RW	<b>Full Bias Current</b>  Set this bit to 1 for full bias current. See the data sheet for details.
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:24	BIASPROG	0x07	RW	<b>Bias Configuration</b>  These bits control the bias current level. See the data sheet for details.
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21	IFALL	0	RW	<b>Falling Edge Interrupt Sense</b>  Set this bit to 1 to set the EDGE interrupt flag on falling edges of comparator output.
	Value	Mode		Description
	0	DISABLED		Interrupt flag is not set on falling edges
	1	ENABLED		Interrupt flag is set on falling edges
20	IRISE	0	RW	<b>Rising Edge Interrupt Sense</b>  Set this bit to 1 to set the EDGE interrupt flag on rising edges of comparator output.
	Value	Mode		Description
	0	DISABLED		Interrupt flag is not set on rising edges
	1	ENABLED		Interrupt flag is set on rising edges
19:18	INPUTRANGE	0x0	RW	<b>Input Range</b>  Adjust performance of the comparator for a given input voltage range.
	Value	Mode		Description
	0	FULL		Setting when the input can be from 0 to ACMPVDD.
	1	GTVDDDIV2		Setting when the input will always be greater than ACMPVDD/2.

Bit	Name	Reset	Access	Description
2	LTVDDDIV2			Setting when the input will always be less than ACMPVDD/2.
17:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15	ACCURACY	0	RW	<b>ACMP Accuracy Mode</b>
				Select between low and high accuracy mode of the comparator. Note, high frequency changes can cause the ACMP performance to degrade. For such uses, such as quickly scanning through multiple channels or setting the ACMP to oscillate for capacitive sense, this bit should be set to 1.
	Value	Mode		Description
	0	LOW		ACMP operates in low-accuracy mode but consumes less current.
	1	HIGH		ACMP operates in high-accuracy mode but consumes more current.
14:12	PWRSEL	0x0	RW	<b>Power Select</b>
				Selects the power source for the ACMP(ACMPVDD). NOTE, this field should only be changed when the block is disabled (EN=0).
	Value	Mode		Description
	0	AVDD		AVDD supply
	1	DVDD		DVDD supply
	2	IOVDD0		IOVDD/IOVDD0 supply
	4	IOVDD1		IOVDD1 supply (if part has two I/O voltages)
11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10	APORTVMASTER-DIS	0	RW	<b>APORT Bus Master Disable for Bus Selected By VASEL</b>
				Determines if the ACMP will request the X or Y APOR Tbus selected by VASEL. This bit allows multiple APOR Tconnected devices to monitor the same APOR Tbus simultaneously by allowing the ACMP to not master the selected bus. When 1, the determination is expected to be from another peripheral, and the ACMP only passively looks at the bus. When 1, the selection of channel for a selected bus is ignored (the bus is not), and is whatever selection the external device mastering the bus has configured for the APOR Tbus.
	Value			Description
	0			Bus mastering enabled
	1			Bus mastering disabled
9	APORTYMASTER-DIS	0	RW	<b>APORT Bus Y Master Disable</b>
				Determines if the ACMP will request the APOR T Y bus selected by POSSEL or NEGSEL. This bit allows multiple APOR Tconnected devices to monitor the same APOR Tbus simultaneously by allowing the ACMP to not master the selected bus. When 1, the determination is expected to be from another peripheral, and the ACMP only passively looks at the bus. When 1, the selection of channel for a selected bus is ignored (the bus is not), and is whatever selection the external device mastering the bus has configured for the APOR Tbus.
	Value			Description
	0			Bus mastering enabled
	1			Bus mastering disabled

Bit	Name	Reset	Access	Description									
8	APORTXMASTER-DIS	0	RW	<b>APORT Bus X Master Disable</b>									
Determines if the ACMP will request the APORt X bus selected by POSSEL or NEGSEL. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously by allowing the ACMP to not master the selected bus. When 1, the determination is expected to be from another peripheral, and the ACMP only passively looks at the bus. When 1, the selection of channel for a selected bus is ignored (the bus is not), and is whatever selection the external device mastering the bus has configured for the APORt bus.													
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Bus mastering enabled</td></tr> <tr> <td>1</td><td>Bus mastering disabled</td></tr> </tbody> </table>					Value	Description	0	Bus mastering enabled	1	Bus mastering disabled			
Value	Description												
0	Bus mastering enabled												
1	Bus mastering disabled												
7:4	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>											
3	GPIOINV	0	RW	<b>Comparator GPIO Output Invert</b>									
Set this bit to 1 to invert the comparator alternate function output to GPIO.													
<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NOTINV</td><td>The comparator output to GPIO is not inverted</td></tr> <tr> <td>1</td><td>INV</td><td>The comparator output to GPIO is inverted</td></tr> </tbody> </table>					Value	Mode	Description	0	NOTINV	The comparator output to GPIO is not inverted	1	INV	The comparator output to GPIO is inverted
Value	Mode	Description											
0	NOTINV	The comparator output to GPIO is not inverted											
1	INV	The comparator output to GPIO is inverted											
2	INACTVAL	0	RW	<b>Inactive Value</b>									
The value of this bit is used as the comparator output when the comparator is inactive.													
<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOW</td><td>The inactive value is 0</td></tr> <tr> <td>1</td><td>HIGH</td><td>The inactive state is 1</td></tr> </tbody> </table>					Value	Mode	Description	0	LOW	The inactive value is 0	1	HIGH	The inactive state is 1
Value	Mode	Description											
0	LOW	The inactive value is 0											
1	HIGH	The inactive state is 1											
1	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>											
0	EN	0	RW	<b>Analog Comparator Enable</b>									
Enable/disable analog comparator.													

## 26.5.2 ACMPn\_INPUTSEL - Input Selection Register

Offset	Bit Position																
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15
<b>Reset</b>												0x00					
<b>Access</b>		RW	RW	0	RW	0	RW	0	RW	RW	RW		RW	0x00		RW	
<b>Name</b>	CSRESSEL	CSRESEN	VLPSEL		VBSEL		VASEL			NEGSEL						POSSEL	

Bit	Name	Reset	Access	Description
31	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
30:28	<b>CSRESSEL</b>	0x0	RW	<b>Capacitive Sense Mode Internal Resistor Select</b>
	These bits select the resistance value for the internal capacitive sense resistor. Resulting actual resistor values are given in the device data sheets.			
	Value	Mode	Description	
	0	RES0	Internal capacitive sense resistor value 0	
	1	RES1	Internal capacitive sense resistor value 1	
	2	RES2	Internal capacitive sense resistor value 2	
	3	RES3	Internal capacitive sense resistor value 3	
	4	RES4	Internal capacitive sense resistor value 4	
	5	RES5	Internal capacitive sense resistor value 5	
	6	RES6	Internal capacitive sense resistor value 6	
	7	RES7	Internal capacitive sense resistor value 7	
27	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
26	<b>CSRESEN</b>	0	RW	<b>Capacitive Sense Mode Internal Resistor Enable</b>
	Enable/disable the internal capacitive sense resistor.			
25	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
24	<b>VLPSEL</b>	0	RW	<b>Low-Power Sampled Voltage Selection</b>
	Select the input to the sampled voltage VLP			
	Value	Mode	Description	
	0	VADIV	VADIV	
	1	VBDIV	VBDIV	
23	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		

Bit	Name	Reset	Access	Description
22	VBSEL	0	RW	<b>VB Selection</b>
Select the input for the VB Divider				
	Value	Mode		Description
	0	1V25		1.25V
	1	2V5		2.50V
21:16	VASEL	0x00	RW	<b>VA Selection</b>
Select the input for the VA Divider				
	Mode	Value		Description
	VDD	0x0		ACMPVDD
	APORT2YCH0	0x1		APORT2Y Channel 0
	APORT2YCH2	0x3		APORT2Y Channel 2
	APORT2YCH4	0x5		APORT2Y Channel 4
	...	...		...
	APORT2YCH30	0x1f		APORT2Y Channel 30
	APORT1XCH0	0x20		APORT1X Channel 0
	APORT1YCH1	0x21		APORT1Y Channel 1
	APORT1XCH2	0x22		APORT1X Channel 2
	APORT1YCH3	0x23		APORT1Y Channel 3
	APORT1XCH4	0x24		APORT1X Channel 4
	APORT1YCH5	0x25		APORT1Y Channel 5
	...	...		...
	APORT1XCH30	0x3e		APORT1X Channel 30
	APORT1YCH31	0x3f		APORT1Y Channel 31
15:8	NEGSEL	0x00	RW	<b>Negative Input Select</b>
Select negative input.				
	APORT0XCH0	0x00		Dedicated APORT0X Channel 0
	APORT0XCH1	0x01		Dedicated APORT0X Channel 1
	APORT0XCH2	0x02		Dedicated APORT0X Channel 2
	...	...		...
	APORT0XCH15	0x0f		Dedicated APORT0X Channel 15
	APORT0YCH0	0x10		Dedicated APORT0Y Channel 0
	APORT0YCH1	0x11		Dedicated APORT0Y Channel 1
	APORT0YCH2	0x12		Dedicated APORT0Y Channel 2
	...	...		...
	APORT0YCH15	0x1f		Dedicated APORT0Y Channel 15

Bit	Name	Reset	Access	Description
	APORT1XCH0	0x20		APORT1X Channel 0
	APORT1YCH1	0x21		APORT1Y Channel 1
	APORT1XCH2	0x22		APORT1X Channel 2
	APORT1YCH3	0x23		APORT1Y Channel 3
	APORT1XCH4	0x24		APORT1X Channel 4
	APORT1YCH5	0x25		APORT1Y Channel 5
...	...	...		...
	APORT1XCH30	0x3e		APORT1X Channel 30
	APORT1YCH31	0x3f		APORT1Y Channel 31
	APORT2YCH0	0x40		APORT2Y Channel 0
	APORT2XCH1	0x41		APORT2X Channel 1
	APORT2YCH2	0x42		APORT2Y Channel 2
	APORT2XCH3	0x43		APORT2X Channel 3
	APORT2YCH4	0x44		APORT2Y Channel 4
	APORT2XCH5	0x45		APORT2X Channel 5
...	...	...		...
	APORT2YCH30	0x5e		APORT2Y Channel 30
	APORT2XCH31	0x5f		APORT2X Channel 31
	APORT3XCH0	0x60		APORT3X Channel 0
	APORT3YCH1	0x61		APORT3Y Channel 1
	APORT3XCH2	0x62		APORT3X Channel 2
	APORT3YCH3	0x63		APORT3Y Channel 3
	APORT3XCH4	0x64		APORT3X Channel 4
	APORT3YCH5	0x65		APORT3Y Channel 5
...	...	...		...
	APORT3XCH30	0x7e		APORT3X Channel 30
	APORT3YCH31	0x7f		APORT3Y Channel 31
	APORT4YCH0	0x80		APORT4Y Channel 0
	APORT4XCH1	0x81		APORT4X Channel 1
	APORT4YCH2	0x82		APORT4Y Channel 2
	APORT4XCH3	0x83		APORT4X Channel 3
	APORT4YCH4	0x84		APORT4Y Channel 4
	APORT4XCH5	0x85		APORT4X Channel 5
...	...	...		...
	APORT4YCH30	0x9e		APORT4Y Channel 30
	APORT4XCH31	0x9f		APORT4X Channel 31
	DACOUT0	0xf2		DAC Channel 0 Output

Bit	Name	Reset	Access	Description
	DACOUT1	0xf3		DAC Channel 1 Output
	VLP	0xfb		Low-Power Sampled Voltage
	VBDIV	0xfc		Divided VB Voltage
	VADIV	0xfd		Divided VA Voltage
	VDD	0xfe		ACMPVDD as selected via PWRSEL
	VSS	0xff		VSS
7:0	POSSEL	0x00	RW	<b>Positive Input Select</b>
				Select positive input.
	APORT0XCH0	0x00		Dedicated APOR0X Channel 0
	APORT0XCH1	0x01		Dedicated APOR0X Channel 1
	APORT0XCH2	0x02		Dedicated APOR0X Channel 2
	...	...		...
	APORT0XCH15	0x0f		Dedicated APOR0X Channel 15
	APORT0YCH0	0x10		Dedicated APOR0Y Channel 0
	APORT0YCH1	0x11		Dedicated APOR0Y Channel 1
	APORT0YCH2	0x12		Dedicated APOR0Y Channel 2
	...	...		...
	APORT0YCH15	0x1f		Dedicated APOR0Y Channel 15
	APORT1XCH0	0x20		APORT1X Channel 0
	APORT1YCH1	0x21		APORT1Y Channel 1
	APORT1XCH2	0x22		APORT1X Channel 2
	APORT1YCH3	0x23		APORT1Y Channel 3
	APORT1XCH4	0x24		APORT1X Channel 4
	APORT1YCH5	0x25		APORT1Y Channel 5
	...	...		...
	APORT1XCH30	0x3e		APORT1X Channel 30
	APORT1YCH31	0x3f		APORT1Y Channel 31
	APORT2YCH0	0x40		APORT2Y Channel 0
	APORT2XCH1	0x41		APORT2X Channel 1
	APORT2YCH2	0x42		APORT2Y Channel 2
	APORT2XCH3	0x43		APORT2X Channel 3
	APORT2YCH4	0x44		APORT2Y Channel 4
	APORT2XCH5	0x45		APORT2X Channel 5
	...	...		...
	APORT2YCH30	0x5e		APORT2Y Channel 30
	APORT2XCH31	0x5f		APORT2X Channel 31

Bit	Name	Reset	Access	Description
	APORT3XCH0	0x60		APORT3X Channel 0
	APORT3YCH1	0x61		APORT3Y Channel 1
	APORT3XCH2	0x62		APORT3X Channel 2
	APORT3YCH3	0x63		APORT3Y Channel 3
	APORT3XCH4	0x64		APORT3X Channel 4
	APORT3YCH5	0x65		APORT3Y Channel 5
...	...	...		
	APORT3XCH30	0x7e		APORT3X Channel 30
	APORT3YCH31	0x7f		APORT3Y Channel 31
	APORT4YCH0	0x80		APORT4Y Channel 0
	APORT4XCH1	0x81		APORT4X Channel 1
	APORT4YCH2	0x82		APORT4Y Channel 2
	APORT4XCH3	0x83		APORT4X Channel 3
	APORT4YCH4	0x84		APORT4Y Channel 4
	APORT4XCH5	0x85		APORT4X Channel 5
...	...	...		
	APORT4YCH30	0x9e		APORT4Y Channel 30
	APORT4XCH31	0x9f		APORT4X Channel 31
	DACOUT0	0xf2		DAC Channel 0 Output
	DACOUT1	0xf3		DAC Channel 1 Output
	VLP	0xfb		Low-Power Sampled Voltage
	VBDIV	0xfc		Divided VB Voltage
	VADIV	0xfd		Divided VA Voltage
	VDD	0xfe		ACMPVDD as selected via PWRSEL
	VSS	0xff		VSS

## 26.5.3 ACMPn\_STATUS - Status Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																
Bit	Name	Reset	Access	Description																												
31:4	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																														
3	EXTIFACT	0	R	<b>External Override Interface Active</b>																												
	This bit is set when the external override interface is ready to use.																															
2	APORTCONFLICT	0	R	<b>APORT Conflict Output</b>																												
	1 if any of the APORt BUSes being requested by the ACMPn are also being requested by another peripheral																															
1	ACMPOUT	0	R	<b>Analog Comparator Output</b>																												
	Analog comparator output value.																															
0	ACMPACT	0	R	<b>Analog Comparator Active</b>																												
	Analog comparator active status.																															

## 26.5.4 ACMPn\_IF - Interrupt Flag Register

Offset	Bit Position																																
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	APORTCONFLICT	0	R	<b>APORT Conflict Interrupt Flag</b>
				1 if any of the APORt BUSes being requested by the ACMPn are also being requested by another peripheral
1	WARMUP	0	R	<b>Warm-up Interrupt Flag</b>
				Indicates that the analog comparator warm-up period is finished.
0	EDGE	0	R	<b>Edge Triggered Interrupt Flag</b>
				Indicates that there has been a rising or falling edge on the analog comparator output.

## 26.5.5 ACMPn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	APORTCONFLICT	0	W1	<b>Set APORTCONFLICT Interrupt Flag</b>
				Write 1 to set the APORTCONFLICT interrupt flag
1	WARMUP	0	W1	<b>Set WARMUP Interrupt Flag</b>
				Write 1 to set the WARMUP interrupt flag
0	EDGE	0	W1	<b>Set EDGE Interrupt Flag</b>
				Write 1 to set the EDGE interrupt flag

## 26.5.6 ACMPn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	APORTCONFLICT	0	(R)W1	<b>Clear APORTCONFLICT Interrupt Flag</b>
				Write 1 to clear the APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	WARMUP	0	(R)W1	<b>Clear WARMUP Interrupt Flag</b>
				Write 1 to clear the WARMUP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	EDGE	0	(R)W1	<b>Clear EDGE Interrupt Flag</b>
				Write 1 to clear the EDGE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 26.5.7 ACMPn\_IEN - Interrupt Enable Register

Offset	Bit Position																																				
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0					
Reset																																					
Access																																					
Name																																					
APORTCONFLICT	RW	0	2																																		
WARMUP	RW	0	1																																		
EDGE	RW	0	0																																		

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	APORTCONFLICT	0	RW	<b>APORTCONFLICT Interrupt Enable</b>  Enable/disable the APORTCONFLICT interrupt
1	WARMUP	0	RW	<b>WARMUP Interrupt Enable</b>  Enable/disable the WARMUP interrupt
0	EDGE	0	RW	<b>EDGE Interrupt Enable</b>  Enable/disable the EDGE interrupt

## 26.5.8 ACMPn\_APORTREQ - APORTR Request Status Register

Offset	Bit Position																					
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10
<b>Reset</b>																			0	9	0	8
<b>Access</b>																			0	7	0	6
<b>Name</b>																			APORT4YREQ	R	0	4
																			APORT4XREQ	R	0	3
																			APORT3YREQ	R	0	2
																			APORT3XREQ	R	0	1
																			APORT2YREQ	R	0	0
																			APORT2XREQ	R	0	0
																			APORT1YREQ	R	0	0
																			APORT1XREQ	R	0	0
																			APORT0YREQ	R	0	0
																			APORT0XREQ	R	0	0

Bit	Name	Reset	Access	Description
31:10	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YREQ	0	R	<b>1 If the Bus Connected to APORTR4Y is Requested</b>  Reports if the bus connected to APORTR4Y is being requested from the APORTR
8	APORT4XREQ	0	R	<b>1 If the Bus Connected to APORTR4X is Requested</b>  Reports if the bus connected to APORTR4X is being requested from the APORTR
7	APORT3YREQ	0	R	<b>1 If the Bus Connected to APORTR3Y is Requested</b>  Reports if the bus connected to APORTR3Y is being requested from the APORTR
6	APORT3XREQ	0	R	<b>1 If the Bus Connected to APORTR3X is Requested</b>  Reports if the bus connected to APORTR3X is being requested from the APORTR
5	APORT2YREQ	0	R	<b>1 If the Bus Connected to APORTR2Y is Requested</b>  Reports if the bus connected to APORTR2Y is being requested from the APORTR
4	APORT2XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
3	APORT1YREQ	0	R	<b>1 If the Bus Connected to APORTR1X is Requested</b>  Reports if the bus connected to APORTR1X is being requested from the APORTR
2	APORT1XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
1	APORT0YREQ	0	R	<b>1 If the Bus Connected to APORTR0Y is Requested</b>  Reports if the bus connected to APORTR0Y is being requested from the APORTR
0	APORT0XREQ	0	R	<b>1 If the Bus Connected to APORTR0X is Requested</b>  Reports if the bus connected to APORTR0X is being requested from the APORTR

## 26.5.9 ACMPn\_APORTCNFICT - APORTCNFICT Conflict Status Register

Offset	Bit Position																						
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	
Reset																							
Access																							
Name																							

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT4Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT4Y is also being requested by another peripheral
8	APORT4XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT4X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT4X is also being requested by another peripheral
7	APORT3YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT3Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT3Y is also being requested by another peripheral
6	APORT3XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT3X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT3X is also being requested by another peripheral
5	APORT2YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT2Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT2Y is also being requested by another peripheral
4	APORT2XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT2X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT2X is also being requested by another peripheral
3	APORT1YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT1Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT1Y is also being requested by another peripheral
2	APORT1XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT1X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT1X is also being requested by another peripheral
1	APORT0YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT0Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT0Y is also being requested by another peripheral

Bit	Name	Reset	Access	Description
0	APORT0XCONFLICT	0	R	<b>1 If the Bus Connected to APOR0X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR0X is also being requested by another peripheral

## 26.5.10 ACMPn\_HYSTERESIS0 - Hysteresis 0 Register

Offset	Bit Position																																			
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset																																				0x0
Access					RW									RW																					RW	
Name		DIVVB							DIVVA																										HYST	

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:24	DIVVB	0x00	RW	<b>Divider for VB Voltage When ACMPOUT=0</b>  Divider to scale VB when ACMPOUT=0. VBDIV = VB * (DIVVB+1)/64.
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:16	DIVVA	0x00	RW	<b>Divider for VA Voltage When ACMPOUT=0</b>  Divider to scale VA when ACMPOUT=0. VADIV = VA * (DIVVA+1)/64.
15:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	HYST	0x0	RW	<b>Hysteresis Select When ACMPOUT=0</b>  Select hysteresis level when comparator output is 0. The hysteresis levels can vary, please see the electrical characteristics for the device for more information.

Value	Mode	Description
0	HYST0	No hysteresis
1	HYST1	14 mV hysteresis
2	HYST2	25 mV hysteresis
3	HYST3	30 mV hysteresis
4	HYST4	35 mV hysteresis
5	HYST5	39 mV hysteresis
6	HYST6	42 mV hysteresis
7	HYST7	45 mV hysteresis
8	HYST8	No hysteresis
9	HYST9	-14 mV hysteresis
10	HYST10	-25 mV hysteresis
11	HYST11	-30 mV hysteresis
12	HYST12	-35 mV hysteresis
13	HYST13	-39 mV hysteresis
14	HYST14	-42 mV hysteresis
15	HYST15	-45 mV hysteresis

#### 26.5.11 ACMPn HYSTERESIS1 - Hysteresis 1 Register

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:24	DIVVB	0x00	RW	<b>Divider for VB Voltage When ACMPOUT=1</b>
				Divider to scale VB when ACMPOUT=1. VBDIV = VB * (DIVVB+1)/64.
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:16	DIVVA	0x00	RW	<b>Divider for VA Voltage When ACMPOUT=1</b>
				Divider to scale VA when ACMPOUT=1. VADIV = VA * (DIVVA+1)/64.
15:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	HYST	0x0	RW	<b>Hysteresis Select When ACMPOUT=1</b>
				Select hysteresis level when comparator output is 1. The hysteresis levels can vary, please see the electrical characteristics for the device for more information.

Value	Mode	Description
0	HYST0	No hysteresis
1	HYST1	14 mV hysteresis
2	HYST2	25 mV hysteresis
3	HYST3	30 mV hysteresis
4	HYST4	35 mV hysteresis
5	HYST5	39 mV hysteresis
6	HYST6	42 mV hysteresis
7	HYST7	45 mV hysteresis
8	HYST8	No hysteresis
9	HYST9	-14 mV hysteresis
10	HYST10	-25 mV hysteresis
11	HYST11	-30 mV hysteresis
12	HYST12	-35 mV hysteresis
13	HYST13	-39 mV hysteresis
14	HYST14	-42 mV hysteresis
15	HYST15	-45 mV hysteresis

### 26.5.12 ACMPn\_ROUTEOPEN - I/O Routing Pine Enable Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	OUTOPEN	0	RW	<b>ACMP Output Pin Enable</b> Enable/disable analog comparator output to pin.

## 26.5.13 ACMPn\_ROUTELOC0 - I/O Routing Location Register

Bit	Name	Reset	Access	Description
31:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:0	OUTLOC	0x00	RW	<b>I/O Location</b> Decides the location of the OUT pin.
Value	Mode			Description
0	LOC0			Location 0
1	LOC1			Location 1
2	LOC2			Location 2
3	LOC3			Location 3
4	LOC4			Location 4
5	LOC5			Location 5
6	LOC6			Location 6
7	LOC7			Location 7



## 26.5.14 ACMPn\_EXTIFCTRL - External Override Interface Control

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																															
Access	RW																															
Name	APORTSEL																															
EN																																

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:4	APORTSEL	0x0	RW	<b>APORT Selection for External Interface</b>
		Decides which APORt(s) the ACMP will use when controlled by an external module.		
	Value	Mode	Description	
	0	APORT0X	APORT0X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT0XCH0.	
	1	APORT0Y	APORT0Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT0YCH0.	
	2	APORT1X	APORT1X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT1XCH0.	
	3	APORT1Y	APORT1Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT1YCH0.	
	4	APORT1XY	APORT1X/Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT1XCH0.	
	5	APORT2X	APORT2X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT2XCH0.	
	6	APORT2Y	APORT2Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT2YCH0.	
	7	APORT2YX	APORT2Y/X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT2YCH0.	
	8	APORT3X	APORT3X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT3XCH0.	
	9	APORT3Y	APORT3Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT3YCH0.	
	10	APORT3XY	APORT3X/Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT3XCH0.	
	11	APORT4X	APORT4X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT4YCH0.	
	12	APORT4Y	APORT4Y used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT4YCH0.	
	13	APORT4YX	APORT4Y/X used. EXT_BASE = ACMP_INPUTSEL_POS_SEL_AP0RT4YCH0.	

Bit	Name	Reset	Access	Description
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EN	0	RW	<b>Enable External Interface</b>  Set to enable an external module, like LESENSE, to control the ACMP

## 27. ADC - Analog to Digital Converter



### Quick Facts

#### What?

The ADC is used to convert analog signals into a digital representation and features low-power, autonomous operation.

#### Why?

In many applications there is a need to measure analog signals and record them in a digital representation, without exhausting the energy source.

#### How?

A low power ADC samples up to 32 input channels in a programmable sequence. With the help of PRS and DMA, the ADC can operate without CPU intervention in EM2 DeepSleep and EM3 Stop, minimizing the number of powered up resources. The ADC can further be duty-cycled to reduce the energy consumption.

### 27.1 Introduction

The ADC uses a Successive Approximation Register (SAR) architecture, with a resolution of up to 12 bits at up to one million samples per second (1 Msps). The integrated input multiplexer can select from external I/Os and several internal signals.


## 27.2 Features

- Programmable resolution (6/8/12-bit)
  - 13 conversion clock cycles for a 12-bit conversion
  - Maximum 1 Msps @ 12-bit
  - Maximum 1.6 Msps @ 6-bit
- Configurable acquisition time
- Externally controllable conversion start time using PRS in TIMED mode
- Integrated prescaler for conversion clock generation
  - Selectable clock division factor from 1 to 128
- Wide conversion clock range: 32 kHz to 16 MHz
- Can be run during EM2 DeepSleep and EM3 Stop, waking up the system upon various enabled interrupts
- Can be run during EM2 DeepSleep and EM3 Stop with DMA enabled to pull data from the FIFOs without waking up the system
- Supports up to 144 external input channels and several internal inputs
  - Includes temperature sensor and random number generator function
- Left or right adjusted results
  - Results in 2's complement representation
  - Differential results sign extended to 32-bits results
- Programmable scan sequence
  - Up to 32 configurable samples in scan sequence
  - Mask to select which pins are included in the sequence
  - Triggered by software or PRS input
  - One shot or repetitive mode
  - Oversampling available
  - Four deep FIFO to store conversion data along with channel ID and option to overwrite old data when full
  - Programmable watermark (DVL) to generate SCAN interrupt
  - Supports overflow and underflow interrupt generation
  - Supports window compare function
  - Conversion tailgating support for predictable periodic scans
- Programmable single channel conversion
  - Triggered by software or PRS input
  - Can be interleaved between two scan sequences
  - One shot or repetitive mode
  - Oversampling available
  - Four deep FIFO to store conversion data with option to overwrite old data when full
  - programmable watermark (DVL) to generate SINGLE interrupt
  - Supports overflow and underflow interrupt generation
  - Supports window compare function
- Hardware oversampling support
  - 1st order accumulate and dump filter
  - From 2 to 4096 oversampling ratio (OSR)
  - Results in 16-bit representation
  - Enabled individually for scan sequence and single channel mode
  - Common OSR select
- Programmable and preset input full scale (peak-to-peak) range (VFS) with selectable reference sources
  - VFS=1.25 V using internal VBGR reference
  - VFS=2.5 V using internal VBGR reference
  - VFS=AVDD with AVDD as reference source
  - VFS=5 V with internal VBGR reference
  - Single ended external reference
  - Differential external reference
  - VFS=2xAVDD with AVDD as reference source
  - User-programmable dividers for flexible VFS options from internal, external or supply voltage reference sources

- Support for offset and gain calibration
- Interrupt generation and/or DMA request when
  - Programmable number of converted data available in the single FIFO (also generates DMA request)
  - Programmable number of converted data available in the scan FIFO (also generates DMA request)
  - Single FIFO overflow or underflow
  - Scan FIFO overflow or underflow
  - Latest Single conversion tripped compare logic
  - Latest Scan conversion tripped compare logic
  - Analog over-voltage interrupt
  - Programming Error interrupt due to APORT Bus Request conflict or NEGSEL programming error

### 27.3 Functional Description

An overview of the ADC is shown in [Figure 27.1 ADC Overview on page 912](#).



**Figure 27.1. ADC Overview**

### 27.3.1 Clock Selection

The ADC logic is partitioned into two clock domains: HFFPERCCLK and ADC\_CLK. The HFFPERCCLK domain contains the register interface logic, APORt request logic and portions of FIFO read logic. The HFFPERCCLK is the default clock for the ADC peripheral. The rest of the ADC is clocked by the ADC\_CLK domain. The ADC\_CLK is chosen by ADCCLKMODE bit in the ADCn\_CTRL register.

The ADC\_CLK is the main clock for the ADC engine. If the ADCCLKMODE is set to SYNC, the ADC\_CLK is equal to the HFFPERCCLK and the ADC operates in synchronous mode. If the ADCCLKMODE is set to ASYNC, the ADC\_CLK is ASYNCCLK and the ADC operates in asynchronous mode. This distinction is important to understand as there are additional system restrictions and benefits to running the ADC in asynchronous mode detailed in [27.3.15 ASYNC ADC\\_CLK Usage Restrictions and Benefits](#).

**Note:** Whenever ADC is being used in asynchronous mode, then HFFPERCLK must be at least 1.5 times higher than the ADC\_CLK.

The ADC has an internal clock prescaler, controlled by PRESC bits in ADCn\_CTRL, which can divide the ADC\_CLK by any factor between 1 and 128 to generate the conversion clock (adc\_clk\_sar) for the ADC. This adc\_clk\_sar is also used to generate acquisition timing. Note that the maximum clock frequency for adc\_clk\_sar is 16 MHz. The ADC warmup time is determined by ADC\_CLK and not by adc\_clk\_sar.

ASYNCCLK is a clock source from the CMU which is considered asynchronous to HFFPERCCLK. The CMU\_ADCCTRL register can be programmed to request and use ASYNCCLK. It has multiple choices for its source, including AUXHFRCO, HFxo and HFSRCCLK, and can optionally be inverted. If the chosen source for ASYNCCLK is not active at the time of request, the CMU enables the source oscillator upon receiving the request, and shuts down the oscillator when the ADC stops requesting the clock. Consult the CMU chapter for details of how to program the clock sources for the ASYNCCLK and oscillator start-up time details.

Software may choose a clock request generation scheme by programming the ASYNCCLKEN and WARMMODE of the ADCn\_CTRL register. If the ASYNCCLKEN is set to ASNEEDED with WARMMODE set to NORMAL, the ADC requests ASYNCCLK only when a conversion trigger is activated. The ASYNCCLK request is withdrawn after the conversion is complete. All other options keep the ASYNCCLK request "ON" until software programs these fields otherwise or changes the ADCCLKMODE to SYNC.

For EM2 DeepSleep or EM3 Stop operation of the ADC, the ADC\_CLK must be configured for AUXHFRCO as this is the only available option during EM2 DeepSleep or EM3 Stop. The ADC\_CLK source should not be changed as the system enters or exits various energy modes, otherwise measurement inaccuracies will result.

### 27.3.2 Conversions

A conversion consists of two phases: acquisition and approximation. The input is sampled in the acquisition phase before it is converted to digital representation during the approximation phase. The acquisition time can be configured independently for scan sequence and single channel conversions (see [27.3.3 ADC Modes](#)) by setting AT in ADCn\_SINGLECTRL/ADCn\_SCANCTRL. The acquisition times can be set to 1, 2, 3 or any integer power of 2 from 4 to 256 adc\_clk\_sar cycles.


**Note:** For high impedance sources the acquisition time should be adjusted to allow enough time for the internal sample capacitor to fully charge. The minimum acquisition time for sampling at 1 Msps and typical input loading is 187.5 ns.

The ADC uses one adc\_clk\_sar cycle per output bit in the approximation phase plus 1 extra adc\_clk\_sar cycle.

$$T_{conv} = (T_{acq} + (N + 1) \times T_{adc\_clk\_sar}) \times OVSSEL$$

Where  $T_{acq}$  is the acquisition time set by the AT bit field, N is the resolution (in bits), and OVSSEL is the oversampling ratio according to the OVSSEL field in ADCn\_CTRL when oversampling is enabled (see [27.3.10.6 Oversampling](#)).

**Figure 27.2. ADC Total Conversion Time Per Output**



**Figure 27.3. ADC Conversion Timing**

### 27.3.3 ADC Modes

The ADC contains two programmable modes: single channel mode and scan mode. Both modes have separate configuration registers and a four-deep FIFO for conversion results. Both modes may be set up to run only once per trigger or to automatically repeat after each operation. The scan mode has priority over the single channel mode. However by default, if scan sequence is running, a triggered single channel conversion will be interleaved between two scan samples.

#### 27.3.3.1 Single Channel Mode

Single channel mode can be used to convert a single channel either once per trigger or repetitively. The configuration of single channel mode is done using the ADCn\_SINGLECTRL and ADCn\_SINGLECTRLX registers and the result FIFO can be read through the ADCn\_SINGLEDATA register. The DVL field of the ADCn\_SINGLECTRLX controls the FIFO watermark crossing which sets the SINGLEDV bit in ADCn\_STATUS high and is cleared when the data is read and the number of unread data samples falls below the DVL threshold. The user can choose to throw out new samples or overwrite the old samples when the FIFO becomes full by programming the FIFOFACT field of the ADCn\_SINGLECTRLX register. Single channel results can also be read through ADCn\_SINGLEDATAP without popping the FIFO, returning its latest element. The DIFF field in ADCn\_SINGLECTRL selects whether differential or single ended inputs are used and POSSEL and NEGSEL selects the input signal(s). The CMPEN bit in the ADCn\_SINGLECTRL register enables the window compare function, and the latest converted data is compared against values programmed into the ADGT and ADLT fields of the ADCn\_CMPTHR register and generates SINGLECMP interrupts if enabled. The window compare function allows for compare triggering both within (if ADGT less than ADLT) or out of (if ADGT greater than ADLT) window.

#### 27.3.3.2 Scan Mode

Scan mode is used to perform conversions across multiple channels, sweeping a set of selected inputs in a sequence. The configuration of scan mode is done in the ADCn\_SCANCTRL and ADCn\_SCANCTRLX registers. It has similar controls and data read mechanisms to single channel mode. There are two key differences between single channel mode and scan mode: the input sequence is programmed differently, and it has additional information in the result to indicate the channel on which the conversion was acquired. [27.3.7 Input Selection](#) explains how the input sequence is chosen. When the scan sequence is triggered, the ADC samples all inputs that are included in the mask (ADCn\_SCANMASK), starting at the lowest pin number. DIFF in ADCn\_SCANCTRL selects whether single ended or differential inputs are used. The FIFO data is tagged with SCANINPUTID and can be read along with the scan data using ADCn\_SCANDATA register. The ADCn\_SCANDATAP can be used to read the latest valid entry from the scan FIFO without popping it. There is also a ADCn\_SCANDATA register that contains results without the SCANINPUTID appended.

**Note:** If using scan mode with ADCn\_SCANCTRL\_REP = 1 and ADCn\_SCANCTRLX\_REPDELAY = NODELAY, the last channel in the scan will report a SCANINPUTID of 0. Using ADCn\_SCANCTRLX\_REPDELAY with any value other than NODELAY will report the correct SCANINPUTID.

#### 27.3.4 Warm-up Time

After power-on, the ADC requires some time for internal bias currents and references to settle prior to starting a conversion. This time period is called the warm-up time. Warm-up timing is performed by hardware. Software must program the number of ADC\_CLK cycles required to count at least 1  $\mu$ s in the TIMEBASE field of the ADCn\_CTRL register. TIMEBASE only affects the timing of the warm-up sequence and is not dependent on adc\_clk\_sar. When enabling the ADC or changing references between samples, the ADC is automatically warmed up for 5  $\mu$ s (5 times the period indicated by TIMEBASE).

Normally, the ADC will be warmed up only when samples are requested and is shut off when there are no more samples waiting. However, if lower latency is needed, configuring the WARMUPMODE field in ADCn\_CTRL allows the ADC and/or reference to stay warm between samples, reducing the warm-up time or eliminating it altogether. [Figure 27.4 ADC Analog Power Consumption With Different WARMUPMODE Settings on page 916](#) shows the effects on analog power consumption in scenarios using different WARMUPMODE settings.


The user can program which reference should be kept warm in the CHCONREFWARMIDLE bitfield in the ADCn\_CTRL register. By default the scan mode reference is kept warm. The user can also choose to keep the single channel mode reference warm or to keep the last used reference warm. If the default setting is kept (scan mode reference is to be kept warm) and if the single-mode reference setting is different than scan-mode, then single mode conversions will first warmup its reference for 5  $\mu$ s before a conversion can begin.

Various warmup modes are described here:

- **NORMAL:** This is the lowest power option for general-purpose use and low sampling rates (below 35 ksp). The ADC and references are shut off when there are no samples waiting. The ADC does not consume any power when it is shut down. A 5  $\mu$ s warmup time will be initiated prior to every conversion. Figure a in [Figure 27.4 ADC Analog Power Consumption With Different WARMUPMODE Settings on page 916](#) shows this mode.
- **KEEPINSTANDBY:** This mode is suitable for infrequent sampling of lower impedance inputs, and is the lowest power option for sampling rates between about 35 and 125 ksp. It may also be useful for lower sampling rates where latency is important. The reference selected for scan mode is kept warm, but the ADC is powered down. The ADC will initiate a 1  $\mu$ s warmup period before a conversion begins. Because the reference is kept warm, the ADC will consume a small amount of standby current when it is not converting. Figure b in [Figure 27.4 ADC Analog Power Consumption With Different WARMUPMODE Settings on page 916](#) shows this mode.
- **KEEPINSLOWACC:** This mode is useful for high-impedance inputs which are sampled infrequently. It is similar to KEEPINSTANDBY, but continuously tracks the input, keeping the input multiplexer connected to the APOR bus. This mode consumes little more power than KEEPINSTANDBY mode (about 2  $\mu$ A extra) when a conversion is not in progress. This allows the user to avoid programming long acquisition time that would otherwise be necessary for high-impedance inputs when ADC wakes up to full power mode, thereby reducing the total current consumption per conversion.
- **KEEPADCWARM:** This mode provides the lowest latency and allows for maximum sampling rates. The ADC and reference circuitry remain powered on even when conversions are not in progress. Figure c in [Figure 27.4 ADC Analog Power Consumption With Different WARMUPMODE Settings on page 916](#) shows this mode. This mode consumes the most power, but as soon as a trigger event occurs, the acquisition and conversion begin with no warm-up time. Note that if KEEPADCWARM mode is set and HFXO is selected as the ADC clock source, the HFXO will remain on in EM2.

When KEEPADCWARM is chosen, ADC is termed as being in continuous operation. When any other warmup mode is chosen, ADC is termed to be in duty-cycled operation.

When entering EM2 DeepSleep or EM3 Stop, if the ADC is not going to be used, it should be returned to an idle state and WARMUPMODE in ADCn\_CTRL written to 0. Refer to [27.3.17 ADC Programming Model](#) for more information on placing the ADC in an idle state. If the ADC is going to be used in these low energy modes, the user can use any of the WARMUPMODE settings, but should be mindful of the power consumption that comes along with the different mode settings. For EM2 DeepSleep or EM3 Stop operation, the ADC clock source must be configured to use AUXHFRCO.



**Figure 27.4. ADC Analog Power Consumption With Different WARMUPMODE Settings**

**Note:** When using any warm-up mode other than NORMAL, always switch back to the NORMAL mode before switching to another warm-up mode.

### 27.3.5 Power Supply

The ADC block power ( $V_{ADC}$ ) is derived from the VDDX\_ANA supply rail. VDDX\_ANA can be selected from the AVDD or DVDD supply pins using the EMU\_PWRCTRL\_ANASW bit field.

### 27.3.6 Input Pin Considerations

For external ADC inputs routed through the APOR, the maximum supported analog input voltage will be limited to the  $\text{MIN}(V_{ADC}, \text{IOVDD})$  (where  $V_{ADC}$  is VDDX\_ANA, as described in [27.3.5 Power Supply](#)). Note that pins configured as ADC inputs should disable OVT (by setting the corresponding GPIO\_Px\_OVTDIS bit) to reduce any potential distortion introduced by the OVT circuitry.


ADC external reference inputs are not routed through the APOR, and the maximum supported analog input voltage for an external reference will also be limited to the  $\text{MIN}(V_{ADC}, \text{IOVDD})$ .

### 27.3.7 Input Selection

The ADC samples and converts the analog voltage differential at its positive and negative voltage inputs. The input multiplexers of the ADC can connect these inputs to one of several internal nodes (e.g., temperature sensor) or to external signals via analog ports (APORT0, APOR1, APORT2, APORT3 or APORT4).

The analog ports APORT1, APORT2, APORT3, and APORT4 connect to external pins via analog buses (BUSAX, BUSAY, BUSBX, etc.) which are shared among other analog peripherals on the device. APORT1 through APORT4 are each 32 channels wide with connections to two sub-buses: a 16-channel X bus and a 16-channel Y bus. In the ADC module, all X buses connect to the INP\_MUX and all Y buses connect to the INN\_MUX as shown in [Figure 27.5 APORT Connection to the ADC on page 917](#). Connections to the X and Y sub-buses alternate channels on the APORT. On APORT1 and APORT3, even-numbered channels connect to the X bus, and odd-numbered channels connect to the Y bus. On APORT2 and APORT4, even-numbered channels connect to the Y bus and odd-numbered channels connect to the X bus. The APORT to BUS mappings may vary from device to device. Refer to the APORT Client Map in the device data sheet for exact mappings.

Unlike APORT1 through APORT4, APORT0 is not a shared resource. It consists of a 16-channel X bus and a 16-channel Y bus, each with dedicated I/O pin connections. Note that APORT0 is not available on all device families.



**Figure 27.5. APORT Connection to the ADC**

For differential measurements, one input must be chosen from an X bus and the other from a Y bus. Choosing both inputs from an X bus or both from a Y bus will generate a PROGERR interrupt (if enabled) of NEGSELCONF type. The PROGERR type can be checked in the ADCn\_STATUS register.

The mapping and availability for external I/O connections to ADC0 inputs is shown in device data sheet.

Multiple peripherals may request the same shared system bus (BUSAX, BUSAY, BUSBX, etc.). When this happens, a conflict status is generated and that bus is kept floating. If this happens with the ADC, the PROGERR field in ADCn\_STATUS is set to BUSCONF, and an interrupt may be generated (if enabled). When connecting dedicated I/Os through APORTo, all inputs are available to APORToX and APORToY and no bus conflict is possible. Refer to [27.3.7.3 APORt Conflicts](#) for more information on identifying and resolving bus conflicts.

**Note:** The internal inputs can only be sampled in single channel, single-ended mode. NEGSEL should be fixed to VSS for these conversions.

#### 27.3.7.1 Configuring ADC Inputs in Single Channel Mode

In single channel mode, the ADCn\_SINGLECTRL register provides the POSSEL and NEGSEL selection for positive and negative channel selection of the ADC. The APORt Client Map provides external pin to internal bus channel mapping enumeration for a particular device. Software can also choose internal nodes for POSSEL.

For single-ended conversions on external (APORt-connected) signals, POSSEL and NEGSEL are fully configurable. However, when performing conversions on internal signals, NEGSEL must be set to VSS. This NEGSEL reconfigurability feature in single-ended mode may not be available in all devices. If compatibility with devices that do not support this feature is desired, NEGSEL should be set to VSS for all single channel single-ended conversions.

Note that in both the POSSEL and NEGSEL fields, it is possible to choose inputs from both X and Y buses, even though X channels are physically connected to the positive mux (INP\_MUX) and Y channels are physically connected to the negative mux (INN\_MUX). For single-ended operation (DIFF = 0), if the positive input is chosen from a Y channel the ADC performs a negative single ended conversion and automatically inverts the result at the end, producing a positive result. For differential conversions (DIFF = 1), if a Y channel is chosen for the positive input and an X channel is chosen for the negative input, the ADC result will be inverted to produce the correct polarity.

Refer to device-specific data sheet for specific pin connection options. Note that the same I/O pin may appear in multiple locations.

### 27.3.7.2 Configuring ADC Inputs in Scan Mode

In scan mode, the ADC can sample and convert up to 32 external channels on each conversion trigger. Internal channels are not available in scan mode. The ADC's scanner logic automatically changes the input mux settings between conversions, eliminating the need for firmware intervention.

The ADC scanner logic is controlled by a set of 32 logical channels called SCANINPUTIDs. The 32 SCANINPUTIDs are arranged in four groups of 8 channels each. Each channel group can point to a predefined series of 8 sequential channels on any of the available APORTs. The ADCn\_SCANINPUTSEL register is used to configure which group of physical APORt channels each of the SCANINPUTID channel groups map to. For example, selecting APORT1CH16TOCH23 in the INPUT7TO0SEL field selects APORT1CH16 for SCANINPUTID0, APORT1CH17 for SCANINPUTID1, APORT1CH18 for SCANINPUTID2, and so on.

The four SCANINPUTID groups are fully independent and may be selected from any APORT in any combination. It is possible also to repeat the same selection in multiple groups. For example, the user may select APORT2CH0TOCH7 for all four of the SCANINPUTID groups.

In many cases, the user application will not require all 32 channels of the scanner to be converted. Each of the scanner channels may be individually enabled according to the needs of the system. The ADCn\_SCANMASK register is used to enable and disable individual SCANINPUTIDs. The bits in the ADCnSCANMASK register correspond one-to-one with the SCANINPUTID channel numbers. During a scan operation, the ADC scanner logic will convert only the enabled SCANINPUTIDs, in order from lowest to highest.

In single-ended mode, all conversions performed by the ADC will be relative to VSS. For any enabled SCANINPUTID, the selected APORT channel will be connected to the ADC with the opposite ADC input terminal connected to VSS. Note that the channel groups selected in ADCn\_SCANINPUTSEL point to a block of 8 channels on an APORT, which includes both X and Y channels. Depending on the channels enabled by ADCn\_SCANMASK, the ADC may perform conversions on the X or the Y bus associated with that APORT.

[Figure 27.6 ADC Single-ended Scan Mode Example on page 919](#) shows an example of a single-ended scan configuration. In this example, ADCn\_SCANINPUTSEL has been configured to place APORT1CH16TO23 in the first, third, and fourth channel groups. APORT4CH8TO15 has been placed in the second channel group. ADCn\_SCANMASK selects six of these channels for inclusion in the scan. When an ADC scan is initiated with this configuration, the ADC begins at SCANINPUTID0 and converts each enabled channel in turn. This scan configuration results in a set of six single-ended ADC conversions: PF0, PF3, PA5, PA5, PF7, and PF4.

SCANINPUTSEL	APORT1CH16TO23				APORT1CH16TO23				APORT4CH8TO15				APORT1CH16TO23			
APORT-Channel	1-23	1-22	1-21	1-20	1-19	1-18	1-17	1-16	1-23	1-22	1-21	1-20	1-19	1-18	1-17	1-16
I/O Pin	PF7	PF6	PF5	PF4	PF3	PF2	PF1	PF0	PF7	PF6	PF5	PF4	PF3	PF2	PF1	PF0
SCANMASK	0	0	0	1	0	0	0	0	0	0	0	0	0	1	1	0
SCANINPUTID	31				24	23			16	15			8	7		0

**Figure 27.6. ADC Single-ended Scan Mode Example**

In differential mode, the default operation of the ADC scanner is to perform a differential measurement between the selected APORT channel and the next channel on that APORT. For example, if the enabled SCANINPUTID points to APORT1CH6, the ADC will perform a differential conversion between APORT1CH6 and APORT1CH7.

There are two exceptions to this rule, listed in order of precedence:

1. When converting SCANINPUTID15, the differential conversion will be performed between the channel selected by SCANINPUTID15 and the channel selected by SCANINPUTID8.
2. When APORTnCH31 is the selected input, the differential conversion will be performed between APORTnCH31 and APORTnCH0.

[Figure 27.7 ADC Differential Scan Mode Example on page 920](#) shows an example of a differential scan configuration. In this example, ADCn\_SCANINPUTSEL has been configured to place APORT1CH16TO23 in the first, third, and fourth channel groups. APORT4CH8TO15 has been placed in the second channel group. ADCn\_SCANMASK selects three channels pairs for inclusion in the scan. When an ADC scan is initiated with this configuration, the ADC begins at SCANINPUTID0 and converts each enabled channel in turn. This scan configuration results in a set of three differential ADC conversions: PF0-PF1, PF2-PF3, and PA4-PA5.

SCANINPUTSEL	APORT1CH16TO23				APORT1CH16TO23				APORT4CH8TO15				APORT1CH16TO23			
	PF7-none	PF6-PF7	PF5-PF6	PF4-PF5	PF3-PF4	PF2-PF3	PF1-PF2	PF0-PF1	PF7-none	PF6-PF7	PF5-PF6	PF4-PF5	PF3-PF4	PF2-PF3	PF1-PF2	PF0-PF1
APORT-Channel (Positive)	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
APORT-Channel (Negative)	1-23	1-22	1-21	1-20	1-19	1-18	1-17	1-16	1-23	1-22	1-21	1-20	1-19	1-18	1-17	1-16
I/O Differential																
SCANMASK	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
SCANINPUTID	31	24	23	16	15	8	7	0	31	24	23	16	15	8	7	0

Figure 27.7. ADC Differential Scan Mode Example

In certain applications it may be desirable to perform differential conversions on several channels against a common voltage. The ADCn\_SCANNEGSEL register allows eight of the SCANINPUTIDs to re-map the negative terminal of a differential conversion to a common channel. In the first ADCn\_SCANINPUTSEL group, the negative input for SCANINPUT 0, 2, 4, and 6 may be re-mapped to any of the odd-numbered channels in that group (SCANINPUT 1, 3, 5, or 7). Likewise, in the second ADCn\_SCANINPUTSEL group, the negative input for SCANINPUT 9, 11, 13, and 15 may be re-mapped to any of the even-numbered channels in that group (SCANINPUT 8, 10, 12, or 14).

Figure 27.8 ADC Differential Scan Mode Re-mapping Negative Input Selections on page 920 shows the effects of the ADCn\_SCANNEGSEL register on the re-mappable inputs. The left side of the figure shows the default channel mapping, and the right side of the figure shows how ADCn\_SCANNEGSEL can be programmed to map the same negative input on up to four channels.

SCANINPUTSEL	Default SCANNEGSEL Selections								Re-mapped using SCANNEGSEL								
	APORT1CH16TO23				APORT1CH16TO23				APORT1CH16TO23				APORT1CH16TO23				
APORT-Channel (Positive)	1-16	1-23	1-22	1-21	1-22	1-21	1-20	1-19	1-22	1-21	1-20	1-19	1-22	1-21	1-20	1-19	
APORT-Channel (Negative)	0	PF7-PF0	PF6-PF7	PF5-PF6	PF4-PF5	PF3-PF4	PF2-PF3	PF1-PF2	PF0-PF1	PF7-PF6	PF6-PF5	PF5-PF4	PF4-PF3	PF3-PF2	PF2-PF1	PF1-PF0	PF0-PF1
SCANNEGSEL																	
I/O Differential																	
SCANINPUTID	15	8	7	0	15	8	7	0	15	8	7	0	15	8	7	0	

Figure 27.8. ADC Differential Scan Mode Re-mapping Negative Input Selections

### 27.3.7.3 APORt Conflicts

The ADC shares common analog buses connected to its APORtS (1-4) with other analog peripherals (see device-specific data sheet). As the ADC performs single or scan conversions, it requests the shared buses and sends selections for the control switches to connect the desired I/O pins. If another analog peripheral requests the same shared bus at the same time, there will be a collision and none of the peripherals will be granted control of that bus.

To help debug over-utilization of APORt resources, the ADC hardware provides status information in local registers. The ADCn\_APORtREQ register gives the user visibility into which APORt(s) the ADC is requesting given the setting of the input selection registers. ADCn\_APORtCONFLICT reports any conflicts that occur. If PROGERR in ADCn\_IEN is set, any conflict generates an interrupt. The PROGERR field in the ADCn\_STATUS register indicates whether the programming error happened as a result of an APORt bus conflict (BUSCONF) or from a negative-input selection conflict (NEGSELCONF). If the PROGERR interrupt occurred due to a negative selection conflict, then the interrupt can be cleared by software only after correcting the conflict. If a software clear is attempted without correcting the configuration, the interrupt will be cleared for one clock cycle but then it will trigger again as the invalid configuration still persists.

**Note:** The ADC requests shared bus connections as soon as that bus is selected in the input select registers, even if the ADC is not performing any conversions. This means that by using the APORt request, the ADC will acquire the associated shared analog bus, preventing other peripherals from using it. The bus will be released only when the input select registers are changed.

It is possible for the ADC to passively monitor shared bus signals without controlling the switches and creating bus conflicts. This can be done by setting the ADCn\_APORtMASTERDIS register. When ADCn\_APORtMASTERDIS is used, channel selection defers to the peripheral acting as the bus master for that shared bus, and no bus conflict will occur. The ADC will connect its input to the shared bus, but the specific channel will be controlled by the peripheral designated as the bus master.

### 27.3.8 Reference Selection and Input Range Definition

The full scale voltage (VFS) of the ADC is defined as the full input range, from the lowest possible input voltage to the highest. For single-ended conversions, the input range on the selected positive input is from 0 to VFS. For differential conversions, the input to the converter is the difference between the positive and negative input selections. This can range from  $-VFS/2$  to  $+VFS/2$ .

VFS for the converter is determined by a combination of the selected voltage reference (VREF) and programmable divider circuits on the ADC input and voltage reference paths. Users have full control over the VREF and divider selections, offering a very flexible and wide selection of VFS values. In most applications however, it is not necessary to adjust VFS beyond a set of common pre-defined choices. For the simplest VFS configuration, refer to [27.3.8.1 Basic Full-Scale Voltage Configuration](#). If the application requires a VFS configuration not available in the pre-defined choices, [27.3.8.2 Advanced Full-Scale Voltage Configuration](#) covers additional configuration options.

### 27.3.8.1 Basic Full-Scale Voltage Configuration

Basic configuration of the VFS (full scale voltage) for the converter is done by programming the REF bitfield in ADCn\_SINGLECTRL (for single channel mode) or ADCn\_SCANCTRL (for scan mode) to any of the pre-defined options. The list of available pre-defined VFS options is:

- VFS = 1.25 V using internal VBGR as the reference source
- VFS = 2.5 V using internal VBGR as the reference source
- VFS = AVDD using AVDD as the reference source ( $AVDD \leq 3.6\text{ V}$ )
- VFS = 5 V using internal VBGR as the reference source
- VFS = ADCn\_EXTP external pin as a single-ended reference source (1.2 V - 3.6 V)
- VFS = ADCn\_EXTP - ADCnEXTN external pins as a differential reference source. ( 1.2 V - 3.6 V difference)
- VFS = 2 x AVDD using AVDD as the reference source ( $AVDD \leq 3.6\text{ V}$ )

The maximum and minimum input voltage which the ADC can recognize at any external pin is limited to the minimum of the  $V_{ADC}$  and  $IOVDD$  supply voltages (where  $V_{ADC}$  is  $VDDX\_ANA$ , as described in [27.3.5 Power Supply](#)). If VFS is configured to be larger than the supply range, the full ADC range will not be available. For example, with a 3.3 V supply and VFS configured to 5 V, the input voltage for single-ended conversions will be limited to 0 to 3.3 V, though the effective VFS is still 5 V.

The ADC uses a chip-level bias circuit to provide bias current for its operation. For highest accuracy when using a VBGR-derived internal bandgap reference source, GPBIASACC in ADCn\_BIASPROG should be cleared to 0 (HIGHACC). This will allow the ADC to enable high-accuracy mode from the bias circuitry during conversions. When AVDD or an external pin reference option is used, software may set GPBIASACC in ADCn\_BIASPROG to 1 (LOWACC) to conserve energy. Note that VDAC and dc-dc usage may also switch the chip-level bias to high-accuracy mode (even if GPBIASACC is set to LOWACC), potentially impacting ADC results. For example, if ADC is doing a conversion with GPBIASACC set to LOWACC and VDAC also starts a conversion using the internal low noise reference, then the chip-level bias circuit will be automatically switched to high-accuracy mode (potentially corrupting results of the on-going ADC conversion). Similarly, dc-dc startup automatically switches the chip-level bias circuit to high-accuracy mode for a short time, i.e., if dc-dc startup happens when ADC is doing a conversion (with GPBIASACC set to LOWACC), ADC results may get corrupted. DC-DC startup automatically switches the bias circuit to high-accuracy mode for 25  $\mu\text{s}$ . It is during this time that ADC conversions with the GPBIASACC set to LOWACC should be avoided.

If the pre-defined VFS options do not suit the particular application, refer to [27.3.8.2 Advanced Full-Scale Voltage Configuration](#) for more advanced VFS options.

### 27.3.8.2 Advanced Full-Scale Voltage Configuration

For most applications, the pre-defined VFS options described in [27.3.8.1 Basic Full-Scale Voltage Configuration](#) are suitable. Advanced VFS configurations are also possible by programming the REF bitfield in ADCn\_SINGLECTRL or ADCn\_SCANCTRL to the CONF option. Programming the REF bitfield to CONF allows the user to select the specific VREF source and adjust the programmable input and reference divider options directly.

The general procedure for programming an advanced VFS configuration is as follows:

1. Select the voltage reference source using VREFSEL.
2. Configure VREFATTFIX and VREFATT so that the reference voltage at the ADC is between 0.7 and 1.05 V.
3. Configure VINATT to achieve the desired full-scale voltage.

The VREFSEL field in ADCn\_SINGLECTRLX or ADCn\_SCANCTRLX selects the voltage reference source. The ADC can choose from the following voltage reference (VREF) sources:

- VBGR: An internal 0.83 V bandgap reference voltage. This is the most precise internal reference source available.
- VDDXWATT: An attenuated version of the AVDD supply voltage. The attenuation factor is determined by the VREFATTFIX and/or VREFATT bit fields.
- VREFPWATT: An external reference source applied to the ADCn\_EXTP pin, and attenuated by the attenuation factor (determined by the VREFATTFIX and/or VREFATT bit fields). This is the appropriate choice for external reference inputs greater than 1.05 V.
- VREFP: An external reference source applied to the ADCn\_EXTP pin, without any attenuation. This is the appropriate choice for external reference inputs between 0.7 V and 1.05 V.
- VENTROPY: A very low internal reference voltage (approx. 0.1 V). This option is intended to be used only with the ADC inputs tied internally to VSS, for generating random noise at the ADC output.
- VREFPNWATT: A differential version of VREFPWATT, with the reference source applied to the ADCn\_EXTP and ADCn\_EXTN pins and attenuated. This is the appropriate choice where a differential reference of greater than 1.05 V is required.
- VREFPN: A differential version of VREFP, with the reference source applied to the ADCn\_EXTP and ADCn\_EXTN pins and no attenuation. This is the appropriate choice where a differential reference of between 0.7 V and 1.05 V is required.
- VBGRLOW: An internal 0.78 V bandgap reference voltage.

The ADC reference voltage should be attenuated to a lower voltage when using AVDD or the external reference source. A simple method for a wide range of reference sources is to set VREFATTFIX to 1. The VREF attenuation factor ( $ATT_{VREF}$ ) can then be selected between 1/3 (when VREFATT is greater than 0), and 1/4 (when VREFATT is equal to 0). For reference sources between 1.2 V and 3.6 V,  $ATT_{VREF} = 1/3$  is the best choice.  $ATT_{VREF} = 1/4$  can be used with references from 1.6 V to 3.8 V, with slight performance degradation.

Finer granularity on  $ATT_{VREF}$  is possible as well, by clearing VREFATTFIX to 0, and setting the VREFATT field. For optimal performance with  $VREFATTFIX = 0$ , the attenuated ADC reference input should be limited to between 0.7 V and 1.05 V. When VREFATTFIX is cleared to 0,  $ATT_{VREF}$  is set according to the equation:

$$ATT_{VREF} = (VREFATT + 6) / 24 \text{ for } VREFATT < 13, \text{ and } (VREFATT - 3) / 12 \text{ for } VREFATT \geq 13$$

**Figure 27.9.  $ATT_{VREF}$ : VREF Attenuation Factor**

The ADC input also includes a programmable attenuator. The VIN attenuator is used to widen the available input range of the ADC beyond the reference source. The VIN attenuation factor ( $ATT_{VIN}$ ) is determined by the VINATT field according to the equation:

$$ATT_{VIN} = VINATT / 12 \text{ for } VINATT \geq 3 \text{ (settings 0, 1, and 2 are not allowable values for VINATT)}$$

**Figure 27.10.  $ATT_{VIN}$ : VIN Attenuation Factor**

VFS can be calculated by the formula given below for any given VREF source, VREF attenuation, and VIN attenuation:

$$VFS = 2 \times VREF \times ATT_{VREF} / ATT_{VIN}$$

VREF is selected in the VREFSEL bitfield, and

$ATT_{VREF}$  is the VREF attenuation factor, determined by VREFATT or VREFATTFIX

$ATT_{VIN}$  is the VIN attenuation factor, determined by VINATT

**Figure 27.11. VFS: Full-Scale Input Range**

The maximum and minimum input voltage which the ADC can recognize at any external pin is limited to the minimum of the  $V_{ADC}$  and  $IOVDD$  supply voltages (where  $V_{ADC}$  is  $VDDX\_ANA$ , as described in [27.3.5 Power Supply](#)). If VFS is configured to be larger than the supply range, the full ADC range will not be available. For example, with a 3.3 V supply and VFS configured to 5 V, the input voltage for single-ended conversions will be limited to 0 to 3.3 V, though the effective VFS is still 5 V.

The ADC uses a chip-level bias circuit to provide bias current for its operation. For highest accuracy when using a VBGR-derived internal bandgap reference source, GPBIASACC in ADCn\_BIASPROG should be cleared to 0 (HIGHACC). This will allow the ADC to enable high-accuracy mode from the bias circuitry during conversions. When AVDD or an external pin reference option is used, software may set GPBIASACC in ADCn\_BIASPROG to 1 (LOWACC) to conserve energy. Note that VDAC and dc-dc usage may also switch the chip-level bias to high-accuracy mode (even if GPBIASACC is set to LOWACC), potentially impacting ADC results. For example, if ADC is doing a conversion with GPBIASACC set to LOWACC and VDAC also starts a conversion using the internal low noise reference, then the chip-level bias circuit will be automatically switched to high-accuracy mode (potentially corrupting results of the on-going ADC conversion). Similarly, dc-dc startup automatically switches the chip-level bias circuit to high-accuracy mode for a short time, i.e., if dc-dc startup happens when ADC is doing a conversion (with GPBIASACC set to LOWACC), ADC results may get corrupted. DC-DC startup automatically switches the bias circuit to high-accuracy mode for 25  $\mu$ s. It is during this time that ADC conversions with the GPBIASACC set to LOWACC should be avoided.

The combination of VREF, ATT<sub>VREF</sub> and ATT<sub>VIN</sub> can produce a wide range of full-scale voltage options for the converter. [Table 27.1 Advanced VFS Configuration: VREF = AVDD on page 924](#) shows some example VFS configurations using AVDD as a reference source.

**Table 27.1. Advanced VFS Configuration: VREF = AVDD**

AVDD Voltage	VREF Attenuation Settings	Reference Voltage at ADC	VIN Attenuation Settings	VFS
1.85 V	VREFATTFFIX = 0  VREFATT = 6  <b>ATT<sub>VREF</sub> = 1/2</b>	0.925 V	VINATT = 12  <b>ATT<sub>VIN</sub> = 1</b>	1.85 V  (+/-0.925 V differential)
3.0 V	VREFATTFFIX = 0  VREFATT = 2  <b>ATT<sub>VREF</sub> = 1/3</b>	1.0 V	VINATT = 8  <b>ATT<sub>VIN</sub> = 2/3</b>	3.0 V  (+/-1.5 V differential)
3.0 V	VREFATTFFIX = 0  VREFATT = 2  <b>ATT<sub>VREF</sub> = 1/3</b>	1.0 V	VINATT = 4  <b>ATT<sub>VIN</sub> = 1/3</b>	6.0 V  (+/-3.0 V differential)
3.6 V	VREFATTFFIX = 1  VREFATT = 0  <b>ATT<sub>VREF</sub> = 1/4</b>	0.9 V	VINATT = 6  <b>ATT<sub>VIN</sub> = 1/2</b>	3.6 V  (+/-1.8 V differential)

### 27.3.9 Programming of Bias Current

The ADC uses a chip-level bias generator to provide bias current for its operation. The ADC's internal bias can be scaled by ADCBIA-SPROG field of the ADCn\_BIASPROG register. At lower conversion speeds, the ADCBIASPROG can be used to lower active power. Some commonly used settings are given in the ADCBIASPROG register description. For proper operation, the ADC conversion speed must be scaled accordingly. The scale factor is calculated as:

$$\text{Bias scale factor} = (1 - \text{ADCBIASPROG}[2:0]/8) / (1 + 3 \times \text{ADCBIASPROG}[3])$$

**Figure 27.12. Bias Scale Factor**

The bias programming register also includes the VFAULTCLR bit field. If VREFOF interrupt is enabled and it is triggered, then the user needs to set this bit in the ISR before clearing the interrupt flag. This bit then needs to be reset after the interrupt flag is cleared in order to enable the VREFOV flag to trigger on the next VREFOV condition.


The bias current settings should only be changed while the ADC is disabled (i.e. in NORMAL warm-up mode and no conversion in progress).

### 27.3.10 Feature Set

The following sections explain different ADC features.

#### 27.3.10.1 Conversion Tailgating

Scan conversions have priority over single channel conversions. This means that if scan and single triggers are received simultaneously, or even if the scan is received later when ADC is being warmed up for performing a single conversion, the scan conversion will have priority and will be done before the single conversion. However, a scan trigger will not interrupt in the middle of a single conversion, i.e., if the single conversion is in the acquisition or approximation phase, then the scan will have to wait for the single conversion to complete. If a scan sequence is triggered by a timer on a periodic basis, single channel conversion that started just before a scan trigger can delay the start of the scan sequence, thus causing jitter in sample rate. To solve this, conversion tailgating can be chosen by setting TAILGATE in ADCn\_CTRL. When this bit is set, any triggered single channels will wait for the next scan sequence to finish before activating (see [Figure 27.13 ADC Conversion Tailgating on page 925](#)). The single channel will then follow immediately after the scan sequence. In this way, the scan sequence will always start immediately when triggered, provided that the period between the scan triggers is big enough to allow the single sample conversion that was triggered to finish before the next scan trigger arrives. Note that if tailgating is set and a single channel conversion is triggered, it will indefinitely wait for a scan conversion before starting the single channel conversion.



**Figure 27.13. ADC Conversion Tailgating**

### 27.3.10.2 Repetitive Mode

Both single channel and scan mode can be run as a one shot conversion or in repetitive mode. The REP bitfield in ADCn\_SINGLECTRL/ADCn\_SCANCTRL registers can be used to activate the repetitive mode for single and scan respectively. In order to achieve the maximum sampling rate of 1 Msps, repetitive mode should be used.

It is also possible to have a programmable delay between these repetitive conversions. The REPDELAY bitfield in the ADCn\_SINGLECTRLX and ADCn\_SCANCTRLX registers can be used to set the delay between two repeated conversions in single channel and scan mode respectively. For single channel mode when a single conversion in repetitive mode ends, the user programmed REPDELAY is inserted and then the next single conversion is re triggered after the delay period is over. For scan mode the REPDELAY is inserted after the entire scan sequence ends. Once the delay period is over, scan mode is internally re-triggered. Note that when the ADC is in SYNC mode and REPDELAY is set to generate a delay, it takes an additional 5 HPPERCLK cycles after the trigger before the next conversion begins. If REPDELAY is set to NODELAY, the next conversion begins immediately, without any delay or additional HPPERCLKs. The [27.3.10.1 Conversion Tailgating](#) explains how the single channel and scan mode conversions can push each other out of phase. Conversion tailgating can be chosen in repetitive mode as well in order to ensure that the scan sequence will always start immediately when triggered, provided the scan REPDELAY chosen is big enough for the single conversion to finish. The status flags SINGLEACT and SCANACT stay high throughout the repeat mode, i.e., even during the delay period. The flags show that the conversions are either active or pending. Whether the ADC turns off or stays warmed up between these repeated conversions depends on the WARMUPMODE chosen in the ADCn\_CTRL register. When using single channel mode with repeat mode and REPDELAY enabled, then once the ADC has started operation (i.e., singleact status flag has gone high) then no new single conversion triggers (software START/ PRS triggers) should be sent to the ADC until the ADC has stopped converting (i.e., singleact status flag has gone low). The same applies to scan sequence conversions.

### 27.3.10.3 Conversion Trigger

The conversion modes can be activated by writing a 1 to the SINGLESTART or SCANSTART bit in the ADCn\_CMD register. The conversions can be stopped by writing a 1 to the SINGLESTOP or SCANSTOP bit in the ADCn\_CMD register. A START command will have priority over a STOP command. When the ADC is stopped in the middle of a conversion, the result buffer is cleared (the FIFO contents for any prior conversions are still intact). Every time a STOP command is issued, the user should wait for the corresponding status flag (SINGLEACT/SCANACT) to go low and then either read all the data in the FIFO or send the corresponding FIFOCLEAR command. The SINGLEACT and SCANACT bits in ADCn\_STATUS are set high when the modes are actively converting or have pending conversions.


It is also possible to trigger conversions from PRS signals. The PRS is treated as an asynchronous trigger. Setting PRSEN in ADCn\_SINGLECTRL/ADCn\_SCANCTRL enables triggering from PRS input. Which PRS channel to listen to is defined by PRSEL in ADCn\_SINGLECTRLX/ADCn\_SCANCTRLX. When PRS trigger is selected, it is still possible to trigger a conversion from software. Refer to the PRS chapter for more information on how to set up the PRS channels. When the conversions are triggered using the ADCn\_CMD register, then the SINGLEACT and SCANACT bits in the ADCn\_STATUS are set as soon as the START command is written to the register. When the conversion is triggered using PRS, it takes some cycles from the time PRS trigger is received until the SINGLEACT and SCANACT bits are set due to the synchronization requirement. If SINGLEACT is already high then sending a new START command or a new PRS trigger for a single conversion will not have any impact as ADC already has a single conversion ongoing or a single conversion pending (single conversion can be pending if ADC is busy running a scan sequence). The same rules apply for SCANACT and SCAN START and PRS triggers. When software issues a SINGLE/SCAN STOP command, it must wait until SINGLEACT/ SCANACT flag goes low before issuing a new START.

The PRS may trigger the ADC in two possible ways, configured by PRSMODE in ADCn\_SINGLECTRLX/ADCn\_SCANCTRLX. In PULSED mode, a PRS pulse triggers the ADC to start the ADC\_CLK (if not already enabled), warm up (if not already warm), start the acquisition period, and perform the conversion. This is identical to issuing a START command from software. In this mode, the input sampling finishes at the end of the acquisition period (AT).

If the ADC\_CLK and the source of the trigger (START command or PRS pulse) are not synchronous, the frequency of the input sampling (FS), will experience a  $1_{1/2}$  to  $2_{1/2}$  ADC\_CLK cycle jitter due to synchronization requirements.

To precisely control the sample frequency, the PRSMODE can be set to TIMED mode. In this mode, a long PRS pulse is expected to trigger the ADC and its negative edge directly finishes input sampling and starts the approximation phase, giving precise sampling frequency management. The restriction is that the PRS pulse has to be long enough to start the ADC\_CLK (if not already enabled), and finish the acquisition period based on the AT field in ADCn\_SINGLECTRL/ADCn\_SCANCTRL. The PRS pulse needs to be high when AT event finishes. If it is not high when AT finishes, then it is ignored and input sampling finishes after AT event has ended (a two cycle latency is added to the conversion in this scenario). In this case, the ADC sets the PRSTIMEDERR interrupt flag.

If the PRS pulse is too long (e.g., FS = 32kHz), the analog ADC start can be delayed to save power. The CONVSTARTDELAY along with its EN in the ADCn\_SINGLECTRLX or ADCn\_SCANCTRLx can be programmed to implement a 0 to 8 microseconds delay. The microsecond tick is counted by TIMEBASE with ADC\_CLK similar to warmup case. This saves power as the ADC is not enabled until the last possible microsecond before the fall edge of the PRS arrives to open the sampling switch and to start the approximation phase. [Figure 27.14 ADC PRS Timed Mode with ASNEEDED ADC\\_CLK Request on page 927](#) shows PRS Timed mode triggering with CONVSTARTDELAY and ASNEEDED ADC\_CLK request. See that power is saved by both delaying the ADC EN and by requesting the ADC\_CLK only during ADC operation. This is especially useful in saving power when running the ADC in EM2 DeepSleep or EM3 Stop power mode with low sampling frequency.



**Figure 27.14. ADC PRS Timed Mode with ASNEEDED ADC\_CLK Request**

When a PRS pulse is received, if the ADC\_CLK is not running (ASNEEDED mode), then the ADC requests the clock by setting clkreq\_adc\_async high. If the chosen clock source (HFXO/ HFSRCCLK/ AUXHFRCO) is already running, then it takes 5 ADC\_CLK cycles after the clock request is asserted for the ADC\_CLK to start. HFXO and HFSRCCLK (if chosen as ADC clock source) need to be already running before ADC sends out the clock request. If AUXHFRCO is chosen as the ADC clock source, and it is not already

running, then the CMU automatically turns it on when the ADC sends a clock request. In such a case, it takes (7 ADC\_CLK cycles + the oscillator startup time) for the ADC\_CLK to start. The oscillator startup time can be found in the device data sheet.

When triggering repeat mode using PRS and then stopping the triggered mode using STOP command, ensure that the PRS pulse used to generate the repeat mode has gone low by the time the STOP command is issued. If the PRS pulse continues to stay high after ADC has stopped the ongoing conversion, then it will be picked as a new trigger to start a new conversion.

**Note:**

- The conversion settings should not be changed while the ADC is running. Doing so may lead to unpredictable behavior.
- The adc\_clk\_sar phase is always reset by a conversion trigger as long as a conversion is not in progress. This gives predictable latency from the time of the trigger to the time the conversion starts, regardless of when in the trigger occurs.
- Software and LESENSE should not trigger conversions if PRS Timed mode is selected and PRSEN is set to 1 in the ADCn\_SINGLECTRL/ADCn\_SCANCTRL register.
- If the PRS Timed mode is being used, the acquisition time (AT) must be set greater than 0.

Scan conversions can be triggered using LESENSE as well. LESENSE only triggers one input conversion at a time (not the whole sequence of 32 possible inputs). The input to be converted using LESENSE must be configured by the user in the ADCn\_SCANINPUTSEL register before triggering the conversion, i.e., one of the 32 inputs chosen in the ADCn\_SCANINPUTSEL register must be the one that is to be converted using LESENSE. The ADCn\_SCANMASK is not used for LESENSE triggered conversions. Instead, the user can select which input should be converted through LESENSE inside the LESENSE settings (LESENSE\_CHX). The results of LESENSE triggered conversions are not loaded in the FIFO/ DATA registers but are instead available in the LESENSE register. Similarly, the SCAN interrupt flag is not set on completion of a LESENSE triggered conversion (because that flag is set only when the data is written to the Scan FIFO). When there is a LESENSE triggered conversion going on or pending, the SCANACT status flag is set. The SCANPEND interrupt flag is set when a software/PRS triggered scan goes pending because a LESENSE triggered scan is running (software/PRS triggered scan will start after the currently running LESENSE scan conversion completes). Similarly, SCANEXTPEND interrupt flag is set when the LESENSE triggered scan conversion goes pending because a software/PRS triggered scan is running. LESENSE triggered conversions can be stopped at any time using the SCANSTOP command in the ADCn\_CMD register. Note that the LESENSE triggered conversion cannot trigger the Scan repeat mode.

The DBGHALT bit-field in the ADCn\_CTRL register can be used to choose the ADC behavior in debug mode. If this bit is set to 1, then in debug mode ADC completes the current conversions and then halts. This means that all conversion triggers that were received before the debug halt occurred will be serviced before the ADC halts. All conversion triggers received after the ADC was halted, will be serviced when the debug mode is not halted any more. If the repetitive mode is running (in repetitive mode ADC keeps doing conversions until the user sends a software STOP) and a debug mode halt occurs, then the ADC will gracefully complete the current on-going conversion and then halt. The repetitive mode conversions will restart as soon as the debug mode is not halted any more.

#### 27.3.10.4 Output Results

ADC output results are presented in 2's complement form and the format for single ended and differential conversions are given in [Table 27.2 ADC Single Ended Conversion on page 929](#) and [Table 27.3 ADC Differential Conversion on page 929](#), respectively. If differential mode is selected, the results are sign extended up to 32-bits (shown in [Table 27.5 ADC Results Representation on page 930](#)).

**Table 27.2. ADC Single Ended Conversion**

Input Voltage	Output Results	
	Binary	Hex value
4095/4096 × VFS	111111111111	FFF
0.5 × VFS	100000000000	800
1/4096 × VFS	000000000001	001
0	000000000000	000

**Table 27.3. ADC Differential Conversion**

Input	Output Results	
	Binary	Hex value
2047/4096 × VFS	011111111111	7FF
0.25 × VFS	010000000000	400
1/4096 × VFS	000000000001	001
0	000000000000	000
-1/4096 × VFS	111111111111	FFF
-0.25 × VFS	110000000000	C00
-0.5 × VFS	100000000000	800

#### 27.3.10.5 Resolution

The ADC performs 12-bit conversions by default. However, if full 12-bit resolution is not needed, it is possible to speed up the conversion by selecting a lower resolution (6 or 8 bits). For more information on the accuracy of the ADC, the reader is referred to the electrical characteristics section for the device.

### 27.3.10.6 Oversampling

To achieve higher accuracy, hardware oversampling can be enabled individually for each mode (Set RES in ADCn\_SINGLECTRL/ADCn\_SCANCTRL to 0x3). The oversampling rate (OVSSEL in ADCn\_CTRL) can be set to any integer power of 2 from 2 to 4096 and the configuration is shared between the scan and single channel mode (OVSSEL field in ADCn\_CTRL).

With oversampling, each input is sampled at 12-bits of resolution a number of times (given by OVSSEL), and the results are filtered by a first order accumulate and dump filter to form the end result. The data presented in the ADCn\_SINGLEDATA and ADCn\_SCANDATA registers are the direct contents of the accumulation register (sum of samples). However, if the oversampling ratio is set higher than 16x, the accumulated results are shifted to fit the MSB in bit 15 as shown in [Table 27.4 Oversampling Result Shifting and Resolution on page 930](#).

**Table 27.4. Oversampling Result Shifting and Resolution**

Oversampling setting	# right shifts	Result Resolution # bits
2x	0	13
4x	0	14
8x	0	15
16x	0	16
32x	1	16
64x	2	16
128x	3	16
256x	4	16
512x	5	16
1024x	6	16
2048x	7	16
4096x	8	16

### 27.3.10.7 Adjustment

By default, all results are right adjusted, with the LSB of the result in bit position 0 (zero). In differential mode the signed bit is extended up to bit 31, but in single ended mode the bits above the result are read as 0. By setting ADJ in ADCn\_SINGLECTRL/ADCn\_SCANCTRL, the results are left adjusted as shown in [Table 27.5 ADC Results Representation on page 930](#). When left adjusted, the MSB is always placed on bit 15 and sign extended to bit 31. All bits below the conversion result are read as 0 (zero).

**Table 27.5. ADC Results Representation**

Adjustment	Resolution	Bits																		
		31 ... 16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Right	12	11 ... 11	11	11	11	11	11	10	9	8	7	6	5	4	3	2	1	0		
	8	7 ... 7	7	7	7	7	7	7	7	7	7	6	5	4	3	2	1	0		
	6	5 ... 5	5	5	5	5	5	5	5	5	5	5	5	4	3	2	1	0		
	OVS	15 ... 15	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Left	12	11 ... 11	11	10	9	8	7	6	5	4	3	2	1	0	-	-	-	-		
	8	7 ... 7	7	6	5	4	3	2	1	0	-	-	-	-	-	-	-	-		
	6	5 ... 5	5	4	3	2	1	0	-	-	-	-	-	-	-	-	-	-		
	OVS	15 ... 15	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		

### 27.3.10.8 Channel Connection

The inputs are connected to the analog ADC at the beginning of the acquisition phase and are disconnected at the end of the acquisition phase. The time when the APORt switches are closed (for the next input to be converted) can be controlled by the CHCONMODE bitfield in the ADCn\_CTRL register. By default, this field is set to the MAXSETTLE option. For MAXSETTLE, APORt switches are closed on the next input as soon as the acquisition phase for the current conversion is complete. This means that the APORt switches are closed approximately 12 adc\_clk\_sar cycles (assuming 12 bit resolution) before the acquisition phase of the current conversion starts, giving APORt switches maximum time to settle. The time for which APORt switches should be closed before the acquisition phase starts, should be the same for all inputs in order to get consistent results. This means that if the ADC is warmed up with CHCONREFWARMIDLE set to 0 (scan reference warmed up and the APORt switches for the first scan channel closed) and a single trigger comes in, the single conversion will have to wait 12 adc\_clk\_sar cycles before it can start (even if single is using the same reference as scan). In this case, it might be more suitable to switch to the MAXRESP option in the CHCONMODE bitfield. In MAXRESP, the APORt switches for the upcoming conversion are closed just before the acquisition phase starts. This gives less settling time to the APORt switches but removes the extra waiting time before a conversion can start (which could be the case with MAXSETTLE as discussed above).

### 27.3.10.9 Temperature Measurement

The ADC includes an internal temperature sensor. This sensor is measured during production test and the temperature readout from the ADC at production temperature, ADC0CAL3\_TEMPREAD1V25, is given in the Device Information (DI) page. The production temperature, CAL\_TEMP, is also given in this page. The temperature sensor slope, V\_TS\_SLOPE (mV/degree Celsius), for the sensor is found in the data sheet for the device. Using the 1.25 V VFS option and 12-bit resolution, the temperature can be calculated according to the following formula (VFS in the formula is 1250 mV) :

$$T_{CELSIUS} = \text{CAL\_TEMP} - (\text{ADC0CAL3\_TEMPREAD1V25} - \text{ADC\_result}) \times \text{VFS} / (4096 \times V_{TS\_SLOPE})$$

**Figure 27.15. ADC Temperature Measurement**

#### Note:

- The minimum acquisition time for the temperature reference is found in the electrical characteristics for the device. If using the 1.25 V reference, extra acquisition time is required. In this case the AT field of ADCn\_SINGLECTRL or ADCn\_SCANCTRL should be set to a value of 9 or higher.
- For the most accurate temperature sensor results, GPBIASACC in ADCn\_BIASPROG should be set to 0 to keep the bias in HIGH-ACC mode.
- If the device has more than one ADC, all ADCs may not be equipped with the temperature sensor. See the device data sheet.

### 27.3.10.10 ADC as a Random Number Generator

The ADC can be used as a random number generator. This is done by:

1. Choose the REF in the ADCn\_SINGLECTRL as CONF, setting the VREFSEL in the ADCn\_SINGLECTRLX as VENTROPY and VINATT in the same register to its maximum value of 15.
2. Set DIFF to 1 and RES to 0 in the ADCn\_SINGLECTRL register.
3. Trigger a single channel conversion and then read ADCn\_SINGLEDATA register when the conversion finishes.

The LSB[2:0] of each sample will be a random number. In this mode, the POSSEL or NEGSEL in ADCn\_SINGLECTRL can be connected to VSS or any other noisy input.

### 27.3.11 Interrupts, PRS Output

The single and scan modes have separate SINGLE and SCAN interrupt flags indicating whether corresponding FIFO contains DVL # of valid conversion data. Corresponding interrupt enable bit has to be set in ADCn\_IEN in order to generate interrupts. For these interrupts, there is no software clear mechanism by writing to ADCn\_IFC. The user needs to read enough data from the interrupted FIFO to ensure it contains less than DVL # of elements. The ADCn\_SINGLEFIFOCOUNT/ADCn\_SCANFIFOCOUNT can provide number of valid elements remaining in corresponding FIFO. The FIFO can also be cleared by ADCn\_SINGLEFIFOCLEAR/ADCn\_SCANFIFO-CLEAR, but any existing data will be lost by this operation.

In addition to the SINGLE and SCAN interrupt flags, there is separate scan and single channel result overflow interrupt flag which signals that a result from a scan or single channel FIFO has been overwritten before being read. There is also separate scan and single channel result underflow interrupt flag which signals that a FIFO read was issued when the FIFO was empty.

There is separate scan and single compare interrupt flag which signals a compare match with latest sample if the CMPEN in ADCn\_SINGLECTRL/ADCn\_SCANCTRL is enabled.

ADC has two separate PRS outputs, one for single channel and one for scan sequence. A finished conversion results in a one ADC\_CLK cycle pulse, which is output to the Peripheral Reflex System (PRS). Note that the PRS pulse for scan is generated once after every channel conversion in the scan sequence.

### 27.3.12 DMA Request

The ADC has two DMA request lines, SINGLREQ and SCANREQ, which are set when a single or scan FIFO receives DVL# of samples. The requests are cleared when the corresponding single or scan result register is read and corresponding FIFO count reaches lower than DVL. It also has two additional DMA Single request lines, SINGLESREQ and SCANSREQ, that are set when the corresponding FIFO is not empty.

### 27.3.13 Calibration

The ADC supports offset and gain calibration to correct errors due to process and temperature variations. This must be done individually for each reference used. For each reference, it needs to be repeated for single-ended, negative single-ended (see [27.3.7 Input Selection](#) for details) and differential measurement. The ADC calibration (ADCn\_CAL) register contains register fields for calibrating offset and gain for both single and scan mode. The gain and offset calibration are done in single channel mode, but the resulting calibration values can be used for both single and scan mode.

Gain and offset for various references and modes are calibrated during production and the calibration values for these can be found in the Device Information page. During reset, the gain and offset calibration registers are loaded with the production calibration values for the 1V25 reference. Others can be loaded as needed or the user can perform calibration on the fly using the particular reference and mode to be used and write the result in the ADCn\_CAL before starting the ADC conversion with them.

#### 27.3.13.1 Offset Calibration

Offset calibration must be performed prior to gain calibration. Follow these steps for the offset calibration in single mode:

1. Select the desired full scale configuration by setting the REF bit field of the ADCn\_SINGLECTRL register.
2. Set the AT bit field of the ADCn\_SINGLECTRL register to 16CYCLES.
3. Set the POSSEL and NEGSEL of the ADCn\_SINGLECTRL register to VSS, and set the DIFF to 1 for enabling differential input if calibrating for DIFF measurement. During calibration, the ADC samples represent the code coming out of the analog. Thus, since the input voltage is 0, the expected ADC output is 0b100000000000 in differential mode, 0b000000000000 in single-ended mode and 0b111111111111 in negative single-ended mode.
4. A binary search is used to find the offset calibration value. Set the CALEN to 1, and OFFSETINVMODE to 1 (if calibrating for negative single-ended conversion) in the ADCn\_CAL register. If user is performing negative single-ended calibration, the SINGLEOFFSETINV provides the offset else SINGLEOFFSET bit provides the offset (for both single-ended and differential offset calibration). Start with 0b0000 (or 0b1111 if doing calibration for differential mode) in SINGLEOFFSET or with 0b1000 in SINGLEOFFSETINV (if calibrating for negative single-ended conversion). Set the SINGLESTART bit in the ADCn\_CMD register to perform a 12-bit conversion and read the ADCn\_SINGLEDATA register. The offset is (ADCn\_SINGLEDATA - expected ADC output). Calculate this and write [3:0] of the result into SINGLEOFFSET or SCANOFFSETINV (if doing negative single-ended conversion). The user repeats till ADCn\_SINGLEDATA matches expected ADC output. The ADC has a 8LSB built in negative offset to allow for negative offset correction. So, with default offset value, which corrects for the negative offset, the converted ADCn\_SINGLEDATA would match expected ADC output if there were no offset. To get better noise immunity, the sampling phase can be repeated with Oversampling enabled. The result of the binary search is written to the SINGLEOFFSET (or SINGLEOFFSETINV) field of the ADCn\_CAL register.

### 27.3.13.2 Gain Calibration

Offset calibration must be performed prior to gain calibration. The Gain Calibration is done in the following manner:

1. Select an external ADC channel for single channel conversion (a differential channel can also be used).
2. Apply an external voltage on the selected ADC input channel. This voltage should correspond to the top of the ADC input range for the selected reference.
3. Set SINGLEGAIN[6:0] to 64 in the ADCn\_CAL and measure gain, repeat gain calibration walking the 1 in SINGLEGAIN[6] to SINGLEGAIN[0] till sampled ADCn\_SINGLEDATA matches expected value. This is done by setting CALEN in ADCn\_CAL set to 1 and performing single channel, reading in the raw ADC code from the ADCn\_SINGLEDATA and comparing it with expected code, i.e. 0b111111111111 for single-ended or differential conversion, and 0b000000000000 for negative single-ended conversion. The target value is ideally the top of the ADC input range, but it is recommended to use a value a couple of LSBs below in order to avoid overshooting. The result of the binary search is written to the SINGLEGAIN field of the ADCn\_CAL register.

For the VDD reference and external reference, there is no hardware gain calibration. Calibration can be done by software after taking a sample.

### 27.3.14 EM2 DeepSleep or EM3 Stop Operation

The ADC can operate in EM2 DeepSleep or EM3 Stop mode. For EM2 DeepSleep or EM3 Stop operation the ADC\_CLK must be selected as AUXHFRCO. The section [27.3.1 Clock Selection](#) describes how to choose AUXHFRCO as the ADC\_CLK. The AUXHFRCO can be kept on for as long as sample conversion is needed or it can be requested by trigger event and after the conversion is done, the AUXHFRCO can be shut down. The second option saves power at the expense of the delay to start the AUXHFRCO oscillator. All the trigger modes are available in EM2 DeepSleep or EM3 Stop as well.

While in EM2 DeepSleep or EM3 Stop, the ADC can wake the system to EM0 Active on enabled interrupts. Following interrupts can wake up the system to EM0 Active:

- SINGLE or SCAN interrupt indicating that the corresponding FIFO has reached the DVL watermark.
- Overflow interrupt (SINGLEOF or SCANOF)
- Underflow interrupt (SINGLEUF or SCANUF), triggered if DMA pops more data than present in the FIFO while the system is asleep
- Compare interrupt (SINGLECMP or SCANCMP)
- Over voltage interrupt (VREFOV)

The ADC can also work with the DMA so that the system does not have to wake up to consume data. This can happen if the SCAN or SINGLE interrupt is disabled and the SINGLEDMAWU or SCANDMAWU in the ADCn\_CTRL is set. The DMA will be triggered by the ADC when DVL samples become available in the corresponding FIFO. The DMA will then pop all the elements of the corresponding FIFO and put the system back into the low power state. A system-level wake up will occur upon the DMA done interrupt. Note that other enabled ADC interrupts can still wake up the system when operating with the DMA. For example, the user can configure the window compare function to trip when the result reaches a certain threshold while gathering ADC data in EM2 DeepSleep or EM3 Stop.

The ADC works with the EMU to wake up the system or the DMA. It takes 2  $\mu$ s from the time the ADC request a wakeup to start of the peripheral clocks. In this ASYNC mode of ADC\_CLK, it takes 6 HFFPERCCLK cycles to read a single entry from the single or scan FIFO. So, with a 20MHz HFFPERCCLK, it takes about 4  $\mu$ s per DMA wakeup to empty a full FIFO (4 entries). This restricts the sampling rate in EM2 DeepSleep or EM3 Stop in order to avoid FIFO overflows.

The AUXHFRCO power can be reduced by reducing the clock speed, and the user may adjust the ADCBIASPROG field in the ADCn\_BIASPROG register to reduce active power of the ADC during the conversions, thus reducing power even more in EM2 DeepSleep/EM3 Stop. Refer to the data sheet for relevant power consumption numbers.

If the ADC is not to be used in EM2 DeepSleep or EM3 Stop, then the user should ensure that the ADC is not busy before going to the low power mode. [27.3.17 ADC Programming Model](#) explains how to ensure the ADC is not busy. If the chip enters EM2 DeepSleep or EM3 Stop when ADC is busy without using AUXHFRCO, then the ADC clock will stop but the ADC will stay on, resulting in higher supply current. If this occurs, the EM23ERR interrupt flag will be set. Software will see this interrupt flag only when the chip wakes up.

### 27.3.15 ASYNC ADC\_CLK Usage Restrictions and Benefits

When the ADC\_CLK is chosen to come from ASYNCCLK, (ADCCLKMODE is set to ASYNC), the ADC\_CLK and the ADC peripheral clock are considered asynchronous and this adds some restrictions:

- Due to a synchronization delay, accessing the following registers takes extra time (up to additional 7 HPERCCLK cycles): ADCn\_SINGLEDATA, ADCn\_SCANDATA, ADCn\_SINGLEDATAP, ADCn\_SCANDATAP, ADCn\_SCANDATAx, ADCn\_SCANDATAxP, ADCn\_SINGLEFIFOCOUNT, ADCn\_SCANFIFOCOUNT, ADCn\_SINGLEFIFOCLEAR, ADCn\_SCANFIFOCLEAR.
- The safe time to change the ADCn\_SINGLECTRL, ADCn\_SINGLECTRLx, ADCn\_SCANCTRL, ADCn\_SCANCTRLx, ADCn\_SCANINPUTSEL, ADCn\_SCANNEGSEL or ADCn\_SCANMASK register is when SINGLEACT/SCANACT in the ADCn\_STATUS is 0 with no pending trigger event. The user can enforce this by writing the SINGLESTOP or SCANSTOP in the ADCn\_CMD register and ensuring no trigger event can come before modifying the registers.
- When the ADC needs to run in EM2 DeepSleep or EM3 Stop, only AUXHFRCO can provide the ADC\_CLK to the ADC. Thus the user needs to set ASYNC mode of ADCCLKMODE and setup the CMU to provide the AUXHFRCO clock as ASYNCCLK.
- If the ADC needs to run on a particular adc\_clk\_sar frequency to achieve a sample rate and the HPERCCLK is not a proper multiple for such clock frequency, a higher frequency system clock, HFRCO, can be chosen to be ADC\_CLK using ASYNC mode. This allows HPERCCLK to be set to an optimum value from a system view point.
- ASYNC mode can also help with digital noise mitigation as this clock is asynchronous (not balanced) with the system clock. Moreover, the user can use the invert option to invert the source of ASYNCCLK helping in noise mitigation further.
- Whenever ADC is being used in asynchronous mode, then HPERCLK must be at least 1.5 times higher than the ADC\_CLK.
- With ASNEEDED setting for ASYNCCLK request, the ADC\_CLK power can be reduced.

### 27.3.16 Window Compare Function

The ADC supports a window compare function on both the latest single and scan outputs. The compare thresholds, ADGT and ADLT, are defined in the ADCn\_CMPTH register. These are 16-bit values and their format must match the type of conversion (single-ended or differential) the user is trying to compare with. For example, a 12-bit differential conversion is sign extended to 16 bits while a 12-bit single-ended conversion result would get zero padded to 16-bit result before comparing with ADGT and ADLT. If over-sampling is enabled, the conversion result could grow to 16-bits. There is a single set of ADLT and ADGT threshold for both single and scan compare. The user can however enable single or scan compare logic individually by enabling CMPEN in ADCn\_SINGLECTRL or ADCn\_SCANCTRL register.

The user can perform comparison both within or outside of the window defined by the ADGT and ADLT. If the ADLT is greater than ADGT, the ADC compares if the current sample is within the window. Otherwise, the ADC compares if the current sample is outside of the window.

### 27.3.17 ADC Programming Model

The ADC configuration registers are considered static and can only be updated when (1) ADC is in SYNC mode and (2) ADC is idle. ADC is considered busy when it is doing conversions (either the SINGLEACT or SCANACT status flag is high) or when it is warmed up (one of the following status flags is high: WARM, SINGLEREFWARM, SCANREFWARM). The following registers are considered ADC configuration registers: CMU\_ADCCTRL, ADCn\_CTRL, ADCn\_SINGLECTRL, ADCn\_SINGLECTRLX, ADCn\_SCANCTRL, ADCn\_SCANCTRLX, ADCn\_SCANINPUTSEL, ADCn\_SCANNEGSEL, ADCn\_IEN, ADCn\_BIASPROG, ADCn\_SCANMASK, ADCn\_CAL and ADCn\_CMPTH.R.

From reset, the ADC is in SYNC mode by default. The user can program the configuration registers as needed. If PRS is to be used, PRSEN in ADCn\_SINGLECTRL/ADCn\_SCANCTRL should be set after all other configuration is complete. Once configuration is complete, the ADC is ready to receive triggers. The user must ensure that no LESENSE triggers come in during the time the ADC configuration registers are being updated.

After the ADC has been used to perform conversions, the user must ensure that the ADC is idle before updating the configuration registers. The first step is to ensure that no new triggers (PRS, LESENSE) are being issued. It can take a few cycles from when a trigger is received to when SINGLEACT/SCANACT flags go high due to synchronization requirement. If it is unclear when the triggers were issued and if those are under synchronization or not, the user should add a small delay before checking the status flags. If the SINGLEACT/SCANACT status flags are high, the corresponding STOP command should be issued and the user should wait until the SINGLEACT/SCANACT flags go low. If the ADC was warmed up, then the WARMUPMODE should be changed to NORMAL and then the user should wait on WARM, SINGLEREFWARM and SCANREFWARM flags until those go low. Now the ADC is idle.

If both LESENSE scan and PRS/software scan conversions are taking place, then since there are two scans occurring, the SCAN STOP command needs to be issued twice. The user can check the SCANPENDING status flag. If the flag is set then the user needs to send out 2 SCAN STOP commands. After sending out the first SCAN STOP, the user needs to wait until the SCANPENDING flag goes low. Then the second SCAN STOP command should be issued and the user should wait on the SCANACT status flag to go low.

**Note:**

When switching ADCCLKMODE in the ADCn\_CTRL register, use the appropriate sequence below:

- SYNC to ASYNC:

1. Disable ADC interrupts
2. Clear the FIFOs
3. Switch the ADCCLKMODE

If the ADC is to be used in ASYNC clock mode with WARMUPMODE set to KEEPADCWARM, then both ADCCLKMODE and WARMUPMODE fields in the ADCn\_CTRL register should be set to the desired values in the same register write. This will ensure that the ADC power-on sequence is valid.

- ASYNC TO SYNC:

1. Disable ADC interrupts
2. Switch the ADCCLKMODE
3. Clear the FIFOs

The FIFOs are cleared by writing 1 to the ADCn\_SCANFIFOCLEAR and ADCn\_SINGLEFIFOCLEAR registers.

When switching from ASYNC to SYNC, ensure that the ASYNC clock is turned off before doing the switch.

## 27.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	ADCn_CTRL	RW	Control Register
0x008	ADCn_CMD	W1	Command Register
0x00C	ADCn_STATUS	R	Status Register
0x010	ADCn_SINGLECTRL	RW	Single Channel Control Register
0x014	ADCn_SINGLECTRLX	RW	Single Channel Control Register Continued
0x018	ADCn_SCANCTRL	RW	Scan Control Register
0x01C	ADCn_SCANCTRLX	RW	Scan Control Register Continued
0x020	ADCn_SCANMASK	RW	Scan Sequence Input Mask Register
0x024	ADCn_SCANINPUTSEL	RW	Input Selection Register for Scan Mode
0x028	ADCn_SCANNEGSEL	RW	Negative Input Select Register for Scan
0x02C	ADCn_CMPTHR	RW	Compare Threshold Register
0x030	ADCn_BIASPROG	RW	Bias Programming Register for Various Analog Blocks Used in ADC Operation
0x034	ADCn_CAL	RW	Calibration Register
0x038	ADCn_IF	R	Interrupt Flag Register
0x03C	ADCn_IFS	W1	Interrupt Flag Set Register
0x040	ADCn_IFC	(R)W1	Interrupt Flag Clear Register
0x044	ADCn_IEN	RW	Interrupt Enable Register
0x048	ADCn_SINGLEDATA	R(a)	Single Conversion Result Data
0x04C	ADCn_SCANDATA	R(a)	Scan Conversion Result Data
0x050	ADCn_SINGLEDATAP	R	Single Conversion Result Data Peek Register
0x054	ADCn_SCANDATAP	R	Scan Sequence Result Data Peek Register
0x068	ADCn_SCANDATAX	R(a)	Scan Sequence Result Data + Data Source Register
0x06C	ADCn_SCANDATAXP	R	Scan Sequence Result Data + Data Source Peek Register
0x07C	ADCn_APORTREQ	R	APORT Request Status Register
0x080	ADCn_APORTCFLICT	R	APORT Conflict Status Register
0x084	ADCn_SINGLEFIFOCOUNT	R	Single FIFO Count Register
0x088	ADCn_SCANFIFOCOUNT	R	Scan FIFO Count Register
0x08C	ADCn_SINGLEFIFOCLEAR	W1	Single FIFO Clear Register
0x090	ADCn_SCANFIFOCLEAR	W1	Scan FIFO Clear Register
0x094	ADCn_APORTMASTERDIS	RW	APORT Bus Master Disable Register

## 27.5 Register Description

### 27.5.1 ADCn\_CTRL - Control Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RW	0x0	0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	RW	0x0	
Name	CHCONREFWARMIDLE	CHCONMODE	DBGHALT	OVSSEL	TIMEBASE	PRES	ADCCCLKMODE	ASYNCNCLKEN	TAILGATE	SCANDMAWU	SINGLEDMAWU	WARMUPMODE																				
31:30	CHCONREFWARMIDLE	0x0	RW	<b>Channel Connect and Reference Warm Sel When ADC is IDLE</b>	Channel connect and reference warm preference																											
29	CHCONMODE	0	RW	<b>Channel Connect</b>	Selects Channel Connect Mode																											
28	DBGHALT	0	RW	<b>Debug Mode Halt Enable</b>	Selects ADC behavior during debug mode.																											
27:24	OVSSEL	0x0	RW	<b>Oversample Rate Select</b>	Select oversampling rate. Oversampling must be enabled for this setting to take effect.																											

Bit	Name	Reset	Access	Description
31:30	CHCONREFWARMIDLE	0x0	RW	<b>Channel Connect and Reference Warm Sel When ADC is IDLE</b>
				Channel connect and reference warm preference
	Value	Mode		Description
	0	PREFSCAN		Keep scan reference warm and APORt switches for first scan channel closed if WARMUPMODE is not NORMAL
	1	PREFSINGLE		Keep single reference warm and keep APORt switches for single channel closed if WARMUPMODE is not NORMAL
	2	KEEPPREV		Keep last used reference warm and keep APORt switches for corresponding channel closed if WARMUPMODE is not NORMAL
29	CHCONMODE	0	RW	<b>Channel Connect</b>
				Selects Channel Connect Mode
	Value	Mode		Description
	0	MAXSETTLE		Connect APORt switches for the next input as soon as possible. This optimizes settling time.
	1	MAXRESP		Connect APORt switches for the next input at the end of the conversion.
28	DBGHALT	0	RW	<b>Debug Mode Halt Enable</b>
				Selects ADC behavior during debug mode.
	Value			Description
	0			Continue operation as normal during debug mode.
	1			Complete the current conversion and then halt during debug mode.
27:24	OVSSEL	0x0	RW	<b>Oversample Rate Select</b>
				Select oversampling rate. Oversampling must be enabled for this setting to take effect.

Bit	Name	Reset	Access	Description
	Value	Mode		Description
0	X2			2 samples for each conversion result
1	X4			4 samples for each conversion result
2	X8			8 samples for each conversion result
3	X16			16 samples for each conversion result
4	X32			32 samples for each conversion result
5	X64			64 samples for each conversion result
6	X128			128 samples for each conversion result
7	X256			256 samples for each conversion result
8	X512			512 samples for each conversion result
9	X1024			1024 samples for each conversion result
10	X2048			2048 samples for each conversion result
11	X4096			4096 samples for each conversion result
23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:16	TIMEBASE	0x1F	RW	<b>1us Time Base</b>
				Sets the time base used for the ADC warm up sequence based on ADC_CLK. The TIMEBASE field should be set equal to produce timing of 1us or greater.
	Value			Description
	TIMEBASE			ADC STANDBY/SLOWACC mode warm-up is set to 1 x (TIMEBASE + 1) ADC_CLK cycles and NORMAL mode warm-up is set to 5 x (TIMEBASE + 1) ADC_CLK cycles.
15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:8	PRESC	0x00	RW	<b>Prescalar Setting for ADC Sample and Conversion Clock</b>
				Sets the prescale factor to generate the ADC conversion clock (adc_sar_clk) from ADC_CLK.
	Value			Description
	PRESC			Clock prescale factor. ADC_CLK is divided by (PRESC+1) to produce adc_clk_sar.
7	ADCCLKMODE	0	RW	<b>ADC Clock Mode</b>
				Selects ADC_CLK source as synchronous or asynchronous - with respect to the Peripheral Clock (HFPERCCLK).
	Value	Mode		Description
0	SYNC			Synchronous clocking. Uses HFPERCCLK to generate ADC_CLK, ADC will not be available in EM2 in this mode.
1	ASYNC			Asynchronous clocking. Uses clk_adc_async coming from CMU to generate ADC_CLK. ADC might be available in EM2 in this mode if the CLK_ADC_ASYNC is available in EM2

Bit	Name	Reset	Access	Description
6	ASYNCCLKEN	0	RW	<b>Selects ASYNC CLK Enable Mode When ADCCLKMODE=1</b>  Write a 1 to keep ASYNC CLK always enabled.
<hr/>				
	Value	Mode		Description
	0	ASNEEDED		ASYNC CLK is enabled only during ADC Conversion.
	1	ALWAYSON		ASYNC CLK is always enabled.
<hr/>				
5	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
<hr/>				
4	TAILGATE	0	RW	<b>Conversion Tailgating</b>
	Enable/disable conversion tailgating. Single channel conversions wait for a scan sequence to finish before starting.			
	Value	<hr/>		
	0	Scan sequence has priority, but can be delayed by ongoing single channels.		
	1	Scan sequence has priority and single channels will only start immediately after completion of a scan sequence.		
<hr/>				
3	SCANDMAWU	0	RW	<b>SCANFIFO DMA Wakeup</b>
	Selects whether to wakeup the DMA controller when in EM2 and DVL is reached in SCANFIFO			
	Value	<hr/>		
	0	While in EM2, the DMA controller will not get requests about DVL reached in SCANFIFO		
	1	DMA is available in EM2 for processing SCANFIFO DVL request		
<hr/>				
2	SINGLEDMAWU	0	RW	<b>SINGLEFIFO DMA Wakeup</b>
	Selects whether to wakeup the DMA controller when in EM2 and DVL is reached in SINGLEFIFO			
	Value	<hr/>		
	0	While in EM2, the DMA controller will not get requests about Data Valid Level (DVL) reached in SINGLEFIFO		
	1	DMA is available in EM2 for processing SINGLEFIFO DVL request		
<hr/>				
1:0	WARMUPMODE	0x0	RW	<b>Warm-up Mode</b>
	Select Warm-up Mode for ADC			
	Value	Mode	<hr/>	
	0	NORMAL	ADC is shut down after each conversion. 5us warmup time is used before each conversion.	
	1	KEEPINSTANDBY	ADC is kept in standby mode between conversions. 1us warmup time is used before each conversion.	
	2	KEEPINSLOWACC	ADC is kept in slow acquisition mode between conversions. 1us warmup time is used before each conversion.	
	3	KEEPADCWARM	ADC is kept on after conversions, allowing for continuous conversion.	

## 27.5.2 ADCn\_CMD - Command Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									SCANSTOP	W1	0					
Access																									SCANSTART	W1	0					
Name																									SINGLESTOP	W1	0					
Bit	Name	Reset	Access	Description																					SINGLESTART	W1	0					
31:4	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																														
3	SCANSTOP	0	W1	<b>Scan Sequence Stop</b>	Write a 1 to stop scan sequence.																											
2	SCANSTART	0	W1	<b>Scan Sequence Start</b>	Write a 1 to start scan sequence.																											
1	SINGLESTOP	0	W1	<b>Single Channel Conversion Stop</b>	Write a 1 to stop single channel conversions.																											
0	SINGLESTART	0	W1	<b>Single Channel Conversion Start</b>	Write to 1 to start converting in single channel mode.																											

## 27.5.3 ADCn\_STATUS - Status Register

Offset	Bit Position																																	
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																			0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
Access																			R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
Name																			SCANDV	SINGLEDV	WARM	PROGERR	SCANREFWARM	SINGLEREFWARM	SCANPENDING	SCANACT	SINGLEACT	0	0	0	0	0	0	0

Bit	Name	Reset	Access	Description
31:18	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
17	SCANDV	0	R	<b>Scan Data Valid</b>  SCANCTRLX_DVL # of scan conversion data results are available in Scan FIFO.
16	SINGLEDV	0	R	<b>Single Channel Data Valid</b>  SINGLECTRLX_DVL # of single channel conversion results are available in Single FIFO.
15:13	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
12	WARM	0	R	<b>ADC Warmed Up</b>  ADC is warmed up.
11:10	PROGERR	0x0	R	<b>Programming Error Status</b>  Programming Error Status
	Mode	Value		Description
	BUSCONF	x1		APORT reported a BUS Conflict.
	NEGSELCONF	1x		SINGLECTRL's NEGSEL choice is invalid with respect to POSSEL choice. Occurs when two X channels or two Y channels are selected.
9	SCANREFWARM	0	R	<b>Scan Reference Warmed Up</b>  Reference selected for scan mode is warmed up.
8	SINGLEREFWARM	0	R	<b>Single Channel Reference Warmed Up</b>  Reference selected for single channel mode is warmed up.
7:3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
2	SCANPENDING	0	R	<b>Scan Conversion Pending</b>  Indicates that either an external scan (e.g., lesense triggered) or a PRS/software triggered scan has gone pending. SCANPENDIF and SCANEXTPENDIF show which one of two went pending.
1	SCANACT	0	R	<b>Scan Conversion Active</b>  Scan sequence is active or has pending conversions.

Bit	Name	Reset	Access	Description
0	SINGLEACT	0	R	<b>Single Channel Conversion Active</b>  Single channel conversion is active or has pending conversions.

## 27.5.4 ADCn\_SINGLECTRL - Single Channel Control Register

Offset	Bit Position																																	
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset	0	0					0x0					0xFF									0xFF													
Access	RW	RW	RW				RW					RW									RW													
Name	CMPEN	PRSEN					AT					NEGSEL									POSSEL									REF	RES	ADJ	DIFF	REP

Bit	Name	Reset	Access	Description
31	CMPEN	0	RW	<b>Compare Logic Enable for Single Channel</b>  Enable/disable Compare Logic
	Value			Description
	0			Disable Compare Logic.
	1			Enable Compare Logic.
30	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
29	PRSEN	0	RW	<b>Single Channel PRS Trigger Enable</b>  Enabled/disable PRS trigger of single channel.
	Value			Description
	0			Single channel is not triggered by PRS input.
	1			Single channel is triggered by PRS input selected by PRSSEL.
28	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
27:24	AT	0x0	RW	<b>Single Channel Acquisition Time</b>  Select the acquisition time for single channel.
	Value	Mode		Description
	0	1CYCLE		1 conversion clock cycle acquisition time for single channel
	1	2CYCLES		2 conversion clock cycles acquisition time for single channel
	2	3CYCLES		3 conversion clock cycles acquisition time for single channel
	3	4CYCLES		4 conversion clock cycles acquisition time for single channel
	4	8CYCLES		8 conversion clock cycles acquisition time for single channel
	5	16CYCLES		16 conversion clock cycles acquisition time for single channel
	6	32CYCLES		32 conversion clock cycles acquisition time for single channel
	7	64CYCLES		64 conversion clock cycles acquisition time for single channel
	8	128CYCLES		128 conversion clock cycles acquisition time for single channel
	9	256CYCLES		256 conversion clock cycles acquisition time for single channel

Bit	Name	Reset	Access	Description																																																																														
23:16	NEGSEL	0xFF	RW	<b>Single Channel Negative Input Selection</b>																																																																														
Selects the negative input to the ADC for Single Channel Differential mode (in case of singled ended mode, the negative input is grounded). The user can choose any of the 32 channels of any of the 5 BUSes but must ensure that POSSEL and NEGSEL are chosen from different resources (X or Y) BUS. In case of an invalid configuration, the ADC will perform a single-ended sampling and issue a BUSCONFLICT IRQ.																																																																																		
<table border="1"> <thead> <tr> <th>Mode</th><th>Value</th><th>Description</th></tr> </thead> <tbody> <tr><td>APORT0XCH0</td><td>0</td><td>Select APORT0XCH0</td></tr> <tr><td>APORT0XCH1</td><td>1</td><td>Select APORT0XCH1</td></tr> <tr><td>...</td><td>...</td><td>.....</td></tr> <tr><td>APORT0XCH15</td><td>15</td><td>Select APORT0XCH15</td></tr> <tr><td>APORT0YCH0</td><td>16</td><td>Select APORT0YCH0</td></tr> <tr><td>APORT0YCH1</td><td>17</td><td>Select APORT0YCH1</td></tr> <tr><td>APORT0YCH15</td><td>31</td><td>Select APORT0YCH15</td></tr> <tr><td>APORT1XCH0</td><td>32</td><td>Select APORT1XCH0</td></tr> <tr><td>APORT1YCH1</td><td>33</td><td>Select APORT1YCH1</td></tr> <tr><td>...</td><td>...</td><td>.....</td></tr> <tr><td>APORT1YCH31</td><td>63</td><td>Select APORT1YCH31</td></tr> <tr><td>APORT2YCH0</td><td>64</td><td>Select APORT2YCH0</td></tr> <tr><td>APORT2XCH1</td><td>65</td><td>Select APORT2XCH1</td></tr> <tr><td>...</td><td>...</td><td>.....</td></tr> <tr><td>APORT2XCH31</td><td>95</td><td>Select APORT2XCH31</td></tr> <tr><td>APORT3XCH0</td><td>96</td><td>Select APORT3XCH0</td></tr> <tr><td>APORT3YCH1</td><td>97</td><td>Select APORT3YCH1</td></tr> <tr><td>...</td><td>...</td><td>.....</td></tr> <tr><td>APORT3YCH31</td><td>127</td><td>Select APORT3YCH31</td></tr> <tr><td>APORT4YCH0</td><td>128</td><td>Select APORT4YCH0</td></tr> <tr><td>APORT4XCH1</td><td>129</td><td>Select APORT4XCH1</td></tr> <tr><td>...</td><td>...</td><td>.....</td></tr> <tr><td>APORT4XCH31</td><td>159</td><td>Select APORT4XCH31</td></tr> <tr><td>TESTN</td><td>245</td><td>Reserved for future expansion</td></tr> <tr><td>VSS</td><td>255</td><td>VSS</td></tr> </tbody> </table>					Mode	Value	Description	APORT0XCH0	0	Select APORT0XCH0	APORT0XCH1	1	Select APORT0XCH1	...	...	.....	APORT0XCH15	15	Select APORT0XCH15	APORT0YCH0	16	Select APORT0YCH0	APORT0YCH1	17	Select APORT0YCH1	APORT0YCH15	31	Select APORT0YCH15	APORT1XCH0	32	Select APORT1XCH0	APORT1YCH1	33	Select APORT1YCH1	...	...	.....	APORT1YCH31	63	Select APORT1YCH31	APORT2YCH0	64	Select APORT2YCH0	APORT2XCH1	65	Select APORT2XCH1	...	...	.....	APORT2XCH31	95	Select APORT2XCH31	APORT3XCH0	96	Select APORT3XCH0	APORT3YCH1	97	Select APORT3YCH1	...	...	.....	APORT3YCH31	127	Select APORT3YCH31	APORT4YCH0	128	Select APORT4YCH0	APORT4XCH1	129	Select APORT4XCH1	...	...	.....	APORT4XCH31	159	Select APORT4XCH31	TESTN	245	Reserved for future expansion	VSS	255	VSS
Mode	Value	Description																																																																																
APORT0XCH0	0	Select APORT0XCH0																																																																																
APORT0XCH1	1	Select APORT0XCH1																																																																																
...	...	.....																																																																																
APORT0XCH15	15	Select APORT0XCH15																																																																																
APORT0YCH0	16	Select APORT0YCH0																																																																																
APORT0YCH1	17	Select APORT0YCH1																																																																																
APORT0YCH15	31	Select APORT0YCH15																																																																																
APORT1XCH0	32	Select APORT1XCH0																																																																																
APORT1YCH1	33	Select APORT1YCH1																																																																																
...	...	.....																																																																																
APORT1YCH31	63	Select APORT1YCH31																																																																																
APORT2YCH0	64	Select APORT2YCH0																																																																																
APORT2XCH1	65	Select APORT2XCH1																																																																																
...	...	.....																																																																																
APORT2XCH31	95	Select APORT2XCH31																																																																																
APORT3XCH0	96	Select APORT3XCH0																																																																																
APORT3YCH1	97	Select APORT3YCH1																																																																																
...	...	.....																																																																																
APORT3YCH31	127	Select APORT3YCH31																																																																																
APORT4YCH0	128	Select APORT4YCH0																																																																																
APORT4XCH1	129	Select APORT4XCH1																																																																																
...	...	.....																																																																																
APORT4XCH31	159	Select APORT4XCH31																																																																																
TESTN	245	Reserved for future expansion																																																																																
VSS	255	VSS																																																																																
15:8	POSSEL	0xFF	RW	<b>Single Channel Positive Input Selection</b>																																																																														
Selects the positive input to the ADC for single channel operation. Software can choose any of the 32 channels of any BUS as positive input. In DIFF mode POSSEL and NEGSEL need to be chosen from different resources (X or Y). If an X BUS is connected to POSSEL, only a Y BUS can connect to NEGSEL, and vice-versa. The user can also select some internal nodes as positive input for single-ended sampling. These internal nodes cannot be sampled differentially.																																																																																		
<table border="1"> <thead> <tr> <th>Mode</th><th>Value</th><th>Description</th></tr> </thead> <tbody> <tr><td>APORT0XCH0</td><td>0</td><td>Select APORT0XCH0</td></tr> <tr><td>APORT0XCH1</td><td>1</td><td>Select APORT0XCH1</td></tr> </tbody> </table>					Mode	Value	Description	APORT0XCH0	0	Select APORT0XCH0	APORT0XCH1	1	Select APORT0XCH1																																																																					
Mode	Value	Description																																																																																
APORT0XCH0	0	Select APORT0XCH0																																																																																
APORT0XCH1	1	Select APORT0XCH1																																																																																

Bit	Name	Reset	Access	Description
...	...	...	.....	
APORT0XCH15	15		Select APORT0XCH15	
APORT0YCH0	16		Select APORT0YCH0	
APORT0YCH1	17		Select APORT0YCH1	
APORT0YCH15	31		Select APORT0YCH15	
APORT1XCH0	32		Select APORT1XCH0	
APORT1YCH1	33		Select APORT1YCH1	
...	...	...	.....	
APORT1YCH31	63		Select APORT1YCH31	
APORT2YCH0	64		Select APORT2YCH0	
APORT2XCH1	65		Select APORT2XCH1	
...	...	...	.....	
APORT2XCH31	95		Select APORT2XCH31	
APORT3XCH0	96		Select APORT3XCH0	
APORT3YCH1	97		Select APORT3YCH1	
...	...	...	.....	
APORT3YCH31	127		Select APORT3YCH31	
APORT4YCH0	128		Select APORT4YCH0	
APORT4XCH1	129		Select APORT4XCH1	
...	...	...	.....	
APORT4XCH31	159		Select APORT4XCH31	
AVDD	224		Select AVDD	
BUVDD	225		Select BUVDD	
DVDD	226		Select DVDD	
PAVDD	227		Reserved for future use	
DECOPPLE	228		Select DECOPPLE	
IOVDD	229		Select IOVDD	
IOVDD1	230		Select IOVDD1. Not Applicable if no IOVDD1 is available.	
VSP	231		Reserved for future expansion	
OPA2	242		OPA2 output. Not Applicable if no OPA is available.	
TEMP	243		Temperature sensor	
DAC0OUT0	244		DAC0 output 0. Not Applicable if no DAC is available.	
R5VOUT	245		5V sub-system ADC mux output. Not Applicable if no 5V sub-system is available.	
SP1	246		Reserved for future expansion	
SP2	247		Reserved for future expansion	
DAC0OUT1	248		DAC0 output 1. Not Applicable if no DAC is available.	

Bit	Name	Reset	Access	Description
	SUBLSB	249		SUBLSB measurement enabled.
	OPA3	250		OPA3 output. Not Applicable if no OPA is available.
	VSS	255		VSS
7:5	REF	0x0	RW	<b>Single Channel Reference Selection</b>
				Select reference to ADC single channel mode.
	Value	Mode		Description
	0	1V25		VFS = 1.25V with internal VBGR reference
	1	2V5		VFS = 2.5V with internal VBGR reference
	2	VDD		VFS = AVDD with AVDD as reference source
	3	5V		VFS = 5V with internal VBGR reference
	4	EXTSINGLE		Single ended external reference
	5	2XEXTDIFF		Differential external reference, 2x
	6	2XVDD		VFS = 2xAVDD with AVDD as the reference source
	7	CONF		Use SINGLECTRLX to configure reference
4:3	RES	0x0	RW	<b>Single Channel Resolution Select</b>
				Select single channel conversion resolution.
	Value	Mode		Description
	0	12BIT		12-bit resolution.
	1	8BIT		8-bit resolution.
	2	6BIT		6-bit resolution.
	3	OVS		Oversampling enabled. Oversampling rate is set in OVSRSEL.
2	ADJ	0	RW	<b>Single Channel Result Adjustment</b>
				Select single channel result adjustment.
	Value	Mode		Description
	0	RIGHT		Results are right adjusted.
	1	LEFT		Results are left adjusted.
1	DIFF	0	RW	<b>Single Channel Differential Mode</b>
				Select single ended or differential input.
	Value			Description
	0			Single ended input.
	1			Differential input.
0	REP	0	RW	<b>Single Channel Repetitive Mode</b>
				Enable/disable repetitive single channel conversions.
	Value			Description

Bit	Name	Reset	Access	Description
0				ADC will perform one conversion per trigger in single channel mode.
1				ADC will repeat conversions in single channel mode continuously until SINGLESTOP is written.

## 27.5.5 ADCn\_SINGLECTRLX - Single Channel Control Register Continued

Offset	Bit Position																																	
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset	RW	0x0																																
Access	RW	0x0																																
Name	REPDELAY	CONVSTARTDELAYEN	CONVSTARTDELAY	PRSEL	PRSMODE	FIFOFACT	DVL	VINATT	VREFATT	VREFATTFIX	VREFSEL																							

Bit	Name	Reset	Access	Description
31:29	REPDELAY	0x0	RW	<b>REPDELAY Select for SINGLE REP Mode</b>  Delay value between two repeated conversions.
	Value	Mode		Description
	0	NODELAY		No delay
	1	4CYCLES		4 conversion clock cycles
	2	8CYCLES		8 conversion clock cycles
	3	16CYCLES		16 conversion clock cycles
	4	32CYCLES		32 conversion clock cycles
	5	64CYCLES		64 conversion clock cycles
	6	128CYCLES		128 conversion clock cycles
	7	256CYCLES		256 conversion clock cycles
28	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
27	CONVSTARTDELAYEN	0	RW	<b>Enable Delaying Next Conversion Start</b>  Delay value for next conversion start event.
	Value			Description
	0			CONVSTARTDELAY is disabled.
	1			CONVSTARTDELAY is enabled.
26:22	CONVSTARTDELAY	0x00	RW	<b>Delay Value for Next Conversion Start If CONVSTARTDELAYEN is Set</b>  Delay value for next conversion start event in 1us ticks (based on TIMEBASE).
	Value			Description
	DELAY			Delay the next conversion start by (CONVSTARTDELAY+1) us

Bit	Name	Reset	Access	Description																											
21:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
19:17	PRSSEL	0x0	RW	<b>Single Channel PRS Trigger Select</b>																											
				Select PRS trigger for single channel.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS ch 0 triggers single channel</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS ch 1 triggers single channel</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS ch 2 triggers single channel</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS ch 3 triggers single channel</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS ch 4 triggers single channel</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS ch 5 triggers single channel</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS ch 6 triggers single channel</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS ch 7 triggers single channel</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS ch 0 triggers single channel	1	PRSCH1	PRS ch 1 triggers single channel	2	PRSCH2	PRS ch 2 triggers single channel	3	PRSCH3	PRS ch 3 triggers single channel	4	PRSCH4	PRS ch 4 triggers single channel	5	PRSCH5	PRS ch 5 triggers single channel	6	PRSCH6	PRS ch 6 triggers single channel	7	PRSCH7	PRS ch 7 triggers single channel
Value	Mode	Description																													
0	PRSCH0	PRS ch 0 triggers single channel																													
1	PRSCH1	PRS ch 1 triggers single channel																													
2	PRSCH2	PRS ch 2 triggers single channel																													
3	PRSCH3	PRS ch 3 triggers single channel																													
4	PRSCH4	PRS ch 4 triggers single channel																													
5	PRSCH5	PRS ch 5 triggers single channel																													
6	PRSCH6	PRS ch 6 triggers single channel																													
7	PRSCH7	PRS ch 7 triggers single channel																													
16	PRSMODE	0	RW	<b>Single Channel PRS Trigger Mode</b>																											
				PRS trigger mode of single channel.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PULSED</td><td>Single channel trigger is considered a regular asynchronous pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.</td></tr> <tr><td>1</td><td>TIMED</td><td>Single channel trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.</td></tr> </tbody> </table>	Value	Mode	Description	0	PULSED	Single channel trigger is considered a regular asynchronous pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.	1	TIMED	Single channel trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.																		
Value	Mode	Description																													
0	PULSED	Single channel trigger is considered a regular asynchronous pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.																													
1	TIMED	Single channel trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.																													
15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
14	FIFOFACT	0	RW	<b>Single Channel FIFO Overflow Action</b>																											
				Select how FIFO behaves when full																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>DISCARD</td><td>FIFO stops accepting new data if full, triggers SINGLEOF IRQ.</td></tr> <tr><td>1</td><td>OVERWRITE</td><td>FIFO overwrites old data when full, triggers SINGLEOF IRQ.</td></tr> </tbody> </table>	Value	Mode	Description	0	DISCARD	FIFO stops accepting new data if full, triggers SINGLEOF IRQ.	1	OVERWRITE	FIFO overwrites old data when full, triggers SINGLEOF IRQ.																		
Value	Mode	Description																													
0	DISCARD	FIFO stops accepting new data if full, triggers SINGLEOF IRQ.																													
1	OVERWRITE	FIFO overwrites old data when full, triggers SINGLEOF IRQ.																													
13:12	DVL	0x0	RW	<b>Single Channel DV Level Select</b>																											
				Select single channel Data Valid level. SINGLE IRQ is set when (DVL+1) number of single channels have been converted and their results are available in the Single FIFO.																											
11:8	VINATT	0x0	RW	<b>Code for VIN Attenuation Factor</b>																											
				Used to set the VIN attenuation factor.																											
7:4	VREFATT	0x0	RW	<b>Code for VREF Attenuation Factor When VREFSEL is 1, 2 or 5</b>																											
				Used to set VREF attenuation factor.																											

Bit	Name	Reset	Access	Description
3	VREFATT FIX	0	RW	<b>Enable Fixed Scaling on VREF</b>
Enables fixed scaling on VREF				
Value		Description		
0		VREFATT setting is used to scale VREF when VREFSEL is 1, 2 or 5.		
1		A fixed VREF attenuation is used to cover a large reference source range. When VREFATT = 0, the scaling factor is 1/4. For non-zero values of VREFATT, the scaling factor is 1/3.		
2:0	VREFSEL	0x0	RW	<b>Single Channel Reference Selection</b>
Select reference VREF to ADC single channel mode.				
Value		Mode	Description	
0		VBGR	Internal 0.83V Bandgap reference	
1		VDDXWATT	Scaled AVDD: AVDD*(the VREF attenuation factor)	
2		VREFPWATT	Scaled singled ended external Vref: ADCn_EXTP*(the VREF attenuation factor)	
3		VREFP	Raw single ended external Vref: ADCn_EXTP	
4		VENTROPY	Special mode used to generate ENTROPY.	
5		VREFPNWATT	Scaled differential external Vref from : (ADCn_EXTP-ADCn_EXTN)*(the VREF attenuation factor)	
6		VREFPN	Raw differential external Vref from : (ADCn_EXTP-ADCn_EXTN)	
7		VBGRLOW	Internal Bandgap reference at low setting 0.78V	

## 27.5.6 ADCn\_SCANCTRL - Scan Control Register

Offset	Bit Position																																
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0																																
Access	RW	RW	RW																										RW	RW	RW	RW	RW
Name	CMPEN	PRSEN																											REF	RES	ADJ	DIFF	REP
Bit	Name	Reset	Access	Description																													
31	CMPEN	0	RW	<b>Compare Logic Enable for Scan</b>																													
	Enable/disable Compare Logic																																
	Value			Description																													
	0			Disable Compare Logic.																													
	1			Enable Compare Logic.																													
30	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																															
29	PRSEN	0	RW	<b>Scan Sequence PRS Trigger Enable</b>																													
	Enabled/disable PRS trigger of scan sequence.																																
	Value			Description																													
	0			Scan sequence is not triggered by PRS input																													
	1			Scan sequence is triggered by PRS input selected by PRSEL																													
28	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																															
27:24	AT	0x0	RW	<b>Scan Acquisition Time</b>																													
	Select the acquisition time for scan.																																
	Value	Mode		Description																													
	0	1CYCLE		1 conversion clock cycle acquisition time for scan																													
	1	2CYCLES		2 conversion clock cycles acquisition time for scan																													
	2	3CYCLES		3 conversion clock cycles acquisition time for scan																													
	3	4CYCLES		4 conversion clock cycles acquisition time for scan																													
	4	8CYCLES		8 conversion clock cycles acquisition time for scan																													
	5	16CYCLES		16 conversion clock cycles acquisition time for scan																													
	6	32CYCLES		32 conversion clock cycles acquisition time for scan																													
	7	64CYCLES		64 conversion clock cycles acquisition time for scan																													
	8	128CYCLES		128 conversion clock cycles acquisition time for scan																													
	9	256CYCLES		256 conversion clock cycles acquisition time for scan																													

Bit	Name	Reset	Access	Description																											
23:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
7:5	REF	0x0	RW	<b>Scan Sequence Reference Selection</b>  Select reference to ADC scan sequence.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>1V25</td><td>VFS = 1.25V with internal VBGR reference</td></tr> <tr> <td>1</td><td>2V5</td><td>VFS = 2.5V with internal VBGR reference</td></tr> <tr> <td>2</td><td>VDD</td><td>VFS = AVDD with AVDD as reference source</td></tr> <tr> <td>3</td><td>5V</td><td>VFS = 5V with internal VBGR reference</td></tr> <tr> <td>4</td><td>EXTSINGLE</td><td>Single ended external reference</td></tr> <tr> <td>5</td><td>2XEXTDIFF</td><td>Differential external reference, 2x</td></tr> <tr> <td>6</td><td>2XVDD</td><td>VFS=2xAVDD with AVDD as the reference source</td></tr> <tr> <td>7</td><td>CONF</td><td>Use SCANCTRLX to configure reference</td></tr> </tbody> </table>	Value	Mode	Description	0	1V25	VFS = 1.25V with internal VBGR reference	1	2V5	VFS = 2.5V with internal VBGR reference	2	VDD	VFS = AVDD with AVDD as reference source	3	5V	VFS = 5V with internal VBGR reference	4	EXTSINGLE	Single ended external reference	5	2XEXTDIFF	Differential external reference, 2x	6	2XVDD	VFS=2xAVDD with AVDD as the reference source	7	CONF	Use SCANCTRLX to configure reference
Value	Mode	Description																													
0	1V25	VFS = 1.25V with internal VBGR reference																													
1	2V5	VFS = 2.5V with internal VBGR reference																													
2	VDD	VFS = AVDD with AVDD as reference source																													
3	5V	VFS = 5V with internal VBGR reference																													
4	EXTSINGLE	Single ended external reference																													
5	2XEXTDIFF	Differential external reference, 2x																													
6	2XVDD	VFS=2xAVDD with AVDD as the reference source																													
7	CONF	Use SCANCTRLX to configure reference																													
4:3	RES	0x0	RW	<b>Scan Sequence Resolution Select</b>  Select scan sequence conversion resolution.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>12BIT</td><td>12-bit resolution</td></tr> <tr> <td>1</td><td>8BIT</td><td>8-bit resolution</td></tr> <tr> <td>2</td><td>6BIT</td><td>6-bit resolution</td></tr> <tr> <td>3</td><td>OVS</td><td>Oversampling enabled. Oversampling rate is set in OVSRSEL</td></tr> </tbody> </table>	Value	Mode	Description	0	12BIT	12-bit resolution	1	8BIT	8-bit resolution	2	6BIT	6-bit resolution	3	OVS	Oversampling enabled. Oversampling rate is set in OVSRSEL												
Value	Mode	Description																													
0	12BIT	12-bit resolution																													
1	8BIT	8-bit resolution																													
2	6BIT	6-bit resolution																													
3	OVS	Oversampling enabled. Oversampling rate is set in OVSRSEL																													
2	ADJ	0	RW	<b>Scan Sequence Result Adjustment</b>  Select scan sequence result adjustment.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>RIGHT</td><td>Results are right adjusted</td></tr> <tr> <td>1</td><td>LEFT</td><td>Results are left adjusted</td></tr> </tbody> </table>	Value	Mode	Description	0	RIGHT	Results are right adjusted	1	LEFT	Results are left adjusted																		
Value	Mode	Description																													
0	RIGHT	Results are right adjusted																													
1	LEFT	Results are left adjusted																													
1	DIFF	0	RW	<b>Scan Sequence Differential Mode</b>  Select single ended or differential input.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Single ended input</td></tr> <tr> <td>1</td><td>Differential input</td></tr> </tbody> </table>	Value	Description	0	Single ended input	1	Differential input																					
Value	Description																														
0	Single ended input																														
1	Differential input																														
0	REP	0	RW	<b>Scan Sequence Repetitive Mode</b>  Enable/disable repetitive scan sequence.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>Scan conversion mode is deactivated after one sequence.</td></tr> </tbody> </table>	Value	Description	0	Scan conversion mode is deactivated after one sequence.																							
Value	Description																														
0	Scan conversion mode is deactivated after one sequence.																														

Bit	Name	Reset	Access	Description
1				Scan conversion mode repeats continuously until SCANSTOP is written.

## 27.5.7 ADCn\_SCANCTRLX - Scan Control Register Continued

Offset	Bit Position											
0x01C	31	30	30	29	28	27	26	25	24	23	22	21
<b>Reset</b>	RW	0x0			0	0						
<b>Access</b>	RW				RW	0x00						
<b>Name</b>	REPDELAY				CONVSTARTDELAYEN	RW	0					
					CONVSTARTDELAY							
						RW	0x0	18	19	20	21	
						RW	0x0	17	16	15	14	
						PRSMODE	0					
						FIFOFACT	0					
						DVL	RW	0x0	13	12	11	
						VINATT						
							RW	0x0	9	8	7	
							RW	0x0	5	4	3	
							VREFATTFIX	0			2	
							VREFSEL	0x0	1	0		

Bit	Name	Reset	Access	Description
31:29	REPDELAY	0x0	RW	<b>REPDELAY Select for SCAN REP Mode</b>
				Delay value between two repeated conversions.
	Value	Mode		Description
	0	NODELAY		No delay
	1	4CYCLES		4 conversion clock cycles
	2	8CYCLES		8 conversion clock cycles
	3	16CYCLES		16 conversion clock cycles
	4	32CYCLES		32 conversion clock cycles
	5	64CYCLES		64 conversion clock cycles
	6	128CYCLES		128 conversion clock cycles
	7	256CYCLES		256 conversion clock cycles
28	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
27	CONVSTARTDE-LAYEN	0	RW	<b>Enable Delaying Next Conversion Start</b>
				Delay value for next conversion start event.
	Value			Description
	0			CONVSTARTDELAY is disabled
	1			CONVSTARTDELAY is enabled.
26:22	CONVSTARTDELAY	0x00	RW	<b>Delay Next Conversion Start If CONVSTARTDELAYEN is Set</b>
				Delay value for next conversion start event in 1us ticks (based on TIMEBASE)
	Value			Description
	DELAY			Delay the next conversion start by (DELAY+1) us

Bit	Name	Reset	Access	Description																											
21:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
19:17	PRSEL	0x0	RW	<b>Scan Sequence PRS Trigger Select</b>  Select PRS trigger for scan sequence.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS ch 0 triggers scan sequence</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS ch 1 triggers scan sequence</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS ch 2 triggers scan sequence</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS ch 3 triggers scan sequence</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS ch 4 triggers scan sequence</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS ch 5 triggers scan sequence</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS ch 6 triggers scan sequence</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS ch 7 triggers scan sequence</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS ch 0 triggers scan sequence	1	PRSCH1	PRS ch 1 triggers scan sequence	2	PRSCH2	PRS ch 2 triggers scan sequence	3	PRSCH3	PRS ch 3 triggers scan sequence	4	PRSCH4	PRS ch 4 triggers scan sequence	5	PRSCH5	PRS ch 5 triggers scan sequence	6	PRSCH6	PRS ch 6 triggers scan sequence	7	PRSCH7	PRS ch 7 triggers scan sequence
Value	Mode	Description																													
0	PRSCH0	PRS ch 0 triggers scan sequence																													
1	PRSCH1	PRS ch 1 triggers scan sequence																													
2	PRSCH2	PRS ch 2 triggers scan sequence																													
3	PRSCH3	PRS ch 3 triggers scan sequence																													
4	PRSCH4	PRS ch 4 triggers scan sequence																													
5	PRSCH5	PRS ch 5 triggers scan sequence																													
6	PRSCH6	PRS ch 6 triggers scan sequence																													
7	PRSCH7	PRS ch 7 triggers scan sequence																													
16	PRSMODE	0	RW	<b>Scan PRS Trigger Mode</b>  PRS trigger mode of scan.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PULSED</td><td>Scan trigger is considered a regular async pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.</td></tr> <tr><td>1</td><td>TIMED</td><td>Scan trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.</td></tr> </tbody> </table>	Value	Mode	Description	0	PULSED	Scan trigger is considered a regular async pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.	1	TIMED	Scan trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.																		
Value	Mode	Description																													
0	PULSED	Scan trigger is considered a regular async pulse that starts ADC warm-up, then acquisition/conversion sequence. The ADC_CLK controls the warmup-time.																													
1	TIMED	Scan trigger should be a pulse long enough to provide the required warm-up time for the selected ADC warmup mode. The negative edge requests sample acquisition. DELAY can be used to delay the warm-up request if the pulse is too long.																													
15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
14	FIFOFACT	0	RW	<b>Scan FIFO Overflow Action</b>  Select how FIFO behaves when full																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>DISCARD</td><td>FIFO stops accepting new data if full, triggers SCANOF IRQ.</td></tr> <tr><td>1</td><td>OVERWRITE</td><td>FIFO overwrites old data when full, triggers SCANOF IRQ.</td></tr> </tbody> </table>	Value	Mode	Description	0	DISCARD	FIFO stops accepting new data if full, triggers SCANOF IRQ.	1	OVERWRITE	FIFO overwrites old data when full, triggers SCANOF IRQ.																		
Value	Mode	Description																													
0	DISCARD	FIFO stops accepting new data if full, triggers SCANOF IRQ.																													
1	OVERWRITE	FIFO overwrites old data when full, triggers SCANOF IRQ.																													
13:12	DVL	0x0	RW	<b>Scan DV Level Select</b>  Select Scan Data Valid level. SCAN IRQ is set when (DVL+1) number of scan channels have been converted and their results are available in the SCAN FIFO.																											
11:8	VINATT	0x0	RW	<b>Code for VIN Attenuation Factor</b>  Used to set the VIN attenuation factor.																											
7:4	VREFATT	0x0	RW	<b>Code for VREF Attenuation Factor When VREFSEL is 1, 2 or 5</b>  Used to set VREF attenuation factor.																											

Bit	Name	Reset	Access	Description
3	VREFATT FIX	0	RW	<b>Enable Fixed Scaling on VREF</b>
Enables fixed scaling on VREF				
Value		Description		
0		VREFATT setting is used to scale VREF when VREFSEL is 1, 2 or 5.		
1		A fixed VREF attenuation is used to cover a large reference source range. When VREFATT = 0, the scaling factor is 1/4. For non-zero values of VREFATT, the scaling factor is 1/3.		
2:0	VREFSEL	0x0	RW	<b>Scan Channel Reference Selection</b>
Select reference VREF to ADC scan channel mode.				
Value		Mode	Description	
0		VBGR	Internal 0.83V Bandgap reference	
1		VDDXWATT	Scaled AVDD: AVDD*(the VREF attenuation factor)	
2		VREFPWATT	Scaled singled ended external Vref: ADCn_EXTP*(the VREF attenuation factor)	
3		VREFP	Raw single ended external Vref: ADCn_EXTP	
5		VREFPNWATT	Scaled differential external Vref from : (ADCn_EXTP-ADCn_EXTN)*(the VREF attenuation factor)	
6		VREFPN	Raw differential external Vref from : (ADCn_EXTP-ADCn_EXTN)	
7		VBGRLOW	Internal Bandgap reference at low setting 0.78V	

## 27.5.8 ADCn\_SCANMASK - Scan Sequence Input Mask Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	SCANINPUTEN																															

Bit	Name	Reset	Access	Description
-----	------	-------	--------	-------------

31:0	SCANINPUTEN	0x00000000	RW	Scan Sequence Input Mask
------	-------------	------------	----	--------------------------

Set one or more bits in this mask to select which inputs are included in scan sequence in either single ended or differential mode. This works with SCANINPUTSEL register. The SCANINPUTSEL chooses 32 possible channels for single-ended or 32 pairs of possible channels for differential scanning from BUSes. These chosen channels are referred as ADCn\_INPUTx in the description. Four even inputs from first group of 8 ADCn\_INPUTx and four odd inputs from second group of 8 ADCn\_INPUTx have programmable NEGSEL, defined in SCANNEGSEL register. If the SCANMASK is set to 0 and scan conversion is triggered, ADC will do a conversion with garbage results since no inputs were enabled for conversion.

Mode	Value	Description
DIFF = 0		
INPUT0	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT0 included in mask xxxxxxxxxx1
INPUT1	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT1 included in mask xxxxxxxxxx1x
INPUT2	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT2 included in mask xxxxxxxxxx1xx
INPUT3	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT3 included in mask xxxxxx1xxx
INPUT4	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT4 included in mask xxxxxx1xxxx
INPUT5	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT5 included in mask xxxxx1xxxxx
INPUT6	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT6 included in mask xxxx1xxxxx
INPUT7	xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT7 included in mask xxx1xxxxxx
...	.....	.....
INPUT31	1xxxxxxxxxxxxxxxxxxxxxx	ADCn_INPUT31 included in mask xxxxxxxxxx
DIFF = 1		
INPUT0INPUT0NEG- SEL	xxxxxxxxxxxxxxxxxxxxxx	(Positive input: ADCn_INPUT0 Negative input: chosen by IN- PUT0NEGSEL) included in mask xxxxxxxxxx1

Bit	Name	Reset	Access	Description
	INPUT1INPUT2	xxxxxxxxxxxxxxxxxxxxxx xxxxxxxxx1x		(Positive input: ADCn_INPUT1 Negative input: ADCn_INPUT2) included in mask
	INPUT2INPUT2NEG-SEL	xxxxxxxxxxxxxxxxxxxxxx xxxxxxxx1xx		(Positive input: ADCn_INPUT2 Negative input: chosen by INPUT2NEGSEL) included in mask
	INPUT3INPUT4	xxxxxxxxxxxxxxxxxxxxxx xxxxxx1xxx		(Positive input: ADCn_INPUT3 Negative input: ADCn_INPUT4) included in mask
	INPUT4INPUT4NEG-SEL	xxxxxxxxxxxxxxxxxxxxxx xxxxxx1xxxx		(Positive input: ADCn_INPUT4 Negative input: chosen by INPUT4NEGSEL) included in mask
	INPUT5INPUT6	xxxxxxxxxxxxxxxxxxxxxx xxxxx1xxxxxx		(Positive input: ADCn_INPUT5 Negative input: ADCn_INPUT6) included in mask
	INPUT6INPUT6NEG-SEL	xxxxxxxxxxxxxxxxxxxxxx xxxx1xxxxxx		(Positive input: ADCn_INPUT6 Negative input: chosen by INPUT6NEGSEL) included in mask
	INPUT7INPUT0	xxxxxxxxxxxxxxxxxxxxxx xxx1xxxxxx		(Positive input: ADCn_INPUT7 Negative input: ADCn_INPUT8) included in mask
	INPUT8INPUT9	xxxxxxxxxxxxxxxxxxxxxx xx1xxxxxx		(Positive input: ADCn_INPUT8 Negative input: ADCn_INPUT9) included in mask
	INPUT9INPUT9NEG-SEL	xxxxxxxxxxxxxxxxxxxxxx x1xxxxxx		(Positive input: ADCn_INPUT9 Negative input: chosen by INPUT9NEGSEL) included in mask
	INPUT10INPUT11	xxxxxxxxxxxxxxxxxxxxxx 1xxxxxx		(Positive input: ADCn_INPUT10 Negative input: ADCn_INPUT11) included in mask
	INPUT11IN-PUT11NEGSEL	xxxxxxxxxxxxxxxxxxxxxx1 xxxxxxxxxx		(Positive input: ADCn_INPUT11 Negative input: chosen by INPUT11NEGSEL) included in mask
	INPUT12INPUT13	xxxxxxxxxxxxxxxxxxxxxx1x xxxxxxxxxx		(Positive input: ADCn_INPUT12 Negative input: ADCn_INPUT13) included in mask
	INPUT13IN-PUT13NEGSEL	xxxxxxxxxxxxxxxxxxxxxx1xx xxxxxxxxxx		(Positive input: ADCn_INPUT13 Negative input: chosen by INPUT13NEGSEL) included in mask
	INPUT14INPUT15	xxxxxxxxxxxxxxxxxxxxxx1xxx xxxxxxxxxx		(Positive input: ADCn_INPUT14 Negative input: ADCn_INPUT15) included in mask
	INPUT15IN-PUT15NEGSEL	xxxxxxxxxxxxxxxxxxxxxx1xxxx xxxxxxxxxx		(Positive input: ADCn_INPUT15 Negative input: chosen by INPUT15NEGSEL) included in mask
	INPUT16INPUT17	xxxxxxxxxxxxxxxxxxxxxx1xxxxx xxxxxxxxxx		(Positive input: ADCn_INPUT16 Negative input: ADCn_INPUT17) included in mask
.....	.....	.....		
	INPUT28INPUT29	xxx1xxxxxxxxxxxxxx xxxxxxxxxx		(Positive input: ADCn_INPUT28 Negative input: ADCn_INPUT29) included in mask
	INPUT29INPUT30	xx1xxxxxxxxxxxxxx xxxxxxxxxx		(Positive input: ADCn_INPUT29 Negative input: ADCn_INPUT30) included in mask
	INPUT30INPUT31	x1xxxxxxxxxxxxxx xxxxxxxxxx		(Positive input: ADCn_INPUT30 Negative input: ADCn_INPUT31) included in mask
	INPUT31INPUT24	1xxxxxxxxxxxxxx xxxxxxxxxx		(Positive input: ADCn_INPUT31 Negative input: ADCn_INPUT24) included in mask

## 27.5.9 ADCn\_SCANINPUTSEL - Input Selection Register for Scan Mode

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00																								0x00							
Access	RW																								RW							
Name	INPUT24TO31SEL																								INPUT0TO7SEL							

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28:24	INPUT24TO31SEL	0x00	RW	<b>Inputs Chosen for ADCn_INPUT24-ADCn_INPUT31 as Referred in SCANMASK</b>

Mode	Value	Description
APORT0CH0TO7	0	Select APORT0's CH0-CH7 as ADCn_INPUT24-ADCn_INPUT31
APORT0CH8TO15	1	Select APORT0's CH8-CH15 as ADCn_INPUT24-ADCn_INPUT31
APORT1CH0TO7	4	Select APORT1's CH0-CH7 as ADCn_INPUT24-ADCn_INPUT31
APORT1CH8TO15	5	Select APORT1's CH8-CH15 as ADCn_INPUT24-ADCn_INPUT31
APORT1CH16TO23	6	Select APORT1's CH16-CH23 as ADCn_INPUT24-ADCn_INPUT31
APORT1CH24TO31	7	Select APORT1's CH24-CH31 as ADCn_INPUT24-ADCn_INPUT31
APORT2CH0TO7	8	Select APORT2's CH0-CH7 as ADCn_INPUT24-ADCn_INPUT31
...	.....	.....
APORT3CH0TO7	12	Select APORT3's CH0-CH7 as ADCn_INPUT24-ADCn_INPUT31
...	.....	.....
APORT4CH0TO7	16	Select APORT4's CH0-CH7 as ADCn_INPUT24-ADCn_INPUT31
...	.....	.....

23:21	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
20:16	INPUT16TO23SEL	0x00

Mode	Value	Description
APORT0CH0TO7	0	Select APORT0's CH0-CH7 as ADCn_INPUT16-ADCn_INPUT23
APORT0CH8TO15	1	Select APORT0's CH8-CH15 as ADCn_INPUT16-ADCn_INPUT23
APORT1CH0TO7	4	Select APORT1's CH0-CH7 as ADCn_INPUT16-ADCn_INPUT23

Bit	Name	Reset	Access	Description
	APORT1CH8TO15	5		Select APOR1's CH8-CH15 as ADCn_INPUT16-ADCn_INPUT23
	APORT1CH16TO23	6		Select APOR1's CH16-CH23 as ADCn_INPUT16-ADCn_INPUT23
	APORT1CH24TO31	7		Select APOR1's CH24-CH31 as ADCn_INPUT16-ADCn_INPUT23
	APORT2CH0TO7	8		Select APOR2's CH0-CH7 as ADCn_INPUT16-ADCn_INPUT23
...		.		.....
	APORT3CH0TO7	12		Select APOR3's CH0-CH7 as ADCn_INPUT16-ADCn_INPUT23
...		.		.....
	APORT4CH0TO7	16		Select APOR4's CH0-CH7 as ADCn_INPUT16-ADCn_INPUT23
...		.		.....
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12:8	INPUT8TO15SEL	0x00	RW	<b>Inputs Chosen for ADCn_INPUT8-ADCn_INPUT15 as Referred in SCANMASK</b>

Mode	Value	Description
APORT0CH0TO7	0	Select APOR0's CH0-CH7 as ADCn_INPUT8-ADCn_INPUT15
APORT0CH8TO15	1	Select APOR0's CH8-CH15 as ADCn_INPUT8-ADCn_INPUT15
APORT1CH0TO7	4	Select APOR1's CH0-CH7 as ADCn_INPUT8-ADCn_INPUT15
APORT1CH8TO15	5	Select APOR1's CH8-CH15 as ADCn_INPUT8-ADCn_INPUT15
APORT1CH16TO23	6	Select APOR1's CH16-CH23 as ADCn_INPUT8-ADCn_INPUT15
APORT1CH24TO31	7	Select APOR1's CH24-CH31 as ADCn_INPUT8-ADCn_INPUT15
APORT2CH0TO7	8	Select APOR2's CH0-CH7 as ADCn_INPUT8-ADCn_INPUT15
...	.	.....
APORT3CH0TO7	12	Select APOR3's CH0-CH7 as ADCn_INPUT8-ADCn_INPUT15
...	.	.....
APORT4CH0TO7	16	Select APOR4's CH0-CH7 as ADCn_INPUT8-ADCn_INPUT15
...	.	.....

7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4:0	INPUT0TO7SEL	0x00	RW	<b>Inputs Chosen for ADCn_INPUT7-ADCn_INPUT0 as Referred in SCANMASK</b>

Mode	Value	Description
APORT0CH0TO7	0	Select APOR0's CH0-CH7 as ADCn_INPUT0-ADCn_INPUT7
APORT0CH8TO15	1	Select APOR0's CH8-CH15 as ADCn_INPUT0-ADCn_INPUT7
APORT1CH0TO7	4	Select APOR1's CH0-CH7 as ADCn_INPUT0-ADCn_INPUT7
APORT1CH8TO15	5	Select APOR1's CH8-CH15 as ADCn_INPUT0-ADCn_INPUT7
APORT1CH16TO23	6	Select APOR1's CH16-CH23 as ADCn_INPUT0-ADCn_INPUT7

Bit	Name	Reset	Access	Description
	APORT1CH24TO31	7		Select APORT1's CH24-CH31 as ADCn_INPUT0-ADCn_INPUT7
	APORT2CH0TO7	8		Select APORT2's CH0-CH7 as ADCn_INPUT0-ADCn_INPUT7
...		.		.....
	APORT3CH0TO7	12		Select APORT3's CH0-CH7 as ADCn_INPUT0-ADCn_INPUT7
...		.		.....
	APORT4CH0TO7	16		Select APORT4's CH0-CH7 as ADCn_INPUT0-ADCn_INPUT7
...		.		.....

#### 27.5.10 ADCn\_SCANNEGSEL - Negative Input Select Register for Scan

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:14	INPUT15NEGSEL	0x0	RW	<b>Negative Input Select Register for ADCn_INPUT15 in Differential Scan Mode</b>
	Selects negative channel			
	Value	Mode		Description
	0	INPUT8		Selects ADCn_INPUT8 as negative channel input
	1	INPUT10		Selects ADCn_INPUT10 as negative channel input
	2	INPUT12		Selects ADCn_INPUT12 as negative channel input
	3	INPUT14		Selects ADCn_INPUT14 as negative channel input
13:12	INPUT13NEGSEL	0x3	RW	<b>Negative Input Select Register for ADCn_INPUT13 in Differential Scan Mode</b>
	Selects negative channel			
	Value	Mode		Description
	0	INPUT8		Selects ADCn_INPUT8 as negative channel input
	1	INPUT10		Selects ADCn_INPUT10 as negative channel input
	2	INPUT12		Selects ADCn_INPUT12 as negative channel input
	3	INPUT14		Selects ADCn_INPUT14 as negative channel input
11:10	INPUT11NEGSEL	0x2	RW	<b>Negative Input Select Register for ADCn_INPUT11 in Differential Scan Mode</b>
	Selects negative channel			
	Value	Mode		Description
	0	INPUT8		Selects ADCn_INPUT8 as negative channel input
	1	INPUT10		Selects ADCn_INPUT10 as negative channel input
	2	INPUT12		Selects ADCn_INPUT12 as negative channel input
	3	INPUT14		Selects ADCn_INPUT14 as negative channel input

Bit	Name	Reset	Access	Description															
9:8	INPUT9NEGSEL	0x1	RW	<b>Negative Input Select Register for ADCn_INPUT9 in Differential Scan Mode</b>  Selects negative channel															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>INPUT8</td><td>Selects ADCn_INPUT8 as negative channel input</td></tr> <tr> <td>1</td><td>INPUT10</td><td>Selects ADCn_INPUT10 as negative channel input</td></tr> <tr> <td>2</td><td>INPUT12</td><td>Selects ADCn_INPUT12 as negative channel input</td></tr> <tr> <td>3</td><td>INPUT14</td><td>Selects ADCn_INPUT14 as negative channel input</td></tr> </tbody> </table>	Value	Mode	Description	0	INPUT8	Selects ADCn_INPUT8 as negative channel input	1	INPUT10	Selects ADCn_INPUT10 as negative channel input	2	INPUT12	Selects ADCn_INPUT12 as negative channel input	3	INPUT14	Selects ADCn_INPUT14 as negative channel input
Value	Mode	Description																	
0	INPUT8	Selects ADCn_INPUT8 as negative channel input																	
1	INPUT10	Selects ADCn_INPUT10 as negative channel input																	
2	INPUT12	Selects ADCn_INPUT12 as negative channel input																	
3	INPUT14	Selects ADCn_INPUT14 as negative channel input																	
7:6	INPUT6NEGSEL	0x3	RW	<b>Negative Input Select Register for ADCn_INPUT1 in Differential Scan Mode</b>  Selects negative channel															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>INPUT1</td><td>Selects ADCn_INPUT1 as negative channel input</td></tr> <tr> <td>1</td><td>INPUT3</td><td>Selects ADCn_INPUT3 as negative channel input</td></tr> <tr> <td>2</td><td>INPUT5</td><td>Selects ADCn_INPUT5 as negative channel input</td></tr> <tr> <td>3</td><td>INPUT7</td><td>Selects ADCn_INPUT7 as negative channel input</td></tr> </tbody> </table>	Value	Mode	Description	0	INPUT1	Selects ADCn_INPUT1 as negative channel input	1	INPUT3	Selects ADCn_INPUT3 as negative channel input	2	INPUT5	Selects ADCn_INPUT5 as negative channel input	3	INPUT7	Selects ADCn_INPUT7 as negative channel input
Value	Mode	Description																	
0	INPUT1	Selects ADCn_INPUT1 as negative channel input																	
1	INPUT3	Selects ADCn_INPUT3 as negative channel input																	
2	INPUT5	Selects ADCn_INPUT5 as negative channel input																	
3	INPUT7	Selects ADCn_INPUT7 as negative channel input																	
5:4	INPUT4NEGSEL	0x2	RW	<b>Negative Input Select Register for ADCn_INPUT4 in Differential Scan Mode</b>  Selects negative channel															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>INPUT1</td><td>Selects ADCn_INPUT1 as negative channel input</td></tr> <tr> <td>1</td><td>INPUT3</td><td>Selects ADCn_INPUT3 as negative channel input</td></tr> <tr> <td>2</td><td>INPUT5</td><td>Selects ADCn_INPUT5 as negative channel input</td></tr> <tr> <td>3</td><td>INPUT7</td><td>Selects ADCn_INPUT7 as negative channel input</td></tr> </tbody> </table>	Value	Mode	Description	0	INPUT1	Selects ADCn_INPUT1 as negative channel input	1	INPUT3	Selects ADCn_INPUT3 as negative channel input	2	INPUT5	Selects ADCn_INPUT5 as negative channel input	3	INPUT7	Selects ADCn_INPUT7 as negative channel input
Value	Mode	Description																	
0	INPUT1	Selects ADCn_INPUT1 as negative channel input																	
1	INPUT3	Selects ADCn_INPUT3 as negative channel input																	
2	INPUT5	Selects ADCn_INPUT5 as negative channel input																	
3	INPUT7	Selects ADCn_INPUT7 as negative channel input																	
3:2	INPUT2NEGSEL	0x1	RW	<b>Negative Input Select Register for ADCn_INPUT2 in Differential Scan Mode</b>  Selects negative channel															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>INPUT1</td><td>Selects ADCn_INPUT1 as negative channel input</td></tr> <tr> <td>1</td><td>INPUT3</td><td>Selects ADCn_INPUT3 as negative channel input</td></tr> <tr> <td>2</td><td>INPUT5</td><td>Selects ADCn_INPUT5 as negative channel input</td></tr> <tr> <td>3</td><td>INPUT7</td><td>Selects ADCn_INPUT7 as negative channel input</td></tr> </tbody> </table>	Value	Mode	Description	0	INPUT1	Selects ADCn_INPUT1 as negative channel input	1	INPUT3	Selects ADCn_INPUT3 as negative channel input	2	INPUT5	Selects ADCn_INPUT5 as negative channel input	3	INPUT7	Selects ADCn_INPUT7 as negative channel input
Value	Mode	Description																	
0	INPUT1	Selects ADCn_INPUT1 as negative channel input																	
1	INPUT3	Selects ADCn_INPUT3 as negative channel input																	
2	INPUT5	Selects ADCn_INPUT5 as negative channel input																	
3	INPUT7	Selects ADCn_INPUT7 as negative channel input																	
1:0	INPUT0NEGSEL	0x0	RW	<b>Negative Input Select Register for ADCn_INPUT0 in Differential Scan Mode</b>  Selects negative channel															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> </table>	Value	Mode	Description												
Value	Mode	Description																	

Bit	Name	Reset	Access	Description
0	INPUT1			Selects ADCn_INPUT1 as negative channel input
1	INPUT3			Selects ADCn_INPUT3 as negative channel input
2	INPUT5			Selects ADCn_INPUT5 as negative channel input
3	INPUT7			Selects ADCn_INPUT7 as negative channel input

### 27.5.11 ADCn\_CMPTHR - Compare Threshold Register

Offset	Bit Position																											
0x02C	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
Reset	0x0000																											
Access	RW																											
Name	ADGT ADLT																											

Bit	Name	Reset	Access	Description
31:16	ADGT	0x0000	RW	<b>Greater Than Compare Threshold</b>
				Compare threshold value for greater-than comparison. Must match the conversion data representation chosen.
15:0	ADLT	0x0000	RW	<b>Less Than Compare Threshold</b>
				Compare threshold value for less-than comparison. Must match the conversion data representation chosen.

## 27.5.12 ADCn\_BIASPROG - Bias Programming Register for Various Analog Blocks Used in ADC Operation

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0						
Access																										RW						
Name																										GPBIASACC	VFAULTCLR	ADCBIASPROG				

Bit	Name	Reset	Access	Description																					
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																					
16	GPBIASACC	0	RW	<b>Accuracy Setting for the System Bias During ADC Operation</b>																					
				Select bias accuracy mode for ADC operation. For devices with multiple ADCs, the bias will use the high accuracy setting unless all ADC instances configure GPBIASACC to LOWACC.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>HIGHACC</td> <td>High accuracy setting. Use when configured for an internal VBGR reference source.</td> </tr> <tr> <td>1</td> <td>LOWACC</td> <td>Low accuracy setting. Can be used for all references other than VBGR to conserve energy.</td> </tr> </tbody> </table>	Value	Mode	Description	0	HIGHACC	High accuracy setting. Use when configured for an internal VBGR reference source.	1	LOWACC	Low accuracy setting. Can be used for all references other than VBGR to conserve energy.												
Value	Mode	Description																							
0	HIGHACC	High accuracy setting. Use when configured for an internal VBGR reference source.																							
1	LOWACC	Low accuracy setting. Can be used for all references other than VBGR to conserve energy.																							
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																					
12	VFAULTCLR	0	RW	<b>Clear VREFOF Flag</b>																					
				Use this bit to request clearing of the VREFOF flag. If VREFOF irq is enabled and is triggered, the user must set this bit in the ISR to clear VREFOF. The user needs to reset this bit to enable VREFOF to trigger further IRQs upon VREF overflow conditions.																					
11:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																					
3:0	ADCBIASPROG	0x0	RW	<b>Bias Programming Value of Analog ADC Block</b>																					
				These bits are used to adjust the bias current in ADC analog block.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>NORMAL</td> <td>Normal power (use for 1Msps operation)</td> </tr> <tr> <td>4</td> <td>SCALE2</td> <td>Scaling bias to 1/2</td> </tr> <tr> <td>8</td> <td>SCALE4</td> <td>Scaling bias to 1/4</td> </tr> <tr> <td>12</td> <td>SCALE8</td> <td>Scaling bias to 1/8</td> </tr> <tr> <td>14</td> <td>SCALE16</td> <td>Scaling bias to 1/16</td> </tr> <tr> <td>15</td> <td>SCALE32</td> <td>Scaling bias to 1/32</td> </tr> </tbody> </table>	Value	Mode	Description	0	NORMAL	Normal power (use for 1Msps operation)	4	SCALE2	Scaling bias to 1/2	8	SCALE4	Scaling bias to 1/4	12	SCALE8	Scaling bias to 1/8	14	SCALE16	Scaling bias to 1/16	15	SCALE32	Scaling bias to 1/32
Value	Mode	Description																							
0	NORMAL	Normal power (use for 1Msps operation)																							
4	SCALE2	Scaling bias to 1/2																							
8	SCALE4	Scaling bias to 1/4																							
12	SCALE8	Scaling bias to 1/8																							
14	SCALE16	Scaling bias to 1/16																							
15	SCALE32	Scaling bias to 1/32																							

## 27.5.13 ADCn\_CAL - Calibration Register

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access	RW			RW					RW	0x7						RW	0x8									RW	0x7				RW	
Name	CALEN			SCANGAIN					SCANOFFSETINV							SCANOFFSET										SINGLEOFFSETINV					SINGLEOFFSET	
Bit	Name	Reset	Access	Description																												
31	CALEN	0	RW	<b>Calibration Mode is Enabled</b>	When enabled, the adc performs conversion and sends raw data to the ADC fifos. This can also be used to debug the adc data conversion																											
30:24	SCANGAIN	0x40	RW	<b>Scan Mode Gain Calibration Value</b>	This register contains the gain calibration value used with scan conversions. This field is set to the production gain calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is unsigned. Higher values lead to higher ADC results.																											
23:20	SCANOFFSETINV	0x7	RW	<b>Scan Mode Offset Calibration Value for Negative Single-ended Mode</b>	This register contains the offset calibration value used with scan conversions for negative single-ended mode. This field is set to the production offset calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is encoded as a signed 2's complement number. Higher values lead to lower ADC results.																											
19:16	SCANOFFSET	0x8	RW	<b>Scan Mode Offset Calibration Value for Differential or Positive Single-ended Mode</b>	This register contains the offset calibration value used with scan conversions for differential or positive single-ended mode. This field is set to the production offset calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is encoded as a signed 2's complement number. Higher values lead to lower ADC results.																											
15	OFFSETINVMODE	0	RW	<b>Negative Single-ended Offset Calibration is Enabled</b>	When enabled, along with CALEN bit, the ADC performs negative singled ended conversion. When not enabled, if CALEN is set, DIFF bit of SINGLECTRL register decides whether to do positive single-ended or differential conversion.																											
14:8	SINGLEGAIN	0x40	RW	<b>Single Mode Gain Calibration Value</b>	This register contains the gain calibration value used with single conversions. This field is set to the production gain calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is unsigned. Higher values lead to higher ADC results.																											
7:4	SINGLEOFFSETINV	0x7	RW	<b>Single Mode Offset Calibration Value for Negative Single-ended Mode</b>	This register contains the offset calibration value used with single conversions for negative single-ended mode. This field is set to the production offset calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is encoded as a signed 2's complement number. Higher values lead to lower ADC results.																											

Bit	Name	Reset	Access	Description
3:0	SINGLEOFFSET	0x8	RW	<b>Single Mode Offset Calibration Value for Differential or Positive Single-ended Mode</b>  This register contains the offset calibration value used with single conversions for differential or positive single-ended mode. This field is set to the production offset calibration value for the 1V25 internal reference during reset, hence the reset value might differ from device to device. The field is encoded as a signed 2's complement number. Higher values lead to lower ADC results.

## 27.5.14 ADCn\_IF - Interrupt Flag Register

Offset	Bit Position																															
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset			R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0		
Access			R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0	R	0		
Name			EM23ERR	PRSTIMEDERR	SCANPEND	SCANEXTPEND	PROGERR	VREFOV																				SCAN	SINGLE			

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	EM23ERR	0	R	<b>EM23 Entry Error Flag</b>  Indicates that an incorrect clock was selected as ADC_CLK when going into EM23 resulting in an incorrect conversion.
28	PRSTIMEDERR	0	R	<b>PRS Timed Mode Error Flag</b>  Indicates that in PRS timed mode, a PRS negative edge arrived before the AT event and it was ignored.
27	SCANPEND	0	R	<b>Scan Trigger Pending Flag</b>  Indicates that an external scan (e.g., LESENSE triggered) is running and PRS/software triggered scan has gone pending.
26	SCANEXTPEND	0	R	<b>External Scan Trigger Pending Flag</b>  Indicates that a PRS/software triggered scan is running and the external scan (e.g., LESENSE triggered) has gone pending.
25	PROGERR	0	R	<b>Programming Error Interrupt Flag</b>  Indicates that a programming error has occurred. Read the STATUS register for cause.
24	VREFOV	0	R	<b>VREF Over Voltage Interrupt Flag</b>  Indicates that attenuated vref is greater than 1.3V when this bit is set. The ADC stops converting and disconnects the reference when this happens to protect the internal low-voltage circuits.
23:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	SCANCMP	0	R	<b>Scan Result Compare Match Interrupt Flag</b>  Indicates scan result compare matched the window conditions when this bit is set.
16	SINGLECMP	0	R	<b>Single Result Compare Match Interrupt Flag</b>  Indicates single result compare matched the window conditions when this bit is set.
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	SCANUF	0	R	<b>Scan FIFO Underflow Interrupt Flag</b>  Indicates scan result FIFO underflow when this bit is set. An underflow occurs if the FIFO is read and there is no data available.
10	SINGLEUF	0	R	<b>Single FIFO Underflow Interrupt Flag</b>  Indicates single result FIFO underflow when this bit is set. An underflow occurs if the FIFO is read and there is no data available.

Bit	Name	Reset	Access	Description
9	SCANOF	0	R	<b>Scan FIFO Overflow Interrupt Flag</b>  Indicates scan result FIFO overflow when this bit is set. An overflow occurs if there is not room in the FIFO to store a new result.
8	SINGLEOF	0	R	<b>Single FIFO Overflow Interrupt Flag</b>  Indicates single result FIFO overflow when this bit is set. An overflow occurs if there is not room in the FIFO to store a new result.
7:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	SCAN	0	R	<b>Scan Conversion Complete Interrupt Flag</b>  Indicates (DVL+1) number of scan channel results are available in the Scan FIFO.
0	SINGLE	0	R	<b>Single Conversion Complete Interrupt Flag</b>  Indicates (DVL+1) number of single channel results are available in the Single FIFO.

## 27.5.15 ADCn\_IFS - Interrupt Flag Set Register

Offset	Bit Position																									
0x03C	31	30	29	0	28	W1	0	27	W1	0	26	W1	0	25	W1	0	24	W1	0	23	22	21	20	19	18	
<b>Reset</b>																										
<b>Access</b>																										
<b>Name</b>	EM23ERR	PRSTIMEDERR	SCANPEND	SCANEXTPEND	PROGERR	VREFOV																				
	W1	W1	W1	W1	W1	W1																				

Bit	Name	Reset	Access	Description
31:30	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
29	EM23ERR	0	W1	<b>Set EM23ERR Interrupt Flag</b>
	Write 1 to set the EM23ERR interrupt flag			
28	PRSTIMEDERR	0	W1	<b>Set PRSTIMEDERR Interrupt Flag</b>
	Write 1 to set the PRSTIMEDERR interrupt flag			
27	SCANPEND	0	W1	<b>Set SCANPEND Interrupt Flag</b>
	Write 1 to set the SCANPEND interrupt flag			
26	SCANEXTPEND	0	W1	<b>Set SCANEXTPEND Interrupt Flag</b>
	Write 1 to set the SCANEXTPEND interrupt flag			
25	PROGERR	0	W1	<b>Set PROGERR Interrupt Flag</b>
	Write 1 to set the PROGERR interrupt flag			
24	VREFOV	0	W1	<b>Set VREFOV Interrupt Flag</b>
	Write 1 to set the VREFOV interrupt flag			
23:18	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
17	SCANCMP	0	W1	<b>Set SCANCMP Interrupt Flag</b>
	Write 1 to set the SCANCMP interrupt flag			
16	SINGLECMP	0	W1	<b>Set SINGLECMP Interrupt Flag</b>
	Write 1 to set the SINGLECMP interrupt flag			
15:12	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
11	SCANUF	0	W1	<b>Set SCANUF Interrupt Flag</b>
	Write 1 to set the SCANUF interrupt flag			
10	SINGLEUF	0	W1	<b>Set SINGLEUF Interrupt Flag</b>
	Write 1 to set the SINGLEUF interrupt flag			
9	SCANOF	0	W1	<b>Set SCANOF Interrupt Flag</b>
	Write 1 to set the SCANOF interrupt flag			

Bit	Name	Reset	Access	Description
8	SINGLEOF	0	W1	<b>Set SINGLEOF Interrupt Flag</b>  Write 1 to set the SINGLEOF interrupt flag
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 27.5.16 ADCn\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name	EM23ERR	(R)W1																														

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	EM23ERR	0	(R)W1	<b>Clear EM23ERR Interrupt Flag</b>
				Write 1 to clear the EM23ERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
28	PRSTIMEDERR	0	(R)W1	<b>Clear PRSTIMEDERR Interrupt Flag</b>
				Write 1 to clear the PRSTIMEDERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
27	SCANPEND	0	(R)W1	<b>Clear SCANPEND Interrupt Flag</b>
				Write 1 to clear the SCANPEND interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
26	SCANEXTPEND	0	(R)W1	<b>Clear SCANEXTPEND Interrupt Flag</b>
				Write 1 to clear the SCANEXTPEND interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
25	PROGERR	0	(R)W1	<b>Clear PROGERR Interrupt Flag</b>
				Write 1 to clear the PROGERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
24	VREFOV	0	(R)W1	<b>Clear VREFOV Interrupt Flag</b>
				Write 1 to clear the VREFOV interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
23:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	SCANCMP	0	(R)W1	<b>Clear SCANCMP Interrupt Flag</b>
				Write 1 to clear the SCANCMP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
16	SINGLECMP	0	(R)W1	<b>Clear SINGLECMP Interrupt Flag</b>
				Write 1 to clear the SINGLECMP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
11	SCANUF	0	(R)W1	<b>Clear SCANUF Interrupt Flag</b>  Write 1 to clear the SCANUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
10	SINGLEUF	0	(R)W1	<b>Clear SINGLEUF Interrupt Flag</b>  Write 1 to clear the SINGLEUF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	SCANOF	0	(R)W1	<b>Clear SCANOF Interrupt Flag</b>  Write 1 to clear the SCANOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	SINGLEOF	0	(R)W1	<b>Clear SINGLEOF Interrupt Flag</b>  Write 1 to clear the SINGLEOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

### 27.5.17 ADCn\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	EM23ERR	0	RW	<b>EM23ERR Interrupt Enable</b> Enable/disable the EM23ERR interrupt
28	PRSTIMEDERR	0	RW	<b>PRSTIMEDERR Interrupt Enable</b> Enable/disable the PRSTIMEDERR interrupt
27	SCANPEND	0	RW	<b>SCANPEND Interrupt Enable</b> Enable/disable the SCANPEND interrupt
26	SCANEXTPEND	0	RW	<b>SCANEXTPEND Interrupt Enable</b> Enable/disable the SCANEXTPEND interrupt
25	PROGERR	0	RW	<b>PROGERR Interrupt Enable</b> Enable/disable the PROGERR interrupt
24	VREFOV	0	RW	<b>VREFOV Interrupt Enable</b> Enable/disable the VREFOV interrupt
23:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17	SCANCMP	0	RW	<b>SCANCMP Interrupt Enable</b> Enable/disable the SCANCMP interrupt
16	SINGLECMP	0	RW	<b>SINGLECMP Interrupt Enable</b> Enable/disable the SINGLECMP interrupt
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	SCANUF	0	RW	<b>SCANUF Interrupt Enable</b> Enable/disable the SCANUF interrupt
10	SINGLEUF	0	RW	<b>SINGLEUF Interrupt Enable</b> Enable/disable the SINGLEUF interrupt
9	SCANOF	0	RW	<b>SCANOF Interrupt Enable</b> Enable/disable the SCANOF interrupt

Bit	Name	Reset	Access	Description
8	SINGLEOF	0	RW	<b>SINGLEOF Interrupt Enable</b>  Enable/disable the SINGLEOF interrupt
7:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	SCAN	0	RW	<b>SCAN Interrupt Enable</b>  Enable/disable the SCAN interrupt
0	SINGLE	0	RW	<b>SINGLE Interrupt Enable</b>  Enable/disable the SINGLE interrupt

**27.5.18 ADCn\_SINGLEDATA - Single Conversion Result Data (Actionable Reads)**

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATA																															

Bit	Name	Reset	Access	Description
31:0	DATA	0x00000000	R	<b>Single Conversion Result Data</b>  This register holds the results from the last single channel mode conversion. Reading this field pops one entry from the SINGLE FIFO.

**27.5.19 ADCn\_SCANDATA - Scan Conversion Result Data (Actionable Reads)**

Offset	Bit Position																															
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATA																															

Bit	Name	Reset	Access	Description
31:0	DATA	0x00000000	R	<b>Scan Conversion Result Data</b>  The register holds the results from the last scan mode conversion. Reading this field pops one entry from the SCAN FIFO.

**27.5.20 ADCn\_SINGLEDATAP - Single Conversion Result Data Peek Register**

Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATAP																															

Bit	Name	Reset	Access	Description
31:0	DATAP	0x00000000	R	<b>Single Conversion Result Data Peek</b>
The register holds the results from the last single channel mode conversion. Reading this field will not pop an entry from the SINGLE FIFO.				

**27.5.21 ADCn\_SCANDATAP - Scan Sequence Result Data Peek Register**

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATAP																															

Bit	Name	Reset	Access	Description
31:0	DATAP	0x00000000	R	<b>Scan Conversion Result Data Peek</b>
The register holds the results from the last scan mode conversion. Reading this field will not pop an entry from the SCAN FIFO.				

## 27.5.22 ADCn\_SCANDATAx - Scan Sequence Result Data + Data Source Register (Actionable Reads)

Offset	Bit Position																															
0x068	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset													0x000				0x00000															
Access													R																			
Name													SCANINPUTID													DATA						

Bit	Name	Reset	Access	Description
31:21	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
20:16	SCANINPUTID	0x00	R	<b>Scan Conversion Input ID</b>
		Indicates from which input the results in SCANDATA originated. Reading this field pops one entry from the SCAN FIFO.		
15:0	DATA	0x0000	R	<b>Scan Conversion Result Data</b>
		Holds the results from the last scan conversion. Reading this field pops one entry from the SCAN FIFO.		

## 27.5.23 ADCn\_SCANDATAXP - Scan Sequence Result Data + Data Source Peek Register

Offset	Bit Position																															
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset													0x000				0x00000															
Access													R													R						
Name													SCANINPUTIDPEEK													DATAP						

Bit	Name	Reset	Access	Description
31:21	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
20:16	SCANINPUTIDPEEK	0x00	R	<b>Scan Conversion Data Source Peek</b>
		Indicates from which input channel the results in SCANDATA originated. Reading this field does not pop any entry from the SCAN FIFO.		
15:0	DATAP	0x0000	R	<b>Scan Conversion Result Data Peek</b>
		The register holds the results from the last scan conversion. Reading this field does not pop any entry from the SCAN FIFO.		

## 27.5.24 ADCn\_APORTRREQ - APORTR Request Status Register

Offset	Bit Position																					
0x07C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10
<b>Reset</b>																			0	9	0	8
<b>Access</b>																			0	7	0	6
<b>Name</b>																			APORT4YREQ	R	0	4
																			APORT4XREQ	R	0	3
																			APORT3YREQ	R	0	2
																			APORT3XREQ	R	0	1
																			APORT2YREQ	R	0	0
																			APORT2XREQ	R	0	0
																			APORT1YREQ	R	0	0
																			APORT1XREQ	R	0	0
																			APORT0YREQ	R	0	0
																			APORT0XREQ	R	0	0

Bit	Name	Reset	Access	Description
31:10	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YREQ	0	R	<b>1 If the Bus Connected to APORTR4Y is Requested</b>  Reports if the bus connected to APORTR4Y is being requested from the APORTR
8	APORT4XREQ	0	R	<b>1 If the Bus Connected to APORTR4X is Requested</b>  Reports if the bus connected to APORTR4X is being requested from the APORTR
7	APORT3YREQ	0	R	<b>1 If the Bus Connected to APORTR3Y is Requested</b>  Reports if the bus connected to APORTR3Y is being requested from the APORTR
6	APORT3XREQ	0	R	<b>1 If the Bus Connected to APORTR3X is Requested</b>  Reports if the bus connected to APORTR3X is being requested from the APORTR
5	APORT2YREQ	0	R	<b>1 If the Bus Connected to APORTR2Y is Requested</b>  Reports if the bus connected to APORTR2Y is being requested from the APORTR
4	APORT2XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
3	APORT1YREQ	0	R	<b>1 If the Bus Connected to APORTR1Y is Requested</b>  Reports if the bus connected to APORTR1Y is being requested from the APORTR
2	APORT1XREQ	0	R	<b>1 If the Bus Connected to APORTR1X is Requested</b>  Reports if the bus connected to APORTR1X is being requested from the APORTR
1	APORT0YREQ	0	R	<b>1 If the Bus Connected to APORTR0Y is Requested</b>  Reports if the bus connected to APORTR0Y is being requested from the APORTR
0	APORT0XREQ	0	R	<b>1 If the Bus Connected to APORTR0X is Requested</b>  Reports if the bus connected to APORTR0X is being requested from the APORTR

## 27.5.25 ADCn\_APORTCNFICT - APORTCNFICT Conflict Status Register

Offset	Bit Position																						
0x080	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	
Reset																							
Access																							
Name																							

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	APORT4YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT4Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT4Y is also being requested by another peripheral
8	APORT4XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT4X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT4X is also being requested by another peripheral
7	APORT3YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT3Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT3Y is also being requested by another peripheral
6	APORT3XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT3X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT3X is also being requested by another peripheral
5	APORT2YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT2Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT2Y is also being requested by another peripheral
4	APORT2XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT2X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT2X is also being requested by another peripheral
3	APORT1YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT1Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT1Y is also being requested by another peripheral
2	APORT1XCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT1X is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT1X is also being requested by another peripheral
1	APORT0YCONFLICT	0	R	<b>1 If the Bus Connected to APORTCNFICT0Y is in Conflict With Another Peripheral</b>
				Reports if the bus connected to APORTCNFICT0Y is also being requested by another peripheral

Bit	Name	Reset	Access	Description
0	APORT0XCONFLICT	0	R	<b>1 If the Bus Connected to APOR0X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APOR0X is also being requested by another peripheral

**27.5.26 ADCn\_SINGLEFIFOCOUNT - Single FIFO Count Register**

Offset	Bit Position																																		
0x084	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
<b>Reset</b>																																	0x0		
<b>Access</b>																																	R		
<b>Name</b>																																		SINGLED C	

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	SINGLED C	0x0	R	<b>Single Data Count</b>  Number of unread data available in Single FIFO.

**27.5.27 ADCn\_SCANFIFOCOUNT - Scan FIFO Count Register**

Offset	Bit Position																																		
0x088	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
<b>Reset</b>																																	0x0		
<b>Access</b>																																	R		
<b>Name</b>																																		SCAND C	

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	SCAND C	0x0	R	<b>Scan Data Count</b>  Number of unread data available in Scan FIFO.

#### 27.5.28 ADCn\_SINGLEFIFOCLEAR - Single FIFO Clear Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																																
Name																	SINGLE FIFO CLEAR	W1	0													

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	SINGLEFIFOCLEAR	0	W1	<b>Clear Single FIFO Content</b>  Write a 1 to clear Single FIFO content.

### 27.5.29 ADCn\_SCANFIFOCLEAR - Scan FIFO Clear Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	SCANFIFOCLEAR	0	W1	<b>Clear Scan FIFO Content</b>  Write a 1 to clear Scan FIFO content.

## 27.5.30 ADCn\_APORMASTERDIS - APOR Bus Master Disable Register



Offset	Bit Position																															
0x094	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YMASTER- DIS	0	RW	<b>APORT4Y Master Disable</b>
				Determines if the ADC will request this APOR bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APOR bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APOR bus. This bit allows multiple APOR connected devices to monitor the same APOR bus simultaneously.
	Value			Description
	0			APORT mastering enabled
	1			APORT mastering disabled
8	APORT4XMASTER- DIS	0	RW	<b>APORT4X Master Disable</b>
				Determines if the ADC will request this APOR bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APOR bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APOR bus. This bit allows multiple APOR connected devices to monitor the same APOR bus simultaneously.
	Value			Description
	0			APORT mastering enabled
	1			APORT mastering disabled
7	APORT3YMASTER- DIS	0	RW	<b>APORT3Y Master Disable</b>
				Determines if the ADC will request this APOR bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APOR bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APOR bus. This bit allows multiple APOR connected devices to monitor the same APOR bus simultaneously.
	Value			Description
	0			APORT mastering enabled
	1			APORT mastering disabled

Bit	Name	Reset	Access	Description						
6	APORT3XMASTER- DIS	0	RW	<b>APORT3X Master Disable</b>						
Determines if the ADC will request this APORt bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APORt bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APORt bus. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>APORT mastering enabled</td></tr> <tr> <td>1</td><td>APORT mastering disabled</td></tr> </tbody> </table>					Value	Description	0	APORT mastering enabled	1	APORT mastering disabled
Value	Description									
0	APORT mastering enabled									
1	APORT mastering disabled									
5	APORT2YMASTER- DIS	0	RW	<b>APORT2Y Master Disable</b>						
Determines if the ADC will request this APORt bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APORt bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APORt bus. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>APORT mastering enabled</td></tr> <tr> <td>1</td><td>APORT mastering disabled</td></tr> </tbody> </table>					Value	Description	0	APORT mastering enabled	1	APORT mastering disabled
Value	Description									
0	APORT mastering enabled									
1	APORT mastering disabled									
4	APORT2XMASTER- DIS	0	RW	<b>APORT2X Master Disable</b>						
Determines if the ADC will request this APORt bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APORt bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APORt bus. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>APORT mastering enabled</td></tr> <tr> <td>1</td><td>APORT mastering disabled</td></tr> </tbody> </table>					Value	Description	0	APORT mastering enabled	1	APORT mastering disabled
Value	Description									
0	APORT mastering enabled									
1	APORT mastering disabled									
3	APORT1YMASTER- DIS	0	RW	<b>APORT1Y Master Disable</b>						
Determines if the ADC will request this APORt bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APORt bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APORt bus. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>APORT mastering enabled</td></tr> <tr> <td>1</td><td>APORT mastering disabled</td></tr> </tbody> </table>					Value	Description	0	APORT mastering enabled	1	APORT mastering disabled
Value	Description									
0	APORT mastering enabled									
1	APORT mastering disabled									
2	APORT1XMASTER- DIS	0	RW	<b>APORT1X Master Disable</b>						
Determines if the ADC will request this APORt bus (if selected by POSSEL or NEGSEL or SCANINPUTSEL). When 1, ADC only passively monitors the APORt bus and the selection of the channel for the selected bus is ignored. The channel selection is done by the device that masters the APORt bus. This bit allows multiple APORt connected devices to monitor the same APORt bus simultaneously.										
<table border="1"> <thead> <tr> <th>Value</th><th>Description</th></tr> </thead> </table>					Value	Description				
Value	Description									

Bit	Name	Reset	Access	Description
0				APORT mastering enabled
1				APORT mastering disabled
1:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 28. LESENSE - Low Energy Sensor Interface



### Quick Facts

#### What?

LESENSE is a low energy sensor interface capable of autonomously collecting and processing data from multiple sensors even when in EM2. Flexible configuration makes LESENSE a versatile sensor interface compatible with a wide range of sensors and measurement schemes.

#### Why?

Capability to autonomously monitor sensors allows the EFM32 Tiny Gecko 11 to reside in a low energy mode for long periods of time while keeping track of sensor status and sensor events.

#### How?

LESENSE is highly configurable and is capable of collecting data from a wide range of sensor types. Once the data is collected, the programmable state machine, LESENSE decoder, is capable of processing sensor data without CPU intervention. A large result buffer allows the chip to remain in EM2 for long periods of time while autonomously collecting data.

### 28.1 Introduction

LESENSE is a low energy sensor interface utilizing on-chip peripherals to perform measurement of a configurable set of sensors. The sensor measurements results can be processed by the LESENSE decoder, a configurable state machine with up to 32 states. The results can also be stored in a result buffer to be collected by the CPU or DMA for further processing.

LESENSE operates from EM0 down to EM2, and can wake up the CPU on configurable events.

## 28.2 Features


- Up to 16 sensors
- Autonomous sensor monitoring in EM0, EM1, and EM2
- Highly configurable decoding of sensor results
- Interrupt on sensor events
- Configurable enable signals to external sensors
- Circular buffer for storage of up to 16 sensor results
- Multiple evaluation modes minimize the need for software interaction
- Supports ADC0 sampling and evaluation
- Support for multiple sensor types
  - LC sensors
  - Capacitive sensing
  - General analog sensors

## 28.3 Functional Description

The LESENSE module is capable of controlling on-chip peripherals in order to perform monitoring of different sensors with little or no CPU intervention. LESENSE uses the analog comparators (ACMP) or ADC0 for measurement of sensor signals. LESENSE can also control the VDAC to generate accurate reference voltages. [Figure 28.1 LESENSE Block Diagram on page 986](#) shows an overview of the LESENSE module.

The LESENSE module consists of a sequencer, an evaluation block, a decoder, and a RAM block:

- The sequencer handles interaction with other peripherals and controls timing of sensor measurements. It also includes a counter that can be used to count pulses on the ACMP output.
- The evaluation block is used to process the data collected by the sequencer.
- To autonomously analyze sensor results, the LESENSE decoder provides the ability to define a finite state machine with up to 32 states, as well as define programmable actions upon state transitions. This allows the decoder to implement a wide range of decoding schemes, such as quadrature decoding.
- A RAM block is used for storage of configuration and measurement results. This allows LESENSE to have a relatively large result buffer enabling the chip to remain in a low energy mode for long periods of time while collecting sensor data.



**Figure 28.1. LESENSE Block Diagram**

### 28.3.1 Channel Configuration

LESENSE has 16 individually configurable channels, each with its own set of configuration registers. Channel configuration is split into three registers; CHx\_TIMING, CHx\_INTERACT, and CHx\_EVAL. Individual timing for each sensor is configured in CHx\_TIMING, sensor interaction is configured in CHx\_INTERACT, and configurations regarding evaluation of the measurements are done in CHx\_EVAL. For improved readability, CHx\_CONF will be used to refer to the channel configuration registers (CHx\_TIMING, CHx\_INTERACT, and CHx\_EVAL) throughout this chapter.

By default, the channel configuration registers are directly mapped to the channel number. Configuring SCANCONF in CTRL makes it possible to alter this mapping.

Configuring SCANCONF to INVMAP will make channels 0-7 use the channel configuration registers for channels 8-15, and vice versa. This feature allows an application to quickly and easily switch the configuration set for the channels.

Setting SCANCONF to TOGGLE will make channel x alternate between using CHx\_CONF and CHx+8\_CONF. The configuration used is decided by the state of the corresponding bit in SCANRES. For instance, if channel 3 is performing a scan and bit 3 in SCANRES is set, CH11\_CONF will be used. Channels 8 through 15 will toggle between CHx\_CONF and CHx+8\_CONF. This mode provides an easy way to implement hysteresis on channel events, as threshold values can be changed depending on the sensor status.

Setting SCANCONF to DECDEF will make the state of the decoder define which scan configuration to be used. If the decoder state is at index 16 or higher, channel x will use CHx+8\_CONF, otherwise it will use CHx\_CONF. Similarly, channels 8 through 15 will use CHx\_CONF when the decoder state index is less than 8 and CHx+8\_CONF when the decoder state index is higher than 7. Allowing the decoder state to define which configuration to use enables easy implementation of hysteresis, for example, as different threshold values can be used for the same channel depending on the state of the application. [Table 28.1 LESENSE Scan Configuration Selection on page 987](#) summarizes how channel configuration is selected for different settings of SCANCONF.

**Table 28.1. LESENSE Scan Configuration Selection**

LESENSE channel x	SCANCONF						
	DIRMAP	INVMAP	TOGGLE		DECDEF		
			SCANRES[n] = 0	SCANRES[n] = 1	DECSTATE < 16	DECSTATE >= 16	
0 <= x < 8	CHx_CONF	CHx+8_CONF	CHx_CONF	CHx+8_CONF	CHx_CONF	CHx+8_CONF	
8 <= x < 16	CHx_CONF	CHx+8_CONF	CHx_CONF	CHx+8_CONF	CHx_CONF	CHx+8_CONF	

Channels are enabled in the CHEN register, where bit x enables channel x. During a scan, all enabled channels are measured, starting with the lowest indexed channel. [Figure 28.3 Scan Sequence on page 988](#) illustrates a scan sequence with channels 3, 5, and 9 enabled.

### 28.3.2 Scan Sequence

LESENSE runs on LFACLK<sub>LESENSE</sub>, which is a prescaled version of LFACLK. The prescaling factor for LFACLK<sub>LESENSE</sub> is selected in the CMU, available prescaling factors are:


- DIV1: LFACLK<sub>LESENSE</sub> = LFACLK/1
- DIV2: LFACLK<sub>LESENSE</sub> = LFACLK/2
- DIV4: LFACLK<sub>LESENSE</sub> = LFACLK/4
- DIV8: LFACLK<sub>LESENSE</sub> = LFACLK/8

All enabled channels are scanned each scan period. How a new scan is started is configured in the SCANMODE bit field in CTRL. If set to PERIODIC, the scan frequency is generated using a counter which is clocked by LFACLK<sub>LESENSE</sub>. This counter has its own prescaler. This prescaling factor is configured in PCPRESC in TIMCTRL. A new scan sequence is started each time the counter reaches the top value, PCTOP. The scan frequency is calculated using [Figure 28.2 Scan Frequency on page 988](#). If SCANMODE is set to ONE-SHOT, a single scan will be made when START in CMD is set. To start a new scan on a PRS event, set SCANMODE to PRS and configure PRS channel in PRSSEL. The PRS start signal needs to be active for at least one LFACLK<sub>LESENSE</sub> cycle to make sure LESENSE is able to register it.

$$F_{\text{scan}} = \text{LFACLK}_{\text{LESENSE}} / ((1 + \text{PCTOP}) * 2^{\text{PCPRESC}})$$

**Figure 28.2. Scan Frequency**

It is possible to interleave additional sensor measurements in between the periodic scans. Issuing a start command when LESENSE is idle will immediately start a new scan, without disrupting the frequency of the periodic scans. If the period counter overflows during the interleaved scan, the periodically scheduled scan will start immediately after the interleaved scan completes.




**Figure 28.3. Scan Sequence**

### 28.3.3 Sensor Timing

For each channel in the scan sequence, the LESENSE interface goes through three phases: idle, excite, and measure. The durations of the excite and measure phases are configured in the CHx\_TIMING registers. The excite phase duration can be configured to be either a number of AUXHFRCO cycles or a number of LFACLK<sub>LESENSE</sub> cycles, depending on which one is selected by the EXCLK bit in the CHx\_INTERACT register. LESENSE includes two timers: A low frequency timer, running on LFACLK<sub>LESENSE</sub>, and a high frequency timer, running on AUXHFRCO. The low frequency or high frequency timers can be prescaled by configuring LFPRESC or AUXPRES, respectively, in the TIMCTRL register. The duration of the measure phase is programmed via MEASUREDLY and SAMPLEDLY in the CHx\_TIMING registers. The output of the ACMP will be ignored for MEASUREDLY EXCLK cycles after start of the sensor measurement. Sampling of the sensor will happen after SAMPLEDLY LFACLK<sub>LESENSE</sub>, or AUXHFRCO cycles, depending on the configuration of the SAMPLECLK in the CHx\_INTERACT register. The configurable measure- and sample delays enables LESENSE to easily define exact time windows for sensor measurements. A start delay can be inserted before sensor measurement begin by configuring STARTDLY in TIMCTRL. This delay can be used to ensure that the VDAC conversion is done and voltages have stabilized before the sensor measurement begins. The AUXHFRCO startup can be delayed until the system enters the excite phase, by configuring AUXSTARTUP in TIMCTRL to ONDEMAND. This will reduce the time the AUXHFRCO is enabled and reduce power consumption, with the tradeoff that the starting point for high frequency timing will also be delayed the same amount as the AUXHFRCO startup time.

[Figure 28.4 Timing Diagram, AUXHFRCO Based Timing on page 989](#) depicts a sensor sequence with AUXHFRCO based timing (EXTIME=5, MEASUREDLY=7, SAMPLEDLY=13), while [Figure 28.5 Timing Diagram, LFACLK Based Timing on page 990](#) depicts a sequence with LFACLK<sub>LESENSE</sub> based timing (EXTIME=1, MEASUREDLY=1, SAMPLEDLY=2).



**Figure 28.4. Timing Diagram, AUXHFRCO Based Timing**




Figure 28.5. Timing Diagram, LFACLK Based Timing

### 28.3.4 Sensor Interaction

Many sensor types require some type of excitation in order to work. The LESENSE module can generate a variety of sensor stimuli, both on the same pin as the measurement is to be made on, as well as alternative pins.

By default, excitation is performed on the pin associated with the channel (i.e., excitation and sensor measurement is performed on the same pin). The mode of the pin during the excitation phase is configured by the EXMODE bitfield in CHx\_INTERACT. The available modes during the excite phase are:

- DISABLED: The pin is disabled.
- HIGH: The pin is driven high.
- LOW: The pin is driven low.
- DACOUT: The pin is connected to the output of a VDAC channel.


**Note:** Excitation with VDAC output is only available on some channels. Refer to [28.3.9 VDAC Interface](#) for details. If the VDAC is in opamp-mode, setting EXMODE to DACOUT will result in excitation with output from the opamp.

LESENSE is able to perform sensor excitation on a pin other than the one being measured. When ALTEX in CHx\_INTERACT is set, the excitation will occur on the alternative excite pin associated with the given channel. By default, the alternative excite pins are mapped to the LES\_ALTEX pins, but they can also be mapped to LESENSE CH<sub>x+8 mod 16</sub>. Mapping of the alternative excite pins is configured in ALTEXMAP in the CTRL register. [Table 28.2 LESENSE Excitation Pin Mapping on page 991](#) summarizes the mapping of excitation pins for different configurations.

**Table 28.2. LESENSE Excitation Pin Mapping**

LESENSE channel	ALTEX = 0	ALTEX = 1	
		ALTEXMAP = CH	ALTEXMAP = ALTEX
0	LES_CH0	LES_CH8	LES_ALTEX0
1	LES_CH1	LES_CH9	LES_ALTEX1
2	LES_CH2	LES_CH10	LES_ALTEX2
3	LES_CH3	LES_CH11	LES_ALTEX3
4	LES_CH4	LES_CH12	LES_ALTEX4
5	LES_CH5	LES_CH13	LES_ALTEX5
6	LES_CH6	LES_CH14	LES_ALTEX6
7	LES_CH7	LES_CH15	LES_ALTEX7
8	LES_CH8	LES_CH0	LES_ALTEX0
9	LES_CH9	LES_CH1	LES_ALTEX1
10	LES_CH10	LES_CH2	LES_ALTEX2
11	LES_CH11	LES_CH3	LES_ALTEX3
12	LES_CH12	LES_CH4	LES_ALTEX4
13	LES_CH13	LES_CH5	LES_ALTEX5
14	LES_CH14	LES_CH6	LES_ALTEX6
15	LES_CH15	LES_CH7	LES_ALTEX7

[Figure 28.6 Pin Sequencing on page 992](#) illustrates the sequencing of the pin associated with the active channel and its alternative pin.



**Figure 28.6. Pin Sequencing**

The LES\_ALTEXn pins have the ability to excite regardless of what channel is active. Setting AEXn in ALTEXCONF will make LES\_ALTEXn excite for all channels using alternative excitation (i.e., ALTEX in CHx\_INTERACT is set).

**Note:** When exciting on the pin associated with the active channel, the pin will go through a tri-stated phase before returning to the idle configuration. This will not happen on pins used as alternative excitation pins.

The pin configuration for the idle phase can be configured individually for each LESENSE channel and alternative excite pin in the IDLECONF and ALTEXCONF registers. The modes available are the same as the modes available in the excitation phase. In the measure phase, the pin mode on the active channel is always disabled (analog input).

To allow the LESENSE mode to control a GPIO pin, the pin must be enabled in the ROUTEPEN register and configured as push-pull. The IDLECONF configuration should not be altered while the pin enable for a given pin is set in ROUTEPEN.

### 28.3.5 Sensor Sampling

During the measurement phase, LESENSE can sample data from sensors using either ADC0 or an ACMP. This is configured in CHx\_INTERACT\_SAMPLE. If the ACMP is used, LESENSE can evaluate the ACMP output at a single point in time (CHx\_INTERACT\_SAMPLE = ACMP), or count pulses on the ACMP output (CHx\_INTERACT\_SAMPLE = ACMPCOUNT) for a programmable period of time.

LESENSE includes the ability to sample both analog comparators simultaneously, effectively cutting the time spent on sensor interaction in some applications in half. Setting DUALSAMPLE in CTRL enables this mode. In dual sample mode, channels X and X+8 are paired, meaning they will be sampled at the same time. DUALSAMPLE mode only works when CHx\_INTERACT\_SAMPLE is set to ACMP.

If ADC0 is used, LESENSE will initiate ADC conversions and fetch the ADC data for further evaluation. If the ADC is configured in differential mode, CHx\_INTERACT\_SAMPLE must be set to ADCDIFF. In this mode, the output from the ADC and the threshold used for comparison are given in two's complement notation.


See sections [28.3.12 ADC Interface](#) and [28.3.10 ACMP Interface](#) for more details on the LESENSE interface to the ADC and ACMPs. The sampled data from ADC or ACMP will be referred to as sensor data in the remainder of this manual.

### 28.3.6 Sensor Evaluation

When a measurement phase is completed, the sensor data is evaluated by the evaluation block. If the sensor data is taken from ACMP sample in a single point in time (CHx\_INTERACT\_SAMPLE = ACMP), the evaluation is limited to determining if the sensor data is 0 or 1. For the other sample modes, there are three ways to do sensor evaluation; threshold comparison, sliding window, or step detection. Evaluation mode is configured in CHx\_EVAL\_MODE.

If the evaluation of sensor data evaluates to true, the corresponding bit in the result register (SCANRES) is set. By configuring SETIF in CHx\_INTERACT, interrupt flags can also be set on SCANRES events. [Figure 28.7 Scan Result and Interrupt Generation on page 993](#) illustrates how the sensor data or ACMP sample is used for evaluation and interrupt generation.

**Note:** For initialization purposes, SCANRES can be written by software. SCANRES should not be written while LESENSE is running (i.e., the RUNNING bit in LESENSE\_STATUS is high).



**Figure 28.7. Scan Result and Interrupt Generation**


The results from sensor data evaluation can be fed into the decoder through the SENSORSTATE register. In DUALSAMPLE mode, results from both the sampled ACMPs will be stored in both SCANRES and SENSORSTATE.

#### 28.3.6.1 Threshold Comparison

In threshold comparison mode, the sensor data is compared to a threshold configured in CHx\_EVAL\_COMPTHRES. There are two modes of threshold comparison: 'less than' and 'greater than or equal'. Threshold comparison mode is configured in CHx\_EVAL\_COMP.

### 28.3.6.2 Sliding Window

In sliding window mode, the sensor data is compared against the upper and lower limits of a window range. The window is defined by a base, given by CHx\_EVAL\_COMPTHRES, and a size configured in EVALCTRL\_WINSIZE. The window size is constant and the same for all LESENSE channels, while the base is specific to each channel and will be updated by LESENSE when the sensor data is outside the current window range. If the sensor data is within the window range, the sensor evaluation will remain the same as it was for the previous measurement. If the sensor data is below the window range, the measurement will be evaluated to false. If the sensor data is above the window range, the measurement will be evaluated to true. In both cases, the window base in CHx\_EVAL\_COMPTHRES will be updated to reflect the new window range. [Figure 28.8 Sliding Window on page 994](#) shows how the sliding window evaluation mode can be used to implement a system with two self calibrating thresholds.



**Figure 28.8. Sliding Window**

### 28.3.6.3 Step Detection

Step detection is used to detect steps in the sensor data compared to sensor data from the previous measurement. The size of the step is configured in EVALCTRL\_WINSIZE. In this mode, step up and step down are evaluated as described in [Figure 28.9 Step Detection on page 994](#):


$$\begin{aligned} \text{STEP\_UP} &= \text{SENSORDATA}_i \geq \text{SENSORDATA}_{i-1} + \text{EVALCTRL\_WINSIZE} \\ \text{STEP\_DOWN} &= \text{SENSORDATA}_i < \text{SENSORDATA}_{i-1} - \text{EVALCTRL\_WINSIZE} \end{aligned}$$

**Figure 28.9. Step Detection**

If either a step up or a step down is detected, the SCANRES bit for the active channel will be set. In addition, the STEPDIR bit for the channel will be updated to indicate if a step up or a step down was detected. STEPDIR = 1 indicates a step up. In this mode, previous sensor data is stored in CHx\_EVAL\_COMPTHRES.

### 28.3.7 Decoder

Many applications, such as quadrature decoding, require some sort of processing of the sensor readings. In quadrature decoding, the sensors repeatedly pass through a set of states which correspond to the position of the sensors. This sequence, and many other decoding schemes, can be described as a finite state machine. To support this type of decoding without CPU intervention, the LESENSE module includes a highly configurable decoder capable of decoding input from up to four sensors. The decoder is implemented as a programmable state machine with up to 32 states. When doing a sensor scan, the results from the sensors are placed in the decoder input register, SENSORSTATE, if DECODE in CHx\_INTERACT is set. The resulting position after a scan is illustrated in [Figure 28.10 Sensor Scan and Decode Sequence on page 995](#), where the bottom blocks show how the SENSORSTATE register is filled. If step detection is enabled, the step direction is placed in SENSORSTATE in the position after the sensor result. When the scan sequence is complete, the decoder evaluates the state of the sensors chosen for decoding, as depicted in [Figure 28.10 Sensor Scan and Decode Sequence on page 995](#).




**Figure 28.10. Sensor Scan and Decode Sequence**

Upon a state transition, LESENSE can generate a pulse on one or more of the decoder PRS channels. Which PRS channel to generate a pulse on is configured in the PRSACT bit field. If PRSCNT in DECCTRL is set, count signals will be generated on decoder PRS channels 0 and 1 according to the PRSACT configuration. In this mode, channel 0 will pulse each time a count event occurs, while channel 1 indicates the count direction (1 being up and 0 being down). The count direction will be kept at its previous state in between count events. The EFM32 Tiny Gecko 11 pulse counter may be used to keep track of events based on these PRS outputs.

If SETIF is set, the DECODER interrupt flag will be set when the transition occurs. If INTMAP in DECCTRL and SETIF is set, a transition from state x or x+16 will set the CHx interrupt flag in addition to the DECODER flag.

Setting CHAIN in STx\_TCONFA enables the decoder to evaluate more than two possible transitions for each state. If none of the transitions defined in STx\_TCONFA or STx\_TCONFb match, the decoder will jump to the next descriptor pair and evaluate the transitions defined there. The decoder uses two LFACLK<sub>LESENSE</sub> cycles for each descriptor pair to be evaluated. If ERRCHK in CTRL is set, the decoder will check that the sensor state has not changed if none of the defined transitions match. The DECERR interrupt flag will be set if none of the transitions match and the sensor state has changed. [Figure 28.11 Decoder State Transition Evaluation on page 996](#) illustrates state transitions. The "Generate PRS signals and set interrupt flag" blocks will perform actions according to the configuration in STx\_TCONFA and STx\_TCONFb.

**Note:** If only one transition from a state is used, STx\_TCONFA and STx\_TCONFb should be configured equally.



**Figure 28.11. Decoder State Transition Evaluation**

The DECODER has a PRS output named DECCMP. This output can be used to indicate which state, or subset of states, the decoder is currently in. This PRS output is enabled by setting DECCMPEN in PRSCTRL, and configured through DECCMPMASK and DECCMPVAL in PRSCTRL. The value of this PRS output is given by [Figure 28.12 DECCMP PRS Output on page 997](#),

PRS\_DECCMP = (DECSTATE & ~DECCMPMASK) == (DECCMPVAL & ~DECCMPMASK)

Figure 28.12. DECCMP PRS Output

To prevent unnecessary interrupt requests or PRS outputs when the decoder toggles back and forth between two states, a hysteresis option is available. The hysteresis function is triggered if a type A transition is preceded by a type B transition, and vice versa. A type A transition is defined in STx\_TCONFA, and a type B transition is defined in STx\_TCONFb. When descriptor chaining is used, a jump to another descriptor will cancel out the hysteresis effect. [Figure 28.13 Decoder Hysteresis on page 997](#) illustrates how the hysteresis triggers upon state transitions.




Figure 28.13. Decoder Hysteresis

- When HYSTPRSx is set, PRS signal x is suppressed when the hysteresis triggers.
- When HYSTIRQ is set, interrupt requests are suppressed when the hysteresis triggers.

**Note:** The decoder error interrupt flag, DECERR, is not affected by the hysteresis.


### 28.3.8 Measurement Results

Part of the LESENSE RAM is treated as a circular buffer for storage of up to 16 sensor measurements results. Each time LESENSE writes data to the result buffer, the result write pointer (PTR\_WR) is incremented. Each time a new result is read through the BUFDATA register, the result read pointer (PTR\_RD) is incremented. The read pointer will not be incremented if there is no valid, unread data in the result buffer. By default LESENSE will not write additional data to a full result buffer until the data is read by software or DMA. Setting BUFWOF in CTRL enables LESENSE to write to the result buffer even if it is full. In this mode, the result read pointer will follow the write pointer if the buffer is full. The result of this is that data read from the result read register (BUFDATA) will be the oldest unread result. The location pointers are available in PTR.

The result buffer has three flags in the STATUS register: BUFDATAV, BUFHALFFULL, and BUFFULL. The flags indicate when new data is available, when the buffer is half full, and when it is full, respectively.

The result buffer also has three interrupt flags in the IR register: BUFDATAV, BUFSIZE, and BUFOF. BUFDATAV is set when data is available in the buffer. BUFSIZE is set when the buffer is either full or half-full, depending on the configuration of BUFLDL in CTRL. BUFOF is set if the result buffer overflows.

During a scan, the state of each sensor is stored in SCANRES. If a sensor triggers, a 1 is stored in SCANRES, else a 0 is stored in SCANRES. Whether or not a sensor is said to be triggered depends of the configuration for the given channel. See [28.3.6 Sensor Evaluation](#) for details. If STRSAMPLE in CHx\_EVAL is set, the sensor data for each channel will be stored in the LESENSE result buffer. If STRSCANRES in CTRL is set, the result vector, SCANRES, will also be stored in the result buffer. This will be stored after each scan and will be interleaved with the counter values. The contents of the result buffer can be read from BUFDATA or from BUF[x]\_DATA. When reading from BUF[x]\_DATA, neither the result read pointer or the status flags BUFDATAV, BUFHALFFULL, or BUFFULL will be updated. When reading through the BUFDATA register, the oldest unread result will be read.



**Figure 28.14. Circular Result Buffer**

[Figure 28.14 Circular Result Buffer on page 998](#) illustrates how the result buffer would be filled when channels 3, 5, and 9 are enabled and have STRSAMPLE in CHx\_EVAL set, in addition to STRSCANRES in CTRL. The measurement result from the three channels will be sequentially written during the scan, while SCANRES is written to the result buffer upon scan completion.

### 28.3.9 VDAC Interface

LESENSE is able to drive the VDAC for generation of accurate reference voltages. This is enabled by setting DACCHxEN in PERCTRL. The refresh rate of the VDAC channels can be configured in DACCONVTRIG in PERCTRL. If DACCONVTRIG is set to CHANNELSTART, the VDAC channels are refreshed prior to each sensor measurement, as depicted in [Figure 28.4 Timing Diagram, AUXHFRCO Based Timing on page 989](#). If DACCONVTRIG is set to SCANSTART, the VDAC channels are refreshed prior to each scan. The conversion data is either taken from the data registers in the EFM32 Tiny Gecko 11 VDAC interface (VDAC0\_CH0DATA and VDAC0\_CH1DATA) or from the THRES bitfield in the CHx\_INTERACT register for the active LESENSE channel. VDAC data used is configured in DACCHxDATA in PERCTRL.

Bias configuration, calibration and reference selection is done in the EFM32 Tiny Gecko 11 VDAC module and LESENSE will not override these configurations.

LESENSE has the possibility to control switches that connect the VDAC alternate outputs. This allows LESENSE to excite sensors with output from the VDAC channels, this is done by setting CHx\_INTERACT\_EXMODE to DACOUT. The LESENSE channels can also be connected to the VDAC output when the given channel is idle, this is done by setting IDLECONF\_CHx to DAC.

**Note:** Only LESENSE channels 0, 1, 2, 3, 12, 13, 14, 15 have the possibility to excite using the VDAC alternate outputs, or connect to the VDAC alternate outputs during the idle phase.

The VDAC may be chosen as reference to the analog comparators for accurate reference generation. If the VDAC is configured in continuous mode this does not require any external components. If sample/off mode is used, an external capacitor is needed to maintain the voltage between samples. To configure the VDAC to use this external capacitor, connect the capacitor to the VDAC pin for the given channel and set SHORT in VDAC\_OPAX\_OUT.

**Note:** The VDAC mode should not be altered while DACACTIVE in STATUS is set

### 28.3.10 ACMP Interface

The analog comparators (ACMPs) are used to measure the sensors, and have to be configured according to the application in order for LESENSE to work properly. Depending on the configuration in the ACMP0MODE and ACMP1MODE bit-fields in PERCTRL, LESENSE will take control of the positive input mux and the voltage dividers (DIVVA, DIVVB) for ACMP0 and ACMP1. The remaining configuration of the analog comparators is done in the ACMP register interface.

If ACMPxMODE in PERCTRL is set to MUX, LESENSE will take control of the positive input mux of the ACMP, through the external override interface, described in the ACMP chapter (see [26.3.12 External Override Interface](#)). The offset given by LESENSE, EXT\_OFFSET, depends on whether one or two ACMPs are controlled by LESENSE. If only one ACMP is used, EXT\_OFFSET will have the same value as the active channel. If both ACMP0 and ACMP1 are used, LESENSE channel 0-7 will use ACMP0 with EXT\_OFFSET 0-7, and LESENSE channel 8-15 will use ACMP1 with EXT\_OFFSET 0-7.

If ACMPxMODE in PERCTRL is set to MUXTHRES, LESENSE will also take control of the voltage dividers in the ACMP, DIVVA and DIVVB. The thresholds used are individual to each channel and is configured using the 6 LSBs of CHx\_INTERACT\_THRES. By default, ACMP\_HYSTERESIS0\_DIVVX and ACMP\_HYSTERESIS1\_DIVVX will be given the same value, the 6 LSBs of CHx\_INTERACT\_THRES. To allow different values for ACMP\_HYSTERESIS0\_DIVVX and ACMP\_HYSTERESIS1\_DIVVX, ACMPxHYSTEN in PERCTRL needs to be set. This allows the hysteresis feature in the ACMP to be utilized. ACMP\_HYSTERESIS0\_DIVVX will get the value programmed in CHx\_INTERACT\_THRES[5:0], while ACMP\_HYSTERESIS1\_DIVVX will get the value programmed in CHx\_INTERACT\_THRES[11:6].

### 28.3.11 ACMP and VDAC Duty Cycling

By default, the analog comparators and the VDAC are shut down between LESENSE scans to save energy. If this is not desired, WAR-MUPMODE in PERCTRL can be configured to prevent them from being shut down.

Both the VDAC and analog comparators rely on a bias module for correct operation. This bias module has a low power mode which consumes less energy at the cost of reduced accuracy. BIASEMODE in BIASECTRL configures how the bias module is controlled by LESENSE. When set to DUTYCYCLE, LESENSE will set the bias module in high accuracy mode whenever LESENSE is active, and keep it in the low power mode otherwise. When BIASEMODE is set to HIGHACC, the high accuracy mode is always selected. When set to DONTTOUCH, LESENSE will not control the bias module.

### 28.3.12 ADC Interface

The LESENSE module can be configured to trigger conversions on ADC0 and use data from ADC0 to evaluate sensor status. In order to do this, the scan mode of the ADC has to be configured. When the sample delay configured in CHx\_TIMING\_SAMPLEDLY has expired, LESENSE will initiate an ADC sample. The active LESENSE channel determines which ADC0 channel to be sampled, where LESENSE channel X corresponds to ADC0 scan channel X.

### 28.3.13 DMA Requests

LESENSE issues a DMA request when the result buffer is either full or half full, depending on the configuration of BUFIDL in CTRL. The request is cleared when the buffer level drops below the threshold defined in BUFIDL. A single DMA request is also set whenever there is unread data in the buffer. DMAWU in CTRL configures at which buffer level LESENSE should wake-up the DMA when in EM2.

**Note:** The DMA controller should always fetch data from the BUFDATA register.

### 28.3.14 PRS Output

LESENSE is an asynchronous PRS producer and has twenty PRS outputs. The decoder has four outputs and in addition, all bits in the SCANRES register are available as PRS outputs. For further information on the decoder PRS output, refer to [28.3.7 Decoder](#).

### 28.3.15 RAM

LESENSE includes a RAM block used for storage of configuration and results. Registers mapped to the RAM include: STx\_TCONFA, STx\_TCONFb, BUFX\_DATA, BUFDATA, CHx\_TIMING, CHx\_INTERACT, and CHx\_EVAL. These registers have unknown value out of reset and have to be initialized before use.


**Note:** Read-modify-write operations on uninitialized RAM register produces undefined values.

### 28.3.16 Application Examples

The following sections detail several example applications for the LESENSE block.

### 28.3.16.1 Capacitive Sense

Figure 28.15 Capacitive Sense Setup on page 1001 illustrates how the EFM32 Tiny Gecko 11 can be configured to monitor four capacitive buttons.



**Figure 28.15. Capacitive Sense Setup**


The following steps show how to configure LESENSE to scan through the four buttons 100 times per second, issuing an interrupt if one of them is pressed.

1. Assuming LFACLK<sub>LESENSE</sub> is 32 kHz, set PCPRESC to 3 and PCTOP to 39 in CTRL. This will set the LESENSE scan frequency to 100 Hz.
2. Enable channels 0 through 3 in CHEN and set IDLECONF for these channels to DISABLED. In capacitive sense mode, the GPIO should always be disabled (i.e., analog input).
3. Configure the ACMP to operate in CAPSENSE mode (refer to the ACMP chapter for more details).
4. Configure the following bit fields in CHx\_CONF, for channels 0 through 3:
  - a. Set EXTIME to 0. No excitation is needed in this mode.
  - b. Set SAMPLE to ACMPCOUNT and COMP to LESS. This makes LESENSE interpret a sensor as active if the frequency on a channel drops below the threshold (i.e., the button is pressed).
  - c. Set SAMPLLEDLY to an appropriate value - each sensor will be measured for SAMPLLEDLY/F<sub>LFACLK\_LESENSE</sub> seconds. MEASUREMENTLY should be set to 0
5. Set CTRTHRESHOLD to an appropriate value. An interrupt will be issued if the counter value for a sensor is below this threshold after the measurement phase.
6. Enable interrupts on channels 0 through 3.
7. Start scan sequence by writing a 1 to START in CMD.

In a capacitive sense application, it might be required to calibrate the threshold values on a periodic basis, for example to compensate for humidity and other physical variations. LESENSE is able to store up to 16 counter values from a configurable number of channels, making it possible to collect sample data while in EM2. When calibration is to be performed, the CPU only has to be woken up for a short period of time as the data to be processed already lies in the result registers. To enable storing of the count value for a channel, set STRSAMPLE in the CHx\_INTERACT register.


### 28.3.16.2 LC Sensor

Figure 28.16 LC Sensor Setup on page 1002 below illustrates how the EFM32 Tiny Gecko 11 can be set up to monitor four LC sensors.



**Figure 28.16. LC Sensor Setup**

LESENSE can be used to excite and measure the damping factor in LC sensor oscillations. To measure the damping factor, the ACMP can be used to generate a high output each time the sensor voltage exceeds a certain level. These pulses are counted using an asynchronous counter and compared with the threshold in COMPTHRES in the CHx\_EVAL register. If the number of pulses exceeds the threshold level, the sensor is said to be active, otherwise it is inactive. Figure 28.17 LC Sensor Oscillations on page 1002 illustrates how the output pulses from the ACMP correspond to damping of the oscillations. The results from sensor evaluation can automatically be fed into the decoder in order to keep track of rotations.



**Figure 28.17. LC Sensor Oscillations**

The following steps show how to configure LESENSE to scan through the four LC sensors 100 times per second.


1. Assuming LFACLK<sub>LESENSE</sub> is 32kHz, set PCPRESC to 3 and PCTOP to 39 in CTRL. This will set the LESENSE scan frequency to 100Hz.
2. Enable the VDAC and configure it to produce a voltage of Vdd/2.

3. Enable channels 0 through 3 in CHEN. Set IDLECONF for the active channels to DACOUT. The channel pins should be connected to the VDAC output (effectively shorting the LC sensor) in the idle phase to damp the oscillations.
4. Configure the ACMP to use scaled Vdd as negative input, refer to ACMP chapter for details.
5. Enable and configure PCNT and asynchronous PRS.
6. Configure the GPIOs used as PUSH/PULL.
7. Configure the following bit fields in CHx\_CONF, for channels 0 through 3:
  - a. Set EXCLK to AUXHFRCO. AUXHFRCO is needed to achieve short excitation time.
  - b. Set EXTIME to an appropriate value. Excitation will last for EXTIME/F<sub>AUXHFRCO</sub> seconds.
  - c. Set EXMODE to HIGH. The LC sensors are excited by pulling the excitation pin high.
  - d. Set SAMPLE to ACMPCOUNT and COMP to LESS. Status of each sensor is evaluated based on the number of pulses generated by the ACMP. If they are less than the threshold value, the sensor is said to be active.
  - e. Set SAMPLEDLY to an appropriate value, each sensor will be measured for SAMPLEDLY/F<sub>LFACLK\_LESENSE</sub> seconds.
8. Set CTRTHRESHOLD to an appropriate value. If the sensor is active, the counter value after the measurement phase should be less than the threshold. If it is inactive, the counter value should be greater than the threshold.
9. Start scan sequence by writing a 1 to START in CMD.

**Note:** Exciting the LC sensor by pulling the excitation pin high allows the ESD protection in the pads to clamp any voltage swings below the ground voltage, giving a consistent starting point for the oscillations.

### 28.3.16.3 LESENSE Decoder 1

The example below illustrates how the LESENSE module can be used for decoding using three sensors.



**Figure 28.18. FSM Example 1**

Figure 28.18 FSM Example 1 on page 1004, configure the following LESENSE registers:


1. Configure the channels to be used, be sure to set DECODE in CHx\_EVAL.
2. Set PRSCNT to enable generation of count waveforms on PRS. Also configure a PCNT to listen to the PRS channels and count accordingly.
3. Configure the following in STx\_TCONFA and STx\_TCONFb:
  - a. Set MASK = 0b1000 in STx\_TCONFA and STx\_TCONFb for all used states. This enables three sensors to be evaluated by the decoder.
  - b. Configure the remaining bit fields in STx\_TCONFA and STx\_TCONFb as described in [Table 28.3 LESENSE Decoder Configuration for FSM Example 1 on page 1004](#).
4. To initialize the decoder, run one scan, and read the present sensor status from SENSORSTATE. Then write the index of this state to DECSTATE.
5. Write to START in CMD to start scanning of sensors and decoding.

**Table 28.3. LESENSE Decoder Configuration for FSM Example 1**

Register	TCONFA_NEXTSTATE	TCONFA_COMP	TCONFA_PRSACT	TCONFb_NEXTSTATE	TCONFb_COMP	TCONFb_PRSACT
ST0	1	0b001	UP	7	0b100	DOWN
ST1	2	0b011	UP	0	0b000	DOWN
ST2	3	0b010	UP	1	0b001	DOWN
ST3	4	0b110	UP	2	0b011	DOWN
ST4	5	0b111	UP	3	0b010	DOWN
ST5	6	0b101	UP	4	0b110	DOWN
ST6	7	0b100	UP	5	0b111	DOWN
ST7	0	0b000	UP	6	0b101	DOWN

**28.3.16.4 LESENSE Decoder 2**

The example below illustrates how the LESENSE decoder can be used to implement the state machine seen in [Figure 28.19 FSM Example 2 on page 1005](#).

**Figure 28.19. FSM Example 2**

1. Configure STx\_TCONFA and STx\_TCONFb as described in [Table 28.4 LESENSE Decoder Configuration for FSM Example 2 on page 1005](#).
2. To initialize the decoder, run one scan, and read the present sensor status from SENSORSTATE. Then write the index of this state to DECSTATE.
3. Write to START in CMD to start scanning of sensors and decoding.

**Table 28.4. LESENSE Decoder Configuration for FSM Example 2**

Register	NEXTSTATE	COMP	MASK	CHAIN
ST0_TCONFA	8	0b1000	0b0111	1
ST0_TCONFb	2	0b0001	0b1000	-
ST1_TCONFA	6	0b0010	0b1000	0
ST1_TCONFb	6	0b0010	0b1000	-
ST2_TCONFA	8	0b1000	0b0111	1
ST2_TCONFb	4	0b0011	0b1000	-
ST3_TCONFA	0	0b0000	0b1000	0
ST3_TCONFb	0	0b0000	0b1000	-
ST4_TCONFA	8	0b1000	0b0111	1
ST4_TCONFb	6	0b0010	0b1000	-
ST5_TCONFA	2	0b0001	0b1000	0
ST5_TCONFb	2	0b0001	0b1000	-
ST6_TCONFA	8	0b1000	0b0111	1
ST6_TCONFb	0	0b0000	0b1000	-
ST7_TCONFA	4	0b0011	0b1000	0
ST7_TCONFb	4	0b0011	0b1000	-

## 28.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	LESENSE_CTRL	RW	Control Register
0x004	LESENSE_TIMCTRL	RW	Timing Control Register
0x008	LESENSE_PERCTRL	RW	Peripheral Control Register
0x00C	LESENSE_DECCTRL	RW	Decoder Control Register
0x010	LESENSE_BIASCTRL	RW	Bias Control Register
0x014	LESENSE_EVALCTRL	RW	LESENSE Evaluation Control
0x018	LESENSE_PRSCTRL	RW	PRS Control Register
0x01C	LESENSE_CMD	W1	Command Register
0x020	LESENSE_CHEN	RW	Channel Enable Register
0x024	LESENSE_SCANRES	RWH	Scan Result Register
0x028	LESENSE_STATUS	R	Status Register
0x02C	LESENSE_PTR	R	Result Buffer Pointers
0x030	LESENSE_BUFDATA	R(a)	Result Buffer Data Register
0x034	LESENSE_CURCH	R	Current Channel Index
0x038	LESENSE_DECSTATE	RWH	Current Decoder State
0x03C	LESENSE_SENSORSTATE	RWH	Decoder Input Register
0x040	LESENSE_IDLECONF	RW	GPIO Idle Phase Configuration
0x044	LESENSE_ALTEXCONF	RW	Alternative Excite Pin Configuration
0x050	LESENSE_IF	R	Interrupt Flag Register
0x054	LESENSE_IFS	W1	Interrupt Flag Set Register
0x058	LESENSE_IFC	(R)W1	Interrupt Flag Clear Register
0x05C	LESENSE_IEN	RW	Interrupt Enable Register
0x060	LESENSE_SYNCBUSY	R	Synchronization Busy Register
0x064	LESENSE_ROUTEPEN	RW	I/O Routing Register
0x100	LESENSE_ST0_TCONFA	RW	State Transition Configuration a
0x104	LESENSE_ST0_TCONFb	RW	State Transition Configuration B
...	LESENSE_STx_TCONFA	RW	State Transition Configuration a
...	LESENSE_STx_TCONFb	RW	State Transition Configuration B
0x1F8	LESENSE_ST31_TCONFA	RW	State Transition Configuration a
0x1FC	LESENSE_ST31_TCONFb	RW	State Transition Configuration B
0x200	LESENSE_BUF0_DATA	RWH	Scan Results
...	LESENSE_BUFX_DATA	RWH	Scan Results
0x23C	LESENSE_BUF15_DATA	RWH	Scan Results
0x240	LESENSE_CH0_TIMING	RW	Scan Configuration
0x244	LESENSE_CH0_INTERACT	RW	Scan Configuration

Offset	Name	Type	Description
0x248	LESENSE_CH0_EVAL	RWH	Scan Configuration
...	LESENSE_CHx_TIMING	RW	Scan Configuration
...	LESENSE_CHx_INTERACT	RW	Scan Configuration
...	LESENSE_CHx_EVAL	RWH	Scan Configuration
0x330	LESENSE_CH15_TIMING	RW	Scan Configuration
0x334	LESENSE_CH15_INTERACT	RW	Scan Configuration
0x338	LESENSE_CH15_EVAL	RWH	Scan Configuration

## 28.5 Register Description

### 28.5.1 LESENSE\_CTRL - Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RW	0	RW	0x0	RW	0	RW	0x0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0	RW	0x0	RW	0	RW	0	RW	0	RW	0
Name	DEBUGRUN	DMAWU	BUFIDL	STRSCANRES	BUFW	DUALSAMPLE	ALTEXMAP	SCANCONF	PRSEL	SCANMODE																						

Bit	Name	Reset	Access	Description												
31:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
22	DEBUGRUN	0	RW	<b>Debug Mode Run Enable</b>												
				Set to keep LESENSE running in debug mode.												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>LESENSE can not start new scans in debug mode</td></tr> <tr> <td>1</td> <td>LESENSE can start new scans in debug mode</td></tr> </tbody> </table>	Value	Description	0	LESENSE can not start new scans in debug mode	1	LESENSE can start new scans in debug mode						
Value	Description															
0	LESENSE can not start new scans in debug mode															
1	LESENSE can start new scans in debug mode															
21:20	DMAWU	0x0	RW	<b>DMA Wake-up From EM2</b>												
				Set buffer threshold for waking up the DMA controller when the system is in EM2												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DISABLE</td> <td>No DMA wake-up from EM2</td></tr> <tr> <td>1</td> <td>BUFDATAV</td> <td>DMA wake-up from EM2 when data is valid in the result buffer</td></tr> <tr> <td>2</td> <td>BUFLEVEL</td> <td>DMA wake-up from EM2 when the result buffer is full/half-full depending on BUFIDL configuration</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	No DMA wake-up from EM2	1	BUFDATAV	DMA wake-up from EM2 when data is valid in the result buffer	2	BUFLEVEL	DMA wake-up from EM2 when the result buffer is full/half-full depending on BUFIDL configuration
Value	Mode	Description														
0	DISABLE	No DMA wake-up from EM2														
1	BUFDATAV	DMA wake-up from EM2 when data is valid in the result buffer														
2	BUFLEVEL	DMA wake-up from EM2 when the result buffer is full/half-full depending on BUFIDL configuration														
19	BUFIDL	0	RW	<b>Result Buffer Interrupt and DMA Trigger Level</b>												
				Set buffer threshold for DMA requests and interrupt generation												
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>HALFFULL</td> <td>DMA and interrupt flags set when result buffer is half-full</td></tr> <tr> <td>1</td> <td>FULL</td> <td>DMA and interrupt flags set when result buffer is full</td></tr> </tbody> </table>	Value	Mode	Description	0	HALFFULL	DMA and interrupt flags set when result buffer is half-full	1	FULL	DMA and interrupt flags set when result buffer is full			
Value	Mode	Description														
0	HALFFULL	DMA and interrupt flags set when result buffer is half-full														
1	FULL	DMA and interrupt flags set when result buffer is full														
18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>												
17	STRSCANRES	0	RW	<b>Enable Storing of SCANRES</b>												
				When set, SCANRES will be stored in the result buffer after each scan												

Bit	Name	Reset	Access	Description																											
16	BUFOW	0	RW	<b>Result Buffer Overwrite</b>  If set, LESENSE will always write to the result buffer, even if it is full																											
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
13	DUALSAMPLE	0	RW	<b>Enable Dual Sample Mode</b>  When set, both ACMPs will be sampled simultaneously.																											
12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
11	ALTEXMAP	0	RW	<b>Alternative Excitation Map</b>  This bit is used to configure which pins alternate excitation is mapped to.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>ALTEX</td><td>Alternative excitation is mapped to the LES_ALTEX pins.</td></tr> <tr> <td>1</td><td>CH</td><td>Alternative excitation is mapped to the pin of LESENSE channel (X+8 mod 16), X being the active channel.</td></tr> </tbody> </table>	Value	Mode	Description	0	ALTEX	Alternative excitation is mapped to the LES_ALTEX pins.	1	CH	Alternative excitation is mapped to the pin of LESENSE channel (X+8 mod 16), X being the active channel.																		
Value	Mode	Description																													
0	ALTEX	Alternative excitation is mapped to the LES_ALTEX pins.																													
1	CH	Alternative excitation is mapped to the pin of LESENSE channel (X+8 mod 16), X being the active channel.																													
10:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
8:7	SCANCONF	0x0	RW	<b>Select Scan Configuration</b>  These bits control which CHx_CONF registers to be used.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DIRMAP</td><td>The channel configuration register registers used are directly mapped to the channel number.</td></tr> <tr> <td>1</td><td>INVMAP</td><td>The channel configuration register registers used are CH<sub>x+8</sub>_CONF for channels 0-7 and CH<sub>x-8</sub>_CONF for channels 8-15.</td></tr> <tr> <td>2</td><td>TOGGLE</td><td>The channel configuration register registers used toggles between CH<sub>x</sub>_CONF and CH<sub>x+8</sub>_CONF when channel x triggers</td></tr> <tr> <td>3</td><td>DECDEF</td><td>The decoder state defines the CONF registers to be used.</td></tr> </tbody> </table>	Value	Mode	Description	0	DIRMAP	The channel configuration register registers used are directly mapped to the channel number.	1	INVMAP	The channel configuration register registers used are CH <sub>x+8</sub> _CONF for channels 0-7 and CH <sub>x-8</sub> _CONF for channels 8-15.	2	TOGGLE	The channel configuration register registers used toggles between CH <sub>x</sub> _CONF and CH <sub>x+8</sub> _CONF when channel x triggers	3	DECDEF	The decoder state defines the CONF registers to be used.												
Value	Mode	Description																													
0	DIRMAP	The channel configuration register registers used are directly mapped to the channel number.																													
1	INVMAP	The channel configuration register registers used are CH <sub>x+8</sub> _CONF for channels 0-7 and CH <sub>x-8</sub> _CONF for channels 8-15.																													
2	TOGGLE	The channel configuration register registers used toggles between CH <sub>x</sub> _CONF and CH <sub>x+8</sub> _CONF when channel x triggers																													
3	DECDEF	The decoder state defines the CONF registers to be used.																													
6:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
4:2	PRSSEL	0x0	RW	<b>Scan Start PRS Select</b>  Select PRS source for scan start if SCANMODE is set to PRS.																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr> <td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr> <td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> <tr> <td>3</td><td>PRSCH3</td><td>PRS Channel 3 selected as input</td></tr> <tr> <td>4</td><td>PRSCH4</td><td>PRS Channel 4 selected as input</td></tr> <tr> <td>5</td><td>PRSCH5</td><td>PRS Channel 5 selected as input</td></tr> <tr> <td>6</td><td>PRSCH6</td><td>PRS Channel 6 selected as input</td></tr> <tr> <td>7</td><td>PRSCH7</td><td>PRS Channel 7 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input	3	PRSCH3	PRS Channel 3 selected as input	4	PRSCH4	PRS Channel 4 selected as input	5	PRSCH5	PRS Channel 5 selected as input	6	PRSCH6	PRS Channel 6 selected as input	7	PRSCH7	PRS Channel 7 selected as input
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													
3	PRSCH3	PRS Channel 3 selected as input																													
4	PRSCH4	PRS Channel 4 selected as input																													
5	PRSCH5	PRS Channel 5 selected as input																													
6	PRSCH6	PRS Channel 6 selected as input																													
7	PRSCH7	PRS Channel 7 selected as input																													

Bit	Name	Reset	Access	Description
1:0	SCANMODE	0x0	RW	<b>Configure Scan Mode</b>
These bits control how the scan frequency is decided				
	Value	Mode	Description	
	0	PERIODIC	A new scan is started each time the period counter overflows	
	1	ONESHOT	A single scan is performed when START in CMD is set	
	2	PRS	Pulse on PRS channel	

**28.5.2 LESENSE\_TIMCTRL - Timing Control Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset				0					0x0							0x00							0x0												
Access		RW							RW							RW							RW												
Name	AUXSTARTUP							STARTDLY								PCTOP							PCPRESC											AUXPRESC	

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28	AUXSTARTUP	0	RW	<b>AUXHFRCO Startup Configuration</b>
				This bit can be set to ONDEMAND to delay startup of the AUXHFRCO when high frequency timer is used
	Value	Mode		Description
	0	PREDEMAND		AUXHFRCO is started half a clock cycle before it's needed
	1	ONDEMAND		AUXHFRCO is started at the time it is needed
27:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23:22	STARTDLY	0x0	RW	<b>Start Delay Configuration</b>
				Delay sensor interaction STARTDELAY LFACLK <sub>LESENSE</sub> cycles for each channel
21:20	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
19:12	PCTOP	0x00	RW	<b>Period Counter Top Value</b>
				These bits contain the top value for the period counter.
11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10:8	PCPRESC	0x0	RW	<b>Period Counter Prescaling</b>
				This bitfield is used to divide the clock to the period counter
	Value	Mode		Description
	0	DIV1		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /1
	1	DIV2		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /2
	2	DIV4		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /4
	3	DIV8		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /8
	4	DIV16		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /16
	5	DIV32		The period counter clock frequency is LFACLK <sub>LESENSE</sub> /32

Bit	Name	Reset	Access	Description
6	DIV64			The period counter clock frequency is $\text{LFACLK}_{\text{LESENSE}}/64$
7	DIV128			The period counter clock frequency is $\text{LFACLK}_{\text{LESENSE}}/128$
7	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
6:4	LFPRESC	0x0	RW	<b>Prescaling Factor for Low Frequency Timer</b>
	This bitfield is used to divide the clock to the low frequency timer			
	Value	Mode	Description	
	0	DIV1	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/1$	
	1	DIV2	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/2$	
	2	DIV4	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/4$	
	3	DIV8	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/8$	
	4	DIV16	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/16$	
	5	DIV32	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/32$	
	6	DIV64	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/64$	
	7	DIV128	Low frequency timer is clocked with $\text{LFACLK}_{\text{LESENSE}}/128$	
3:2	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
1:0	AUXPRESC	0x0	RW	<b>Prescaling Factor for High Frequency Timer</b>
	This bitfield is used to divide the clock to the high frequency timer			
	Value	Mode	Description	
	0	DIV1	High frequency timer is clocked with $\text{AUXHFRCO}/1$	
	1	DIV2	High frequency timer is clocked with $\text{AUXHFRCO}/2$	
	2	DIV4	High frequency timer is clocked with $\text{AUXHFRCO}/4$	
	3	DIV8	High frequency timer is clocked with $\text{AUXHFRCO}/8$	

**28.5.3 LESENSE\_PERCTRL - Peripheral Control Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																																									
Reset	31	30	29	28	0x0	27	0	26	0	25	0	24	0	23	0x0	22	0x0	21	0x0	20	19	18	17	16	15	14	13	12	11	10	9	DACCONVTRIG	RW	0	8	7	DACSTARTUP	RW	0	6	5	4	DACCH1DATA	RW	0	3	DACCH0DATA	RW	0	2	DACCH1EN	RW	0	1	DACCH0EN	RW	0	0
Access																																																										
Name																																																										

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:28	WARMUPMODE	0x0	RW	<b>ACMP and VDAC Duty Cycle Mode</b>
				This bitfield is used to configure how the VDAC and ACMP are duty cycled when LESENSE is controlling them
	Value	Mode		Description
	0	NORMAL		The analog comparators and VDAC are shut down when LESENSE is idle
	1	KEEPACMPWARM		The analog comparators are kept powered up when LESENSE is idle
	2	KEEPDACPWARM		The VDAC is kept powered up when LESENSE is idle
	3	KEEPACMPDACPWARM		The analog comparators and VDAC are kept powered up when LESENSE is idle
27	ACMP1HYSTEN	0	RW	<b>ACMP1 Hysteresis Enable</b>
				Set to control ACMP1_HYSTERESIS0_DIVVX and ACMP1_HYSTERESIS1_DIVVX separately.
26	ACMP0HYSTEN	0	RW	<b>ACMP0 Hysteresis Enable</b>
				Set to control ACMP0_HYSTERESIS0_DIVVX and ACMP0_HYSTERESIS1_DIVVX separately.
25	ACMP1INV	0	RW	<b>Invert Analog Comparator 1 Output</b>
				This bit can be set to invert the output coming from ACMP1
24	ACMP0INV	0	RW	<b>Invert Analog Comparator 0 Output</b>
				This bit can be set to invert the output coming from ACMP0
23:22	ACMP1MODE	0x0	RW	<b>ACMP1 Mode</b>
				Configure how LESENSE controls ACMP1
	Value	Mode		Description
	0	DISABLE		LESENSE does not control ACMP1
	1	MUX		LESENSE controls the input mux (POSEL) of ACMP1
	2	MUXTHRES		LESENSE controls the input mux and the threshold value (VDDLEVEL) of ACMP1

Bit	Name	Reset	Access	Description
21:20	ACMP0MODE	0x0	RW	<b>ACMP0 Mode</b>  Configure how LESENSE controls ACMP0
<hr/>				
	Value	Mode		Description
	0	DISABLE		LESENSE does not control ACMP0
	1	MUX		LESENSE controls the input mux (POSSEL) of ACMP0
	2	MUXTHRES		LESENSE controls the input mux (POSSEL) and the threshold value (VDDLEVEL) of ACMP0
<hr/>				
19:9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
<hr/>				
8	DACCONVTRIG	0	RW	<b>VDAC Conversion Trigger Configuration</b>  This bit is used to configure how frequently a VDAC conversion is triggered
<hr/>				
	Value	Mode		Description
	0	CHANNELSTART		VDAC is enabled before every LESENSE channel measurement.
	1	SCANSTART		VDAC is only enabled once per scan.
<hr/>				
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
<hr/>				
6	DACSTARTUP	0	RW	<b>VDAC Startup Configuration</b>  This bit is used to configure the duration between the VDAC conversion trigger and the sensor interaction
<hr/>				
	Value	Mode		Description
	0	FULLCYCLE		VDAC is started a full LFACLK <sub>LESENSE</sub> cycle before sensor interaction starts.
	1	HALFCYCLE		VDAC is started half a LFACLK <sub>LESENSE</sub> cycle before sensor interaction starts.
<hr/>				
5:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
<hr/>				
3	DACCH1DATA	0	RW	<b>VDAC CH1 Data Selection</b>  This bit decides if the data used for VDAC conversion is taken from the VDAC interface or from LESENSE
<hr/>				
	Value	Mode		Description
	0	DACDATA		VDAC data is defined by CH1DATA in the VDAC interface.
	1	THRES		VDAC data is defined by THRES in CH <sub>x</sub> _INTERACT.
<hr/>				
2	DACCH0DATA	0	RW	<b>VDAC CH0 Data Selection</b>  This bit decides if the data used for VDAC conversion is taken from the VDAC interface or from LESENSE
<hr/>				
	Value	Mode		Description
	0	DACDATA		VDAC data is defined by CH0DATA in the VDAC interface.
	1	THRES		VDAC data is defined by THRES in CH <sub>x</sub> _INTERACT.
<hr/>				

Bit	Name	Reset	Access	Description
1	DACCH1EN	0	RW	<b>VDAC CH1 Enable</b> Enable LESENSE control of VDAC0 CH1
0	DACCH0EN	0	RW	<b>VDAC CH0 Enable</b> Enable LESENSE control of VDAC0 CH0

**28.5.4 LESENSE\_DECCTRL - Decoder Control Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10										
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:28	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
27:25	PRSSEL3	0x0	RW	<b>LESENSE Decoder PRS Input 3 Configuration</b>
				Select PRS input for bit 3 of the LESENSE decoder
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as input
	1	PRSCH1		PRS Channel 1 selected as input
	2	PRSCH2		PRS Channel 2 selected as input
	3	PRSCH3		PRS Channel 3 selected as input
	4	PRSCH4		PRS Channel 4 selected as input
	5	PRSCH5		PRS Channel 5 selected as input
	6	PRSCH6		PRS Channel 6 selected as input
	7	PRSCH7		PRS Channel 7 selected as input
24:23	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	PRSSEL2	0x0	RW	<b>LESENSE Decoder PRS Input 2 Configuration</b>
				Select PRS input for bit 2 of the LESENSE decoder
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as input
	1	PRSCH1		PRS Channel 1 selected as input
	2	PRSCH2		PRS Channel 2 selected as input
	3	PRSCH3		PRS Channel 3 selected as input
	4	PRSCH4		PRS Channel 4 selected as input
	5	PRSCH5		PRS Channel 5 selected as input
	6	PRSCH6		PRS Channel 6 selected as input
	7	PRSCH7		PRS Channel 7 selected as input

Bit	Name	Reset	Access	Description																											
19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
17:15	PRSSEL1	0x0	RW	<b>LESENSE Decoder PRS Input 1 Configuration</b>  Select PRS input for the bit 1 of the LESENSE decoder																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS Channel 3 selected as input</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS Channel 4 selected as input</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS Channel 5 selected as input</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS Channel 6 selected as input</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS Channel 7 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input	3	PRSCH3	PRS Channel 3 selected as input	4	PRSCH4	PRS Channel 4 selected as input	5	PRSCH5	PRS Channel 5 selected as input	6	PRSCH6	PRS Channel 6 selected as input	7	PRSCH7	PRS Channel 7 selected as input
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													
3	PRSCH3	PRS Channel 3 selected as input																													
4	PRSCH4	PRS Channel 4 selected as input																													
5	PRSCH5	PRS Channel 5 selected as input																													
6	PRSCH6	PRS Channel 6 selected as input																													
7	PRSCH7	PRS Channel 7 selected as input																													
14:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
12:10	PRSSEL0	0x0	RW	<b>LESENSE Decoder PRS Input 0 Configuration</b>  Select PRS input for the bit 0 of the LESENSE decoder																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>PRSCH0</td><td>PRS Channel 0 selected as input</td></tr> <tr><td>1</td><td>PRSCH1</td><td>PRS Channel 1 selected as input</td></tr> <tr><td>2</td><td>PRSCH2</td><td>PRS Channel 2 selected as input</td></tr> <tr><td>3</td><td>PRSCH3</td><td>PRS Channel 3 selected as input</td></tr> <tr><td>4</td><td>PRSCH4</td><td>PRS Channel 4 selected as input</td></tr> <tr><td>5</td><td>PRSCH5</td><td>PRS Channel 5 selected as input</td></tr> <tr><td>6</td><td>PRSCH6</td><td>PRS Channel 6 selected as input</td></tr> <tr><td>7</td><td>PRSCH7</td><td>PRS Channel 7 selected as input</td></tr> </tbody> </table>	Value	Mode	Description	0	PRSCH0	PRS Channel 0 selected as input	1	PRSCH1	PRS Channel 1 selected as input	2	PRSCH2	PRS Channel 2 selected as input	3	PRSCH3	PRS Channel 3 selected as input	4	PRSCH4	PRS Channel 4 selected as input	5	PRSCH5	PRS Channel 5 selected as input	6	PRSCH6	PRS Channel 6 selected as input	7	PRSCH7	PRS Channel 7 selected as input
Value	Mode	Description																													
0	PRSCH0	PRS Channel 0 selected as input																													
1	PRSCH1	PRS Channel 1 selected as input																													
2	PRSCH2	PRS Channel 2 selected as input																													
3	PRSCH3	PRS Channel 3 selected as input																													
4	PRSCH4	PRS Channel 4 selected as input																													
5	PRSCH5	PRS Channel 5 selected as input																													
6	PRSCH6	PRS Channel 6 selected as input																													
7	PRSCH7	PRS Channel 7 selected as input																													
9	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																											
8	INPUT	0	RW	<b>LESENSE Decoder Input Configuration</b>  Select input to the LESENSE decoder																											
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr><td>0</td><td>SENSORSTATE</td><td>The SENSORSTATE register is used as input to the decoder.</td></tr> <tr><td>1</td><td>PRS</td><td>PRS channels are used as input to the decoder.</td></tr> </tbody> </table>	Value	Mode	Description	0	SENSORSTATE	The SENSORSTATE register is used as input to the decoder.	1	PRS	PRS channels are used as input to the decoder.																		
Value	Mode	Description																													
0	SENSORSTATE	The SENSORSTATE register is used as input to the decoder.																													
1	PRS	PRS channels are used as input to the decoder.																													
7	PRSCNT	0	RW	<b>Enable Count Mode on Decoder PRS Channels 0 and 1</b>  When set, decoder PRS0 and PRS1 will be used to produce output which can be used by a PCNT to count up or down.																											

Bit	Name	Reset	Access	Description
6	HYSTIRQ	0	RW	<b>Enable Decoder Hysteresis on Interrupt Requests</b>  When set, hysteresis is enabled in the decoder, suppressing interrupt requests.
5	HYSTPRS2	0	RW	<b>Enable Decoder Hysteresis on PRS2 Output</b>  When set, hysteresis is enabled in the decoder, suppressing changes on PRS channel 2
4	HYSTPRS1	0	RW	<b>Enable Decoder Hysteresis on PRS1 Output</b>  When set, hysteresis is enabled in the decoder, suppressing changes on PRS channel 1
3	HYSTPRS0	0	RW	<b>Enable Decoder Hysteresis on PRS0 Output</b>  When set, hysteresis is enabled in the decoder, suppressing changes on PRS channel 0
2	INTMAP	0	RW	<b>Enable Decoder to Channel Interrupt Mapping</b>  When set, a transition from state x in the decoder will set interrupt flag CH[x mod 16]
1	ERRCHK	0	RW	<b>Enable Check of Current State</b>  When set, the decoder checks the current state in addition to the states defined in TCONF
0	DISABLE	0	RW	<b>Disable the Decoder</b>  When set, the decoder is disabled. When disabled the decoder will keep its current state

### 28.5.5 LESENSE\_BIASCTRL - Bias Control Register (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																													
Reset																														0x0
Access																														RW
Name																														BIASMODE

Bit	Name	Reset	Access	Description
31:2	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
1:0	BIASMODE	0x0	RW	<b>Select Bias Mode</b>  This bitfield is used to configure how LESENSE interacts with the bias module
Value		Mode	Description	
0		DONTTOUCH	Bias module is controlled by the EMU and is not affected by LESENSE	
1		DUTYCYCLE	Bias module duty cycled between low power and high accuracy mode	
2		HIGHACC	Bias module always in high accuracy mode	

**28.5.6 LESENSE\_EVALCTRL - LESENSE Evaluation Control (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																	
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																		
Access																																		
Name																																		

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:0	WINSIZE	0x0000	RW	<b>Sliding Window and Step Detection Size</b>
------	---------	--------	----	---

In sliding window mode, this bitfield configures the window size. In step detection mode, this bitfield is used to configure the threshold for step detection

**28.5.7 LESENSE\_PRSCTRL - PRS Control Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																														0x000			
Access																															RW		
Name																																	DECMPVAL
Bit	Name	Reset	Access	Description																													
31:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
16	DECCMPEN	0	RW	<b>Enable PRS Output DECCMP</b>  Enables decoder state compare match PRS output																													
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
12:8	DECCMPMASK	0x00	RW	<b>Decoder State Compare Value Mask</b>  Masks DECCMPVAL and DECSTATE for comparison																													
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																													
4:0	DECCMPVAL	0x00	RW	<b>Decoder State Compare Value</b>  Triggers PRS output when equal to DECSTATE																													

**28.5.8 LESENSE\_CMD - Command Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																														
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4			
Reset																															
Access																															
Name																															
CLEARBUF	W1	0	3	DECODE	W1	0	2	STOP	W1	0	1	START	W1	0	0	CLEARBUF	W1	0	3	DECODE	W1	0	2	STOP	W1	0	1	START	W1	0	

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3	CLEARBUF	0	W1	<b>Clear Result Buffer</b>
				Set this bit to reset the read and write pointers of the result buffer.
2	DECODE	0	W1	<b>Start Decoder</b>
				Set this bit to start the LESENSE decoder.
1	STOP	0	W1	<b>Stop Scanning of Sensors</b>
				Set this bit to stop LESENSE. If issued during a scan, the command will take effect after scan completion.
0	START	0	W1	<b>Start Scanning of Sensors</b>
				Set this bit to start LESENSE.

**28.5.9 LESENSE\_CHEN - Channel Enable Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																
CHEN	RW	0x0000																														

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	CHEN	0x0000	RW	<b>Enable Scan Channel</b>
				Set bit X to enable channel X

**28.5.10 LESENSE\_SCANRES - Scan Result Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																0x0000															
Access	RWH																RWH															
Name	STEPDIR																SCANRES															

Bit	Name	Reset	Access	Description
31:16	STEPDIR	0x0000	RWH	<b>Direction of Previous Step Detection</b>
In step detection mode, bit X will be set if a step up was detected on channel X				
15:0	SCANRES	0x0000	RWH	<b>Scan Results</b>
Bit X will be set depending on channel X evaluation				

**28.5.11 LESENSE\_STATUS - Status Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:6	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5	DACACTIVE	0	R	<b>LESENSE VDAC Interface is Active</b>  LESENSE is currently using the VDAC.
4	SCANACTIVE	0	R	<b>LESENSE Scan Active</b>  LESENSE is currently interfacing to sensors.
3	RUNNING	0	R	<b>LESENSE Periodic Counter Running</b>  LESENSE is running in periodic mode.
2	BUFFULL	0	R	<b>Result Buffer Full</b>  Set when the result buffer is full
1	BUFHALFFULL	0	R	<b>Result Buffer Half Full</b>  Set when the result buffer is half full
0	BUFDATAV	0	R	<b>Result Data Valid</b>  Set when data is available in the result buffer. Cleared when the buffer is empty.

**28.5.12 LESENSE\_PTR - Result Buffer Pointers (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0																											0x0				
Access	R																										R					
Name	WR																										RD					

Bit	Name	Reset	Access	Description
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
7:4	WR	0x0	R	<b>Result Buffer Write Pointer</b>  These bits show the next index in the result buffer to be written to. Incremented when LESENSE writes to result buffer
3:0	RD	0x0	R	<b>Result Buffer Read Pointer</b>  These bits show the index of the oldest unread data in the result buffer. Incremented on read from BUFDATA.

**28.5.13 LESENSE\_BUFDATA - Result Buffer Data Register (Async Reg) (Actionable Reads)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xX																										0xFFFF					
Access	R																										R					
Name	BUFDATA																										BUFDATA					

Bit	Name	Reset	Access	Description
31:20	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
19:16	BUFDATASRC	0xX	R	<b>Result Data Source</b>  This bitfield contains the channel index for the sensor result in BUFDATA.
15:0	BUFDATA	0xFFFF	R	<b>Result Data</b>  This register can be used to read the oldest unread data from the result buffer.

#### 28.5.14 LESENSE\_CURCH - Current Channel Index (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	CURCH	0x0	R	<b>Current Channel Index</b>  Shows the index of the current channel

#### **28.5.15 LESENSE\_DECSTATE - Current Decoder State (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4:0	DECSTATE	0x00	RWH	<b>Current Decoder State</b>  Shows the current decoder state

**28.5.16 LESENSE\_SENSORSTATE - Decoder Input Register (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																			
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Access																																				
Name																																		SENSORSTATE	RWH	0x0

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	SENSORSTATE	0x0	RWH	<b>Decoder Input Register</b>  Shows the status of sensors chosen as input to the decoder

**28.5.17 LESENSE\_IDLECONF - GPIO Idle Phase Configuration (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
<b>Reset</b>	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0	0x0
<b>Access</b>	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW
<b>Name</b>	CH15	CH14	CH13	CH12	CH11	CH10	CH9	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1	CHO

Bit	Name	Reset	Access	Description
31:30	CH15	0x0	RW	<b>Channel 15 Idle Phase Configuration</b>
This bitfield determines how the channel is configured during the idle phase				
	Value	Mode		Description
	0	DISABLE		CH15 output is disabled in idle phase
	1	HIGH		CH15 output is high in idle phase
	2	LOW		CH15 output is low in idle phase
	3	DAC		CH15 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
29:28	CH14	0x0	RW	<b>Channel 14 Idle Phase Configuration</b>
This bitfield determines how the channel is configured during the idle phase				
	Value	Mode		Description
	0	DISABLE		CH14 output is disabled in idle phase
	1	HIGH		CH14 output is high in idle phase
	2	LOW		CH14 output is low in idle phase
	3	DAC		CH14 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
27:26	CH13	0x0	RW	<b>Channel 13 Idle Phase Configuration</b>
This bitfield determines how the channel is configured during the idle phase				
	Value	Mode		Description
	0	DISABLE		CH13 output is disabled in idle phase
	1	HIGH		CH13 output is high in idle phase
	2	LOW		CH13 output is low in idle phase
	3	DAC		CH13 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
25:24	CH12	0x0	RW	<b>Channel 12 Idle Phase Configuration</b>
This bitfield determines how the channel is configured during the idle phase				
	Value	Mode		Description

Bit	Name	Reset	Access	Description
0		DISABLE		CH12 output is disabled in idle phase
1		HIGH		CH12 output is high in idle phase
2		LOW		CH12 output is low in idle phase
3		DAC		CH12 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
23:22	CH11	0x0	RW	<b>Channel 11 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH11 output is disabled in idle phase
	1	HIGH		CH11 output is high in idle phase
	2	LOW		CH11 output is low in idle phase
	3	DAC		CH11 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
21:20	CH10	0x0	RW	<b>Channel 10 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH10 output is disabled in idle phase
	1	HIGH		CH10 output is high in idle phase
	2	LOW		CH10 output is low in idle phase
	3	DAC		CH10 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
19:18	CH9	0x0	RW	<b>Channel 9 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH9 output is disabled in idle phase
	1	HIGH		CH9 output is high in idle phase
	2	LOW		CH9 output is low in idle phase
	3	DAC		CH9 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
17:16	CH8	0x0	RW	<b>Channel 8 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH8 output is disabled in idle phase
	1	HIGH		CH8 output is high in idle phase
	2	LOW		CH8 output is low in idle phase
	3	DAC		CH8 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15

Bit	Name	Reset	Access	Description															
15:14	CH7	0x0	RW	<b>Channel 7 Idle Phase Configuration</b>  This bitfield determines how the channel is configured during the idle phase															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>CH7 output is disabled in idle phase</td></tr> <tr> <td>1</td><td>HIGH</td><td>CH7 output is high in idle phase</td></tr> <tr> <td>2</td><td>LOW</td><td>CH7 output is low in idle phase</td></tr> <tr> <td>3</td><td>DAC</td><td>CH7 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	CH7 output is disabled in idle phase	1	HIGH	CH7 output is high in idle phase	2	LOW	CH7 output is low in idle phase	3	DAC	CH7 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
Value	Mode	Description																	
0	DISABLE	CH7 output is disabled in idle phase																	
1	HIGH	CH7 output is high in idle phase																	
2	LOW	CH7 output is low in idle phase																	
3	DAC	CH7 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15																	
13:12	CH6	0x0	RW	<b>Channel 6 Idle Phase Configuration</b>  This bitfield determines how the channel is configured during the idle phase															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>CH6 output is disabled in idle phase</td></tr> <tr> <td>1</td><td>HIGH</td><td>CH6 output is high in idle phase</td></tr> <tr> <td>2</td><td>LOW</td><td>CH6 output is low in idle phase</td></tr> <tr> <td>3</td><td>DAC</td><td>CH6 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	CH6 output is disabled in idle phase	1	HIGH	CH6 output is high in idle phase	2	LOW	CH6 output is low in idle phase	3	DAC	CH6 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
Value	Mode	Description																	
0	DISABLE	CH6 output is disabled in idle phase																	
1	HIGH	CH6 output is high in idle phase																	
2	LOW	CH6 output is low in idle phase																	
3	DAC	CH6 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15																	
11:10	CH5	0x0	RW	<b>Channel 5 Idle Phase Configuration</b>  This bitfield determines how the channel is configured during the idle phase															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>CH5 output is disabled in idle phase</td></tr> <tr> <td>1</td><td>HIGH</td><td>CH5 output is high in idle phase</td></tr> <tr> <td>2</td><td>LOW</td><td>CH5 output is low in idle phase</td></tr> <tr> <td>3</td><td>DAC</td><td>CH5 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	CH5 output is disabled in idle phase	1	HIGH	CH5 output is high in idle phase	2	LOW	CH5 output is low in idle phase	3	DAC	CH5 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
Value	Mode	Description																	
0	DISABLE	CH5 output is disabled in idle phase																	
1	HIGH	CH5 output is high in idle phase																	
2	LOW	CH5 output is low in idle phase																	
3	DAC	CH5 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15																	
9:8	CH4	0x0	RW	<b>Channel 4 Idle Phase Configuration</b>  This bitfield determines how the channel is configured during the idle phase															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>CH4 output is disabled in idle phase</td></tr> <tr> <td>1</td><td>HIGH</td><td>CH4 output is high in idle phase</td></tr> <tr> <td>2</td><td>LOW</td><td>CH4 output is low in idle phase</td></tr> <tr> <td>3</td><td>DAC</td><td>CH4 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	CH4 output is disabled in idle phase	1	HIGH	CH4 output is high in idle phase	2	LOW	CH4 output is low in idle phase	3	DAC	CH4 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
Value	Mode	Description																	
0	DISABLE	CH4 output is disabled in idle phase																	
1	HIGH	CH4 output is high in idle phase																	
2	LOW	CH4 output is low in idle phase																	
3	DAC	CH4 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15																	
7:6	CH3	0x0	RW	<b>Channel 3 Idle Phase Configuration</b>  This bitfield determines how the channel is configured during the idle phase															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>CH3 output is disabled in idle phase</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	CH3 output is disabled in idle phase									
Value	Mode	Description																	
0	DISABLE	CH3 output is disabled in idle phase																	

Bit	Name	Reset	Access	Description
1		HIGH		CH3 output is high in idle phase
2		LOW		CH3 output is low in idle phase
3		DAC		CH3 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
5:4	CH2	0x0	RW	<b>Channel 2 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH2 output is disabled in idle phase
	1	HIGH		CH2 output is high in idle phase
	2	LOW		CH2 output is low in idle phase
	3	DAC		CH2 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
3:2	CH1	0x0	RW	<b>Channel 1 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH1 output is disabled in idle phase
	1	HIGH		CH1 output is high in idle phase
	2	LOW		CH1 output is low in idle phase
	3	DAC		CH1 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15
1:0	CH0	0x0	RW	<b>Channel 0 Idle Phase Configuration</b>
				This bitfield determines how the channel is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		CH0 output is disabled in idle phase
	1	HIGH		CH0 output is high in idle phase
	2	LOW		CH0 output is low in idle phase
	3	DAC		CH0 output is connected to VDAC output in idle phase. Note that this mode is only available on channels 0, 1, 2, 3, 12, 13, 14, 15

**28.5.18 LESENSE\_ALTEXCONF - Alternative Excite Pin Configuration (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Access	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW			
Name	AEX7	AEX6	AEX5	AEX4	AEX3	AEX2	AEX1	AEX0	IDLECONF7	IDLECONF6	IDLECONF5	IDLECONF4	IDLECONF3	IDLECONF2	IDLECONF1	IDLECONF0	0x0																

Bit	Name	Reset	Access	Description
31:24	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	AEX7	0	RW	<b>ALTEX7 Always Excite Enable</b>
				Set this bit to excite ALTEX7 regardless of what channel is active
22	AEX6	0	RW	<b>ALTEX6 Always Excite Enable</b>
				Set this bit to excite ALTEX6 regardless of what channel is active
21	AEX5	0	RW	<b>ALTEX5 Always Excite Enable</b>
				Set this bit to excite ALTEX5 regardless of what channel is active
20	AEX4	0	RW	<b>ALTEX4 Always Excite Enable</b>
				Set this bit to excite ALTEX4 regardless of what channel is active
19	AEX3	0	RW	<b>ALTEX3 Always Excite Enable</b>
				Set this bit to excite ALTEX3 regardless of what channel is active
18	AEX2	0	RW	<b>ALTEX2 Always Excite Enable</b>
				Set this bit to excite ALTEX2 regardless of what channel is active
17	AEX1	0	RW	<b>ALTEX1 Always Excite Enable</b>
				Set this bit to excite ALTEX1 regardless of what channel is active
16	AEX0	0	RW	<b>ALTEX0 Always Excite Enable</b>
				Set this bit to excite ALTEX0 regardless of what channel is active
15:14	IDLECONF7	0x0	RW	<b>ALTEX7 Idle Phase Configuration</b>
				This bitfield determines how the alternate excite pin is configured during the idle phase
	Value	Mode		Description
	0	DISABLE		ALTEX7 output is disabled in idle phase
	1	HIGH		ALTEX7 output is high in idle phase
	2	LOW		ALTEX7 output is low in idle phase
13:12	IDLECONF6	0x0	RW	<b>ALTEX6 Idle Phase Configuration</b>
				This bitfield determines how the alternate excite pin is configured during the idle phase

Bit	Name	Reset	Access	Description
	Value	Mode		Description
0	DISABLE			ALTEX6 output is disabled in idle phase
1	HIGH			ALTEX6 output is high in idle phase
2	LOW			ALTEX6 output is low in idle phase
11:10	IDLECONF5	0x0	RW	<b>ALTEX5 Idle Phase Configuration</b>
	This bitfield determines how the alternate excite pin is configured during the idle phase			
	Value	Mode		Description
0	DISABLE			ALTEX5 output is disabled in idle phase
1	HIGH			ALTEX5 output is high in idle phase
2	LOW			ALTEX5 output is low in idle phase
9:8	IDLECONF4	0x0	RW	<b>ALTEX4 Idle Phase Configuration</b>
	This bitfield determines how the alternate excite pin is configured during the idle phase			
	Value	Mode		Description
0	DISABLE			ALTEX4 output is disabled in idle phase
1	HIGH			ALTEX4 output is high in idle phase
2	LOW			ALTEX4 output is low in idle phase
7:6	IDLECONF3	0x0	RW	<b>ALTEX3 Idle Phase Configuration</b>
	This bitfield determines how the alternate excite pin is configured during the idle phase			
	Value	Mode		Description
0	DISABLE			ALTEX3 output is disabled in idle phase
1	HIGH			ALTEX3 output is high in idle phase
2	LOW			ALTEX3 output is low in idle phase
5:4	IDLECONF2	0x0	RW	<b>ALTEX2 Idle Phase Configuration</b>
	This bitfield determines how the alternate excite pin is configured during the idle phase			
	Value	Mode		Description
0	DISABLE			ALTEX2 output is disabled in idle phase
1	HIGH			ALTEX2 output is high in idle phase
2	LOW			ALTEX2 output is low in idle phase
3:2	IDLECONF1	0x0	RW	<b>ALTEX1 Idle Phase Configuration</b>
	This bitfield determines how the alternate excite pin is configured during the idle phase			
	Value	Mode		Description
0	DISABLE			ALTEX1 output is disabled in idle phase
1	HIGH			ALTEX1 output is high in idle phase
2	LOW			ALTEX1 output is low in idle phase

Bit	Name	Reset	Access	Description
1:0	IDLECONF0	0x0	RW	<b>ALTEX0 Idle Phase Configuration</b>
This bitfield determines how the alternate excite pin is configured during the idle phase				
Value	Mode			Description
0	DISABLE			ALTEX0 output is disabled in idle phase
1	HIGH			ALTEX0 output is high in idle phase
2	LOW			ALTEX0 output is low in idle phase

## 28.5.19 LESENSE\_IF - Interrupt Flag Register

Offset	Bit Position																															
0x050	31	30	29	28	27	26	25	24	23	CNTOF	BUFOF	BULEVEL	BUFDATAV	DECERR	DEC	SCANCOMPLETE	CH15	CH14	CH13	CH12	CH11	CH10	CH9	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1	CH0
Reset										R 0 22	R 0 21	R 0 20	R 0 19	R 0 18	R 0 17	R 0 16	R 0 15	R 0 14	R 0 13	R 0 12	R 0 11	R 0 10	R 0 9	R 0 8	R 0 7	R 0 6	R 0 5	R 0 4	R 0 3	R 0 2	R 0 1	R 0 0
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
22	CNTOF	0	R	<b>CNTOF Interrupt Flag</b>  Set when the LESENSE counter overflows.
21	BUFOF	0	R	<b>BUFOF Interrupt Flag</b>  Set when the result buffer overflows
20	BULEVEL	0	R	<b>BULEVEL Interrupt Flag</b>  Set when the data buffer is full.
19	BUFDATAV	0	R	<b>BUFDATAV Interrupt Flag</b>  Set when data is available in the result buffer.
18	DECERR	0	R	<b>DECERR Interrupt Flag</b>  Set when the decoder detects an error
17	DEC	0	R	<b>DEC Interrupt Flag</b>  Set when the decoder has issued an interrupt request
16	SCANCOMPLETE	0	R	<b>SCANCOMPLETE Interrupt Flag</b>  Set when a scan sequence is completed
15	CH15	0	R	<b>CH15 Interrupt Flag</b>  Set when channel 15 triggers
14	CH14	0	R	<b>CH14 Interrupt Flag</b>  Set when channel 14 triggers
13	CH13	0	R	<b>CH13 Interrupt Flag</b>  Set when channel 13 triggers
12	CH12	0	R	<b>CH12 Interrupt Flag</b>  Set when channel 12 triggers
11	CH11	0	R	<b>CH11 Interrupt Flag</b>  Set when channel 11 triggers
10	CH10	0	R	<b>CH10 Interrupt Flag</b>  Set when channel 10 triggers

Bit	Name	Reset	Access	Description
9	CH9	0	R	<b>CH9 Interrupt Flag</b> Set when channel 9 triggers
8	CH8	0	R	<b>CH8 Interrupt Flag</b> Set when channel 8 triggers
7	CH7	0	R	<b>CH7 Interrupt Flag</b> Set when channel 7 triggers
6	CH6	0	R	<b>CH6 Interrupt Flag</b> Set when channel 6 triggers
5	CH5	0	R	<b>CH5 Interrupt Flag</b> Set when channel 5 triggers
4	CH4	0	R	<b>CH4 Interrupt Flag</b> Set when channel 4 triggers
3	CH3	0	R	<b>CH3 Interrupt Flag</b> Set when channel 3 triggers
2	CH2	0	R	<b>CH2 Interrupt Flag</b> Set when channel 2 triggers
1	CH1	0	R	<b>CH1 Interrupt Flag</b> Set when channel 1 triggers
0	CH0	0	R	<b>CH0 Interrupt Flag</b> Set when channel 0 triggers

## 28.5.20 LESENSE\_IFS - Interrupt Flag Set Register

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name										CNTOF	BUFOF	BULEVEL	BUFDATAV	DECERR	DEC	SCANCOMPLETE	CH15	CH14	CH13	CH12	CH11	CH10	CH9	CH8	CH7	CH6	CH5	CH4	CH3	CH2	CH1	CH0

Bit	Name	Reset	Access	Description
31:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
22	CNTOF	0	W1	<b>Set CNTOF Interrupt Flag</b>  Write 1 to set the CNTOF interrupt flag
21	BUFOF	0	W1	<b>Set BUFOF Interrupt Flag</b>  Write 1 to set the BUFOF interrupt flag
20	BULEVEL	0	W1	<b>Set BULEVEL Interrupt Flag</b>  Write 1 to set the BULEVEL interrupt flag
19	BUFDATAV	0	W1	<b>Set BUFDATAV Interrupt Flag</b>  Write 1 to set the BUFDATAV interrupt flag
18	DECERR	0	W1	<b>Set DECERR Interrupt Flag</b>  Write 1 to set the DECERR interrupt flag
17	DEC	0	W1	<b>Set DEC Interrupt Flag</b>  Write 1 to set the DEC interrupt flag
16	SCANCOMPLETE	0	W1	<b>Set SCANCOMPLETE Interrupt Flag</b>  Write 1 to set the SCANCOMPLETE interrupt flag
15	CH15	0	W1	<b>Set CH15 Interrupt Flag</b>  Write 1 to set the CH15 interrupt flag
14	CH14	0	W1	<b>Set CH14 Interrupt Flag</b>  Write 1 to set the CH14 interrupt flag
13	CH13	0	W1	<b>Set CH13 Interrupt Flag</b>  Write 1 to set the CH13 interrupt flag
12	CH12	0	W1	<b>Set CH12 Interrupt Flag</b>  Write 1 to set the CH12 interrupt flag
11	CH11	0	W1	<b>Set CH11 Interrupt Flag</b>  Write 1 to set the CH11 interrupt flag

Bit	Name	Reset	Access	Description
10	CH10	0	W1	<b>Set CH10 Interrupt Flag</b> Write 1 to set the CH10 interrupt flag
9	CH9	0	W1	<b>Set CH9 Interrupt Flag</b> Write 1 to set the CH9 interrupt flag
8	CH8	0	W1	<b>Set CH8 Interrupt Flag</b> Write 1 to set the CH8 interrupt flag
7	CH7	0	W1	<b>Set CH7 Interrupt Flag</b> Write 1 to set the CH7 interrupt flag
6	CH6	0	W1	<b>Set CH6 Interrupt Flag</b> Write 1 to set the CH6 interrupt flag
5	CH5	0	W1	<b>Set CH5 Interrupt Flag</b> Write 1 to set the CH5 interrupt flag
4	CH4	0	W1	<b>Set CH4 Interrupt Flag</b> Write 1 to set the CH4 interrupt flag
3	CH3	0	W1	<b>Set CH3 Interrupt Flag</b> Write 1 to set the CH3 interrupt flag
2	CH2	0	W1	<b>Set CH2 Interrupt Flag</b> Write 1 to set the CH2 interrupt flag
1	CH1	0	W1	<b>Set CH1 Interrupt Flag</b> Write 1 to set the CH1 interrupt flag
0	CH0	0	W1	<b>Set CH0 Interrupt Flag</b> Write 1 to set the CH0 interrupt flag

## 28.5.21 LESENSE\_IFC - Interrupt Flag Clear Register

Offset	31	30	29	28	27	26	25	24	23	Bit Position																																																									
Reset	(R)W1	0	22	(R)W1	0	21	(R)W1	0	20																																																										
Access																																																																			
Name	CNTOF	(R)W1	0	BUFOF	(R)W1	0	BUFLEVEL	(R)W1	0	DECERR	(R)W1	0	18	(R)W1	0	17	(R)W1	0	16	(R)W1	0	15	(R)W1	0	14	(R)W1	0	13	(R)W1	0	12	(R)W1	0	11	(R)W1	0	10	(R)W1	0	9	(R)W1	0	8	(R)W1	0	7	(R)W1	0	6	(R)W1	0	5	(R)W1	0	4	(R)W1	0	3	(R)W1	0	2	(R)W1	0	1	(R)W1	0	0

Bit	Name	Reset	Access	Description
31:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22	CNTOF	0	(R)W1	<b>Clear CNTOF Interrupt Flag</b>
				Write 1 to clear the CNTOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
21	BUFOF	0	(R)W1	<b>Clear BUFOF Interrupt Flag</b>
				Write 1 to clear the BUFOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
20	BUFLEVEL	0	(R)W1	<b>Clear BUFLEVEL Interrupt Flag</b>
				Write 1 to clear the BUFLEVEL interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
19	BUFDATAV	0	(R)W1	<b>Clear BUFDATAV Interrupt Flag</b>
				Write 1 to clear the BUFDATAV interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
18	DECERR	0	(R)W1	<b>Clear DECERR Interrupt Flag</b>
				Write 1 to clear the DECERR interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
17	DEC	0	(R)W1	<b>Clear DEC Interrupt Flag</b>
				Write 1 to clear the DEC interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
16	SCANCOMPLETE	0	(R)W1	<b>Clear SCANCOMPLETE Interrupt Flag</b>
				Write 1 to clear the SCANCOMPLETE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15	CH15	0	(R)W1	<b>Clear CH15 Interrupt Flag</b>
				Write 1 to clear the CH15 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
14	CH14	0	(R)W1	<b>Clear CH14 Interrupt Flag</b>
				Write 1 to clear the CH14 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

Bit	Name	Reset	Access	Description
13	CH13	0	(R)W1	<b>Clear CH13 Interrupt Flag</b>  Write 1 to clear the CH13 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
12	CH12	0	(R)W1	<b>Clear CH12 Interrupt Flag</b>  Write 1 to clear the CH12 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
11	CH11	0	(R)W1	<b>Clear CH11 Interrupt Flag</b>  Write 1 to clear the CH11 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
10	CH10	0	(R)W1	<b>Clear CH10 Interrupt Flag</b>  Write 1 to clear the CH10 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
9	CH9	0	(R)W1	<b>Clear CH9 Interrupt Flag</b>  Write 1 to clear the CH9 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
8	CH8	0	(R)W1	<b>Clear CH8 Interrupt Flag</b>  Write 1 to clear the CH8 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
7	CH7	0	(R)W1	<b>Clear CH7 Interrupt Flag</b>  Write 1 to clear the CH7 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
6	CH6	0	(R)W1	<b>Clear CH6 Interrupt Flag</b>  Write 1 to clear the CH6 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
5	CH5	0	(R)W1	<b>Clear CH5 Interrupt Flag</b>  Write 1 to clear the CH5 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
4	CH4	0	(R)W1	<b>Clear CH4 Interrupt Flag</b>  Write 1 to clear the CH4 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
3	CH3	0	(R)W1	<b>Clear CH3 Interrupt Flag</b>  Write 1 to clear the CH3 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
2	CH2	0	(R)W1	<b>Clear CH2 Interrupt Flag</b>  Write 1 to clear the CH2 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
1	CH1	0	(R)W1	<b>Clear CH1 Interrupt Flag</b>  Write 1 to clear the CH1 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	CH0	0	(R)W1	<b>Clear CH0 Interrupt Flag</b>  Write 1 to clear the CH0 interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 28.5.22 LESENSE\_IEN - Interrupt Enable Register

Offset	Bit Position																
0x05C	31	30	29	28	27	26	25	24	23								
Reset	RW	0	22	RW	0	21	RW	0	20	RW	0	19	RW	0	18	RW	0
Access																	
Name				CNTOF			BUFOF			BUFLEVEL			BUFDATAV			DECERR	
Bit	Name	Reset	Access	Description													
31:23	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>													
22	CNTOF	0	RW	<b>CNTOF Interrupt Enable</b>													
		Enable/disable the CNTOF interrupt															
21	BUFOF	0	RW	<b>BUFOF Interrupt Enable</b>													
		Enable/disable the BUFOF interrupt															
20	BUFLEVEL	0	RW	<b>BUFLEVEL Interrupt Enable</b>													
		Enable/disable the BUFLEVEL interrupt															
19	BUFDATAV	0	RW	<b>BUFDATAV Interrupt Enable</b>													
		Enable/disable the BUFDATAV interrupt															
18	DECERR	0	RW	<b>DECERR Interrupt Enable</b>													
		Enable/disable the DECERR interrupt															
17	DEC	0	RW	<b>DEC Interrupt Enable</b>													
		Enable/disable the DEC interrupt															
16	SCANCOMPLETE	0	RW	<b>SCANCOMPLETE Interrupt Enable</b>													
		Enable/disable the SCANCOMPLETE interrupt															
15	CH15	0	RW	<b>CH15 Interrupt Enable</b>													
		Enable/disable the CH15 interrupt															
14	CH14	0	RW	<b>CH14 Interrupt Enable</b>													
		Enable/disable the CH14 interrupt															
13	CH13	0	RW	<b>CH13 Interrupt Enable</b>													
		Enable/disable the CH13 interrupt															
12	CH12	0	RW	<b>CH12 Interrupt Enable</b>													
		Enable/disable the CH12 interrupt															
11	CH11	0	RW	<b>CH11 Interrupt Enable</b>													
		Enable/disable the CH11 interrupt															

Bit	Name	Reset	Access	Description
10	CH10	0	RW	<b>CH10 Interrupt Enable</b> Enable/disable the CH10 interrupt
9	CH9	0	RW	<b>CH9 Interrupt Enable</b> Enable/disable the CH9 interrupt
8	CH8	0	RW	<b>CH8 Interrupt Enable</b> Enable/disable the CH8 interrupt
7	CH7	0	RW	<b>CH7 Interrupt Enable</b> Enable/disable the CH7 interrupt
6	CH6	0	RW	<b>CH6 Interrupt Enable</b> Enable/disable the CH6 interrupt
5	CH5	0	RW	<b>CH5 Interrupt Enable</b> Enable/disable the CH5 interrupt
4	CH4	0	RW	<b>CH4 Interrupt Enable</b> Enable/disable the CH4 interrupt
3	CH3	0	RW	<b>CH3 Interrupt Enable</b> Enable/disable the CH3 interrupt
2	CH2	0	RW	<b>CH2 Interrupt Enable</b> Enable/disable the CH2 interrupt
1	CH1	0	RW	<b>CH1 Interrupt Enable</b> Enable/disable the CH1 interrupt
0	CH0	0	RW	<b>CH0 Interrupt Enable</b> Enable/disable the CH0 interrupt

### 28.5.23 LESENSE\_SYNCBUSY - Synchronization Busy Register

Offset	Bit Position																																
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	
Access																																	
Name																																	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7	CMD	0	R	<b>CMD Register Busy</b> Set when the value written to CMD is being synchronized.
6:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

**28.5.24 LESENSE\_ROUTEPEN - I/O Routing Register (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	
Name	ALTEX7PEN	ALTEX6PEN	ALTEX5PEN	ALTEX4PEN	ALTEX3PEN	ALTEX2PEN	ALTEX1PEN	ALTEX0PEN	CH15PEN	CH14PEN	CH13PEN	CH12PEN	CH11PEN	CH10PEN	CH9PEN	CH8PEN	CH7PEN	CH6PEN	CH5PEN	CH4PEN	CH3PEN	CH2PEN	CH1PEN	CH0PEN	RW	RW	RW	RW	RW			

Bit	Name	Reset	Access	Description
31:24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	ALTEX7PEN	0	RW	<b>ALTEX7 Pin Enable</b>  Set this bit to enable LESENSE ALTEX7 pin
22	ALTEX6PEN	0	RW	<b>ALTEX6 Pin Enable</b>  Set this bit to enable LESENSE ALTEX6 pin
21	ALTEX5PEN	0	RW	<b>ALTEX5 Pin Enable</b>  Set this bit to enable LESENSE ALTEX5 pin
20	ALTEX4PEN	0	RW	<b>ALTEX4 Pin Enable</b>  Set this bit to enable LESENSE ALTEX4 pin
19	ALTEX3PEN	0	RW	<b>ALTEX3 Pin Enable</b>  Set this bit to enable LESENSE ALTEX3 pin
18	ALTEX2PEN	0	RW	<b>ALTEX2 Pin Enable</b>  Set this bit to enable LESENSE ALTEX2 pin
17	ALTEX1PEN	0	RW	<b>ALTEX1 Pin Enable</b>  Set this bit to enable LESENSE ALTEX1 pin
16	ALTEX0PEN	0	RW	<b>ALTEX0 Pin Enable</b>  Set this bit to enable LESENSE ALTEX0 pin
15	CH15PEN	0	RW	<b>CH15 Pin Enable</b>  Set this bit to enable LESENSE CH15 pin
14	CH14PEN	0	RW	<b>CH14 Pin Enable</b>  Set this bit to enable LESENSE CH14 pin
13	CH13PEN	0	RW	<b>CH13 Pin Enable</b>  Set this bit to enable LESENSE CH13 pin
12	CH12PEN	0	RW	<b>CH12 Pin Enable</b>  Set this bit to enable LESENSE CH12 pin
11	CH11PEN	0	RW	<b>CH11 Pin Enable</b>  Set this bit to enable LESENSE CH11 pin

Bit	Name	Reset	Access	Description
10	CH10PEN	0	RW	<b>CH10 Pin Enable</b>  Set this bit to enable LESENSE CH10 pin
9	CH9PEN	0	RW	<b>CH9 Pin Enable</b>  Set this bit to enable LESENSE CH9 pin
8	CH8PEN	0	RW	<b>CH8 Pin Enable</b>  Set this bit to enable LESENSE CH8 pin
7	CH7PEN	0	RW	<b>CH7 Pin Enable</b>  Set this bit to enable LESENSE CH7 pin
6	CH6PEN	0	RW	<b>CH6 Pin Enable</b>  Set this bit to enable LESENSE CH6 pin
5	CH5PEN	0	RW	<b>CH5 Pin Enable</b>  Set this bit to enable LESENSE CH5 pin
4	CH4PEN	0	RW	<b>CH4 Pin Enable</b>  Set this bit to enable LESENSE CH4 pin
3	CH3PEN	0	RW	<b>CH3 Pin Enable</b>  Set this bit to enable LESENSE CH3 pin
2	CH2PEN	0	RW	<b>CH2 Pin Enable</b>  Set this bit to enable LESENSE CH2 pin
1	CH1PEN	0	RW	<b>CH1 Pin Enable</b>  Set this bit to enable LESENSE CH1 pin
0	CH0PEN	0	RW	<b>CH0 Pin Enable</b>  Set this bit to enable LESENSE CH0 pin

**28.5.25 LESENSE\_STx\_TCONFA - State Transition Configuration a (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																	
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																	0xX	0xXX								0xX	0xXX							
Access																	RW	RW								RW	RW							
Name																	PRSACT	NEXTSTATE								MASK	COMP							

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18:16	PRSACT	0xX	RW	<b>Configure Transition Action</b>
		Configure which action to perform when sensor state equals COMP		
	DECCTRL_PRSCNT = 0			
	Mode	Value		Description
	NONE	0		No PRS pulses generated
	PRS0	1		Generate pulse on LESPRS0
	PRS1	2		Generate pulse on LESPRS1
	PRS01	3		Generate pulse on LESPRS0 and LESPRS1
	PRS2	4		Generate pulse on LESPRS2
	PRS02	5		Generate pulse on LESPRS0 and LESPRS2
	PRS12	6		Generate pulse on LESPRS1 and LESPRS2
	PRS012	7		Generate pulse on LESPRS0, LESPRS1 and LESPRS2
	DECCTRL_PRSCNT = 1			
	NONE	0		Do not count
	UP	1		Count up
	DOWN	2		Count down
	PRS2	4		Generate pulse on LESPRS2
	UPANDPRS2	5		Count up and generate pulse on LESPRS2.
	DOWNANDPRS2	6		Count down and generate pulse on LESPRS2.
15	SETIF	X	RW	<b>Set Interrupt Flag Enable</b>
		Set interrupt flag when sensor state equals COMP		
14	CHAIN	X	RW	<b>Enable State Descriptor Chaining</b>
		When set, descriptor in the next location will also be evaluated		

Bit	Name	Reset	Access	Description
13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12:8	NEXTSTATE	0xXX	RW	<b>Next State Index</b>  Index of next state to be entered if the sensor state equals COMP
7:4	MASK	0xX	RW	<b>Sensor Mask</b>  Set bit X to exclude sensor X from evaluation.
3:0	COMP	0xX	RW	<b>Sensor Compare Value</b>  State transition is triggered when sensor state equals COMP

**28.5.26 LESENSE\_STx\_TCONFB - State Transition Configuration B (Async Reg)**For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x104	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset													0xX	X							0xXX				0xX				0xX			
Access													RW							RW				RW				RW				
Name													PRSACT				SETIF				NEXTSTATE				MASK				COMP			

Bit	Name	Reset	Access	Description
31:19	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
18:16	PRSACT	0xX	RW	<b>Configure Transition Action</b>
	Configure which action to perform when sensor state equals COMP			
	DECCTRL_PRSCNT = 0			
	Mode	Value		Description
	NONE	0		No PRS pulses generated
	PRS0	1		Generate pulse on PRS0
	PRS1	2		Generate pulse on PRS1
	PRS01	3		Generate pulse on PRS0 and PRS1
	PRS2	4		Generate pulse on PRS2
	PRS02	5		Generate pulse on PRS0 and PRS2
	PRS12	6		Generate pulse on PRS1 and PRS2
	PRS012	7		Generate pulse on PRS0, PRS1 and PRS2
	DECCTRL_PRSCNT = 1			
	NONE	0		Do not count
	UP	1		Count up
	DOWN	2		Count down
	PRS2	4		Generate pulse on PRS2
	UPANDPRS2	5		Count up and generate pulse on PRS2.
	DOWNANDPRS2	6		Count down and generate pulse on PRS2.
15	SETIF	X	RW	<b>Set Interrupt Flag</b>
	Set interrupt flag when sensor state equals COMP			
14:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
12:8	NEXTSTATE	0xXX	RW	<b>Next State Index</b>  Index of next state to be entered if the sensor state equals COMP
7:4	MASK	0xX	RW	<b>Sensor Mask</b>  Set bit X to exclude sensor X from evaluation.
3:0	COMP	0xX	RW	<b>Sensor Compare Value</b>  State transition is triggered when sensor state equals COMP

### 28.5.27 LESENSE\_BUFX\_DATA - Scan Results (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																		
0x200	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																																			
Access																																			
Name																																			
	Bit	Name	Reset	Access	Description																														

Bit	Name	Reset	Access	Description
31:20	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
19:16	DATASRC	0xX	R	<b>Result Data Source</b>  This bitfield contains the channel index for the sensor result in DATA.
15:0	DATA	0xFFFF	RWH	<b>Scan Result Buffer</b>  This bitfield contains the sensor result.

**28.5.28 LESENSE\_CHx\_TIMING - Scan Configuration (Async Reg)**

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																																									
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0										
Reset									0xXXX								0xXX								0XX																	
Access									RW									RW									RW															
Name									MEASUREDLY									SAMPLEDLY									EXTIME															
Bit	Name	Reset	Access	Description																																						
31:24	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																								
23:14	MEASUREDLY	0xXXX	RW	<b>Set Measure Delay</b>	Configure measure delay. Sensor measuring is delayed for MEASUREDLY EXCLK cycles.																																					
13:6	SAMPLEDLY	0xXX	RW	<b>Set Sample Delay</b>	Configure sample delay. Sampling will occur after SAMPLEDLY SAMPLECLK cycles.																																					
5:0	EXTIME	0XX	RW	<b>Set Excitation Time</b>	Configure excitation time. Excitation will last EXTIME EXCLK cycles.																																					

#### 28.5.29 LESENSE\_CHx\_INTERACT - Scan Configuration (Async Reg)

For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Bit	Name	Reset	Access	Description															
31:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
21	ALTEX	X	RW	<b>Use Alternative Excite Pin</b>															
				If set, alternative excite pin will be used for excitation															
20	SAMPLECLK	X	RW	<b>Select Clock Used for Timing of Sample Delay</b>															
				This bit is used to configure which clock is used for timing of SAMPLEDLY															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LFACLK</td><td>LFACLK will be used for timing</td></tr> <tr> <td>1</td><td>AUXHFRCO</td><td>AUXHFRCO will be used for timing</td></tr> </tbody> </table>	Value	Mode	Description	0	LFACLK	LFACLK will be used for timing	1	AUXHFRCO	AUXHFRCO will be used for timing						
Value	Mode	Description																	
0	LFACLK	LFACLK will be used for timing																	
1	AUXHFRCO	AUXHFRCO will be used for timing																	
19	EXCLK	X	RW	<b>Select Clock Used for Excitation Timing</b>															
				This bit is used to configure which clock is used for timing of EXTIME and MEASUREDLY															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LFACLK</td><td>LFACLK will be used for timing</td></tr> <tr> <td>1</td><td>AUXHFRCO</td><td>AUXHFRCO will be used for timing</td></tr> </tbody> </table>	Value	Mode	Description	0	LFACLK	LFACLK will be used for timing	1	AUXHFRCO	AUXHFRCO will be used for timing						
Value	Mode	Description																	
0	LFACLK	LFACLK will be used for timing																	
1	AUXHFRCO	AUXHFRCO will be used for timing																	
18:17	EXMODE	0xX	RW	<b>Set GPIO Mode</b>															
				GPIO mode for the excitation phase of the scan sequence. Note that DACOUT is only available on channels 0, 1, 2, 3, 12, 13, 14, 15															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DISABLE</td><td>Disabled</td></tr> <tr> <td>1</td><td>HIGH</td><td>Push Pull, GPIO is driven high</td></tr> <tr> <td>2</td><td>LOW</td><td>Push Pull, GPIO is driven low</td></tr> <tr> <td>3</td><td>DACOUT</td><td>VDAC output</td></tr> </tbody> </table>	Value	Mode	Description	0	DISABLE	Disabled	1	HIGH	Push Pull, GPIO is driven high	2	LOW	Push Pull, GPIO is driven low	3	DACOUT	VDAC output
Value	Mode	Description																	
0	DISABLE	Disabled																	
1	HIGH	Push Pull, GPIO is driven high																	
2	LOW	Push Pull, GPIO is driven low																	
3	DACOUT	VDAC output																	
16:14	SETIF	0xX	RW	<b>Enable Interrupt Generation</b>															
				Select interrupt generation mode for CHx interrupt flag.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> </table>	Value	Mode	Description												
Value	Mode	Description																	

Bit	Name	Reset	Access	Description
0		NONE		No interrupt is generated
1		LEVEL		Set interrupt flag if the sensor triggers.
2		POSEDGE		Set interrupt flag on positive edge of the sensor state
3		NEGEDGE		Set interrupt flag on negative edge of the sensor state
4		BOTHEDGES		Set interrupt flag on both edges of the sensor state
13:12	SAMPLE	0xX	RW	<b>Select Sample Mode</b>
				Select measurement to be used for evaluation
	Value	Mode		Description
	0	ACMPCOUNT		Counter output will be used in evaluation
	1	ACMP		ACMP output will be used in evaluation
	2	ADC		ADC output will be used in evaluation
	3	ADCDIFF		Differential ADC output will be used in evaluation
11:0	THRES	0XXX	RW	<b>ACMP Threshold or VDAC Data</b>
				Set threshold used for ACMP, or data used in VDAC conversion.

**28.5.30 LESENSE\_CHx\_EVAL - Scan Configuration (Async Reg)**


For more information about asynchronous registers see [4.3 Access to Low Energy Peripherals \(Asynchronous Registers\)](#).

Offset	Bit Position																															
0x248	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xXXXX																															
Access	RWH																															
Name	COMPTHRES																															

Bit	Name	Reset	Access	Description
31:23	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
22:21	MODE	0xX	RW	<b>Configure Evaluation Mode</b>
	Select which evaluation mode to be used on the measurement result			
	Value	Mode	Description	
	0	THRES	Threshold comparison is used to evaluate sensor result	
	1	SLIDINGWIN	Sliding window is used to evaluate sensor result	
	2	STEPDET	Step detection is used to evaluate sensor result	
20	SCANRESINV	X	RW	<b>Enable Inversion of Result</b>
	If set, the bit stored in SCANRES will be inverted.			
19:18	STRSAMPLE	0xX	RW	<b>Enable Storing of Sensor Sample in Result Buffer</b>
	If set, the sensor sample value will be stored and available in the result buffer			
	Value	Mode	Description	
	0	DISABLE	Nothing will be stored in the result buffer.	
	1	DATA	The sensor sample data will be stored in the result buffer.	
	2	DATASRC	The data source (i.e., the channel) will be stored alongside the sensor sample data.	
17	DECODE	X	RW	<b>Send Result to Decoder</b>
	If set, the result from this channel will be shifted into the decoder register.			
16	COMP	X	RW	<b>Select Mode for Threshold Comparison</b>
	Set compare mode for threshold comparisons (CHx_INTERACT_SAMPLE != ACMP and CHx_EVAL_MODE == THRES).			
	Value	Mode	Description	
	0	LESS	Comparison evaluates to 1 if sensor data is less than COMPTHRES.	
	1	GE	Comparison evaluates to 1 if sensor data is greater than or equal to COMPTHRES.	

Bit	Name	Reset	Access	Description
15:0	COMPTHRES	0xFFFF	RWH	<b>Decision Threshold for Sensor Data</b>  In threshold comparison mode, this bitfield is used to configure threshold used for comparison. In step detection mode, this bitfield is written by LESENSE, and contains the value from previous sensor measurement. In sliding window mode, this bitfield is written by LESENSE, and contains the window base for the given channel.

## 29. GPCRC - General Purpose Cyclic Redundancy Check



Quick Facts
<b>What?</b>
The GPCRC is an error-detecting module commonly used in digital networks and storage systems to detect accidental changes to data.
<b>Why?</b>
The GPCRC module can detect errors in data, giving a higher system reliability and robustness.
<b>How?</b>
Blocks of data entering GPCRC module can have a short checksum, based on the remainder of a polynomial division of their contents; on retrieval the calculation is repeated, and corrective action can be taken against presumed data corruption if the check values do not match.

### 29.1 Introduction


The GPCRC module is a slave peripheral that implements a Cyclic Redundancy Check (CRC) function. It supports both 32-bit and 16-bit polynomials. The supported 32-bit polynomial is 0x04C11DB7(IEEE 802.3), while the 16-bit polynomial can be programmed to any value, depending on the needs of the application. Common 16-bit polynomials are 0x1021 (CCITT-16), 0x3D65 (IEC16-MBus), and 0x8005 (zigbee, 802.15.4, and USB).

### 29.2 Features

- Programmable 16-bit polynomial, fixed 32-bit polynomial
- Byte-level bit reversal for the CRC input
- Byte-order reorientation for the CRC input
- Word or half-word bit reversal of the CRC result
- Ability to configure and seed an operation in a single register write
- Single-cycle CRC computation for 32-, 16-, or 8-bit blocks
- DMA operation

## 29.3 Functional Description

An overview of the GPCRC module is shown in [Figure 29.1 GPCRC Overview on page 1054](#).




**Figure 29.1. GPCRC Overview**

### 29.3.1 Polynomial Specification

POLYSEL in GPCRC\_CTRL selects between 32-bit and 16-bit polynomial functions. When a 32-bit polynomial is selected, the fixed IEEE 802.3 polynomial(0x04C11DB7) is used. When a 16-bit polynomial is selected, any valid polynomial can be defined by the user in GPCRC\_POLY.

A valid 16-bit CRC polynomial must have an  $x^{16}$  term and an  $x^0$  term. Theoretically, a 16-bit polynomial has 17 terms total. The convention used is to omit the  $x^{16}$  term. The polynomial should be written in **reversed** (little endian) bit order. The most significant bit corresponds to the lowest order term. Thus, the most significant bit in CRC\_POLY represents the  $x^0$  term, and the least significant bit in CRC\_POLY represents the  $x^{15}$  term. The highest significant bit of CRC\_POLY should always set to 1. The polynomial representation for the CRC-16-CCIT polynomial  $x^{16} + x^{12} + x^5 + 1$ , or 0x8408 in reversed order, is shown in [Figure 29.2 Polynomial Representation on page 1055](#).



**Figure 29.2. Polynomial Representation**

### 29.3.2 Input and Output Specification

The CRC input data can be written to the GPCRC\_INPUTDATA, GPCRC\_INPUTDATAWORD or GPCRC\_INPUTDATABYTE register via the APB bus based on different data size. If BYTEMODE in GPCRC\_CTRL is set, only the least significant byte of the data word will be used for the CRC calculation no matter which input register is written. There are also three output registers for different ordering. Reading from GPCRC\_DATA will get the result based on the polynomial in reversed order, while reading from GPCRC\_DATAREV will get the result based on the polynomial in normal order. The CRC calculation needs one clock cycle, reading from GPCRC\_DATA, GPCRC\_DATAREV or GPCRC\_DATABYTEREVE register or writing to GPCRC\_CMD register is halted while the calculation is in progress.

### 29.3.3 Initialization


The CRC can be pre-loaded or re-initialized by first writing a 32-bit programmable init value to INIT in GPCRC\_INIT and then setting INIT in GPCRC\_CMD. It can also be re-initialized automatically when read from DATA, DATAREV or DATABYTEREVE provided that AUTOINIT in GPCRC\_CTRL is set, the CRC would be re-initialized with the stored init value.

### 29.3.4 DMA Usage

A DMA channel may be used to transfer data into the CRC engine. All bytes and half-word writes must be word-aligned. The recommended DMA usage model is to use the DMA to transfer all available words of data and use software writes to capture any remaining bytes.

### 29.3.5 Byte-Level Bit Reversal and Byte Reordering


The byte-level bit reversal and byte reordering operations occur before the data is used in the CRC calculation. Byte reordering can occur on words or half words. The hardware ignores the BYTEREVERSE field with any byte writes or operations with byte mode enabled (BYTEMODE = 1), but the bit reversal settings (BITREVERSE) are still applied to the byte. 32-bit little endian MSB-first data can be treated like 32-bit little endian LSB-first data, as shown in [Figure 29.3 Data Ordering Example - 32-bit MSB -first to LSB-first on page 1056](#). In this example, 32-bit data is written to GPCRC\_INPUTDATA, BYTEREVERSE is set for byte ordering, and BITREVERSE is set for byte-level bit reversal.



**Figure 29.3. Data Ordering Example - 32-bit MSB -first to LSB-first**

When handling 16-bit data, the byte reordering function only swap the two lowest bytes and clear the two highest bytes, as shown in [Figure 29.4 Data Ordering Example - 16-bit MSB -first to LSB-first on page 1057](#). In this example, 16-bit data is written to GPCRC\_INPUTDATAWORD, BYTEREVERSE is set for byte ordering, and BITREVERSE is set for byte-level bit reversal.

Input data is big endian, MSB-first



**Figure 29.4. Data Ordering Example - 16-bit MSB -first to LSB-first**

Assuming a word input byte order of B3 B2 B1 B0, the values used in the CRC calculation for the various settings of the byte-level bit reversal and byte reordering are shown in [Table 29.1 Byte-Level Bit Reversal and Byte Reordering Results \(B3 B2 B1 B0 Input Order\)](#) on page 1057.

**Table 29.1. Byte-Level Bit Reversal and Byte Reordering Results (B3 B2 B1 B0 Input Order)**

Input Width(bits)	BYTEREVERSE Setting	BITREVERSE Setting	Input to CRC Calculation
32	0	0	B3 B2 B1 B0
32	1	1	'B0 'B1 'B2 'B3
32	1	0	B0 B1 B2 B3
32	0	1	'B3 'B2 'B1 'B0
16	0	0	XX XX B1 B0
16	1	1	XX XX 'B0 'B1
16	1	0	XX XX B0 B1
16	0	1	XX XX 'B1 'B0
8	-	0	XX XX XX XX B0
8	-	1	XX XX XX XX 'B0

Input Width(bits)	BYTEREVERSE Setting	BITREVERSE Setting	Input to CRC Calculation
<b>Note:</b>			
1. X indicates a "don't care". 2. Bn is the byte field within the word. 3. 'Bn is the bit-reversed byte field within the word.			

## 29.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	GPCRC_CTRL	RW	Control Register
0x004	GPCRC_CMD	W1	Command Register
0x008	GPCRC_INIT	RWH	CRC Init Value
0x00C	GPCRC_POLY	RW	CRC Polynomial Value
0x010	GPCRC_INPUTDATA	W	Input 32-bit Data Register
0x014	GPCRC_INPUTDATAHWORD	W	Input 16-bit Data Register
0x018	GPCRC_INPUTDATABYTE	W	Input 8-bit Data Register
0x01C	GPCRC_DATA	R	CRC Data Register
0x020	GPCRC_DATAREV	R	CRC Data Reverse Register
0x024	GPCRC_DATABYTTEREV	R	CRC Data Byte Reverse Register

## 29.5 Register Description

### 29.5.1 GPCRC\_CTRL - Control Register

Offset	Bit Position																																		
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																																			
Access																																			
Name																																			

Bit	Name	Reset	Access	Description
31:14	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
13	AUTOINIT	0	RW	<b>Auto Init Enable</b>
				Enables auto init by re-seeding the CRC result based on the value in INIT after reading of DATA, DATAREV or DATABYTEREV.
12:11	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
10	BYTEREVERSE	0	RW	<b>Byte Reverse Mode</b>
				Allows byte level reverse of bytes B3, B2, B1, B0 within the 32-bit data word
	Value	Mode		Description
	0	NORMAL		No reverse: B3, B2, B1, B0
	1	REVERSED		Reverse byte order. For 32-bit: B0, B1, B2, B3; For 16-bit: 0, 0, B0, B1
9	BITREVERSE	0	RW	<b>Byte-level Bit Reverse Enable</b>
				Reverses bits within each byte of the 32-bit data word
	Value	Mode		Description
	0	NORMAL		No reverse
	1	REVERSED		Reverse bit order in each byte
8	BYTEMODE	0	RW	<b>Byte Mode Enable</b>
				Treats all writes as bytes. Only the least significant byte of the data-word will be used for CRC calculation for all writes
7:5	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
4	POLYSEL	0	RW	<b>Polynomial Select</b>
				Selects 16-bit CRC programmable polynomial or 32-bit CRC fixed polynomial
	Value	Mode		Description
	0	CRC32		CRC-32 (0x04C11DB7) polynomial selected
	1	16		16-bit CRC programmable polynomial selected

Bit	Name	Reset	Access	Description
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	EN	0	RW	<b>CRC Functionality Enable</b>
Enables CRC functionality.				
Value		Mode	Description	
0		DISABLE	Disable CRC function. Reordering function is available, only BITREVERSE and BYTEREVERSE bits are configurable in this mode	
1		ENABLE	Writes to inputdata registers result in CRC operations	

### 29.5.2 GPCRC\_CMD - Command Register

Offset	Bit Position																																	
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																	0	
Access																																		W1
Name																																		INIT

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	INIT	0	W1	<b>Initialization Enable</b>
Writing 1 to this bit initialize the CRC by writing the INIT value in CRC_INIT to CRC_DATA.				

### 29.5.3 GPCRC\_INIT - CRC Init Value

Offset	Bit Position																																	
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																																	0x00000000	
Access																																		RWH
Name																																		INIT

Bit	Name	Reset	Access	Description
31:0	INIT	0x00000000	RWH	<b>CRC Initialization Value</b>
This value is loaded into CRC_DATA upon issuing the INIT command in CRC_CMD				

#### 29.5.4 GPCRC\_POLY - CRC Polynomial Value

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access																	0x0000								RW							
Name																	POLY															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

This value defines 16-bit POLY, which is used as the polynomial during the 16-bit CRC calculation. The polynomial is defined in reversed representation, meaning that the lowest degree term is in the highest bit position of POLY. Additionally, the highest degree term in the polynomial is implicit. Further examples of the CRC configuration can be found in the documentation.

### 29.5.5 GPCRC\_INPUTDATA - Input 32-bit Data Register

Bit	Name	Reset	Access	Description
31:0	INPUTDATA	0x00000000	W	<b>Input Data for 32-bit</b>

CRC Input 32-bit Data can be written to this register. Each time this register is written, the CRC value is updated.

### 29.5.6 GPCRC\_INPUTDATAHWORD - Input 16-bit Data Register

Offset	Bit Position																															
0x014	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	W															
Name																	INPUTDATAHWORD															

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15:0	INPUTDATAHWORD	0x0000	W	<b>Input Data for 16-bit</b>  CRC Input 16-bit Data can be written to this register. Each time this register is written, the CRC value is updated.

### 29.5.7 GPCRC\_INPUTDATABYTE - Input 8-bit Data Register

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x00															
Access																	W															
Name																	INPUTDATABYTE															

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	INPUTDATABYTE	0x00	W	<b>Input Data for 8-bit</b>  CRC Input 8-bit Data can be written to this register. Each time this register is written, the CRC value is updated.

### 29.5.8 GPCRC\_DATA - CRC Data Register

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATA																															
Bit	Name	Reset	Access	Description																												
31:0	DATA	0x00000000	R	CRC Data Register																												
		CRC Data Register, read only. The CRC data register may still be indirectly written from software, by writing the INIT register and then issue an INITIALIZE command.																														

### 29.5.9 GPCRC\_DATAREV - CRC Data Reverse Register


Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATAREV																															
Bit	Name	Reset	Access	Description																												
31:0	DATAREV	0x00000000	R	Data Reverse Value																												
		Bit reversed version of CRC Data register. When a 32-bit CRC polynomial is selected, the reversal occurs on the entire 32-bit word. When a 16-bit CRC polynomial is selected, the bits [15:0] are reversed.																														

### 29.5.10 GPCRC\_DATABYTEREV - CRC Data Byte Reverse Register

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	DATABYTEREV																															

Bit	Name	Reset	Access	Description
31:0	DATABYTEREV	0x00000000	R	<b>Data Byte Reverse Value</b>  Byte reversed version of CRC Data register. When a 32-bit CRC polynomial is selected, the bytes are swizzled to {B0, B1, B2, B3}. When a 16-bit CRC polynomial is selected, the bytes are swizzled to {0, 0, B0, B1}.

## 30. TRNG - True Random Number Generator



### Quick Facts

#### What?

The TRNG module is a non-deterministic random number generator based on a full hardware solution.

#### Why?

Secure cryptography commonly relies on randomly-generated numbers for key generation. Software solutions for random number generation do not usually produce results with enough entropy to satisfy existing standards. Dedicated hardware can provide suitable entropy in an energy-efficient, non-intrusive manner, while also relieving software burden.

#### How?

Ring oscillators and sampling logic combine to produce non-deterministic random numbers.

### 30.1 Introduction


The TRNG module is a non-deterministic random number generator based on a full hardware solution. The TRNG output passes the NIST 800-22 and AIS31 test suites.

### 30.2 Features

- Simple bus interface to access random numbers, control, and status registers
- 64 x 32-bit FIFO for random number access
- Interrupt sources from different FIFO, error, and noise alarm events
- Passes NIST 800-22 and AIS31
- Ready for NIST 800-90B
- Health tests compliant to NIST 800-90B and AIS31

### 30.3 Functional Description

Software drivers provided by Silicon Labs offer a simple API interface to the TRNG module. It is highly recommended to use the provided software libraries to access the TRNG module. An overview of the TRNG module is shown in [Figure 30.1 TRNG Overview on page 1066](#).



**Figure 30.1. TRNG Overview**

#### 30.3.1 Built-In Tests

The TRNG module includes several built-in tests to detect issues with the noise source, ensure entropy, and meet cryptography standards. The Repetition Count Test and Adaptive Proportion Test with window sizes of 64 and 4096 bits described in section 6.5.1.2 of NIST-800-90B (<http://csrc.nist.gov/publications/drafts/800-90/draft-sp800-90b.pdf>) are implemented in hardware and run continuously on the data. All three tests have corresponding interrupt flags that can optionally be used to generate a system interrupt.

The AIS31 Online Test described in section 5.5.3 of [https://www.bsi.bund.de/SharedDocs/Downloads/DE/BSI/Zertifizierung/Interpretationen/AIS\\_31\\_Functionality\\_classes\\_for\\_random\\_number\\_generators\\_e.pdf](https://www.bsi.bund.de/SharedDocs/Downloads/DE/BSI/Zertifizierung/Interpretationen/AIS_31_Functionality_classes_for_random_number_generators_e.pdf) is also implemented in hardware, and runs continuously on the data. Both the preliminary noise alarm and the noise alarm are optionally available as interrupt sources from the TRNG module. If a noise alarm occurs, the TRNG will be shut down, and must be reset with a software reset.

Additionally, the NIST-800-90B and AIS31 startup tests may be optionally enabled or disabled by software. The NIST-800-90B startup test is enabled if the CONTROL\_BYPNIST bit is cleared to 0. The AIS31 startup test is likewise enabled when CONTROL\_BYPAIS31 is cleared to 0. If either the NIST-800-90B or AIS31 startup tests are enabled, no data will be written to the output FIFO until the startup requirements for these tests pass.

#### 30.3.2 FIFO Interface

The TRNG module includes a 64-word output FIFO to hold the output data as it becomes available. The number of 32-bit words available in the FIFO may be checked at any time by reading the FIFOLEVEL register. When the FIFO is completely filled, the TRNG will be shut down, the STATUS\_FULLIF flag will be set, and no further data will be written to the FIFO until the FIFO has been flushed. Data may be read from the FIFO one word (32-bits) at a time via the FIFO register. The STATUS\_FULLIF flag is cleared upon reading the FIFOLEVEL register.

### 30.3.3 Data Format - Byte Ordering

All cryptographic data is handled following the big-endian format (AES standard). The first byte (lowest address) of the data is the Most Significant Byte (MSB). However, the bus interfaces on the core use little endian format for internal byte ordering within a 32-bit word. The Least Significant Byte (LSB) within a word is stored at the lowest address.

For example, a 128-bit block 0x00112233445566778899AABBCCDDEEFF is read from the FIFO in the following order:

Word 1 = 0x33221100  
Word 2 = 0x77665544  
Word 3 = 0xBBAA9988  
Word 4 = 0xFFDDEECC

This is important to note when checking the conditioning function for validity. The KEY registers also follow this standard, with KEY0 holding the MSB of a 128-bit value and KEY3 holding the LSB.

### 30.3.4 TRNG Usage

It is highly recommended to use the software libraries provided by Silicon Labs to access the TRNG module. The information in the following sections are reference for users who choose to write their own low-level software drivers.

### 30.3.4.1 Checking the Conditioning Function

The conditioning function receives 512 bits from the entropy source and generates 128 bits of output. The conditioning function can be tested by writing a known key and known data into the block with test mode enabled, then validating against the expected output. The sequence of operations to test the conditioning function is as follows:

1. Apply a software reset by setting CONTROL\_SOFTRESET to 1, then clearing it to 0.
2. Configure the CONTROL register. Important configuration options include:
  - Enable test mode by setting CONTROL\_TESTEN to 1.
  - Ensure the conditioning function is used by clearing CONTROL\_CONDBYPASS to 0.
3. Write the key into registers KEY0, KEY1, KEY2, and KEY3.
4. Write the 512 bits of known data to TESTDATA 32 bits at a time, polling for STATUS\_TESTDATABUSY = 0 after each write.
5. Read the 128-bit result from the FIFO 32 bits at a time.

[Table 30.1 Known-Answer Test for Conditioning Function on page 1068](#) shows an example with a given key, known data input, and expected output (taken from section F.2.1 in <http://csrc.nist.gov/publications/nistpubs/800-38a/sp800-38a.pdf>).

**Table 30.1. Known-Answer Test for Conditioning Function**

	128-bit Format	32-bit Bus Format
Key	0x2B7E151628AED2A6ABF7158809CF4F3C	0x16157E2B 0xA6D2AE28 0x8815F7AB 0x3C4FCF09
Input	0x6BC0BCE12A459991E134741A7F9E1925  0xAE2D8A571E03AC9C9EB76FAC45AF8E51  0x30C81C46A35CE411E5FBC1191A0A52EF  0xF69F2445DF4F9B17AD2B417BE66C3710	0xE1BCC06B 0x9199452A 0x1A7434E1 0x25199E7F 0x578A2DAE 0x9CAC031E 0xAC6FB79E 0x518EAF45 0x461CC830 0x11E45CA3 0x19C1FBE5 0xEF520A1A 0x45249FF6 0x179B4FDF 0x7B412BAD 0x10376CE6
Expected output	0x3FF1CAA1681FAC09120ECA307586E1A7	0xA1CAF13F 0x09AC1F68 0x30CA0E12 0xA7E18675

### 30.3.4.2 Checking the Entropy Source

The entropy source may be checked using the three built in test sources: repetition count, 64-sample adaptive proportion, and 4096-sample adaptive proportion. The entropy source may be tested using the following sequence:

1. Apply a software reset by setting CONTROL\_SOFTRESET to 1, then clearing it to 0.
2. Configure the CONTROL register. Important configuration options include:
  - Disable test mode by clearing CONTROL\_TESTEN to 0.
  - Bypass the conditioning function by setting CONTROL\_CONDBYPASS to 1.
  - Enable the TRNG by setting CONTROL\_ENABLE to 1.
3. Check the FIFOLEVEL register to monitor the amount of generated random numbers or wait for the STATUS\_FULLIF flag to set, indicating the FIFO is full. Note that STATUS\_FULLIF may be configured to generate an interrupt if desired.
4. When FIFOLEVEL has reached the expected value or when STATUS\_FULLIF is set, read the random numbers using the FIFO register. Those values can be discarded.
5. Continue reading and discarding the random data until at least  $4097 \times 2$  bits ( $257 \times 32$ -bit words) have been read. This ensures that enough time has passed for the longest test to run.
6. Check the STATUS register for error flags.

### 30.3.4.3 Programming a Random Key

1. Check the FIFOLEVEL register to monitor the amount of generated random numbers or wait for the STATUS\_FULLIF flag to set, indicating the FIFO is full. Note that STATUS\_FULLIF may be configured to generate an interrupt if desired.
2. When FIFOLEVEL has reached the expected value or when STATUS\_FULLIF is set, read the random numbers using the FIFO register.
3. Use four 32-bit random values to program a random key to the KEY0, KEY1, KEY2, and KEY3 registers.
4. Apply a software reset by setting CONTROL\_SOFTRESET to 1, then clearing it to 0. This will flush the FIFO data.

### 30.3.4.4 Reading Samples

1. Check the FIFOLEVEL register to monitor the amount of generated random numbers or wait for the STATUS\_FULLIF flag to set, indicating the FIFO is full. Note that STATUS\_FULLIF may be configured to generate an interrupt if desired.
2. When FIFOLEVEL has reached the expected value or when STATUS\_FULLIF is set, read the random numbers using the FIFO register.

## 30.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	TRNGn_CONTROL	RW	Main Control Register
0x004	TRNGn_FIFOLEVEL	R(a)	FIFO Level Register
0x00C	TRNGn_FIFODEPTH	R	FIFO Depth Register
0x010	TRNGn_KEY0	RW	Key Register 0
0x014	TRNGn_KEY1	RW	Key Register 1
0x018	TRNGn_KEY2	RW	Key Register 2
0x01C	TRNGn_KEY3	RW	Key Register 3
0x020	TRNGn_TESTDATA	RW	Test Data Register
0x030	TRNGn_STATUS	RWH	Status Register
0x034	TRNGn_INITWAITVAL	RW	Initial Wait Counter
0x100	TRNGn_FIFO	R(a)	FIFO Data

## 30.5 Register Description

### 30.5.1 TRNGn\_CONTROL - Main Control Register

Offset	Bit Position																			
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14		
Access																				
Name	BYPAIS31	RW	0	13	BYPNIST	RW	0	12	FORCERUN	RW	0	11	ALMIEN	RW	0	10	PREIEN	RW	0	9
	SOFTRESET	RW	0	8	FULLIEN	RW	0	7	APT4096IEN	RW	0	6	APT64IEN	RW	0	5	REPCOUNTIEN	RW	0	4
					CONDBYPASS	RW	0	3	TESTEN	RW	0	2					ENABLE	RW	0	0

Bit	Name	Reset	Access	Description									
31:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>									
13	BYPAIS31	0	RW	<b>AIS31 Start-up Test Bypass.</b> Bypass for AIS31 startup test.									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NORMAL</td><td>AIS31 startup test is applied. No data will be written to the FIFO until the test passes.</td></tr> <tr> <td>1</td><td>BYPASS</td><td>AIS31 startup test is bypassed.</td></tr> </tbody> </table>	Value	Mode	Description	0	NORMAL	AIS31 startup test is applied. No data will be written to the FIFO until the test passes.	1	BYPASS	AIS31 startup test is bypassed.
Value	Mode	Description											
0	NORMAL	AIS31 startup test is applied. No data will be written to the FIFO until the test passes.											
1	BYPASS	AIS31 startup test is bypassed.											
12	BYPNIST	0	RW	<b>NIST Start-up Test Bypass.</b> Bypass for NIST-800-90B startup test.									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NORMAL</td><td>NIST-800-90B startup test is applied. No data will be written to the FIFO until the test passes.</td></tr> <tr> <td>1</td><td>BYPASS</td><td>NIST-800-90B startup test is bypassed.</td></tr> </tbody> </table>	Value	Mode	Description	0	NORMAL	NIST-800-90B startup test is applied. No data will be written to the FIFO until the test passes.	1	BYPASS	NIST-800-90B startup test is bypassed.
Value	Mode	Description											
0	NORMAL	NIST-800-90B startup test is applied. No data will be written to the FIFO until the test passes.											
1	BYPASS	NIST-800-90B startup test is bypassed.											
11	FORCERUN	0	RW	<b>Oscillator Force Run</b> Set this bit to force oscillators to run even when FIFO is full.									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>NORMAL</td><td>Oscillators will shut down when FIFO is full</td></tr> <tr> <td>1</td><td>RUN</td><td>Oscillators will continue to run even after FIFO is full</td></tr> </tbody> </table>	Value	Mode	Description	0	NORMAL	Oscillators will shut down when FIFO is full	1	RUN	Oscillators will continue to run even after FIFO is full
Value	Mode	Description											
0	NORMAL	Oscillators will shut down when FIFO is full											
1	RUN	Oscillators will continue to run even after FIFO is full											
10	ALMIEN	0	RW	<b>Interrupt enable for AIS31 noise alarm</b> Enable/disable AIS31 noise alarm interrupt.									
9	PREIEN	0	RW	<b>Interrupt enable for AIS31 preliminary noise alarm</b> Enable/disable AIS31 preliminary noise alarm interrupt.									
8	SOFTRESET	0	RW	<b>Software Reset</b> Set to reset the module. This bit is not cleared automatically.									

Bit	Name	Reset	Access	Description
	Value	Mode		Description
0		NORMAL		Module not in reset
1		RESET		The continuous test, the conditioning function and the FIFO are reset
7	FULLIEN	0	RW	<b>Interrupt Enable for FIFO Full</b>
				Enable/Disable FIFO full interrupt.
6	APT4096IEN	0	RW	<b>Interrupt Enable for Adaptive Proportion Test Failure (4096-sample Window)</b>
				Enable/Disable 4096-sample Adaptive Proportion test failure interrupt.
5	APT64IEN	0	RW	<b>Interrupt Enable for Adaptive Proportion Test Failure (64-sample Window)</b>
				Enable/Disable 64-sample Adaptive Proportion test failure interrupt.
4	REPCOUNTIEN	0	RW	<b>Interrupt Enable for Repetition Count Test Failure</b>
				Enable/Disable Repetition Count Test failure interrupt.
3	CONDBYPASS	0	RW	<b>Conditioning Bypass</b>
				Enables bypassing of the conditioning function (to observe entropy source directly).
	Value	Mode		Description
0		NORMAL		The conditionig function is used
1		BYPASS		The conditioning function is bypassed
2	TESTEN	0	RW	<b>Test Enable</b>
				Selects the input for the conditioning function and continuous tests.
	Value	Mode		Description
0		NOISE		Non-determinisitic random number generation
1		TESTDATA		Pseudo-random number generation
1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	ENABLE	0	RW	<b>TRNG Module Enable</b>
				Enable the TRNG. The module will generate random numbers unless the FIFO is full.
	Value	Mode		Description
0		DISABLED		Module disabled
1		ENABLED		Module enabled

**30.5.2 TRNGn\_FIFOLEVEL - FIFO Level Register (Actionable Reads)**

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	VALUE																															
Bit	Name	Reset	Access	Description																												
31:0	VALUE	0x00000000	R	<b>FIFO Level</b>																												
		Number of 32-bit words of random data available in the FIFO. The STATUS_FULLIF flag is cleared when FIFOLEVEL is read.																														

**30.5.3 TRNGn\_FIFODEPTH - FIFO Depth Register**

Offset	Bit Position																																
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000040																																
Access	R																																
Name	VALUE																																
Bit	Name	Reset	Access	Description																													
31:0	VALUE	0x00000040	R	<b>FIFO Depth.</b>																													
		Maximum number of 32-bit words that can be stored in the FIFO.																															

#### 30.5.4 TRNGn\_KEY0 - Key Register 0

### **30.5.5 TRNGn\_KEY1 - Key Register 1**

**30.5.6 TRNGn\_KEY2 - Key Register 2**

Offset	Bit Position																																
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	VALUE																																

Bit	Name	Reset	Access	Description
31:0	VALUE	0x00000000	RW	<b>Key 2</b>  AES Key 32-bit sub-word 2.

**30.5.7 TRNGn\_KEY3 - Key Register 3**

Offset	Bit Position																																
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0x00000000																																
Access	RW																																
Name	VALUE																																

Bit	Name	Reset	Access	Description
31:0	VALUE	0x00000000	RW	<b>Key 3</b>  AES Key 32-bit sub-word 3 (LSB).

## 30.5.8 TRNGn\_TESTDATA - Test Data Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	VALUE																															

Bit	Name	Reset	Access	Description
31:0	VALUE	0x00000000	RW	<b>Test data input to conditioning function or to the continuous tests</b>  Each word written to this register represents 32 bits of input data for the selected test in test mode (CONTROL_TESTEN = 1). TESTDATABUSY in the STATUS register will be set to 1 each time data is written, and will clear to 0 when the next data word can be written. Writes to this register are ignored if the TESTEN bit in the CONTROL register is 0.

## 30.5.9 TRNGn\_STATUS - Status Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0		
Access																										R	0	0	0	0		
Name																										ALMIF	PREIF	FULLIF	APT4096IF	APT64IF	REPCOUNTIF	TESTDATABUSY

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	ALMIF	0	R	<b>AIS31 Noise Alarm interrupt status</b>  Set when a noise alarm is detected in the AIS31 online test.
8	PREIF	0	RWH	<b>AIS31 Preliminary Noise Alarm interrupt status</b>  Set when a preliminary noise alarm is detected in the AIS31 online test.
7	FULLIF	0	R	<b>FIFO Full Interrupt Status</b>  Set when the FIFO is full. The STATUS_FULLIF flag is cleared by reading FIFOLEVEL.
6	APT4096IF	0	R	<b>Adaptive Proportion test failure (4096-sample window) interrupt status</b>  Set when an Adaptive Proportion test (4096-sample window) failure occurs.
5	APT64IF	0	R	<b>Adaptive Proportion test failure (64-sample window) interrupt status</b>  Set when an Adaptive Proportion test (64-sample window) failure occurs.
4	REPCOUNTIF	0	R	<b>Repetition Count Test Interrupt Status</b>  Set when a Repetition Count Test failure occurs.
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	TESTDATABUSY	0	R	<b>Test Data Busy</b>  Indicates that data written to TESTDATA is being processed.
Value	Mode	Description		
0	IDLE	TESTDATA write is finished processing or no test in progress.		
1	BUSY	TESTDATA write is still being processed.		

## 30.5.10 TRNGn\_INITWAITVAL - Initial Wait Counter

Offset	Bit Position																																
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0xFF		
Access																																RW	
Name																																	VALUE



Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	VALUE	0xFF	RW	<b>Wait counter value</b>  Number of clock cycles to wait before sampling data from the noise source.

## 30.5.11 TRNGn\_FIFO - FIFO Data (Actionable Reads)

Offset	Bit Position																																
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0x00000000	
Access																																R	
Name																																	VALUE

Bit	Name	Reset	Access	Description
31:0	VALUE	0x00000000	R	<b>FIFO Read Data</b>  Data may be read from the FIFO 32 bits at a time using this register.

## 31. CRYPTO - Crypto Accelerator



### Quick Facts

#### What?

A fast and energy efficient autonomous hardware accelerator for AES encryption and decryption with 128- or 256-bit keys, ECC over prime and binary Galois finite fields, SHA-1, SHA-224 and SHA-256.

#### Why?

Efficient cryptography with little or no CPU intervention helps to meet the speed and energy demands of the application. Hardware implementations are generally more secure against side-channel attacks than software implementations.

#### How?

Programmable sequences of instructions on big numbers allow fast processing with little CPU intervention.

### 31.1 Introduction

The CRYPTO module allows efficient acceleration of common cryptographic operations and allows these to be used efficiently with a low CPU load. Operations performed by CRYPTO can be set up as a sequence of instructions on a set of 128-bit, 256-bit or 512-bit registers to implement or accelerate Elliptic Curve Cryptography (ECC), SHA-1, SHA-224, SHA-256, and various block cipher modes based on the Advanced Encryption Standard, also known as AES (FIPS-197).

CRYPTO is capable of autonomously fetching data, performing cipher operations and storing data across multiple blocks. When the source data is not a multiple of 16 bytes (128 bits), Zero-padding can be included in the last block. Block operations such as Counter Mode (CTR), Electronic Code Book (ECB), Cipher Block Chaining (CBC), Cipher Feedback (CFB) and Output Feedback (OFB) are easily implemented. Block Cipher modes of operation such as Electronic Code Book (ECB), Counter Mode (CTR), Cipher Block Chaining (CBC), CBC-MAC (CBC Message Authentication Code), CCM (Counter with CBC-MAC) and GCM (Galois Counter mode) are easily implemented.

CRYPTO is delivered with an extensive software library in Simplicity Studio that implements all major cryptographic algorithms, including but not limited to AES, SHA-1, SHA-2, ECC, and legacy algorithms DES, 3DES, MD4, MD5 and RC4. The implementation accelerates the algorithms using CRYPTO when possible.

### 31.2 Features

- Efficient AES core
  - Encryption/decryption using 128-bit key (54 clock cycles) or 256-bit key (75 clock cycles)
  - Key buffer
  - Supports autonomous cipher block modes (e.g. ECB, CTR, CBC, PCBC, CFB, CBC-MAC, GMAC, CCM, CCM\* and GCM) across multiple blocks
- Accelerated SHA-1, SHA-224 and SHA-256
- Accelerated Elliptic Curve Cryptography (ECC)
  - Binary and Prime fields
  - Supports NIST recommended curves: P-192, P-224, P-256, K-163, K-233, B-163, and B-233
- Galois/Counter Mode (GCM)
  - ALU operations on GCM GF(2<sup>128</sup>) field
- Flexible 256-bit ALU and sequencer
  - 5 general purpose 256-bit registers
  - Supports ADD, SUB, MUL, shift, XOR, etc.
  - Up to 20 instructions can be chained to implement various block cipher modes
- Efficient operation
  - DMA request signals for data read and write
  - Optional XOR Data write
  - Interrupt on finished operations
- Extensive software support
  - Extensive software library in Simplicity Studio
  - Implements all major cryptographic algorithms: AES, SHA-1, SHA-2, and ECC
  - Implements legacy algorithms: DES, 3DES, MD4, MD5, and RC4
  - Hardware accelerated when possible


### 31.3 Usage and Programming Interface

Many security systems fail due to mistakes in the implementation. Therefore implementations should be left to experts in cryptographic algorithms.

To solve this, the module is supported by an hardened cryptography software library and API delivered through Silicon Labs' Simplicity Studio. The software API is a frontend for performing all supported cryptographic operations, and must be used to receive prompt support.

### 31.4 Functional Description

A block diagram of the CRYPTO module is shown in [Figure 31.1 CRYPTO Overview on page 1080](#).



**Figure 31.1. CRYPTO Overview**

### 31.4.1 Data and Key Registers

The CRYPTO module contains five 256-bit registers. Accelerators are implemented through instructions operating on these registers, either by copying data between registers and external components through DMA, or by executing instructions on the registers.

Depending on the instruction, the registers can be accessed as 128-bit, 256-bit or 512-bit registers. The registers can also be accessed through different interface registers to achieve different results.

When writing to and reading from the CRYPTO\_DATAx, CRYPTO\_KEY, CRYPTO\_KEYBUF, CRYPTO\_DDATAx and CRYPTO\_QDATAx registers, the least significant part is accessed first and the most significant part last, see [Figure 31.2 CRYPTO Data and Key Register Operation on page 1082](#). The same is the case for the XOR and byte-access registers for DATA0 and DATA1. It is important to note that some of the 256-bit registers are composed of the 128-bit registers, and both the 512-bit registers are composed of the 256-bit registers.

**Note:** From here on, the 128, 256 and 512-bit registers are named DATAx, DDATAx, QDATAx, etc, And the access-points to these registers are named CRYPTO\_DATAx, CRYPTO\_DDATAx, CRYPTO\_QDATAx, etc.

DATA0 can be accessed through CRYPTO\_DATA0 (32-bit), CRYPTO\_DATA0XOR (32-bit), CRYPTO\_DATA0BYTE (8-bit) and CRYPTO\_DATA0XORBYTE (8-bit). Direct access to bytes 12 - 15 is available through CRYPTO\_DATA0BYTE12-15 (8-bit). The DATA0XOR (in CRYPTO\_DATA0XOR) is used for XOR'ing a value with the current value in DATA0. This is used in a large variety of block cipher modes. All of these registers operate on DATA0.

DATA1 can be accessed through CRYPTO\_DATA1 (32-bit) and CRYPTO\_DATA1BYTE (8-bit).


The remaining data registers have regular 32-bit access through their respective registers. Note that all data registers require a full read or write to be fully accessed. This means that the 128-bit registers need four 32-bit reads/writes, the 256-bit registers need 8 reads/writes and the 512-bit registers need 16 reads/writes. For a read, if all read accesses are not done, the register will end up as a shifted version of the original value.

**Note:** For byte-wise data accesses (DDATAxBYTE, DATAxBYTE, etc.), all reads and writes must be performed in groups of 4, due to internal buffering and shifting of 32 bits at a time. Accessing a number of bytes that is not a multiple of four can cause data incoherency in all of the data registers.

The KEY and KEYBUF registers are 256 bit wide when AES256 is set in CRYPTO\_CTRL. Else they are 128 bit wide. When used as a part of DDATAx and QDATAx, they are always 256 bit wide.

The registers DDATA0BIG and QDATA1BIG produce byte-swapped versions of DDATA0 and QDATA1 respectively. These may be used when a computation requires byte-swapping. An example of this is SHA computation, where data needs to be changed to big endian before CRYPTO can work with it. Little endian data is then loaded in through QDATA1BIG and the resulting little endian hash can be read out from DDATA0BIG, see [31.4.5 SHA](#).

Except for KEYBUF, the contents of all data registers are lost when going to EM2.

**Figure 31.2. CRYPTO Data and Key Register Operation**

### 31.4.1.1 DATA0 Zero

DATA0ZERO in CRYPTO\_DSTATUS contains status flags indicating if any 32-bit blocks within DATA0 is 0. For example, if DATA0[95:64] is equal to 0x00000000, ZERO64TO95 is set.

### 31.4.1.2 DDATA0 and DDATA1 Quick Observation

DDATA0LSBS in CRYPTO\_DSTATUS shows the 4 least significant bits in DDATA0. DDATA0MSBS in CRYPTO\_DSTATUS shows the 4 most significant bits of DDATA0, while DDATA1MSB in CRYPTO\_DSTATUS shows the msb of DDATA1. These observation bitfields are useful for determining the sign of the value in the data registers without having to read out the full register data register values

The 4 bits observed by DDATA0MSBS will change depending on RESULTWIDTH in CRYPTO\_WAC. When using 260-bit results, DDATA0MSBS shows bits 259-256, when using 256-bit results, it is bits 255-252, and for 128-bit results, bits 127-124 can be observed. When RESULTWIDTH is 260 bits, the 4 most significant bits, e.g. bits 259-256 are also available in CRYPTO\_DDATA0BYTE32, where they can also be written. Using this register is the only way of inputting the upper 4 bits of a 260-bit number to CRYPTO.

### 31.4.1.3 Result Width

RESULTWIDTH in CRYPTO\_WAC determines the width of the operation when performing arithmeticshift instructions with CRYPTO. Using less wide results will reduce the current consumption of the CRYPTO module. The higher-order bits that are beyond the selected result width are ignored in the computation of arithmeticshift operations, however, these higher-order bits will be undefined in the result of such instructions.

When RESULTWIDTH=260BIT, all DDATA registers effectively become 260 bits wide, so that the upper 4 bits are not lost when transferring data from DDATA0 to the other DDATA registers. Likewise, the arithmeticshift instructions shall consider the full 260-bit values of DDATA0-DDATA4 when used as operation inputs. Note that DDATA0 is the only 260-bit register of which MSBs can be observed/written. The upper 4 bits are observed through DDATA0MSBS in CRYPTO\_DSTATUS or through CRYPTO\_DDATA0BYTE32. For all DDATAx registers, the extra MSBs are cleared when DDATAx is written. Furthermore, for a particular x, a write to DDATAx or any of its aliased registers will cause DDATAx MSBs to be cleared. Note, writing to KEY/KEYBUF will only clear MSBs of DDATA1/DDATA4 when AES256 mode is set. Likewise, writing to DATA0/DATA2 will not clear DDATA2/DDATA3 MSBs.

Since the DATA0-DATA3 registers are always 128-bit, all bit positions greater than 128 are interpreted as 0 when RESULTWIDTH is greater than 128 bits. However, the assignment instructions DATAxTODDATAy will not zero-out the upper 128 bits of the DDATAy target. Instead, those upper words become undefined after such operations.

## 31.4.2 Instructions and Execution

The CRYPTO module implements a set of instructions in order to load and manipulate data effectively. These instructions are grouped into four types:

- ALU instructions - arithmetic and logical bitwise operations
- Transfer instructions - moving data between registers and external peripherals like DMA
- Conditional instructions - conditionally execute instructions based on context
- Special instructions - various crypto and support instructions

A single instruction can be executed by writing INSTR in CRYPTO\_CMD. This will execute the instruction, and the interface of CRYPTO will be locked until the execution has completed. Multiple commands can safely be issued after each other by the CPU as long as NOBUSYSTALL in CRYPTO\_CTRL is not set. If CRYPTO gets a new command or a data access request while busy it will then stall the bus, and execute the new command as soon as it is done with the previous one. Note, there are some exceptions to this rule. For example, see [31.4.8 DMA](#).

Stalling of the bus can be disabled by setting NOBUSYSTALL in CRYPTO\_CTRL, however manipulating (reading or writing) registers while running an instruction will result in undefined behaviour. Additionally, if NOBUSYSTALL=0 and a new command or data access request is made while the CRYPTO is simultaneously performing a data transfer instruction, it is possible for system lockup due to bus stalling loops. The safest approach is to always check if an instruction is running by looking at INSTRRUNNING in CRYPTO\_STATUS.

Note that this automatic stalling feature does not apply to automated CRYPTO instruction sequences (described next), since there may be cycle delays between individual instructions for which bus accesses are not prevented. For sequences, always check the SEQRUNNING status bit or the SEQDONE interrupt flag to ensure the sequence is finished before attempting CRYPTO register accesses.

### 31.4.2.1 Sequences

For executing a set of instructions, it is more efficient to load them into the CRYPTO module and run them as a sequence. This is done by writing the instructions into CRYPTO\_SEQ0-CRYPTO\_SEQ4, and marking the end of the instruction sequence with either an END or an EXEC instruction. The END simply means end-of-instructions, while writing EXEC means end-of-instructions and execute immediately.

The five registers allow up to 20 instructions to be loaded. To start execution, either end the instructions with an EXEC instruction, or set SEQSTART in CRYPTO\_CMD. CRYPTO will then execute the instructions, starting in CRYPTO\_SEQ0, and ending at the first END instruction. SEQRUNNING in CRYPTO\_STATUS is set while the sequence is running, and the interrupt flag SEQDONE in CRYPTO\_IF will be set when the sequence has completed.

A sequence can be stopped by issuing the SEQSTOP command in the CRYPTO\_CMD register. This command also clears the state of ongoing CRYPTO instructions including DMA access. Check SEQRUNNING in CRYPTO\_STATUS after issuing the SEQSTOP command flag to make sure any ongoing sequence/transfer has completed before accessing data registers again.

### 31.4.2.2 Available Instructions

The available ALU instructions are listed in [Table 31.1 ALU Instructions on page 1085](#), long instructions are listed in [Table 31.2 Long Instructions on page 1086](#), data transfer instructions are listed in [Table 31.3 Transfer Instructions on page 1086](#), conditional instructions are listed in [Table 31.4 Conditional Instructions on page 1087](#) and special instructions are listed in [Table 31.5 Special Instructions on page 1087](#). The tables explains the side-effects of the instructions and shows which registers are affected. V0 and V1 in the instructions descriptions can be any of the DDATAx registers and a selection of the DATAx registers. They can be selected using the SELDDATAxDDATAy, SELDATAxDDATAy, SELDDATAxDATAy and SELDATAxDATAy instructions. The first register in the instruction will be selected for V0, and the second for V1. This configuration stays even when the sequence is complete, and can also be set up front. The currently selected V0 and V1 can be read V0 and V1 in CRYPTO\_CSTATUS.

**Table 31.1. ALU Instructions**

Instruction	Description	Constraints/Notes
ADD	DDATA0 = V0 + V1	If V0 != DDATA0, then V1 != DDATA0
ADDO	DDATA0 = V0 + V1	Carry is only set, not cleared. If V0 != DDATA0, then V1 != DDATA0
ADDC	DDATA0 = V0 + V1 + carry	If V0 != DDATA0, then V1 != DDATA0
ADDIC	DDATA0 = V0 + V1 + carry << 128	If V0 != DDATA0, then V1 != DDATA0. If resultwidth is 128b, then carry is undefined
MADD	DDATA0 = (V0 + V1) mod P	If V0 != DDATA0, then V1 != DDATA0
MADD32	DDATA0[i] = V0[i] + V1[i]. Word-wise addition	carry is not modified. If V0 != DDATA0, then V1 != DDATA0
SUB	DDATA0 = V0 - V1	V1 != DDATA0. If V1 is 128b and resultwidth > 128b, then upper 128b are unknown
SUBC	DDATA0 = V0 - V1 - carry	V1 != DDATA0. If V1 is 128b and resultwidth > 128b, then upper 128b are unknown
MSUB	DDATA0 = (V0 - V1) mod P	V1 != DDATA0. If V1 is 128b and resultwidth > 128b, then upper 128b are unknown
MUL	DDATA0 = DDATA1 * V1. See <a href="#">31.4.2.3 MULx Details</a>	V1 != DDATA0,DDATA1
MULC	DDATA0 = DDATA1 * V1 + (DDATA0 << MULWIDTH). See <a href="#">31.4.2.3 MULx Details</a>	V1 != DDATA0,DDATA1
MMUL	DDATA0 = (DDATA1 * V1) mod P	V1 != DDATA0,DDATA1
MULO	DDATA0 = DDATA1 * V1. See <a href="#">31.4.2.3 MULx Details</a>	V1 != DDATA0,DDATA1. Carry is only set, not cleared
SHL	DDATA0 = V0 << 1	If V0 is 128b and resultwidth is 260b, then upper 4b are unknown
SHLC	DDATA0 = V0 << 1   carry	If V0 is 128b and resultwidth is 260b, then upper 4b are unknown
SHLB	DDATA0 = V0 << 1   V0[resultwidth-1]	If V0 is 128b and resultwidth is 260b, then upper 4b are unknown
SHL1	DDATA0 = V0 << 1   1	If V0 is 128b and resultwidth is 260b, then upper 4b are unknown
SHR	DDATA0 = V0 >> 1	
SHRC	DDATA0 = V0 >> 1   carry << resultwidth-1	
SHRB	DDATA0 = V0 >> 1   V0[0] << resultwidth-1	

Instruction	Description	Constraints/Notes
SHR1	DDATA0 = V0 >> 1   1 << resultwidth-1	
SHRA	DDATA0 = V0 >> 1   V0[resultwidth-1] << resultwidth-1	
CLR	DDATA0 = 0	
XOR	DDATA0 = V0 ^ V1	If V0 != DDATA0, then V1 != DDATA0
INV	DDATA0 = ~V0	
CSET	CARRY = 1	
CCLR	CARRY = 0	
BBSWAP128	DDATA0[127:0] = bbswap(V0[127:0])	See 31.4.2.6 BBSWAP128 Instruction
INC	DDATA0 = DDATA0 + 1	
DEC	DDATA0 = DDATA0 - 1	

**Table 31.2. Long Instructions**

Instruction	Operation	Constraints/Notes
LADD	{DDATA1,DDATA0} = V0 + V1, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} + V1, if V0 = DDATA0	If V0 != DDATA0, then V1 != DDATA0
LADDO	{DDATA1,DDATA0} = V0 + V1, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} + V1, if V0 = DDATA0	Carry is only set, not cleared. If V0 != DDATA0, then V1 != DDATA0
LADDC	{DDATA1,DDATA0} = V0 + V1 + carry, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} + V1 + carry, if V0 = DDATA0	If V0 != DDATA0, then V1 != DDATA0
LADDIC	{DDATA1,DDATA0} = V0 + V1 + carry << 256, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} + V1 + carry << 256, if V0 = DDATA0	If V0 != DDATA0, then V1 != DDATA0
LSUB	{DDATA1,DDATA0} = V0 - V1, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} - V1, if V0 = DDATA0	V1 != DDATA0. If V1 is 128b, then upper 128b are unknown
LSUBC	{DDATA1,DDATA0} = V0 - V1 - carry, if V0 != DDATA0. {DDATA1,DDATA0} = {DDATA1,DDATA0} - V1 - carry, if V0 = DDATA0	V1 != DDATA0. If V1 is 128b, then upper 128b are unknown
LMUL	{DDATA1,DDATA0} = DDATA1 * V1	V1 != DDATA0, DDATA1
LMULO	{DDATA1,DDATA0} = DDATA1 * V1	V1 != DDATA0, DDATA1. Carry is only set, not cleared
LINC	{DDATA1,DDATA0} = {DDATA1,DDATA0} + 1	
LDEC	{DDATA1,DDATA0} = {DDATA1,DDATA0} - 1	

**Table 31.3. Transfer Instructions**

Instruction	Operation	Constraints/Notes
DATATODMA0	DMA = DATA0, DMA request DMA0RD	DATA0 = DATA0, DDATA0, DDATA0BIG, QDATA0 as defined by DMA0RSEL
DMA0TODATA	DATA0 = DMA, DMA request DATA0WR	DATA0 = DATA0, DDATA0, DDATA0BIG, QDATA0
DMA0TODATAXOR	DATA0 = DATA0 ^ DMA, DMA request DATAXORWR	

Instruction	Operation	Constraints/Notes
DATATODMA1	DMA = DATAx, DMA request DMA1RD	DATAx = DATA1, DDATA1, QDATA1, QDATA1BIG as defined by DMA1RSEL
DMA1TODATA	DATAx = DMA, DMA request DATA0WR	DATAx = DATA1, DDATA1, QDATA1, QDATA1BIG
DATAxTODATAy	DATAy = DATAx	
DATAxTODATA0XOR	DATA0 = DATA0 ^ DATAx	If resultwidth is 128b, then carry is undefined
DATAxTODATA0XOR-LEN	DATA0 = DATA0 ^ (DATAx & (2**LENGTH-1))	LENGTH is LENGTHA or LENGTHB depending on active part of sequence. If resultwidth is 128b, then carry is undefined
DDATAxTODDATAy	DDATAy = DDATAx	
DDATAxHTODATA1	DATA1 = DDATAx[255:128]	Bits DDATA2[259:256] become undefined
DDATAxLTODATAy	DATAy = DDATAx[127:0]	
SELDDATAxDDATAy	Use DDATAx as V0, DDATAy as V1	x = 0,1,2,3,4; y = 0,1,2,3,4
SELDDATAxDDATAy	Use DATAx as V0, DDATAy as V1	x = 0,1,2; y = 0,1,2,3,4
SELDDATAxDATAy	Use DDATAx as V0, DATAy as V1	x = 0,1,2,3,4; y = 0,1
SELDDATAxDATAy	Use DATAx as V0, DATAy as V1	x = 0,1,2; y = 0,1

**Table 31.4. Conditional Instructions**

Instruction	Operation	Constraints
EXECIFA	Execute following instructions if in part A of sequence	
EXECIFB	Execute following instructions if in part B of sequence	
EXECIFNLAST	Execute following instructions if not in last iteration of sequence	
EXECIFLAST	Execute following instructions if in last iteration of sequence	
EXECIFCARRY	Execute following instructions if carry bit is set	
EXECIFNCARRY	Execute following instructions if carry bit not is set	
EXECALWAYS	Always execute following instructions	

**Table 31.5. Special Instructions**

Instruction	Operation
END	Ends execution.
EXEC	When written to CRYPTO_SEQx register, automatically triggers execution of all instruction up to this point.
AESENC	DATA0 = AESENC(DATA0)
AESDEC	DATA0 = AESDEC(DATA0)
SHA	DDATA0 = SHA(Q1)
DATA1INC	DATA1 = inc(DATA1). See <a href="#">31.4.2.5 DATA1INC and DATA1INCCLR Instructions</a>
DATA1INCCLR	DATA1 = clearinc(DATA1). See <a href="#">31.4.2.5 DATA1INC and DATA1INCCLR Instructions</a>

### 31.4.2.3 MULx Details

For the MULx instructions (not MMUL), MULWIDTH in CRYPTO\_WAC specifies the width of operands DDATA1 (and sometimes V1). This is useful in order to optimize performance because multiplications take the same number of cycles as the bits in the operands plus a couple of cycles for setup.

As with the other ALU instructions, RESULTWIDTH limits the width of the final result of the MULx and MMUL instructions.

### 31.4.2.4 Long Instruction Details

For the Long instructions listed in [Table 31.2 Long Instructions on page 1086](#), RESULTWIDTH in CRYPTO\_WAC is ignored and is treated as if it were set to 512 bits. Likewise, MULWIDTH is also ignored and is treated as if it were set to 256 bits.

### 31.4.2.5 DATA1INC and DATA1INCCLR Instructions

DATA1INC and DATA1INCCLR operate on the 1, 2, 3 or 4 most significant bytes in DATA1, depending on INCWIDTH in CRYPTO\_CTRL. DATA1INC increments these bytes in big endian, while DATA1INCCLR clears the bytes.

### 31.4.2.6 BBSWAP128 Instruction

The BBSWAP128 instruction copies the contents of the V0 operand to DDATA0 while swapping the bits of the lower 16 bytes. The operand is not changed. This operation is required for GCM. See [31.4.7 GCM and GMAC](#)

### 31.4.2.7 Carry

The carry output from most instructions can be observed through the CARRY bit in CRYPTO\_DSTATUS. Shift-instructions set CARRY to the value that is shifted out of the register, addition and multiplication set it on register overflow, and subtraction sets it on borrow, e.g. underflow.

In addition to generating carry information, some instructions also use the current value of CARRY. ADDC, SUBC, SHLC and SHRC all use carry to generate the result. For all of these instructions, carry allows a program to chain instructions together to operate on bigger numbers than allowed by CRYPTO. For example, by chaining first an ADD, and then an ADDC which uses the carry from the ADD operation, two 512-bit numbers can be added. By chaining more instructions, even larger numbers can be manipulated.

Other uses of CARRY include observation. To check if a register is 0, one can subtract 1 using the DEC instruction, and check if goes negative by checking the CARRY bit. CARRY can be set manually and in CRYPTO programs using the CSET and CCLR instructions, which set and clear the CARRY bit.

The MULC instruction does not use CARRY like the other carry instructions (i.e., instructions ending in 'C' such as 'ADDC'), but rather preserves the old contents of the multiplication register.

## 31.4.3 Repeated Sequence

To maximize efficiency, it is desirable to be able to run a set of instructions over multiple blocks of data autonomously. To repeat a sequence over a larger set of data, set LENGTHA in CRYPTO\_SEQCTRL to the number of bytes in the set, and BLOCKSIZE to the size of the blocks in the set. The sequence will then be repeated N times, where N is LENGTHA / BLOCKSIZE if LENGTHA is a multiple of BLOCKSIZE, or ceiling( LENGTHA / BLOCKSIZE ) if not. In the latter case, data written by DMA will be zero-padded up to BLOCKSIZE if it is written to a register which has a size equal to BLOCKSIZE. One notable exception is when LENGTHA is 0. In this case the sequence will still execute once, but the block transfer instructions will not execute.


**Note:** If DMAxRSEL in CRYPTO\_CTRL selects a register that is smaller than the specified blocksize, DATATODMAX/DMAxTODATA instructions will not use the full blocksize, but will only transfer enough data to empty/fill the register once. For example, if BLOCKSIZE is set to 64B and DMA0RSEL=DDATA0, the instruction DATATODMA0 will only read 32B instead of 64B. The processing of LENGTHA/B will continue as if all 64B had been transferred.

A repeated sequence can also be made do slightly different operations on different parts of the data set. A sequence can be divided into two parts; part A, and part B. By configuring LENGTHA in CRYPTO\_SEQCTRL to the length of part A, and LENGTHB in CRYPTO\_SEQCTRLB to the length of part B, CRYPTO will first run iterations over part A, knowing it is A, and then part B, knowing it is part B. By using the conditional instructions listed in [Table 31.4 Conditional Instructions on page 1087](#), a program can execute different instructions depending on whether it is in part A or part B.

### 31.4.4 AES


The AES core operates on data in the 128-bit register DATA0 using either a 128-bit or 256-bit key from the KEY register. The key width is specified by AES256 in CRYPTO\_CTRL. AES operations are implemented as the AESENC and AESDEC instructions, for AES encryption and AES decryption respectively. An overview of the AES functionality is shown in [Figure 31.3 CRYPTO AES Overview on page 1089](#).

AES encryption and decryption enables various block cipher modes like ECB, CTR, CBC, PCBC, CFB, OFB, CBC-MAC, GMAC, CCM, CCM\*, and GCM.



**Figure 31.3. CRYPTO AES Overview**

The input data before encryption is called the PlainText and output from the encryption is called CipherText. For encryption, the key is called PlainKey. After encryption, the resulting key in the KEY registers is the CipherKey. This key must be loaded into the KEY registers prior to the decryption. After one decryption, the resulting key will be the PlainKey. The resulting PlainKey/CipherKey is only dependent on the value in the KEY registers before encryption/decryption. The resulting keys and data are shown in [Figure 31.4 CRYPTO Key and Data Definitions on page 1089](#).



**Figure 31.4. CRYPTO Key and Data Definitions**

The KEY is by default loaded from KEYBUF prior to each AESENC or AESDEC instruction. If the KEY is not to be overwritten, key buffering should be disabled (KEYBUFDIS in CRYPTO\_CTRL). Disabling key buffering also allows the use of key loading through DMA.

The data and key orientation in the CRYPTO registers are shown in [Figure 31.5 CRYPTO Data and Key Orientation as Defined in the Advanced Encryption Standard on page 1090](#).




Figure 31.5. CRYPTO Data and Key Orientation as Defined in the Advanced Encryption Standard

### 31.4.5 SHA

The CRYPTO SHA instruction implements SHA-1 with a 160-bit digest or SHA-2 with a 224-bit digest (SHA-224) or 256-bit digest (SHA-256). Depending on SHAMODE in CRYPTO\_CTRL, SHA-1, SHA-224 or SHA-256 will be run on the data in QDATA1, and the result will be put on DDATA0. The contents in QDATA1 will be destroyed in the process.

To run SHA on a dataset, it must first be pre-processed by appending a bit '1' to the message, then padding the data with '0' bits until the message length in bits modulo 512 is 448. Then append the length of the message before pre-processing as a 64-bit big-endian integer. This pre-processing is known as MD-strengthening, and must be done by software before processing with the CRYPTO module.

The pre-processed data can now be run through the CRYPTO module. Begin by writing the values listed in [Table 31.6 SHA Init Values on page 1091](#) to CRYPTO\_DDATA1 from top to bottom, then execute the instructions listed in [Table 31.7 SHA Preparations on page 1091](#).

**Table 31.6. SHA Init Values**

SHA-1	SHA-224	SHA-256
0x67452301	0xC1059ED8	0x6A09E667
0xEFCDAB89	0x367CD507	0xBB67AE85
0x98BADCCE	0x3070DD17	0x3C6EF372
0x10325476	0xF70E5939	0xA54FF53A
0xC3D2E1F0	0xFFC00B31	0x510E527F
0x00000000	0x68581511	0x9B05688C
0x00000000	0x64F98FA7	0x1F83D9AB
0x00000000	0xBEFA4FA4	0x5BE0CD19

**Table 31.7. SHA Preparations**

STEP	ACTION	Description
STEP0	DDATA1TODDATA0	Copy init data to DDATA0
STEP1	SELDDATA0DDATA1	Select DDATA0 and DDATA1 as operands for SHA instruction

Then, for each 512-bit block, write the block to CRYPTO\_QDATA1BIG, execute the instructions listed in [Table 31.8 SHA for 512-bit Block on page 1091](#).

**Table 31.8. SHA for 512-bit Block**

STEP	ACTION	Description
STEP0	SHA	Perform SHA operation on data in QDATA1
STEP1	MADD32	Accumulate with previous data in DDATA1
STEP2	DDATA0TODDATA1	Copy hash to DDATA1

After the last iteration, the resulting hash can be read out from CRYPTO\_DDATA0BIG.

### 31.4.6 ECC

The CRYPTO module implements support for Elliptic Curve Cryptography through the modular instructions MADD, MMUL and MSUB, which perform modular addition, multiplication and subtraction respectively. The instructions can operate on a set of both prime fields GF(p) and binary fields GF(2^m).

The type of modular arithmetic used and the modulus for the modular operations are specified by MODOP and MODULUS in CRYPTO\_WAC respectively. Changing these in the middle of an operation leads to undefined behaviour.

### 31.4.7 GCM and GMAC

CRYPTO implements support for Galois/Counter Mode (GCM), and also Galois Message Authentication Code (GMAC), by providing AES instructions and allowing multiplication on the field GF(2<sup>128</sup>) defined by the polynomial  $x^{128} + x^7 + x^2 + x + 1$ .

**Note:** BBSWAP128 needs to be applied to both operands and the result of the MMUL instruction when using it for GCM and GMAC

Efficient sequencer programs can be set up to perform GCM authentication and encryption/decryption on data from either DMA, or CPU. To achieve a single-pass solution, LENGTHA in CRYPTO\_SEQCTRL is set to the length of the authentication part, and LENGTHB is set to the length of the rest of the message. Conditional instructions can then be used to make sure the two parts of the message are processed correctly. A similar approach is used to implement CCM.

### 31.4.8 DMA

The CRYPTO module has 5 DMA request signals (see [Table 31.9 DMA Signals on page 1092](#)) split over 2 internal DMA channels: DMA0 and DMA1. These DMA channels are not associated with channel 0 and 1 of the system DMA, and any system DMA channel can serve any of the 5 DMA requests. See the DMA chapter for information on how to configure the system DMA.

The DMA signals are set through the use of DMA oriented instructions, and cleared by reading or writing the respective CRYPTO data registers.

**Table 31.9. DMA Signals**

Name	Set on	Cleared on
DMA0WR	Instruction DMA0TODATA, and DMA0TODATAXOR if COMBDMA0WEREQ in CRYPTO_CTRL is set	Full CRYPTO_DATA0, CRYPTO_DDATA0, CRYPTO_DDATA0BIG or CRYPTO_QDATA0 write, or CRYPTO_DDATA0XOR if COMBDMA0WEDMAREQ in CRYPTO_CTRL is set
DMA0XORWR	Instruction DMA0TODATAXOR	Full CRYPTO_DATA0XOR write
DMA0RD	Instructions DATATODMA0	Full CRYPTO_DATA0, CRYPTO_DDATA0, CRYPTO_DDATA0BIG or CRYPTO_QDATA0 read, depending on DMA0MODE in CRYPTO_CTRL
DMA1WR	Instructions DMA1TODATA	Full CRYPTO_DATA1, CRYPTO_DDATA1, CRYPTO_QDATA1 or CRYPTO_QDATA1BIG write
DMA1RD	Instructions DATATODMA1	Full CRYPTO_DATA1, CRYPTO_DDATA1, CRYPTO_QDATA1 or CRYPTO_QDATA1BIG read, depending on DMA1MODE in CRYPTO_CTRL

**Note:** DMAxRSEL in CRYPTO\_CTRL has to be set to the data registers that are to be read using the respective DMA channels on a DATATODMAx instruction. As an important note, DMAxRSEL in CRYPTO\_CTRL selects what is read from **any** of the selectable read registers during an ongoing DATATODMAx transfer .

When a DMA oriented CRYPTO instruction is used (either through a STEP in a Sequence or through CRYPTO\_CMD), the corresponding DMA signal is set. The instruction is complete when the entire source/destination is read/written (e.g. if DMA0TODATA is used, the operation is complete when a total of 128 valid bits have been written through the CRYPTO\_DATA0 register). DMAACTIVE in CRYPTO\_STATUS is set while CRYPTO is working on a DMA-related instruction, e.g. waiting for the DMA to read or write data to CRYPTO (see [31.4.8.1 DMA Initial Bytes Skip](#)).

Normally, when a sequence or instruction is executed, access to most CRYPTO registers will stall the CPU or DMA that is trying to access CRYPTO until the operation is done, preventing accesses to CRYPTO that could potentially interfere with an operation. During DMA operations, all non-DMA registers are writeable and readable, but progress through the DMA operation will only be tracked with the registers targeted by the DMA operation (i.e., if the DMA operation is supposed to transfer 3 words to DATA0, the DMA can first choose to transfer data to e.g. DATA3, and then fulfill the transfer to DATA0).

Because the bus interface to CRYPTO is normally locked outside of DMA transfers, a wrongly set up DMA transfer (e.g., transferring one byte too many) may lock up the interface.. One way to assist in debugging such issues can be setting NOBUSYSTALL in CRYPTO\_CTRL. This will prevent any stall on CRYPTO register accesses during sequences and instructions. Use this option with care, as modifying a register that is being used by CRYPTO can lead to undefined behavior.

### 31.4.8.1 DMA Initial Bytes Skip

The DMA must be configured to use 32-bit transfer size. This normally would imply that the source data must be aligned to a 4 byte address boundary. However, it is possible to skip the initial bytes (1 to 3) when using DMA to write to DATA0 or DATA1 through a CRYPTO instruction operation. The number of bytes to skip are set in DMA0SKIP and DMA1SKIP in CRYPTO\_SEQCTRL. This implies that if DMA0SKIP is set to another value than 0, the initial DMA access will require 5 DMA transfers, even though only 4x32-bit is required.

**Note:** Any valid unused bytes from a previous DMA write will be used before new DMA data is requested. This data is invalidated by using STOP in CRYPTO\_CMD.

### 31.4.8.2 DMA Unaligned Read/Write

Except for DATA0 and DATA1, which can be loaded bytewise using the CRYPTO\_DATA0BYTE, CRYPTO\_DATA0XORBYTE and CRYPTO\_DATA1BYTE registers, the CRYPTO data registers are loaded 32-bits at a time. Special care must be taken when using the DMA and the data buffer is not aligned to a 32-bit address, because the DMA does not directly support 32-bit unaligned accesses.

As an example, let an in-memory 16-byte data buffer start at address  $4*N + M$  and end at the byte before.  $4*N + 16 + M$ , where  $M$  is between 0 and 3 inclusive. With an  $M=0$ , we have fully aligned accesses, and everything is fine. For  $M>0$  however, the access is unaligned. If  $M=1$ , that means that the first 32-bit aligned word of the memory buffer contains 1 byte before the buffer, and 3 bytes of the buffer. Similarly, the last 32-bit aligned word of the memory buffer contains the last byte of the buffer, and three bytes after the buffer.

When doing an unaligned read, we want to only pass the 16 bytes of the buffer to the CRYPTO module. Not the  $N$  bytes before in the 32-bit aligned word, and not the  $4-N$  words at the end. To achieve this, set DxDMAREADMODE in CRYPTO\_CTRL to either UNALIGNEDFULL or UNALIGNEDLENLIMIT, and set DATAxDMASKIP in CRYPTO\_SEQCTRL equal to  $N$ . When reading in data using a DMA-oriented instruction to DATAx, DDATAx or QDATAx, the read will now only contain the 16 bytes, and not the  $N$  bytes before or  $4-N$  words after. Note that in this case, the DMA has to be set up to transfer 5 32-bit words instead of the effective 4.

Being able to read unaligned data does not solve all cases however. If data is to be written back to the buffer after passing through CRYPTO, e.g. when doing an in-place encryption or decryption, it is very undesirable to actually modify the  $N$  bytes before and  $4-N$  bytes after the buffer. This is solved using the UAR-suffixed registers in CRYPTO when reading data out from the CRYPTO module, e.g. CRYPTO\_DATA0UAR, CRYPTO\_DATA1UAR, CRYPTO\_DDATA0UAR, CRYPTO\_DDATA1UAR, CRYPTO\_QDATA0UAR, etc. When an unaligned buffer is written to a CRYPTO buffer, CRYPTO stores the  $N$  first bytes and the  $4-N$  last bytes internally. When reading out from an UAR register, these bytes are placed back into the data if DATAxDMApres is set in CRYPTO\_SEQCTRL.

Note that the latter case only works if the first  $N$  and the last  $4-N$  bytes are not changed while CRYPTO works on the data. Internally CRYPTO has 2 buffers for the bytes before and after. The first one is connected to read/write of the DATA0, DDATA0 and QDATA0 registers, and the second is connected to the DATA1, DDATA1 and QDATA1 registers.

If DATAxRMODE in CRYPTO\_CTRL is set to FULL or UNALIGNEDFULL and the corresponding DATAxPRES in CRYPTO\_SEQCTRL is set, then a whole number of data buffers have to be written by the DMA. In all other cases, it is enough to write the number of 32-bit words to pass all LENGTH bits to the target CRYPTO buffer.

### 31.4.9 Debugging

There are multiple ways of debugging CRYPTO sequences. The most straight-forward way is to write individual instructions to INSTR in CRYPTO\_CMD. An instruction can be written, and data can be read out and examined before running another instruction.

Running individual instructions to debug a program falls short when working with repeated sequences. In these cases, a sequence is run multiple times over a set of data. This cannot be directly replicated with individual instructions.

To debug a sequence, set HALT in CRYPTO\_SEQCTRL. When set, CRYPTO requires software or the debugger to step it through each instruction in the sequence. To step through the sequence, set SEQSTEP in CRYPTO\_CMD. This will execute the current instruction, and make CRYPTO ready to execute the next one.

When stepping through a sequence, the current instruction index can be read from SEQIP in CRYPTO\_CSTATUS. SEQSKIP, also in CRYPTO\_CSTATUS tells whether the next instruction will be executed or not, based on previous conditionals in the program. SEQPART in CRYPTO\_CSTATUS shows whether CRYPTO is currently in part A or B of a sequence. Even with NOBUSYSTALL in CRYPTO\_CTRL cleared, read and write accesses to CRYPTO will be allowed when CRYPTO is waiting to be stepped. This is to allow data registers to be inspected during debugging.

**Note:** The data registers in CRYPTO (those marked read-actionable) require shifting of data in order to return the result. For this reason, reading these registers will have no effect and will return unknown values during normal debugger read accesses (see [5.3.6 Debugger Reads of Actionable Registers](#)).

### 31.5 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	CRYPTO_CTRL	RW	Control Register
0x004	CRYPTO_WAC	RW	Wide Arithmetic Configuration
0x008	CRYPTO_CMD	W	Command Register
0x010	CRYPTO_STATUS	R	Status Register
0x014	CRYPTO_DSTATUS	R	Data Status Register
0x018	CRYPTO_CSTATUS	R	Control Status Register
0x020	CRYPTO_KEY	RWH(nB)(a)	KEY Register Access
0x024	CRYPTO_KEYBUF	RWH(nB)(a)	KEY Buffer Register Access
0x030	CRYPTO_SEQCTRL	RWH	Sequence Control
0x034	CRYPTO_SEQCTRLB	RWH	Sequence Control B
0x040	CRYPTO_IF	R	AES Interrupt Flags
0x044	CRYPTO_IFS	W1	Interrupt Flag Set Register
0x048	CRYPTO_IFC	(R)W1	Interrupt Flag Clear Register
0x04C	CRYPTO_IEN	RW	Interrupt Enable Register
0x050	CRYPTO_SEQ0	RW	Sequence Register 0
0x054	CRYPTO_SEQ1	RW	Sequence Register 1
0x058	CRYPTO_SEQ2	RW	Sequence Register 2
0x05C	CRYPTO_SEQ3	RW	Sequence Register 3
0x060	CRYPTO_SEQ4	RW	Sequence Register 4
0x080	CRYPTO_DATA0	RWH(nB)(a)	DATA0 Register Access
0x084	CRYPTO_DATA1	RWH(nB)(a)	DATA1 Register Access
0x088	CRYPTO_DATA2	RWH(nB)(a)	DATA2 Register Access
0x08C	CRYPTO_DATA3	RWH(nB)(a)	DATA3 Register Access
0x0A0	CRYPTO_DATA0XOR	RWH(nB)(a)	DATA0XOR Register Access
0x0B0	CRYPTO_DATA0BYTE	RWH(nB)(a)	DATA0 Register Byte Access
0x0B4	CRYPTO_DATA1BYTE	RWH(nB)(a)	DATA1 Register Byte Access
0x0BC	CRYPTO_DATA0XORBYTE	RWH(nB)(a)	DATA0 Register Byte XOR Access
0x0C0	CRYPTO_DATA0BYTE12	RWH(nB)	DATA0 Register Byte 12 Access
0x0C4	CRYPTO_DATA0BYTE13	RWH(nB)	DATA0 Register Byte 13 Access
0x0C8	CRYPTO_DATA0BYTE14	RWH(nB)	DATA0 Register Byte 14 Access
0x0CC	CRYPTO_DATA0BYTE15	RWH(nB)	DATA0 Register Byte 15 Access
0x100	CRYPTO_DDATA0	RWH(nB)(a)	DDATA0 Register Access
0x104	CRYPTO_DDATA1	RWH(nB)(a)	DDATA1 Register Access
0x108	CRYPTO_DDATA2	RWH(nB)(a)	DDATA2 Register Access
0x10C	CRYPTO_DDATA3	RWH(nB)(a)	DDATA3 Register Access

Offset	Name	Type	Description
0x110	CRYPTO_DDATA4	RWH(nB)(a)	DDATA4 Register Access
0x130	CRYPTO_DDATA0BIG	RWH(nB)(a)	DDATA0 Register Big Endian Access
0x140	CRYPTO_DDATA0BYTE	RWH(nB)(a)	DDATA0 Register Byte Access
0x144	CRYPTO_DDATA1BYTE	RWH(nB)(a)	DDATA1 Register Byte Access
0x148	CRYPTO_DDATA0BYTE32	RWH(nB)	DDATA0 Register Byte 32 Access
0x180	CRYPTO_QDATA0	RWH(nB)(a)	QDATA0 Register Access
0x184	CRYPTO_QDATA1	RWH(nB)(a)	QDATA1 Register Access
0x1A4	CRYPTO_QDATA1BIG	RWH(nB)(a)	QDATA1 Register Big Endian Access
0x1C0	CRYPTO_QDATA0BYTE	RWH(nB)(a)	QDATA0 Register Byte Access
0x1C4	CRYPTO_QDATA1BYTE	RWH(nB)(a)	QDATA1 Register Byte Access

## 31.6 Register Description

### 31.6.1 CRYPTO\_CTRL - Control Register

Offset	Bit Position																																	
Reset	31	0	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Access	RW	RW	0x0	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	
Name	COMBDMA0WEREQ	DMA1RSEL	DMA1MODE	DMA0RSEL	DMA0MODE	INCWIDTH	NOBUSSTALL	SHA	KEYBUFDS	AES																								

Bit	Name	Reset	Access	Description
31	COMBDMA0WEREQ	0	RW	<b>Combined Data0 Write DMA Request</b>  When cleared, the DATA0WR and DATA0XORWR operate independently. When set, DATA0XORWR requests are also given through DATA0WR
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29:28	DMA1RSEL	0x0	RW	<b>DATA0 DMA Unaligned Read Register Select</b>  Specifies which read register is used for DMA1RD DMA requests (see related notes in <a href="#">31.4.8 DMA</a> and <a href="#">31.4.3 Repeated Sequence</a> )
	Value	Mode		Description
	0	DATA1		
	1	DDATA1		
	2	QDATA1		
	3	QDATA1BIG		
27:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25:24	DMA1MODE	0x0	RW	<b>DMA1 Read Mode</b>  This field determines how data is read when using DMA
	Value	Mode		Description
	0	FULL		Target register is fully read/written during every DMA transaction
	1	LENLIMIT		Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + 1 bytes + necessary zero padding is read. Zero padding is automatically added when writing.
	2	FULLBYTE		Target register is fully read/written during every DMA transaction. Byte-wise DMA.

Bit	Name	Reset	Access	Description															
3	LENLIMITBYTE			Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + 1 bytes + necessary zero padding is read. Bytewise DMA. Zero padding is automatically added when writing.															
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
21:20	DMA0RSEL	0x0	RW	<b>DMA0 Read Register Select</b>  Specifies which read register is used for DMA0RD DMA requests (see related notes in <a href="#">31.4.8 DMA</a> and <a href="#">31.4.3 Repeated Sequence</a> )															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>DATA0</td><td></td></tr> <tr> <td>1</td><td>DDATA0</td><td></td></tr> <tr> <td>2</td><td>DDATA0BIG</td><td></td></tr> <tr> <td>3</td><td>QDATA0</td><td></td></tr> </tbody> </table>	Value	Mode	Description	0	DATA0		1	DDATA0		2	DDATA0BIG		3	QDATA0	
Value	Mode	Description																	
0	DATA0																		
1	DDATA0																		
2	DDATA0BIG																		
3	QDATA0																		
19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
17:16	DMA0MODE	0x0	RW	<b>DMA0 Read Mode</b>  This field determines how data is read when using DMA.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>FULL</td><td>Target register is fully read/written during every DMA transaction</td></tr> <tr> <td>1</td><td>LENLIMIT</td><td>Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Zero padding is automatically added when writing.</td></tr> <tr> <td>2</td><td>FULLBYTE</td><td>Target register is fully read/written during every DMA transaction. Byte-wise DMA.</td></tr> <tr> <td>3</td><td>LENLIMITBYTE</td><td>Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Bytewise DMA. Zero padding is automatically added when writing.</td></tr> </tbody> </table>	Value	Mode	Description	0	FULL	Target register is fully read/written during every DMA transaction	1	LENLIMIT	Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Zero padding is automatically added when writing.	2	FULLBYTE	Target register is fully read/written during every DMA transaction. Byte-wise DMA.	3	LENLIMITBYTE	Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Bytewise DMA. Zero padding is automatically added when writing.
Value	Mode	Description																	
0	FULL	Target register is fully read/written during every DMA transaction																	
1	LENLIMIT	Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Zero padding is automatically added when writing.																	
2	FULLBYTE	Target register is fully read/written during every DMA transaction. Byte-wise DMA.																	
3	LENLIMITBYTE	Length Limited. When the current length, i.e. LENGTHA or LENGTHB indicates that there are less bytes available than the register size, only length + necessary zero padding is read. Bytewise DMA. Zero padding is automatically added when writing.																	
15:14	INCWIDTH	0x0	RW	<b>Increment Width</b>  This field determines the number of bytes used for the increment function in data1.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>INCWIDTH1</td><td>Byte 15 in DATA1 is used for the increment function.</td></tr> <tr> <td>1</td><td>INCWIDTH2</td><td>Bytes 14 and 15 in DATA1 are used for the increment function.</td></tr> <tr> <td>2</td><td>INCWIDTH3</td><td>Bytes 13 to 15 in DATA1 are used for the increment function.</td></tr> <tr> <td>3</td><td>INCWIDTH4</td><td>Bytes 12 to 15 in DATA1 are used for the increment function.</td></tr> </tbody> </table>	Value	Mode	Description	0	INCWIDTH1	Byte 15 in DATA1 is used for the increment function.	1	INCWIDTH2	Bytes 14 and 15 in DATA1 are used for the increment function.	2	INCWIDTH3	Bytes 13 to 15 in DATA1 are used for the increment function.	3	INCWIDTH4	Bytes 12 to 15 in DATA1 are used for the increment function.
Value	Mode	Description																	
0	INCWIDTH1	Byte 15 in DATA1 is used for the increment function.																	
1	INCWIDTH2	Bytes 14 and 15 in DATA1 are used for the increment function.																	
2	INCWIDTH3	Bytes 13 to 15 in DATA1 are used for the increment function.																	
3	INCWIDTH4	Bytes 12 to 15 in DATA1 are used for the increment function.																	
13:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
10	NOBUSYSTALL	0	RW	<b>No Stalling of Bus When Busy</b>  When set, bus accesses will not be stalled on access during an operation															

Bit	Name	Reset	Access	Description									
9:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>									
2	SHA	0	RW	<b>SHA Mode</b>  Select SHA-1 or SHA-2 mode.									
				<table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>SHA1</td><td>SHA-1 mode</td></tr><tr><td>1</td><td>SHA2</td><td>SHA-2 mode (SHA-224 or SHA-256)</td></tr></tbody></table>	Value	Mode	Description	0	SHA1	SHA-1 mode	1	SHA2	SHA-2 mode (SHA-224 or SHA-256)
Value	Mode	Description											
0	SHA1	SHA-1 mode											
1	SHA2	SHA-2 mode (SHA-224 or SHA-256)											
1	KEYBUFDIS	0	RW	<b>Key Buffer Disable</b>  Set to Disable key buffering.									
0	AES	0	RW	<b>AES Mode</b>  Select AES mode									
				<table border="1"><thead><tr><th>Value</th><th>Mode</th><th>Description</th></tr></thead><tbody><tr><td>0</td><td>AES128</td><td>AES-128 mode</td></tr><tr><td>1</td><td>AES256</td><td>AES-256 mode</td></tr></tbody></table>	Value	Mode	Description	0	AES128	AES-128 mode	1	AES256	AES-256 mode
Value	Mode	Description											
0	AES128	AES-128 mode											
1	AES256	AES-256 mode											

## 31.6.2 CRYPTO\_WAC - Wide Arithmetic Configuration

Offset	Bit Position																																			
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset																										0	0x0									
Access																										RW										
Name																										RESULTWIDTH	RW									
																										MULWIDTH										
																										MODOP										
																										MODULUS										

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
11:10	RESULTWIDTH	0x0	RW	<b>Result Width</b>  Result-size for non-modulus instructions
	Value	Mode		Description
	0	256BIT		Results have 256 bits
	1	128BIT		Results have 128 bits
	2	260BIT		Results have 260 bits. Upper bits of result can be read through DDA-TA0MSBS in CRYPTO_STATUS
9:8	MULWIDTH	0x0	RW	<b>Multiply Width</b>  Number of bits to multiply on non-modulus multiply instruction
	Value	Mode		Description
	0	MUL256		Multiply 256 bits
	1	MUL128		Multiply 128 bits
	2	MULMOD		Same number of bits as specified by MODULUS
7:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	MODOP	0	RW	<b>Modular Operation Field Type</b>  Field type used for modular operations
	Value	Mode		Description
	0	BINARY		Modular operations use XOR as required by certain algorithms
	1	REGULAR		Modular operations use normal modular arithmetic, not XOR
3:0	MODULUS	0x0	RW	<b>Modular Operation Modulus</b>  Modulus used for modular operations
	Value	Mode		Description
	0	BIN256		Generic modulus. $p = 2^{256}$

Bit	Name	Reset	Access	Description
1	BIN128			Generic modulus. $p = 2^{128}$
2	ECCBIN233P			Modulus for B-233 and K-233 ECC curves. $p(t) = t^{233} + t^{74} + 1$
3	ECCBIN163P			Modulus for B-163 and K-163 ECC curves. $p(t) = t^{163} + t^7 + t^6 + t^3 + 1$
4	GCMBIN128			Modulus for GCM. $P(t) = t^{128} + t^7 + t^2 + t + 1$
5	ECCPRIME256P			Modulus for P-256 ECC curve. $p = 2^{256} - 2^{224} + 2^{192} + 2^{96} - 1$
6	ECCPRIME224P			Modulus for P-224 ECC curve. $p = 2^{224} - 2^{96} - 1$
7	ECCPRIME192P			Modulus for P-192 ECC curve. $p = 2^{192} - 2^{64} - 1$
8	ECCBIN233N			P modulus for B-233 ECC curve
9	ECCBIN233KN			P modulus for K-233 ECC curve
10	ECCBIN163N			P modulus for B-163 ECC curve
11	ECCBIN163KN			P modulus for K-163 ECC curve
12	ECCPRIME256N			P modulus for P-256 ECC curve
13	ECCPRIME224N			P modulus for P-224 ECC curve
14	ECCPRIME192N			P modulus for P-192 ECC curve

## 31.6.3 CRYPTO\_CMD - Command Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0	0x00						
Access																										W						
Name																										INSTR						

Bit	Name	Reset	Access	Description
31:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11	SEQSTEP	0	W1	<b>Sequence Step</b>  When in a halted sequence, executes the current instruction and moves to the next
10	SEQSTOP	0	W1	<b>Sequence Stop</b>  Set to stop encryption/decryption regardless of it being a single or a SEQUENCE.
9	SEQSTART	0	W1	<b>Encryption/Decryption SEQUENCE Start</b>  Set to start encryption/decryption SEQUENCE.
8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
7:0	INSTR	0x00	W	<b>Execute Instruction</b>  Write to this field to perform any of the instructions described below. Illegal values are ignored. See <a href="#">31.4.2.2 Available Instructions</a> for details and requirements of each instruction
	Value	Mode		Description
	0	END		End of program
	1	EXEC		Start executing instructions up to this point, which also marks end of program
	3	DATA1INC		See detailed instruction listing
	4	DATA1INCCLR		See detailed instruction listing
	5	AESENC		AES Encryption
	6	AESDEC		AES Decryption
	7	SHA		SHA
	8	ADD		Add
	9	ADDC		Add with carry
	10	LADD		Long addition
	11	LADDC		Long addition with carry
	12	MADD		Modular addition
	13	MADD32		Word-wise addition
	16	SUB		Subtract

Bit	Name	Reset	Access	Description
17	SUBC			Subtract with carry
18	LSUB			Long subtraction
19	LSUBC			Long subtract with carry
20	MSUB			Modular subtraction
24	MUL			Multiply
25	MULC			See detailed instruction listing
26	LMUL			Long multiply
28	MMUL			Modular multiplication
29	MULO			See detailed instruction listing
31	LMULO			See detailed instruction listing
32	SHL			Shift left
33	SHLC			Shift left with carry (Rotate left)
34	SHLB			See detailed instruction listing
35	SHL1			See detailed instruction listing
36	SHR			Shift right
37	SHRC			Shift right with carry (Rotate right)
38	SHRB			See detailed instruction listing
39	SHR1			See detailed instruction listing
40	ADDO			See detailed instruction listing
41	ADDIC			See detailed instruction listing
42	LADDO			See detailed instruction listing
43	LADDIC			See detailed instruction listing
48	CLR			Clear DDATA0
49	XOR			XOR
50	INV			Invert operand
52	CSET			Carry set
53	CCLR			Carry clear
54	BBSWAP128			See detailed instruction listing
56	INC			Increment DDATA0
57	DEC			Decrement DDATA0
58	LINC			Long increment
59	LDEC			Long decrement
62	SHRA			Arithmetic shift right
64	DATA0TODATA0			DATA0 = DATA0
65	DATA0TODATA0XOR			DATA0 = DATA0 ^ DATA0
66	DATA0TODATA0XOR-LEN			DATA0[len-1:0] = DATA0[len-1:0] ^ DATA0[len-1:0]

Bit	Name	Reset	Access	Description
68	DATA0TODATA1			DATA1 = DATA0
69	DATA0TODATA2			DATA2 = DATA0
70	DATA0TODATA3			DATA3 = DATA0
72	DATA1TODATA0			DATA0 = DATA1
73	DATA1TODATA0XOR			DATA0 = DATA0 ^ DATA1
74	DATA1TODATA0XOR-LEN			DATA0[len-1:0] = DATA0[len-1:0] ^ DATA1[len-1:0]
77	DATA1TODATA2			DATA2 = DATA1
78	DATA1TODATA3			DATA3 = DATA1
80	DATA2TODATA0			DATA0 = DATA2
81	DATA2TODATA0XOR			DATA0 = DATA0 ^ DATA2
82	DATA2TODATA0XOR-LEN			DATA0[len-1:0] = DATA0[len-1:0] ^ DATA2[len-1:0]
84	DATA2TODATA1			DATA1 = DATA2
86	DATA2TODATA3			DATA3 = DATA2
88	DATA3TODATA0			DATA0 = DATA3
89	DATA3TODATA0XOR			DATA0 = DATA0 ^ DATA3
90	DATA3TODATA0XOR-LEN			DATA0[len-1:0] = DATA0[len-1:0] ^ DATA3[len-1:0]
92	DATA3TODATA1			DATA1 = DATA3
93	DATA3TODATA2			DATA2 = DATA3
99	DATATODMA0			See detailed instruction listing
107	DATATODMA1			See detailed instruction listing
112	DMA0TODATA			See detailed instruction listing
113	DMA0TODATAXOR			See detailed instruction listing
114	DMA1TODATA			See detailed instruction listing
129	DDATA0TODDATA1			DDATA1 = DDATA0
130	DDATA0TODDATA2			DDATA2 = DDATA0
131	DDATA0TODDATA3			DDATA3 = DDATA0
132	DDATA0TODDATA4			DDATA4 = DDATA0
133	DDATA0LTODATA0			DATA0 = DDATA0[127:0]
134	DDATA0HTODATA1			DATA1 = DDATA0[255:128]
135	DDATA0LTODATA2			DATA2 = DDATA0[127:0]
136	DDATA1TODDATA0			DDATA0 = DDATA1
138	DDATA1TODDATA2			DDATA2 = DDATA1
139	DDATA1TODDATA3			DDATA3 = DDATA1
140	DDATA1TODDATA4			DDATA4 = DDATA1
141	DDATA1LTODATA0			DATA0 = DDATA1[127:0]

Bit	Name	Reset	Access	Description
142	DDATA1HTODATA1			DATA1 = DDATA1[255:128]
143	DDATA1LTODATA2			DATA2 = DDATA1[127:0]
144	DDATA2TODDATA0			DDATA0 = DDATA2
145	DDATA2TODDATA1			DDATA1 = DDATA2
147	DDATA2TODDATA3			DDATA3 = DDATA2
148	DDATA2TODDATA4			DDATA4 = DDATA2
151	DDATA2LTODATA2			DATA2 = DDATA2[127:0]
152	DDATA3TODDATA0			DDATA0 = DDATA3
153	DDATA3TODDATA1			DDATA1 = DDATA3
154	DDATA3TODDATA2			DDATA2 = DDATA3
156	DDATA3TODDATA4			DDATA4 = DDATA3
157	DDATA3LTODATA0			DATA0 = DDATA3[127:0]
158	DDATA3HTODATA1			DATA1 = DDATA3[255:128]
160	DDATA4TODDATA0			DDATA0 = DDATA4
161	DDATA4TODDATA1			DDATA1 = DDATA4
162	DDATA4TODDATA2			DDATA2 = DDATA4
163	DDATA4TODDATA3			DDATA3 = DDATA4
165	DDATA4LTODATA0			DATA0 = DDATA4[127:0]
166	DDATA4HTODATA1			DATA1 = DDATA4[255:128]
167	DDATA4LTODATA2			DATA2 = DDATA4[127:0]
168	DATA0TODDATA0			DDATA0 = DATA0
169	DATA0TODDATA1			DDATA1 = DATA0
176	DATA1TODDATA0			DDATA0 = DATA1
177	DATA1TODDATA1			DDATA1 = DATA1
184	DATA2TODDATA0			DDATA0 = DATA2
185	DATA2TODDATA1			DDATA1 = DATA2
186	DATA2TODDATA2			DDATA2 = DATA2
192	SELDDATA0DDATA0			Use DDATA0 as V0, DDATA0 as V1
193	SELDDATA1DDATA0			Use DDATA1 as V0, DDATA0 as V1
194	SELDDATA2DDATA0			Use DDATA2 as V0, DDATA0 as V1
195	SELDDATA3DDATA0			Use DDATA3 as V0, DDATA0 as V1
196	SELDDATA4DDATA0			Use DDATA4 as V0, DDATA0 as V1
197	SELDATA0DDATA0			Use DATA0 as V0, DDATA0 as V1
198	SELDATA1DDATA0			Use DATA1 as V0, DDATA1 as V1
199	SELDATA2DDATA0			Use DATA2 as V0, DDATA2 as V1
200	SELDDATA0DDATA1			Use DDATA0 as V0, DDATA1 as V1
201	SELDDATA1DDATA1			Use DDATA1 as V0, DDATA1 as V1

Bit	Name	Reset	Access	Description
202	SELDDATA2DDATA1			Use DDATA2 as V0, DDATA1 as V1
203	SELDDATA3DDATA1			Use DDATA3 as V0, DDATA1 as V1
204	SELDDATA4DDATA1			Use DDATA4 as V0, DDATA1 as V1
205	SELDATA0DDATA1			Use DATA0 as V0, DDATA0 as V1
206	SELDATA1DDATA1			Use DATA1 as V0, DDATA1 as V1
207	SELDATA2DDATA1			Use DATA2 as V0, DDATA2 as V1
208	SELDDATA0DDATA2			Use DDATA0 as V0, DDATA2 as V1
209	SELDDATA1DDATA2			Use DDATA1 as V0, DDATA2 as V1
210	SELDDATA2DDATA2			Use DDATA2 as V0, DDATA2 as V1
211	SELDDATA3DDATA2			Use DDATA3 as V0, DDATA2 as V1
212	SELDDATA4DDATA2			Use DDATA4 as V0, DDATA2 as V1
213	SELDATA0DDATA2			Use DATA0 as V0, DDATA0 as V1
214	SELDATA1DDATA2			Use DATA1 as V0, DDATA1 as V1
215	SELDATA2DDATA2			Use DATA2 as V0, DDATA2 as V1
216	SELDDATA0DDATA3			Use DDATA0 as V0, DDATA3 as V1
217	SELDDATA1DDATA3			Use DDATA1 as V0, DDATA3 as V1
218	SELDDATA2DDATA3			Use DDATA2 as V0, DDATA3 as V1
219	SELDDATA3DDATA3			Use DDATA3 as V0, DDATA3 as V1
220	SELDDATA4DDATA3			Use DDATA4 as V0, DDATA3 as V1
221	SELDATA0DDATA3			Use DATA0 as V0, DDATA0 as V1
222	SELDATA1DDATA3			Use DATA1 as V0, DDATA1 as V1
223	SELDATA2DDATA3			Use DATA2 as V0, DDATA2 as V1
224	SELDDATA0DDATA4			Use DDATA0 as V0, DDATA4 as V1
225	SELDDATA1DDATA4			Use DDATA1 as V0, DDATA4 as V1
226	SELDDATA2DDATA4			Use DDATA2 as V0, DDATA4 as V1
227	SELDDATA3DDATA4			Use DDATA3 as V0, DDATA4 as V1
228	SELDDATA4DDATA4			Use DDATA4 as V0, DDATA4 as V1
229	SELDATA0DDATA4			Use DATA0 as V0, DDATA4 as V1
230	SELDATA1DDATA4			Use DATA1 as V0, DDATA4 as V1
231	SELDATA2DDATA4			Use DATA2 as V0, DDATA4 as V1
232	SELDDATA0DATA0			Use DDATA0 as V0, DATA0 as V1
233	SELDDATA1DATA0			Use DDATA1 as V0, DATA0 as V1
234	SELDDATA2DATA0			Use DDATA2 as V0, DATA0 as V1
235	SELDDATA3DATA0			Use DDATA3 as V0, DATA0 as V1
236	SELDDATA4DATA0			Use DDATA4 as V0, DATA0 as V1
237	SELDATA0DATA0			Use DATA0 as V0, DATA0 as V1
238	SELDATA1DATA0			Use DATA1 as V0, DATA0 as V1

Bit	Name	Reset	Access	Description
239	SELDDATA2DATA0			Use DATA2 as V0, DATA0 as V1
240	SELDDATA0DATA1			Use DDATA0 as V0, DATA1 as V1
241	SELDDATA1DATA1			Use DDATA1 as V0, DATA1 as V1
242	SELDDATA2DATA1			Use DDATA2 as V0, DATA1 as V1
243	SELDDATA3DATA1			Use DDATA3 as V0, DATA1 as V1
244	SELDDATA4DATA1			Use DDATA4 as V0, DATA1 as V1
245	SELDDATA0DATA1			Use DATA0 as V0, DATA1 as V1
246	SELDDATA1DATA1			Use DATA1 as V0, DATA1 as V1
247	SELDDATA2DATA1			Use DATA2 as V0, DATA1 as V1
248	EXECIFA			Run following if in A sequence
249	EXECIFB			Run following if in B sequence
250	EXECIFNLAST			Run following if in last iteration of combined A and B sequence
251	EXECIFLAST			Run following if in last iteration of combined A and B sequence
252	EXECIFCARRY			Run following if CARRY bit is set
253	EXECIFNCARRY			Run following if CARRY bit is not set
254	EXECALWAYS			Resume execution

### 31.6.4 CRYPTO\_STATUS - Status Register

Offset	Bit Position																														
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
Reset																													0	0	0
Access																													R	R	R
Name																												DMAACTIVE	INSTRRUNNING	SEQRUNNING	

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2	DMAACTIVE	0	R	<b>DMA Action is Active</b>
	This bit indicates that the AES module is waiting for a DMA transfer to complete.			
1	INSTRRUNNING	0	R	<b>Action is Active</b>
	This bit indicates that the AES module busy executing an instruction. The origin of the instruction is either through CRYPTO_CMD or due to a running SEQUENCE.			
0	SEQRUNNING	0	R	<b>AES SEQUENCE Running</b>
	This bit indicates that the AES module is running an encryption/decryption SEQUENCE.			

### 31.6.5 CRYPTO\_DSTATUS - Data Status Register

Offset	Bit Position							
Reset	31	30	29	28	27	26	25	24
Access	R	0						
Name	CARRY							
DDATA1MSB	R	X	20	19	18	17	16	15
DDATA0MSBS	R	0xX						
DDATA0LSBS	R	0xX	9	8	7	6	5	4
DATA0ZERO	R	0xX	1	0				

Bit	Name	Reset	Access	Description
31:25	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
24	CARRY	0	R	<b>Carry From Arithmetic Operation</b>  Set on carry from arithmetic operations
23:21	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
20	DDATA1MSB	X	R	<b>MSB in DDATA1</b>  Allows read of 255 in DDATA1. Does not depend on RESULTWIDTH in CRYPTO_WAC
19:16	DDATA0MSBS	0xX	R	<b>MSB in DDATA0</b>  Allows read of 4 MSBs in DDATA0. The bits depend on RESULTWIDTH in CRYPTO_WAC
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:8	DDATA0LSBS	0xX	R	<b>LSBs in DDATA0</b>  Allows read of 4 LSBs in DDATA0
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	DATA0ZERO	0xX	R	<b>Data 0 Zero</b>  This field contains flags indicating if any 32 bit part of DATA0 is 0.
<hr/>				
Value	Mode	Description		
1	ZERO0TO31	In DATA0 bits 0 to 31 are all zero.		
2	ZERO32TO63	In DATA0 bits 32 to 63 are all zero.		
4	ZERO64TO95	In DATA0 bits 64 to 95 are all zero.		
8	ZERO96TO127	In DATA0 bits 96 to 127 are all zero.		

## 31.6.6 CRYPTO\_CSTATUS - Control Status Register

Offset	Bit Position																																			
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset									0x00									0									0x2									0x1
Access									R									R									R									R
Name									SEQIP									SEQSKIP	R	0	0	0	0	0	0	0	V1									V0

Bit	Name	Reset	Access	Description
31:25	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
24:20	SEQIP	0x00	R	<b>Sequence Next Instruction Pointer</b>  Next sequence instruction when in halted sequence
19:18	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
17	SEQSKIP	0	R	<b>Sequence Skip Next Instruction</b>  When in halted sequence, tells whether next instruction will be skipped
16	SEQPART	0	R	<b>Sequence Part</b>  Shows whether currently in part A or B of a sequence
	Value	Mode	Description	
	0	SEQA		
	1	SEQB		
15:11	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
10:8	V1	0x2	R	<b>Selected ALU Operand 1</b>  Selectable operand for arithmetic operations
	Value	Mode	Description	
	0	DDATA0		
	1	DDATA1		
	2	DDATA2		
	3	DDATA3		
	4	DDATA4		
	5	DATA0		
	6	DATA1		
	7	DATA2		
7:3	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		

Bit	Name	Reset	Access	Description
2:0	V0	0x1	R	<b>Selected ALU Operand 0</b>
Selectable operand for arithmetic operations				
	Value	Mode		Description
0		DDATA0		
1		DDATA1		
2		DDATA2		
3		DDATA3		
4		DDATA4		
5		DATA0		
6		DATA1		
7		DATA2		

### 31.6.7 CRYPTO\_KEY - KEY Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	KEY																															

Bit	Name	Reset	Access	Description
31:0	KEY	0xFFFFFFFF X	RWH	<b>Key Access</b>

Access the KEY. 4x32bits (8x32bits if AES256 in CRYPTO\_CTRL is set) read/write accesses are required to fully read/write KEY.

## 31.6.8 CRYPTO\_KEYBUF - KEY Buffer Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	KEYBUF																															

Bit	Name	Reset	Access	Description
31:0	KEYBUF	0xFFFFFFFF X	RWH	<b>Key Buffer Access</b>

Access to KEYBUF. 4x32bits (8x32bits if AES256 in CRYPTO\_CTRL is set) read/write accesses are required to fully read/write KEYBUF

## 31.6.9 CRYPTO\_SEQCTRL - Sequence Control

Offset	Bit Position																																			
	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
<b>Reset</b>	0																																			0x0000
<b>Access</b>	RW																																			RWH
<b>Name</b>	HALT	DMA1PRESA	RW	DMA0PRESA	RW	0	DMA1SKIP	RWH	DMA0SKIP	RWH	0x0	RW	BLOCKSIZE																				LENGTHA			

Bit	Name	Reset	Access	Description
31	HALT	0	RW	<b>Halt Sequence</b>  Allows stepping through CRYPTO instructions in the sequence for debugging.
30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
29	DMA1PRESA	0	RW	<b>DMA1 Preserve a</b>  Set to write skipped bytes back on next DMA1WR triggered write. Use this together with DMA1SKIP to enable in-place conversions with CRYPTO
28	DMA0PRESA	0	RW	<b>DMA0 Preserve a</b>  Set to write skipped bytes back on next DMA0WR triggered write. Use this together with DMA0SKIP to enable in-place conversions with CRYPTO
27:26	DMA1SKIP	0x0	RWH	<b>DMA1 Skip</b>  Set to number of bytes to exclude from data received by next DMA1RD instruction
25:24	DMA0SKIP	0x0	RWH	<b>DMA0 Skip</b>  Set to number of bytes to exclude from data received by next DMA0RD instruction
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	BLOCKSIZE	0x0	RW	<b>Size of Data Blocks</b>  Defines the width of blocks processed in each iteration of a sequence running on a dataset (see related note in <a href="#">31.4.3 Repeated Sequence</a> )
	Value	Mode		Description
	0	16BYTES		A block is 16 bytes long
	1	32BYTES		A block is 32 bytes long
	2	64BYTES		A block is 64 bytes long
19:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
13:0	LENGTHA	0x0000	RWH	<b>Buffer Length a in Bytes</b>  This field sets the number of bytes to be handled during the repeated sequence. Set it to the exact number of bytes. If the number is not a multiple of BLOCKSIZE, the last data block is zero-padded. Format is unsigned integer.

### **31.6.10 CRYPTO\_SEQCTRLB - Sequence Control B**

Bit	Name	Reset	Access	Description
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
29	DMA1PRESB	0	RW	<b>DMA1 Preserve B</b>  For unaligned sequences, set this bit along with DMA1PRESA for in-place conversions where all data is written out from CRYPTO again. If only the second part of a data-set is written, enable only this to preserve the data read in during part A
28	DMA0PRESB	0	RW	<b>DMA0 Preserve B</b>  For unaligned sequences, set this bit along with DMA0PRESA for in-place conversions where all data is written out from CRYPTO again. If only the second part of a data-set is written, enable only this to preserve the data read in during part A
27:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
13:0	LENGTHB	0x0000	RWH	<b>Buffer Length B in Bytes</b>  Sets the number of bytes to be handled in a second iteration over a programmed sequence.

### **31.6.11 CRYPTO\_IF - AES Interrupt Flags**

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
1	SEQDONE	0	R	<b>Sequence Done</b> Set when an instruction sequence has completed
0	INSTRDONE	0	R	<b>Instruction Done</b> Set when an instruction has completed

## 31.6.12 CRYPTO\_IFS - Interrupt Flag Set Register

Offset	Bit Position																															
0x044	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																														W1	0	0
Access																														W1	0	0
Name																														SEQDONE	INSTRDONE	INSTRDONE

Bit	Name	Reset	Access	Description
31:2	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
1	SEQDONE	0	W1	<b>Set SEQDONE Interrupt Flag</b>
				Write 1 to set the SEQDONE interrupt flag
0	INSTRDONE	0	W1	<b>Set INSTRDONE Interrupt Flag</b>
				Write 1 to set the INSTRDONE interrupt flag

## 31.6.13 CRYPTO\_IFC - Interrupt Flag Clear Register

Offset	Bit Position																															
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																														(R)W1	0	0
Access																														(R)W1	0	0
Name																														SEQDONE	INSTRDONE	INSTRDONE

Bit	Name	Reset	Access	Description
31:2	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
1	SEQDONE	0	(R)W1	<b>Clear SEQDONE Interrupt Flag</b>
				Write 1 to clear the SEQDONE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
0	INSTRDONE	0	(R)W1	<b>Clear INSTRDONE Interrupt Flag</b>
				Write 1 to clear the INSTRDONE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

### 31.6.14 CRYPTO\_IEN - Interrupt Enable Register

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	SEQDONE	0	RW	<b>SEQDONE Interrupt Enable</b> Enable/disable the SEQDONE interrupt
0	INSTRDONE	0	RW	<b>INSTRDONE Interrupt Enable</b> Enable/disable the INSTRDONE interrupt

### 31.6.15 CRYPTO\_SEQ0 - Sequence Register 0

Bit	Name	Reset	Access	Description
31:24	INSTR3	0x00	RW	<b>Sequence Instruction 3</b>
Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.				
23:16	INSTR2	0x00	RW	<b>Sequence Instruction 2</b>
Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.				
15:8	INSTR1	0x00	RW	<b>Sequence Instruction 1</b>
Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.				
7:0	INSTR0	0x00	RW	<b>Sequence Instruction 0</b>
Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.				

## 31.6.16 CRYPTO\_SEQ1 - Sequence Register 1

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00				0x00				0x00				0x00				0x00				0x00				0x00							
Access	RW				RW				RW				RW				RW				RW				RW							
Name	INSTR7				INSTR6				INSTR5				INSTR4				INSTR4				INSTR4				INSTR4							

Bit	Name	Reset	Access	Description
31:24	INSTR7	0x00	RW	<b>Sequence Instruction 7</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
23:16	INSTR6	0x00	RW	<b>Sequence Instruction 6</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
15:8	INSTR5	0x00	RW	<b>Sequence Instruction 5</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
7:0	INSTR4	0x00	RW	<b>Sequence Instruction 4</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.

## 31.6.17 CRYPTO\_SEQ2 - Sequence Register 2

Offset	Bit Position																															
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00				0x00				0x00				0x00				0x00				0x00				0x00							
Access	RW				RW				RW				RW				RW				RW				RW							
Name	INSTR11				INSTR10				INSTR9				INSTR8				INSTR8				INSTR8				INSTR8							

Bit	Name	Reset	Access	Description
31:24	INSTR11	0x00	RW	<b>Sequence Instruction 11</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
23:16	INSTR10	0x00	RW	<b>Sequence Instruction 10</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
15:8	INSTR9	0x00	RW	<b>Sequence Instruction 9</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
7:0	INSTR8	0x00	RW	<b>Sequence Instruction 8</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.

## 31.6.18 CRYPTO\_SEQ3 - Sequence Register 3

Offset	Bit Position																															
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00								0x00								0x00								0x00							
Access	RW								RW								RW								RW							
Name	INSTR15								INSTR14								INSTR13								INSTR12							

Bit	Name	Reset	Access	Description
31:24	INSTR15	0x00	RW	<b>Sequence Instruction 15</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
23:16	INSTR14	0x00	RW	<b>Sequence Instruction 14</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
15:8	INSTR13	0x00	RW	<b>Sequence Instruction 13</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
7:0	INSTR12	0x00	RW	<b>Sequence Instruction 12</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.

## 31.6.19 CRYPTO\_SEQ4 - Sequence Register 4

Offset	Bit Position																															
0x060	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00								0x00								0x00								0x00							
Access	RW								RW								RW								RW							
Name	INSTR19								INSTR18								INSTR17								INSTR16							

Bit	Name	Reset	Access	Description
31:24	INSTR19	0x00	RW	<b>Sequence Instruction 19</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
23:16	INSTR18	0x00	RW	<b>Sequence Instruction 18</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
15:8	INSTR17	0x00	RW	<b>Sequence Instruction 17</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.
7:0	INSTR16	0x00	RW	<b>Sequence Instruction 16</b>  Sequence instruction. See INSTR in CRYPTO_CMD for a possible values.

## 31.6.20 CRYPTO\_DATA0 - DATA0 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x080	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DATA0																															

Bit	Name	Reset	Access	Description
31:0	DATA0	0xFFFFFFFF	RWH	<b>Data 0 Access</b> X

Access to DATA0. 4x32bits read/write accesses are required to fully read/write DATA0

## 31.6.21 CRYPTO\_DATA1 - DATA1 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x084	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DATA1																															

Bit	Name	Reset	Access	Description
31:0	DATA1	0xFFFFFFFF	RWH	<b>Data 1 Access</b> X

Access to DATA1. 4x32bits read/write accesses are required to fully read/write DATA1

## 31.6.22 CRYPTO\_DATA2 - DATA2 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x088	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DATA2																															

Bit	Name	Reset	Access	Description
31:0	DATA2	0xFFFFFFFF	RWH	<b>Data 2 Access</b> X

Access to DATA2. 4x32bits read/write accesses are required to fully read/write DATA2.

## 31.6.23 CRYPTO\_DATA3 - DATA3 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x08C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DATA3																															

Bit	Name	Reset	Access	Description
31:0	DATA3	0xFFFFFFFF	RWH	<b>Data 3 Access</b> X

Access to DATA3. 4x32bits read/write accesses are required to fully read/write DATA3.

## 31.6.24 CRYPTO\_DATA0XOR - DATA0XOR Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x0A0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DATA0XOR																															

Bit	Name	Reset	Access	Description
31:0	DATA0XOR	0xFFFFFFFF X	RWH	<b>XOR Data 0 Access</b>

Any value written to this register will be XOR'ed with the value of DATA0. The result is stored in DATA0. Reads return DATA0 directly. 4x32bits read/write accesses are required to perform a full XOR write to DATA0

## 31.6.25 CRYPTO\_DATA0BYTE - DATA0 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x0B0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFF																															
Access	RWH																															
Name	DATA0BYTE																															

Bit	Name	Reset	Access	Description
31:8	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
7:0	DATA0BYTE	0XX	RWH	<b>Data 0 Byte Access</b>

Access to DATA0. 16x8bits read/write accesses are required to fully read/write DATA0. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.26 CRYPTO\_DATA1BYTE - DATA1 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x0B4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0XX		
Access																															RWH		
Name																																	DATA1BYTE

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DATA1BYTE	0xXX	RWH	<b>Data 1 Byte Access</b>  Access to DATA1. 16x8bits read/write accesses are required to fully read/write DATA1. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.27 CRYPTO\_DATA0XORBYTE - DATA0 Register Byte XOR Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x0BC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0XX	
Access																																RWH	
Name																																	DATA0XORBYTE

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DATA0XORBYTE	0xXX	RWH	<b>Data 0 XOR Byte Access</b>  Access to DATA0. 16x8bits read/write accesses are required to fully read/write DATA0. Written data is XOR'ed with the already present data in DATA0. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.28 CRYPTO\_DATA0BYTE12 - DATA0 Register Byte 12 Access (No Bit Access)

Offset	Bit Position																															
0x0C0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0xFF							
Access																									RWH							
Name																									DATA0BYTE12							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	DATA0BYTE12	0xFF	RWH	<b>Data 0 Byte 12 Access</b>  Access to DATA0 byte 12.

## 31.6.29 CRYPTO\_DATA0BYTE13 - DATA0 Register Byte 13 Access (No Bit Access)

Offset	Bit Position																															
0x0C4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0xFF							
Access																									RWH							
Name																									DATA0BYTE13							

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7:0	DATA0BYTE13	0xFF	RWH	<b>Data 0 Byte 13 Access</b>  Access to DATA0 byte 13.

## 31.6.30 CRYPTO\_DATA0BYTE14 - DATA0 Register Byte 14 Access (No Bit Access)

Offset	Bit Position																															
0x0C8	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0XXX							
Access																									RWH							
Name																									DATA0BYTE14							

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DATA0BYTE14	0xXX	RWH	<b>Data 0 Byte 14 Access</b>  Access to DATA0 byte 14.

## 31.6.31 CRYPTO\_DATA0BYTE15 - DATA0 Register Byte 15 Access (No Bit Access)

Offset	Bit Position																								0XXX <td data-kind="ghost"></td>							
0x0CC	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									RWH							
Access																									DATA0BYTE15							
Name																										DATA0BYTE15						

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DATA0BYTE15	0xXX	RWH	<b>Data 0 Byte 15 Access</b>  Access to DATA0 byte 15.

## 31.6.32 CRYPTO\_DDATA0 - DDATA0 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x100	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA0																															

Bit	Name	Reset	Access	Description
31:0	DDATA0	0xFFFFFFFF X	RWH	<b>Double Data 0 Access</b>

Access to DDATA0. 8x32bits read/write accesses are required to fully read/write DDATA0.

## 31.6.33 CRYPTO\_DDATA1 - DDATA1 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x104	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA1																															

Bit	Name	Reset	Access	Description
31:0	DDATA1	0xFFFFFFFF X	RWH	<b>Double Data 0 Access</b>

Access to DDATA1, which is equal to the full width of KEY regardless of AES256 in CRYPTO\_CTRL. 8x32bits read/write accesses are required to fully read/write DDATA1.

## 31.6.34 CRYPTO\_DDATA2 - DDATA2 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x108	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA2																															

Bit	Name	Reset	Access	Description
31:0	DDATA2	0xFFFFFFFF X	RWH	<b>Double Data 0 Access</b>

Access to DDATA2, which consists of {DATA1, DATA0}. 8x32bits read/write accesses are required to fully read/write DDATA2.

## 31.6.35 CRYPTO\_DDATA3 - DDATA3 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x10C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA3																															

Bit	Name	Reset	Access	Description
31:0	DDATA3	0xFFFFFFFF X	RWH	<b>Double Data 0 Access</b>

Access to DDATA3, which consists of {DATA3, DATA2}. 8x32bits read/write accesses are required to fully read/write DDATA3.

## 31.6.36 CRYPTO\_DDATA4 - DDATA4 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x110	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA4																															

Bit	Name	Reset	Access	Description
31:0	DDATA4	0xFFFFFFFF X	RWH	<b>Double Data 0 Access</b>

Access to DDATA4, which is equal to the full width of KEYBUF regardless of AES256 in CRYPTO\_CTRL. 8x32bits read/write accesses are required to fully read/write DDATA4.

## 31.6.37 CRYPTO\_DDATA0BIG - DDATA0 Register Big Endian Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x130	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	DDATA0BIG																															

Bit	Name	Reset	Access	Description
31:0	DDATA0BIG	0xFFFFFFFF X	RWH	<b>Double Data 0 Big Endian Access</b>

Big endian access to DDATA0. 8x32bits read/write accesses are required to fully read/write DDATA0.

## 31.6.38 CRYPTO\_DDATA0BYTE - DDATA0 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x140	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0XXX	
Access																																RWH	
Name																																	DDATA0BYTE

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DDATA0BYTE	0xXX	RWH	<b>Ddata 0 Byte Access</b>  Access to DDATA0. 32x8bits read/write accesses are required to fully read/write DDATA0. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.39 CRYPTO\_DDATA1BYTE - DDATA1 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x144	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0XXX	
Access																																RWH	
Name																																	DDATA1BYTE

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	DDATA1BYTE	0xXX	RWH	<b>Ddata 1 Byte Access</b>  Access to DDATA1. 32x8bits read/write accesses are required to fully read/write DDATA1. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.40 CRYPTO\_DDATA0BYTE32 - DDATA0 Register Byte 32 Access (No Bit Access)

Offset	Bit Position																															
0x148	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xX																															
Access	RWH																															
Name	DDATA0BYTE32																															

Bit	Name	Reset	Access	Description
31:4	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
3:0	DDATA0BYTE32	0xX	RWH	<b>Ddata 0 Byte 32 Access</b>  Access to DDATA0 byte 32. This is used when RESULTWIDTH in CRYPTO_WAC is set to 260BIT.

## 31.6.41 CRYPTO\_QDATA0 - QDATA0 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x180	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	QDATA0																															

Bit	Name	Reset	Access	Description
31:0	QDATA0	0xFFFFFFFF X	RWH	<b>Quad Data 0 Access</b>

Access to QDATA0, which is equal to {DDATA1, DDATA0}. 16x32bits read/write accesses are required to fully read/write QDATA0.

## 31.6.42 CRYPTO\_QDATA1 - QDATA1 Register Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x184	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	QDATA1																															

Bit	Name	Reset	Access	Description
31:0	QDATA1	0xFFFFFFFF X	RWH	<b>Quad Data 1 Access</b>

Access to QDATA1, which is equal to {DATA3, DATA2, DATA1, DATA0} and {DDATA3, DDATA2}. 16x32bits read/write accesses are required to fully read/write QDATA1.

## 31.6.43 CRYPTO\_QDATA1BIG - QDATA1 Register Big Endian Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																															
0x1A4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0xFFFFFFFF																															
Access	RWH																															
Name	QDATA1BIG																															

Bit	Name	Reset	Access	Description
31:0	QDATA1BIG	0xFFFFFFFF X	RWH	<b>Quad Data 1 Big Endian Access</b>

Big endian access to QDATA1, which is equal to {DATA3, DATA2, DATA1, DATA0} and {DDATA3, DDATA2}. 16x32bits read/write accesses are required to fully read/write QDATA1.

## 31.6.44 CRYPTO\_QDATA0BYTE - QDATA0 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x1C0	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																															0XXX		
Access																															RWH		
Name																																	QDATA0BYTE



Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	QDATA0BYTE	0xXX	RWH	<b>Qdata 0 Byte Access</b>  Access to QDATA0. 64x8bits read/write accesses are required to fully read/write QDATA0. Accesses must be performed in multiples of 4, or data incoherency may occur

## 31.6.45 CRYPTO\_QDATA1BYTE - QDATA1 Register Byte Access (No Bit Access) (Actionable Reads)

Offset	Bit Position																																
0x1C4	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																0XXX	
Access																																RWH	
Name																																	QDATA1BYTE

Bit	Name	Reset	Access	Description
31:8	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
7:0	QDATA1BYTE	0xXX	RWH	<b>Qdata 1 Byte Access</b>  Access to QDATA1. 64x8bits read/write accesses are required to fully read/write QDATA1. Accesses must be performed in multiples of 4, or data incoherency may occur

## 32. GPIO - General Purpose Input/Output



### Quick Facts

#### What?

The General Purpose Input/Output (GPIO) is used for pin configuration, direct pin manipulation and sensing, as well as routing for peripheral pin connections.

#### Why?

Easy to use and highly configurable input/output pins are important to fit many communication protocols as well as minimizing software control overhead. Flexible routing of peripheral functions helps to ease PCB layout.

#### How?

Each pin on the device can be individually configured as either an input or an output with several different drive modes. Also, individual bit manipulation registers minimizes control overhead. Peripheral connections to pins can be routed to several different locations, thus solving congestion issues that may arise with multiple functions on the same pin. Fully asynchronous interrupts can also be generated from any pin.

### 32.1 Introduction

In the EFM32 Tiny Gecko 11 devices the General Purpose Input/Output (GPIO) pins are organized into ports with up to 16 pins each. These GPIO pins can individually be configured as either an output or input. More advanced configurations like open-drain, open-source, and glitch filtering can be configured for each individual GPIO pin. The GPIO pins can also be overridden by peripheral pin connections, like Timer PWM outputs or USART communication, which can be routed to several locations on the device. The GPIO supports up to 16 asynchronous external pin interrupts, which enable interrupts from any pin on the device. Also, the input value of a pin can be routed through the Peripheral Reflex System to other peripherals.

**Note:** To use the GPIO, the GPIO clock must first be enabled in CMU\_HFBUSCLKEN0. Setting this bit enables the HFBUSCLK for the GPIO.

## 32.2 Features

- Individual configuration for each pin
  - Tristate (reset state)
  - Push-pull
  - Open-drain
  - Pull-up resistor
  - Pull-down resistor
  - Drive strength
    - 1 mA
    - 10 mA
  - Slewrate
  - Over Voltage Tolerance
- EM4 IO pin retention
  - Output enable
  - Output value
  - Pull enable
  - Pull direction
  - Over Voltage Tolerance
- EM4 wake-up on selected GPIO pins
- Glitch suppression input filter
- Alternate functions (e.g. peripheral outputs and inputs)
  - Routed to several locations on the device
  - Pin connections can be enabled individually
  - Output data can be overridden by peripheral
  - Output enable can be overridden by peripheral
- Toggle register for output data
- Dedicated data input register (read-only)
- Interrupts
  - 2 Interrupt lines using either levels or edges
    - EM4 wake-up pins are selectable for level interrupts
    - All GPIO pins are selectable for edge interrupts
  - Separate enable, status, set and clear registers
  - Asynchronous sensing
  - Rising, falling or both edges
  - High or low level detection
  - Wake up from EM0 Active-EM3 Stop
- Peripheral Reflex System producer
  - All GPIO pins are selectable
- Configuration lock functionality to avoid accidental changes

### 32.3 Functional Description


An overview of the GPIO module is shown in [Figure 32.1 Pin Configuration on page 1132](#). The GPIO pins are grouped into 16-pin ports. Each individual GPIO pin is called Pxn where x indicates the port (A, B, C ...) and n indicates the pin number (0,1,...,15). Fewer than 16 bits may be available on some ports, depending on the total number of I/O pins on the package. After a reset, both input and output are disabled for all pins on the device, except for the Serial Wire Debug pins.

To use a pin, the Mode Register (GPIO\_Px\_MODEL/GPIO\_Px\_MODEH) must be configured for the pin to make it an input or output. These registers can also do more advanced configuration, which is covered in [32.3.1 Pin Configuration](#). When the port is configured as an input or an output, the Data In Register (GPIO\_Px\_DIN) can be used to read the level of each pin in the port (bit n in the register is connected to pin n on the port). When configured as an output, the value of the Data Out Register (GPIO\_Px\_DOUT) will be driven to the pin.

The DOUT value can be changed in 4 different ways:

- Writing to the GPIO\_Px\_DOUT register
- Writing the BITSET address of the GPIO\_Px\_DOUT register sets the DOUT bits
- Writing the BITCLEAR address of the GPIO\_Px\_DOUT register clears the DOUT bits
- Writing the GPIO\_Px\_DOUTTGL register toggles the corresponding DOUT bits

Reading the GPIO\_Px\_DOUT register will return its contents. Reading the GPIO\_Px\_DOUTTGL register will return 0.



**Figure 32.1. Pin Configuration**

**Note:** There is no ESD diode to IOVDD because if using LCD Voltage Boost the pin voltage may be higher than IOVDD. Nevertheless there is an ESD protection block against over voltage.

### 32.3.1 Pin Configuration


In addition to setting the pins as either outputs or inputs, the GPIO\_Px\_MODEL and GPIO\_Px\_MODEH registers can be used for more advanced configurations. GPIO\_Px\_MODEL contains 8 bit fields named MODEn ( $n=0,1,\dots,7$ ) which control pins 0-7, while GPIO\_Px\_MODEH contains 8 bit fields named MODEn ( $n=8,9,\dots,15$ ) which control pins 8-15. In some modes GPIO\_Px\_DOUT is also used for extra configurations like pull-up/down and glitch suppression filter enable. [Table 32.1 Pin Configuration on page 1133](#) shows the available configurations.

**Table 32.1. Pin Configuration**

MODEn	Input	Output	DOUT	Pull-down	Pull-up	Alt Port Ctrl	Input Filter	Description
DISABLED	Disabled if not DINDIS	Disabled	0					Input disabled
			1		On			Input disabled with pull-up
INPUT			0					Input enabled
			1			On		Input enabled with filter
INPUTPULL			0	On				Input enabled with pull-down
			1		On			Input enabled with pull-up
INPUTPULLFILTER			0	On		On		Input enabled with pull-down and filter
			1		On	On		Input enabled with pull-up and filter
PUSHPULL		Push-pull	x					Push-pull
PUSHPULLALT			x			On		Push-pull with alternate port control values
WIREDOR		Open Source (Wired-OR)	x					Open-source
WIREDORPULLDOWN			x	On				Open-source with pull-down
WIREDAND		Open Drain (Wired-AND)	x					Open-drain
WIREDANDFILTER			x			On		Open-drain with filter
WIREDANDPULLUP			x		On			Open-drain with pull-up
WIREDANDPULLUPFILTER			x		On	On		Open-drain with pull-up and filter
WIREDANDALT			x			On		Open-drain with alternate port control values
WIREDANDALTFILTER			x			On	On	Open-drain with alternate port control values and filter
WIREDANDALTPULLUP			x		On	On		Open-drain with alternate port control values and pull-up
WIREDANDALTPULLUPFILTER			x		On	On	On	Open-drain with alternate port control values, pull-up and filter


MODEn determines which mode the pin is in at a given time. Setting MODEn to DISABLED disables the pin, reducing power consumption to a minimum. When the output driver, input driver and Over Voltage Tolerance is disabled, the pin can be used as a connection for an analog module. An input is enabled by setting MODEn to any value other than DISABLED while DINDIS for the given port is cleared.

Set DINDIS to disable the input of a gpio port. The pull-up, pull-down and glitch filter function can optionally be applied to the input, see [Figure 32.2 Tristated Output With Optional Pull-up or Pull-down on page 1134](#).



**Figure 32.2. Tristated Output With Optional Pull-up or Pull-down**


When MODEn is PUSH\_PULL or PUSH\_PULL\_ALT, the pin operates in push-pull mode. In this mode, the pin can have alternate port control values and can be driven either high or low, dependent on the value of GPIO\_Px\_DOUT. The push-pull configuration is shown in [Figure 32.3 Push-Pull Configuration on page 1134](#).



**Figure 32.3. Push-Pull Configuration**

When MODEn is WIRED\_OR or WIRED\_OR\_PULLDOWN, the pin operates in open-source mode (with a pull-down resistor for WIRED\_OR\_PULLDOWN). When driving a high value in open-source mode, the pull-down is disconnected to save power.

When the mode is prefixed with WIRED\_AND, the pin operates in open-drain mode as shown in [Figure 32.4 Open-drain on page 1134](#). In open-drain mode, the pin can have an input filter, a pull-up, alternate port control values or any combination of these. When driving a low value in open-drain mode, the pull-up is disconnected to save power.



**Figure 32.4. Open-drain**

### 32.3.1.1 Over Voltage Tolerance

Over voltage capability is available for most pins. If available, it allows the pin to be used at either the minimum of IOVDD + 2V and 5.5V (for 5V tolerant pads) or the minimum of IOVDD + 2V and 3.8V (for non-5V tolerant pads supporting LCD). The data sheet specifies which pins can be used as 5V tolerant pins. Default over voltage is enabled for each pin supporting that feature. Over voltage tolerance (OVT) can be disabled on a per pin basis. The over voltage tolerance feature applied to the selected pins is configured in the GPIO\_Px\_OVTDIS register. Disabling the over voltage tolerance for a pin will provide less distortion on that pin, which is useful when the pin is used as analog input.

**Note:** The VDAC (and OPAMPs) and LCD can drive outputs above IOVDD and therefore the involved pads typically require OVT to be enabled.

### 32.3.1.2 Alternate Port Control

The Alternate Port Control allows for additional flexibility of port level settings. A user may setup two different port configurations (normal and alternate modes) and select which is applied on a pin by pin bases. For example you may configure half of port A to use the low drive strength setting (normal mode) while the other half uses high drive strength (alternate mode).

Alternate port control is enabled when MODEn is set to any of the ALT enumerated modes (ie. PUSHPULLALT). When MODEn is an alternate mode, the pin uses the alternate port control values specified in the DINDISALT, SLEWRATEALT, and DRIVESTRENGTHALT fields in GPIO\_Px\_CTRL. In all other modes, the port control values are used from the DINDIS, SLEWRATE, and DRIVESTRENGTH fields in GPIO\_Px\_CTRL.

### 32.3.1.3 Drive Strength

The drive strength can be applied to pins on a port-by-port basis. The drive strength applied to pins configured using normal MODEn settings can be controlled using the DRIVESTRENGTH field in GPIO\_Px\_CTRL. The drive strength applied to pins configured using alternate MODEn settings can be controlled using the DRIVESTRENGTHALT field.

### 32.3.1.4 Slewrate

The slewrate can be applied to pins on a port-by-port basis. The slewrate applied to pins configured using normal MODEn settings can be controlled using the SLEWRATE fields in GPIO\_Px\_CTRL. The slewrate applied to pins configured using the alternate MODEn settings can be controlled using the SLEWRATEALT field.

### 32.3.1.5 Input Disable

The pin inputs can be disabled on a port-by-port basis. The input of pins configured using the normal MODEn settings can be disabled by setting DINDIS in GPIO\_Px\_CTRL. The input of pins configured using the alternate MODEn settings can be disabled by setting DINDISALT.

### 32.3.1.6 Configuration Lock

GPIO\_Px\_MODEL, GPIO\_Px\_MODEH, GPIO\_Px\_CTRL, GPIO\_Px\_PINLOCKN, GPIO\_Px\_OVTDIS, GPIO\_EXTIPSELL, GPIO\_EXTIPSELH, GPIO\_EXTIPINSELL, GPIO\_EXTIPINSELH, GPIO\_INSENSE, GPIO\_ROUTEOPEN, and GPIO\_ROUTELOC0 can be locked by writing any value other than 0xA534 to GPIO\_LOCK. Writing the value 0xA534 to the GPIOx\_LOCK register unlocks the configuration registers.

In addition to configuration lock, GPIO\_Px\_MODEL, GPIO\_Px\_MODEH, GPIO\_Px\_DOUT, GPIO\_Px\_DOUTTGL, and GPIO\_Px\_OVTDIS can be locked individually for each pin by clearing the corresponding bit in GPIO\_Px\_PINLOCKN. When a bit in the GPIO\_Px\_PINLOCKN register is cleared, it will stay cleared until reset.

### 32.3.2 EM4 Wake-up

It is possible to trigger a wake-up from EM4 using any of the selectable EM4WU GPIO pins. The wake-up request can be triggered through the pins by enabling the corresponding bit in the GPIO\_EM4WUEN register. When EM4 wake-up is enabled for the pin, the input filter is enabled during EM4. This is done to avoid false wake-up caused by glitches. In addition, the polarity of the EM4 wake-up request can be selected using the GPIO\_EXTILEVEL register.




Figure 32.5. EM4 Wake-up Logic

The pins used for EM4 wake-up must be configured as inputs with glitch filters using the GPIO\_Px\_MODEL/GPIO\_Px\_MODEH register. If the input is disabled and the wakeup polarity is low, a false wakeup will occur when entering EM4. If the input is enabled, the glitch filtered is disabled, and the polarity is set low, a glitch will occur when going into EM4 that will cause an immediate wake-up. Before going down to EM4, it is important to clear the wake-up logic by setting the GPIO\_IFC bit, which clears the wake-up logic, including the GPIO\_IF register. It is possible to determine which pin caused the EM4WU by reading the GPIO\_IF register. The mapping between EM4WU pins and the bit indexes in the GPIO\_EM4WUEN, GPIO\_EXTILEVEL, GPIO\_IFC, GPIO\_IFS, GPIO\_IEN, and GPIO\_IF registers is as follows:

Table 32.2. EM4WU Register Bit Index to EM4WU Pin Mapping

EM4WU Register Bit Indexes	EM4WU Pin
16	GPIO_EM4WU0
17	GPIO_EM4WU1
18	GPIO_EM4WU2
19	GPIO_EM4WU3
...	...
31	GPIO_EM4WU15

**Note:** See the device data sheet for actual pin location

### 32.3.3 EM4 Retention

By default, GPIO pins revert back to their reset state when EM4 is entered. The GPIO pins can be configured to retain the settings for output enable, output value, pull enable, pull direction and over voltage tolerance while in EM4.

EM4 GPIO retention is controlled with the EM4IORETMODE field in the EMU\_EM4CTRL register. Setting EM4IORETMODE to EM4EXIT will cause retention to persist while in EM4 and reset the GPIOs during wakeup. Setting EM4IORETMODE to SWUNLATCH will cause the retention to persist until the EM4UNLATCH bit is written by software. Note that when using SWUNLATCH, the GPIO register values are still reset on wakeup from EM4. In order to ensure that the GPIO state does not change, software must re-write the GPIO registers before setting EM4UNLATCH and ending EM4 GPIO retention. See the EMU chapter for additional documentation on its registers and the EM4UNLATCH bit.

### 32.3.4 Alternate Functions

Alternate functions are connections to pins from peripherals, i.e. Timers, USARTs, etc.. These peripherals contain route registers, where the pin connections are enabled. In addition, the route registers contain a location bit field that configures which pin an output of that peripheral will be connected to if enabled. After connecting a peripheral, the pin configuration stays as set in GPIO\_Px\_MODEL, GPIO\_Px\_MODEH and GPIO\_Px\_DOUT registers. For example, the pin configuration must be set to output enable in GPIO\_Px\_MODEL or GPIO\_Px\_MODEH for a peripheral to be able to use the pin as an output.

It is not recommended to select two or more peripherals as output on the same pin. The reader is referred to the pin map section of the device data sheet for more information on the possible locations of each alternate function.

**Note:**

- Some of the alternate function locations have non-interference priority. These locations prevent the use of the selected pin for other alternate functions. For example, these can be used to secure TIMER PWM outputs from software errors (i.e. another alternate function enabled to the same pin inadvertently).
- Certain alternate functions have high speed priority locations. These locations ensure fastest possible paths to the pins which is useful for timing critical alternate functions. For the alternate function output signals which are using these locations the MODEn must be configured as PUSH/PULL or PUSH/PULLALT.
- An overview of these locations is provided in the pin map section of the device data sheet.

#### 32.3.4.1 Analog Connections

When using the GPIO pin for analog functionality, it is recommended to disable the over voltage tolerance by setting the corresponding pin in the GPIO\_Px\_OVTDIS register and setting the MODEn in GPIO\_Px\_MODEL or GPIO\_Px\_MODEH equal to DISABLE to disable the input sense, output driver and pull resistors.

#### 32.3.4.2 Debug Connections

##### 32.3.4.2.1 Serial Wire Debug Connection

The SW Debug Port is routed as an alternate function and the SWDIO and SWCLK pin connections are enabled by default with internal pull up and pull down resistors, respectively. It is possible to disable these pin connections (and disable the pull resistors) by setting the SWDIOTMSPEN and SWCLKTCKPEN bits in GPIO\_ROUTEOPEN to 0.

##### 32.3.4.2.2 JTAG Debug Connection

The JTAG Debug Port is routed as an alternate function and the TMS, TCK, TDO, and TDI pin connections are enabled by default with internal pull up, pull down, no pull, and pull up resistors, respectively. It is possible to disable these pin connections (and disable the pull resistors) by setting the SWDIOTMSPEN, SWCLKTCKPEN, TDOPEN, and TDIPEN bits in GPIO\_ROUTEOPEN to 0.

##### 32.3.4.2.3 Disabling Debug Connections


When the debug pins are disabled, the device can no longer be accessed by a debugger. A reset will set the debug pins back to their enabled default state. The GPIO\_ROUTEOPEN register can only be updated when the debugger is disconnected from the system. Any attempts to modify GPIO\_ROUTEOPEN when the debugger is connected will not occur. If you do disable the debug pins, make sure you have at least a 3 second timeout at the start of your program code before you disable the debug pins. This way the debugger will have time to connect to the device after a reset and before the pins are disabled.

### 32.3.5 Interrupt Generation

Interrupts may be triggered on edge events for any GPIO pin, or on pin input levels for GPIO capable of EM4 wake-up.

### 32.3.5.1 Edge Interrupt Generation

The GPIO can generate an interrupt from any edge of the input of any GPIO pin on the device. The edge interrupts have asynchronous sense capability, enabling wake-up from energy modes as low as EM3 Stop, see [Figure 32.6 Pin N Interrupt Generation on page 1138](#).



**Figure 32.6. Pin N Interrupt Generation**

External pin interrupts can be represented in the form of EXTI[index], where index is the external interrupt number. For example, the EXTI7 interrupt has an index of 7. All pins within a group of four (0-3,4-7,8-11,12-15) from all ports are grouped together to trigger one interrupt. The group of pins available to trigger an interrupt is determined by the interrupt index and calculated as  $\text{int}(\text{index}/4)$ . For example the first 4 interrupts (EXTI0 - EXTI3) are triggered by pins in the first group ( $Px[3:0]$ ) and the second 4 interrupts (EXTI4-EXTI7) are triggered by pins in the second group ( $Px[7:4]$ ).

The EXTIPSELn bits in GPIO\_EXTIPSELL or GPIO\_EXTIPSELH select which PORT in the group will trigger the interrupt. The EXTIPINSELn bits in GPIO\_EXTIPINSELL or GPIO\_EXTIPINSELH will determine which pin inside the selected group will trigger the interrupt.

For example if EXTIPSEL11 = PORTB and EXTPINSEL11 = 0 then PB8 will be used for EXTI11. EXTI11 uses the third group ( $11/4 = 2$ ) so the list of possible pins is  $Px[11:8]$ . The setting of EXTIPSEL11 further narrows the selection to PB[11:8]. Finally EXTPINSEL11 selects the first pin in that group which is PB8.

The GPIO\_EXTIRISE[n] and GPIO\_EXTIFALL[n] registers enable sensing of rising and falling edges. By setting the EXT[n] bit in GPIO\_IEN, a high interrupt flag n, will trigger one of two interrupt lines. The even interrupt line is triggered by any enabled even numbered interrupt flag index, while the odd interrupt line is triggered by odd flag indexes. The interrupt flags can be set and cleared by software when writing the GPIO\_IFS and GPIO\_IFC registers. Since the external interrupts are asynchronous, they are sensitive to noise. To increase noise tolerance, the MODEL and MODEH fields in the GPIO\_Px\_MODEL and GPIO\_Px\_MODEH registers, respectively, should be set to include glitch filtering for pins that have external interrupts enabled.

### 32.3.5.2 Level Interrupt Generation

GPIO can generate a level interrupt using the input of any GPIO EM4 wake-up pins on the device. The interrupts have asynchronous sense capability, enabling wake-up from energy modes as low as EM4.

In order to enable the level interrupt, set the EM4WU field in the GPIO\_IEN register and the EM4WUUn field in the GPIO\_EXTILEVEL register. Upon a level interrupt occurring, the corresponding EM4WU index in the GPIO\_IF register will be set along with the odd or even interrupt line depending on the index inside of GPIO\_IF. For example, by setting the EM4WU8 in GPIO\_EXTILEVEL and EM4WU[8] in GPIO\_IEN, the interrupt flag EM4WU[8] in GPIO\_IF will be triggered by a high level on pin EM4WU8 and a interrupt request will be sent on IRQ\_GPIO EVEN.

The wake-up granularity of the level interrupts is based on the settings of the EM4WU field in the GPIO\_IEN register and the EM4WUEN field in the GPIO\_EM4WUEN register, see [Table 32.3 Level Interrupt Energy Mode Wakeup on page 1139](#)

**Table 32.3. Level Interrupt Energy Mode Wakeup**

GPIO_IEN	GPIO_EM4WUEN	Energy Mode Wakeup
0	0	No Interrupt
0	1	EM4H,EM4S
1	0	EM1,EM2,EM3,EM4H,EM4S
1	1	EM1,EM2,EM3,EM4H,EM4S

### 32.3.6 Output to PRS

All pins within a group of four(0-3,4-7,8-11,12-15) from all ports are grouped together to form one PRS producer which outputs to the PRS. The pin from which the output should be taken is selected in the same fashion as the edge interrupts.

PRS output is not affected by the interrupt edge detection logic or gated by the IEN bits. See [Figure 32.6 Pin N Interrupt Generation on page 1138](#) for an illustration of where the PRS output signal is generated.

### 32.3.7 Synchronization

To avoid metastability in synchronous logic connected to the pins, all inputs are synchronized with double flip-flops. The flip-flops for the input data run on the HFBUSCLK. Consequently, when a pin changes state, the change will have propagated to GPIO\_Px\_DIN after two 2 HFBUSCLK cycles. Synchronization (also running on the HFBUSCLK) is also added for interrupt input. To save power when the external interrupts or level interrupts are not used, the synchronization flip-flops for these can be turned off by clearing INT or EM4WU, respectively, in GPIO\_INSENSE register.

### 32.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	GPIO_PA_CTRL	RW	Port Control Register
0x004	GPIO_PA_MODEL	RW	Port Pin Mode Low Register
0x008	GPIO_PA_MODEH	RW	Port Pin Mode High Register
0x00C	GPIO_PA_DOUT	RW	Port Data Out Register
0x018	GPIO_PA_DOUTTGL	W1	Port Data Out Toggle Register
0x01C	GPIO_PA_DIN	R	Port Data in Register
0x020	GPIO_PA_PINLOCKN	RW	Port Unlocked Pins Register
0x028	GPIO_PA_OVTDIS	RW	Over Voltage Disable for All Modes
...	GPIO_Px_CTRL	RW	Port Control Register
...	GPIO_Px_MODEL	RW	Port Pin Mode Low Register
...	GPIO_Px_MODEH	RW	Port Pin Mode High Register
...	GPIO_Px_DOUT	RW	Port Data Out Register
...	GPIO_Px_DOUTTGL	W1	Port Data Out Toggle Register
...	GPIO_Px_DIN	R	Port Data in Register
...	GPIO_Px_PINLOCKN	RW	Port Unlocked Pins Register
...	GPIO_Px_OVTDIS	RW	Over Voltage Disable for All Modes
0x210	GPIO_PL_CTRL	RW	Port Control Register
0x214	GPIO_PL_MODEL	RW	Port Pin Mode Low Register
0x218	GPIO_PL_MODEH	RW	Port Pin Mode High Register
0x21C	GPIO_PL_DOUT	RW	Port Data Out Register
0x228	GPIO_PL_DOUTTGL	W1	Port Data Out Toggle Register
0x22C	GPIO_PL_DIN	R	Port Data in Register
0x230	GPIO_PL_PINLOCKN	RW	Port Unlocked Pins Register
0x238	GPIO_PL_OVTDIS	RW	Over Voltage Disable for All Modes
0x400	GPIO_EXTIPSELL	RW	External Interrupt Port Select Low Register
0x404	GPIO_EXTIPSELH	RW	External Interrupt Port Select High Register
0x408	GPIO_EXTIPINSELL	RW	External Interrupt Pin Select Low Register
0x40C	GPIO_EXTIPINSELH	RW	External Interrupt Pin Select High Register
0x410	GPIO_EXTRIRISE	RW	External Interrupt Rising Edge Trigger Register
0x414	GPIO_EXTFALL	RW	External Interrupt Falling Edge Trigger Register
0x418	GPIO_EXITLEVEL	RW	External Interrupt Level Register
0x41C	GPIO_IF	R	Interrupt Flag Register
0x420	GPIO_IFS	W1	Interrupt Flag Set Register
0x424	GPIO_IFC	(R)W1	Interrupt Flag Clear Register
0x428	GPIO_IEN	RW	Interrupt Enable Register

Offset	Name	Type	Description
0x42C	GPIO_EM4WUEN	RW	EM4 Wake Up Enable Register
0x440	GPIO_ROUTEOPEN	RW	I/O Routing Pin Enable Register
0x450	GPIO_INSENSE	RW	Input Sense Register
0x454	GPIO_LOCK	RWH	Configuration Lock Register

## 32.5 Register Description

### 32.5.1 GPIO\_Px\_CTRL - Port Control Register

Offset	Bit Position																																			
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset				0																																
Access		RW								RW	0x5																									
Name	DINDISALT								SLEWRATEALT							DRIVESTRENGTHALT	RW	0															DRIVESTRENGTH	RW	0	0

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28	DINDISALT	0	RW	<b>Alternate Data in Disable</b>  Data input disable for port pins using alternate modes.
27:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	SLEWRATEALT	0x5	RW	<b>Alternate Slewrate Limit for Port</b>  Slewrate limit for port pins using alternate modes. Higher values represent faster slewrates.
19:17	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
16	DRIVESTRENGTH-ALT	0	RW	<b>Alternate Drive Strength for Port</b>  Drive strength setting for port pins using alternate drive strength.
	Value	Mode		Description
	0	STRONG		10 mA drive current
	1	WEAK		1 mA drive current
15:13	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
12	DINDIS	0	RW	<b>Data in Disable</b>  Data input disable for port pins not using alternate modes.
11:7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	SLEWRATE	0x5	RW	<b>Slewrate Limit for Port</b>  Slewrate limit for port pins not using alternate modes. Higher values represent faster slewrates.
3:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

Bit	Name	Reset	Access	Description
0	DRIVESTRENGTH	0	RW	<b>Drive Strength for Port</b>
Drive strength setting for port pins not using alternate modes.				
	Value	Mode		Description
	0	STRONG		10 mA drive current
	1	WEAK		1 mA drive current

## 32.5.2 GPIO\_Px\_MODEL - Port Pin Mode Low Register

Offset	Bit Position																	
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	
<b>Reset</b>		0x0					0x0						0x0					
<b>Access</b>	RW	RW			RW		RW			RW			RW		RW			
<b>Name</b>	MODE7		MODE6			MODE5			MODE4			MODE3		MODE2		MODE1		MODE0

Bit	Name	Reset	Access	Description
-----	------	-------	--------	-------------

31:28 MODE7 0x0 RW **Pin 7 Mode**

Configure mode for pin 7.

Value	Mode	Description
0	DISABLED	Input disabled. Pullup if DOUT is set.
1	INPUT	Input enabled. Filter if DOUT is set
2	INPUTPULL	Input enabled. DOUT determines pull direction
3	INPUTPULLFILTER	Input enabled with filter. DOUT determines pull direction
4	PUSHPULL	Push-pull output
5	PUSHPULLALT	Push-pull using alternate control
6	WIREDOR	Wired-or output
7	WIREDORPULLDOWN	Wired-or output with pull-down
8	WIREDAND	Open-drain output
9	WIREDANDFILTER	Open-drain output with filter
10	WIREDANDPULLUP	Open-drain output with pullup
11	WIREDANDPULLUP-FILTER	Open-drain output with filter and pullup
12	WIREDANDALT	Open-drain output using alternate control
13	WIREDANDALTFILTER	Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP	Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER	Open-drain output using alternate control with filter and pullup

27:24 MODE6 0x0 RW **Pin 6 Mode**

Configure mode for pin 6.

Value	Mode	Description
0	DISABLED	Input disabled. Pullup if DOUT is set.
1	INPUT	Input enabled. Filter if DOUT is set
2	INPUTPULL	Input enabled. DOUT determines pull direction
3	INPUTPULLFILTER	Input enabled with filter. DOUT determines pull direction

Bit	Name	Reset	Access	Description
4	PUSHPULL			Push-pull output
5	PUSHPULLALT			Push-pull using alternate control
6	WIREDOR			Wired-or output
7	WIREDORPULLDOWN			Wired-or output with pull-down
8	WIREDAND			Open-drain output
9	WIREDANDFILTER			Open-drain output with filter
10	WIREDANDPULLUP			Open-drain output with pullup
11	WIREDANDPULLUP-FILTER			Open-drain output with filter and pullup
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
23:20	MODE5	0x0	RW	<b>Pin 5 Mode</b>
				Configure mode for pin 5.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup

Bit	Name	Reset	Access	Description
19:16	MODE4	0x0	RW	<b>Pin 4 Mode</b>
Configure mode for pin 4.				
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup
15:12	MODE3	0x0	RW	<b>Pin 3 Mode</b>
Configure mode for pin 3.				
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup

Bit	Name	Reset	Access	Description
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
11:8	MODE2	0x0	RW	<b>Pin 2 Mode</b>
				Configure mode for pin 2.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup
7:4	MODE1	0x0	RW	<b>Pin 1 Mode</b>
				Configure mode for pin 1.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output

Bit	Name	Reset	Access	Description
7	WIREDORPULLDOWN			Wired-or output with pull-down
8	WIREDAND			Open-drain output
9	WIREDANDFILTER			Open-drain output with filter
10	WIREDANDPULLUP			Open-drain output with pullup
11	WIREDANDPULLUP-FILTER			Open-drain output with filter and pullup
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
3:0	MODE0	0x0	RW	<b>Pin 0 Mode</b>
				Configure mode for pin 0.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup

## 32.5.3 GPIO\_Px\_MODEH - Port Pin Mode High Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0				0x0				0x0				0x0				0x0				0x0				0x0							
Access	RW				RW				RW				RW				RW				RW				RW							
Name	MODE15				MODE14				MODE13				MODE12				MODE11				MODE10				MODE9				MODE8			

Bit	Name	Reset	Access	Description
31:28	MODE15	0x0	RW	<b>Pin 15 Mode</b>
Configure mode for pin 15.				
Value	Mode	Description		
0	DISABLED	Input disabled. Pullup if DOUT is set.		
1	INPUT	Input enabled. Filter if DOUT is set		
2	INPUTPULL	Input enabled. DOUT determines pull direction		
3	INPUTPULLFILTER	Input enabled with filter. DOUT determines pull direction		
4	PUSHPULL	Push-pull output		
5	PUSHPULLALT	Push-pull using alternate control		
6	WIREDOR	Wired-or output		
7	WIREDORPULLDOWN	Wired-or output with pull-down		
8	WIREDAND	Open-drain output		
9	WIREDANDFILTER	Open-drain output with filter		
10	WIREDANDPULLUP	Open-drain output with pullup		
11	WIREDANDPULLUP-FILTER	Open-drain output with filter and pullup		
12	WIREDANDALT	Open-drain output using alternate control		
13	WIREDANDALTFILTER	Open-drain output using alternate control with filter		
14	WIREDANDALTPULLUP	Open-drain output using alternate control with pullup		
15	WIREDANDALTPULLUPFILTER	Open-drain output using alternate control with filter and pullup		
27:24	MODE14	0x0	RW	<b>Pin 14 Mode</b>
Configure mode for pin 14.				
Value	Mode	Description		
0	DISABLED	Input disabled. Pullup if DOUT is set.		
1	INPUT	Input enabled. Filter if DOUT is set		
2	INPUTPULL	Input enabled. DOUT determines pull direction		
3	INPUTPULLFILTER	Input enabled with filter. DOUT determines pull direction		

Bit	Name	Reset	Access	Description
4	PUSHPULL			Push-pull output
5	PUSHPULLALT			Push-pull using alternate control
6	WIREDOR			Wired-or output
7	WIREDORPULLDOWN			Wired-or output with pull-down
8	WIREDAND			Open-drain output
9	WIREDANDFILTER			Open-drain output with filter
10	WIREDANDPULLUP			Open-drain output with pullup
11	WIREDANDPULLUP-FILTER			Open-drain output with filter and pullup
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
23:20	MODE13	0x0	RW	<b>Pin 13 Mode</b>
				Configure mode for pin 13.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup

Bit	Name	Reset	Access	Description
19:16	MODE12	0x0	RW	<b>Pin 12 Mode</b>
Configure mode for pin 12.				
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup
15:12	MODE11	0x0	RW	<b>Pin 11 Mode</b>
Configure mode for pin 11.				
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup

Bit	Name	Reset	Access	Description
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
11:8	MODE10	0x0	RW	<b>Pin 10 Mode</b>
				Configure mode for pin 10.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup
7:4	MODE9	0x0	RW	<b>Pin 9 Mode</b>
				Configure mode for pin 9.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output

Bit	Name	Reset	Access	Description
7	WIREDORPULLDOWN			Wired-or output with pull-down
8	WIREDAND			Open-drain output
9	WIREDANDFILTER			Open-drain output with filter
10	WIREDANDPULLUP			Open-drain output with pullup
11	WIREDANDPULLUP-FILTER			Open-drain output with filter and pullup
12	WIREDANDALT			Open-drain output using alternate control
13	WIREDANDALTFILTER			Open-drain output using alternate control with filter
14	WIREDANDALTPULL-UP			Open-drain output using alternate control with pullup
15	WIREDANDALTPUL-LUPFILTER			Open-drain output using alternate control with filter and pullup
3:0	MODE8	0x0	RW	<b>Pin 8 Mode</b>
				Configure mode for pin 8.
	Value	Mode		Description
	0	DISABLED		Input disabled. Pullup if DOUT is set.
	1	INPUT		Input enabled. Filter if DOUT is set
	2	INPUTPULL		Input enabled. DOUT determines pull direction
	3	INPUTPULLFILTER		Input enabled with filter. DOUT determines pull direction
	4	PUSHPULL		Push-pull output
	5	PUSHPULLALT		Push-pull using alternate control
	6	WIREDOR		Wired-or output
	7	WIREDORPULLDOWN		Wired-or output with pull-down
	8	WIREDAND		Open-drain output
	9	WIREDANDFILTER		Open-drain output with filter
	10	WIREDANDPULLUP		Open-drain output with pullup
	11	WIREDANDPULLUP-FILTER		Open-drain output with filter and pullup
	12	WIREDANDALT		Open-drain output using alternate control
	13	WIREDANDALTFILTER		Open-drain output using alternate control with filter
	14	WIREDANDALTPULL-UP		Open-drain output using alternate control with pullup
	15	WIREDANDALTPUL-LUPFILTER		Open-drain output using alternate control with filter and pullup

**32.5.4 GPIO\_Px\_DOUT - Port Data Out Register**

Offset	Bit Position																							
0x00C	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																							
<b>Reset</b>																								
<b>Access</b>																								
<b>Name</b>																								

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	DOUT	0x0000	RW	<b>Data Out</b>  Data output on pin.

**32.5.5 GPIO\_Px\_DOUTTGL - Port Data Out Toggle Register**

Offset	Bit Position																							
0x018	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																							
<b>Reset</b>																								
<b>Access</b>																								
<b>Name</b>																								

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	DOUTTGL	0x0000	W1	<b>Data Out Toggle</b>  Write bits to 1 to toggle corresponding bits in GPIO_Px_DOUT. Bits written to 0 will have no effect.

**32.5.6 GPIO\_Px\_DIN - Port Data in Register**

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x0000							
<b>Access</b>																									R							
<b>Name</b>																									DIN							

Bit	Name	Reset	Access	Description
31:16	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	DIN	0x0000	R	<b>Data in</b>  Port data input.

**32.5.7 GPIO\_Px\_PINLOCKN - Port Unlocked Pins Register**

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0xFFFF							
<b>Access</b>																									RW							
<b>Name</b>																									PINLOCKN							

Bit	Name	Reset	Access	Description
31:16	<i>Reserved</i>			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	PINLOCKN	0xFFFF	RW	<b>Unlocked Pins</b>  Shows unlocked pins in the port. To lock pin n, clear bit n. The pin is then locked until reset.

## 32.5.8 GPIO\_Px\_OVTDIS - Over Voltage Disable for All Modes

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0000															
Access																	RW															
Name																	OVTDIS															

Bit	Name	Reset	Access	Description
31:16	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>		
15:0	OVTDIS	0x0000	RW	<b>Disable Over Voltage Capability</b>  Disabling the Over Voltage capability will provide less distortion on analog inputs.

## 32.5.9 GPIO\_EXTIPSELL - External Interrupt Port Select Low Register

Offset	Bit Position																																				
0x400	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0					
Reset		0x0	RW																																		
Access																																					
Name	EXTIPSEL7																																				
	EXTIPSEL6																																				
	EXTIPSEL5																																				
	EXTIPSEL4																																				
	EXTIPSEL3																																				
	EXTIPSEL2																																				
	EXTIPSEL1																																				
	EXTIPSEL0																																				

Bit	Name	Reset	Access	Description																					
31:28	EXTIPSEL7	0x0	RW	<b>External Interrupt 7 Port Select</b>  Select input port for external interrupt 7.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td><td>PORTA</td><td>Port A group selected for external interrupt 7</td></tr> <tr> <td>1</td><td>PORTB</td><td>Port B group selected for external interrupt 7</td></tr> <tr> <td>2</td><td>PORTC</td><td>Port C group selected for external interrupt 7</td></tr> <tr> <td>3</td><td>PORTD</td><td>Port D group selected for external interrupt 7</td></tr> <tr> <td>4</td><td>PORTE</td><td>Port E group selected for external interrupt 7</td></tr> <tr> <td>5</td><td>PORTF</td><td>Port F group selected for external interrupt 7</td></tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 7	1	PORTB	Port B group selected for external interrupt 7	2	PORTC	Port C group selected for external interrupt 7	3	PORTD	Port D group selected for external interrupt 7	4	PORTE	Port E group selected for external interrupt 7	5	PORTF	Port F group selected for external interrupt 7
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 7																							
1	PORTB	Port B group selected for external interrupt 7																							
2	PORTC	Port C group selected for external interrupt 7																							
3	PORTD	Port D group selected for external interrupt 7																							
4	PORTE	Port E group selected for external interrupt 7																							
5	PORTF	Port F group selected for external interrupt 7																							
27:24	EXTIPSEL6	0x0	RW	<b>External Interrupt 6 Port Select</b>  Select input port for external interrupt 6.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td><td>PORTA</td><td>Port A group selected for external interrupt 6</td></tr> <tr> <td>1</td><td>PORTB</td><td>Port B group selected for external interrupt 6</td></tr> <tr> <td>2</td><td>PORTC</td><td>Port C group selected for external interrupt 6</td></tr> <tr> <td>3</td><td>PORTD</td><td>Port D group selected for external interrupt 6</td></tr> <tr> <td>4</td><td>PORTE</td><td>Port E group selected for external interrupt 6</td></tr> <tr> <td>5</td><td>PORTF</td><td>Port F group selected for external interrupt 6</td></tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 6	1	PORTB	Port B group selected for external interrupt 6	2	PORTC	Port C group selected for external interrupt 6	3	PORTD	Port D group selected for external interrupt 6	4	PORTE	Port E group selected for external interrupt 6	5	PORTF	Port F group selected for external interrupt 6
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 6																							
1	PORTB	Port B group selected for external interrupt 6																							
2	PORTC	Port C group selected for external interrupt 6																							
3	PORTD	Port D group selected for external interrupt 6																							
4	PORTE	Port E group selected for external interrupt 6																							
5	PORTF	Port F group selected for external interrupt 6																							
23:20	EXTIPSEL5	0x0	RW	<b>External Interrupt 5 Port Select</b>  Select input port for external interrupt 5.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td><td>PORTA</td><td>Port A group selected for external interrupt 5</td></tr> <tr> <td>1</td><td>PORTB</td><td>Port B group selected for external interrupt 5</td></tr> <tr> <td>2</td><td>PORTC</td><td>Port C group selected for external interrupt 5</td></tr> <tr> <td>3</td><td>PORTD</td><td>Port D group selected for external interrupt 5</td></tr> <tr> <td>4</td><td>PORTE</td><td>Port E group selected for external interrupt 5</td></tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 5	1	PORTB	Port B group selected for external interrupt 5	2	PORTC	Port C group selected for external interrupt 5	3	PORTD	Port D group selected for external interrupt 5	4	PORTE	Port E group selected for external interrupt 5			
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 5																							
1	PORTB	Port B group selected for external interrupt 5																							
2	PORTC	Port C group selected for external interrupt 5																							
3	PORTD	Port D group selected for external interrupt 5																							
4	PORTE	Port E group selected for external interrupt 5																							

Bit	Name	Reset	Access	Description
	5	PORTF		Port F group selected for external interrupt 5
19:16	EXTIPSEL4	0x0	RW	<b>External Interrupt 4 Port Select</b>
				Select input port for external interrupt 4.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 4
	1	PORTB		Port B group selected for external interrupt 4
	2	PORTC		Port C group selected for external interrupt 4
	3	PORTD		Port D group selected for external interrupt 4
	4	PORTE		Port E group selected for external interrupt 4
	5	PORTF		Port F group selected for external interrupt 4
15:12	EXTIPSEL3	0x0	RW	<b>External Interrupt 3 Port Select</b>
				Select input port for external interrupt 3.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 3
	1	PORTB		Port B group selected for external interrupt 3
	2	PORTC		Port C group selected for external interrupt 3
	3	PORTD		Port D group selected for external interrupt 3
	4	PORTE		Port E group selected for external interrupt 3
	5	PORTF		Port F group selected for external interrupt 3
11:8	EXTIPSEL2	0x0	RW	<b>External Interrupt 2 Port Select</b>
				Select input port for external interrupt 2.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 2
	1	PORTB		Port B group selected for external interrupt 2
	2	PORTC		Port C group selected for external interrupt 2
	3	PORTD		Port D group selected for external interrupt 2
	4	PORTE		Port E group selected for external interrupt 2
	5	PORTF		Port F group selected for external interrupt 2
7:4	EXTIPSEL1	0x0	RW	<b>External Interrupt 1 Port Select</b>
				Select input port for external interrupt 1.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 1
	1	PORTB		Port B group selected for external interrupt 1
	2	PORTC		Port C group selected for external interrupt 1
	3	PORTD		Port D group selected for external interrupt 1

Bit	Name	Reset	Access	Description
	4	PORTE		Port E group selected for external interrupt 1
	5	PORTF		Port F group selected for external interrupt 1
3:0	EXTIPSEL0	0x0	RW	<b>External Interrupt 0 Port Select</b>
				Select input port for external interrupt 0.
Value	Mode			Description
0	PORTA			Port A group selected for external interrupt 0
1	PORTB			Port B group selected for external interrupt 0
2	PORTC			Port C group selected for external interrupt 0
3	PORTD			Port D group selected for external interrupt 0
4	PORTE			Port E group selected for external interrupt 0
5	PORTF			Port F group selected for external interrupt 0

## 32.5.10 GPIO\_EXTIPSELH - External Interrupt Port Select High Register

Offset	Bit Position																
0x404	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15
<b>Reset</b>		0x0															
<b>Access</b>	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW
<b>Name</b>	EXTIPSEL15	EXTIPSEL14	EXTIPSEL13	EXTIPSEL12	EXTIPSEL11	EXTIPSEL10	EXTIPSEL9	EXTIPSEL8									

Bit	Name	Reset	Access	Description																					
31:28	EXTIPSEL15	0x0	RW	<b>External Interrupt 15 Port Select</b>  Select input port for external interrupt 15.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PORTA</td> <td>Port A group selected for external interrupt 15</td> </tr> <tr> <td>1</td> <td>PORTB</td> <td>Port B group selected for external interrupt 15</td> </tr> <tr> <td>2</td> <td>PORTC</td> <td>Port C group selected for external interrupt 15</td> </tr> <tr> <td>3</td> <td>PORTD</td> <td>Port D group selected for external interrupt 15</td> </tr> <tr> <td>4</td> <td>PORTE</td> <td>Port E group selected for external interrupt 15</td> </tr> <tr> <td>5</td> <td>PORTF</td> <td>Port F group selected for external interrupt 15</td> </tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 15	1	PORTB	Port B group selected for external interrupt 15	2	PORTC	Port C group selected for external interrupt 15	3	PORTD	Port D group selected for external interrupt 15	4	PORTE	Port E group selected for external interrupt 15	5	PORTF	Port F group selected for external interrupt 15
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 15																							
1	PORTB	Port B group selected for external interrupt 15																							
2	PORTC	Port C group selected for external interrupt 15																							
3	PORTD	Port D group selected for external interrupt 15																							
4	PORTE	Port E group selected for external interrupt 15																							
5	PORTF	Port F group selected for external interrupt 15																							
27:24	EXTIPSEL14	0x0	RW	<b>External Interrupt 14 Port Select</b>  Select input port for external interrupt 14.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PORTA</td> <td>Port A group selected for external interrupt 14</td> </tr> <tr> <td>1</td> <td>PORTB</td> <td>Port B group selected for external interrupt 14</td> </tr> <tr> <td>2</td> <td>PORTC</td> <td>Port C group selected for external interrupt 14</td> </tr> <tr> <td>3</td> <td>PORTD</td> <td>Port D group selected for external interrupt 14</td> </tr> <tr> <td>4</td> <td>PORTE</td> <td>Port E group selected for external interrupt 14</td> </tr> <tr> <td>5</td> <td>PORTF</td> <td>Port F group selected for external interrupt 14</td> </tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 14	1	PORTB	Port B group selected for external interrupt 14	2	PORTC	Port C group selected for external interrupt 14	3	PORTD	Port D group selected for external interrupt 14	4	PORTE	Port E group selected for external interrupt 14	5	PORTF	Port F group selected for external interrupt 14
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 14																							
1	PORTB	Port B group selected for external interrupt 14																							
2	PORTC	Port C group selected for external interrupt 14																							
3	PORTD	Port D group selected for external interrupt 14																							
4	PORTE	Port E group selected for external interrupt 14																							
5	PORTF	Port F group selected for external interrupt 14																							
23:20	EXTIPSEL13	0x0	RW	<b>External Interrupt 13 Port Select</b>  Select input port for external interrupt 13.																					
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PORTA</td> <td>Port A group selected for external interrupt 13</td> </tr> <tr> <td>1</td> <td>PORTB</td> <td>Port B group selected for external interrupt 13</td> </tr> <tr> <td>2</td> <td>PORTC</td> <td>Port C group selected for external interrupt 13</td> </tr> <tr> <td>3</td> <td>PORTD</td> <td>Port D group selected for external interrupt 13</td> </tr> <tr> <td>4</td> <td>PORTE</td> <td>Port E group selected for external interrupt 13</td> </tr> </tbody> </table>	Value	Mode	Description	0	PORTA	Port A group selected for external interrupt 13	1	PORTB	Port B group selected for external interrupt 13	2	PORTC	Port C group selected for external interrupt 13	3	PORTD	Port D group selected for external interrupt 13	4	PORTE	Port E group selected for external interrupt 13			
Value	Mode	Description																							
0	PORTA	Port A group selected for external interrupt 13																							
1	PORTB	Port B group selected for external interrupt 13																							
2	PORTC	Port C group selected for external interrupt 13																							
3	PORTD	Port D group selected for external interrupt 13																							
4	PORTE	Port E group selected for external interrupt 13																							

Bit	Name	Reset	Access	Description
	5	PORTF		Port F group selected for external interrupt 13
19:16	EXTIPSEL12	0x0	RW	<b>External Interrupt 12 Port Select</b>
				Select input port for external interrupt 12.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 12
	1	PORTB		Port B group selected for external interrupt 12
	2	PORTC		Port C group selected for external interrupt 12
	3	PORTD		Port D group selected for external interrupt 12
	4	PORTE		Port E group selected for external interrupt 12
	5	PORTF		Port F group selected for external interrupt 12
15:12	EXTIPSEL11	0x0	RW	<b>External Interrupt 11 Port Select</b>
				Select input port for external interrupt 11.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 11
	1	PORTB		Port B group selected for external interrupt 11
	2	PORTC		Port C group selected for external interrupt 11
	3	PORTD		Port D group selected for external interrupt 11
	4	PORTE		Port E group selected for external interrupt 11
	5	PORTF		Port F group selected for external interrupt 11
11:8	EXTIPSEL10	0x0	RW	<b>External Interrupt 10 Port Select</b>
				Select input port for external interrupt 10.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 10
	1	PORTB		Port B group selected for external interrupt 10
	2	PORTC		Port C group selected for external interrupt 10
	3	PORTD		Port D group selected for external interrupt 10
	4	PORTE		Port E group selected for external interrupt 10
	5	PORTF		Port F group selected for external interrupt 10
7:4	EXTIPSEL9	0x0	RW	<b>External Interrupt 9 Port Select</b>
				Select input port for external interrupt 9.
	Value	Mode		Description
	0	PORTA		Port A group selected for external interrupt 9
	1	PORTB		Port B group selected for external interrupt 9
	2	PORTC		Port C group selected for external interrupt 9
	3	PORTD		Port D group selected for external interrupt 9

Bit	Name	Reset	Access	Description
4	PORTE			Port E group selected for external interrupt 9
5	PORTF			Port F group selected for external interrupt 9
3:0	EXTIPSEL8	0x0	RW	<b>External Interrupt 8 Port Select</b>
	Select input port for external interrupt 8.			
Value	Mode			Description
0	PORTA			Port A group selected for external interrupt 8
1	PORTB			Port B group selected for external interrupt 8
2	PORTC			Port C group selected for external interrupt 8
3	PORTD			Port D group selected for external interrupt 8
4	PORTE			Port E group selected for external interrupt 8
5	PORTF			Port F group selected for external interrupt 8

## 32.5.11 GPIO\_EXTIPINSELL - External Interrupt Pin Select Low Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Access	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW	RW		
Name	EXTIPINSEL7	EXTIPINSEL6	EXTIPINSEL5	EXTIPINSEL4	EXTIPINSEL3	EXTIPINSEL2	EXTIPINSEL1	EXTIPINSEL0																								

Bit	Name	Reset	Access	Description															
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
29:28	EXTIPINSEL7	0x3	RW	<b>External Interrupt 7 Pin Select</b>  Select the pin for external interrupt 7.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN4</td> <td>Pin 4</td> </tr> <tr> <td>1</td> <td>PIN5</td> <td>Pin 5</td> </tr> <tr> <td>2</td> <td>PIN6</td> <td>Pin 6</td> </tr> <tr> <td>3</td> <td>PIN7</td> <td>Pin 7</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN4	Pin 4	1	PIN5	Pin 5	2	PIN6	Pin 6	3	PIN7	Pin 7
Value	Mode	Description																	
0	PIN4	Pin 4																	
1	PIN5	Pin 5																	
2	PIN6	Pin 6																	
3	PIN7	Pin 7																	
27:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
25:24	EXTIPINSEL6	0x2	RW	<b>External Interrupt 6 Pin Select</b>  Select the pin for external interrupt 6.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN4</td> <td>Pin 4</td> </tr> <tr> <td>1</td> <td>PIN5</td> <td>Pin 5</td> </tr> <tr> <td>2</td> <td>PIN6</td> <td>Pin 6</td> </tr> <tr> <td>3</td> <td>PIN7</td> <td>Pin 7</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN4	Pin 4	1	PIN5	Pin 5	2	PIN6	Pin 6	3	PIN7	Pin 7
Value	Mode	Description																	
0	PIN4	Pin 4																	
1	PIN5	Pin 5																	
2	PIN6	Pin 6																	
3	PIN7	Pin 7																	
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
21:20	EXTIPINSEL5	0x1	RW	<b>External Interrupt 5 Pin Select</b>  Select the pin for external interrupt 5.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN4</td> <td>Pin 4</td> </tr> <tr> <td>1</td> <td>PIN5</td> <td>Pin 5</td> </tr> <tr> <td>2</td> <td>PIN6</td> <td>Pin 6</td> </tr> <tr> <td>3</td> <td>PIN7</td> <td>Pin 7</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN4	Pin 4	1	PIN5	Pin 5	2	PIN6	Pin 6	3	PIN7	Pin 7
Value	Mode	Description																	
0	PIN4	Pin 4																	
1	PIN5	Pin 5																	
2	PIN6	Pin 6																	
3	PIN7	Pin 7																	

Bit	Name	Reset	Access	Description															
19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
17:16	EXTIPINSEL4	0x0	RW	<b>External Interrupt 4 Pin Select</b>  Select the pin for external interrupt 4.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN4</td><td>Pin 4</td></tr> <tr> <td>1</td><td>PIN5</td><td>Pin 5</td></tr> <tr> <td>2</td><td>PIN6</td><td>Pin 6</td></tr> <tr> <td>3</td><td>PIN7</td><td>Pin 7</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN4	Pin 4	1	PIN5	Pin 5	2	PIN6	Pin 6	3	PIN7	Pin 7
Value	Mode	Description																	
0	PIN4	Pin 4																	
1	PIN5	Pin 5																	
2	PIN6	Pin 6																	
3	PIN7	Pin 7																	
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
13:12	EXTIPINSEL3	0x3	RW	<b>External Interrupt 3 Pin Select</b>  Select the pin for external interrupt 3.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN0</td><td>Pin 0</td></tr> <tr> <td>1</td><td>PIN1</td><td>Pin 1</td></tr> <tr> <td>2</td><td>PIN2</td><td>Pin 2</td></tr> <tr> <td>3</td><td>PIN3</td><td>Pin 3</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN0	Pin 0	1	PIN1	Pin 1	2	PIN2	Pin 2	3	PIN3	Pin 3
Value	Mode	Description																	
0	PIN0	Pin 0																	
1	PIN1	Pin 1																	
2	PIN2	Pin 2																	
3	PIN3	Pin 3																	
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
9:8	EXTIPINSEL2	0x2	RW	<b>External Interrupt 2 Pin Select</b>  Select the pin for external interrupt 2.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN0</td><td>Pin 0</td></tr> <tr> <td>1</td><td>PIN1</td><td>Pin 1</td></tr> <tr> <td>2</td><td>PIN2</td><td>Pin 2</td></tr> <tr> <td>3</td><td>PIN3</td><td>Pin 3</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN0	Pin 0	1	PIN1	Pin 1	2	PIN2	Pin 2	3	PIN3	Pin 3
Value	Mode	Description																	
0	PIN0	Pin 0																	
1	PIN1	Pin 1																	
2	PIN2	Pin 2																	
3	PIN3	Pin 3																	
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
5:4	EXTIPINSEL1	0x1	RW	<b>External Interrupt 1 Pin Select</b>  Select the pin for external interrupt 1.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN0</td><td>Pin 0</td></tr> <tr> <td>1</td><td>PIN1</td><td>Pin 1</td></tr> <tr> <td>2</td><td>PIN2</td><td>Pin 2</td></tr> <tr> <td>3</td><td>PIN3</td><td>Pin 3</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN0	Pin 0	1	PIN1	Pin 1	2	PIN2	Pin 2	3	PIN3	Pin 3
Value	Mode	Description																	
0	PIN0	Pin 0																	
1	PIN1	Pin 1																	
2	PIN2	Pin 2																	
3	PIN3	Pin 3																	

Bit	Name	Reset	Access	Description
3:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	EXTIPINSEL0	0x0	RW	<b>External Interrupt 0 Pin Select</b>  Select the pin for external interrupt 0.

---

Value	Mode	Description
0	PIN0	Pin 0
1	PIN1	Pin 1
2	PIN2	Pin 2
3	PIN3	Pin 3

## 32.5.12 GPIO\_EXTIPINSELH - External Interrupt Pin Select High Register

Offset	Bit Position																															
0x40C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description															
31:30	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
29:28	EXTIPINSEL15	0x3	RW	<b>External Interrupt 15 Pin Select</b>  Select the pin for external interrupt 15.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN12</td> <td>Pin 12</td> </tr> <tr> <td>1</td> <td>PIN13</td> <td>Pin 13</td> </tr> <tr> <td>2</td> <td>PIN14</td> <td>Pin 14</td> </tr> <tr> <td>3</td> <td>PIN15</td> <td>Pin 15</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN12	Pin 12	1	PIN13	Pin 13	2	PIN14	Pin 14	3	PIN15	Pin 15
Value	Mode	Description																	
0	PIN12	Pin 12																	
1	PIN13	Pin 13																	
2	PIN14	Pin 14																	
3	PIN15	Pin 15																	
27:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
25:24	EXTIPINSEL14	0x2	RW	<b>External Interrupt 14 Pin Select</b>  Select the pin for external interrupt 14.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN12</td> <td>Pin 12</td> </tr> <tr> <td>1</td> <td>PIN13</td> <td>Pin 13</td> </tr> <tr> <td>2</td> <td>PIN14</td> <td>Pin 14</td> </tr> <tr> <td>3</td> <td>PIN15</td> <td>Pin 15</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN12	Pin 12	1	PIN13	Pin 13	2	PIN14	Pin 14	3	PIN15	Pin 15
Value	Mode	Description																	
0	PIN12	Pin 12																	
1	PIN13	Pin 13																	
2	PIN14	Pin 14																	
3	PIN15	Pin 15																	
23:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
21:20	EXTIPINSEL13	0x1	RW	<b>External Interrupt 13 Pin Select</b>  Select the pin for external interrupt 13.															
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PIN12</td> <td>Pin 12</td> </tr> <tr> <td>1</td> <td>PIN13</td> <td>Pin 13</td> </tr> <tr> <td>2</td> <td>PIN14</td> <td>Pin 14</td> </tr> <tr> <td>3</td> <td>PIN15</td> <td>Pin 15</td> </tr> </tbody> </table>	Value	Mode	Description	0	PIN12	Pin 12	1	PIN13	Pin 13	2	PIN14	Pin 14	3	PIN15	Pin 15
Value	Mode	Description																	
0	PIN12	Pin 12																	
1	PIN13	Pin 13																	
2	PIN14	Pin 14																	
3	PIN15	Pin 15																	

Bit	Name	Reset	Access	Description															
19:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
17:16	EXTIPINSEL12	0x0	RW	<b>External Interrupt 12 Pin Select</b>  Select the pin for external interrupt 12.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN12</td><td>Pin 12</td></tr> <tr> <td>1</td><td>PIN13</td><td>Pin 13</td></tr> <tr> <td>2</td><td>PIN14</td><td>Pin 14</td></tr> <tr> <td>3</td><td>PIN15</td><td>Pin 15</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN12	Pin 12	1	PIN13	Pin 13	2	PIN14	Pin 14	3	PIN15	Pin 15
Value	Mode	Description																	
0	PIN12	Pin 12																	
1	PIN13	Pin 13																	
2	PIN14	Pin 14																	
3	PIN15	Pin 15																	
15:14	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
13:12	EXTIPINSEL11	0x3	RW	<b>External Interrupt 11 Pin Select</b>  Select the pin for external interrupt 11.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN8</td><td>Pin 8</td></tr> <tr> <td>1</td><td>PIN9</td><td>Pin 9</td></tr> <tr> <td>2</td><td>PIN10</td><td>Pin 10</td></tr> <tr> <td>3</td><td>PIN11</td><td>Pin 11</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN8	Pin 8	1	PIN9	Pin 9	2	PIN10	Pin 10	3	PIN11	Pin 11
Value	Mode	Description																	
0	PIN8	Pin 8																	
1	PIN9	Pin 9																	
2	PIN10	Pin 10																	
3	PIN11	Pin 11																	
11:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
9:8	EXTIPINSEL10	0x2	RW	<b>External Interrupt 10 Pin Select</b>  Select the pin for external interrupt 10.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN8</td><td>Pin 8</td></tr> <tr> <td>1</td><td>PIN9</td><td>Pin 9</td></tr> <tr> <td>2</td><td>PIN10</td><td>Pin 10</td></tr> <tr> <td>3</td><td>PIN11</td><td>Pin 11</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN8	Pin 8	1	PIN9	Pin 9	2	PIN10	Pin 10	3	PIN11	Pin 11
Value	Mode	Description																	
0	PIN8	Pin 8																	
1	PIN9	Pin 9																	
2	PIN10	Pin 10																	
3	PIN11	Pin 11																	
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
5:4	EXTIPINSEL9	0x1	RW	<b>External Interrupt 9 Pin Select</b>  Select the pin for external interrupt 9.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>PIN8</td><td>Pin 8</td></tr> <tr> <td>1</td><td>PIN9</td><td>Pin 9</td></tr> <tr> <td>2</td><td>PIN10</td><td>Pin 10</td></tr> <tr> <td>3</td><td>PIN11</td><td>Pin 11</td></tr> </tbody> </table>	Value	Mode	Description	0	PIN8	Pin 8	1	PIN9	Pin 9	2	PIN10	Pin 10	3	PIN11	Pin 11
Value	Mode	Description																	
0	PIN8	Pin 8																	
1	PIN9	Pin 9																	
2	PIN10	Pin 10																	
3	PIN11	Pin 11																	

Bit	Name	Reset	Access	Description
3:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1:0	EXTIPINSEL8	0x0	RW	<b>External Interrupt 8 Pin Select</b>
				Select the pin for external interrupt 8.
Value	Mode			Description
0	PIN8			Pin 8
1	PIN9			Pin 9
2	PIN10			Pin 10
3	PIN11			Pin 11

### 32.5.13 GPIO\_EXTIRISE - External Interrupt Rising Edge Trigger Register

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
15:0	EXTIRISE	0x0000	RW	<b>External Interrupt N Rising Edge Trigger Enable</b>
Set bit n to enable triggering of external interrupt n on rising edge.				
<hr/>		<hr/>		
Value		Description		
<hr/>		<hr/>		
EXTIRISE[n] = 0		Rising edge trigger disabled		
<hr/>		<hr/>		
EXTIRISE[n] = 1		Rising edge trigger enabled		
<hr/>		<hr/>		

## 32.5.14 GPIO\_EXTIFALL - External Interrupt Falling Edge Trigger Register

Offset	Bit Position																															
0x414	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																															
Access																																
Name																																

Bit	Name	Reset	Access	Description						
31:16	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>								
15:0	EXTIFALL	0x0000	RW	<b>External Interrupt N Falling Edge Trigger Enable</b>						
Set bit n to enable triggering of external interrupt n on falling edge.										
<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>EXTIFALL[n] = 0</td> <td>Falling edge trigger disabled</td> </tr> <tr> <td>EXTIFALL[n] = 1</td> <td>Falling edge trigger enabled</td> </tr> </tbody> </table>					Value	Description	EXTIFALL[n] = 0	Falling edge trigger disabled	EXTIFALL[n] = 1	Falling edge trigger enabled
Value	Description									
EXTIFALL[n] = 0	Falling edge trigger disabled									
EXTIFALL[n] = 1	Falling edge trigger enabled									

## 32.5.15 GPIO\_EXTILEVEL - External Interrupt Level Register

Offset	Bit Position																															
0x418	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:26	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
25	EM4WU9	0	RW	<b>EM4 Wake Up Level for EM4WU9 Pin</b>
24	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
23	EM4WU7	0	RW	<b>EM4 Wake Up Level for EM4WU7 Pin</b>
22	EM4WU6	0	RW	<b>EM4 Wake Up Level for EM4WU6 Pin</b>
21	EM4WU5	0	RW	<b>EM4 Wake Up Level for EM4WU5 Pin</b>
20	EM4WU4	0	RW	<b>EM4 Wake Up Level for EM4WU4 Pin</b>
19	EM4WU3	0	RW	<b>EM4 Wake Up Level for EM4WU3 Pin</b>
18	EM4WU2	0	RW	<b>EM4 Wake Up Level for EM4WU2 Pin</b>
17	EM4WU1	0	RW	<b>EM4 Wake Up Level for EM4WU1 Pin</b>
16	EM4WU0	0	RW	<b>EM4 Wake Up Level for EM4WU0 Pin</b>
15:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

**32.5.16 GPIO\_IF - Interrupt Flag Register**

Offset	Bit Position																																						
0x41C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0							
Reset	0x0000																0x0000																						
Access	R																R																						
Name	EM4WU																EXT																						
Bit	Name	Reset	Access	Description																																			
31:16	EM4WU	0x0000	R	<b>EM4 Wake Up Pin Interrupt Flag</b>																																			
	EM4 wake up Pin Interrupt flag.																																						
	Value	Description																																					
	0	Interrupt flag cleared																																					
	1	Interrupt flag set																																					
15:0	EXT	0x0000	R	<b>External Pin Interrupt Flag</b>																																			
	Pin n external interrupt flag.																																						
	Value	Description																																					
	0	External interrupt flag cleared																																					
	1	External interrupt flag set																																					

**32.5.17 GPIO\_IFS - Interrupt Flag Set Register**

Offset	Bit Position																																		
0x420	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset	0x0000																0x0000																		
Access	W1																W1																		
Name	EM4WU																EXT																		
Bit	Name	Reset	Access	Description																															
31:16	EM4WU	0x0000	W1	<b>Set EM4WU Interrupt Flag</b>																															
	Write 1 to set the EM4WU interrupt flag																																		
15:0	EXT	0x0000	W1	<b>Set EXT Interrupt Flag</b>																															
	Write 1 to set the EXT interrupt flag																																		

**32.5.18 GPIO\_IFC - Interrupt Flag Clear Register**

Offset	Bit Position																															
0x424	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																0x0000															
Access	(R)W1																(R)W1															
Name	EM4WU																EXT															

Bit	Name	Reset	Access	Description
31:16	EM4WU	0x0000	(R)W1	<b>Clear EM4WU Interrupt Flag</b>
				Write 1 to clear the EM4WU interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).
15:0	EXT	0x0000	(R)W1	<b>Clear EXT Interrupt Flag</b>
				Write 1 to clear the EXT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

**32.5.19 GPIO\_IEN - Interrupt Enable Register**

Offset	Bit Position																															
0x428	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																0x0000															
Access	RW																RW															
Name	EM4WU																EXT															

Bit	Name	Reset	Access	Description
31:16	EM4WU	0x0000	RW	<b>EM4WU Interrupt Enable</b>
				Enable/disable the EM4WU interrupt
15:0	EXT	0x0000	RW	<b>EXT Interrupt Enable</b>
				Enable/disable the EXT interrupt

## 32.5.20 GPIO\_EM4WUEN - EM4 Wake Up Enable Register

Offset	Bit Position																															
0x42C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																															
Access	RW																															
Name	EM4WUEN																															

Bit	Name	Reset	Access	Description						
31:16	EM4WUEN	0x0000	RW	<b>EM4 Wake Up Enable</b>						
Write 1 to enable EM4 wake up request, write 0 to disable EM4 wake up request.										
<table border="1"> <thead> <tr> <th>Value</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Disable EM4 wake up on pin</td> </tr> <tr> <td>1</td> <td>Enable EM4 wake up on pin</td> </tr> </tbody> </table>					Value	Description	0	Disable EM4 wake up on pin	1	Enable EM4 wake up on pin
Value	Description									
0	Disable EM4 wake up on pin									
1	Enable EM4 wake up on pin									
15:0	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>								

## 32.5.21 GPIO\_ROUTEPEN - I/O Routing Pin Enable Register

Offset	Bit Position																															
0x440	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	TDIPEN	1	RW	<b>JTAG Test Debug Input Pin Enable</b>  Enable JTAG TDI connection to pin.
2	TDOPEN	1	RW	<b>JTAG Test Debug Output Pin Enable</b>  Enable JTAG TDO connection to pin.
1	SWDIOTMSPEN	1	RW	<b>Serial Wire Data and JTAG Test Mode Select Pin Enable</b>  Enable Serial Wire Data and JTAG Test Mode Select connection to pin. <b>WARNING:</b> When this pin is disabled, the device can no longer be accessed by a debugger. A reset will set the pin back to a default state as enabled. If you disable this pin, make sure you have at least a 3 second timeout at the start of your program code before you disable the pin. This way, the debugger will have time to halt the device after a reset before the pin is disabled.
0	SWCLKTCKPEN	1	RW	<b>Serial Wire Clock and JTAG Test Clock Pin Enable</b>  Enable Serial Wire and JTAG Clock connection to pin. <b>WARNING:</b> When this pin is disabled, the device can no longer be accessed by a debugger. A reset will set the pin back to a default state as enabled. If you disable this pin, make sure you have at least a 3 second timeout at the start of your program code before you disable the pin. This way, the debugger will have time to halt the device after a reset before the pin is disabled.

### 32.5.22 GPIO\_INSENSE - Input Sense Register

Bit	Name	Reset	Access	Description
31:2	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
1	EM4WU	1	RW	<b>EM4WU Interrupt Sense Enable</b>
		Set this bit to enable input sensing for EM4WU interrupts.		
0	INT	1	RW	<b>Interrupt Sense Enable</b>
		Set this bit to enable input sensing for interrupts.		

## 32.5.23 GPIO\_LOCK - Configuration Lock Register

Offset	Bit Position																															
0x454	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																													0x0000			
Access																													RWH			
Name																													LOCKKEY			



Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

15:0    LOCKKEY    0x0000    RWH    **Configuration Lock Key**

Write any other value than the unlock code to lock MODEL, MODEH, CTRL, PINLOCKN, OVTDIS, EXTIPSELL, EXTIPSELH, EXTIGSELL, EXTIGSELH, INSENSE, ROUTEPEN, and ROUTELOC0 from editing. Write the unlock code to unlock. When reading the register, bit 0 is set when the lock is enabled.

Mode	Value	Description
<b>Read Operation</b>		
UNLOCKED	0	GPIO registers are unlocked
LOCKED	1	GPIO registers are locked
<b>Write Operation</b>		
LOCK	0	Lock GPIO registers
UNLOCK	0xA534	Unlock GPIO registers

## 33. APORT - Analog Port



### Quick Facts

#### What?

The Analog Port (APORT) is a set of analog buses which are used to connect I/O pins to analog peripheral signals.

#### Why?

The APORT gives on-chip analog resources access to a large number of I/O pins, and provides the system designer with a high degree of routing flexibility.

#### How?

An analog peripheral requests a pad by simply configuring its input/output to use a channel on APORT. That selection becomes an APORT request where the APORT control switches the pad and the analog signal onto a common bus.


### 33.1 Introduction

APORT consists of wires, switches, and control logic needed to route signals between analog peripherals and I/O pins. On-chip clients can be either producers or consumers. Analog producers are active devices that drive current/voltage into an APORT, such as current or voltage DACs. Consumers are passive devices that monitor or react to the current/voltage routed to them via the APORT, such as ADCs or analog comparators (ACMP).

### 33.2 Features

- Pins are typically mapped to two different APORT buses
- Arbitration and conflict status provided to each APORT client

### 33.3 Functional Description



**Figure 33.1. Analog Bus (ABUS)**

An analog bus (ABUS) consists of analog switches connected to a common wire as shown in [Figure 33.1 Analog Bus \(ABUS\) on page 1178](#). An APORt consists of multiple ABUSes. Since many clients can operate differentially, buses are grouped by pairs as X and Y. If a given client uses a single ABUS (e.g. single-ended ADC), X and Y are just labels to differentiate the two buses.

When operating differentially, most APORt clients require that one input be chosen from an X bus and the other from a Y bus. For example, the ACMP block will not allow both positive and negative inputs to be chosen from X buses.

#### 33.3.1 I/O Pin Considerations

For external analog signals routed through the APORt, the maximum supported analog I/O voltage will typically be limited to the  $\text{MIN}(\text{V}_{\text{ANALOGSUPPLY}}, \text{IOVDD})$  (where  $\text{V}_{\text{ANALOGSUPPLY}}$  is the supply pin powering the analog module). Practically, this means that if  $\text{IOVDD}=1.8$  V, the maximum supported analog IO voltage on APORt-routed signals will be limited to 1.8 V, regardless of the analog module supply voltage.

## 33.3.2 APORT ABUS Naming





Figure 33.2. Conceptual APORT Structure

APORT ABUSES are prefixed with "BUS" and are grouped in pairs. Each pair is uniquely identified using a letter prefix ("A", "B", "C", etc.) followed by either a "X" or "Y" to identify the ABUS in the pair. For example, "BUSDX" decodes as: "BUS"=ABUS, "D"=pair, "X"=bus. [Figure 33.2 Conceptual APORT Structure on page 1179](#) illustrates this organization.

APORT clients are generally described once in this reference manual regardless of its number of instances. For example, the ACMP client is described once, but the device could contain multiple instances of the ACMP. Because of this, for APORT client descriptions in this reference manual, the ABUS connections are generalized with the prefix "APORT" followed by a number (instead of the "BUS"

followed by a letter). It is possible that different instances of an APORT client connect to different ABUSes. For example, ACMP0 APORT1X might connect to the ABUS BUSAX while ACMP1 APORT1X might connect to ABUS BUSCX. Refer to the APORT Client Map in the device data sheet to map the generalized APORT client bus name to an actual device ABUS. A given ABUS has multiple switches which need to be identified. The switches on a bus are specified with the ABUS connection ID followed by a channel ID. For example, channel switch 7 on a given APORT client might be given as APORT1XCH7. Not all APORT channels map to actual GPIO. Refer to the APORT Client Maps in the device data sheet for APORT to GPIO mapping.



**Figure 33.3. Detailed APORT Structure**

Figure 33.3 Detailed APORT Structure on page 1180 shows all the possible routes between different peripherals and different pins via APORT BUS for the largest package of the EFM32TG11 device family. Note that, in the figure, the BUSxX and BUSxY are annotated as xX and xY, where x=A,B,C,D and the APORTrnX and APORTrnY are annotated as nX and nY, where n=1,2,3,4.

For example, the VDAC0\_OUT0 APORT output 4Y can be routed to pin PF2 through BUSDY. The configuration required for this routing is as follows:

- Set VDAC0\_OPA0\_OUT\_APORROUTSEL = APORTR4YCH18. This selects the VDAC0/OPA0 APORT output 4Y and pin PF2.

- Set VDAC0\_OPA0\_OUT\_APOROUTEN = 1 and VDAC0\_OPA0\_OUT\_APOROUTENPRS = 0. This enables the VDAC to ungate its output to BUSDY.

Another example, when ADC is configured to operate in single channel mode for differential inputs (see [27.3.3.1 Single Channel Mode](#) for how to configure ADC in single channel mode), the positive ADC APOR input 2X and the negative ADC APOR input 2Y can be routed to pin PB5 and PB6 via USBX and USBY respectively with the following configuration:

- Set ADCn\_SINGLECTRL\_POSSEL = APOR2XCH21. This selects the pin PB5 for the positive input to the ADC.
- Set ADCn\_SINGLECTRL\_NEGSEL = APOR2YCH22. This selects the pin PB6 for the negative input to the ADC.


For smaller packages, not all GPIO pins are available. See the pinout sections of the device data sheet for pin availability on a specific device.

### 33.3.3 Managing ABUSes

The ABUSes of an APORT are shared resources. The user needs to be mindful of this in assigning I/O for different clients throughout the chip, as it is possible to have conflicts for a given ABUS. Each ABUS has an arbiter responsible for limiting the control over the ABUS to one and only one client. If multiple clients attempt to control an ABUS, the arbiter allows no client control over the ABUS and asserts a conflict signal to the clients. The user has the ability to check for such a conflict in each client's status, as well as generate an interrupt.

Having only one client control an ABUS is not the same as having only one user of an ABUS. It is possible for multiple clients to access a single ABUS, but requires all but one client to relinquish control of the ABUS. To do this, some clients have bits to disable bus mastership which are 0 by default. One example is the APORTEXMASTERDIS bit in the ACMPn\_CTRL. When set to 1, the client will not assert control of the APORT X BUS switches, but may still connect to an APORT X BUS that is controlled by another client.


For example, the ADC and ACMP both want to use the same pin on a particular ABUS the user might set the bus master disable bit to 1 for the ACMP. The ADC is the sole master of the switch configuration on that ABUS, so switches are configured using the configuration set in the ADC. When the ACMP channel is chosen on that same bus, the actual pin connection is dictated by the ADC settings for that bus.



**Figure 33.4. APORT Example 1**

[Figure 33.4 APORT Example 1 on page 1182](#) illustrates the sharing of APORT. For illustration purposes, each ABUS is identified by a numeric index (instead of BUSAX, BUSAY, BUSBX, etc.). Also, the requests from all the APORT clients are packed into a bit-vector named APORT\_REQ to illustrate the request from the APORT Clients (instead of by name such as APORT1XREQ, APORT1YREQ, APORT2XREQ, etc.). In [Figure 33.4 APORT Example 1 on page 1182](#), ABUS and client are the same color if the client has been granted the ABUS.

In [Figure 33.4 APORT Example 1 on page 1182](#) ADC0 has requested ABUS[3:0], ACMP1 has requested ABUS[5:4], ACMP0 has requested ABUS[7], and ABUS[6] is unused. No APORT Client has requested the same ABUS as another, so there is no conflict.

**Figure 33.5. APOR CONTROL Example 2: Bus Conflict**

In Figure 33.5 APOR CONTROL Example 2: Bus Conflict on page 1183 is a similar example to Figure 33.4 APOR CONTROL Example 1 on page 1182, but now both ACMP0 and ACMP1 are requesting ABUS[4]. This is a configuration error, so APOR grants neither client ABUS[4]. The user must resolve the conflict before ABUS[4] is useable.




**Figure 33.6. APOR CONTROL Example 3: Sharing an ABUS**

Figure 33.6 APOR CONTROL Example 3: Sharing an ABUS on page 1183 illustrates ABUS sharing. Both ACMPs are configured identically, except ACMP0 has its APORTXMASTERDIS bit-field set to 1. There is only one APOR master for ABUS[5:4] in this case, so there is no conflict.

## 34. CSEN - Capacitive Sense Module



### Quick Facts

#### What?

The capacitive sense (CSEN) module uses a capacitance-to-digital circuit to measure the capacitance of touch-sensitive switches. The module contains an advanced capacitance-to-digital converter that can be configured to take measurements on a single port pin or scan through a group of up to 64 port pins connected via the APORTE buses. Port pins/channels can also be shorted together internally to measure the combined capacitance, lowering the required energy usage for wake-on-touch applications. Adjustable maximum capacitance allows for optimal dynamic range, while hardware accumulation and filtering reduce processor computation time. Interrupts can be generated when CSEN completes conversions or when the measured value crosses a threshold.

#### Why?

The CSEN module is designed to perform extremely low-power autonomous conversions of capacitive touch switches.

#### How?

The CSEN module uses charge timing techniques to compare external capacitance against internal reference capacitors.

### 34.1 Introduction

The capacitive sensing (CSEN) module uses a capacitance-to-digital circuit to determine the capacitance on an input pin. The module can take measurements from different physical pins using the APORTE multiplexer. In addition, the module can measure multiple pins in sequence using the scan modes, or multiple pins at the same time (bonded together) using the multiple-channel measurement feature. CSEN is available in EM0, EM1, EM2 and EM3.




Figure 34.1. CSEN Overview

## 34.2 Features

- Up to 64 Channels, connected via APORT buses.
- Single sample, continuous single sample, single scan and continuous scan modes supported.
- Support for both SAR and Delta Modulation conversions.
  - SAR conversions are programmable to resolutions of 10, 12, 14, or 16 bits.
  - Delta Modulation conversions support dynamic or fixed gain, and are programmable to resolutions of 10, 12, 14, or 16 bits.
- Supports channel bonding to monitor multiple channels, shorted internally, with a single conversion. The maximum number of channels to be shorted is limited by the maximum capacitance that can be measured by the analog core.
- Conversions triggered by software, PRS, or dedicated timer running from LFXO, LFRCO, or ULFRCO.
- Hardware accumulation of 1, 2, 4, 8, 16, 32, or 64 samples. The result can be right-shifted to the desired resolution or collected in a 22-bit accumulator for further processing by software.
- Hardware exponential moving average (EMA) filter for candidate touch detection during low power autonomous operation.
- Automatic threshold comparison with programmable polarity.
- Low-frequency noise filter to reject noise sources such as 50/60 Hz.
- DMA interface to collect accumulated samples in on-chip RAM. The DMA interface can also be used to program starting values for delta-modulation conversions. The DMA interface can run down to EM2.

## 34.3 Timing

Conversion timing for the CSEN block is flexible, with access to several clocks and conversion trigger sources.

### 34.3.1 Clocks

The CSEN module takes two external clock sources as input. The register interface is driven by the HFPERCLK source, allowing for fast access to the control and data for the block. The local timer is driven by the LFBCLK source. The CSEN block also contains an internal, low-energy conversion clock source ( $\text{CLK}_{\text{CSEN}}$ ). Conversions are self-timed and the block only requires external clocks under certain circumstances.

For register access,  $\text{HFPERCLK}_{\text{CSEN}}$  must be enabled to the CSEN block in the CMU\_HFPERCLKEN0 register. When register access is not required, this clock may be shut down for energy savings.

$\text{LFBCLK}_{\text{CSEN}}$  is used by the local CSEN timer. It should be enabled to the CSEN block in the CMU\_LFBCLKEN0 register any time the CSEN local timer is used as a conversion trigger.

### 34.3.2 Conversion Triggers

CSEN conversions can be triggered from one of three different sources, selected by CTRL\_STM: a software register write, a PRS channel, or the local CSEN timer. The selected trigger source begins a conversion cycle. Depending on the selected conversion mode, one conversion trigger may generate one or many output words from the CSEN module. See [34.6 Conversion Modes](#) for more details on the CSEN output for each mode.

#### Software Triggered Conversions

When CTRL\_STM is set to START, conversions are triggered by software. Software triggering is typically used when operating the CSEN block in a continuous mode to gather conversions as quickly as the converter allows. Software triggering may also be used in applications where a single conversion or one scan cycle is needed infrequently and sporadically by different software processes. When configured for software triggering, a write of the CMD\_START bit to logic 1 initiates conversions.

#### PRS Triggered Conversions

When CTRL\_STM is set to PRS, conversions are triggered via a PRS event. PRS triggers are typically used when it is necessary to synchronize CSEN conversions with other events in the system. For example, the LETIMER may be used in EM2 to initiate a CSEN scan operation and other events at the same time. A number of different PRS channels may be configured as the trigger source. The specific PRS channel to be used as a trigger source is selected in the PRSSEL register.

## CSEN Timer Triggered Conversions

When CTRL\_STM is set to TIMER, a local 8-bit CSEN timer is used to trigger conversions. The local timer is typically used in conjunction with non-continuous conversion modes to provide periodic conversion triggers at slow sampling rates. The local timer is clocked from LFBCLK<sub>CSEN</sub>, and configured with the TIMCTRL register. The CSEN timer has a local prescaler (set by the TIMCTRL\_PCPRESC field), which divides the LFBCLK<sub>CSEN</sub> further. The TIMCTRL\_PCTOP field sets the reload value for the CSEN timer. The CSEN timer counts down for the number of clocks specified in TIMCTRL\_PCTOP. When the counter reaches zero, a conversion cycle is triggered and the timer is reloaded.

### 34.3.3 Shutdown and Warmup

Many target applications for CSEN require low power operation and infrequent sampling. By default, the converter will power down when it is not in use to save energy. Upon receiving a conversion trigger, the CSEN block will power on and wait for (3 + TIMCTRL\_WARMPCNT) CLK<sub>CSEN</sub> clock cycles before starting conversions.

CTRL\_WARMUPMODE defines the behavior of the CSEN converter when it is not actively converting. Software may choose to keep the CSEN block powered on at all times by setting the CTRL\_WARMUPMODE bit to logic 1.

## 34.4 Conversion Types

The CSEN block offers two different types of conversions: SAR, and Delta Modulation.

### 34.4.1 SAR Conversion Type

SAR (successive approximation register) conversions are self-contained and do not depend on the results of any previous conversions. SAR conversions will be performed when CTRL\_CONVSEL is set to SAR. CTRL\_SARCR sets the SAR conversion resolution, and is selectable between 10, 12, 14, or 16 bits. SAR conversions last for N cycles of CLK<sub>CSEN</sub>, where N is the selected resolution (i.e. 12-bit conversions last for 12 CLK<sub>CSEN</sub> cycles).

Every SAR conversion consists of a set of tests, one for each bit of the converter. The MSB is tested first, followed by all other bits down to the LSB. Each test narrows the possible value by 1/2 until the final result is determined.


### 34.4.2 Delta Modulation Conversion Type

Delta modulation (DM) conversions provide significant noise, response time, and energy consumption improvements over SAR conversions. A DM conversion inherently takes longer than a SAR conversion to arrive at one result. However, it is much less susceptible to noise events in the system. Whereas a large number of SAR conversions may need to be averaged to produce a desired noise resolution, the same noise resolution can be achieved with few DM conversions. However, DM conversions require more specific knowledge of the underlying conversion process to implement effectively. Silicon Laboratories software libraries use delta modulation for the best possible performance. It is recommended to use the provided libraries in most applications. The information provided in this section is intended as a reference for CSEN module driver development.


Delta modulation conversions are performed when CTRL\_CONVSEL is set to DM. DMCFG\_DMCR sets the DM conversion resolution, and is selectable between 10, 12, 14, or 16 bits. The selected resolution does not have an impact on conversion timing.

A delta modulated conversion begins with a test against a provided initial value, known as the baseline. If the comparison is high (the external capacitor is larger than the initial value), the comparison value is increased by a specified amount (the delta). If the comparison is low, the comparison value is decreased by the delta. The cycle then repeats, testing against the new value. Each subsequent test brings the test value closer to the external capacitance value, until the desired number of tests have been performed and an output result is produced. The converter may be configured to use a fixed delta value, or to reduce the value by a factor of two at specific intervals.

The DM state machine is configured using different fields in the DMCFG register. The DMG field sets the initial delta step to be used, between 0 and 255 codes at the selected resolution (specified by DMCFG\_CRMODE). The DMCFG\_DMR field specifies how many tests in a row are to be performed using each delta step. The converter will perform  $(4 \times \text{DMCFG\_DMR})$  tests at each delta step for  $\text{DMCFG\_DMR} > 0$ . For  $\text{DMCFG\_DMR} = 0$ , the converter will perform 64 tests at each delta step. The number of tests performed at each delta step is referred to here as a "cycle". The DMCFG\_DMCR field specifies how many cycles the state machine will take to produce one conversion output. For  $\text{DMCFG\_DMCR} = 0$ , the number of cycles will be 16. If the DMCFG\_DMGRDIS bit is cleared to 0, the delta step will be halved after each cycle. If DMCFG\_DMGRDIS is set to 1, all cycles will use a fixed delta step value. Each test performed by the converter requires one  $\text{CLK}_{\text{CSEN}}$ , and so a full DM conversion requires  $\text{number\_of\_cycles} \times \text{tests\_per\_cycle}$  clocks of  $\text{CLK}_{\text{CSEN}}$ . [Figure 34.2 Delta Modulation Conversion With Gain Reduction \(DMCFG\\_DMGRDIS = 0\) on page 1187](#) and [Figure 34.3 Delta Modulation Conversion With Fixed Delta Step \(DMCFG\\_DMGRDIS = 1\) on page 1188](#) show how delta modulation conversions are performed with and without gain reduction.



**Figure 34.2. Delta Modulation Conversion With Gain Reduction (DMCFG\_DMGRDIS = 0)**



**Figure 34.3. Delta Modulation Conversion With Fixed Delta Step (DMCFG\_DMGDIS = 1)**

The initial test value (baseline) for a DM conversion can be written to the DMBASELINE register prior to the start of the conversion. DMBASELINE contains two fields: BASELINEUP and BASELINEDN. Only the BASELINEUP field is used when chopping is disabled (CTRL\_CHOPEN = 0). If chopping is enabled, software must maintain a second baseline value for the ramp-down phase, and write it to BASELINEDN.

### 34.5 Input Configuration

CSEN channel inputs are routed through the on-chip APORt bus matrix. Each APORt bus is a shared resource among certain analog peripherals on the device. Some knowledge of how the CSEN block utilizes the APORt buses is necessary to avoid conflicts with other peripherals.

Each time the CSEN module connects to an external pin to take a conversion, it uses one or two of the shared APORt buses. By default, the CSEN module charges the external capacitor through one APORt connection on the CEXT line, and senses the voltage at the capacitor through a different APORt connection on the CEXT\_SENSE line. This eliminates any errors introduced by series impedance of the APORt buses, particularly if the external capacitance is large. To conserve on-chip resources, it is possible to both charge and sense through the CEXT line, by setting CTRL\_LOCALSENS to logic 1. When CTRL\_LOCALSENS is set to 1, the CEXT\_SENSE line is not needed and the corresponding bus may be used by other peripherals.

The CSEN module has four APORt buses connected to the CEXT signal and four APORt buses connected to the CEXT\_SENSE signal. The specific buses used for each pin selection depend on the channel, according to [Table 34.1 CSEN APORt Bus Connectivity on page 1189](#). For example, if APORt1XCH4 (APORt1 channel 4) is selected in SINGLECTRL\_SINGLESEL, the CEXT signal will be connected to the shared BUSAX, channel 4. If CTRL\_LOCALSENS is set to DISABLE, then the CEXT\_SENSE signal will be connected to APORt2YCH4, and use the shared bus BUSBY, channel 4.

The same connections apply to scan mode conversions and bonded conversions. For scan mode conversions, the connection through the bus is only made on one channel at a time, when that channel is being converted in the scan. For bonded connections, all selected channel connections are made simultaneously.

**Table 34.1. CSEN APORt Bus Connectivity**

Selected CSEN Channel	CEXT Routing	CEXT_SENSE Routing (LOCALSENS = 0)
APORt1, Even Channel	APORt1XCHn / BUSAXCHn	APORt2YCHn / BUSBYCHn
APORt1, Odd Channel	APORt1YCHn / BUSAYCHn	APORt2XCHn / BUSBXCHn
APORt3, Even Channel	APORt3XCHn / BUSCXCHn	APORt4YCHn / BUSDYCHn
APORt3, Odd Channel	APORt3YCHn / BUSCYCHn	APORt4XCHn / BUSDXCHn

When the CSEN module requests an APORt bus that is already in use by another peripheral, an APORt conflict will occur. The IF\_APORtCONFLICT interrupt flag will be set to 1 (generating an interrupt if enabled), and the APORtCONFLICT register will reflect the bus(es) where the conflict occurred. Careful channel planning for the system will avoid APORt conflicts in most systems.

Channel selection for the CSEN module depends on the selected conversion mode. More details on how to select specific input pins are found in [34.6 Conversion Modes](#).

### 34.6 Conversion Modes

The CSEN module supports several conversion modes:

- Single Channel - A conversion trigger starts conversions on a single channel. One output result is produced, then the converter will halt.
- Scan - A conversion trigger starts a scan sequence, which converts a specified number of channels independently and in sequence. One output result is produced per channel, then the converter will halt.
- Bonded Channel - A conversion trigger starts conversions on a bonded channel. A bonded channel is several input channels which are shorted together internally. One output result is produced, then the converter will halt.
- Continuous Single Channel - A conversion trigger starts continuous conversions on a single channel. The single channel conversion will re-trigger automatically after each output result and repeat until halted.
- Continuous Scan - A conversion trigger starts continuous channel scanning. The scan sequence will re-trigger automatically at the end of each scan and repeat until halted.
- Continuous Bonded Channel - A conversion trigger starts continuous conversions on a bonded channel. The bonded channel conversion will re-trigger automatically after each output result and repeat until halted.

The conversion mode is selected by the CTRL\_CM and CTRL\_MCEN fields. Refer to [34.6.1 Single Channel Conversions](#), [34.6.2 Scan Conversions](#), and [34.6.3 Bonded Channel Conversions](#) for specific information on configuring the CSEN module to the desired conversion mode.

### 34.6.1 Single Channel Conversions

CSEN is configured for single channel mode when CTRL\_MCEN = DISABLE and CTRL\_CM = SGL. For continuous single channel mode, CTRL\_MCEN = DISABLE and CTRL\_CM = CONTSGL.

In single channel mode, SINGLECTRL\_SINGLESEL specifies the input channel to be converted. Firmware may select any of the pins connected to the CEXT signal via the APORt. Refer to the Analog Port (APORT) Client Maps section in the product data sheet for mapping of the CEXT signal to specific pins.

When a single channel conversion is triggered, the CSEN block will use the configured conversion type (SAR or DM) to convert the capacitance seen at the selected input pin to a digital value one or more times. The hardware accumulator setting (CTRL\_ACU) determines how many times the input pin will be sampled and accumulated before an output word is produced. The IF\_CONV interrupt flag will be set to 1 by hardware when an output word is available in the DATA register.

**Note:** The auto-ground feature is typically not used in single channel conversion mode and should be disabled by software. However, if auto-grounding is enabled, it will ground the unused channels specified by the SCANINPUTSEL0/1 and SCANMASKSEL0/1 registers. See the channel selection discussion in [34.6.2 Scan Conversions](#) for more details.

### 34.6.2 Scan Conversions

CSEN is configured for scan mode when CTRL\_MCEN = DISABLE and CTRL\_CM = SCAN. For continuous scan mode, CTRL\_MCEN = DISABLE and CTRL\_CM = CONTSCAN.

In scan mode, the input channels to be converted during the scan are determined by the SCANINPUTSEL0/1 and SCANMASK0/1 registers. There are 64 available channels in the scanner logic. SCANINPUTSEL0/1 allow software to route CSEN scan channels to APORt-capable GPIO in groups of 8. SCANMASK0/1 specify which channels on those groups are to be included in the scan.

**Note:** It is possible to include the same group of 8 in more than one place in the scan sequence. However, for the majority of use cases, the SCANINPUTSEL0 register should be written to 0x07060504, and SCANINPUTSEL1 should be written to 0x0F0E0D0C. This will configure the CSEN scan channels to match their order in bonded mode.

Individual channels are included in the scan based on their bit positions in the mask registers, SCANMASK0 and SCANMASK1. A '1' in the corresponding bit of the mask register will include that channel in the scan. Refer to the Analog Port (APORT) Client Maps section in the product data sheet for mapping of the CEXT signal to specific pins.

When a scan conversion is triggered, the CSEN block will convert each of the selected channels in turn, starting at channel 0 and working up to channel 63. If a channel is not configured for scan in the SCANMASK0/1 register (i.e. the bit for that channel is '0'), it will be skipped.

An example of how the scan logic progresses through channels is shown in [Figure 34.4 Scan Mode Sequencing on page 1191](#). In this simple example, SCANMASK0 = 0x00000318 and SCANMASK1 = 0x00000006, which selects channels 3, 4, 8, 9, 33, and 34 in turn.

	SCANMASK Values	CSEN Input Channel	DATA Output Order
0	0	0	Channel 3
1	0	1	Channel 4
2	0	2	Channel 8
3	1	3	Channel 9
4	1	4	Channel 33
5	0	5	Channel 34
6	0	6	
7	0	7	
8	1	8	
9	1	9	
10	0	10	
11	0	11	
12	0	12	
13	0	13	
...	...	...	
27	0	27	
28	0	28	
29	0	29	
30	0	30	
31	0	31	
	0	32	
0	1	33	
1	1	34	
2	0	35	
3	0	36	
...	...	...	
27	0	59	
28	0	60	
29	0	61	
30	0	62	
31	0	63	

**Figure 34.4. Scan Mode Sequencing**

An auto-grounding feature is available for scan mode conversions. This feature forces hardware to ground all of the non-active CSEN channels selected by SCANMASK0/1, to reduce bleed-through from measurements on other CSEN channels. Auto-grounding is enabled by setting the CTRL\_AUTOGND bit to logic 1.

CSEN will use the configured conversion type (SAR or DM) to convert the capacitance seen at each of the selected input pins to a digital value one or more times. The hardware accumulator setting (CTRL\_ACU) determines how many times each input pin will be sampled and accumulated before an output word is produced. The IF\_CONV interrupt flag will be set to 1 by hardware when each output word is available in the DATA register, and the IF\_EOS interrupt flag will be set to 1 by hardware at the completion of a scan cycle.

The DMBASELINE register provides the starting point for DM conversions. This starting point will be different for each channel in the scan, and the DMBASELINE register should be updated accordingly. This is typically done via DMA.

**Note:** DMA or software must read the output words from the DATA register before completion of the next conversion. New conversions will over-write the DATA register contents.

### 34.6.3 Bonded Channel Conversions

CSEN is configured for bonded mode when CTRL\_MCEN = ENABLE and CTRL\_CM = SGL. For continuous bonded mode, CTRL\_MCEN = ENABLE and CTRL\_CM = CONTSGL.

Bonded channel conversions are intended primarily for wake-on-touch applications where minimal power consumption is necessary. Bonded channel conversions operate similar to single channel conversions, except that multiple channels are shorted together and converted as a single capacitance value.

In bonded mode, the channels to be bonded are based on their bit positions in the mask registers SCANMASK0 and SCANMASK1, according to a fixed location, as shown in [Figure 34.5 CSEN Input Configuration in Bonded Mode on page 1192](#). SCANMASK0 selects channels from APOR1 and SCANMASK1 selects channels from APOR3. Even-numbered channels are connected through the X bus, and odd-numbered channels are connected through the Y bus. Channels with a '1' in the corresponding position of SCANMASK0/1 will be shorted together during the conversion and converted as a single channel. Refer to the Analog Port (APORT) Client Maps section in the product data sheet for mapping of the CEXT signal to specific pins.

	CSEN Input Channel	APORT Connection	Shared Bus Channel		CSEN Input Channel	APORT Connection	Shared Bus Channel
SCANMASK0	0	APORT1XCH0	BUSAX channel 0		32	APORT3XCH0	BUSCX channel 0
	1	APORT1YCH1	BUSAY channel 1		33	APORT3YCH1	BUSCY channel 1
	2	APORT1XCH2	BUSAX channel 2		34	APORT3XCH2	BUSCX channel 2
	3	APORT1YCH3	BUSAX channel 3		35	APORT3YCH3	BUSCX channel 3
	4	APORT1XCH4	BUSAY channel 4		36	APORT3XCH4	BUSCY channel 4
	..	..	..		..	..	..
	..	..	..		..	..	..
	..	..	..		..	..	..
	27	APORT1YCH27	BUSAY channel 27		59	APORT3YCH27	BUSCY channel 27
	28	APORT1XCH28	BUSAX channel 28		60	APORT3XCH28	BUSCX channel 28
	29	APORT1YCH29	BUSAY channel 29		61	APORT3YCH29	BUSCY channel 29
	30	APORT1XCH30	BUSAX channel 30		62	APORT3XCH30	BUSCX channel 30
	31	APORT1YCH31	BUSAY channel 31		63	APORT3YCH31	BUSCY channel 31

**Figure 34.5. CSEN Input Configuration in Bonded Mode**

When a bonded conversion is triggered, the CSEN block will use the configured conversion type (SAR or DM) to convert the total capacitance seen at the selected input pins to a digital value one or more times. The hardware accumulator setting (CTRL\_ACU) determines how many times the input pins will be sampled and accumulated before an output word is produced. The IF\_CONV interrupt flag will be set to 1 by hardware when an output word is available in the DATA register.

**Note:** The auto-ground feature should not be used in bonded conversion mode. Software should clear CTRL\_AUTOGND to 0 when configuring CSEN for bonded conversions.

### 34.7 Output Data

Output data from the CSEN module is posted to the DATA register. The data encoding can be affected by several configuration settings.

[Figure 34.6 Data Encoding for Different Resolution Settings on page 1193](#) shows the effect that the resolution settings (CTRL\_SARCR for SAR conversions or DMCFG\_CRMODE for DM conversions) have on the output word. In this example, only one sample is accumulated. Regardless of the resolution setting, the MSB is always presented in bit position 15.

CSEN_DATA Register																															
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

**Figure 34.6. Data Encoding for Different Resolution Settings**


A hardware accumulator allows the CSEN block to accumulate multiple samples on the same channel for each conversion data word produced, and automatically right-shift to normalize the data to 16 bits. This is effective as a simple noise filter. The CTRL\_ACU field sets the number of samples to be accumulated from 1, 2, 4, 8, 16, 32, or 64 samples. The right-shift operation can optionally be disabled by setting CTRL\_DRSF to 1. [Figure 34.7 Data Encoding for Different Accumulator Settings on page 1193](#) shows the effects of the accumulator, with and without right-shifting on the output data word. In this example, the sample resolution is fixed at 12 bits, but the same principles apply to any resolution setting.

CSEN_DATA Register																															
31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
When DRSF = 0, accumulation extends LSB																															
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
When DRSF = 1, accumulation extends MSB																															
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	

**Figure 34.7. Data Encoding for Different Accumulator Settings**

When the conversion type is delta modulation (CTRL\_CONVSEL = DM) and chopping is enabled (CTRL\_CHOPEN = ENABLE), this is a special case for the output word. In this case, both the "up" and the "down" portions of the conversion must be stored. The DATA

register will hold the "up" portion in the lower 16 bits and the "down" portion in the upper 16 bits as shown in [Figure 34.8 Data Encoding for Delta Modulation With Chopping on page 1194](#).



**Figure 34.8. Data Encoding for Delta Modulation With Chopping**

### 34.8 Low Frequency Noise Filter (Chopping)

The CSEN module includes a low-frequency noise filter, which is implemented internally using a chopping mechanism. Chopping is enabled by setting CTRL\_CHOPEN to ENABLE. In a normal conversion cycle (CTRL\_CHOPEN = DISABLE), the charge timing is always performed on a positive (up) ramp. When chopping is enabled, the converter will alternate between using a positive (up) and negative (down) ramp for each sample. While the absolute capacitance value contributes the same amount for an up or a down conversion, any low-frequency offset artifacts due to supply changes will have opposite polarity. Averaging the results of an "up" and a "down" conversion taken back-to-back effectively eliminates the low-frequency offset differences.

When chopping is used with SAR type conversions, the accumulator performs the necessary averaging in hardware. The accumulator must be set to average at least two samples when chopping is enabled. Because the accumulator always works on multiples of two samples, an even number of "up" and "down" samples will be included in the average.

When chopping is used with DM type conversions, user software must maintain both an "up" and "down" portion of the baseline for the conversion separately. For this reason, the output word will contain both values when using DM conversions. In order to gain the benefits of chopping in DM mode, software should average the "up" and "down" results together.

### 34.9 Wake on Threshold and Exponential Moving Average

The CSEN module has the capability to operate in the energy-efficient EM2 or EM3 modes and autonomously wake the system when a predetermined threshold is crossed, either while doing single channel conversions or bonded channel conversions. This allows a system to monitor one or more input channels to implement low-energy "wait-for-touch" features. There are two different comparator threshold tests available for this purpose:

- Absolute - used to compare data outputs with "less than or equal" or "greater than" tests against a fixed value. This is useful for applications with short sleep durations, which simply want to wake quickly if a certain condition is met.
- Relative EMA - used to compare data outputs against a moving average window. This is extremely useful for applications with long-term sleep requirements. The relative comparison allows the CSEN module to adjust for slow changes in capacitance such as those due to environmental changes (temperature, supply) without waking the system.

The absolute test is used when CTRL\_CMPEN = ENABLE and CTRL\_EMACMP = DISABLE. In this mode, any output word written to the DATA register will be compared against the value in the CMPTHR register. The polarity of the comparison is configured with the CTRL\_CMPPOL field. Setting CTRL\_CMPPOL to GT means that the comparison will be true if DATA is greater than CMPTHR. Setting CTRL\_CMPPOL to LTE means that the comparison will be true if DATA is less than or equal to CMPTHR. On a true result, the IF\_CMP interrupt flag is set to 1, and any continuous conversion in progress will be halted.

The relative EMA test is used when CTRL\_EMACMP = ENABLE. In this mode, the exponential moving average (EMA) value is used to establish a low-noise average code reading. The EMA is a moving average that is re-calculated on every output data word from the converter, according to the following equation:

$$\text{EMA}[n] = \text{EMA}[n-1] - \text{EMA}[n-1]/N + \text{DATA}/N,$$

**Figure 34.9. CSEN Exponential Moving Average Calculation**

The EMA register stores the current EMA value. This register may be written by software to quickly establish a new baseline average. N in the equation above is the sample weighting of the EMA filter, and is controlled with the EMASAMPLE field. Lower values of EMASAMPLE mean less averaging, and quicker response time, while higher EMASAMPLE values will reject more noise at the expense of response time.

When relative EMA comparisons are enabled, every new sample is compared with a window around the EMA. The lower bound of this window is EMA - CMPTHR, and the upper bound of the window is EMA + CMPTHR. If the new sample written to DATA falls outside that window (lower than the lower bound or higher than the upper bound), the CMP interrupt flag is set to 1 and any continuous conversion in progress is halted. Using the EMA comparison, large jumps in the output data word will trip the comparator and wake the system, but gradual changes will not trigger false positives. [Figure 34.10 Wake on Threshold With Relative EMA on page 1196](#) shows an example of the EMA moving average filter and window.




Figure 34.10. Wake on Threshold With Relative EMA

### 34.10 Analog Adjustments

The analog front-end of the CSEN module has some additional controls that may be useful in certain applications.

#### 34.10.1 Current Reference and Gain

The internal current source used for charging the reference capacitor can be adjusted using the ANACTRL\_IREFPROG field. This adjusts the ratio of the internal reference current source vs. the external drive current source, and thereby adjusts the effective gain of the converter. The lowest gain setting is when ANACTRL\_IREFPROG = 0, and the highest is with ANACTRL\_IREFPROG = 7. The difference between the lowest and highest setting is approximately 10x. High gain gives the best sensitivity and resolution for small capacitors, such as those typically implemented as touch-sensitive PCB features. Lower gain allows for larger capacitor values to be measured. It can also be useful to lower the gain when performing bonded channel conversions.

#### 34.10.2 Current Drive

The external capacitor is charged with a current-source DAC during conversions. The full scale output of the current DAC can be adjusted using the ANACTRL\_IDACIREFS field. When ANACTRL\_IDACIREFS is 0, the drive current is at its maximum setting. For ANACTRL\_IDACIREFS settings of 1-7, the drive current is reduced by a factor of ANACTRL\_IDACIREFS / 8. For most touch switch applications, the maximum (default) current drive (ANACTRL\_IDACIREFS = 0) should be used. Lower current drive may be useful when there is additional series impedance between the device pin and the capacitive sensor.

#### 34.10.3 Reset (Discharge) Timing

During a conversion, the external capacitance is charged and discharged multiple times. The amount of time used for the reset (discharge) phase is controlled by the ANACTRL\_TRSTPROG field. For most touch sensitive switch applications, the fastest (default) timing should be used. Extended reset timing may be useful in applications with additional series impedance between the device pin and the capacitive sensor.

### 34.11 DMA Interface

The CSEN module has DMA support for reads of the DATA register and writes to the DMBASELINE register. This enables the CSEN module to operate autonomously from software, either to free up software cycles during EM0 or to enable lower power operation in EM1 and EM2.

DMA transfers to and from the CSEN module are enabled by setting the CTRL\_DMAEN bit to 1. If the converter is used in SAR mode, only DMA reads (from the DATA register) are triggered. If the converter is used in delta modulation mode, both DMA reads from the DATA register and DMA writes to the DMBASELINE register are triggered.

Requests for a DATA register read occur at the end of a conversion cycle any time the CSEN module writes new output information to the DATA register. DMA may read half words (16 bits) or full words (32 bits) from the DATA register, depending on the specific CSEN configuration and the needs of the application. The CSEN module does not halt when the DMA read request is posted. It will immediately begin the next conversion. If the DMA read request is not serviced by the time the next conversion has completed, the IF\_DMAOF flag will be set to indicate an overflow event has occurred.

Requests for a data write to the DMBASELINE register occur only when using delta-modulation type conversions. The write request will be triggered at the start of a conversion, prior to the first sample comparison. The conversion will not begin until the DMA services this write request.

**Note:** If an absolute or EMA threshold interrupt is enabled when using the DMA, software must be aware that the converter will halt when the interrupt condition occurs. In this case it may be necessary to reconfigure portions of the DMA transfer before resuming conversions.

### 34.12 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	CSEN_CTRL	RW	Control
0x004	CSEN_TIMCTRL	RW	Timing Control
0x008	CSEN_CMD	W1	Command
0x00C	CSEN_STATUS	R	Status
0x010	CSEN_PRSSEL	RW	PRS Select
0x014	CSEN_DATA	RWH	Output Data
0x018	CSEN_SCANMASK0	RW	Scan Channel Mask 0
0x01C	CSEN_SCANINPUTSEL0	RW	Scan Input Selection 0
0x020	CSEN_SCANMASK1	RW	Scan Channel Mask 1
0x024	CSEN_SCANINPUTSEL1	RW	Scan Input Selection 1
0x028	CSEN_APORTREQ	R	APORT Request Status
0x02C	CSEN_APORTCNFICT	R	APORT Request Conflict
0x030	CSEN_CMPTHRESHOLD	RW	Comparator Threshold
0x034	CSEN_EMA	RWH	Exponential Moving Average
0x038	CSEN_EMACTRL	RW	Exponential Moving Average Control
0x03C	CSEN_SINGLECTRL	RW	Single Conversion Control
0x040	CSEN_DMBASELINE	RW	Delta Modulation Baseline
0x044	CSEN_DMCFG	RW	Delta Modulation Configuration
0x048	CSEN_ANACTRL	RW	Analog Control
0x054	CSEN_IF	R	Interrupt Flag
0x058	CSEN_IFS	W1	Interrupt Flag Set
0x05C	CSEN_IFC	(R)W1	Interrupt Flag Clear
0x060	CSEN_IEN	RW	Interrupt Enable

### 34.13 Register Description

### 34.13.1 CSEN CTRL - Control

Offset	Bit Position		
Name	Reset	Access	Offset
0x000	31	30	29
CPACCURACY	RW 0	28	
LOCALSENS	RW 0	27	
WARMUPMODE	RW 0	26	
EMACMPEN	RW 0	25	
MXUC	RW 0	24	
AUTOGND	RW 0	23	
CHOPEN	RW 0	22	
CONVSEL	RW 0	21	
DMAEN	RW 0	20	
DRSF	RW 0	19	
CMPEN	RW 0	18	
STM	RW 0x3	17	
MCEN	RW 0	15	
ACU	RW 0x0	13	
SARCR	RW 0x0	9	
CM	RW 0x0	5	
CMPPOL	RW 0	2	
EN	RW 0	1	0

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

28 CPACCURACY 0 RW Charge Pump Accuracy

This bit enables a more accurate reference for the APORT supply voltage. If

This bit enables a more accurate reference for the APORT supply voltage. For the CSEN module, this bit has no effect on performance and should be written to 0.

Value	Mode	Description
0	LO	Request Low Accuracy Mode.
1	HI	Request High Accuracy Mode.

27 LOCALSENS 0 RW Local Sensing Enable

When cleared to 0, Kelvin sensing will be used. The external capacitor will be charged through the CEXT signal and the voltage at the pin will be monitored through a different APORt bus on the CEXT\_CSEN signal. When this bit is set to 1, charging and sensing are both performed with the CEXT signal.

26 WARMUPMODE 0 RW Select Warmup Mode for CSEN

Use this bit to keep the analog core enabled regardless of the conversion state.

Value	Mode	Description
0	NORMAL	CSEN analog core is shutdown after each operation completes. The next conversion trigger will incur a delay of $(3 + \text{WARMUPCNT})$ CSEN clock cycles before the conversion begins.
1	KEEPSENWARM	CSEN remains powered up, allowing continuous conversion

25 EMACMPEN 0 RW **Greater and Less Than Comparison Using the Exponential Moving Average (EMA) is Enabled**

24 MXUC 0 RW CSEN Mux Disconnect

CSEN Mux Disconnect.

Value	Mode	Description
0	CONN	The CSEN mux inputs are connected.

Bit	Name	Reset	Access	Description
	1	UNC		The CSEN mux inputs unconnected.
23	AUTOGND	0	RW	<b>CSEN Automatic Ground Enable</b>
				Use this bit to enable automatic grounding of unused channels during scan conversions. For instance, if five channels are included in a scan, four channels will be grounded while one channel is being converted. This feature should be disabled when performing bonded conversions (MCE = 1).
	Value	Mode		Description
	0	DISABLE		Auto grounding is disabled.
	1	ENABLE		Auto grounding is enabled.
22	CHOPEN	0	RW	<b>CSEN Chop Enable</b>
				Enables chopping for low-frequency noise filtering. When chopping is enabled, the ACU field must be set to a value greater than ACC1.
	Value	Mode		Description
	0	DISABLE		Chopping is disabled.
	1	ENABLE		Chopping is enabled.
21	CONVSEL	0	RW	<b>CSEN Converter Select</b>
				This bit selects between SAR conversions and delta modulation conversions.
	Value	Mode		Description
	0	SAR		The CSEN uses the SAR method for conversions.
	1	DM		The CSEN uses the delta modulation method for conversions.
20	DMAEN	0	RW	<b>CSEN DMA Enable Bit</b>
				Enables DMA transfers. DMA triggers are provided for DATA register reads of SAR and DM conversions. DMA triggers are also provided for DMBASELINE writes when DM conversions are performed.
	Value	Mode		Description
	0	DISABLE		CSEN DMA is disabled.
	1	ENABLE		CSEN DMA is enabled.
19	DRSF	0	RW	<b>CSEN Disable Right-Shift</b>
				Disables the hardware accumulator right-shift operation.
	Value	Mode		Description
	0	DISABLE		DATA[15:0] stores the last conversion (accumulated) result.
	1	ENABLE		DATA[21:0] stores the last conversion (accumulated) result.
18	CMPEN	0	RW	<b>CSEN Digital Comparator Enable</b>
				This bit enables the digital comparator which compares the accumulated CSEN conversions to the value stored in the CMPTHR register. When enabled, a comparator event will halt continuous conversions. Note that this bit is only effective when EMACMPEN = 0.
	Value	Mode		Description
	0	DISABLE		CSEN comparator is disabled.

Bit	Name	Reset	Access	Description
	1	ENABLE		CSEN comparator is enabled.
17:16	STM	0x3	RW	<b>Start Trigger Select</b>
				Selects the start-of-conversion trigger to be used. Depending on the CSEN configuration, a single trigger may result in one or more conversions across multiple channels.
	Value	Mode		Description
	0	PRS		PRS Triggering. Conversions are triggered by the PRS channel selected in PRSSEL.
	1	TIMER		Timer Triggering. Conversions are triggered by a local CSEN timer reload.
	2	START		Software Triggering. Conversions are triggered by writing a 1 to the START field of the CMD register.
15	MCEN	0	RW	<b>CSEN Multiple Channel Enable</b>
				This field enables bonded-channel conversions, where selected channels are shorted together. Use only with CM = SGL or CONTSGL.
	Value	Mode		Description
	0	DISABLE		Multiple channel feature is disabled.
	1	ENABLE		Selected channels are internally shorted together and the combined node is converted.
14:12	ACU	0x0	RW	<b>CSEN Accumulator Mode Select</b>
				This field configures the hardware accumulator.
	Value	Mode		Description
	0	ACC1		Accumulate 1 sample.
	1	ACC2		Accumulate 2 sample.
	2	ACC4		Accumulate 4 sample.
	3	ACC8		Accumulate 8 sample.
	4	ACC16		Accumulate 16 sample.
	5	ACC32		Accumulate 32 sample.
	6	ACC64		Accumulate 64 sample.
11:10	Reserved			To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>
9:8	SARCR	0x0	RW	<b>SAR Conversion Resolution.</b>
				This field selects the resolution of SAR type conversions.
	Value	Mode		Description
	0	CLK10		Conversions last 10 internal CSEN clocks and are 10-bits in length.
	1	CLK12		Conversions last 12 internal CSEN clocks and are 12-bits in length.
	2	CLK14		Conversions last 14 internal CSEN clocks and are 14-bits in length.
	3	CLK16		Conversions last 16 internal CSEN clocks and are 16-bits in length.

Bit	Name	Reset	Access	Description
7:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
5:4	CM	0x0	RW	<b>CSEN Conversion Mode Select</b>
				This field is used to select a conversion method.
	Value	Mode		Description
	0	SGL		Single Channel Mode: One conversion of a single channel (when MCE = 0) or set of bonded channels (when MCE = 1) per conversion trigger.
	1	SCAN		Scan Mode: Scans multiple selected channels once per conversion trigger.
	2	CONTSGL		Continuous Single Channel: Continuous conversion of a single channel (when MCE = 0) or set of bonded channels (when MCE = 1).
	3	CONTSCAN		Continuous Scan Mode: Continuously scans multiple selected channels.
3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2	CMPPOL	0	RW	<b>CSEN Digital Comparator Polarity Select</b>
				This bit determines the polarity of the digital comparator.
	Value	Mode		Description
	0	GT		The digital comparator flag (CMPIF) is set if the conversion result is greater than the threshold.
	1	LTE		The digital comparator flag (CMPIF) is set if the conversion result is less than or equal to the threshold.
1	EN	0	RW	<b>CSEN Enable</b>
				This bit enables the CSEN module. The CSEN module can be configured while disabled and then enabled when conversions are required. Clearing this bit to 0 will cancel any conversions in progress, but does not reset the configuration.
	Value	Mode		Description
	0	DISABLE		CSEN disabled.
	1	ENABLE		CSEN enabled and ready to convert. Must be done before the start trigger.
0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 34.13.2 CSEN\_TIMCTRL - Timing Control

Offset	Bit Position																															
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																	0x0	0x00								0x0						
Access																	RW	RW								RW						
Name																	WARMUPCNT	PCTOP								PCPRESC						

Bit	Name	Reset	Access	Description
31:18	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
17:16	WARMUPCNT	0x0	RW	<b>Warmup Period Counter</b>
				Configures the warmup time for the converter when WARMUPMODE = NORMAL. The CSEN warmup time is defined as WARMUPCNT+3 CSEN clocks.
15:8	PCTOP	0x00	RW	<b>Period Counter Top Value</b>
				This field contains the reload value for the period counter. If CTRL_STM = TIMER, the counter counts down and a start trigger is generated when the counter reaches zero. The counter is automatically reloaded from this field.
7:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
2:0	PCPRESC	0x0	RW	<b>Period Counter Prescaler</b>
				This field sets the pre-scaler for local CSEN timer clock.
	Value	Mode	Description	
	0	DIV1	The period counter clock frequency is LFBCLKCSEN/1	
	1	DIV2	The period counter clock frequency is LFBCLKCSEN/2	
	2	DIV4	The period counter clock frequency is LFBCLKCSEN/4	
	3	DIV8	The period counter clock frequency is LFBCLKCSEN/8	
	4	DIV16	The period counter clock frequency is LFBCLKCSEN/16	
	5	DIV32	The period counter clock frequency is LFBCLKCSEN/32	
	6	DIV64	The period counter clock frequency is LFBCLKCSEN/64	
	7	DIV128	The period counter clock frequency is LFBCLKCSEN/128	

## 34.13.3 CSEN\_CMD - Command

Offset	Bit Position																																			
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0			
Reset																																				
Access																																				
Name																																				
	START	0	W1	<b>Start Software-Triggered Conversions</b>																																

When CTRL\_STM = START, writing a 1 to this bit will trigger CSEN conversions.

## 34.13.4 CSEN\_STATUS - Status

Offset	Bit Position																																						
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0						
Reset																																							
Access																																							
Name																																							
	CSENBUSY	0	R	<b>Busy Flag</b>																																			

This bit is set to 1 when a conversion is currently taking place.

Value	Mode	Description
0	IDLE	Conversion is complete or a conversion is not currently in progress.
1	BUSY	Conversion is in progress.

## 34.13.5 CSEN\_PRSSEL - PRS Select

Offset	Bit Position																											
0x010	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
<b>Reset</b>																												0x0
<b>Access</b>																												RW
<b>Name</b>																												PRSSEL

Bit	Name	Reset	Access	Description
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
2:0	PRSSEL	0x0	RW	<b>PRS Channel Select</b>
				Selects the PRS channel to be used as a conversion trigger when CTRL_STM = PRS.
	Value	Mode		Description
	0	PRSCH0		PRS Channel 0 selected as the start trigger
	1	PRSCH1		PRS Channel 1 selected as the start trigger
	2	PRSCH2		PRS Channel 2 selected as the start trigger
	3	PRSCH3		PRS Channel 3 selected as the start trigger
	4	PRSCH4		PRS Channel 4 selected as the start trigger
	5	PRSCH5		PRS Channel 5 selected as the start trigger
	6	PRSCH6		PRS Channel 6 selected as the start trigger
	7	PRSCH7		PRS Channel 7 selected as the start trigger

## 34.13.6 CSEN\_DATA - Output Data

Offset	Bit Position																											
0x014	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
<b>Reset</b>																												0x00000000
<b>Access</b>																												RWH
<b>Name</b>																												DATA

Bit	Name	Reset	Access	Description
31:0	DATA	0x00000000	RWH	<b>Output Data</b>
				Output data words are written to the DATA register when sampling and accumulation for a channel have completed. Data encoding depends on the resolution, accumulator settings, and conversion type. See the chapter text for more details on data output encoding.

## 34.13.7 CSEN\_SCANMASK0 - Scan Channel Mask 0

Offset	Bit Position																															
0x018	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	SCANINPUTEN																															

Bit	Name	Reset	Access	Description
-----	------	-------	--------	-------------

31:0	SCANINPUTEN	0x00000000	RW	<b>Scan Channel Mask</b>
------	-------------	------------	----	--------------------------

Scan channel mask for CSEN channels CSEN\_INPUT0 through CSEN\_INPUT31. For scan mode conversions, a '1' in any bit position will include the channel specified by SCANINPUTSEL0 in a scan. For bonded channel conversions, a '1' in any bit position includes the corresponding channel from APOR1 / BUSA in the bonded conversion. If AUTOGND = ENABLE the scan mask also determines the pins that will be grounded when inactive, for both scan and single channel conversions.

## 34.13.8 CSEN\_SCANINPUTSEL0 - Scan Input Selection 0

Offset	Bit Position																															
0x01C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0								0x0								0x0								0x0							
Access	RW								RW								RW								RW							
Name	INPUT24TO31SEL								INPUT16TO23SEL								INPUT8TO15SEL								INPUT0TO7SEL							

Bit	Name	Reset	Access	Description
31:28	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		

27:24	INPUT24TO31SEL	0x0	RW	<b>CSEN_INPUT24-31 Select</b>
Channels chosen for CSEN_INPUT24-CSEN_INPUT31 as referred in SCANMASK0				
Mode		Value		Description
APORT1CH0TO7		4		Select APорт1 CH0-CH7 as CSEN_INPUT24-CSEN_INPUT31
APORT1CH8TO15		5		Select APорт1 CH8-CH15 as CSEN_INPUT24-CSEN_INPUT31
APORT1CH16TO23		6		Select APорт1 CH16-CH23 as CSEN_INPUT24-CSEN_INPUT31
APORT1CH24TO31		7		Select APорт1 CH24-CH31 as CSEN_INPUT24-CSEN_INPUT31
APORT3CH0TO7		12		Select APорт3 CH0-CH7 as CSEN_INPUT24-CSEN_INPUT31
APORT3CH8TO15		13		Select APорт3 CH8-CH15 as CSEN_INPUT24-CSEN_INPUT31
APORT3CH16TO23		14		Select APорт3 CH16-CH23 as CSEN_INPUT24-CSEN_INPUT31
APORT3CH24TO31		15		Select APорт3 CH24-CH31 as CSEN_INPUT24-CSEN_INPUT31

23:20	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
-------	----------	--	--	--

19:16	INPUT16TO23SEL	0x0	RW	<b>CSEN_INPUT16-23 Select</b>
Channels chosen for CSEN_INPUT16-CSEN_INPUT23 as referred in SCANMASK0				
Mode		Value		Description
APORT1CH0TO7		4		Select APорт1 CH0-CH7 as CSEN_INPUT16-CSEN_INPUT23
APORT1CH8TO15		5		Select APорт1 CH8-CH15 as CSEN_INPUT16-CSEN_INPUT23
APORT1CH16TO23		6		Select APорт1 CH16-CH23 as CSEN_INPUT16-CSEN_INPUT23
APORT1CH24TO31		7		Select APорт1 CH24-CH31 as CSEN_INPUT16-CSEN_INPUT23
APORT3CH0TO7		12		Select APорт3 CH0-CH7 as CSEN_INPUT16-CSEN_INPUT23
APORT3CH8TO15		13		Select APорт3 CH8-CH15 as CSEN_INPUT16-CSEN_INPUT23
APORT3CH16TO23		14		Select APорт3 CH16-CH23 as CSEN_INPUT16-CSEN_INPUT23
APORT3CH24TO31		15		Select APорт3 CH24-CH31 as CSEN_INPUT16-CSEN_INPUT23

Bit	Name	Reset	Access	Description
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:8	INPUT8TO15SEL	0x0	RW	<b>CSEN_INPUT8-15 Select</b>
Channels chosen for CSEN_INPUT8-CSEN_INPUT15 as referred in SCANMASK0				
Mode		Value	Description	
APORT1CH0TO7		4	Select APOR1 CH0-CH7 as CSEN_INPUT8-CSEN_INPUT15	
APORT1CH8TO15		5	Select APOR1 CH8-CH15 as CSEN_INPUT8-CSEN_INPUT15	
APORT1CH16TO23		6	Select APOR1 CH16-CH23 as CSEN_INPUT8-CSEN_INPUT15	
APORT1CH24TO31		7	Select APOR1 CH24-CH31 as CSEN_INPUT8-CSEN_INPUT15	
APORT3CH0TO7		12	Select APORT3 CH0-CH7 as CSEN_INPUT8-CSEN_INPUT15	
APORT3CH8TO15		13	Select APORT3 CH8-CH15 as CSEN_INPUT8-CSEN_INPUT15	
APORT3CH16TO23		14	Select APORT3 CH16-CH23 as CSEN_INPUT8-CSEN_INPUT15	
APORT3CH24TO31		15	Select APORT3 CH24-CH31 as CSEN_INPUT8-CSEN_INPUT15	
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	INPUT0TO7SEL	0x0	RW	<b>CSEN_INPUT0-7 Select</b>
Channels chosen for CSEN_INPUT7-CSEN_INPUT0 as referred in SCANMASK0				
Mode		Value	Description	
APORT1CH0TO7		4	Select APOR1 CH0-CH7 as CSEN_INPUT0-CSEN_INPUT7	
APORT1CH8TO15		5	Select APORT1 CH8-CH15 as CSEN_INPUT0-CSEN_INPUT7	
APORT1CH16TO23		6	Select APORT1 CH16-CH23 as CSEN_INPUT0-CSEN_INPUT7	
APORT1CH24TO31		7	Select APORT1 CH24-CH31 as CSEN_INPUT0-CSEN_INPUT7	
APORT3CH0TO7		12	Select APORT3 CH0-CH7 as CSEN_INPUT0-CSEN_INPUT7	
APORT3CH8TO15		13	Select APORT3 CH8-CH15 as CSEN_INPUT0-CSEN_INPUT7	
APORT3CH16TO23		14	Select APORT3 CH16-CH23 as CSEN_INPUT0-CSEN_INPUT7	
APORT3CH24TO31		15	Select APORT3 CH24-CH31 as CSEN_INPUT0-CSEN_INPUT7	

## 34.13.9 CSEN\_SCANMASK1 - Scan Channel Mask 1

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	RW																															
Name	SCANINPUTEN																															

Bit	Name	Reset	Access	Description
31:0	SCANINPUTEN	0x00000000	RW	<b>Scan Channel Mask.</b>  Scan channel mask for CSEN channels CSEN_INPUT32 through CSEN_INPUT63. For scan mode conversions, a '1' in any bit position will include the channel specified by SCANINPUTSEL1 in a scan. For bonded channel conversions, a '1' in any bit position includes the corresponding channel from APOR3 / BUSC in the bonded conversion. If AUTOGND = ENABLE the scan mask also determines the pins that will be grounded when inactive, for both scan and single channel conversions.

## 34.13.10 CSEN\_SCANINPUTSEL1 - Scan Input Selection 1

Offset	Bit Position																															
0x024	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0								0x0								0x0								0x0							
Access	RW								RW								RW								RW							
Name	INPUT56TO63SEL								INPUT48TO55SEL								INPUT40TO47SEL								INPUT32TO39SEL							

Bit	Name	Reset	Access	Description
31:28	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
27:24	INPUT56TO63SEL	0x0	RW	<b>CSEN_INPUT56-63 Select</b>  Channels chosen for CSEN_INPUT56-CSEN_INPUT63 as referred in SCANMASK1
	Mode	Value	Description	
	APORT1CH0TO7	4	Select APорт1 CH0-CH7 as CSEN_INPUT56-CSEN_INPUT63	
	APORT1CH8TO15	5	Select APорт1 CH8-CH15 as CSEN_INPUT56-CSEN_INPUT63	
	APORT1CH16TO23	6	Select APорт1 CH16-CH23 as CSEN_INPUT56-CSEN_INPUT63	
	APORT1CH24TO31	7	Select APорт1 CH24-CH31 as CSEN_INPUT56-CSEN_INPUT63	
	APORT3CH0TO7	12	Select APорт3 CH0-CH7 as CSEN_INPUT56-CSEN_INPUT63	
	APORT3CH8TO15	13	Select APорт3 CH8-CH15 as CSEN_INPUT56-CSEN_INPUT63	
	APORT3CH16TO23	14	Select APорт3 CH16-CH23 as CSEN_INPUT56-CSEN_INPUT63	
	APORT3CH24TO31	15	Select APорт3 CH24-CH31 as CSEN_INPUT56-CSEN_INPUT63	
23:20	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>		
19:16	INPUT48TO55SEL	0x0	RW	<b>CSEN_INPUT48-55 Select</b>  Channels chosen for CSEN_INPUT48-CSEN_INPUT55 as referred in SCANMASK1
	Mode	Value	Description	
	APORT1CH0TO7	4	Select APорт1 CH0-CH7 as CSEN_INPUT48-CSEN_INPUT55	
	APORT1CH8TO15	5	Select APорт1 CH8-CH15 as CSEN_INPUT48-CSEN_INPUT55	
	APORT1CH16TO23	6	Select APорт1 CH16-CH23 as CSEN_INPUT48-CSEN_INPUT55	
	APORT1CH24TO31	7	Select APорт1 CH24-CH31 as CSEN_INPUT48-CSEN_INPUT55	
	APORT3CH0TO7	12	Select APорт3 CH0-CH7 as CSEN_INPUT48-CSEN_INPUT55	
	APORT3CH8TO15	13	Select APорт3 CH8-CH15 as CSEN_INPUT48-CSEN_INPUT55	
	APORT3CH16TO23	14	Select APорт3 CH16-CH23 as CSEN_INPUT48-CSEN_INPUT55	
	APORT3CH24TO31	15	Select APорт3 CH24-CH31 as CSEN_INPUT48-CSEN_INPUT55	

Bit	Name	Reset	Access	Description
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:8	INPUT40TO47SEL	0x0	RW	<b>CSEN_INPUT40-47 Select</b>
Channels chosen for CSEN_INPUT40-CSEN_INPUT47 as referred in SCANMASK1				
Mode		Value	Description	
APORT1CH0TO7		4	Select APOR1 CH0-CH7 as CSEN_INPUT40-CSEN_INPUT47	
APORT1CH8TO15		5	Select APOR1 CH8-CH15 as CSEN_INPUT40-CSEN_INPUT47	
APORT1CH16TO23		6	Select APOR1 CH16-CH23 as CSEN_INPUT40-CSEN_INPUT47	
APORT1CH24TO31		7	Select APOR1 CH24-CH31 as CSEN_INPUT40-CSEN_INPUT47	
APORT3CH0TO7		12	Select APORT3 CH0-CH7 as CSEN_INPUT40-CSEN_INPUT47	
APORT3CH8TO15		13	Select APORT3 CH8-CH15 as CSEN_INPUT40-CSEN_INPUT47	
APORT3CH16TO23		14	Select APORT3 CH16-CH23 as CSEN_INPUT40-CSEN_INPUT47	
APORT3CH24TO31		15	Select APORT3 CH24-CH31 as CSEN_INPUT40-CSEN_INPUT47	
7:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
3:0	INPUT32TO39SEL	0x0	RW	<b>CSEN_INPUT32-39 Select</b>
Channels chosen for CSEN_INPUT32-CSEN_INPUT39 as referred in SCANMASK1				
Mode		Value	Description	
APORT1CH0TO7		4	Select APOR1 CH0-CH7 as CSEN_INPUT32-CSEN_INPUT39	
APORT1CH8TO15		5	Select APORT1 CH8-CH15 as CSEN_INPUT32-CSEN_INPUT39	
APORT1CH16TO23		6	Select APORT1 CH16-CH23 as CSEN_INPUT32-CSEN_INPUT39	
APORT1CH24TO31		7	Select APORT1 CH24-CH31 as CSEN_INPUT32-CSEN_INPUT39	
APORT3CH0TO7		12	Select APORT3 CH0-CH7 as CSEN_INPUT32-CSEN_INPUT39	
APORT3CH8TO15		13	Select APORT3 CH8-CH15 as CSEN_INPUT32-CSEN_INPUT39	
APORT3CH16TO23		14	Select APORT3 CH16-CH23 as CSEN_INPUT32-CSEN_INPUT39	
APORT3CH24TO31		15	Select APORT3 CH24-CH31 as CSEN_INPUT32-CSEN_INPUT39	

## 34.13.11 CSEN\_APORTREQ - APORTR Request Status

Offset	Bit Position																																		
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset																										0	0	0	0	0	0	0	0	0	0
Access																										0	0	0	0	0	0	0	0	0	0
Name																										APORT4YREQ	APORT4XREQ	APORT3YREQ	APORT3XREQ	APORT2YREQ	APORT2XREQ	APORT1YREQ	APORT1XREQ	APORT1XREQ	APORT1XREQ

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
9	APORT4YREQ	0	R	<b>1 If the Bus Connected to APORTR4Y is Requested</b>  Reports if the bus connected to APORTR4Y is being requested from the APORTR
8	APORT4XREQ	0	R	<b>1 If the Bus Connected to APORTR4X is Requested</b>  Reports if the bus connected to APORTR4X is being requested from the APORTR
7	APORT3YREQ	0	R	<b>1 If the Bus Connected to APORTR3Y is Requested</b>  Reports if the bus connected to APORTR3Y is being requested from the APORTR
6	APORT3XREQ	0	R	<b>1 If the Bus Connected to APORTR3X is Requested</b>  Reports if the bus connected to APORTR3X is being requested from the APORTR
5	APORT2YREQ	0	R	<b>1 If the Bus Connected to APORTR2Y is Requested</b>  Reports if the bus connected to APORTR2Y is being requested from the APORTR
4	APORT2XREQ	0	R	<b>1 If the Bus Connected to APORTR2X is Requested</b>  Reports if the bus connected to APORTR2X is being requested from the APORTR
3	APORT1YREQ	0	R	<b>1 If the Bus Connected to APORTR1X is Requested</b>  Reports if the bus connected to APORTR1X is being requested from the APORTR
2	APORT1XREQ	0	R	<b>1 If the Bus Connected to APORTR1X is Requested</b>  Reports if the bus connected to APORTR1X is being requested from the APORTR
1:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 34.13.12 CSEN\_APORTCNFICT - APORTC Request Conflict

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0																															
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:10	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
9	APORT4YCONFLICT	0	R	<b>1 If the Bus Connected to APORTC4Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC4Y is also being requested by another peripheral
8	APORT4XCONFLICT	0	R	<b>1 If the Bus Connected to APORTC4X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC4X is also being requested by another peripheral
7	APORT3YCONFLICT	0	R	<b>1 If the Bus Connected to APORTC3Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC3Y is also being requested by another peripheral
6	APORT3XCONFLICT	0	R	<b>1 If the Bus Connected to APORTC3X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC3X is also being requested by another peripheral
5	APORT2YCONFLICT	0	R	<b>1 If the Bus Connected to APORTC2Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC2Y is also being requested by another peripheral
4	APORT2XCONFLICT	0	R	<b>1 If the Bus Connected to APORTC2X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC2X is also being requested by another peripheral
3	APORT1YCONFLICT	0	R	<b>1 If the Bus Connected to APORTC1Y is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC1Y is also being requested by another peripheral
2	APORT1XCONFLICT	0	R	<b>1 If the Bus Connected to APORTC1X is in Conflict With Another Peripheral</b>  Reports if the bus connected to APORTC1X is also being requested by another peripheral
1:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 34.13.13 CSEN\_CMPTH.R - Comparator Threshold

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x0000							
Access																									RW							
Name																										CMPTH.R						

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15:0	CMPTH.R	0x0000	RW	<b>Comparator Threshold.</b>

When CMPPEN is set to 1 and EMACMPEN is cleared to 0, a greater than or less than/equal (based on CMPPOL) comparison between the DATA register and CMPTH.R value. If the desired condition is met, the CMPIF flag will be set. When EMACMPEN is set to 1, a comparison window is used instead. The DATA register will be compared against EMA +/- CMPTH.R. The CMPIF flag is set any time the conversion result is above (EMA + CMPTH.R) or below (EMA - CMPTH.R).

## 34.13.14 CSEN\_EMA - Exponential Moving Average

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																									0x00000000							
Access																									RWH							
Name																										EMA						

Bit	Name	Reset	Access	Description
31:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
21:0	EMA	0x00000000	RWH	<b>Calculated Exponential Moving Average</b>

This register contains the current exponential moving average. The EMA is updated every time an accumulated sample is produced, according to the formula:  $EMA[n] = EMA[n-1] - EMA[n-1]/N + DATA/N$ , where N is the EMA sample weight selected by EMASAMPLE. This register can be written to initialize the average.

## 34.13.15 CSEN\_EMACTRL - Exponential Moving Average Control

Offset	Bit Position																																			
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0				
Reset	0x0																																			
Access																																				
Name																																				EMASAMPLE

Bit	Name	Reset	Access	Description																								
31:3	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>																								
2:0	EMASAMPLE	0x0	RW	<b>EMA Sample Weight</b>																								
This field specifies the sample weighting (N) for the exponential moving average filter.																												
<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>W1</td> <td>EMA weight (N) is 1.</td> </tr> <tr> <td>1</td> <td>W2</td> <td>EMA weight (N) is 2.</td> </tr> <tr> <td>2</td> <td>W4</td> <td>EMA weight (N) is 4.</td> </tr> <tr> <td>3</td> <td>W8</td> <td>EMA weight (N) is 8.</td> </tr> <tr> <td>4</td> <td>W16</td> <td>EMA weight (N) is 16.</td> </tr> <tr> <td>5</td> <td>W32</td> <td>EMA weight (N) is 32.</td> </tr> <tr> <td>6</td> <td>W64</td> <td>EMA weight (N) is 64.</td> </tr> </tbody> </table>					Value	Mode	Description	0	W1	EMA weight (N) is 1.	1	W2	EMA weight (N) is 2.	2	W4	EMA weight (N) is 4.	3	W8	EMA weight (N) is 8.	4	W16	EMA weight (N) is 16.	5	W32	EMA weight (N) is 32.	6	W64	EMA weight (N) is 64.
Value	Mode	Description																										
0	W1	EMA weight (N) is 1.																										
1	W2	EMA weight (N) is 2.																										
2	W4	EMA weight (N) is 4.																										
3	W8	EMA weight (N) is 8.																										
4	W16	EMA weight (N) is 16.																										
5	W32	EMA weight (N) is 32.																										
6	W64	EMA weight (N) is 64.																										

## 34.13.16 CSEN\_SINGLECTRL - Single Conversion Control

Offset	Bit Position																															
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																																
<b>Access</b>																																
<b>Name</b>																																

Bit	Name	Reset	Access	Description
31:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10:4	SINGLESEL	0x00	RW	<b>Single Channel Input Select</b>
		This field selects the channel to be sampled for single channel conversions.		
	Mode	Value	Description	
	APORT1XCH0	32	Select APOR1XCH0	
	APORT1YCH1	33	Select APOR1YCH1	
	...	...	.....	
	APORT3XCH0	96	Select APORT3XCH0	
	APORT3YCH1	97	Select APORT3YCH1	
	...	...	.....	
3:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 34.13.17 CSEN\_DMBASELINE - Delta Modulation Baseline

Offset	Bit Position																															
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x0000																0x0000															
Access	RW																RW															
Name	BASELINEDN																BASELINEUP															

Bit	Name	Reset	Access	Description
31:16	BASELINEDN	0x0000	RW	<b>Delta Modulator Integrator Initial Value</b>  When CHOPEN = ENABLE, this field is used to initialize the ramp-down integrator. Unused if CHOPEN = DISABLE.
15:0	BASELINEUP	0x0000	RW	<b>Delta Modulator Integrator Initial Value</b>  This field is used to initialize the integrator. When CHOPEN = ENABLE, this field is used for the ramp-up integrator.

### 34.13.18 CSEN\_DMCFG - Delta Modulation Configuration

Bit	Name	Reset	Access	Description
31:29	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
28	DMGRDIS	0	RW	<b>Delta Modulation Gain Step Reduction Disable</b>
				If this bit set, the integrator uses a constant gain step for all cycles, given by DMG. Otherwise, at the end of each cycle, the gain step is divided by two and rounded up (DMG = DMG[7:1] + DMG[0]).
27:22	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
21:20	CRMODE	0x0	RW	<b>Delta Modulator Conversion Resolution.</b>
				This field selects the resolution for DM conversions.
	Value	Mode		Description
	0	DM10		10-bit delta modulator
	1	DM12		12-bit delta modulator
	2	DM14		14-bit delta modulator
	3	DM16		16-bit delta modulator
19:16	DMCR	0x0	RW	<b>Delta Modulator Conversion Rate</b>
				The DMCR field determines how many cycles the DM converter will use per conversion. For the case of DMCR = 0, the converter will perform 16 cycles. Each cycle will consist of between 4 and 64 tests as determined by the DMR field.
15:12	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
11:8	DMR	0x0	RW	<b>Delta Modulator Gain Reduction Interval</b>
				The DMR field determines how many tests are performed and integrated at each gain step setting. For DMR = 0, 64 tests will be performed per cycle (at the same gain step). For DMR = 1 to 15, (DMR x 4) tests will be performed per cycle.
7:0	DMG	0x00	RW	<b>Delta Modulator Gain Step</b>
				This field sets the initial gain step size (the "delta") for the delta modulator. This field represents a number of codes at the resolution selected by CRMODE.

## 34.13.19 CSEN\_ANACTRL - Analog Control

Offset	Bit Position																																					
0x048	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0						
Reset													0x0													0x0												
Access													RW													RW												
Name													TRSTPROG													IDACIREFS												

Bit	Name	Reset	Access	Description
31:23	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
22:20	TRSTPROG	0x0	RW	<b>Reset Timing</b>  This field adjusts the amount of time used to discharge the external capacitor during a conversion. Reset timing is increased for larger values of TRSTPROG.
19:11	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
10:8	IDACIREFS	0x0	RW	<b>Current DAC and Reference Current Scale</b>  This field adjusts the currents used in the CSEN block. This directly affects the drive strength to the external capacitor. For IDACIREFS = 0, the maximum drive strength is used. For IDACIREFS = 1 to 7, the relative drive strength is (IDACIREFS / 8).
7	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
6:4	IREFPROG	0x7	RW	<b>Reference Current Control.</b>  This field sets the relative magnitude of the current source that charges the internal reference cap. Lower settings allow for larger external capacitance, and higher settings allow for more precise measurements on smaller capacitors.
3:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>

## 34.13.20 CSEN\_IF - Interrupt Flag

Offset	Bit Position																															
0x054	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																										0	0	0	0	0		
Access																										R	0	0	0	0		
Name																										APORTCONFLICT	R	0	0	0		
																										DMAOF	R	0	0	0		
																										EOS	R	0	0	0		
																										CONV	R	0	0	0		
																										CMP	R	0	0	0		

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	APORTCONFLICT	0	R	<b>APORT Conflict Interrupt Flag</b>  1 if any of the BUSes being requested by the CSEN are also being requested by another peripheral
3	DMAOF	0	R	<b>DMA Overflow Interrupt Flag.</b>  When DMAEN is 1, this flag will be set to 1 by hardware if DMA does not read the DATA register and a new conversion completes.
2	EOS	0	R	<b>End of Scan Interrupt Flag.</b>  This flag is set to 1 at the end of a scan cycle, after all channels have been converted.
1	CONV	0	R	<b>Conversion Done Interrupt Flag</b>  This flag is set to 1 when a data conversion is complete and the result has been posted to DATA.
0	CMP	0	R	<b>Digital Comparator Interrupt Flag</b>  This flag is set to 1 when a CSEN comparator event has happened.

## 34.13.21 CSEN\_IFS - Interrupt Flag Set

Offset	Bit Position																										
0x058	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5
Reset																									4	0	
Access																									W1	0	
Name																									APORTCONFLICT	W1	0
																									DMAOF	W1	0
																									EOS	W1	0
																									CONV	W1	0
																									CMP	W1	0

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
4	APORTCONFLICT	0	W1	<b>Set APORTCONFLICT Interrupt Flag</b>  Write 1 to set the APORTCONFLICT interrupt flag
3	DMAOF	0	W1	<b>Set DMAOF Interrupt Flag</b>  Write 1 to set the DMAOF interrupt flag
2	EOS	0	W1	<b>Set EOS Interrupt Flag</b>  Write 1 to set the EOS interrupt flag
1	CONV	0	W1	<b>Set CONV Interrupt Flag</b>  Write 1 to set the CONV interrupt flag
0	CMP	0	W1	<b>Set CMP Interrupt Flag</b>  Write 1 to set the CMP interrupt flag


## 34.13.22 CSEN\_IFC - Interrupt Flag Clear

Offset	Bit Position																										
0x05C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5
Reset																											
Access																											
Name																											
Bit	Name	Reset	Access	Description																							
31:5	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																									
4	APORTCONFLICT	0	(R)W1	<b>Clear APORTCONFLICT Interrupt Flag</b>	Write 1 to clear the APORTCONFLICT interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).																						
3	DMAOF	0	(R)W1	<b>Clear DMAOF Interrupt Flag</b>	Write 1 to clear the DMAOF interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).																						
2	EOS	0	(R)W1	<b>Clear EOS Interrupt Flag</b>	Write 1 to clear the EOS interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).																						
1	CONV	0	(R)W1	<b>Clear CONV Interrupt Flag</b>	Write 1 to clear the CONV interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).																						
0	CMP	0	(R)W1	<b>Clear CMP Interrupt Flag</b>	Write 1 to clear the CMP interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).																						

### 34.13.23 CSEN\_IEN - Interrupt Enable

Bit	Name	Reset	Access	Description
31:5	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
4	APORTCONFLICT	0	RW	<b>APORTCONFLICT Interrupt Enable</b> Enable/disable the APORTCONFLICT interrupt
3	DMAOF	0	RW	<b>DMAOF Interrupt Enable</b> Enable/disable the DMAOF interrupt
2	EOS	0	RW	<b>EOS Interrupt Enable</b> Enable/disable the EOS interrupt
1	CONV	0	RW	<b>CONV Interrupt Enable</b> Enable/disable the CONV interrupt
0	CMP	0	RW	<b>CMP Interrupt Enable</b> Enable/disable the CMP interrupt

## 35. CAN - Controller Area Network



Quick Facts	
<b>What?</b>	The Controller Area Network (CAN) is a serial communications protocol which efficiently supports distributed realtime control with a very high level of security.
<b>Why?</b>	The domain of applications for CAN ranges from high speed networks to low cost multiplex wiring. In automotive electronics, engine control units, sensors, anti-skid-systems and more are connected using CAN with bitrates up to 1 Mbit/s. At the same time it is cost effective to build into vehicle body electronics, such as lamp clusters and electric windows, to replace the wiring harness otherwise required.
<b>How?</b>	It provides support for broadcast and multicast communication, with deterministic resolution of contention and robust error detection and signaling.

### 35.1 Introduction

CAN is a robust multimaster bus supporting a high data transfer rate of 1 Mbit/s and sophisticated error detection and error handling. The CAN peripheral supports up to 32 different message objects for automatic filtering of received messages. Multiple message object locations can be programmed with the same identifier mask to implement receive message FIFOs.

### 35.2 Features

- Supports CAN protocol version 2.0 part A, B
- Bitrates up to 1 Mbit/s
- Disable Automatic Retransmission mode for Time Triggered CAN applications
- 32 Message Objects
- Each Message Object has its own Identifier Mask
- Programmable FIFO mode
- Maskable interrupt
- Programmable loopback mode for self test operation
- Message RAM retention in EM2




Figure 35.1. Block Diagram

### 35.3 Functional Description

#### 35.3.1 Operating Modes

### 35.3.1.1 Software Initialization

The software initialization is started by setting the bit INIT in the CANn\_CTRL Register, either by software or by a hardware reset, or by going bus-off.

While INIT is set, all message transfer to and from the CAN bus is stopped, the status of the CAN bus output CAN\_TX is recessive (HIGH). The REC and TEC of the CANn\_ERRCNT are unchanged. Setting INIT does not change any configuration register.

To initialize the CAN Controller, the CPU has to set up the Bit Timing Register (CANn\_BITTIMING) and each Message Object. Message Object is a collective representation of the bits in the Message Interface Registers (CANn\_MIRx\_CMDMASK, CANn\_MIRx\_MASK, etc.). More details about the Message Object are stated in [35.3.3 Message Object in the Message Memory](#). If a Message Object is not needed, it is sufficient to set its MSGVAL bit in CANn\_MIRx\_ARB to not valid. Otherwise, the whole Message Object has to be initialized.

Access to the Bit Timing Register (CANn\_BITTIMING) and to the BRP Extension Register (CANn\_BRPE) for the configuration of the bit timing is enabled when both bits INIT and CCE in the CANn\_CTRL register are set.

Resetting INIT (by CPU only) finishes the software initialization. Afterwards, the module synchronizes itself to the data transfer on the CAN bus by waiting for the occurrence of a sequence of 11 consecutive recessive bits ("bus idle") before it can take part in bus activities and start the message transfer.

The initialization of the Message Objects is independent of INIT and can be done at runtime, but the Message Objects should all be configured to particular identifiers or set to not valid before the message transfer begins.

To change the configuration of a Message Object during normal operation, the CPU has to start by setting MSGVAL to not valid. When the configuration is completed, MSGVAL is set to valid again.

**Table 35.1. Software Initialization**

INIT Bit Value	Description
0	Normal Operation
1	Initialization is started

### 35.3.1.2 CAN Message Transfer

Received messages are stored into their appropriate Message Objects if they pass acceptance filtering. The whole message including all the arbitration bits, DLC and 8 data bytes is stored into the Message Object. If the Identifier Mask is used, the arbitration bits which are masked to "don't care" may be overwritten in the Message Object.

Messages to be transmitted are updated by the CPU. If a permanent Message Object (arbitration and control bits set up during configuration) exists for the message, only the data bytes are updated and then TXRQST bit and DATAVALID bit are set in CANn\_MIRx\_CTRL to start the transmission. If several transmit messages are assigned to the same Message Object (when the number of Message Objects is not sufficient), the whole Message Object has to be configured before the transmission of this message is requested.

The transmission of any number of Message Objects may be requested at the same time, they are transmitted subsequently according to their internal priority. Messages may be updated or set to not valid any time, even when their requested transmission is still pending. The old data will be discarded when a message is updated before its pending transmission has started.

Depending on the configuration of the Message Object, the transmission of a message may be requested autonomously by the reception of a remote frame with a matching identifier.

### 35.3.1.3 Disabled Automatic Retransmission

According to the CAN Specification (see ISO11898), the CAN module provides means for automatic retransmission of frames that have lost arbitration or that have been disturbed by errors during transmission. The frame transmission service will not be confirmed to the user before the transmission is successfully completed. By default, this means for automatic retransmission is enabled. It can be disabled to enable the CAN module to work within a Time Triggered CAN (TTCAN, see ISO11898-1) environment.

The Disabled Automatic Retransmission mode is enabled by programming bit DAR in the CANn\_CTRL to 1. In this operation mode, the programmer has to consider the different behaviour of the TXRQST and DATAVALID bits in the Control Registers of the Message Buffers (CANn\_MIRx\_CTRL):

- When a transmission starts, TXRQST of the respective Message Buffer is reset, while DATAVALID remains set.
- When the transmission is completed successfully, the DATAVALID bit is reset.

When a transmission failed (lost arbitration or error) bit DATAVALID remains set. To restart the transmission the CPU has to set TXRQST back to 1.

### 35.3.1.4 Test Mode

The Test Mode is entered by setting the TEST bit in CANn\_CTRL to 1. In Test Mode, the bits TX1, TX0, LBACK, SILENT and BASIC in CANn\_TEST are writable. RX monitors the state of pin CAN\_RX and therefore is only readable. All Test Register functions are disabled when the bit TEST is reset to 0.

### 35.3.1.5 Silent Mode

The CAN module can be set in Silent Mode by programming the SILENT bit in CANn\_TEST to 1.

In Silent Mode, the CAN is able to receive valid data frames and valid remote frames, but it sends only recessive bits on the CAN bus and it cannot start a transmission. If the CAN core is required to send a dominant bit (ACK bit, overload flag, active error flag), the bit is rerouted internally so that the CAN module monitors this dominant bit, although the CAN bus may remain in recessive state. The Silent Mode can be used to analyse the traffic on a CAN bus without affecting it by the transmission of dominant bits (Acknowledge Bits, Error Frames). [Figure 35.2 CAN Core in Silent Mode on page 1227](#) shows the connection of signals CAN\_TX and CAN\_RX to the CAN core in Silent Mode.




Figure 35.2. CAN Core in Silent Mode

### 35.3.1.6 Loop Back Mode

The CAN module can be set in Loop Back Mode by programming the CANn\_TEST bit LBACK to 1 . In Loop Back Mode, the module treats its own transmitted messages as received messages and stores them (if they pass acceptance filtering) into a Receive Buffer. Figure 35.3 CAN Core in Loop Back Mode on page 1228 shows the connection of signals CAN\_TX and CAN\_RX to the CAN core in Loop Back Mode.

This mode is provided for self-test functions. To be independent from external stimulation, the CAN core ignores acknowledge errors (recessive bit sampled in the acknowledge slot of a data/ remote frame) in Loop Back Mode. In this mode the CAN core performs an internal feedback from its Tx output to its Rx input. The actual value of the CAN\_RX input pin is disregarded by the CAN core. The transmitted messages can be monitored at the CAN\_TX pin.





Figure 35.3. CAN Core in Loop Back Mode

### 35.3.1.7 Loop Back Combined With Silent Mode

It is also possible to combine Loop Back Mode and Silent Mode by programming bits LBACK and SILENT to 1 at the same time. This mode can be used for a “Hot Selftest”, meaning the CAN can be tested without affecting a running CAN system connected to the pins CAN\_TX and CAN\_RX. In this mode the CAN\_RX pin is disconnected from the CAN core and the CAN\_TX pin is held recessive. [Figure 35.4 CAN Core in Loop Back Combined With Silent Mode on page 1229](#) shows the connection of signals CAN\_TX and CAN\_RX to the CAN core in case of the combination of Loop Back Mode with Silent Mode.



**Figure 35.4. CAN Core in Loop Back Combined With Silent Mode**

### 35.3.1.8 Basic Mode

The CAN module can be set in Basic Mode by programming the CANn\_TEST bit BASIC to 1

The CANn\_MIR0 Registers are used as Transmit Buffer. The transmission of the contents of the CANn\_MIR0 Registers is requested by writing the BUSY bit of the CANn\_MIR0 Command Request Register to 1. The CANn\_MIR0 Registers are locked while the BUSY bit is set. The BUSY bit indicates that the transmission is pending.

As soon the CAN bus is idle, the CANn\_MIR0 Registers are loaded into the shift register of the CAN core and the transmission is started. When the transmission has completed, the BUSY bit is reset and the locked CANn\_MIR0 Registers are released.

A pending transmission can be aborted at any time by resetting the BUSY bit in the CANn\_MIR0 Command Request Register while the CANn\_MIR0 Registers are locked. If the CPU has reset the BUSY bit, a possible retransmission in case of lost arbitration or in case of an error is disabled.

The CANn\_MIR1 Registers are used as Receive Buffer. After the reception of a message the contents of the shift register is stored into the CANn\_MIR1 Registers, without any acceptance filtering.

Additionally, the actual contents of the shift register can be monitored during the message transfer. Each time a read Message Object is initiated by writing the BUSY bit of the CANn\_MIR1\_CMDREQ Register to 1, the contents of the shift register is stored into the CANn\_MIR1 Registers.

In basic mode the evaluation of all Message Object related control and status bits and of the control bits of the CANn\_MIRx\_CMDMASK Registers is turned off. The message number of the CANn\_MIRx\_CMDREQ registers is not evaluated. The DATAVALID and MESSAGEOF bits of the CANn\_MIR1\_CTRL Register retain their function, DLC3-0 will show the received DLC, the other control bits will be read as 0.

### 35.3.1.9 Software Control of Pin CAN\_TX

4 output functions are available for the CAN transmit pin CAN\_TX. Additionally to its default function -- the serial data output -- it can drive the CAN Sample Point signal to monitor the CAN core's bit timing and it can drive constant dominant or recessive values. The last two functions, combined with the readable CAN receive pin CAN\_RX, can be used to check the CAN bus physical layer.

The output mode of the CAN\_TX pin is selected by programming the CANn\_TEST bits TX1 and TX0

The three test functions for the CAN\_TX pin interfere with all CAN protocol functions. CAN\_TX must be left in its default function when CAN message transfer or any of the test modes Loop Back Mode, Silent Mode, or Basic Mode are selected.

### 35.3.2 Message Interface Register Sets

There are two sets of Interface Registers (CANn\_MIRx) which are used to control the CPU access to the Message RAM. The Interface Registers avoid conflicts between CPU access to the Message RAM and CAN message reception and transmission by buffering the data to be transferred. A complete Message Object or parts of the Message Object may be transferred between the Message RAM and the CANn\_MIRx Message Buffer registers in one single transfer.

The function of the two interface register sets is identical (except for test mode BASIC). They can be used the way that one set of registers is used for data transfer to the Message RAM while the other set of registers is used for the data transfer from the Message RAM, allowing both processes to be interrupted by each other.

Each set of Interface Registers consists of Message Buffer Registers (CANn\_MIRx\_DATAL and CANn\_MIRx\_DATAH) controlled by their own Command Registers (CANn\_MIRx\_CTRL). The Command Mask Register (CANn\_MIRx\_CMDMASK) specifies the direction of the data transfer and which parts of a Message Object will be transferred. The Command Request Register (CANn\_MIRx\_CMDREQ) is used to select a Message Object in the Message RAM as target or source for the transfer and to start the action specified in the Command Mask Register (CANn\_MIRx\_CMDMASK).

**Table 35.2. Interface Register Sets**

Interface Registers 0		Address		Interface Registers 1		Address	
CANn_BASE + 0x60		MIR0 Command Mask		CANn_BASE + 0x80		MIR1 Command Mask	
CANn_BASE + 0x64		MIR0 Mask		CANn_BASE + 0x84		MIR1 Mask	
CANn_BASE + 0x68		MIR0 Arbitration		CANn_BASE + 0x88		MIR1 Arbitration	
CANn_BASE + 0x6C		MIR0 Message Control		CANn_BASE + 0x8C		MIR1 Message Control	
CANn_BASE + 0x70		MIR0 DATA L		CANn_BASE + 0x90		MIR1 DATA L	
CANn_BASE + 0x74		MIR0 DATA H		CANn_BASE + 0x94		MIR1 DATA H	
CANn_BASE + 0x78		MIR0 Command Request		CANn_BASE + 0x98		MIR1 Command Request	

### 35.3.3 Message Object in the Message Memory

There are 32 Message Objects in the Message RAM. To avoid conflicts between CPU access to the Message RAM and CAN message reception and transmission, the CPU cannot directly access the Message Objects, these accesses are handled via the CANn\_MIRx Interface Registers. The bit definitions can be found in descriptions of the CANn\_MIRx registers.

**Table 35.3. Message Object**

UMASK	MSK28-0	MXTD	MDIR	EOB	DATA-VALID	MESSA-GEOF	RXIE	TXIE	INTPND	RMTE	TXRQS T	N.A.
MSGVAL	ID28-0	XTD	DIR	DLC3-0	DATA0	DATA1	DATA2	DATA3	DATA4	DATA5	DATA6	DATA7

### 35.3.4 Management of Message Objects

All the Message Objects must be initialized by the CPU or they must be not valid (MSGVAL = 0) and the bit timing must be configured before the CPU clears the INIT bit in the CANn\_CTRL Register.

The configuration of a Message Object is done by programming Mask, Arbitration, Control and Data field of one of the two interface register sets to the desired values. By writing to the corresponding CANn\_MIRx\_CMDREQ Register, the CANn\_MIRx\_DATAL and CANn\_MIRx\_DATAH Registers are loaded into the addressed Message Object in the Message RAM.

The CPU reads received messages and updates messages to be transmitted via the CANn\_MIRx Interface Registers. Depending on the configuration, the CPU is interrupted on certain CAN message and CAN error events.

### 35.3.5 Data Transfer From/to Message RAM

When the CPU initiates a data transfer between the CANn\_MIRx Registers and Message RAM, the Message Handler sets the BUSY bit in the respective CANn\_MIRx\_CMDREQ to 1. After the transfer has completed, the BUSY bit is set back to 0.

The respective Command Mask Register CANn\_MIRx\_CMDSMASK specifies whether a complete Message Object or only parts of it will be transferred. Due to the structure of the Message RAM it is not possible to write single bits/bytes of one Message Object, it is always necessary to write a complete Message Object into the Message RAM. Therefore the data transfer from the CANn\_MIRx Registers to the Message RAM requires of a read-modify-write cycle. First that parts of the Message Object that are not to be changed are read from the Message RAM and then the complete contents of the Message Buffer (CANn\_MIRx\_DATAL and CANn\_MIRx\_DATAH) Registers are transferred into the Message Object.

After the partial write of a Message Object, that Message Buffer (CANn\_MIRx\_DATAL and CANn\_MIRx\_DATAH) Registers that are not selected in the Command Mask CANn\_MIRx\_CMDSMASK Register will set to the actual contents of the selected Message Object.

After the partial read of a Message Object, that Message Buffer (CANn\_MIRx\_DATAL and CANn\_MIRx\_DATAH) Registers that are not selected in the Command Mask CANn\_MIRx\_CMDSMASK Register will be left unchanged.

### 35.3.6 Transmission of Messages

If the shift register of the CAN is ready for loading and if there is no data transfer between the CANn\_MIRx Registers and Message RAM, the VALID bits in the CANn\_MESSAGESTATE Register and TXRQSTOUT bits in the CANn\_TRANSREQ Register are evaluated. The valid Message Object with the highest priority pending transmission request is loaded into the shift register and the transmission is started. The Message Object's DATAVALID bit is reset.

After a successful transmission and if no new data was written to the Message Object (DATAVALID = 0) since the start of the transmission, the TXRQST bit will be reset. If TXIE in CANn\_MIRx\_CTRL is set, INTPND in CANn\_MIRx\_CTRL will be set after a successful transmission. If the CAN module has lost the arbitration or if an error occurred during the transmission, the message will be retransmitted as soon as the CAN bus is free again. If meanwhile the transmission of a message with higher priority has been requested, the messages will be transmitted in the order of their priority.

### 35.3.7 Acceptance Filtering of Received Messages

When the arbitration and control field (Identifier + IDE + RTR + DLC) of an incoming message is completely shifted into the Rx/Tx Shift Register of the CAN module, it starts the scanning of the Message RAM for a matching valid Message Object.

To scan the Message RAM for a matching Message Object, the arbitration bits from the CAN shift register and then the arbitration and mask fields (including MSGVAL, UMASK, DATAVALID, and EOB) of Message Object 1 are compared. This is repeated with each following Message Object until a matching Message Object is found or until the end of the Message RAM is reached.

If a match occurs, the scanning is stopped and the Module proceeds depending on the type of frame (Data Frame or Remote Frame) received.

#### 35.3.7.1 Reception of Data Frame

Not only the data bytes, but all arbitration bits and the Data Length Code are stored into the corresponding Message Object. This is implemented to keep the data bytes connected with the identifier even if arbitration mask registers are used.

The DATAVALID bit is set to indicate that new data (not yet seen by the CPU) has been received. The CPU should reset DATAVALID when it reads the Message Object. If at the time of the reception the DATAVALID bit was already set, MESSAGEOF is set to indicate that the previous data (supposedly not seen by the CPU) is lost. If the RXIE bit is set, the INTPND bit is set, causing the Interrupt Register CANn\_INTID to point to this Message Object.

The TXRQST bit of this Message Object is reset to prevent the transmission of a Remote Frame, while the requested Data Frame has just been received.

### 35.3.7.2 Reception of Remote Frame

When a Remote Frame is received, 3 difference configurations of the matching Message Object have to be considered:

- DIR = 1 (direction = transmit), RMTEN = 1, UMASK = 1 or 0. At the reception of a matching Remote Frame, the TXRQST bit of this Message Object is set. The rest of the Message Object remains unchanged
- DIR = 1 (direction = transmit), RMTEN = 0, UMASK = 0. At the reception of a matching Remote Frame, the TXRQST bit of this Message Object remains unchanged; the Remote Frame is ignored.
- DIR = 1 (direction = transmit), RMTEN = 0, UMASK = 1. At the reception of a matching Remote Frame, the TXRQST bit of this Message Object is reset. The arbitration and control field (Identifier + IDE + RTR + DLC) from the shift register is stored into the Message Object in the Message RAM and the DATVALID bit of this Message Object is set. The data fiield of the Message Object remains unchanged; the Remote Frame is treated similar to a received Data Frame.

### 35.3.8 Receive/Transmit Priority

The receive/transmit priority for the Message Objects is attached to the message number. Message Object 1 has the highest priority, while Message Object 32 has the lowest priority. If more than one transmission request is pending, they are serviced due to the priority of the corresponding Message Object.

### 35.3.9 Configuration of a Transmit Object

**Table 35.4. Configuration of Transmit Object**

MSGVAL	ARB	DATA	MASK	EOB	DIR	DATA-VALID	MESSA-GEOF	RXIE	TXIE	INTPND	RMTEN	TXRQS T
1	Application	Application	Application	1	1	0	0	0	Application	0	Application	0

The Arbitration Registers (ID28-0 and XTD bit) are given by the application. They define the identifier and type of the outgoing message. If an 11-bit Identifier ("Standard Frame") is used, it is programmed to ID28 - ID18, ID17 - ID0 can then be disregarded

If the RMTEN bit is set, a matching received Remote Frame will cause the TXRQST bit to be set; the Remote Frame will autonomously be answered by a Data Frame

The Data Registers (DLC3-0, Data0-7) are given by the application, TXRQST and RMTEN may not be set before the data is valid

The Mask Registers (MASK28-0, UMASK, MXTD, and MDIR bits) may be used (UMASK='1') to allow groups of Remote Frames with similar identifiers to set the TXRQST bit.

### 35.3.10 Updating a Transmit Object

The CPU may update the data bytes (DATA7:0) of a Transmit Object any time via the CANn\_MIRx Interface registers, neither MSGVAL nor TXRQST have to be reset before the update.

Even if only a part of the data bytes are to be updated, all four bytes of the corresponding CANn\_MIRx\_DATAL Register or MIRx CANn\_MIRx\_DATAH Register have to be valid before the content of that register is transferred to the Message Object. Either the CPU has to write all four bytes into the MIRx Data Register or the Message Object is transferred to the MIRx Data Register before the CPU writes the new data bytes.

When only the (eight) data bytes are updated, first 0x0087 is written to the Command Mask Register and then the number of the Message Object is written to the Command Request Register, concurrently updating the data bytes and setting TXRQST.

To prevent the reset of TXRQST at the end of a transmission that may already be in progress while the data is updated, DATAVALID has to be set together with TXRQST.

When DATAVALID is set together with TXRQST, DATAVALID will be reset as soon as the new transmission has started.




Figure 35.5. Data Transfer Between MIRx Registers and the Message RAM

### 35.3.11 Configuration of a Receive Object

**Table 35.5. Configuration of Receive Object**

MSGVAL	ARB	DATA	MASK	EOB	DIR	DATA-VALID	MESSA-GEOF	RXIE	TXIE	INTPND	RMTEN	TXRQST
1	Application	Application	Application	1	0	0	0	Application	0	0	0	0

The Arbitration Registers (ID28-0 and XTD bit) are given by the application. They define the identifier and type of accepted received messages. If an 11-bit Identifier ("Standard Frame") is used, it is programmed to ID28 - ID18, ID17 - ID0 can then be disregarded. When a Data Frame with an 11-bit Identifier is received, ID17 - ID0 will be set to '0.'

If the RxIE bit is set, the INTPND bit will be set when a received Data Frame is accepted and stored in the Message Object.

The Data Length Code (DLC3-0) is given by the application. When the Message Handler stores a Data Frame in the Message Object, it will store the received Data Length Code and eight data bytes. If the Data Length Code is less than 8, the remaining bytes of the Message Object will be overwritten by non specified values.

The Mask Registers (MASK28-0, UMASK, MXTD, and MDIR bits) may be used (UMask='1') to allow groups of Data Frames with similar identifiers to be accepted. The Dir bit should not be masked in typical applications.

### 35.3.12 Handling of Received Messages

The CPU may read a received message any time via the CANn\_MIRx Interface registers.

Typically the CPU will write first 0x007F to the Command Mask Register and then the number of the Message Object to the Command Request Register. That combination will transfer the whole received message from the Message RAM into the Message Buffer Register. Additionally, the bits DATAVALID and INTPND are cleared in the Message RAM (not in the Message Buffer).

If the Message Object uses masks for acceptance filtering, the arbitration bits show which of the matching messages has been received.

The actual value of DATAVALID shows whether a new message has been received since last time this Message Object was read. The actual value of MESSAGEOF shows whether more than one message has been received since last time this Message Object was read. MESSAGEOF will not be automatically reset.

By means of a Remote Frame, the CPU may request another CAN node to provide new data for a receive object. Setting the TXRQST bit of a receive object will cause the transmission of a Remote Frame with the receive object's identifier. This Remote Frame triggers the other CAN node to start the transmission of the matching Data Frame. If the matching Data Frame is received before the Remote Frame could be transmitted, the TXRQST bit is automatically reset.

### 35.3.13 Configuration of a FIFO Buffer

With the exception of the EOB bit, the configuration of Receive Objects belonging to a FIFO Buffer is the same as the configuration of a (single) Receive Object.

To concatenate two or more Message Objects into a FIFO Buffer, the identifiers and masks (if used) of these Message Objects have to be programmed to matching values. Due to the implicit priority of the Message Objects, the Message Object with the lowest number will be the first Message Object of the FIFO Buffer. The EOB bit of all Message Objects of a FIFO Buffer except the last have to be programmed to 0. The EOB bits of the last Message Object of a FIFO Buffer is set to 1, configuring it as the End of the Block.

### 35.3.14 Reception of Messages With FIFO Buffers

Received messages with identifiers matching to a FIFO Buffer are stored into a Message Object of this FIFO Buffer starting with the Message Object with the lowest message number.

When a message is stored into a Message Object of a FIFO Buffer the DATAVALID bit of this Message Object is set. By setting DATAVALID while EOB is 0 the Message Object is locked for further write accesses by the Message Handler until the CPU has written the DATAVALID bit back to 0.

Messages are stored into a FIFO Buffer until the last Message Object of this FIFO Buffer is reached. If none of the preceding Message Objects is released by writing DATAVALID to 0, all further messages for this FIFO Buffer will be written into the last Message Object of the FIFO Buffer and will therefore overwrite previous messages.

### 35.3.15 Reading From a FIFO Buffer

When the CPU transfers the contents of Message Object to the CANn\_MIRx Message Buffer registers by writing its number to the MIRx Command Request Register, the corresponding Command Mask Register should be programmed the way that bits DATAVALID and INTPND are reset to 0 (TXRQST/DATAVALID = 1 and CLRINTPND = 1). The values of these bits in the Message Control Register always reflect the status before resetting the bits.

To assure the correct function of a FIFO Buffer, the CPU should read out the Message Objects starting at the FIFO Object with the lowest message number.

### 35.3.16 Handling of Interrupts

If several interrupts are pending, the CAN Interrupt Identification Register will point to the pending interrupt with the highest priority, disregarding their chronological order. An interrupt remains pending until the CPU has cleared it.

The Status Interrupt has the highest priority. Among the message interrupts, the Message Object's interrupt priority decreases with increasing message number.

A message interrupt is cleared by clearing the Message Object's INTPND bit. The Status Interrupt is cleared by reading the CANn\_STATUS Register or by using the CANn\_IF0IFC and CANn\_IF1IFC registers respectively.

The interrupt identifier INTID in the CANn\_INTID Register indicates the cause of the interrupt. When no interrupt is pending, the register will hold the value 0. If the value of the CANn\_INTID Register is different from 0, then there is an interrupt pending and, if IE is set, the interrupt line to the CPU, is active (unless the corresponding bits in the CANn\_IF0IEN and CANn\_IF1IEN are 0). The interrupt line remains active until the CANn\_INTID is back to value zero (the cause of the interrupt is reset) or until IE is reset.

The value 0x8000 indicates that an interrupt is pending because the CAN has updated (not necessarily changed) the Status Register (Error Interrupt or Status Interrupt). This interrupt has the highest priority. The CPU can update (reset) the status bits RXOK, TXOK and LEC, but a write access of the CPU to the Status Register can never generate or reset an interrupt.

All other values indicate that the source of the interrupt is one of the Message Objects, INTID points to the pending message interrupt with the highest interrupt priority.

The CPU controls whether a change of the Status Register may cause an interrupt (bits EIE and SIE in the CAN Control Register) and whether the interrupt line becomes active when the Interrupt Identification Register is different from zero (the IF1IEN register and the bit IE in the CAN Control Register). The Interrupt Identification Register will be updated even when IE is reset

The CPU has 3 possibilities to follow the source of a message interrupt. First, it can follow the INTID in the Interrupt Identification Register. Second, it can poll the Interrupt Pending Register and finally it can read the CANn\_IF0IF register.

An interrupt service routine reading the message that is the source of the interrupt may read the message and reset the Message Object's INTPND at the same time (bit CLRINTPND in the Command Mask Register). When INTPND is cleared, the CANn\_INTID will point to the next Message Object with a pending interrupt.

### 35.3.17 Configuration of the Bit Timing

Even if minor errors in the configuration of the CAN bit timing do not result in immediate failure, the performance of a CAN network can be reduced significantly. In many cases, the CAN bit synchronisation will amend a faulty configuration of the CAN bit timing to such a degree that only occasionally an error frame is generated. In the case of arbitration however, when two or more CAN nodes simultaneously try to transmit a frame, a misplaced sample point may cause one of the transmitters to become error passive.

**Table 35.6. Parameters of the CAN Bit Time**


Parameter	Range	Remark
BRP	[1..32]	Defines the length of the time quantum $t_q$
Sync_Seg	$1 t_q$	fixed length, synchronization of bus input to the system clock
Prop_Seg	[1..8] $t_q$	compensates for the physical delay times
Phase_Seg1	[1..8] $t_q$	may be lengthened temporarily by synchronization
Phase_Seg2	[1..8] $t_q$	may be shortened temporarily by synchronization
SJW	[1..4] $t_q$	may not be longer than either Phase Buffer Segment

### 35.3.17.1 Bit Time and Bit Rate

CAN supports bit rates in the range of lower than 1 kBit/s up to 1000 kBit/s. Each member of the CAN network has its own clock generator, usually a quartz oscillator. The timing parameter of the bit time (i.e. the reciprocal of the bit rate) can be configured individually for each CAN node, creating a common bit rate even though the CAN nodes' oscillator periods osc may be different.

According to the CAN specification, the bit time is divided into four segments. The Synchronization Segment, the Propagation Time Segment, the Phase Buffer Segment 1, and the Phase Buffer Segment 2. Each segment consists of a specific, programmable number of time quanta. The length of the time quantum ( $t_q$ ), which is the basic time unit of the bit time, is defined by the CAN controller's system clock  $f_{sys}$  and the Baud Rate Prescaler (BRP):  $t_q = BRP / f_{sys}$ .

The Synchronisation Segment Sync\_Seg is that part of the bit time where edges of the CAN bus level are expected to occur; the distance between an edge that occurs outside of Sync\_Seg and the Sync\_Seg is called the phase error of that edge. The Propagation Time Segment (Prop\_Seg) is intended to compensate for the physical delay times within the CAN network. The Phase Buffer Segments (Phase\_Seg1) and (Phase\_Seg2) surround the Sample Point. The (Re-)Synchronisation Jump Width (SJW) defines how far a resynchronisation may move the Sample Point inside the limits defined by the Phase Buffer Segments to compensate for edge phase errors.



**Figure 35.6. Bit Timing**

### 35.3.17.2 EM2 Operation

The CAN module is retained in EM2 (including the Message RAM). However, to ensure that the Message RAM data is not corrupted, the INIT bit in the Control Register needs to be 1 before entering EM2. This will mean that the user will have to clear the INIT upon exit from EM2 so that the CAN module can resynchronize itself to the bus and then take part in the sending and receiving of messages.

### 35.3.17.3 Software BIST for Message RAM

The Message RAM is tested using a software BIST. The CANn\_MDATA and the CANn\_MEMACC registers are present for this purpose. The CANn\_MDATA register is used to hold the read/write data from/to the RAM and CANn\_MEMACC is used to access a particular memory location. It should be noted, that the Message RAM is 32 locations deep and 136 bits wide so to exercise a location in its entirety the SUBWORD field needs to be used (since access is restricted to word boundaries).

### 35.4 Register Map

The offset register address is relative to the registers base address.

Offset	Name	Type	Description
0x000	CANn_CTRL	RW	Control Register
0x004	CANn_STATUS	RWH	Status Register
0x008	CANn_ERRCNT	R	Error Count Register
0x00C	CANn_BITTIMING	RW	Bit Timing Register
0x010	CANn_INTID	R	Interrupt Identification Register
0x014	CANn_TEST	RWH	Test Register
0x018	CANn_BRPE	RW	BRP Extension Register
0x01C	CANn_TRANSREQ	R	Transmission Request Register
0x020	CANn_MESSAGEDATA	R	New Data Register
0x028	CANn_MESSAGESTATE	R	Message Valid Register
0x02C	CANn_CONFIG	RW	Configuration Register
0x030	CANn_IF0IF	R	Message Object Interrupt Flag Register
0x034	CANn_IF0IFS	W1	Message Object Interrupt Flag Set Register
0x038	CANn_IF0IFC	(R)W1	Message Object Interrupt Flag Clear Register
0x03C	CANn_IF0IEN	RW	Message Object Interrupt Enable Register
0x040	CANn_IF1IF	R	Status Interrupt Flag Register
0x044	CANn_IF1IFS	W1	Message Object Interrupt Flag Set Register
0x048	CANn_IF1IFC	(R)W1	Message Object Interrupt Flag Clear Register
0x04C	CANn_IF1IEN	RW	Status Interrupt Enable Register
0x050	CANn_ROUTE	RW	I/O Routing Register
0x060	CANn_MIRO_CMDMASK	RW	Interface Command Mask Register
0x064	CANn_MIRO_MASK	RW	Interface Mask Register
0x068	CANn_MIRO_ARB	RW	Interface Arbitration Register
0x06C	CANn_MIRO_CTRL	RWH	Interface Message Control Register
0x070	CANn_MIRO_DATAL	RW	Interface Data a Register
0x074	CANn_MIRO_DATAH	RW	Interface Data B Register
0x078	CANn_MIRO_CMDREQ	RWH	Interface Command Request Register
0x080	CANn_MIR1_CMDMASK	RW	Interface Command Mask Register
0x084	CANn_MIR1_MASK	RW	Interface Mask Register
0x088	CANn_MIR1_ARB	RW	Interface Arbitration Register
0x08C	CANn_MIR1_CTRL	RWH	Interface Message Control Register
0x090	CANn_MIR1_DATAL	RW	Interface Data a Register
0x094	CANn_MIR1_DATAH	RW	Interface Data B Register
0x098	CANn_MIR1_CMDREQ	RWH	Interface Command Request Register

## 35.5 Register Description

### 35.5.1 CANn\_CTRL - Control Register

Offset	Bit Position																															
0x000	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	TEST	0	RW	<b>Test Mode Enable Write</b>  Enables access to the Test Register.
6	CCE	0	RW	<b>Configuration Change Enable</b>  Enables access to the Bit Timing Register
5	DAR	0	RW	<b>Disable Automatic Retransmission</b>  When set, automatic retransmission is disabled.
4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3	EIE	0	RW	<b>Error Interrupt Enable</b>  Enables error interrupts on status register change.
2	SIE	0	RW	<b>Status Change Interrupt Enable</b>  Enables status interrupts on status register change.
1	IE	0	RW	<b>Module Interrupt Enable</b>  Top level interrupt enable for the CAN module.
0	INIT	1	RW	<b>Initialize</b>  The Bus Off recovery sequence (see CAN Specification Rev. 2.0) cannot be shortened by setting or resetting INIT. If the device goes Bus Off, it will set INIT of its own accord, stopping all bus activities. Once INIT has been cleared by the CPU, the device will then wait for 129 occurrences of Bus Idle (129 * 11 consecutive recessive bits) before resuming normal operations. At the end of the Bus Off recovery sequence, the Error Management Counters will be reset. During the waiting time after the resetting of INIT, each time a sequence of 11 recessive bits has been monitored, a Bit0Error code is written to the Status Register, enabling the CPU to readily check whether the CAN bus is stuck at dominant or continuously disturbed and to monitor the proceeding of the Bus Off recovery sequence.

## 35.5.2 CANn\_STATUS - Status Register

Offset	Bit Position																																	
0x004	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0		
Reset																										0	0	0	0	0	0			
Access																										R	R	R	RW	RW	RW	RW	RW	RW
Name																										BOFF	EWARN	EPASS	RXOK	RXOK	TXOK	TXOK	LEC	

Bit	Name	Reset	Access	Description
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
7	BOFF	0	R	<b>Bus Off Status</b>
6	EWARN	0	R	<b>Warning Status</b>
5	EPASS	0	R	<b>Error Passive</b>
4	RXOK	0	RW	<b>Received a Message Successfully</b>
3	TXOK	0	RW	<b>Transmitted a Message Successfully</b>
2:0	LEC	0x0	RW	<b>Last Error Code</b>

The LEC field holds a code which indicates the type of the last error to occur on the CAN bus. This field will be cleared to '0' when a message has been transferred (reception or transmission) without error. The unused code 0x07 may be written by the CPU to check for updates.

Value	Mode	Description
0	NONE	No error occurred during last CAN bus event.
1	STUFF	More than 5 equal bits in a sequence have occurred in a part of a received message where this is not allowed.
2	FORM	A fixed format part of a received frame has the wrong format.
3	ACK	The message this CAN Core transmitted was not acknowledged by another node.
4	BIT1	During the transmission of a message (with the exception of the arbitration field), the device wanted to send a recessive level (bit of logical value 1), but the monitored bus value was dominant.
5	BIT0	During the transmission of a message (or acknowledge bit, or active error flag, or overload flag), the device wanted to send a dominant level (data or identifier bit logical value 0), but the monitored Bus value was recessive. During Bus Off recovery this status is set each time a sequence of 11 recessive bits has been monitored. This enables the CPU to monitor the proceeding of the Bus Off recovery sequence (indicating the bus is not stuck at dominant or continuously disturbed).

Bit	Name	Reset	Access	Description
6	CRC			The CRC check sum was incorrect in the message received; the CRC received for an incoming message does not match with the calculated CRC for the received data.
7	UNUSED			When the LEC shows the value '7', no CAN bus event was detected since the CPU wrote this value to the LEC.

### 35.5.3 CANN\_ERRCNT - Error Count Register

Offset	Bit Position																															
0x008	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0	0x00							0x00								
Access																R	R							R								
Name																RECERRP	REC							TEC								

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15	RECERRP	0	R	<b>Receive Error Passive</b>
	Value	Mode		Description
	0	FALSE		The Receive Error Counter is below the error passive level.
	1	TRUE		The Receive Error Counter has reached the error passive level as defined in the CAN Specification.
14:8	REC	0x00	R	<b>Receive Error Counter</b>
	Actual state of the Receive Error Counter. Values between 0 and 127.			
7:0	TEC	0x00	R	<b>Transmit Error Counter</b>
	Actual state of the Transmit Error Counter. Values between 0 and 255.			

## 35.5.4 CANn\_BITTIMING - Bit Timing Register

Offset	Bit Position																															
0x00C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																									0x01							
<b>Access</b>																									RW							
<b>Name</b>																									BRP							

Bit	Name	Reset	Access	Description
31:15	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
14:12	TSEG2	0x2	RW	<b>Time Segment After the Sample Point</b>
				The valid values for TSEG2 are [0.....7]. The actual interpretation by the hardware of this value is such that one more than the value programmed here is used.
11:8	TSEG1	0x3	RW	<b>Time Segment Before the Sample Point</b>
				The valid values for TSEG1 are [1.....15]. The actual interpretation by the hardware of this value is such that one more than the value programmed here is used.
7:6	SJW	0x0	RW	<b>Synchronization Jump Width</b>
				The valid programmed values are [0...3]. The actual interpretation by the hardware of this value is such that one more than the value programmed here is used.
5:0	BRP	0x01	RW	<b>Baud Rate Prescaler</b>
				The value by which the oscillator frequency is divided for generating the bit time quanta. The bit time is built up from a multiple of the quanta. Valid values for the Baud Rate Prescaler are [0...63]. The actual interpretation by the hardware of this value is such that one more than the value programmed here is used.

## 35.5.5 CANn\_INTID - Interrupt Identification Register

Offset	Bit Position																															
0x010	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																0											0x00					
Access																R											R					
Name																INTSTAT											INTID					

Bit	Name	Reset	Access	Description									
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>									
15	INTSTAT	0	R	<b>Status Interrupt</b>									
				A Status Interrupt is generated by bits BOFF and EWARN (Error Interrupt) or by RXOK, TXOK, and LEC (Status Change Interrupt) assumed that the corresponding enable bits in the CAN Control Register are set. A change of bit EPASS or a write to RXOK, TXOK, or LEC will never generate a Status Interrupt. Reading the Status Register will clear the Status Interrupt value (0x8000) in the Interrupt Identification Register, if it is pending.									
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>FALSE</td> <td>Status Interrupt is cleared</td> </tr> <tr> <td>1</td> <td>TRUE</td> <td>Status Interrupt is generated</td> </tr> </tbody> </table>	Value	Mode	Description	0	FALSE	Status Interrupt is cleared	1	TRUE	Status Interrupt is generated
Value	Mode	Description											
0	FALSE	Status Interrupt is cleared											
1	TRUE	Status Interrupt is generated											
14:6	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>									
5:0	INTID	0x00	R	<b>Interrupt Identifier</b>									
				Number here indicated the source of the interrupt. 0: No interrupt is pending. 1-32: Number of Message Object which caused the interrupt. 33-63: Unused.									

### 35.5.6 CANn\_TEST - Test Register

Offset	Bit Position																															
Reset	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	RX	R	0	7				
Access																										TX	RW	0x0	5			
Name																										LBACK	RW	0	4			

Bit	Name	Reset	Access	Description															
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															
7	RX	0	R	<b>Monitors the Actual Value of CAN_RX Pin</b>  Write a 1 to this bit to start timer.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>LOW</td><td>CAN bus is dominant.</td></tr> <tr> <td>1</td><td>HIGH</td><td>CAN bus is recessive.</td></tr> </tbody> </table>	Value	Mode	Description	0	LOW	CAN bus is dominant.	1	HIGH	CAN bus is recessive.						
Value	Mode	Description																	
0	LOW	CAN bus is dominant.																	
1	HIGH	CAN bus is recessive.																	
6:5	TX	0x0	RW	<b>Control of CAN_TX Pin</b>  The different test functions may be combined, but tx[1:0] not equal to 0 disturbs message transfer.															
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>CORE</td><td>Reset value, CAN_TX is controlled by the CAN Core.</td></tr> <tr> <td>1</td><td>SAMPT</td><td>Sample Point can be monitored at CAN_TX pin.</td></tr> <tr> <td>2</td><td>LOW</td><td>CAN_TX pin drives a dominant bit (0) value.</td></tr> <tr> <td>3</td><td>HIGH</td><td>CAN_TX pin drives a recessive bit (1) value.</td></tr> </tbody> </table>	Value	Mode	Description	0	CORE	Reset value, CAN_TX is controlled by the CAN Core.	1	SAMPT	Sample Point can be monitored at CAN_TX pin.	2	LOW	CAN_TX pin drives a dominant bit (0) value.	3	HIGH	CAN_TX pin drives a recessive bit (1) value.
Value	Mode	Description																	
0	CORE	Reset value, CAN_TX is controlled by the CAN Core.																	
1	SAMPT	Sample Point can be monitored at CAN_TX pin.																	
2	LOW	CAN_TX pin drives a dominant bit (0) value.																	
3	HIGH	CAN_TX pin drives a recessive bit (1) value.																	
4	LBACK	0	RW	<b>Loopback Mode</b>  When set, CAN treats its own transmitted messages as received messages.															
3	SILENT	0	RW	<b>Silent Mode</b>  When set, CAN is able to receive valid data frames and valid remote frames, but it sends only recessive bits on the CAN bus and it cannot start a transmission.															
2	BASIC	0	RW	<b>Basic Mode</b>  Enables low-level data transmit and receive via CANn_MIR0_xxx and CANn_MIR1_xxx registers.															
1:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>															

## 35.5.7 CANn\_BRPE - BRP Extension Register

Offset	Bit Position																											
0x018	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																											
Reset																												0x0
Access																												RW
Name																												BRPE

Bit	Name	Reset	Access	Description
31:4	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
3:0	BRPE	0x0	RW	<b>Baud Rate Prescaler Extension</b>  By programming BRPE the Baud Rate Prescaler can be extended to values up to 1023. The actual interpretation by the hardware is that one more than the value programmed by BRPE (MSBs) and BRP (LSBs) is used.

## 35.5.8 CANn\_TRANSREQ - Transmission Request Register

Offset	Bit Position																												
0x01C	31 30 29 28 27 26 25 24 23 22 21 20 19 18 17 16 15 14 13 12 11 10 9 8 7 6 5 4 3 2 1 0																												
Reset																												0x00000000	
Access																												R	
Name																													TXRQSTOUT

Bit	Name	Reset	Access	Description
31:0	TXRQSTOUT	0x00000000	R	<b>Transmission Request Bits (Of All Message Objects)</b>
By reading the TXRQSTOUT bits, the CPU can check for which Message Object's Transmission Request is pending.				
Value		Mode	Description	
0		FALSE	This Message Object is not waiting for transmission.	
1		TRUE	The transmission of this Message Object is requested and is not yet done.	

## 35.5.9 CANn\_MESSAGEDATA - New Data Register

Offset	Bit Position																															
0x020	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	VALID																															

Bit	Name	Reset	Access	Description
31:0	VALID	0x00000000	R	<b>DATAVALID Bits (of All Message Objects)</b>

By reading out the VALID bits, the CPU can check for which Message Object the data portion was updated.

## 35.5.10 CANn\_MESSAGESTATE - Message Valid Register

Offset	Bit Position																															
0x028	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00000000																															
Access	R																															
Name	VALID																															

Bit	Name	Reset	Access	Description
31:0	VALID	0x00000000	R	<b>Message Valid Bits (of All Message Objects)</b>

By reading out the VALID bits, the CPU can check which Message Object is valid.

## 35.5.11 CANn\_CONFIG - Configuration Register

Offset	Bit Position																															
0x02C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15	DBGHALT	0	RW	<b>Debug Halt</b>
	Value	Mode		Description
	0	NORMAL		Normal operation when debug mode is active
	1	STALL		Stall when debug mode is active. Register write access is blocked in this mode
14:0	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>

## 35.5.12 CANn\_IF0IF - Message Object Interrupt Flag Register

Offset	Bit Position																															
0x030	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset																																
Access																																
Name																																

Bit	Name	Reset	Access	Description
31:0	MESSAGE	0x00000000	R	<b>Message Object Interrupt Flag</b>

**35.5.13 CANn\_IF0IFS - Message Object Interrupt Flag Set Register**

Offset	Bit Position																															
0x034	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>	0x00000000																															
<b>Access</b>	W1																															
<b>Name</b>	MESSAGE																															

Bit	Name	Reset	Access	Description
31:0	MESSAGE	0x00000000	W1	<b>Set MESSAGE Interrupt Flag</b>
Write 1 to set the MESSAGE interrupt flag				

**35.5.14 CANn\_IF0IFC - Message Object Interrupt Flag Clear Register**

Offset	Bit Position																															
0x038	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>	0x00000000																															
<b>Access</b>	(R)W1																															
<b>Name</b>	MESSAGE																															

Bit	Name	Reset	Access	Description
31:0	MESSAGE	0x00000000	(R)W1	<b>Clear MESSAGE Interrupt Flag</b>
Write 1 to clear the MESSAGE interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).				

## 35.5.15 CANn\_IF0IEN - Message Object Interrupt Enable Register

Offset	Bit Position																																
0x03C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	0xFFFFFFFF																																
Access	RW																																
Name	MESSAGE																																
Bit	Name	Reset	Access	Description																													
31:0	MESSAGE	0xFFFFFFFF	RW	<b>MESSAGE Interrupt Enable</b>	Enable/disable the MESSAGE interrupt																												

## 35.5.16 CANn\_IF1IF - Status Interrupt Flag Register

Offset	Bit Position																																		
0x040	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0			
Reset	0																																		
Access	R																																		
Name	STATUS																																		
Bit	Name	Reset	Access	Description																															
31:1	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																																	
0	STATUS	0	R	<b>Status Interrupt Flag</b>																															

### 35.5.17 CANn\_IF1IFS - Message Object Interrupt Flag Set Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	STATUS	0	W1	<b>Set STATUS Interrupt Flag</b>  Write 1 to set the STATUS interrupt flag

### 35.5.18 CANn\_IF1IFC - Message Object Interrupt Flag Clear Register

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>
0	STATUS	0	(R)W1	<b>Clear STATUS Interrupt Flag</b>  Write 1 to clear the STATUS interrupt flag. Reading returns the value of the IF and clears the corresponding interrupt flags (This feature must be enabled globally in MSC.).

## 35.5.19 CANn\_IF1IEN - Status Interrupt Enable Register

Offset	Bit Position																																
0x04C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset																																	1
Access																																	RW
Name																																	STATUS

Bit	Name	Reset	Access	Description
31:1	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
0	STATUS	1	RW	<b>STATUS Interrupt Enable</b>  Enable/disable the STATUS interrupt

## 35.5.20 CANn\_ROUTE - I/O Routing Register

Offset	Bit Position																																
0x050	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	0
Reset													0x00				0x00																
Access													RW				RW																
Name													TXLOC				RXLOC																
TXPEN																																	

Bit	Name	Reset	Access	Description																											
31:14	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																													
13:8	TXLOC	0x00	RW	<b>TX Pin Location</b>  Decides the location of the CAN_TX pin .																											
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>LOC0</td> <td>Location 0</td> </tr> <tr> <td>1</td> <td>LOC1</td> <td>Location 1</td> </tr> <tr> <td>2</td> <td>LOC2</td> <td>Location 2</td> </tr> <tr> <td>3</td> <td>LOC3</td> <td>Location 3</td> </tr> <tr> <td>4</td> <td>LOC4</td> <td>Location 4</td> </tr> <tr> <td>5</td> <td>LOC5</td> <td>Location 5</td> </tr> <tr> <td>6</td> <td>LOC6</td> <td>Location 6</td> </tr> <tr> <td>7</td> <td>LOC7</td> <td>Location 7</td> </tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6	7	LOC7	Location 7
Value	Mode	Description																													
0	LOC0	Location 0																													
1	LOC1	Location 1																													
2	LOC2	Location 2																													
3	LOC3	Location 3																													
4	LOC4	Location 4																													
5	LOC5	Location 5																													
6	LOC6	Location 6																													
7	LOC7	Location 7																													
7:2	RXLOC	0x00	RW	<b>RX Pin Location</b>  Decides the location of the CAN_RX pin .																											
				<table border="1"> <thead> <tr> <th>Value</th> <th>Mode</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>LOC0</td> <td>Location 0</td> </tr> <tr> <td>1</td> <td>LOC1</td> <td>Location 1</td> </tr> <tr> <td>2</td> <td>LOC2</td> <td>Location 2</td> </tr> <tr> <td>3</td> <td>LOC3</td> <td>Location 3</td> </tr> <tr> <td>4</td> <td>LOC4</td> <td>Location 4</td> </tr> <tr> <td>5</td> <td>LOC5</td> <td>Location 5</td> </tr> <tr> <td>6</td> <td>LOC6</td> <td>Location 6</td> </tr> <tr> <td>7</td> <td>LOC7</td> <td>Location 7</td> </tr> </tbody> </table>	Value	Mode	Description	0	LOC0	Location 0	1	LOC1	Location 1	2	LOC2	Location 2	3	LOC3	Location 3	4	LOC4	Location 4	5	LOC5	Location 5	6	LOC6	Location 6	7	LOC7	Location 7
Value	Mode	Description																													
0	LOC0	Location 0																													
1	LOC1	Location 1																													
2	LOC2	Location 2																													
3	LOC3	Location 3																													
4	LOC4	Location 4																													
5	LOC5	Location 5																													
6	LOC6	Location 6																													
7	LOC7	Location 7																													
1	Reserved	To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a>																													
0	TXPEN	0	RW	<b>TX Pin Enable</b>  When Enabled the CAN_TX pin is enabled.																											

Bit	Name	Reset	Access	Description
	Value			Description
0				The CAN_TX pin is disabled
1				The CAN_TX pin is enabled

### 35.5.21 CANn\_MIRx\_CMDMASK - Interface Command Mask Register

Bit	Name	Reset	Access	Description									
31:8	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>									
7	WRRD	0	RW	<b>Write/Read RAM</b>									
				The control bits of the MIRx Command Mask Register specify the transfer direction and select which of the MIRx Message Buffer Registers are source or target of the data transfer. The other bits of MIRs Command Mask Register have different functions depending on the transfer direction.									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>READ</td><td>Transfer data from the Message Object addressed by the Command Request Register into the selected Message Buffer Registers.</td></tr> <tr> <td>1</td><td>WRITE</td><td>Transfer data from the selected Message Buffer Registers to the Message Object addressed by the Command Request Register.</td></tr> </tbody> </table>	Value	Mode	Description	0	READ	Transfer data from the Message Object addressed by the Command Request Register into the selected Message Buffer Registers.	1	WRITE	Transfer data from the selected Message Buffer Registers to the Message Object addressed by the Command Request Register.
Value	Mode	Description											
0	READ	Transfer data from the Message Object addressed by the Command Request Register into the selected Message Buffer Registers.											
1	WRITE	Transfer data from the selected Message Buffer Registers to the Message Object addressed by the Command Request Register.											
6	MASKACC	0	RW	<b>Access Mask Bits</b>									
5	ARBACC	0	RW	<b>Access Arbitration Bits</b>									
4	CONTROL	0	RW	<b>Access Control Bits</b>									
3	CLRINTPND	0	RW	<b>Clear Interrupt Pending Bit</b>									
				A read access to a Message Object can be combined with the clearing of the control bits INTPND and DATAVALID. The values of these bits transferred to the MIRx Message Control Register always reflect the status before clearing these bits.									
2	TXRQSTNEWDAT	0	RW	<b>Transmission Request Bit/ New Data Bit</b>									
				If a transmission is requested by programming bit TXRQSTNEWDAT in the MIRx Command Mask Register, bit TXRQST in the MIRx Message Control Register will be ignored									
1	DATAA	0	RW	<b>Access Data Bytes 0-3</b>									
0	DATAB	0	RW	<b>CC Channel Mode</b>									
				These bits select the mode for Compare/Capture channel.									

## 35.5.22 CANn\_MIRx\_MASK - Interface Mask Register

Offset	Bit Position																																
0x064	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0	
Reset	1	1																															
Access	RW	RW																	RW														
Name	MXTD	MDIR																	MASK														
Bit	Name		Reset	Access	Description																												
31	MXTD		1	RW	<b>Mask Extended Identifier</b>																												
30	MDIR		1	RW	<b>Mask Message Direction</b>																												
29	Reserved		<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>																														
28:0	MASK		0x1FFFFFFF		RW	<b>Identifier Mask</b>																											

### 35.5.23 CANn\_MIRx\_ARB - Interface Arbitration Register

Bit	Name	Reset	Access	Description									
31	MSGVAL	0	RW	<b>Message Valid</b> The CPU must reset the MSGVAL bit of all unused Messages Objects during the initialization before it resets bit INIT in the CAN Control Register. This bit must also be reset before the identifier id[28:0], the control bits XTD, DIR, or the Data Length Code dlc[3:0] are modified, or if the Messages Object is no longer required.									
30	XTD	0	RW	<b>Extended Identifier</b>									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>STD</td><td>The 11-bit (standard) Identifier will be used for this Message Object.</td></tr> <tr> <td>1</td><td>EXT</td><td>The 29-bit (extended) Identifier will be used for this Message Object.</td></tr> </tbody> </table>	Value	Mode	Description	0	STD	The 11-bit (standard) Identifier will be used for this Message Object.	1	EXT	The 29-bit (extended) Identifier will be used for this Message Object.
Value	Mode	Description											
0	STD	The 11-bit (standard) Identifier will be used for this Message Object.											
1	EXT	The 29-bit (extended) Identifier will be used for this Message Object.											
29	DIR	0	RW	<b>Message Direction</b>									
				<table border="1"> <thead> <tr> <th>Value</th><th>Mode</th><th>Description</th></tr> </thead> <tbody> <tr> <td>0</td><td>RX</td><td>On TXRQST, a Remote Frame with the identifier of this Message Object is transmitted. On reception of a Data Frame with matching identifier, that message is stored in this Message Object.</td></tr> <tr> <td>1</td><td>TX</td><td>On TXRQST, the respective Message Object is transmitted as a Data Frame. On reception of a Remote Frame with matching identifier, the TXRQST bit of this Message Object is set (if RMTEN = 1).</td></tr> </tbody> </table>	Value	Mode	Description	0	RX	On TXRQST, a Remote Frame with the identifier of this Message Object is transmitted. On reception of a Data Frame with matching identifier, that message is stored in this Message Object.	1	TX	On TXRQST, the respective Message Object is transmitted as a Data Frame. On reception of a Remote Frame with matching identifier, the TXRQST bit of this Message Object is set (if RMTEN = 1).
Value	Mode	Description											
0	RX	On TXRQST, a Remote Frame with the identifier of this Message Object is transmitted. On reception of a Data Frame with matching identifier, that message is stored in this Message Object.											
1	TX	On TXRQST, the respective Message Object is transmitted as a Data Frame. On reception of a Remote Frame with matching identifier, the TXRQST bit of this Message Object is set (if RMTEN = 1).											
28:0	ID	0x00000000	RW	<b>Message Identifier</b> ID[28:0] is 29-bit Identifier for Extended Frame. ID[28:18] is 11-bit Identifier for Standard Frame. When 11-bit (standard) Identifiers are used for a Message Object, the identifiers of received Data Frames are written into bits ID[28:18]. For acceptance filtering, only these bits together with mask bits MSK[28:18] are considered. The Arbitration Registers ID[28:0], XTD, and DIR are used to define the identifier and type of outgoing messages and are used (together with the mask registers MSK[28:0], MXTD, and MDIR) for acceptance filtering of incoming messages. A received message is stored into the valid Message Object with matching identifier and direction=receive (Data Frame) or direction=transmit (Remote Frame). Extended frames can be stored only in Message Objects with XTD=one, standard frames in Message Objects with XTD=zero. If a received message (Data Frame or Remote Frame) matches with more than one valid Message Object, it is stored into that with the lowest message number.									

## 35.5.24 CANn\_MIRx\_CTRL - Interface Message Control Register

Offset	Bit Position																
0x06C	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	0
<b>Reset</b>																	
<b>Access</b>																	
<b>Name</b>																	

Bit	Name	Reset	Access	Description
31:16	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
15	DATAVALID	0	RWH	<b>New Data</b>
14	MESSAGEEOF	0	RWH	<b>Message Lost (only Valid for Message Objects With Direction = Receive)</b>
13	INTPND	0	RW	<b>Interrupt Pending</b>
12	UMASK	0	RW	<b>Use Acceptance Mask</b>  If the UMASK bit is set to one, the Message Object's mask bits have to be programmed during initialization of the Message Object before MSGVAL is set to one.
11	TXIE	0	RW	<b>Transmit Interrupt Enable</b>
10	RXIE	0	RW	<b>Receive Interrupt Enable</b>
9	RMTEN	0	RW	<b>Remote Enable</b>
8	TXRQST	0	RW	<b>Transmit Request</b>
7	EOB	0	RW	<b>End of Buffer</b>  This bit is used to concatenate two or more Message Objects (up to 32) to build a FIFO Buffer. For single Message Objects (not belonging to a FIFO Buffer) this bit must always be set to one.
6:4	<i>Reserved</i>	<i>To ensure compatibility with future devices, always write bits to 0. More information in <a href="#">1.2 Conventions</a></i>		
3:0	DLC	0x0	RW	<b>Data Length Code</b>  The Data Length Code of a Message Object must be defined the same as in all the corresponding objects with the same identifier at other nodes. When the Message Handler stores a data frame, it will write the DLC to the value given by the received message. 0-8: Data Frame has 0-8 data bytes. 9-15: Data Frame has 8 data bytes.

## 35.5.25 CANn\_MIRx\_DATA1 - Interface Data a Register

Offset	Bit Position																															
0x070	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00								0x00								0x00								0x00							
Access	RW								RW								RW								RW							
Name	DATA3								DATA2								DATA1								DATA0							

Bit	Name	Reset	Access	Description
31:24	DATA3	0x00	RW	Fourth Byte of CAN Data Frame
23:16	DATA2	0x00	RW	Third Byte of CAN Data Frame
15:8	DATA1	0x00	RW	Second Byte of CAN Data Frame
7:0	DATA0	0x00	RW	First Byte of CAN Data Frame

## 35.5.26 CANn\_MIRx\_DATAH - Interface Data B Register

Offset	Bit Position																															
0x074	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Reset	0x00								0x00								0x00								0x00							
Access	RW								RW								RW								RW							
Name	DATA7								DATA6								DATA5								DATA4							

Bit	Name	Reset	Access	Description
31:24	DATA7	0x00	RW	Eight Byte of CAN Data Frame
23:16	DATA6	0x00	RW	Seventh Byte of CAN Data Frame
15:8	DATA5	0x00	RW	Sixth Byte of CAN Data Frame
7:0	DATA4	0x00	RW	Fifth Byte of CAN Data Frame

## 35.5.27 CANn\_MIRx\_CMDREQ - Interface Command Request Register

Offset	Bit Position																															
0x078	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
<b>Reset</b>																										0x01						
<b>Access</b>																										RW						
<b>Name</b>																										MSGNUM						

Bit	Name	Reset	Access	Description
31:16	Reserved			<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
15	BUSY	0	R	<b>Busy Flag</b>

A message transfer is started as soon as the CPU has written the message number to the Command Request Register. With this write operation the busy bit is automatically set to '1' and signal CAN\_WAIT\_B is pulled LOW to notify the CPU that a transfer is in progress. After a wait time of 3 to 6 CAN\_CLK periods, the transfer between the Interface Register and the Message RAM has completed. The busy bit is set back to zero and CAN\_WAIT\_B is set back to HIGH.

Value	Mode	Description
0	FALSE	Reset to zero when read/write action has finished.
1	TRUE	Set to one when writing to the MIRx Command Request Register.

14:6	Reserved	<i>To ensure compatibility with future devices, always write bits to 0. More information in 1.2 Conventions</i>
------	----------	---

5:0	MSGNUM	0x01	RW	<b>Message Number</b>
-----	--------	------	----	-----------------------

When a Message Number that is not valid is written into the Command Request Register, the Message Number will be transformed into a valid value and that Message Object will be transferred. There are 32 Message Objects in the Message RAM. To avoid conflicts between CPU accessing to the Message RAM and CAN message reception and transmission, the CPU cannot directly access the Message Objects, these accesses are handled via the MIRx Interface Registers. 1-32: Valid Message Number, the Message Object in the Message RAM is selected for data transfer. 0: Not a valid Message Number, interpreted as 32. 33-63: Not a valid Message Number, interpreted as 1-31.

## 36. Revision History

### Revision 1.1

March, 2021

- Added description of VLP and ACMP startup behavior when External Override Interface is enabled.
- Updated the Notes in [Table 10.8 Oscillator and Clock Availability in Energy Modes on page 321](#).
- Updated the Note under [21.3.1.6 Underflow/Overflow From Neighboring Timer](#).
- Added a Note to [27.3.3.2 Scan Mode](#).
- Updated [27.3.10.9 Temperature Measurement](#) and added an additional Note.
- Made minor changes and fixed typos throughout the document.

### Revision 1.0

November, 2018

- [6.3.8 Instruction Cache](#): Added note about icache flush on bus fault events.
- Changes to Note: element formatting throughout document.
- [Table 9.3 EMU Wake-Up Triggers from Low Energy Modes on page 233](#): Added missing wake-up trigger sources.
- [9.3.13 Powering Off SRAM Blocks](#): Extended description with additional detail.
- [Figure 10.2 CMU Overview - Low Frequency Portion on page 298](#): Corrected clock tree diagram to show CSEN and SYSTICK options.
- [10. CMU - Clock Management Unit](#) : HFXO control register descriptions clarified for startup and steady state configuration.
- [14.3.1.3 Configurable PRS Logic](#): Clarified ANDNEXT and ORPREG behavior for first and last PRS channels.
- [14.3.2 Producers](#): Added more detail about GPIO producer source.
- [14.3.5 DMA Request on PRS](#): Fixed incorrect bit / register names and clarified signals for DMA are PRSRQE0 and PRSREQ1.
- Added section for [19. UART - Universal Asynchronous Receiver/ Transmitter](#).
- [27.3.10.2 Repetitive Mode](#): Added description of timing for SYNC mode and REPDELAY setting.

### Revision 0.5

February, 2018

Initial version.

**Appendix 1. Abbreviations**

This section lists abbreviations used in this document.

**Table 1.1. Abbreviations**

<b>Abbreviation</b>	<b>Description</b>
ACMP	Analog Comparator
ADC	Analog to Digital Converter
AHB	AMBA Advanced High-performance Bus. AMBA is short for "Advanced Microcontroller Bus Architecture".
APB	AMBA Advanced Peripheral Bus. AMBA is short for "Advanced Microcontroller Bus Architecture".
ALE	Address Latch Enable
AUXHFRCO	Auxiliary High Frequency RC Oscillator.
CC	Compare / Capture
CIC	Cascaded Integrator Comb
CLK	Clock
CMD	Command
CMU	Clock Management Unit
CTRL	Control
DAC	Digital to Analog Converter
DBG	Debug
DMA	Direct Memory Access
DRD	Dual Role Device
DTI	Dead Time Insertion
EBI	External Bus Interface
EFM	Energy Friendly Microcontroller
EM	Energy Mode
EM0 Active	Energy Mode 0 (also called active mode)
EM1 Sleep to EM4 Hibernate/Shutoff	Energy Mode 1 to Energy Mode 4 (also called low energy modes)
EMU	Energy Management Unit
ENOB	Effective Number of Bits
FS	Full-speed
GPIO	General Purpose Input / Output
HFRCO	High Frequency RC Oscillator
HFXO	High Frequency Crystal Oscillator
HW	Hardware
I <sup>2</sup> C	Inter-Integrated Circuit interface
LCD	Liquid Crystal Display
LESENSE	Low Energy Sensor Interface

Abbreviation	Description
LETIMER	Low Energy Timer
LEUART	Low Energy Universal Asynchronous Receiver Transmitter
LFRCO	Low Frequency RC Oscillator
LFXO	Low Frequency Crystal Oscillator
LS	Low-speed
MAC	Media Access Controller
NVIC	Nested Vector Interrupt Controller
OSR	Oversampling Ratio
OTG	On-the-go
PCNT	Pulse Counter
PCM	Pulse Code Modulation
PDM	Pulse Density Modulation
PHY	Physical Layer
PRS	Peripheral Reflex System
PWM	Pulse Width Modulation
RC	Resistance and Capacitance
RMU	Reset Management Unit
RTC	Real Time Clock
SAR	Successive Approximation Register
SOF	Start of Frame
SPI	Serial Peripheral Interface
SW	Software
TRNG	True Random Number Generator
UART	Universal Asynchronous Receiver Transmitter
USART	Universal Synchronous Asynchronous Receiver Transmitter
USB	Universal Serial Bus
VMON	Voltage supply monitor
WDOG	Watchdog timer
XTAL	Crystal

# Simplicity Studio

One-click access to MCU and wireless tools, documentation, software, source code libraries & more. Available for Windows, Mac and Linux!



## IoT Portfolio

[www.silabs.com/IoT](http://www.silabs.com/IoT)



## SW/HW

[www.silabs.com/simplicity](http://www.silabs.com/simplicity)



## Quality

[www.silabs.com/quality](http://www.silabs.com/quality)



## Support & Community

[www.silabs.com/community](http://www.silabs.com/community)

### Disclaimer

Silicon Labs intends to provide customers with the latest, accurate, and in-depth documentation of all peripherals and modules available for system and software implementers using or intending to use the Silicon Labs products. Characterization data, available modules and peripherals, memory sizes and memory addresses refer to each specific device, and "Typical" parameters provided can and do vary in different applications. Application examples described herein are for illustrative purposes only. Silicon Labs reserves the right to make changes without further notice to the product information, specifications, and descriptions herein, and does not give warranties as to the accuracy or completeness of the included information. Without prior notification, Silicon Labs may update product firmware during the manufacturing process for security or reliability reasons. Such changes will not alter the specifications or the performance of the product. Silicon Labs shall have no liability for the consequences of use of the information supplied in this document. This document does not imply or expressly grant any license to design or fabricate any integrated circuits. The products are not designed or authorized to be used within any FDA Class III devices, applications for which FDA premarket approval is required or Life Support Systems without the specific written consent of Silicon Labs. A "Life Support System" is any product or system intended to support or sustain life and/or health, which, if it fails, can be reasonably expected to result in significant personal injury or death. Silicon Labs products are not designed or authorized for military applications. Silicon Labs products shall under no circumstances be used in weapons of mass destruction including (but not limited to) nuclear, biological or chemical weapons, or missiles capable of delivering such weapons. Silicon Labs disclaims all express and implied warranties and shall not be responsible or liable for any injuries or damages related to use of a Silicon Labs product in such unauthorized applications.

**Note: This content may contain offensive terminology that is now obsolete. Silicon Labs is replacing these terms with inclusive language wherever possible. For more information, visit [www.silabs.com/about-us/inclusive-lexicon-project](http://www.silabs.com/about-us/inclusive-lexicon-project)**

### Trademark Information

Silicon Laboratories Inc.<sup>®</sup>, Silicon Laboratories<sup>®</sup>, Silicon Labs<sup>®</sup>, SiLabs<sup>®</sup> and the Silicon Labs logo<sup>®</sup>, Bluegiga<sup>®</sup>, Bluegiga Logo<sup>®</sup>, Clockbuilder<sup>®</sup>, CMEMS<sup>®</sup>, DSPLL<sup>®</sup>, EFM<sup>®</sup>, EFM32<sup>®</sup>, EFR, Ember<sup>®</sup>, Energy Micro, Energy Micro logo and combinations thereof, "the world's most energy friendly microcontrollers", Ember<sup>®</sup>, EZLink<sup>®</sup>, EZRadio<sup>®</sup>, EZRadioPRO<sup>®</sup>, Gecko<sup>®</sup>, Gecko OS, Gecko OS Studio, ISOmodem<sup>®</sup>, Precision32<sup>®</sup>, ProSLIC<sup>®</sup>, Simplicity Studio<sup>®</sup>, SiPHY<sup>®</sup>, Telegesis, the Telegesis Logo<sup>®</sup>, USBXpress<sup>®</sup>, Zentri, the Zentri logo and Zentri DMS, Z-Wave<sup>®</sup>, and others are trademarks or registered trademarks of Silicon Labs. ARM, CORTEX, Cortex-M3 and THUMB are trademarks or registered trademarks of ARM Holdings. Keil is a registered trademark of ARM Limited. Wi-Fi is a registered trademark of the Wi-Fi Alliance. All other products or brand names mentioned herein are trademarks of their respective holders.